





USER'S MANUAL

UM343-1
Rev: 2
March 1999



MG001470

XTC™ Series 343

Temperature Transmitters

TABLE OF CONTENTS

SECTION AND TITLE	PAGE
1.0 INTRODUCTION	1-1
1.1 SECTION CONTENTS.....	1-1
1.2 PRODUCT DESCRIPTION	1-3
1.3 CONFIGURATION.....	1-4
1.4 PRODUCT SUPPORT	1-4
2.0 MODEL 275 UNIVERSAL HART COMMUNICATOR.....	2-1
2.1 INTRODUCTION	2-1
2.2 COMMUNICATOR CONNECTIONS	2-1
2.3 CONTROLS OVERVIEW	2-4
2.3.1 Liquid Crystal Display	2-4
2.3.2 Software-Defined Function Keys	2-4
2.3.3 Action Keys	2-6
2.3.4 Alphanumeric and Shift Keys	2-7
2.3.4.1 Rapid Selection of Menu Options.....	2-7
2.3.4.2 Data Entry	2-7
2.4 GETTING TO KNOW THE COMMUNICATOR.....	2-8
2.4.1 Display Icons	2-8
2.4.2 Menu Structure	2-8
2.4.3 Reviewing Installed Devices	2-9
2.5 MAIN MENU.....	2-10
2.5.1 Offline Menu.....	2-10
2.5.1.1 New Configuration	2-11
2.5.1.2 Saved Configuration.....	2-14
2.5.2 Online Menu	2-16
2.5.3 Frequency Device Menu	2-19
2.5.4 Utility Menu.....	2-19
2.5.4.1 Configure Communicator	2-19
2.5.4.2 System Information	2-20
2.5.4.3 Listen for PC.....	2-20
2.5.4.4 Storage Location	2-20
2.5.4.5 Simulation.....	2-20
2.6 USING THE QUICK ACCESS KEY.....	2-21
2.6.1 Adding Quick Access Key Options	2-22
2.6.2 Deleting Quick Access Key Options.....	2-23
3.0 COMMISSIONING AND BENCH TESTING.....	3-1
3.1 COMMISSIONING PROCEDURE.....	3-1
3.1.1 Test Equipment Needed.....	3-1
3.2 ESTABLISHING COMMUNICATION	3-3
3.3 TESTING THE TRANSMITTER	3-3
3.4 REVIEWING CONFIGURATION DATA.....	3-4
3.5 CHECKING TRANSMITTER OUTPUT	3-4

4.0	INSTALLATION	4-1
4.1	EQUIPMENT DELIVERY AND HANDLING.....	4-1
4.1.1	Factory Shipment	4-1
4.1.2	Receipt of Shipment	4-1
4.1.3	Storage	4-1
4.2	ENVIRONMENTAL CONSIDERATIONS.....	4-1
4.3	INSTALLATION CONSIDERATIONS	4-2
4.3.1	Mechanical.....	4-2
4.3.2	Electrical.....	4-2
4.3.3	Transmitter Operating Mode and Network Type	4-3
4.3.3.1	Analog Mode.....	4-3
4.3.3.2	Digital Mode	4-3
4.3.4	Power Supply Requirements	4-7
4.3.4.1	Point-To-Point Network	4-8
4.3.4.2	Multi-Drop Network.....	4-8
4.3.5	Cable Capacitance and Maximum Length	4-9
4.3.5.1	Cable Capacitance.....	4-9
4.3.5.2	Maximum Cable Length Calculation.....	4-9
4.3.6	Network Junctions.....	4-10
4.3.7	Safety Barriers	4-10
4.3.8	Connection of Miscellaneous Hardware	4-11
4.3.9	Determine Sensor Cable Requirements.....	4-12
4.3.10	2-Wire RTD Accuracy Limitation	4-13
4.3.11	Shielding and Grounding	4-14
4.4	MECHANICAL INSTALLATION.....	4-15
4.4.1	Pipe Mounting.....	4-15
4.4.2	Flat Surface Mounting.....	4-18
4.4.3	Direct Mounting to Process	4-18
4.4.4	Local Display Installation and Removal.....	4-21
4.4.5	Electrical Conduit and Cable Installation	4-22
4.4.5.1	Conduit	4-22
4.4.5.2	Signal and Sensor Cables.....	4-22
4.4.5.3	Access to Transmitter Terminal Compartment	4-23
4.5	ELECTRICAL INSTALLATION.....	4-24
5.0	CONFIGURATION AND OPERATION.....	5-1
5.1	REMOTE CONFIGURATION AND OPERATION (Model 275 Hart Communicator).....	5-1
5.1.1	Function Blocks	5-1
5.1.2	Recommended Configuration Procedure.....	5-1
5.1.3	Write-Protect Block.....	5-2
5.1.4	Sensor Input Block.....	5-2
5.1.4.1	Sensor Type Settings	5-2
5.1.4.2	Measured Variable Units	5-3
5.1.4.3	Measure Variable Low/High.....	5-3
5.1.4.4	Damping, Smart Smoothing & Validation Settings.....	5-3
5.1.4.5	Line Frequency Filter Setting.....	5-4
5.1.4.6	Active Input	5-4
5.1.5	Characterizer Block.....	5-5
5.1.6	Operator Display Block.....	5-6
5.1.6.1	Display Setting.....	5-6

5.1.6.2 Display Label.....	5-6
5.1.6.3 Display Language.....	5-6
5.1.6.4 Local Pushbuttons.....	5-6
5.1.7 Transmitter ID Block	5-7
5.1.7.1 Tag, Descriptor, Message & Sensor Serial Number.....	5-7
5.1.7.2 Date.....	5-7
5.1.7.3 Polling Address.....	5-7
5.1.8 Output Block.....	5-8
5.1.8.1 Sensor Failsafe Detection	5-8
5.1.8.2 Failsafe	5-8
5.2 QUICK ACCESS KEY FUNCTIONS	5-9
5.2.1 XMTR Variables	5-9
5.2.2 Status.....	5-9
5.2.3 Range XMTR	5-10
5.3 LOCAL CONFIGURATION (SmartDisplay Pushbuttons).....	5-11
5.3.1 Available Parameters.....	5-11
5.3.2 Configuration Example.....	5-11
6.0 POST INSTALLATION CHECKOUT.....	6-1
6.1 EQUIPMENT REQUIRED.....	6-1
6.2 INSTALLATION REVIEW	6-1
6.3 EQUIPMENT CONNECTION	6-1
6.4 VERIFICATION	6-2
6.4.1 Communication Test	6-2
6.4.2 Communications Error Check.....	6-3
6.4.3 Verify Analog Output Signal	6-3
7.0 CALIBRATION AND MAINTENANCE.....	7-1
7.1 CALIBRATION	7-1
7.1.1 Equipment Required.....	7-1
7.1.2 Calibrate Digital-to-Analog Converter (DAC) Using 275 HART Communicator	7-2
7.1.3 Calibrate Digital-to-Analog Converter (DAC) Using SmartDisplay Pushbuttons	7-4
7.1.4 Reset Digital to Analog Converter (DAC).....	7-5
7.1.5 2-Wire RTD Lead Wire Trim	7-5
7.2 PREVENTIVE MAINTENANCE.....	7-6
7.2.1 Tool and Equipment Requirements	7-6
7.2.2 Transmitter Exterior Inspection, Model 343F Only	7-6
7.2.3 Transmitter Exterior Cleaning, Model 343F Only	7-6
7.2.4 Transmitter Enclosure Interior Inspection, Model 343F Only.....	7-7
7.2.5 Transmitter Calibration	7-7
7.3 TROUBLESHOOTING.....	7-7
7.3.1 Analog Output	7-7
7.3.2 Digital Output (Communication)	7-8
7.3.3 Diagnosing a Defective Transmitter.....	7-9
7.3.4 Enclosure Thread Lubrication.....	7-9
7.4 NON-FIELD-REPLACEABLE ITEMS.....	7-10
7.5 TRANSMITTER REPLACEMENT	7-10
7.6 MAINTENANCE RECORDS	7-11
7.7 RECOMMENDED SPARE AND REPLACEMENT PARTS.....	7-10

7.8 SOFTWARE COMPATIBILITY	7-12
7.9 RETURN SHIPMENT	7-12
8.0 MODEL DESIGNATION AND SPECIFICATIONS	8-1
8.1 MODEL DESIGNATION.....	8-1
8.2 ACCESSORIES	8-2
8.3 SPECIFICATIONS	8-4
8.3.1 Mechanical.....	8-4
8.3.1.1 Model 343D (DIN Rail)	8-4
8.3.1.2 Model 343F (Field-Mount Enclosure)	8-4
8.3.2 Functional and Performance	8-6
8.3.3 Two-Wire Cable.....	8-7
8.3.4 Sensor Inputs	8-8
8.3.5 Environmental.....	8-8
8.3.6 Hazardous Area Classification.....	8-9
8.3.7 Special Conditions For Safe Use.....	8-9
9.0 GLOSSARY.....	9-1
APPENDIX A - FUNCTION BLOCKS.....	A-1
A.1 WRITE PROTECT BLOCK.....	A-1
A.2 SENSOR INPUT BLOCK	A-1
A.3 CHARACTERIZER.....	A-5
A.4 OPERATOR DISPLAY BLOCK	A-5
A.5 TRANSMITTER ID BLOCK	A-6
A.6 OUTPUT BLOCK	A-7
APPENDIX B - TRANSMITTER CONFIGURATION DOCUMENTATION	B-1
B.1 HOW TO USE THIS APENDIX.....	B-1
WARRANTY	
PARTS LIST, PL343-1	

LIST OF ILLUSTRATIONS

FIGURE AND TITLE	PAGE
1-1 Model 343D and Model 343F.....	1-2
1-2 Terminal Connections	1-3
2-1 Model 275 Universal HART Communicator.....	2-2
2-2 HART Connections to a Transmitter Loop	2-3
2-3 Communicator Display Icons	2-8
2-4 Offline Menu Tree	2-11
2-5 Online Menu Tree for Model 343 Transmitter	2-17
2-6 Generic Online Menu Tree	2-18
3-1 Bench Test Connections	3-2
3-2 Field Test Connections.....	3-2

4-1 Point-To-Point Network	4-4
4-2 Model 353 or Model 354 and Model 343 Connections	4-5
4-3 Multi-Drop Network	4-6
4-4 Supply Voltage Versus Network Resistance.....	4-7
4-5 Dimensions, Model 343 on a Universal Mounting Bracket	4-16
4-6 Model 343 on a 2" Pipe Mount Bracket.....	4-17
4-7 Transmitter-To-Process Mounting.....	4-19
4-8 Sensor Assembly.....	4-20
4-9 Rotating a SmartDisplay or LCD Display	4-21
4-10 Conduit Drain and Explosion Proof Installations.....	4-23
4-11 Signal, Sensor, HART Communicator and Display Terminals.....	4-25
4-12 Model 343 Sensor Wiring.....	4-26
6-1 Equipment Connections for System Checkout	6-2
7-1 Bench Test Connections	7-3
7-2 Field Test Connections	7-3
8-1 Typical TC and RTD Thermowell Assemblies without Heads	8-3
8-2 Typical TC or RTD Assembly with Head.....	8-3
8-3 Model 343D Dimensions.....	8-4
8-4 Model 343F Dimensions	8-5

LIST OF TABLES

TABLE AND TITLE	PAGE
2.1 Function Keys with Their Labels and Actions Performed	2-5
2.2 Moore Products Co. Device Descriptions.....	2-10
4.1 Operating Mode and Network.....	4-3
4.2 RTD Wire Characteristics	4-27
4.3 ANSI Thermocouple And Extension Grade Wire Characteristics.....	4-27
5.1 XMTR Variable Parameters.....	5-9
5.2 Status Parameters.....	5-9
5.3 Range XMTR Parameters	5-10
5.4 Local Configuration Parameters	5-11
8.1 Model 343 Model Designation.....	8-1
8.2 General Accessories	8-2
8.3 Thermal Sensors	8-2
8.4 Sensors: Type, Range and Accuracy	8-6

CHANGES FOR REV 2, JUNE 1998

Significant changes are listed below and are indicated in text by change bars in the page margins.

Section 8 Subsection 8.3.6 was changed to indicate CE approval and a Declaration of Conformity was added. Subsection 8.3.7 Special Conditions for Safe Use was added.

This version of UM343-1 was produced March 1999 to permit creation of a Portable Document Format (PDF) file. It contains several updates to the June 1998 copy. Some simply allow the file to be processed. Content changes include: A Note box was added to Table 2.1, Section 4.5 Electrical Installation was updated with an ESD statement and expanded wiring access steps, Section 7.1.3 was renumbered, and Table 8.1 was updated. Content changes are identified by change bars in the page margins. The cover date has been changed but the page dates were not changed.

*The Moore Products Co. logo and APACS are registered trademarks of Moore Products Co.
XTC and SmartDisplay are trademarks of Moore Products Co.
Other trademarks are the property of their respective owners.*

Moore Products Co. assumes no liability for errors or omissions in this and any attached documents or for the application and use of information included in this and any attached documents. The information herein is subject to change without notice.

Procedures in this document have been reviewed for compliance with applicable approval agency requirements and are considered sound practice. Neither Moore Products Co. nor these agencies are responsible for repairs made by the user.



1.0 INTRODUCTION

This User's Manual is for the XTC™ Model 343 Smart Temperature Transmitter. It covers the Model 343D DIN rail mount and Model 343F field mount versions.

The information needed to bench test, install, configure, system test, and service a transmitter is included in this User's Manual. Figure 1-1 shows both 343 models. Figure 1-2 shows the wiring terminations.

IMPORTANT

Save this User's Manual for installing, configuring, operating and servicing a Model 343 transmitter.

1.1 SECTION CONTENTS

Nine sections and three appendices comprise this Manual. A brief description of each section follows.

Section 1, INTRODUCTION, describes each section in this Manual and provides a brief description of the Model 343 Smart Temperature Transmitter.

Section 2, MODEL 275 HART COMMUNICATOR, describes use of the communicator to test, configure, and calibrate a transmitter.

Section 3, COMMISSIONING AND BENCH TESTING, provides procedures to perform a bench test of the transmitter to ensure proper operation of all functions.

Section 4, INSTALLATION, furnishes specific information for mechanical and electrical installation.

Section 5, CONFIGURATION AND OPERATION, has HART Communicator based configuration and operation procedures. Local configuration using the SmartDisplay™ pushbuttons is also described.


Section 6, POST INSTALLATION CHECKOUT, describes how to confirm that the transmitter has been set-up and installed correctly.

Section 7, CALIBRATION AND MAINTENANCE, provides calibration procedures. It also furnishes preventive maintenance, troubleshooting, and assembly replacement procedures. A spare and replacement parts list is provided at the back of this Manual.


Section 8, MODEL DESIGNATION AND SPECIFICATIONS, describes transmitter model numbers, and contains mechanical, functional, performance, and environmental specifications.

IMPORTANT

Before installing or servicing a transmitter, read the information on the transmitter nameplate and the model number description in Section 8 to ensure that the correct model is at hand and that the correct procedures are followed.



Model 343D



Model 343F

FIGURE 1-1 Model 343D and Model 343F

Section 9, GLOSSARY, contains definitions of various transmitter related terms.

Appendix A, FUNCTION BLOCKS, describes transmitter function blocks and the parameters available.

Appendix B, CONFIGURATION DOCUMENTATION, contains a table for recording the transmitter configuration.

WARRANTY contains the product warranty statements and information concerning servicing of the product during the warranty period.

PARTS LIST shows an exploded view of the transmitter and a list of on-hand spare parts and field replaceable parts.




FIGURE 1-2 Terminal Connections

1.2 PRODUCT DESCRIPTION

The Model 343 Temperature Transmitter, shown in Figure 1-1, is a microprocessor-based transmitter that provides accurate, reliable temperature measurement. The Transmitter accepts an RTD, thermocouple, millivolt, slide wire or resistance sensor input. Included is a custom ASIC (Application Specific Integrated Circuit) containing standard temperature calibration curves for J, K, L, C, U, E, T, R, S, B and N type thermocouples and SAMA/DIN curves for a 100 ohm Platinum RTD. The sensed signal is linearized and corrected for ambient temperature changes by the microprocessor and then converted to an equivalent 4-20 mA or HART® (Highway Addressable Remote Transducer) signal.

The analog output signal, HART digital communications, and 24 Vdc power (typical) are carried on a twisted-pair 2-wire cable. The HART digital communication signals are superimposed (AC coupled) on the 4-20 mA loop current allowing communication between the Transmitter and a HART master without

bumping the analog output signal. A digital meter is available for local indication of the transmitter output. Loop and sensor wiring terminals are shown in Figure 1-2.

A transmitter can be configured to operate in either analog mode or digital mode, for a Point-To-Point or a Multi-Drop network respectively.

ANALOG MODE: A single transmitter is connected to a controller, recorder or other field device. A loop known as a Point-To-Point Network interconnects the instruments. The transmitter's output is the process variable and it is sent to a controller or recorder using a standard 4-20 mA analog current.

The HART protocol is used for communication between the transmitter and a Model 275 HART Communicator, a personal computer running configuration software or other remote device. A typical communication may be to: transfer a new or edited configuration, remotely monitor the process variable, or service a transmitter.

DIGITAL MODE: One to fifteen transmitters can be parallel connected to a Multi-Drop Network using only twisted-pair cable. The HART protocol is employed to send process variable information to a HART-compatible controller, recorder, or other device.

1.3 CONFIGURATION

A smart transmitter must be configured before being used. Each transmitter is shipped with either a default configuration or, if specified at time of order, a custom configuration defined by the user. A default configuration may need to be edited by the user before the transmitter is used in a loop.

1.4 PRODUCT SUPPORT

Product support can be obtained from the Moore Products Co. Technical Information Center (TIC). TIC is a customer service center that provides direct phone support on technical issues related to the functionality, application, and integration of all products manufactured by Moore Products Co.

To contact TIC for support, either call 215-646-7400, extension 4TIC (4842) or leave a message in the bulletin board service (BBS) by calling 215-283-4958. The following information should be at hand when contacting TIC for support:

- Caller ID number, or name and company name

When you call for support for the first time, a personal caller number is assigned. This number is mailed in the form of a caller card. Having the number available when calling for support will allow the TIC representative taking the call to use the central customer database to quickly identify the caller's location and past support needs.

- Product part number or model number and version
- If there is a problem with a product's operation:
 - Is the problem intermittent or constant?
 - What steps were performed before the problem occurred?
 - What steps have been performed since the problem occurred?
 - What symptoms accompany the problem? Is an error message displayed?
 - What is the installation environment? For example:
 - type of plant and process, involved loop, control strategy, and related equipment.

- workstation or personal computer manufacturer and model, amount of memory, and operating system.

For product support outside of North America, contact your nearest Moore subsidiary. Subsidiary locations can be found at www.moore-solutions.com.



2.0 MODEL 275 UNIVERSAL HART COMMUNICATOR

The Model 275 Universal HART Communicator is a hand held interface that provides a common communication link to XTC 343 Series transmitters and other HART-compatible instruments.

This section describes HART Communicator connections, liquid crystal display, keypad, and on-line and off-line menus. It also provides short overviews of some of the Communicator's functions. The Communicator is shown in Figure 2-1. For information about the Communicator's battery pack, Memory Module, Data Pack, and maintenance procedures, refer to the manual supplied with the Communicator.

2.1 INTRODUCTION

From a wiring termination point, the HART Communicator interfaces with a Model 343 transmitter or other HART device using a 4-20 mA loop, provided a minimum load resistance of 250 Ω is present between the Communicator and the power supply. The Communicator uses the Bell 202 frequency-shift keying (FSK) technique of high-frequency digital signals imposed on a standard transmitter current loop of 4-20 mA. Because no net energy is added to the loop, HART communication does not disturb the 4-20 mA signal. The Communicator can be used in hazardous and non-hazardous locations.

WARNING

Explosions can cause death or serious injury. Before connecting the HART Communicator in an explosive atmosphere, make sure that the instruments in the loop are installed in accordance with intrinsically safe or non-incendive field wiring practices. Refer to the Communicator nameplate and the manual supplied with the Communicator for certifications and approvals before connecting.

2.2 COMMUNICATOR CONNECTIONS

The Communicator can interface with a transmitter from the control room, the instrument site, or any wiring termination point in the loop. Connections are made through loop connectors on the Communicator's connection panel (Figure 2-1). The connection panel also may have a jack for the optional NiCad battery charger, and it has a serial port for a future connection to a personal computer (PC).

To interface with a transmitter or other HART device, connect the HART Communicator in parallel with the instrument or load resistor. The connections are non-polar. For intrinsically safe FM and CSA wiring connections, see the manual supplied with the Communicator.

WARNING

Explosions can result in death or serious injury. Before making connections to the serial port or NiCad battery charger jack in an explosive atmosphere, check the Communicator nameplate and the manual supplied with the Communicator for approvals.

Figure 2-2 illustrates typical wiring connections between the HART Communicator and a loop with a Model 343 transmitter or other HART-compatible device.





FIGURE 2-1 Model 275 Universal HART Communicator



Notes:

1. HART Communicator Connections:
 Non-hazardous location - Connect as shown above.
 Hazardous location - Refer to Communicator nameplate and the Manual supplied with the Communicator for certifications and approvals before connecting.

 The HART Communicator is a non-polar device.
2. The System Power Supply may be part of the host input device or a separate device.
3. Network resistance equals the sum of the barrier resistances and the current sense resistor. Minimum value 250 Ohms, maximum value 1100 Ohms.
4. Supply and return barriers shown. Interconnect all cable shields and ground only at the barrier.

MG001220

FIGURE 2-2 HART Connections to a Transmitter Loop

A 40" (1 m) cable with a dual banana plug on one end and two mini-grabber clips on the other is provided. The dual banana plug is inserted into the top of the Communicator; the mini-grabber clips are connected to the HART clips on the Model 343 (see Figure 1-2) or to the loop's current sense resistance, usually at a receiving instrument (see Note below).

NOTE

The HART protocol requires a network (loop) resistance between 250 Ω and 1100 Ω to support communications. See Section 4.3.4 to determine resistance value and loop supply voltage.

2.3 CONTROLS OVERVIEW

As shown in Figure 2-1, the front of the HART Communicator has five major functional areas: liquid crystal display (LCD), function keys, action keys, alphanumeric keys, and shift keys. The next five sections describe how each of these functional areas is used to enter commands and display data.

2.3.1 Liquid Crystal Display

The liquid crystal display (LCD) is an 8-line by 21-character display that provides communication between the user and a connected device. When the HART Communicator is connected to a Model 343 transmitter or other HART-compatible device, the top line of the Online menu displays the model name of the device and its tag. A typical display is shown below:

```
MPCO 343:TT100
Online          ←
1->Loop Override
2 Calibrate/Test
3 Configure Xmtr

HELP | SAVE
```

The bottom line of each menu is reserved for dynamic labels for the software-defined function keys, F1-F4, which are found directly below the display. More information on software-defined function keys is given in the next section.

2.3.2 Software-Defined Function Keys

The four software-defined function keys (soft keys), located below the LCD and marked F1 through F4, are used to perform software functions as indicated by the dynamic labels. Pressing the function key immediately beneath a label activates the displayed function.

The label appearing above a function key indicates the function of that key for the current menu. For example, in menus providing access to on-line help, the HELP label appears above the F1 key. In menus providing access to the Online menu, the HOME label appears above the F3 key. Table 2-1 lists these labels and describes what happens when each function key is pressed.

TABLE 2-1 Function Keys With Their Labels And Actions Performed

F1	F2	F3	F4
HELP access on-line help	ON/OFF activate or deactivate a bit-enumerated binary variable	ABORT terminate current task	OK acknowledge information on the LCD
RETRY try to reestablish communication	DEL delete current character or Quick Access Key menu item	ESC leave a value unchanged	ENTER accept user-entered data
EXIT leave the current menu	SEND send configuration data to device	QUIT terminate session because of a communication error	EXIT leave the current menu
YES answer to yes/no question	PGUP move up one help screen	PGDN move down one help screen	NO answer to yes/no question
ALL include current Quick Access Key item on Quick Access Key menu for all devices	PREV go to previous message in a list of messages	NEXT go to next message in a list of messages	ONE include Quick Access Key item for one device
NEXT go to the next variable in off-line edit	SAVE save information to Communicator	HOME go the top menu in the device description	
FILTR open customization menu to sort configurations	MARK toggle marked variable in configuration to be sent to a field device	BACK go back to the menu from which HOME was pressed	
	XPAND opens detailed configuration information	EDIT edit a variable value	
	CMPRS closes detailed configuration information	ADD add current item to Quick Access Key menu	

2.3.3 Action Keys

Directly beneath the LCD and software-defined function keys are six blue, white, and black action keys. Each has a specific function as described below:




ON/OFF KEY – Use to power-up the Communicator. When the Communicator is turned on, it automatically searches for a HART-compatible device on the 4-20 mA loop. If no device is found, the Communicator displays the Main menu:

```
HART Communicator
1->Offline
2 Online
3 Frequency device
4 Utility
```


If a HART-compatible device is found, the Communicator displays the Online menu:

```
MPCO 343:TT100
Online ←
1->Loop Override
2 Calibrate/Test
3 Configure Xmtr


HELP | SAVE
```




UP ARROW KEY – Use to move the cursor up through a menu or list of options or to scroll through lists of available characters when editing fields that accept both alpha and numeric data.



DOWN ARROW KEY – Use to move the cursor through a menu or a list of options or to scroll through lists of available characters when editing fields that accept alpha and numeric data.



LEFT ARROW/PREVIOUS MENU KEY – Use to move the cursor to the left or back to the previous menu.



RIGHT ARROW/SELECT KEY – Use to move the cursor to the right or to select a menu option.



QUICK ACCESS KEY (HOT KEY) – When the Communicator is on and connected to a HART-compatible device, pressing the Quick Access Key instantly displays the Quick Access Key menu of user-defined options. When the Communicator is off and the Quick Access Key is pressed, the Communicator automatically powers-up and displays the Quick Access Key menu. See Section 2.6 for more information on using the Quick Access Key.

IMPORTANT

When performing certain operations, the message “OFF KEY DISABLED” indicates that the Communicator cannot be turned off. This feature helps prevent accidental shutoff of the Communicator while the output of a device is fixed or a device variable is being edited.

2.3.4 Alphanumeric and Shift Keys

The alphanumeric keys perform two functions: (1) rapid selection of menu options and (2) data entry. The shift keys located below the alphanumeric keys on the keypad are used during data entry to select from among the characters available above each number.

2.3.4.1 Rapid Selection of Menu Options

From any menu, use the keypad to select available options in two ways. First, use the UP or DOWN arrow keys, followed by the RIGHT ARROW/SELECT key, to access available options displayed on the LCD.

As an alternative, use the rapid select feature. Simply press the number on the alphanumeric keypad that corresponds to the desired menu option. For example, to quickly access the Utility menu from the Main menu, simply press “4” on the keypad.

2.3.4.2 Data Entry

Some menus require data entry. Use the alphanumeric and shift keys to enter all alphanumeric information into the HART Communicator. Pressing an alphanumeric key alone while editing causes the large character in the center of the key (number 0-9, decimal point, or dash) to be entered.

Pressing and releasing a shift key activates shift and causes the appropriate arrow icon (, , or) to appear in the upper right-hand corner of the LCD. When shift is activated, the indicated alpha characters or symbols are entered when the keypad is used.

Example

To enter a number, such as “7,” simply press the number key.

To enter one of the small characters appearing above the large numeral (i.e., a letter, space, or mathematical symbol), first press and release the corresponding shift key at the bottom of the keypad, then press the desired alphanumeric key. To enter the letter “E,” press and release the middle shift key, then press the number “2” key.

To deactivate a shift key without entering a letter, space, or mathematical symbol, simply press that shift key again.

2.4 GETTING TO KNOW THE COMMUNICATOR

The HART Communicator operates in either of two modes: on-line or off-line. Off-line operation is used to create or edit a configuration that can then be downloaded to a HART device, such as the Model 343. On-line operation is used to download a configuration to a HART device, upload a configuration, edit HART device operating parameters, and monitor process values.

For off-line operation, the Communicator need not be connected to a HART device. On-line operation requires a connection to a HART device.

The menu that appears first when the Communicator is turned on depends on the mode. When the Communicator is powered-up in off-line mode, the first menu displayed is the Main menu. When the Communicator is powered-up in on-line mode, the first menu displayed is the Online menu. To work off-line when connected to the loop, access the Main menu from the Online menu by pressing the LEFT ARROW/PREVIOUS MENU key.

2.4.1 Display Icons

Several different symbols (icons) appear on the LCD to show the state of the Communicator and provide visible response to actions of the user. Figure 2-3 shows the display icons and how they relate to keypad functions.




FIGURE 2-3 Communicator Display Icons

2.4.2 Menu Structure

The HART Communicator uses a hierarchical menu structure. That is, high-level menus are accessed first, and they provide access to lower-level menus. This structure groups related functions together and minimizes the number of options displayed at once.

To learn how the menu structure works, perform the following actions:

1. With the Communicator off-line (not attached to any devices), press the ON/OFF key to turn the Communicator on. It displays the Main menu, with the cursor (->) positioned at "1 Offline."
2. Access the Utility menu by pressing the DOWN arrow key three times, then pressing the RIGHT ARROW/SELECT key. The display changes to show the Utility menu.
3. Access the Configure Communicator menu from the Utility menu by pressing the RIGHT ARROW/SELECT key. The display changes to show the Configure Communicator menu.
4. Access the Contrast menu by pressing the DOWN arrow once, then pressing the RIGHT ARROW/SELECT key. The display shows a message explaining how to adjust the LCD contrast.
5. Press ESC (F3) to return to the Configure Communicator menu.
6. Press the LEFT ARROW/PREVIOUS MENU key two times to return to the Main menu.
7. Press the ON/OFF key to turn the Communicator off.

2.4.3 Reviewing Installed Devices

For the HART Communicator to recognize a HART-compatible device, it must have a description for that device installed. The HART Communicator is supplied from the factory with descriptions for Model 343 Transmitters and other HART-compatible devices from leading manufacturers. In addition, it contains a generic device description, which allows limited access to most HART devices when no device description for that specific device exists in the Communicator.

To review the currently installed devices on the Communicator, use the following steps:

1. Turn on the Communicator (off-line) to display the Main Menu.
2. From the Main menu, press "4" on the keypad for quick access to the Utility Menu.
3. From the Utility menu, press "5" on the keypad to access the simulation mode. The LCD shows the Manufacturer menu, which contains a list of manufacturers whose device descriptions are installed in the Communicator.
4. Press the DOWN arrow until Moore Products appears. Press the RIGHT ARROW/SELECT key to reveal the Model menu, which lists the Moore Products Co. devices currently installed in the Communicator (see Table 2-2).
5. To end the review of devices, press the LEFT ARROW/PREVIOUS MENU key three times.
6. Turn off the Communicator or proceed to the next section.

TABLE 2-2 Moore Products Co. Device Descriptions

MODEL	FIELD DEVICE REVISION	DESCRIPTION	APPROXIMATE VINTAGE¹
340B	Dev V1, DD V1	340 Transmitter-Controllers (pushbutton design)	8/90 - 8/96, Model #s 340__B...
340A	Dev V1, DD V1	340 Transmitter (pushbutton design)	8/90 - 8/94, Model #s 340__A...
343	Dev V1, DDV1	343 Temperature Transmitter	Present Model
344	Dev V1, DD V1	344 Transmitter-Controller	8/90 - 8/94 Model #s 344...
	Dev V2, DD V1	344 Transmitter-Controller	8/90 - Present, Model #s 344...
341 Type 5	Dev V1, DD V1	341 Transmitter	8/94 - Present, Model #s 341...
340A Type 6	Dev V1, DD V1	340 Transmitter (pushbutton design)	8/94 - 8/96, Model #s 343__A...
	Dev V2, DD V1	340 Transmitter (magnetic switch design)	Present, Model #s 340__B...
340S	Dev V1, DD V1	340S SteaMeter™	Present Model

Note

¹Always verify the Model and Field Device Revision for the device at hand using the Quick Access Key\Status\Model command of the Model 275 HART Communicator.

2.5 MAIN MENU

When the Communicator is not connected to a device, the first menu to appear after powering up is the Main menu (at right). If the Communicator is turned on when connected to a device, access the Main menu by pressing the LEFT ARROW/PREVIOUS MENU key. Depending on which submenu of the on-line series is displayed, it may be necessary to press the LEFT ARROW/PREVIOUS MENU key more than once. Alternatively, press HOME (F3) to display the Online menu, followed by the LEFT ARROW/PREVIOUS MENU key to display the Main menu.

HART Communicator
1->Offline
2 Online
3 Frequency Device
4 Utility

From the Main menu, access additional menus by moving the cursor to them with the UP or DOWN arrow keys, followed by pressing the RIGHT ARROW/SELECT key, or simply by pressing the appropriate number (1-4) on the alphanumeric keypad.

2.5.1 Offline Menu

The Offline menu provides access to two other menus: New Configuration and Saved Configuration. These two configuration menus can be used without connecting to a HART-compatible device, but it is not possible to send saved data to a device if no device is connected.

From the Main menu, press “1” on the keypad or the RIGHT ARROW/SELECT key to access the Offline menu. The complete menu tree for the Offline Menu is shown in Figure 2-4.





FIGURE 2-4 Offline Menu Tree

2.5.1.1 New Configuration

This option is used to compile a custom set of device configuration data for downloading later to one or more HART-compatible devices. Downloading the same data to multiple devices ensures that they all store identical configuration data.

Use the following steps to compile off-line, new device configuration data:


1. From the Main menu, press “1” to access the Offline menu.
2. Press “1” to enter a new configuration. The Manufacturer menu appears.
3. Choose a manufacturer by scrolling to the manufacturer name with the DOWN arrow, then pressing RIGHT ARROW/SELECT. The Model menu appears.
4. From the Model menu, choose a device by scrolling through the list, then pressing RIGHT ARROW/SELECT. The Field Device Revision (Fld dev rev) menu appears.



The Field Device Revision menu contains the currently installed software revisions for the field device and device descriptions (DD) for the model selected from the Model menu.

Select the software revision (RIGHT ARROW/SELECT or number) to access the Blank Template menu (at right). To discover the software revision for a particular device, connect the Communicator to the device and follow instructions given in the device manual.

To find the software revision number for a Model 343 Transmitter, establish a connection to the Communicator, then press the Quick Access Key. From the Quick Access Key menu, press “1” to view the Status menu. The software



revision is line 3. If the software revision is not displayed, press “3” to view the Software rev screen.

- With the Blank Template menu displayed, choose from the options available, as follows:

Mark All – Flag all configurable variables before sending them to a HART-compatible device.

Unmark All – Remove the flags from all configurable variables in the configuration. Unmarked configuration variables cannot be sent to a connected HART-compatible device.

Edit Individually – Open the Edit individually menu (at right).

Example

The Edit individually menu permits the user to change a configuration parameter. For example, to change the engineering units from inH₂O to mmH₂O, press the EDIT function key (F3) to display the Measured Var Unit menu (below right).

With the Measured Variable Unit menu displayed, use the DOWN arrow to highlight the new unit, then press the ENTER function key (F4). Or, to leave the Unit variable menu without making any change, press the ESC function key (F3) to return to the Edit individually menu. From the Edit individually menu, use EXIT to go back to the Blank Template menu.

Save As . . .

Selecting the Save As option allows a new configuration to be saved to either the Memory Module or the Data Pack.

The Memory Module holds up to 10 typical configurations, and contains the operating system software and device application software in non-volatile memory. The Data Pack stores up to 100 typical configurations in nonvolatile, removable memory.

Example

From the Offline menu, choose 1 New configuration. This displays the Manufacturer menu. Choose a device, then choose a model from the Model menu. Choose a software revision from the Fld dev rev menu.

```

Unnamed
Edit individually
  Unit
    in H2O

Not marked to send
NEXT | MARK | EDIT | EXIT
  
```

```

Unnamed
Measured Var Unit
inH2O
inH2O
inHg
ftH2O
mmH2O

ESC | ENTER
  
```

The Communicator creates a configuration and displays the Blank Template menu. Choose Save as... to display the Save as... menu (at right). With the Location highlighted, press the SAVE (F2) function key to save the configuration.

If the location highlighted is the Module, but the configuration is to be stored in the Data Pack, or vice versa, press the RIGHT ARROW/SELECT key to display the Location menu. Choose either Module or Data Pack by pressing ENTER (F4). This displays the Save as... menu again. Press SAVE (F2) to save the configuration in the desired location.

The Save As... menu also is used to enter or edit the configuration Name and Data Type. To name a configuration, simply choose option 2, then use the keypad with shift keys to enter the name as shown at right.

When the Save As... menu is displayed, one of the options – Standard, Partial, or Full – will be shown. To change the option, move the cursor to the Data Type _____ line of the Save As... menu and press the RIGHT ARROW/SELECT key to display the Data Type menu (below right).

Data Type Standard refers to all user-editable variables in a device configuration. Data Type Partial refers to only the marked editable variables. Data Type Full refers to a all device variables, whether user-editable or not. In general, it is best to save as Data Type Standard. Saving as Data Type Full preserves a complete configuration for future reference.

When all changes have been made, save the new configuration to either the Memory Module or the Data Pack and return to the Offline menu.

```

Unnamed
Save as...
1->Location  Module
2 Name
3 Data Type Standard

HELP | SAVE

```

```

Unnamed
Name
  UNNAMED
  MYNAME#1

HELP | SAVE

```

```

Unnamed
Data Type
Standard
  Standard
  Partial
  Full


HELP          ESC | ENTER

```

2.5.1.2 Saved Configuration

The second option on the Offline menu is the Saved Configuration menu, which permits access to previously stored configuration data.


1. Press “2” from the Offline Menu to display the Saved Configuration menu (at right).
2. Select either Module Contents or Data Pack Contents to open stored configurations. Both storage locations list all saved configurations by assigned Tag. See XPAND (below) for more configuration identification details. (**Note:** The PC option shown on the menu is not operational with firmware release 1.6.)



The Module Contents menu, which lists the configurations currently stored in the Memory Module, is shown at right. The Data Pack menu is similar. Both give the user several options for handling and viewing configuration data, as explained below.

FILTR

The FILTR function key (F1) opens a menu that provides both Sort and Filter options. These options select only the chosen configurations from all those stored. This is particularly valuable for the Data Pack, which stores up to 100 configurations.




Sort allows unique device configurations to be grouped and displayed by Tag, Descriptor, or user-assigned Name.

Use Filter to group and display configurations according to certain characters within the chosen device identifier (Tag, Descriptor, or Name). For example, selecting all the tags from a certain area of the process or plant.

When setting up a Filter (see display at right), two wildcard characters, the period (.) and the asterisk (*) are used. The period replaces a single character of any value. The asterisk replaces one or more alphanumeric characters of any value.

For example, if A-*-1 is entered as the filter, the configurations displayed will be all those with device tags starting with A-, followed by any combination of characters (e.g., XYZ, S2, 3R) followed by a dash, followed by any single character (e.g., 1, D, M), and ending with a 1. The tags A-M1-B1, A-N2-Z1, or A-SF-X1 would display, whereas the tags BA53, PT101, or ATT48 would not display.



XPAND

The XPAND function key allows a user to view the Tag, Descriptor, and Name for the configuration being edited or viewed. Selecting Compress restores the previous compressed display, which shows only the current Tag, Descriptor, or Name.

3. With the Module Contents or Data Pack Contents menu displayed, press the RIGHT ARROW/SELECT key to open the Saved Configuration menu for a device that was highlighted (at right).

Edit – displays the Edit menu, providing the functions as described under “Edit individually” in Section 2.5.1.1.

When editing off-line, only stored data may be edited. Moreover, data stored as a Partial configuration must be converted to a Standard configuration, then saved, prior to editing.

Copy To... – specifies the storage location for a copy of the configuration. Copy To... also provides a way to change the configuration name.

Send – sends a saved configuration to a connected device.

Print – not implemented with firmware release 1.6.

Delete – removes a saved configuration from memory. A confirmation message appears. Press Yes or No to complete the function.

Rename – provides access to the configuration name editing menu. After making name changes, enter and save the data to return to the previous storage location menu.

Compare – compares a selected device configuration from a stored location with other device configurations. The HART Communicator can compare device types, variables, marked lists, and other configuration parameters. Messages appear indicating if the configurations compared are the same or different.

```

PT118
Saved Configuration ←
1->Edit
2 Copy to...
3 Send
4 Print
5 Delete
HELP

```

2.5.2 Online Menu

The Online menu permits a Model 343 Transmitter to be tested and configured while it is operating. Options available through the Online menu are summarized in Figure 2-5. The Online menu is displayed immediately if a device description for the connected device exists in the Communicator. If not, the Generic Online menu is displayed (see Figure 2-6).

Main Menu

From the Main menu, with a HART-compatible device connected, press “2” to access the Online menu (at right). The Online menu displays the name of the device at the top of the LCD, if it is a supported device. If a device description for the connected device is not present in the Communicator, contact the manufacturer of the device.

When no device description is found, the Communicator provides a generic interface, which enables users to perform functions common to all HART-compatible devices. Model 343-specific menu options are described in detail in Sections 3 and 6.

Generic Menu



The Generic Online menu (at right) is the first menu in the generic interface. It displays critical, up-to-date device information. Configuration parameters for the connected device may be accessed using the Device setup option. Figure 2-6 shows the complete Generic Online menu tree.


From the Online menu, use the options below to change device configurations.

Device setup – provides access to the Device Setup menu. Configurable device parameters common to all HART-compatible devices can be accessed from this menu.

Primary Variable (PV) –the dynamic primary variable and the related engineering unit. When the primary variable contains too many characters to display on the Online menu, access the PV menu to view the primary variable and related engineering units by pressing “1.”

Analog Output (AO) – the dynamic output and the related engineering units. The analog output is a signal on the 4-20 mA scale that corresponds to the primary variable. When analog output contains too many characters to display on the Online menu, access the PV AO Menu to view the analog output and related engineering unit by pressing “3.”





MG001230

FIGURE 2-5 Online Menu Tree for Model 343 Transmitter

Lower Range Value (LRV) – the current lower range value and the related engineering unit. When the lower range value contains too many characters to display on the Online menu, access the PV LRV Menu to view the lower range value and related engineering unit by pressing “4.”

Upper Range Value (URV) – the current upper range value and the related engineering unit. When the lower range value contains too many characters to display on the Online menu, access the PV URV Menu to view the upper range value and related engineering unit by pressing “5.”





FIGURE 2-6 Generic Online Menu Tree

2.5.3 Frequency Device Menu

From the Main menu, press “3” to access the Frequency Device menu. This menu displays the frequency output and corresponding pressure output for current-to-pressure devices. For Model 343 transmitters, the display frequency and pressure values are both “none.”


2.5.4 Utility Menu

From the Main menu, press “4” to access the Utility menu (at right). This menu provide functions that affect the operation of the Communicator, not the connected devices.



2.5.4.1 Configure Communicator

From the Utility Menu, press “1” to access the Configure Communicator menu (below right). Use this menu to set the polling, adjust the contrast of the LCD, set the Communicator shutoff time, or set how many diagnostics messages to ignore before a warning message is displayed.



Use the **Polling** option to direct the HART Communicator to search for a connected device. The Communicator finds every device in the loop and lists them by tag number. If Polling is Never Poll, then the Communicator will not find a connected device.

The **Contrast** menu is used to change the LCD contrast. Contrast returns to the default value when the Communicator is turned off.

Off Time is used to set the Communicator to turn off automatically when not in use to conserve battery power.

The Communicator normally displays diagnostic messages from a connected device. The **Ignore Diagnostics** option permits the user to specify the number of messages to ignore so that messages will not be displayed as often, extending the time between displayed messages. The message count defaults to a nominal count of 50 each time the Communicator is turned on.

2.5.4.2 System Information

From the Utility menu, press “2” to access the System Information menu (at right). This menu can be used to provide information on the motherboard (e.g., firmware revision number), the module hardware and software characteristics, and the Data Pack EEPROM.

```
HART Communicator
System Information ←
1->Motherboard
2 Module
3 Data Pack

HELP|DEL |ESC |ENTER
```

2.5.4.3 Listen for PC

Not implemented in firmware release 1.6.

2.5.4.4 Storage Location

From the Utility menu, the Storage Location menu (at right) provides access to data concerning the Memory Module or the Data Pack. Information available through this menu includes a label for the Memory Module or Data Pack, a feature that displays the total storage used (bytes) and the storage remaining (“free” bytes). The PC selection is not implemented in firmware release 1.6.

```
HART Communicator
Storage location ←
1->Module
2 Data Pack
3 PC

HELP|DEL |ESC |ENTER
```

2.5.4.5 Simulation

The HART Communicator provides a mode that allows users to simulate an on-line connection to a HART-compatible device without connecting to the device. The simulation mode is a training tool that allows users to become familiar with different devices before configuring them in a critical environment. Simulation of an on-line connection is done by selecting a manufacturer from the Manufacturer menu, then selecting a device from the Model menu, just as is done when on-line. After selecting a software revision, the Online menu for the simulated device is displayed. Functions are the same as those available when on-line.

2.6 USING THE QUICK ACCESS KEY

Pressing the Quick Access Key (Hot Key) while on-line displays the Quick Access Key menu, a user-definable menu that provides immediate access to up to 20 frequently performed tasks. The Quick Access Key menu is accessible when the Communicator is powered and on-line, or when the Communicator is off, by simply pressing the Quick Access Key. For the Quick Access Key to be active, the Communicator must be connected properly to a HART-compatible device.


From the factory, the Quick Access Key menu includes (for Model 343 only):

- **XMTR Variables** – View such variables as percent range, process value, etc.
- **Status** – Determine model number and other transmitter identification information.
- **Range XMTR** - Configure parameters associated with the sensor type and range.

More options can be added to provide rapid access to frequently performed tasks. User-defined options can be deleted later, but the two factory options are permanent.

To use the Quick Access Key:

1. Connect the Communicator to a HART-compatible device.
2. Press the Quick Access Key (upper right-hand key in the action keys group). The Communicator will power-up and display the Quick Access Key menu (at right).
3. Before any custom options have been installed, the Quick Access Key menu displays only the five factory-installed options. To add options, see Section 2.6.1.
4. Use the UP and DOWN arrows followed by the RIGHT ARROW/SELECT key to choose an option, or press the option's number on the keypad. The menu for the chosen option displays.
5. Follow the instructions given in Section 5.2 to use the option selected.
6. When finished, press the Quick Access Key to return to the previous menu.



2.6.1 Adding Quick Access Key Options

The Quick Access Key menu contains space for up to 20 on-line options. For example, if device tags and damping must be changed often, simply add both of them to the menu. The Communicator automatically saves them so they can be accessed quickly by pressing the Quick Access Key.

From one of the menus or submenus reached via the Online menu, use the following steps to add customized options to the Quick Access Key Menu:

1. Using the UP or DOWN arrow keys, move the menu bar to highlight the option to be added to the Quick Access Key menu (e.g., Damping, under the Configure Xmtr\Sensor Input menu).



2. Press any shift key, release it, then press the Quick Access Key. The Hotkey Configuration menu displays (at right).

The Hotkey Configuration menu displays the new topic being added to the list of current Quick Access Key options. For example, in the figure at right, Damping is being added.

3. Press ADD (F3) to add the option. Pressing EXIT (F4) terminates the procedure and displays the menu that was displayed when "Shift," Quick Access Key was pressed.
4. After pressing ADD (F3), either press ALL (F1) to add the new option to the Quick Access Key menu for all the HART-compatible devices supported by the Communicator or press ONE (F4) to add the option to the Quick Access Key Menu only for the type of device that is currently connected.
5. Next, the question "Mark as read-only variable on Quick Access Key menu?" may appear. Press YES (F1) to mark the variable for this option as read-only. Press NO (F4) to mark the variable as read/write. Marking a parameter for a device as read-only allows users to view, but not change, the parameter using the Quick Access Key Menu. Marking it as read/write permits the value to be changed from the Quick Access Key menu.

Finally, "Display value of variable on hotkey menu?" is displayed. Press YES (F1) to display the current variable associated with the option next to the option on the Quick Access Key menu as shown at right for Damping and Tag. Press NO (F2) not to display the variable on the Quick Access Key menu.

6. When finished adding options, press EXIT (F4) to exit the Hotkey Configuration menu and return to the menu of the last option deleted.



2.6.2 Deleting Quick Access Key Options

Use the following steps to delete an option from the Quick Access Key menu:

1. From any on-line menu, press any shift key, release it, then press the Quick Access Key.
2. The Hotkey Configuration menu displays (at right).
3. Using the UP or DOWN arrow key, move the menu bar to highlight the option to be deleted and press DEL (F2). Factory-provided options cannot be deleted.
4. When finished deleting options, press EXIT (F4) to exit the Hotkey Configuration menu and return to the menu of the last option deleted.

```
MPCO 343:TT100
Hotkey Configuration
ADD: Descriptor
      Damping
      Tag

      DEL | ADD | EXIT
```


3.0 COMMISSIONING AND BENCH TESTING

Before operating a Model 343 on-line, the instrument should be set up either at the bench or in the field and commissioned using the HART Communicator. Commissioning consists of checking that the transmitter is operational and that all configuration information is correct. For an in-depth discussion of transmitter configuration, refer to Section 5 On-Line Configuration and Operation.

3.1 COMMISSIONING PROCEDURE

A Model 343 can be commissioned either before or after installation. Commissioning on the bench before installation is recommended. A complete transmitter functional test can be performed and configuration procedures can be practiced. If commissioning after installation, install the transmitter as described in Section 4, then return to this section.

To commission the transmitter on the bench, make the connections shown in Figure 3-1. For commissioning in the field, use either the set-up shown in Figure 3-2 or the appropriate installation wiring figure in Section 4.

3.1.1 Test Equipment Needed

TEST EQUIPMENT	DESCRIPTION (see Specifications, Section 8.3)
Power Supply	10 to 42 Vdc, see Section 4.3.4
Multimeter:	
Current	Range: 4 to 20 mA to measure loop current
Voltage	Range: 10-50 Vdc to measure power supply and loop voltages
Current Sense Resistor	250 to 1100 Ω to support HART digital communications
Configuration Device	Model 275 HART Communicator
Temperature Calibrator	Use to simulate RTD and T/C inputs.

NOTE

Test equipment should be 2 to 10 times more accurate than the required transmitter accuracy.




FIGURE 3-1 Bench Test Connections




FIGURE 3-2 Field Test Connections

3.2 ESTABLISHING COMMUNICATION

1. Connect the transmitter, power supply, and HART Communicator in a loop.
2. Apply power to the transmitter.
3. Press the HART Communicator's ON/OFF key. The first display is the Online menu (at right).
4. If the Online menu does not appear, or if a "Device not found" message displays, check connections and try again.

```

MPCO 343:TT100
Online ←
1->Loop Override
2 Calibrate/Test
3 Configure Xmtr

HELP |SAVE

```

3.3 TESTING THE TRANSMITTER

Although a Model 343 Transmitter continuously performs an on-line self-test, a more extensive self-test can be performed once communication with the HART Communicator has been established.

1. From the Online menu, choose option 2, Calibrate/Test to display the Calibrate and Test selections.
2. From the Calibrate/Test menu, choose option 1, Selftest. Press the RIGHT ARROW/SELECT key to start the test.
3. The Communicator will display a warning screen (at right). If a process might be harmed by a change in transmitter output, press "1," ABORT to stop the test. To proceed, press "2," CONTINUE.
4. The transmitter performs the self-test.
 - If testing is successful, the message "Transmitter PASSED the transmitter selftest" displays.
 - If testing fails, the message "Transmitter FAILED the transmitter selftest" displays, and the transmitter goes to the configured failsafe condition.
5. Press OK (F4) to acknowledge the test results and display the Calibrate/Test menu.

```

MPCO 343:TT100
WARNING! Self test
may bump transmitter
output.
1 ABORT
2 CONTINUE

ABORT |ENTER

```

3.4 REVIEWING CONFIGURATION DATA

Before placing a transmitter in service, use the HART Communicator to check that the proper configuration information has been stored.

1. Establish communication as described in Section 3.2.
2. From the Online menu, press “3” to view the Configure Xmtr menu (at right). For each of the function blocks on this menu, check to see that each parameter is set to the correct value as recorded in user documentation (Appendix B).
3. For each function block, perform the following steps:
 - 1) Use the UP or DOWN arrow key to highlight the function block. Press the RIGHT ARROW/SELECT key to view the function block options.
 - 2) Examine each of the options on the function block menu, changing values if necessary. When the first change is made, the SAVE softkey changes to SEND.
4. When all configuration parameters have been examined and changed as needed, press SEND to download the configuration to the transmitter. The SEND softkey changes to SAVE.
5. If this configuration will be used for other transmitters, save the configuration to either the Memory Module or Data Pack by pressing SAVE (F3) from the Configure Xmtr menu or any of its submenus.

```

MPCO 343:TT100
Configure Xmtr      ←
1->Write protect
2 Sensor Input
3 Characterizer
4 Operator Display
5 Transmitter ID
HELP | SAVE | HOME
  
```

3.5 CHECKING TRANSMITTER OUTPUT

After the transmitter configuration has been confirmed and adjusted as necessary, check to be sure that the transmitter is reading the proper temperature in the proper units. Use a resistance decade box, voltage source or temperature calibrator to apply 0, 25, 50, 75, and 100% of scale input values to the transmitter. Check that the corresponding outputs are 4, 8, 12, 16, and 20 mA.

NOTE

Turn OFF the transmitter’s Failsafe Detection feature for proper operation with a temperature calibrator.

With the transmitter configured properly, and with the test equipment in place, perform the following steps:

1. Connect the HART Communicator and press the Quick Access Key.
2. From the Quick Access Key menu, choose “1” XMTR Variables to view the current transmitter output (at right).
3. Apply a temperature representing 0% of the configured range. Wait at least 5 seconds.
4. Choose “6” to see the current display. The current should read 4.00 mA.
5. Repeat steps 1-4 for temperatures representing 25, 50, 75, and 100% of the configured range. Check for the corresponding pressure readings and current values.

MPCO 343:TT100		▼
XMTR Variables		←
1->MV	110	DegF
2 I	9.33	mA
3 %	34.0	PRCT
4	Internal Temp	
HELP SAVE		

This completes commissioning and bench testing of the transmitter.

4.0 INSTALLATION

This Section describes installation of a Model 343 Temperature Transmitter. Topics include: receipt of shipment, installation considerations, and mechanical and electrical installation.

IMPORTANT

The installation must conform to the National Electrical Code and all other applicable construction and electrical codes.

Refer to Section 8 for hazardous area classification information. Some approvals and certifications for hazardous area installation were pending at the time this manual was printed. Contact the factory or your local Moore sales office or subsidiary for the latest information and for installation and servicing of a transmitter in a hazardous area.

4.1 EQUIPMENT DELIVERY AND HANDLING

4.1.1 Factory Shipment

Prior to shipment, a transmitter is fully tested and inspected to ensure proper operation. It is then packaged for shipment. Most accessories are shipped separately.

4.1.2 Receipt of Shipment

Each carton should be inspected at the time of delivery for possible external damage. Any visible damage should be immediately recorded on the carrier's copy of the delivery slip.

Each carton should be carefully unpacked and its contents checked against the enclosed packing list. At the same time, each item should be inspected for any hidden damage that may or may not have been accompanied by exterior carton damage.

If it is found that some items have been damaged or are missing, notify Moore Products Co. immediately and provide full details. In addition, damages must be reported to the carrier with a request for their on-site inspection of the damaged item and its shipping carton.

4.1.3 Storage

If a transmitter is to be stored for a period prior to installation, review the environmental specifications in Section 8.3.5.

4.2 ENVIRONMENTAL CONSIDERATIONS

Many industrial processes create severe environmental conditions. The conditions at each transmitter location must be within the specifications stated in Section 8.3.5.

The transmitter is designed to perform in harsh conditions, however, it is prudent to locate a transmitter to minimize the effects of heat, vibration, shock, and electrical interference.

4.3 INSTALLATION CONSIDERATIONS

Sections 4.3.1 and 4.3.2 outline basic considerations needed to achieve a successful mechanical/electrical installation. The remaining sections then provide detailed pre-installation information.

4.3.1 Mechanical

- Select the sensor input: thermocouple, millivolt, RTD, or resistance. Refer to Section 8.2 for sensor accessories. Also, consider the accuracy limitation of a 2-wire RTD. Refer to Section 4.3.10.
- Determine the need for an optional SmartDisplay or LCD display for local monitoring of transmitter output. Refer to Section 8.1 for model designation or 8.2 for accessory part numbers.
- Determine physical mounting of the transmitter. Consider:
 - Using supplied bracket for pipe or wall mounting. Refer to Sections 4.4.1 and 4.4.2.
 - Transmitter-to-process mounting. Refer to Section 4.4.3.
 - Clearance for installation and maintenance and for reading an optional display. See Figure 8-3.
- See Figure 8-3 for transmitter dimensions and the figures in Section 4.4 for typical mechanical installations. Refer to Section 8.3 for mechanical and environmental specifications.
- Determine whether an explosion-proof or intrinsically safe installation is required. Refer to the transmitter's nameplate for electrical classifications and to Sections 8-1 and 8-3.
 - For an intrinsically safe installation, select user-supplied intrinsic safety barriers. These must be installed in accordance with barrier manufacturer's instructions for the specific barriers used.
 - Transmitter certification is based on the "Entity" concept in which the user selects barriers that permit the system to meet the entity parameters. Refer to Section 4.3.7.
- For an explosion proof installation, select owner-supplied conduit glands. These must be installed in accordance with gland manufacturer's instructions as well as the National Electric Code.
- Determine conduit routing. Refer to Section 4.4.5.
- Prepare installation site drawings showing the following:
 - Location of the Master Device (e.g. HART Communicator or controller)
 - Location and identification of each transmitter
 - Routing of signal cable(s)
 - Location of any signal cable junctions for connecting the HART Communicator
 - Location of sensor(s) and routing of sensor cable(s)

4.3.2 Electrical

- Determine transmitter operating mode (analog or digital) and type of Network needed; refer to Section 4.3.3.
- Determine minimum power supply requirements. Refer to Section 4.3.4.
- Select twinaxial cable type and determine maximum cable length. Refer to Section 4.3.5.
- Determine the need for network junctions. Refer to Section 4.3.6.
- Consider the effect of connecting additional equipment (e.g., recorder, loop powered display) to the network. High impedance devices connected to the network will need a HART communication filter. Refer to Section 4.3.8.

- Select sensor cable type. Refer to Section 4.3.9.
- Read Section 4.3.11 for grounding and shielding recommendations.

4.3.3 Transmitter Operating Mode and Network Type

A transmitter will output either an analog current or an equivalent digital signal, depending upon the selected operating mode. The operating mode will then determine the type of Network (Point-To-Point or Multi-Drop) to be installed, as shown in Table 4.1 and the following subsections. Select the operating mode during transmitter configuration as described in the following subsections and Section 5.

TABLE 4.1 Operating Mode And Network


OPERATING MODE	NETWORK TYPE	NETWORK FIGURE(S)
Analog	Point-To-Point	4-1 and 4-2
Digital	Multi-Drop	4-3

4.3.3.1 Analog Mode

- The transmitter outputs a 4-20 mA signal for input to devices such as controllers and recorders.
- Analog operation employs a Point-To-Point Network comprising a transmitter, Primary/Secondary Master, and other non-signaling devices. Transmitter POLLING ADDRESS must be 0 (zero).
- Use an optional display for local indication of transmitter output.
- A transmitter is factory configured for analog mode unless otherwise ordered.
- Digital HART Communication is superimposed on the analog signal and is used for configuration, diagnostics, and reporting the current process variable.


4.3.3.2 Digital Mode

- The number of Allowable Network Elements is:
 - Primary and Secondary Masters - 1 each
 - Transmitters - 1 to 15
- The process variable is transmitted digitally. The analog output of each transmitter is "parked" at 4 mA.
- The HART communication source can be a Primary or Secondary Master. A Primary Master can be used for data acquisition, maintenance, or control purposes. A Secondary Master, the HART COMMUNICATOR for example, may be used for configuration, diagnostics, and reporting current process variable.
- Use the optional display for local indication of transmitter output.
- Place the transmitter in the digital mode by assigning it a POLLING ADDRESS from 1 to 15.



MG001260

FIGURE 4-1 Point-To-Point Network (Analog Mode)



Notes:

1. The System Power Supply is shown separate from the host input device. In practice, it may be part of the host input device. The host input device can either be a HART or non-HART signaling device, a Primary Master or Secondary Master.
2. Network resistance equals the sum of the barrier resistances and the current sense resistor. Minimum value 250 Ohms; maximum value 1100 Ohms.
3. A maximum of 15 transmitters may be connected. All must be configured for digital mode.
4. Connect the HART Communicator as shown in Figure 2-2 for hazardous or non-hazardous locations. The HART Communicator is a non-polar device.
5. Supply and return barriers shown. Interconnect all cable shields and ground only at the barriers.
6. For access to Model 343 terminals, remove enclosure cap and display module.

FIGURE 4-3 Multi-Drop Network (Digital Mode)

4.3.4 Power Supply Requirements

A power supply is needed to power the transmitter(s). The power supply can be:

- A separate stand-alone supply capable of powering several transmitters. It can be mounted in a control room or in the field. Follow the power supply manufacturer's recommendations with regard to mounting and environmental considerations.
- Located in a controller (such as a Primary Master) or other station able to safely provide additional operating current and meet the power supply specifications of Section 8.3.2.

Determine needed power supply output voltage by calculating the Network Resistance and consulting Figure 4-4. It shows the minimum power supply voltage needed for the calculated Network Resistance.

The total Network Resistance is the sum of the Current Sense Resistance, end-to-end Barrier Resistance (if used), wire resistance, and any other resistances in the loop. The minimum Network Resistance (see Glossary) required to support HART communications is 250Ω. The maximum resistance is 1100Ω.




FIGURE 4-4 Supply Voltage Versus Network Resistance

4.3.4.1 Point-To-Point Network

Figure 4-4 defines an analog mode transmitter's operating region for the allowable ranges of supply voltage and network resistance. Perform the following simple calculations to ensure that the power supply output voltage permits the transmitter to remain within the indicated operating range.

1. Calculate the minimum power supply output voltage.

The minimum network power supply voltage requirement is a function of Network Resistance and full scale current (22.5 mA), and is calculated by the following formula:

$$\text{Minimum Power Supply Output Voltage} = 12 \text{ volts} + (0.0225 \times \text{Network Resistance in ohms})$$

Power supply output voltage must be greater than the calculated value. The minimum voltage across the input terminals of a transmitter is 12 volts.

2. Calculate the maximum power supply output voltage.

The maximum network power supply voltage is a function of Network Resistance and zero scale current (3.85 mA), and is calculated by the following formula:

$$\text{Maximum Power Supply Output Voltage} = 42 \text{ volts} + (0.00385 \times \text{Network Resistance in ohms})$$

Power supply output voltage must be less than the calculated value. The maximum voltage across the input terminals of a transmitter should never exceed 42 volts.

4.3.4.2 Multi-Drop Network

Perform the following simple calculations to ensure that the power supply output voltage permits the transmitter to remain within its operating range.

1. Calculate the minimum power supply output voltage.

Minimum network power supply voltage is a function of Network Resistance and the total current draw of all transmitters in the Network, and is calculated by the following formula:

$$\text{Minimum Supply Output Voltage} = 12 \text{ volts} + [(0.004 \times \text{number of transmitters on Network}) \times (\text{Network Resistance})]$$

Power supply output voltage must be greater than the calculated value. The minimum voltage across the input terminals of a transmitter is 12 volts.

2. Calculate the maximum power supply output voltage.

Maximum network power supply voltage is a function of Network Resistance and total current draw of all the transmitters in the Network, and is calculated by the following formula:

$$\text{Maximum Supply Output Voltage} = 42 \text{ volts} + [(0.004 \times \text{number of transmitters on Network}) \times (\text{Network Resistance})]$$

Power supply output voltage must be less than the calculated value. The maximum voltage across the input terminals of a transmitter should never exceed 42 volts.

The maximum number of transmitters that can be connected to a Multi-Drop Network is fifteen. Each transmitter is "parked" in a low current draw mode (4 mA) to conserve power. Ensure that the network power supply is capable of sourcing the total current consumed by the number of transmitters on the Network.

4.3.5 Cable Capacitance and Maximum Length

A cable length calculation is necessary when HART communication is to be employed. Cable capacitance directly affects maximum Network length.

4.3.5.1 Cable Capacitance

Cable type, conductor size, and recommended cable model numbers are stated in Section 8.3.3 Two-Wire Cable.

Cable capacitance is a parameter used in the calculation of the maximum length of cable that can be used to construct the Network. The lower the cable capacitance the longer the Network can be. Manufacturers typically list two capacitance values for an instrumentation cable:

1. Capacitance between the two conductors.
2. Capacitance between one conductor and the other conductor(s) connected to shield. This capacitance is the worst case value and is to be used in the cable length formula.

4.3.5.2 Maximum Cable Length Calculation

The maximum permissible single-pair cable length is 10,000 feet (3000 meters) or less as determined by the following formula:

$$L = \frac{65,000,000}{R \times C} - \frac{C_f + 10,000}{C}$$

Formula Definitions:

- L: The maximum total length of cable permitted to construct the Network. L = Feet when C is in pF/ft. L = meters when C is in pF/meter.
- R: The Network Resistance which is the ohmic sum of the Current Sense Resistance and Barrier Resistance (both Return and Supply), if any, in the Network and the resistance of the wire.
- C: Cable capacitance per unit length between one conductor and the other conductor connected to the shield. C may be in pF/ft or pF/meter.
- C_f: Total input terminal capacitance of Field Instruments; the Primary Master is excluded. C_f is given by the following formula:

$$C_f = (\text{sum of all } C_n \text{ values}) \times (5000)$$

Where C_n is an integer (e.g., 1, 2, 3) corresponding to the input terminal capacitance of a Field Instrument. C_n values are read from the following table. For Field Instruments without C_n values, use C_n = 1

FIELD INSTRUMENT CAPACITANCE	C _n VALUE
Less than 5000 pF	1
5000 pF to less than 10000 pF	2
10000 pF to less than 15000 pF	3
15000 pF to less than 20000 pF	4
20000 pF to less than 25000 pF	5
25000 pF to less than 30000 pF	6 (Model 343)

Example Calculation:

Assume a Network consists of a 343 and a Field Instrument (C_n = 1 and C_n = 6).

Let R = 250Ω, C = 40 pF/ft., C_f = (1 + 6) x 5000 = 35,000

$$\text{Then } L = \frac{65,000,000}{(250)(40)} - \frac{35,000 + 10,000}{40} = 5375 \text{ feet (1612.5 meters)}$$

4.3.6 Network Junctions

A network junction is shown in Figure 4-1. It is a wiring junction installed at a convenient point in the loop to facilitate wiring, testing, and troubleshooting. Typically the junction is a conventional terminal block mounted on a panel with a protective cover, cabinet, or junction box to enclose and protect wiring terminals.

Multiple junctions can be installed to provide field access terminals for the connection of a HART COMMUNICATOR.

Note the following:

- Network with Barriers - Locate a junction anywhere along the network in the non-hazardous area between a barrier and the Current Sense Resistor.
- Network without Barriers - A junction may be located anywhere along the network between the Current Sense Resistor and transmitter.
- A junction should be a simple electrical series connection containing NO repeaters or other devices (active or passive) that can degrade HART communications.

4.3.7 Safety Barriers

Installed safety barriers must comply with the following:

- Locate intrinsic safety barriers between the system power supply (e.g., Primary Master, if used) residing in the non-hazardous area and the transmitter(s) in the hazardous area.
- Combined or separate supply and return barriers may be used.
- For an intrinsically safe application, the DC voltage applied to the safe side of the barrier must be 0.6 Vdc less than the rated barrier working voltage.
- An Active Supply Barrier must be operated within its specified input working voltage.

- Barrier shunt impedance to ground shall not be less than 5000Ω for the HART range of frequencies (500 Hz to 2500 Hz).
- Barrier end-to-end resistance, stated by the manufacturer, is used in calculating the maximum network cable length and minimum and maximum network voltages.
- The barrier shall be installed and wired in accordance with the manufacturer's instructions.

As hazardous area certifications are received, installation drawings will be located in Appendix C.

4.3.8 Connection of Miscellaneous Hardware

Miscellaneous non-signaling hardware (e.g., recorders, current meters) may be connected to a Point-To-Point Network in accordance with the following list.

IMPORTANT

No non-signaling hardware (meters or measuring devices) may be connected to a Multi-Drop Network since the transmitters, in this mode, do not output an analog process variable.

- Miscellaneous hardware may be series or parallel connected to the Network according to its function.
- Miscellaneous hardware must be passive two-terminal devices.
- Miscellaneous hardware may not generate any type of noise or signals, other than noise that is inherent in resistive components.
- Individual miscellaneous hardware must meet the following requirements:
 - Capacitance to Ground 50 pF maximum
 - Resistance to Ground 1 M Ω minimum
 - Impedance if Series Connected Less than 10 Ω
 - Impedance if Parallel Connected Greater than 50k Ω .
- The maximum number of miscellaneous devices per Network is 16. The combined electrical characteristics may not exceed the following:
 - Maximum capacitance to ground 800 pF
 - Minimum resistance to ground 62.5k Ω
 - Maximum series impedance 160 Ω
 - Minimum parallel impedance 3125 Ω

4.3.9 Determine Sensor Cable Requirements

If the transmitter is mounted remotely from the sensor, the characteristics of the extension cable between the sensor and transmitter will be different for thermocouple inputs than for RTD, ohm, or millivolt type inputs.

A. Thermocouple Sensor-to-Transmitter Extension Cable:

- 1) Select an extension or thermocouple grade wire of the same calibration as the thermocouple: T, J, E, K, C, L, U, R, S, N, or B.
 - **THERMOCOUPLE GRADE:** This wire is made from the same materials used for a thermocouple and is subject to same error limits as a thermocouple.
 - **EXTENSION GRADE:** Noble and refractory thermocouple extension grade wire is made from inexpensive proprietary alloys that simulate the thermoelectric behavior of the actual thermocouple element over a limited range of temperatures.

Base metal (T, J, K, E) thermocouple extension grade wire is made from the same materials as thermocouple wire; however, its use is restricted to a lower range of temperatures.

For extension grade wire, the ambient temperature at the thermocouple head connection point may not exceed the temperature limits of the extension wire.

- 2) Cable Recommendation: FEP Teflon® insulated and jacketed, twisted and shielded. Wire size should be 24 to 16 AWG.

B. RTD/Ohm Sensor-to-Transmitter Extension Cable

The transmitter will compensate for lead wire resistance for 3 and 4-wire RTD's and for an Ohm (potentiometer) sensor when a 3-wire input connection is used. Input connections may be made with copper wire.

- 1) Cable Recommendation for RTD: This cable typically has multiple conductors, a high temperature rating, overall braid shield with three copper TFE Teflon® insulated conductors and TFE Teflon wrapped jacket. Wire size should be 24 to 16 (AWG).
- 2) Cable Recommendation for Ohm: This cable typically has multiple conductors, a temperature rating for instrumentation, overall braid shield, PVC insulated three copper conductors with PVC jacket. Wire size should be 24 to 16 (AWG).

C. Millivolt Sensor-to-Transmitter Extension Cable

Cable Recommendation: This cable typically has multiple conductors, a temperature rating for instrumentation, overall braid shield, PVC insulated twisted pair copper conductors with PVC jacket. Wire size should be 24 to 16 (AWG).

4.3.10 2-Wire RTD Accuracy Limitation

The use of a 2-wire RTD requires a careful analysis of the effects of extension lead wire resistance that can cause an error in temperature measurement.

A 2-wire RTD may be used when the resistance of the run of lead wire may be considered as an additive "constant temperature error" and the changes in lead resistance due to ambient temperature changes may be ignored.

The RTD sensor element is approximately one inch in length. The platinum wire at each end of the RTD is terminated in an insulated copper lead wire. The lead wire extends beyond the sensor probe's protective metal sheath to a distance specified by the user. The lead wires are terminated at the transmitter's sensor terminals when the probe assembly is mounted to the transmitter. On a remote mounted transmitter, the lead wires are terminated in the probe's connection head and extended by a second set of wires to the transmitter.

The extension lead wire resistance is the sum of the resistances of both copper wires connecting the RTD element to the transmitter.

Extension lead wire resistance will add to the resistance of the RTD causing a permanent somewhat higher temperature reading than actually exists at the RTD location. For example, if a 1 degree offset error is acceptable, then the maximum #24 AWG extension lead wire length permissible would be calculated for a 100 Ohm RTD (DIN Curve) as follows:

$$\text{Total length (L)} = \frac{\text{resistance change of RTD per } 1^{\circ}\text{C}}{\text{resistivity of \#24 AWG per foot}}$$

$$L = \frac{0.39 \text{ ohms}}{0.0262 \text{ ohms per foot}} = 14.8 \text{ feet or } 7.4 \text{ feet for each lead.}$$

A 0.3° offset error is caused by an extension lead wire (#24) length of 2.23 feet.

As the calculations indicate, extension lead wire added to a 2-wire RTD can cause serious offset error. A 2-wire RTD should not be used without determining that the results are acceptable.

The effects of lead wire resistance are compensated for by the transmitter when 3 and 4-wire RTDs are used.

4.3.11 Shielding and Grounding

Signal Cable Shield(s)

The preferred method of grounding the loop cable shield is illustrated in Figures 4-1, 4-2, and 4-3.

The following guidelines represent proven grounding practices that will reduce magnetically coupled interference:

- Ground the cable shield at ONE point, as shown.
- Ground the cable shield at the network power supply when barriers are not installed. Ground the cable shield at the barrier ground when barriers are installed.
- When the cable shield is grounded at the power supply:
 - a) The cable shield should remain open (not connected) at the field instrument (transmitter).
 - b) The shields of both cables at a network junction should be spliced. Alternatively, connect both to a terminal in the box or panel, provided that the terminal is isolated from ground.
- Point-To-Point Network

The cable shield(s) may be grounded at a network junction box or wiring panel provided that the cable shields are connected to either a terminal or the box or panel frame, and the terminal or frame is grounded. The power supply (+) and (-) connections must be floated and the cable shield at the transmitter must not be connected.
- Multi-Drop Network

If the Primary Master's power supply output is isolated from ground, the network may be floated. The cable shield should be connected only to one point: the Primary Master's negative supply output.

Sensor Cable Shield


- a) Shielded sensor cable should be used (remote mounted sensor) to minimize the effects of electrical noise. The sensor wires should be twisted to minimize magnetic induced noise.
- b) On a remote mounted thermocouple, if the thermocouple measuring junction is grounded to its sheath (which is also grounded), connect the sensor cable shield to ground as close as practical to the measuring junction.
- c) On a remote mounted thermocouple, if a thermocouple measuring junction is ungrounded, ground the cable shield wire to a point as close as practical to the measuring junction.
- d) Do not connect the cable shield to ground at the transmitter if the cable shield is grounded at the sensor assembly.

4.4 MECHANICAL INSTALLATION

This section describes the mechanical installation of a transmitter and the installation of electrical conduit for wiring. Transmitter dimensions are given in Figures 8-3 and 8-4.

Mount a transmitter in any position (orientation). Be sure to allow sufficient clearance for: installation of wiring, removal of the enclosure caps (Model 343F only), and viewing of an optional SmartDisplay or LCD display.

Model 343D - mount the transmitter by its DIN Rail Clip on a length of standard DIN rail supplied by the owner as shown below.



Model 343F - mount the transmitter as described in Section 4.4.1, 4.4.2, or 4.4.3.

4.4.1 Pipe Mounting

A Model 343F transmitter can be mounted to a vertical or horizontal 2-inch pipe using any one of the three optional mounting brackets. Refer to Figure 4-5 or 4-6 depending upon mounting bracket type.


1. Transmitter to Bracket Mounting

- 1) Align four mounting holes in the enclosure base with the four 0.281-inch diameter holes in the Bracket. The transmitter can be mounted to the Bracket in four possible positions (90° apart).
- 2) Using supplied 1/4-20 x 1/2 bolts, mount the transmitter to the bracket.

2. Bracket to Pipe Mounting

- 1) At the selected location, place the pipe-groove side of the mounting bracket against the pipe.
- 2) Slip the supplied U-bolt around the pipe and through one of the two pairs of mounting holes in the pipe-groove face plate of the bracket.
- 3) Place a supplied washer and hex nut on each end of the U-bolt and hand tighten the nuts. Rotate the bracket around the pipe to position the transmitter, then secure the bracket to the pipe.

3. Reposition the local display (if present) to provide the best possible view. See Section 4.4.4.



Use 1/4"-20 Bolts and Lockwashers to Mount Transmitter to Bracket, 4 places








FIGURE 4-5 Dimensions, Model 343 on a Universal Mounting Bracket

Notes:

- 1. Cold rolled steel and 316 stainless steel versions available.
- 2. Dimensions are in inches (millimeters).



MG001300

FIGURE 4-6 Model 343 on a 2" Pipe Mount Bracket (CRS or 316SS)

4.4.2 Flat Surface Mounting

To mount a Model 343F to a flat surface, use the Universal Mounting Bracket and user supplied 5/16-inch bolts or other hardware required for the selected surface.

1. Bracket To Flat Surface Mounting

- 1) Refer to Figure 4-5 for bracket and mounting hole dimensions.
- 2) Lay out the mounting hole pattern on the selected surface. Drill 0.343-inch diameter mounting holes to accept 5/16-inch bolts. The material and thickness of the mounting surface can affect the selection of mounting hardware.
- 3) Place the bracket against the mounting surface site as shown in Figure 4-5 and align the bracket and surface mounting holes. Install the bracket with user supplied 5/16-inch bolts, washers, and hex nuts or other user selected hardware.

2. Transmitter To Bracket Mounting

- 1) Mount transmitter to bracket as described in Section 4.4.1, step 1.
- 2) Reposition the transmitter's local display (if present) to provide the best possible view. Refer to Section 4.4.4.

4.4.3 Direct Mounting to Process


A Model 343F can be mounted directly at the point of measurement and supported by the thermowell, extension fittings, and probe assembly.

IMPORTANT


It is recommended that high temperature anti-seize compound be applied to the threads of thermowells, extension nipples, union connectors, and sensor assemblies.

Refer to Figures 4-7 and 4-8 and the following for mounting guidance:

1. Disconnect the thermowell from the Sensor Assembly at the union
2. Install the thermowell-nipple-union assembly on the process.
3. If required, install insulation around the surface area of the measurement point to limit the effects of heat radiating from the chamber, vessel, or pipe containing the process material.
4. Thread the remaining sensor-fitting-union into one of the transmitter's two conduit connections being careful not to damage the sensor lead wires. If it is desired to have terminal compartment access from the same direction as the Sensor Assembly, then thread an elbow-plus close nipple-plus coupling onto the fitting prior to threading the assembly into the transmitter. See Figure 4-7.
5. Insert the sensor assembly through the extension nipple and seat into the thermowell. Tighten the union together.
6. Refer to Section 4.5 to connect the sensor wires to the appropriate terminals.




WITHOUT DRAIN SEAL



MG001320

WITH DRAIN SEAL

FIGURE 4-7 Transmitter-To-Process Mounting



Notes:

1. Three styles of thermocouple probe junctions are shown.
2. An RTD probe is a closed end tube only. RTD sensors are not grounded.

FIGURE 4-8 Sensor Assembly

4.4.4 Local Display Installation and Removal

A SmartDisplay or LCD display plugs tightly into the transmitter module as shown. To orient a display, remove an installed display then remove and rotate the transmitter module. The module can be rotated in 90° increments using one of the two pairs of holes in the Model 343F enclosure and in the DIN clip. Refer to the following steps.




FIGURE 4-9 Rotating a SmartDisplay or LCD Display (Model 343F Shown)

1. Model 343F only - Remove the enclosure cap.
2. If a SmartDisplay or LCD display is installed, grasp the display at opposite edges and *pull the display straight out from the transmitter module*. Do not pry the display loose or cock the display during removal.
3. Disconnect sensor and signal wiring as necessary.
4. Remove the transmitter module by loosen the two mounting screws.
5. Orient the transmitter module so that its mounting screws align with one of two pairs of holes in the enclosure or DIN clip.
6. Insert the transmitter module into the enclosure or against the DIN clip and tighten the two mounting screws.
7. Complete any sensor or signal connections.
8. Orient the display so it plugs into the transmitter module. Press the display onto the transmitter module until all connections are made and the display is secure.
9. Model 343F only - Install the enclosure cap.

4.4.5 Electrical Conduit and Cable Installation

Electrical conduit and network, sensor, and power wire are supplied by the user. Access to Model 343F electrical terminals is described in Section 4.4.5.3.

For conduit and cable routing, refer to the user's installation drawings. Installation of conduit and cabling should follow the guidelines given below.

4.4.5.1 Conduit

- Model 343F conduit inlets accept male conduit fittings. Refer to the transmitter's nameplate and Section 8.1 to determine whether conduit threads are ½-14 NPT or M20 x 1.5.
- Seal ½ NPT fittings with teflon[®] tape; seal M20 fittings with a soft-setting sealing compound rated for at least 105°C (221°F).
- When routing conduit, avoid areas that might subject the conduit to chemical or physical abuse or areas with high EMI/RFI conditions.
- Long sensor cable runs should be installed in conduit between the transmitter and sensor.
- Install sensor cable in conduit in areas of high electrical interference.
- Install conduit for field wiring.
- If a high humidity environment can exist and the transmitter is located at a low point in the conduit run, install drain seals at the transmitter's conduit inlets to prevent condensation from entering the transmitter. See Figure 4-10.
- Remove all sharp edges or burrs from conduit that may damage wires.


4.4.5.2 Signal and Sensor Cables

- Mark or tag each signal cable conductor as either SIGNAL (+) or SIGNAL (-) to ensure correct connection at the transmitter.
- Mark or tag each sensor wire to be connected to a remote mounted transmitter to indicate its specific transmitter terminal number (1, 2, 3) connection


Examples: 3-wire RTD tag descriptors: RTD (+), RTDI, RTD (-)

Thermocouple tag descriptors: TC (+), TC (-)

- Use pulling grips and cable lubricants for easier cable pulling. Pull cable through conduit into transmitter terminal compartment.
- Thermocouple wire must be handled with care. Decalibration of the wire can be caused by cold-working the metal conductor as the wire is drawn through a conduit, by rough handling, or by vibration.
- Do not exceed the maximum permitted pulling tension on the cables. Maximum tension is normally specified as 40% of the cable's breaking strength.
- Do not exceed the maximum conduit fill specified by the National Electric Code.



Conduit Drain Installation



Explosion Proof Installation

MG001340

FIGURE 4-10 Conduit Drain and Explosion Proof Installations

4.4.5.3 Access to Transmitter Terminal Compartment

Two terminal areas for signal (loop), HART Communicator, and sensor connections are located on the transmitter module. For access to these terminals, see Section 4.4.4.

This completes the mechanical installation.

4.5 ELECTRICAL INSTALLATION

This section describes signal and sensor wiring. Refer also to Section 4.6 for installations in hazardous locations. Figure 4-11 shows signal and sensor termination terminals.

The following should already have been completed:

- Selection of either analog or digital operating mode and corresponding Point-To-Point or Multi-Drop Network; Section 4.3.3.
- Selection of a power supply; Section 4.3.4.
- Mechanical installation of transmitter(s) installed; Section 4.4.
- Pulling of loop and sensor cables through conduit and into terminal compartment; Section 4.4.5.
- Orientation of the transmitter module for desired display angle; Section 4.4.5.

Procedure

Transmitter module screws are #6. Stranded wire can be connected using ring tongue or spring spade terminals. Form solid wire into a hook or loop before securing under a screw.

Always wear a conductive wrist strap grounded to the enclosure ground screw, power supply ground or signal ground while wiring. Semiconductor devices must be protected from electrostatic discharge (ESD). A service kit with a wrist strap and static dissipative mat is available from Moore (PN 15545-110). Equivalent kits are available from both mail order and local electronic supply companies.

Wire the transmitter as follows.

1. Model 343F only - Remove the enclosure cap.
2. If a SmartDisplay or LCD display is installed, grasp the display at opposite edges and *pull the display straight out from the transmitter module*. Do not pry the display loose or cock the display during removal.
3. Model 343F only – If desired, loosen the two Module Mounting Screws and pull the module straight out from the enclosure. See Figure 4-11.

4. As oriented in Figure 4-11 there are two terminal areas with #6 screws for field connections.

Upper Terminal Area, Sensor Connections

- 1: RTD (+), OHM (+), TC (+), or mV (+) sensor connections
- 2: RTDI (+) sensor connection
- 3: RTD (-) or OHM (-); TC (-) or mV (-) sensor connections
- 4: RTDI (-) sensor connection

Lower Terminal Area, Signal/Loop Connections

- Signal/Loop (-): connection.
- Signal/Loop (+) connection.
- Two HART clips are provided for HART Communicator mini-grabber connections.




FIGURE 4-11 Signal (Loop), Sensor, HART Communicator and Display Terminals

4. Sensor Connections:

Hook each stripped solid wire end or insert each crimp-on terminal under the appropriate terminal screw and tighten the screw for a reliable electrical connection. Refer to Figure 4-12 for sensor connections.

- 1) RTD Sensor - Connect the tagged RTD leads as shown in Figure 4-12 detail A, B, or C, depending upon type of RTD used. Factory available RTD color codes are listed in Table 4.2. Be sure to install the appropriate jumpers as shown.
- 2) Thermocouple Sensor - Connect the tagged thermocouple extension leads as shown in Figure 4-12 detail D. Be sure to install any needed jumpers. The positive and negative thermocouple leads are color coded per ANSI standards as shown in Table 4.3. Thermocouple extension lead insulation should contact the terminal screw but not be under the screw. No bare extension lead should be visible.
- 3) Ohms-to-Milliampere Conversion - connect the OHM (+), OHM (-), and OHM I leads as shown in Figure 4-12 detail E, Ohms Input.
- 4) Millivolt-to-Milliampere Conversion - Connect the mV (+) and mV (-) leads as shown in Figure 4-12 detail F, mV Input.

5. Signal/Loop Connections:

- 1) Determine method of connection. Ring or spring spade crimp-on terminals are suggested.
- 2) Connect the loop cable to the (+) and (-) terminals. Refer to Figure 4-1, 4-2 or 4-3 for the needed connections for the desired type of Network. Terminals will accommodate wire sizes up to 10 AWG.

IMPORTANT

The cable shield must be insulated from all transmitter module terminals.
Refer to Section 4.3.11 for shielding and grounding information.

6. Inspect and confirm the proper connection of each wire.
7. Model 343F only – If the module was removed from the enclosure, carefully orient the module to align it with the threaded module mounting holes in the enclosure and gently insert the module into the enclosure. Tighten the two Module Mounting Screws.
8. If present, orient the optional display so it plugs into the transmitter module. Press the display onto the transmitter module until all connections are made and the display is secure.
9. Model 343F only - Install the enclosure cap.


IMPORTANT

Be certain that enclosure threads are coated with an anti-seize compound and that the cap seal (O-ring) is in place before installing a cap. A typical compound is Never-Seez by Emhart Bostik.


10. If one of the two electrical conduit entrances in the housing is not used, it should be plugged. Refer to the transmitter's nameplate and Section 8.1 to determine whether entrance holes accept ½-14 NPT or M20 x 1.5 fittings.

Seal ½ NPT fittings with teflon tape; seal M20 fittings with a soft setting sealing compound rated for at least 105°C (221°F).


This completes the physical installation.




A. 2-Wire RTD




B. 3-Wire RTD




C. 4-Wire RTD
(Remove Jumper)



D. Thermocouple



E. OHMS Input



F. mV Input

Notes:

1. Install jumper wire between terminals 1 and 2.
2. Install jumper wire between terminals 3 and 4.
3. Connect the sensor and signal cable shields and insulate from ground. Ground shields only at the power source or barrier.

FIGURE 4-12 Model 343 Sensor Wiring

MG001351

TABLE 4.2 RTD Wire Characteristics

RTD TYPE	POSITIVE LEADS		NEGATIVE LEADS	
	RTD (+)	RTDI (+)	RTD (-)	RTDI (-)
2 - Wire	White	N/A	Red	N/A
3 - Wire	White	White	Red	N/A
4 - Wire	White	White	Red	Red

TABLE 4.3 ANSI Thermocouple And Extension Grade Wire Characteristics

ANSI TYPE	POSITIVE LEAD		NEGATIVE LEAD		BARE WIRE CHARACTERISTICS	
	T/C	METAL	COLOR	METAL		COLOR
T		Copper	Blue	Constantan	Red	Copper - yellow Constantan - silver
J		Iron	White	Constantan	Red	Iron - magnetic Constantan - non-magnetic
E		Chromel	Purple	Constantan	Red	Chromel - shiny metal Constantan - dull metal
K		Chromel	Yellow	Alumel	Red	Chromel - non-magnetic Alumel - magnetic
S		Platinum & 10% Rhodium	Black	Pure Platinum	Red	---
R		Platinum & 13% Rhodium	Black	Pure Platinum	Red	---
B		Platinum & 30% Rhodium	Gray	Platinum with 0.6% Rhodium	Red	---



5.0 CONFIGURATION AND OPERATION

Each transmitter is shipped with default data stored in its memory. Some of this data controls communication and transmitter operation and cannot be altered by the user. Other data is used to make the transmitter respond to changes in temperature with a change in current or digital output and is alterable by the user. This data includes configuration parameters that are used to set up the transmitter.

The first part of this section contains the steps to configure and monitor a Model 343 from a 275 HART Communicator. The latter part of the section describes local operation of a transmitter using the optional SmartDisplay pushbuttons.

5.1 REMOTE CONFIGURATION AND OPERATION (MODEL 275 HART COMMUNICATOR)

Following are the basic concepts needed to configure a Model 343 from a Model 275 HART Communicator. Communicator operation is described in Section 2. See Appendix A for a detailed explanation of each Model 343 configuration parameter.

5.1.1 Function Blocks

The Model 343 is configured using the function block concept in which related parameters are grouped together into six function blocks: Write Protect, Sensor Input, Characterizer, Operator Display, Transmitter ID and Output. These function blocks are interconnected in a predetermined manner which can not be altered by the user. See Appendix A for a diagram of function block arrangement.

5.1.2 Recommended Configuration Procedure

1. Using Appendix B, document the desired configuration for the transmitter at hand. Be sure to include the nameplate and tag information. Appendix B also indicates the default value for each parameter. If a default value is acceptable it does not need to be altered.
2. Power the transmitter and establish communication as detailed in Section 3.
3. From the Online Menu select Configure XMTR.
4. From the Configure XMTR Menu select the first function block to be configured.
5. From the Function Block Menu select the first parameter within that block to be edited.
6. Continue selecting and editing parameters until all function blocks and parameters have been configured.
7. SEND the new configuration to the transmitter by selecting SEND from the Configure XMTR Menu (always the F2 key). Note: Sensor Input Block parameters are automatically sent to the transmitter as each parameter is edited individually.
8. If desired SAVE the new configuration (within the HART Communicator) by selecting SAVE from the Configure XMTR Menu (always the F2 key after a SEND has been performed).
9. Save a hard copy of the configuration, Appendix B, for your maintenance records.

5.1.3 Write-Protect Block

The Write-Protect Block protects the transmitter from unauthorized configuration changes. To enable or disable write-protect:

1. Press “1”, Write Protect, from the Configure XMTR Menu.
2. Use the ARROW Keys to highlight *enable* or *disable* and then press “F4”, Enter.
3. SEND your change to the transmitter by pressing “F2”, SEND, from the Configure XMTR Menu, or continue configuring other function blocks.

```
MPCO 343:TT100
Configure XMTR ←
1->Write Protect
2 Sensor Input
3 Characterizer
↓4 Operator Display
HELP |SAVE |HOME
```

```
MPCO 343:TT100
Write Protect ←
1->Disable
2 Enable

|ABORT |ENTER
```

5.1.4 Sensor Input Block

The Sensor Input Block contains the sensor and measurement parameters. Essential to the operation of the transmitter, these parameters are automatically downloaded to the transmitter as each is individually entered. No SEND operation is required. The transmitter will always confirm this with the user.

5.1.4.1 Sensor Type Settings

To configure the Sensor Type:

1. Press “2”, Sensor Input, from the Configure XMTR Menu.
2. Press “1”, Sensor Type.
3. Using the ARROW KEYS, highlight the type of sensor to be used.
4. Press “F4”, Enter.

The HART Communicator will automatically send this information to the transmitter. The transmitter will then prompt the user for Linearization.

1. Using the ARROW KEYS, highlight ON or OFF (for thermocouples and RTDs this should be ON).
2. Press “F4”, Enter.

```
MPCO 343:TT100
Configure XMTR ←
2->Sensor Input
3 Characterizer
4 Operator Display
↓5 Transmitter ID
HELP |SAVE |HOME
```

```
MPCO 343:TT100
Sensor Input ←
1->Sensor Type
2 MV Units
3 MV Low
↓4 MV High
HELP |SAVE |ABORT
```

```
MPCO 343:TT100
Sensor Type
Pt100 Sama
Pt100 Sama
Ni 100 DIN
↓SAMA Ni

|ABORT |ENTER
```

```
MPCO 343:TT100
Linearization Mode
On
On
Off

|ABORT |ENTER
```

Next, the transmitter will prompt the user for the type of Sensor Connection.

1. Using the ARROW KEYS, highlight the connection being made.
2. Press “F4”, Enter, then “F4”, OK.

```
MPCO 343:TT100
Sensor Connection
Four Wire RTD
Two Wire RTD
Three Wire RTD
Four Wire RTD
|ABORT |ENTER
```

If a thermocouple sensor was selected the HART Communicator will also prompt the user for the method of Cold Junction Compensation to be used.

1. Using the ARROW KEYS, highlight the desired Cold Junction Compensation method.
2. Press “F4”, Enter, then “F4”, OK.

```
MPCO 343:TT100
Cold Junction Comp
Actual CJ Comp
Actual CJ Comp
Without CJ Comp
Fixed CJ Comp
|ABORT |ENTER
```

5.1.4.2 Measured Variable Units

Only ohm, mV or a valid temperature unit may be selected as a unit of measure.

1. Press “2” from the Sensor Input Block Menu.
2. Using the ARROW KEYS select the desired units.
3. Press “F4”, Enter, then “F4”, OK.

```
MPCO 343:TT100
MV Units
DegF
DegC
DegF
↓DegR
|ABORT |ENTER
```

5.1.4.3 Measure Variable Low/High

These parameters range the transmitter.

1. Press “3/4” from the Sensor Input Block Menu.
2. Using the numeric keypad, enter the desired low/high range value.
3. Press “F4”, Enter, then “F4”, OK.

```
MPCO 343:TT100
Enter MV High
200.00 DegC
200.00 DegC
HELP |DEL |ABORT |ENTER
```

5.1.4.4 Damping, Smart Smoothing & Validation Settings

These three parameters define the software filtering used for the sensor input.

1. Press “5, 7 or 8” from the Sensor Input Block Menu.
2. Using the numeric keypad, enter the desired value in seconds.
3. Press “F4”, Enter, then “F4”, OK.

```
MPCO 343:TT100
Enter Damping
(32 Sec Maximum)
2.00 Sec
2.00 Sec
HELP |DEL |ABORT |ENTER
```

5.1.4.5 Line Frequency Filter Setting

This parameter defines the power line filtering used for the sensor input.

1. Press “6” from the Sensor Input Block Menu.
2. Using the ARROW KEYS, highlight the desired value.
3. Press “F4”, Enter, the “F4”, OK.

```

MPCO 343:TT100
Line Frequency
60 Hz, High Filter
 50 Hz, High Filter
 50 Hz, High Speed
↓60 Hz, High Filter
                |ABORT |ENTER
    
```

5.1.4.6 Active Input

The Active Input feature is used to configure the Measured Variable Range to a secondary temperature source.

1. Press “9” from the Sensor Input Block Menu.
2. Press “1” to select the MV Low parameter.
3. Press “F4”, OK.
4. Press “F4”, OK.
5. Apply the desired MV Low value to the transmitter terminals and press “2”, read new value.
6. Press “1” to accept this new value as the MV Low, or repeat the previous step.
7. Press “F4”, OK.

Repeat this process for the MV High parameter.

```

MPCO 343:TT100
Active Input      ←
Apply MV Low
Apply MV High

HELP |SAVE |HOME
    
```

```

MPCO 343:TT100
Warn - Loop should be
removed from
automatic control.

                |ABORT |OK
    
```

```

MPCO 343:TT100
MV = 158.00 DegC
MV Low = 0.00 DegC

                |ABORT |OK
    
```

```

MPCO 343:TT100
New MV Low 158.00
1->Accept New Value
2 Read New Value
3 Abort

                |ABORT |ENTER
    
```

5.1.5 Characterizer Block

This is a 22 point characterizer used for performing sensor matching or linearization of non-supported elements.

1. Press “3” from the Configure XMTR Menu.
2. Use the numeric keypad to enter the number of points for the characterizer.
3. Press “F4”, Enter.
4. Use the numeric keypad to enter coordinate X0.
5. Press “F4”, Enter.
6. Use the numeric keypad to enter coordinate Y0.
7. Press “F4”, Enter.
8. Press “F4”, OK, to authorize the transmitter to turn the characterizer ON.
9. Using the numeric keypad, continue entering X and Y coordinates for each remaining characterizer point.
10. Press “F4”, OK, to continue.

```
MPCO 343:TT100
Configure XMTR ←
3->Characterizer
4 Operator Display
5 Transmitter ID
6 Output
HELP |SAVE |ABORT
```

```
MPCO 343:TT100
Enter the number of
points
(min-2, max-22)
10
10
|DEL |ABORT |ENTER
```

```
MPCO 343:TT100
X0
Unit: DegC
0.00
0.00
|DEL |ABORT |ENTER
```

```
MPCO 343:TT100
Y0
Unit: DegC
0.00
0.00C
|DEL |ABORT
|ENTER
```

```
MPCO 343:TT100
Warning: Turning
Characterizer ON
```

```
MPCO 343:TT100
Characterizer turned ON
with 10 points

|OK
```

5.1.6 Operator Display Block

This block configures the Operator Display.

5.1.6.1 Display Setting

1. Press “1” from the Operator Display Block Menu.
2. Use the ARROW KEYS to select the desired display setting.
3. Press “F4”, Enter.
4. Press “F2”, Send, or continue configuring other parameters.

```
MPCO 343:TT100
Configure XMTR      ←
 2 Sensor Input
 3 Characterizer
4->Operator Display
↓5 Transmitter ID
HELP |SAVE |ABORT
```

5.1.6.2 Display Label

1. Press “2” from the Operator Display Block Menu.
2. Use the Alphanumeric Keys to enter the desired display label. Remember to use the shift keys for letters above each number on the keypad.
3. Press “F4”, Enter.
4. Press “F2”, Send, or continue configuring other parameters.

```
MPCO 343:TT100
Operator Display   ←
 1->Display Setting
 2 Display Label
 3 Display Language
 4 Local Pushbuttons
HELP |SEND |ABORT |HOME
```

5.1.6.3 Display Language

1. Press “3” from the Operator Display Block Menu.
2. Use the ARROW KEYS to select the desired language.
3. Press “F4”, Enter.
4. Press “F2”, Send, or continue configuring other parameters.

```
MPCO 343:TT100
Display Label
1234567
1234567
HELP |DEL |ESC |ENTER
```

5.1.6.4 Local Pushbuttons

1. Press “4” from the Operator Display Block Menu.
2. Use the ARROW KEYS to enable or disable transmitter configuration from the local SmartDisplay pushbuttons.
3. Press “F4”, Enter.
4. Press “F2”, Send, or continue configuring other parameters.

```
MPCO 343:TT100
Display Language
English
English
German
Spanish
|ABORT |ENTER
```

```
MPCO 343:TT100
Local Pushbuttons
Enable
Enable
Disable
|ESC |ENTER
```

5.1.7 Transmitter ID Block

This block configures information about the transmitter.

5.1.7.1 Tag, Descriptor, Message & Sensor Serial Number

1. Press “1” though “4” from the Transmitter ID Block Menu.
2. Use the Alphanumeric Keypad to enter information about the transmitter. Remember to use the shift keys for letters above each number on the keypad.
3. Press “F4”, Enter.
4. Press “F2”, Send, or continue configuring other parameters.

```
MPCO 343:TT100
Configure XMTR      ←
 2 Sensor Input
 3 Characterizer
 4 Operator Display
↓5->Transmitter ID
HELP | SEND | ABORT
```

```
MPCO 343:TT100
Transmitter ID     ←
 1->Tag
 2 Description
 3 Message
↓4 Sensor S/N
HELP | SAVE | HOME
```

5.1.7.2 Date

1. Press “5” from the Transmitter ID Block Menu.
2. Use the Numeric Keys to enter the desired date in MM/DD/YY format.
3. Press “F4”, Enter.
4. Press “F2”, Send, or continue configuring other parameters.

```
MPCO 343:TT100
Message
Shop Calibration Date
Shop Calibration Date
HELP | DEL | ABORT | ENTER
```

5.1.7.3 Polling Address

1. Press “6” from the Transmitter ID Block Menu.
2. Use the Numeric Keys to enter a polling address: 0 for analog; 1-15 for multi-drop.
3. Press “F4”, Enter.
4. Press “F2”, Send, or continue configuring other parameters.

```
MPCO 343:TT100
Date
11/19/97
11/19/97
HELP |           | ESC | ENTER
```

```
MPCO 343:TT100
Poll Address
0
0
HELP | DEL | ABORT | ENTER
```

5.1.8 Output Block

The Output Block contains parameters for configuring transmitter failsafe. As these parameters are critical to transmitter operation, each is automatically downloaded after being edited.

5.1.8.1 Sensor Failsafe Detection

1. Press “1” from the Output Block Menu.
2. Use the ARROW KEYS to enable or disable sensor failsafe detection.
3. Press “F4”, Enter, then “F4”, OK.
4. Press “F2”, Send, or continue configuring other parameters.

```

MPCO 343:TT100
Output
1->Failsafe Detection
2 Failsafe

HELP |SAVE |HOME
    
```

```

MPCO 343:TT100
Sensor Failsafe
Detection
ON
On
Off
|ABORT |ENTER
    
```

5.1.8.2 Failsafe

1. Press “2” from the Output Block Menu.
2. Use the ARROW KEYS to select the desired failsafe level for the analog output.
3. Press “F4”, Enter, then “F4”, OK.
4. Press “F2”, Send, or continue configuring other parameters.

```

MPCO 343:TT100
Failsafe
High - 23.0 mA
Off
Low - 3.6 mA
High - 23.0 mA
|ABORT |ENTER
    
```

```

MPCO 343:TT100
Failsafe
On - 23.0 mA

|OK
    
```

5.2 QUICK ACCESS KEY FUNCTIONS

Access the Quick Access Key functions by pressing the Quick Access Key to power-up the Communicator or from any online menu when connected to a transmitter.

The three factory programmed Quick Access Key options provided with Model 343 Transmitters are:

- XMTR Variables
- Status
- Range XMTR

User selected options can be added to the Quick Access Key menu; see Section 2.6.1.

5.2.1 XMTR Variables

Read-Only parameters from the XMTR Variables menu are supplied “live” from the transmitter, as follows:

TABLE 5.1 XMTR Variable Parameters

MENU ITEM	PARAMETER	DESCRIPTION
1	MV	Measured variable
2	I	Current Output.
3	%	Percent Output
4	Internal Temperature	Internal Temperature (Used for CJ compensation)

Note: From the XMTR Variables Menu, press a key from “1” through “4” to observe the desired variable if it is not displayed on the screen.

5.2.2 Status

The Status menu provides data about the transmitter, as follows:

TABLE 5.2 Status Parameters

MENU ITEM	PARAMETER	DESCRIPTION
1	Model Information	Model number and other identification data.
2	Errors	Check for errors and report.

Note: From the Status Menu, press “1” or “2” to observe the desired variable if it is not displayed on the screen.

5.2.3 Range XMTR

The Range XMTR feature provides quick access to the transmitter range parameters. These parameters can all be found in the Sensor Input Block under the Online\Configure XMTR menu.


TABLE 5.3 Range XMTR Parameters

MENU ITEM	PARAMETER	DESCRIPTION
1	Select Sensor	Configure the sensor type and connection
2	MV Units	Measured Variable Units
3	MV Low	Measured Variable Low (4 mA)
4	MV High	Measure Variable High (20 mA)

Note: From the Range XMTR Menu, press a key from “1” through “4” to adjust the desired variable.

5.3 LOCAL CONFIGURATION (SMARTDISPLAY PUSHBUTTONS)

A Model 343 with a SmartDisplay can be configured using two local pushbuttons labeled NEXT and ENTER.



5.3.1 Available Parameters

Configuration from the local pushbuttons permits access only to a subset of the transmitter parameters. Table 5.4 lists the parameters available and the abbreviation that appear on the local display.

TABLE 5.4 Local Configuration Parameters

Function Block	Parameter	Display Abbreviation	Available Selections
Sensor Input Block	Sensor Type/Sensor Connection	Select Input?	RTD: 2, 3, 4 W DIN, SAMA, SPEC T/C: B, C, E, J, K, L, N, R, S, T, U, SPEC mV, ohm, HHT Only (275 programmable only)
Sensor Input Block	MV Units	Select Units?	Deg C/Deg F/Deg R/Deg K
Sensor Input Block	MV Low	Change Zero?	± 9999.9
Sensor Input Block	MV High	Change Full Scale?	± 9999.9
Output Block	Sensor Failsafe Detection	Select Sensor FailSafe?	On/Off
Output Block	Failsafe	Select Failsafe Report?	High/Low/Off
Calibration Routine		Trim 4mA?	See Section 7.1.3
Calibration Routine		Trim 20mA?	See Section 7.1.3
Operator Display Block	Display Language	Select Language?	English/German/French/Spanish

5.3.2 Configuration Example

The following is an example of the procedure for local editing of a configuration using the SmartDisplay pushbuttons. This section uses a two-column format with numbered steps on the left and display representations on the right. Before continuing, remove the enclosure cap from a Model 343F.

IMPORTANT

SmartDisplay pushbuttons can be disabled from a HART Communicator. Use a Hart Communicator to enable or disable the pushbuttons. See Appendix A, section A.4 for more information on this feature.

NOTE

The following is an example only. All parameters are not used in the example.

- Using your finger or the *eraser end* of a pencil to press the ENTER button.
- The display will flash **RETURN TO OPERATE MODE?**. Press the NEXT button to continue with configuration or press the ENTER button to return to normal operation. If left at this prompt for one minute, the transmitter will automatically return to the normal operating mode.

RETURN	TO
OPERATE	MODE ?

NOTE

Most messages need several screens. Each time you press the NEXT button wait momentarily to view the new parameter available for manipulation.

- Press ENTER. The display will flash **SELECT INPUT?** To edit the transmitter's Sensor Input type press ENTER, or press NEXT to move on to the next parameter.
- Press ENTER. The display now indicates the present setting for the input type. To select a different input type press the NEXT button. Continue to press the NEXT button until the desired input type is displayed. Press the ENTER button to select the displayed input type. The display will go blank for a few seconds while the transmitter stores this new input type.
- The display flashes **SELECT INPUT?**. Press the NEXT button to continue to the next parameter.

SELECT	INPUT ?
T/C K	T/C L
...	3W DINP

NOTE

Once a configuration is begun, each parameter must be toggled through before returning to the **RETURN TO OPERATE MODE?** query. The complete list of parameters is shown in Table 5.3.

- Press the NEXT button until the **CHANGE FULL SCALE?** message is displayed.
- Press ENTER to edit the MV High parameter. The display will display **PLUS?** Press ENTER to keep the value as a positive number. Press NEXT to toggle to **MINUS?** then press ENTER to enter the value as a negative number.

SELECT	INPUT ?
--------	---------

CHANGE	FULL
SCALE ?	

0100.0°C	0100.0°C
PLUS ?	MINUS ?

8. The display will now indicate the MV High parameter to 5 significant digits. The left most digit will be blinking and the display will indicate **THOUSN?** Use the NEXT button to change the value of the thousandths digit to the desired value then press ENTER. The display will change and now indicate **HUNDRD?** Again, press the NEXT button as required to edit the hundreds digit to the desired value. Press ENTER when done. Repeat this for the **TENS?**, **ONES?** and **TENTHS?** digit. After setting the tenths digit and pressing ENTER, the display will go blank for a few seconds while the transmitter stores this new MV High value
9. The display will now again flash **CHANGE FULL SCALE?**.
10. Press the NEXT button repeatedly until the **RETURN TO OPERATE MODE?** message appears. If other parameters must be changed, press NEXT to toggle through the complete list of parameters once again, otherwise press ENTER to return the display to normal operating mode.

- 0 <u>1</u> 00.0°C
THOUSN ?

- 2 <u>1</u> 00.0°C
HUNDRD ?

- 200 <u>0</u> .0°C
ONES ?

- 200 <u>0</u> .0°C
TENS ?

- 2000. <u>0</u> °C
TENTHS ?

RETURN

TO

OPERATE

MODE ?

6.0 POST INSTALLATION CHECKOUT

This section provides guidelines to verify that the proper transmitter is installed, correctly wired, and operational prior to placing the system in service. If the transmitter was not commissioned on the bench prior to installation, refer to Section 3 before proceeding.

6.1 EQUIPMENT REQUIRED

- User configuration data for transmitter(s) under test (see Appendix C)
- HART Communicator (see Section 2 of this manual)
- Digital multimeter (DMM); for measuring the 4 to 20 mA output signal


Voltmeter Section	Accuracy $\pm 0.01\%$ of reading
	Resolution 1.0 mV
Ammeter Section	Input impedance 10 M Ω
	Accuracy $\pm 0.1\%$ of reading
	Resolution $\pm 1 \mu\text{A}$
	Shunt resistance 15 Ω or less

6.2 INSTALLATION REVIEW

1. Note the model designation and certifications on the transmitter's nameplate and compare to model specified in user's documentation (P&I drawing).
2. Refer to Section 8 to confirm that the correct model with the correct certifications has been installed. Confirm that any needed hazardous area barriers have been installed and all other installation requirements have been met.
3. Check all wiring for correct and secure connection. Refer to Section 4 of this manual and user's documentation for wiring diagrams.
4. Check wire runs to be sure wires are protected from abrasion or other damage, correctly supported, and isolated from other signal or power wiring.
5. Check that a current sense resistor of the correct value has been installed.
6. Apply power to the power supply or other loop power source (e.g., controller). Use the DMM to check power supply output voltage.

6.3 EQUIPMENT CONNECTION

1. Connect the HART Communicator across a network junction, the current sense resistor, range resistor, or the transmitter under test as shown in Figure 6-1. There is no connection polarity as the HART Communicator is a non-polar device.
2. Connect a DMM in series with either loop wire; see Figure 6-1. Set the DMM to read 4-20 mA.



Notes:

1. HART Communicator Connections:
 - Non-hazardous location - Connect as shown above.
 - Hazardous location - Refer to the Communicator nameplate and the Manual supplied with the Communicator for certifications and approvals before connecting.
2. Connect the DMM (set to mA) in series with either loop wire. Remove jumper to install DMM and replace when DMM is removed.

FIGURE 6-1 Equipment Connections for System Checkout

6.4 VERIFICATION

This section covers communication test, communication error check, analog output verification, and configuration verification.

6.4.1 Communication Test

This test verifies that the HART Communicator and transmitter(s) can communicate properly. From user configuration documentation, obtain transmitter IDs, addresses, and tags.

1. Turn on the HART Communicator.

If the Communicator finds a transmitter on a Point-To-Point Network, the Online menu with the transmitter's type and tag name is displayed. Go to Section 6.4.2.

If the Communicator displays: No device found at address 0. Poll?, go to either step 2 or 3.

2. POINT-TO-POINT NETWORK

Check the following: Communicator connections, all other loop connections, power to transmitter, transmitter address (0), transmitter model number. Repair as necessary and repeat step 1.

3. MULTI-DROP NETWORK

Press Yes (F1) to enter digital mode and search for devices with polling addresses of 1-15.

If the Communicator finds a transmitter on a Multi-Drop Network, the Online menu with the transmitter's type and tag name is displayed. Each transmitter connected to the loop can be interrogated in sequence. Go to the next Section.

If the Communicator displays: *No device found*. Press OK, check all loop connections, power to transmitters, transmitter addresses (1-15), transmitter model numbers, etc. Repair as necessary and repeat step 1. Also make sure the Communicator is configured to poll for transmitters in the digital mode. Refer to Section 2.5.4.1 for information on this feature.

6.4.2 Communications Error Check

1. Establish communication. Press the Quick Access Key to display the Quick Access Key menu.
2. Press "2" on the keypad to display the Status menu. Press "2" again to start checking for errors. The Communicator checks for errors.
3. If no error is present, the message "No Errors" displays. Go to step 4.
4. If one or more errors is detected, one or more error codes is displayed. Go to step 4, then refer to Section 7.3 Troubleshooting to confirm and resolve the error(s).
5. Press OK (F4). Turn off the Communicator or press the LEFT ARROW/PREVIOUS MENU key to return to the menu for the next procedure.

6.4.3 Verify Analog Output Signal

This test verifies that a transmitter is operating properly and is capable of transmitting a 0% or 100% analog output signal that can be received at its destination. The test applies only to transmitters operating in analog mode.

1. Establish communication. Press "1" or RIGHT ARROW/SELECT to select Loop Override.
2. A warning appears: "WARN-Loop should be removed from automatic control." If the loop status cannot be changed for operational reasons, press ABORT (F3) to end this procedure and return to the Online menu. To proceed with verification, go to step 3.

3. Remove the loop from automatic control, then press OK (F4). When OK is pressed, a list of analog output options is displayed (at right).
4. Press “1” on the keypad or ENTER (F4) to select the 4 mA option. The Communicator displays the message “Fld dev output is fixed at 4.000 mA.” Press OK (F4) to confirm and proceed with testing or press ABORT (F3) and proceed to step 8.
5. Read the DMM. The value should be 4 mA.
6. Repeat steps 4 and 5 using the 20 mA output level. The DMM reading should be 20 mA.
7. For outputs other than 4 or 20 mA, choose option 3, Other, and enter any desired output value. The DMM reading should be the entered value in mA.
8. To end the loop override session, press “4” on the keypad or the ABORT (F3) softkey. The message “Returning fld dev to original output” appears.
9. When the message “NOTE–Loop may be returned to automatic control” appears, return the loop to automatic control, then press OK (F4). This completes verification of analog output.

MPCO 343:TT100	
Choose analog output level	
1	4mA
2	20mA
3	Other
4	End
ABORT ENTER	

IMPORTANT

Failure to exit loop override correctly can cause the transmitter to remain parked at a fixed current.

This completes the system checkout. Disconnect test equipment, connect any disconnected wires, and restore any removed protective covers on the transmitter or other devices.



7.0 CALIBRATION AND MAINTENANCE

This section describes calibration, preventive maintenance, and troubleshooting.

The Calibration section contains procedures to calibrate a Model 343's Digital to Analog Converter (DAC). The input circuitry of the Model 343 is self-calibrating and never requires user adjustment.

The Maintenance section has preventive maintenance procedures that are employed to prevent conditions from occurring that would be detrimental to the reliability of the Transmitter. Should a malfunction occur, troubleshooting procedures will assist in minimizing down-time. This section also includes Transmitter removal and replacement procedures, recommended spare and replacement parts, and an exploded view drawing with a parts list.

WARNING

In Division 1 areas, where an explosion-proof rating is required, *remove power from the Transmitter* before removing the Transmitter's end cap for access to the electrical terminal compartment.

7.1 CALIBRATION

A Transmitter is calibrated at the factory and should not require field calibration. Section 7.1.2 describes field calibration of a Transmitter.

A Model 275 can be used for calibration. It provides three calibration programs:

- DAC Output - Calibrates the Digital-to-Analog Converter that sets the transmitter's analog output signal.
- DAC Reset - Resets DAC to factory settings.
- Lead Wire Trim - For a 2-wire RTD, trims the lead wire resistance.

Alternately, if a local SmartDisplay is installed, the pushbuttons may be used to perform the DAC Output calibration.

Recommended test equipment is listed in Section 7.1.1 and typical wiring diagrams are shown in Figures 7-1 and 7-2.

7.1.1 Equipment Required

- Model 275 Universal HART Communicator - refer to Section 2 of this User's Manual
- Digital multimeter (DMM); for calibrating the 4 to 20 mA output signal

Voltmeter Input	Accuracy +/-0.01% of reading
	Resolution 1.0 mV
	Input impedance 10 MS
Ammeter Input	Accuracy +/-0.1% of reading
	Resolution +/-1 μ A
	Shunt resistance 15S or less
- 24 Vdc power supply; for bench calibration
- Resistor 250 Ω +/-1%, carbon, 1/4 watt; for bench calibration

7.1.2 Calibrate Digital-to-Analog Converter (DAC) Using 275 HART Communicator

Calibration of the DAC is not normally required and should be performed only after all other options have been exhausted. Bench calibration is recommended; perform steps 1 through 15.

1. Disconnect the transmitter from the process by performing the steps in Section 7.5.

NOTE

Removing a transmitter can interrupt power to other transmitters powered from a common power source. Note the effect this can have on process control and operation and, if necessary, follow the proper procedures to shut down the process.

When disconnecting the LOOP leads, carefully insulate each lead as it is removed to prevent accidental shorts.

2. Remove the enclosure cap to access the terminal compartment.
3. Connect the HART Communicator and DMM to the loop as shown in either Figure 7-1 or 7-2. Set the DMM to measure mA.
4. Establish communication between the Communicator and transmitter. Refer to Section 3.2 as necessary.
5. Be sure the polling address is set to 0 (analog mode). Refer to Appendix A as necessary.
6. From the Online menu, press "2" to display the Calibrate/Test menu.
7. Press "2" to begin the Calibrate DAC process. The Communicator displays the message "WARN-Loop should be removed from automatic control." If it is permissible to do this, do so, and press OK (F4). If not, press ABORT (F3) to terminate this procedure.
8. If OK was pressed, the Communicator displays the reminder message "Connect reference meter." If necessary, press ABORT (F3) to terminate the procedure and make the meter connection. Return to step 3 and start over.
9. If OK was pressed, the Communicator displays "Setting fld dev output to 4 mA." Press OK (F4) to continue or press ABORT (F3) to terminate the procedure.




FIGURE 7-1 Bench Test Connections






FIGURE 7-2 Field Test Connections

9. Observe the DMM reading, type the reading on the screen displayed (at right), and press ENTER (F4) to confirm the value. Press ABORT (F3) to terminate the procedure without calibrating the DAC.
10. The Communicator displays a confirmation message “Fld dev output 4.000 mA equal to reference meter?” If this is true, press “1” to indicate YES. If it is false, press “2” to indicate NO.
11. If the answer NO is selected, the display goes back to the one shown in step 9. Enter the correct value and proceed.
12. After completing the 4.000 mA calibration, the Communicator displays the message “Setting fld dev output to 20 mA.” Press OK (F4) to continue or press ABORT (F3) to terminate the procedure.
13. Observe the DMM reading, type the reading on the screen displayed (at right), and press ENTER (F4) to confirm the value. Press ABORT (F3) to terminate the procedure without calibrating the DAC.
14. The Communicator displays a confirmation message “Fld dev output 20.000 mA equal to reference meter?” If this is true, press “1” to indicate YES. If it is false, press “2” to indicate NO.
15. If the answer NO is selected, the display goes back to the one shown in step 12. Enter the correct value and proceed.
16. After completing the 20.000 mA calibration, the Communicator displays the message “Returning fld dev to original output” followed by the “Loop may be returned to automatic control.” Press OK (F4) to continue and terminate the procedure.
17. Disconnect the test equipment, reconnect the jumper on the circuit junction terminals (Figure 7-2), and if necessary return the polling address to the appropriate value.




This completes DAC calibration of the transmitter.


7.1.3 Calibrate Digital-to-Analog Converter (DAC) Using SmartDisplay Pushbuttons

Perform steps 1-3 shown in section 7.1.2, then return to this section and perform the following steps.

1. Press the ENTER pushbutton. The display indicates **RETURN TO OPERATE MODE ?** Press NEXT.
2. Press NEXT five times until **TRIM 4 MA ?** is displayed. Press ENTER



3. View the output current on the DMM. It should be 4.00 mA. Use the NEXT pushbutton to select if the output current needs to be raised or lowered. If the output current is correct select either, it does not matter. Press ENTER.
4. The display now indicates **NEXT = +** (or -). Use the NEXT pushbutton to adjust the output current. Depress the NEXT pushbutton only once at a time, viewing the DMM measured value after each adjustment. When the DMM reads 4.00mA, press ENTER. If no adjustment is required simply press ENTER.
5. The display reverts to **TRIM 4 MA ?** indication. Press NEXT to move ahead to the **TRIM 20 MA ?** display. Press ENTER and repeat the procedure above to trim the 20mA value.
6. When finished, press NEXT three times until the display indicates **RETURN TO OPERATE MODE ?** Press ENTER to return to normal operation.



7.1.4 Reset Digital to Analog Converter (DAC)

This procedure resets the DAC to factory settings.

Press "3" from the Calibrate/Test Menu.

1. The transmitter will warn the user that the impending procedure will effect the transmitter output. Press F4, "OK" to confirm the procedure.
2. Next the transmitter will prompt the user, "OK to reset DAC to factory settings?" Press F4 to perform this operation, or press F3 to ABORT.
3. The transmitter will next advise the user that the loop may be returned to automatic control. Press F4, OK.

7.1.5 2-Wire RTD Lead Wire Trim

This procedure measures and trims the lead wire resistance in a 2-Wire RTD.

1. Press "4" from the Calibrate/Test Menu.

7.2 PREVENTIVE MAINTENANCE

Preventive maintenance consists of periodic inspection of the Transmitter, cleaning the external surface of the Transmitter's enclosure and draining condensate from. Preventive maintenance should be performed at regularly scheduled intervals.

7.2.1 Tool and Equipment Requirements

The following tools and equipment are required for servicing:

- Set of Phillips and flat-blade screwdrivers.
- Digital Multimeter (DMM); see Section 7.1.1 for specifications

7.2.2 Transmitter Exterior Inspection, Model 343F Only

The frequency of the inspection will depend on the severity of the Transmitter's environment.

1. Inspect the exterior of the Transmitter enclosure for accumulated oil, dust, dirt, and especially any corrosive process overspray.
2. Check that the enclosure cap is fully threaded onto the enclosure, compressing the O-ring between the cap and the enclosure. The O-ring must not be cracked, broken, or otherwise damaged.
3. If a SmartDisplay is installed, inspect the protective viewing glass in the enclosure cap for cleanliness and damage. A cracked or punctured glass must be replaced; see Section 7.4 and the Parts List at the back of this Manual.
4. Inspect both enclosure conduit entrances for possible moisture leaks. An unused conduit entrance must be plugged and sealed. Inspect the cable clamps of all watertight cable conduits for loose clamps and deteriorated sealing material. Tighten clamps and reseal as necessary.
5. If a conduit drain is installed, inspect the drain seals for obstructions.
6. If subjected to vibration, inspect all transmitter and mounting bracket hardware for tightness. Tighten loose hardware as necessary. Consider steps to reduce vibration.
7. Inspect T/C or RTD process connection for evidence of leakage. Repair as necessary.

7.2.3 Transmitter Exterior Cleaning, Model 343F Only

After an exterior inspection of the Transmitter, the enclosure can be cleaned with the Transmitter operating.

1. Clean the enclosure (except enclosure cap glass) with a mild, nonabrasive liquid detergent, and a soft bristle brush, sponge, or cloth. Rinse the weatherproof enclosure with a gentle spraying of water.

If the Transmitter is subjected to heavy process overspray, keep the enclosure free of excessive accumulation of process residue. Hot water or air may be used to flush away process residue if the temperature of the cleaning medium does not exceed the operating temperatures of the Transmitter as listed in Section 8.3.5 Environmental.

2. Clean enclosure cap glass with a mild nonabrasive liquid cleaner and a soft, lint-free cloth.

7.2.4 Transmitter Enclosure Interior Inspection, Model 343F Only

Remove the enclosure cap periodically to inspect the interior of the enclosure's terminal compartment. Because the enclosure is sealed, there should be no accumulation of dust, dirt, or water (condensate) in the interior. If condensate is present, a conduit drain must be installed. See Figure 4-10.

Check that all wire connections are tight.

Enclosure threads *must be coated* with a wet, paste-type, anti-seize compound such as Never-Seez by Emhart Bostik. Inspect the enclosure O-ring for damage.

7.2.5 Transmitter Calibration

The Model 343 is self-calibrating and does not require calibration.

7.3 TROUBLESHOOTING

This Section provides guidance and procedures to assist in identifying and correcting a malfunctioning transmitter. Section 7.2.1 lists needed tools and equipment.

Make all documentation associated with the transmitter, including piping and loop wiring diagrams and configuration documentation, available to maintenance personnel to facilitate troubleshooting.

The most common symptom of a malfunctioning transmitter is incorrect, erratic, or no output. A malfunction can affect the transmitter's analog output (4-20 mA) or its digital (HART) output. Furthermore, a malfunction can be the result of external forces and not a transmitter fault at all. Section 7.3.1 discusses troubleshooting techniques for the analog output. Section 7.3.2 discusses troubleshooting techniques for the digital (HART) output. Section 7.3.3 describes verifying a true transmitter failure should Section 7.3.1 or 7.3.2 not yield desirable results.

7.3.1 Analog Output

An analog output problem can appear as one of the following:

- No output or very low output. – There is no transmitter output or the output remains low despite changes in the process.
- High output. – Transmitter output remains high despite changes in the process.
- Erratic output. – Transmitter output varies when process does not.
- Sluggish Response – Transmitter seems to respond to process changes very slowly.

Often an analog output problem is caused by incorrect transmitter configuration or by something external to the transmitter. The following list shows possible causes and corrective actions for these problems. If reviewing this list and performing applicable corrective actions does not remedy the problem, proceed to Section 7.3.3 Diagnosing a Defective Transmitter.

Check Sensor

- Check for a disconnected, open or burned out sensor.
- Check for a shorted sensor.

Check Loop Power Supply/Wiring

- Check loop power supply for blown fuse or tripped circuit breaker.
- Check for 12 Vdc minimum across loop +/- terminals in transmitter terminal compartment.
- Check power supply output voltage: 17 Vdc minimum; 42 Vdc maximum.
- Check polarity of loop wiring at both power supply and transmitter.
- Check for loose or broken loop wiring at power supply terminals, supply barriers (if used), junction boxes, and transmitter terminal compartment.
- Check for disconnected or broken current sense resistor.
- Check for short between shield and loop + wire.
- Check for accumulation of moisture in transmitter terminal compartment.
- Check loop cable for proper type and length.
- Check for electrical interference between the loop cable and any adjacent cables in a cable tray or conduit.

Check Transmitter Configuration

- Check for proper operating mode and address: analog, 0; digital, 1-15.
- Check input type, linearization, and filtering.
- Check characterizer status: on or off.

Check for a Transmitter Stuck in Override Mode

- Re-enter Loop Override from HART Communicator Online menu and properly exit Loop Override Mode.

7.3.2 Digital Output (Communication)

A malfunctioning digital output can indicate a defective communication circuit. More commonly, however, these problems are caused by an incorrect or poor installation. It is possible to install a transmitter such that the 4-20 mA signal is correct, yet the digital HART signal is not.

The most common symptom of a communication problem is the inability to locate a transmitter on the loop using a HART Master Device, such as the HART Communicator. Typical messages from the HART Communicator include: device disconnected, no device found, or communication error.

If communication problems occur, check the following. Refer to the specifications in Section 9 as necessary.

- Check that loop resistance is between 250 Ω and 1100 Ω .
- Check that loop electrical noise is not excessive; power supply ripple should not exceed 12 mVp-p.

- Check that any high inductance devices in the loop have a HART communication filter installed across the device's loop terminals.
- Check that the power supply voltage is high enough for the installed total loop resistance. Refer to Section 4.
- Refer to Section 4 and confirm that loop cable length is not excessive.
- Check that the HART Master is connected across a load.

7.3.3 Diagnosing a Defective Transmitter

Should the above not remedy the problem, the sensor or transmitter module may have failed.

If HART communication is functioning, use the HART Communicator to access the transmitter. Microprocessor based self-diagnostic tests continuously examine the sensor assembly and electronics module.

Perform the procedure below to access the diagnostic displays and determine if a fault exists.

1. If not already in communication with the suspect transmitter, establish communication (see Section 3.2).
2. Press the Quick Access Key and then press "2" to view the Status Menu. If "FAILSAFE" is displayed the transmitter has entered the failsafe mode.
3. From the Status menu, press "2" to obtain a list of errors. Note the displayed error message (multiple errors can be displayed).
4. Confirm that the fault still exists. Press the Quick Access Key again to return to the Online menu. Activate the selftest function by choosing "2" Calibrate/Test, then press "1" to perform a self-test. The transmitter will display a warning message, then perform the test.
 - If the fault was temporary – possibly as a result of excessive electrical noise or a power line spike – the Communicator will display "Transmitter PASSED transmitter selftest." If the transmitter passes the selftest, it automatically exits the failsafe mode and resumes normal operation. No further action is required.
 - If the fault remains, the Communicator displays the message "Transmitter FAILED transmitter selftest." Repeat the test for additional confirmation. If the transmitter fails again, see Section 7.5 to replace a transmitter. Send the removed transmitter to the factory for repair; see Section 7.9.

7.3.4 Enclosure Thread Lubrication

An Model 343F enclosure cap should turn smoothly and easily on the enclosure threads. These threads are factory coated with a wet, paste-type, anti-seize compound such as Never-Seez by Emhart Bostik.

- Do not use force to thread a cap onto the enclosure.
- Be careful not to wipe off the lubricant while handling the transmitter.
- Re-coat the enclosure threads if the cap is at all difficult to turn on the enclosure threads.
- Always inspect the enclosure O-ring for damage before installing a cap.

7.4 NON-FIELD-REPLACEABLE ITEMS

- Enclosure Cap Display Viewing Glass: Agency regulations do not permit field replacement of a broken or damaged glass as this would invalidate the enclosure's explosion proof rating. Replace the entire damaged enclosure cap assembly.

7.5 TRANSMITTER REPLACEMENT

To replace a Transmitter, refer to the procedure below and one or more of the following Sections in the Installation section of this Manual:

- 4.4 Mechanical Installation
- 4.5 Electrical Installation

WARNING

Before loosening a sensor process connection, be certain that process material will not cause injury to personnel. Drain process material as necessary.

REMOVAL

1. Remove power from the Transmitter.
2. Remove enclosure end cap from a Model 343F.
3. Unplug the display (if installed). Refer to Section 4.4.4. Carefully set the display aside.
4. Carefully label and disconnect loop and sensor (e.g., T/C or RTD) wiring.
5. Disconnect conduit from a Model 343F.
6. Loosen two screws to remove a Model 343D from the DIN clip; four screws to remove a Model 343D from the mounting bracket.

REPLACEMENT

1. Fasten a Model 343D to a DIN clip or a Model 343F to a mounting bracket. Refer to the Mechanical Installation section as necessary.
2. Connect conduit to a Model 343F.
3. Carefully connect signal (loop) and sensor wiring to the Transmitter.
4. Apply power to the Transmitter and configure. Refer to Section 5 On-Line Configuration and Operation and to Appendix A Function Blocks.
5. Check all connections.
6. Install enclosure end cap in a Model 343F.

7.6 MAINTENANCE RECORDS

An accurate record keeping system for tracking maintenance operations should be established and kept up to date. Data extracted from the record may serve as a base for ordering maintenance supplies, including spare parts. The record may also be useful as a troubleshooting tool. In addition, maintenance records

may be required to provide documentary information in association with a service contract. It is suggested that, as appropriate, the following information be recorded:

1. Date of service incident
2. Name or initials of service person
3. Brief description of incident symptoms and repairs performed
4. Replacement part or assembly number
5. Software compatibility code of original part
6. Software code of replacement part
7. Serial number of original part
8. Serial number of replacement part
9. Issue number of original circuit module
10. Issue number of replacement circuit module
11. Date of completion

7.7 RECOMMENDED SPARE AND REPLACEMENT PARTS

The quantity and variety of on-hand spare parts is determined by the time a Transmitter can be permitted to remain out of service or off-line. Refer to the Parts List at the back of this Manual for recommended on-hand spare parts.

Replaceable parts are listed in the Parts List at the back of this Manual.

To replace a display module, refer to Section 4.4.4 and the Parts List drawing at the back of this Manual. Transmitter module replacement is outlined in Section 7.5.

When ordering a part, provide the following information for the item, module or assembly to be replaced or spared. This information will help insure that a repair technician addresses the observed problem, and that a compatible part is supplied.

1. Part number from Parts List or from a label on assembly
2. The single number software compatibility code
3. Serial number from the label on the Transmitter's nameplate
4. User purchase order number of original order, available from user records
5. New user purchase order number for the assembly to be replaced or spared
6. Reason for return for repair; include system failure symptoms, station failure symptoms, and error codes displayed.

Returns should be packaged in original shipping materials if possible. Otherwise, package item for safe shipment or contact factory for shipping recommendations. Refer to Section 7.9 to obtain a Return Material Authorization number.

7.8 SOFTWARE COMPATIBILITY

A single number software compatibility code identifies Transmitter software revision level. This software controls the Transmitter's operating routines and its HART communications with loop connected stations and gateways.

To read the software level of a Transmitter:

1. Establish communication with the transmitter (see Section 3.2).
2. From the Online menu, press the Quick Access Key.
3. From the Quick Access Key menu, press “2” to access the Status menu, then press “1.” to access the Model Number menu.
4. The third item on the Model Number menu is the software revision number. If this number is not displayed, press “3” to display the Software rev screen, then press EXIT (F4).
5. Turn off the Communicator or press the Quick Access Key to return to the Online menu.

7.9 RETURN SHIPMENT

The return of equipment or parts for any reason must always be coordinated with the manufacturer. Should it become necessary to make a return shipment, be sure to contact Moore Products Co. first and obtain packaging information and carrier recommendations.

Equipment Returned Within North America

To Return Equipment

- Call the Repair Service Group at (215) 646-7400, ext. 4RMA (4762) weekdays between 8:00 a.m. and 4:45 p.m. Eastern Time to obtain an RMA number. Mark the RMA number prominently on the outside of the shipment.
- When calling for an RMA number, provide the reason for the return. If returning equipment for repair, failure information (e.g., error code, failure symptom, installation environment) will be requested. A purchase order number will be requested.

Material Safety Data Sheet

- A Material Safety Data Sheet (MSDS) must be included with each item being returned that was stored or used anywhere hazardous materials were present.

Packaging

- Package assembly in original shipping materials. Otherwise, package it for safe shipment or contact the factory for shipping recommendations. A module must be placed inside a static shielding bag to protect it from electrostatic discharge.

Equipment Returned Outside of North America

Contact the nearest Moore Products subsidiary. Subsidiaries are listed at www.mooreproducts.com. Provide the reason for the return. A purchase order number will be requested. Request equipment packaging and shipping instructions.



8.0 MODEL DESIGNATION AND SPECIFICATIONS

This section contains the model designation table, accessory tables, and specifications.

8.1 MODEL DESIGNATION

Table 8.1 identifies each model designation entry on a transmitter's nameplate. The nameplate also carries other important transmitter information in addition to the model designation: bill of material number (B/M), serial number, span limits, factory calibration (FCTY CAL), and certifications.

IMPORTANT

Confirm transmitter model by referring to the transmitter's model designation on its nameplate and Table 8.1 before installing, applying or removing power, configuring or servicing.

TABLE 8.1 Model 343 Model Designation

BASIC MODEL NUMBER

343D DIN Rail Temperature Transmitter
 343F Field-Mount Temperature Transmitter

Output

A 4-20mA Smart Transmitter with HART Protocol

Output Indicator

N Not Required

1 LCD Display (*No Engineering Units, Value Indicated Only*)

5 SmartDisplay™ (*Indicates °C or °F, Includes Configuration Pushbuttons*)

Standard Options

N Not Required

Y Special Features (*Please Describe*)

Mounting Bracket

1 2" Pipe Mount Bracket with SS Hardware (*Model 343F Only*)

2 Universal Bracket with SS Hardware (*Model 343F Only*)

3 2" Pipe Mount Bracket All SS (*Model 343F Only*)

5 DIN Rail Clip (*Model 343D Only*)

N Not Required

Housing

N Not Required (*Model 343D Only*)

1 Aluminum 1/2" - 14 NPT (*Model 343F Only*)

Aluminum M20 x 1.5 (*Model 343F Only, Not Available with FM/CSA Units*)

Hazardous Area Classifications (1)

3 FM/CSA All (*Model 343F Only*)

7 FM/CSA Intrinsically Safe/Non-Incendive (*Model 343D Only*) (1)

X CENELEC EExia (1)

M CENELEC EExd (*Model 343F Only*) (1)

R SAA Exia/Exd/DIP + ABS Type (Exd & ABS For *Model 343F Only*) (1)

W FM/CSA "3" Approval + ABS Type Approved (*Model 343F Only*) (1)

N Not Required

343F A N N 1 1 N Sample Model No.

(1) Some approvals and certifications were pending when this manual was printed. Contact the factory or your local Moore sales office or subsidiary for the latest information.

8.2 ACCESSORIES

Table 8.2 lists the general accessories available for the transmitter. Accessories are ordered separately since they are not included in a transmitter's model number.

Table 8.3 lists the thermal sensors commonly available for the transmitter. Each sensor can be provided as an integral or remote assembly. The integral version, shown in Figure 8-1, provides a direct connection that becomes part of the transmitter assembly. The remote version, shown in Figure 8-2, includes a connection head that provides a termination point for the sensor wires, allowing the sensor to be installed separately.

TABLE 8.2 General Accessories


DESCRIPTION	PART NUMBER
Transient Protection*	14999-287
General Purpose Power Supply, 24 Vdc, 2A*	15124-1
Field Mounted Power Supply, 28 Vdc, 125 mA* (NEMA 4x, EP)	16055-299
Communication Filter Kit*	16202-3
SmartDisplay Kit	
LCD Meter Kit*	
Model 275 HART Communicator	275D9EI5B0100

TABLE 8.3 Thermal Sensors


DESCRIPTION	BASIC REFERENCE NUMBER
Threaded Bar Stock Well Assembly	344T1**
Flanged Bar Stock Assembly	344T2**
Socket or Weld-In Assembly	344T3**
Flanged Pipe Well Assembly	344T5**
Industrial Assembly (No Thermowell)	344T6**
Sanitary Probe	344T7** and 344T8**

* Refer to GC MC-1 for additional details.

** Refer to GC MC-1 for ordering information.



Thermocouple Thermowell Assembly




3-Wire RTD Thermowell Assembly

X02815S0

Note:
Typical Well Lengths in Inches (Centimeters).

3.50(8.9)	6.00(15.2)	8.00(20.3)	10.00(25.4)	12.00(30.5)
-----------	------------	------------	-------------	-------------

FIGURE 8-1 Typical TC and RTD Thermowell Assemblies without Heads



Note:
Typical Well Lengths in Inches (Centimeters).

X02816S0

3.50(8.9)	6.00(15.2)	8.00(20.3)	10.00(25.4)	12.00(30.5)
-----------	------------	------------	-------------	-------------

FIGURE 8-2 Typical TC or RTD Assembly with Head

Notes for Figures 8-1 and 8-2:

1. 'A' Dimension, Extension Assembly - Joins connection head or transmitter to thermowell.
2. 'F' Dimension, Process Connection - Provides connection to process vessel.
3. 'U' Dimension, Probe - The length of the thermowell assembly inserted into the process (immersion).

8.3 SPECIFICATIONS

The following specifications are for all transmitter models except as noted.

8.3.1 Mechanical

8.3.1.1 Model 343D (DIN Rail)

Transmitter Dimensions	Figure 8-3
Mounting Clip Dimensions	Figure 4-5
Housing	Sealed Plastic (Waterproof Potting)
Electrical Connections	Screw Terminals, 10-26 AWG (5.3-0.14 mm ²)
Weight	4 oz. (111.1 g)




FIGURE 8-3 Model 343D Dimensions

8.3.1.2 Model 343F (Field-Mount Enclosure)

Transmitter Dimensions	Figure 8-4
Mounting Bracket Dimensions	Figure 4-5
Housing	Cast Aluminum, NEMA 4X, IP66/68
Conduit Entrances	(2) 1/2 - 14 NPT, M20 x 1.5 optional
Electrical Connections	Screw Terminals, 10-26 AWG (5.3-0.14 mm ²)
Weight	2.7 lbs. (1.2 kg)




FIGURE 8-4 Model 343F Dimensions

8.3.2 Functional and Performance

Range/Sensor Input Types.....See Table 8.4

TABLE 8.4 Sensors: Type, Range and Accuracy

SENSOR INPUT	INPUT RANGE		ACCURACY ⁽¹⁾
	°C	°F	
RTD - 2,3,4-Wire			
100Ω Pt DIN α = 0.00385	-200 to 850	-328 to 1562	±0.14°C
100Ω Pt SAMA α = 0.003902	-200 to 650	-328 to 1202	±0.14°C
120Ω Ni	-80 to 320	-112 to 608	±0.14°C
100Ω Ni	-60 to 250	-76 to 482	±0.14°C
10Ω Cu	-70 to 150	-94 to 302	±0.14°C
Thermocouples			
Type B NBS	43 to 1800	109 to 3272	±0.8°C (1.5°F)
Type C NBS	0 to 2320	32 to 4208	±0.8°C (1.5°F)
Type E NBS	-270 to 1000	-454 to 1832	±0.3°C (0.5°F)
Type J NBS	-210 to 1200	-346 to 2192	±0.3°C (0.5°F)
Type K NBS	-270 to 1372	-454 to 2502	±0.3°C (0.5°F)
Type L NBS	-200 to 900	-328 to 1652	±0.3°C (0.5°F)
Type N NBS	270 to 1300	518 to 2372	±0.3°C (0.5°F)
Type R NBS	50 to 1768	122 to 3214	±0.8°C (1.5°F)
Type S NBS	-50 to 1768	-58 to 3214	±0.8°C (1.5°F)
Type T NBS	-270 to 400	-454 to 752	±0.3°C (0.5°F)
Type U NBS	-200 to 600	-328 to 1112	±0.8°C (1.5°F)
Millivolt			
Millivolt	-15 to 115 mV		±0.01 mV
Ohm Input			
Ohm	0 to 500Ω		±0.06Ω

Note:

(1) Includes transmitter's absolute digital accuracy and ambient temperature effect over the entire operating range.

Digital Input Accuracy±0.05% of the equivalent mV or ohm reading,
or the accuracy shown in Table 8.6, whichever is
greater.

Cold Junction Measurement Accuracy±0.5°C (±0.9°F), THERMOCOUPLE ONLY

D/A Converter Accuracy±0.05% of span

Total Accuracy = Digital Accuracy + Cold Junction Accuracy + D/A Converter Accuracy

Stability±0.05% of reading ±3.6 μA for 12 months

Update Rate 150 milliseconds

Damping 0 to 32 seconds

Outputs

Analog.....	Two-wire with digital communication superimposed on the 4-20 mA signal, Max, less than 25 mAdc, Min., greater than 3.84 mAdc
Digital	HART protocol

Power Supply

Minimum Compliance Voltage	+12 Vdc with no loop resistance, see Figure 4-4
Maximum Voltage	+42 Vdc
Reverse Polarity Protection	±42 Vdc
Network Resistance (R_L).....	250 Ω minimum, 1100 Ω maximum * $R_L = 43.4V_S - 520.8$; where $V_S =$ PS voltage
Maximum Ripple	0.2 Vp-p, 47-125 Hz
Maximum Noise	0.6 mV RMS maximum
Impedance	10 Ohms maximum

Power Supply Effect Less than 0.005% of output span per volt

Transmitter Input Capacitance 27,000 pF, HART $C_n = 6$; refer to Section 4.3.5

Network Topology**Point-To-Point**

Transmitter Quantity	1
Network Signal and Connection	Analog 4-20 mA, single current loop; see Figures 4-1 and 4-2
Network Resistance	See Figure 4-4

Multi-Drop

Transmitter Quantity	1 to 15
Network Signal and Connection	Digital, parallel connected; see Figure 4-3
Network Resistance	See Figure 4-4

Transmitter Input/Output Isolation

Between Input/Output Terminal	250 Vac, 800 Vdc
Between Case and Network Wiring	250 Vac, 800 Vdc

8.3.3 Two-Wire Cable

Type Twisted Single-Pair, Shielded, Copper

Conductor Size for Network Length

Less than 5000 ft. (1500 m)	24 AWG minimum
More than 5000 ft. (1500 m)	20 AWG minimum, 16 AWG maximum

Cable Capacitance Refer to Section 4.3.5

Recommendation Belden 8641, 24 AWG
Belden 8762, 20 AWG

Maximum Length Refer to Section 4.3.5

8.3.4 Sensor Inputs

Common Mode Rejection	120 dB
Response Time	250mS, typical
Thermocouple (TC)	
Reference Junction Compensation	Owner Selectable
Input Impedance	Greater than 200,000 Ohms
Thermocouple Burnout Direction	HART selectable (UP/DOWN)
Conformity	$\pm 0.05^{\circ}\text{C}$
Millivolt (mV)	
Input Impedance	Greater than 1 Megohm
RTD	
Input Impedance	Greater than 1 Megohm
Ohm	
Input Impedance	Greater than 1 Megohm

8.3.5 Environmental

Ambient Temperature Range, Storage & Operating

Operating	-40° to 85°C (-40° to 185°F)
Display	-20° to 70°C (-4° to 158°F)
Storage	-40° to 85°C (-40° to 185°F)

Humidity

Operating	5-100% RH
Storage	0-100% RH, non-condensing

Maximum Moisture

Operating	Less than 0.050 lb. H ₂ O per lb. of dry air
Storage	Less than 0.028 lb. H ₂ O per lb. of dry air

Corrosive Atmosphere (343F Only).....Operates in Class G3 (Harsh) environment per ISA-S71.04 (Model 343F Only)

Vibration Effect (343F Only)Less than $\pm 0.05\%$ URL per G from 0 to 2000 Hz in any axis (per SAMA PMNC 31.1) up to 7Gs max

EMI Susceptibility

Less than 0.5% of reading at 10 V/m, 20kHz to 1000MHz per SAMA PMC 31.1c

ESD Susceptibility

IEC severity level 4, 15 kV

8.3.6 Hazardous Area Classification

CE Approved – EN50081-2 and EN50082-2; See Declaration of Conformity on a following page.

IMPORTANT

Some approvals and certifications were pending when this manual was printed. Contact the factory or a local Moore sales office or subsidiary for the latest information.

Before installing, applying power to, or servicing a transmitter, see the transmitter's nameplate and the Table in section 8.1 for the electrical classification.

8.3.7 Special Conditions For Safe Use

CE – Acceptance criterion a; $\pm 1\%$ F.S. Passing deviations $>1\%$ are possible.

DECLARATION OF CONFORMITY

according to EN 45014

Moore Products Co.
Sumneytown Pike
Spring House, PA 19477

Declare under our sole responsibility that the product,

Model 343 Temperature Transmitter when labeled with the CE mark

to which this declaration relates is in conformity with the following standards or other normative documents

- EN50081-2, Electromagnetic compatibility: Generic emission standard Industrial environment (acceptance criterion a; +/- 1% F.S. Passing deviations >1% are possible)
- EN50082-2, Electromagnetic compatibility: Generic immunity standard Industrial environment

following the provisions of the:

- EMC Directive 89/336/EEC and amended by 91/263/EEC, 92/31/EEC and 93/68/EEC

Manufactured in Spring House, PA U. S. A.

Date:

5/14/98



John C. Grebe
Director
Embedded Product Development

European Community Representative:
Moore Products Co. (UK) Ltd.

Date: 14TH MAY 1998



John Stansfield
Engineering Services Manager

9.0 GLOSSARY

Listed here are terms used in the field of temperature measurement and terms relevant to HART networks.

ALPHA - The average percent change in resistance per degree of a pure metal resistance device between 0 and 100 degrees Centigrade. Designated by the Greek letter alpha.

ANALOG SIGNALING - A low current signal of 4 to 20 mAdc from a Field Instrument to a Primary Master or non-signaling hardware.

ANSI - American National Standards Institute

AWG - American Wire Gauge

BARRIER - A device whose function is to limit the voltage and current in the hazardous area even if certain types of faults occur on the non-hazardous side of the Barrier.

BARRIER RESISTANCE - The maximum end-to-end resistance of a barrier, as specified by the barrier manufacturer. If both supply and return barriers are used in a network, the barrier resistance is the sum of the end-to-end resistance of both barriers. For active barriers that use resistance to limit current, the barrier resistance is the internal resistance between the hazardous area terminal and the barrier internal node where voltage is regulated.

COMMISSIONING - Testing of a transmitter and loop to verify transmitter configuration and loop operation and wiring.

CONFIGURATION - A database (or archive) created using a HART Communicator and downloaded to a transmitter to define transmitter operation.

CONFIGURE/CONFIGURING - The entering of specific parameter data into a HART Communicator to be downloaded to a transmitter to define that transmitter's operating characteristics.

CONNECTION HEAD - An enclosure attached to the head of a thermocouple or RTD within which the electrical connections are made.

CURRENT SENSE RESISTANCE - The resistance in a Network across which the field instrument (Transmitter) signal voltages are developed.

DAMPING - A user selectable output characteristic that increases the response time of a transmitter to smooth the output when the input signal contains rapid variations.

DIN - Deutsche Industrial Norms - A German agency that sets engineering and dimensional standards and has world-wide recognition.

DIN 43760 - The standard that defines the characteristics of a 100 ohm platinum RTD having an R versus T curve with an Alpha of 0.00385 ohms per ohm per degree C.

DIGITAL SIGNALING - The high frequency HART signal.

EXPLOSION-PROOF ENCLOSURE - An enclosure that can withstand an explosion of gases within it and prevent the explosion of gases surrounding it due to sparks, flashes, or the explosion of the container itself, and maintain an external temperature which will not ignite the surrounding gases.

FIELD INSTRUMENT - A network element that uses current variation for digital signaling or digital plus analog signaling.

HART - Highway Addressable Remote Transducer - A communication protocol that provides simultaneous analog and digital signaling between master and slave devices. It is supported by the HART Communication Foundation.

HART NETWORK - A single pair of cabled wires and the attached communicating HART elements.

LOWER RANGE LIMIT (LRL) - Determined by the transmitter's range, this is the lowest value of the measured variable that the transmitter can be configured to measure.

LOWER RANGE VALUE (LRV) - Representing the 4 mA point in the transmitter's output, this is the lowest value of the measured variable that the transmitter is currently configured to measure.

INTRINSICALLY SAFE INSTRUMENT - An instrument which will not produce any spark or thermal effects under normal or abnormal conditions that will ignite a specified gas mixture.

MAXIMUM OVERRANGE - The maximum pressure (static plus differential) that can safely be applied to a transmitter.

MULTI-DROP NETWORK - A HART Network having from one to fifteen field instruments that are parallel connected on a single 2-wire cable. This Network uses digital signaling only. Analog signaling is not employed.

NETWORK - A Network includes the following items:

- Transmitter(s)
- Network Element (controller, recorder, passive non-signaling element, or other device)
- Cabling interconnecting these devices
- Barriers for intrinsic safety, if installed
- Current sense resistor

NETWORK ELEMENT - Any field instrument or Primary or Secondary Master.

NETWORK RESISTANCE - Defined as the sum of the Current Sense Resistance, Barrier Resistance, if any, and any other resistance in the Network.

NPT - National Pipe Thread

POINT-TO-POINT NETWORK - A Network having a single field instrument and Primary Master. Analog signaling or analog plus digital signaling is possible.

PRIMARY MASTER - The single controlling Network Element that communicates with one or more field instruments.

RERANGING - Changing the transmitter's 4 and 20 mA settings (i.e., setting LRV and URV); this is a configuration function.

RTD - Resistance temperature detector - A temperature transducer based on the principle that the resistivity of a metal shows a marked temperature dependence.

SECONDARY MASTER - An occasional user of the Network such as the HART Communicator.

SPAN - Algebraic difference between the upper and lower range values (URV and LRV).

TEMPERATURE TRANSMITTER (TWO-WIRE) - A device which is used to transmit temperature data from either a thermocouple or RTD via a two-wire current loop. The loop provides power to the transmitter which acts as a variable resistor with respect to its input signal.

THERMOWELL - A closed-end tube designed to protect temperature sensors from severe environments , high pressure, and flows. Usually made of corrosion-resistant metal or ceramic material.

TRANSDUCER - A device that accepts an input, such as pressure, and converts that input into an output of some other form, such as a voltage.

TRANSMITTER POLLING ADDRESS - A unique number assigned during configuration that identifies a transmitter connected to a network. An address between 1 and 15 is assigned to a transmitter connected to a Multi-Drop network. A transmitter connected to a point-to-point network has 0 as an address.

UPPER RANGE LIMIT (URL) - Determined by the transmitter's range, this is the highest value of the measured variable that the transmitter can be configured to measure.

UPPER RANGE VALUE (URV) - Representing the 20 mA point in the transmitter's output, this is the highest value of the measured variable that the transmitter is currently configured to measure.

■

APPENDIX A - FUNCTION BLOCKS

This section provides a detailed description of each function block in a Model 343 Temperature Transmitter. Default configuration information can be found in Appendix B. Below is a block diagram of the function block arrangement in the transmitter.


A.1 WRITE PROTECT BLOCK

The write protect parameter, when enabled, blocks all HART commands which write to the transmitter. The transmitter will still be accessible by a Model 275 HART Communicator or other HART Master, but these devices will only be able to read data from the transmitter. For example, if write protect is enabled the transmitter can not be re-ranged. To enable write commands, disable the write protect parameter.

A.2 SENSOR INPUT BLOCK

The Sensor Input Block allows the user to configure those parameters which pertain to the temperature sensor and measurement. Sensor Input Block parameters are listed below; a description of each parameter then follows.

- Sensor Type..... See Table Below
- Linearization..... Linearization/Off
- Sensor Connection See Table Below
- Cold Junction Compensation Actual CJ Temp
Without CJ Temp
Fixed CJ Temp
External via Ni120
- Internal Temperature Units..... °C, °F
- Measured Variable Units..... °C, °F, °R, °K, Ohms, mV
- Measured Variable Low
- Measured Variable High
- Damping.....0 to 32 Seconds
- Line Frequency Filter 50 Hz High Filter
50 Hz High Speed
60 Hz High Filter
60 Hz High Speed
- Smart Smoothing0 to 32 Seconds
- Validation Time0.25 to 10 Seconds
- Active Input.....See Below



MG001370

Sensor Type

This parameter defines the primary temperature sensor that is to be used with the transmitter. The following sensor types are available.

TABLE A-1. Sensor Types

SENSOR INPUT	INPUT RANGE		ACCURACY ⁽¹⁾
	°C	°F	
RTD 2, 3, or 4-Wire			
100Ω Pt DIN α = 0.00385	-200 to 850	-328 to 1562	±0.14°C
100Ω Pt SAMA α = 0.003902	-200 to 650	-328 to 1202	±0.14°C
120Ω Ni	-80 to 320	-112 to 608	±0.14°C
100Ω Ni	-60 to 250	-76 to 482	±0.14°C
10Ω Cu	-70 to 150	-94 to 302	±0.14°C
Thermocouple			
Type B NBS	43 to 1800	109 to 3272	±0.8°C (1.5°F)
Type C NBS	0 to 2320	32 to 4208	±0.8°C (1.5°F)
Type E NBS	-270 to 1000	-454 to 1832	±0.3°C (0.5°F)
Type J NBS	-210 to 1200	-346 to 2192	±0.3°C (0.5°F)
Type K NBS	-270 to 1372	-454 to 2502	±0.3°C (0.5°F)
Type L NBS	-200 to 900	-328 to 1652	±0.3°C (0.5°F)
Type N NBS	270 to 1300	518 to 2372	±0.3°C (0.5°F)
Type R NBS	50 to 1768	122 to 3214	±0.8°C (1.5°F)
Type S NBS	-50 to 1768	-58 to 3214	±0.8°C (1.5°F)
Type T NBS	-270 to 400	-454 to 752	±0.3°C (0.5°F)
Type U NBS	-200 to 600	-328 to 1112	±0.8°C (1.5°F)
Millivolt			
mV	-15 to 115 mV		±0.01 mV
Ohm			
ohm	0 to 500Ω		±0.06Ω

(1) Includes transmitter's absolute digital accuracy and ambient temperature effect over the entire temperature range.

Sensor Connection

This parameter defines how the primary temperature sensor will be physically connected to the transmitter.

TABLE A-2 Sensor Connections

Millivolt
Thermocouple
Ohm
2-Wire RTD
3-Wire RTD
4-Wire RTD

If the Sensor Type is selected as millivolts or ohms the Sensor Connection will automatically default to that value as well.

Linearization

This parameter defines if the transmitter output will be linear with temperature. For millivolt and ohm input types the linearization parameter is automatically set as “off.” For all other input Sensor Types this parameter should be configured as “linearization.”

Cold Junction Compensation

For thermocouple Sensor Types this parameter defines how cold junction compensation is performed. The following options are available.

Actual CJ Temp - The transmitter uses the actual measured temperature of the thermocouple terminal blocks for its cold junction compensation. This is the most common form of cold junction compensation and will yield the best accuracy.

Without CJ Temp - This disables the CJ compensation.

Fixed CJ Temp - The transmitter uses a fixed value for cold junction compensation. The value must be entered in degrees Celsius.

External via Ni120 - The cold junction temperature is determined by measuring an external two-wire Ni120 RTD connected to terminals 3 and 4.

Internal Temperature Units

This is the unit of measure for the Actual CJ Temp value. Only °C or °F is allowed.

Measured Variable Units

This parameter defines the unit of measure for the transmitter.

Measured Variable Low & Measured Variable High

Also known as the Lower and Upper Range Values (LRV and URV respectively), these two parameters define the range of the transmitter. The MV Low parameter will cause the transmitter to output 4mA. The MV High parameter will cause the transmitter to output 20mA. These two parameters are non-interactive. Changing one does not effect the other. Furthermore, these parameters can be configured to make the transmitter forward or reverse acting, that is, the MV High parameter does not have to be configured for a higher temperature than the MV Low parameter. For example, 100 to 0 DegF is an allowable range with 4mA being transmitted at 100 DegF and 20mA being transmitted at 0 DegF.

The actual limits for the MV Low and High parameters are determined by the particular sensor type being used. These limits are shown in Table A1.

Damping

The damping parameter defines the s/w time constant for the transmitter. This can be set anywhere between 0 and 32 seconds to help smooth process noise.

Line Frequency Filter

By setting this parameter to the local line frequency, power line induced interference may be reduced. Select high speed to maintain optimum transmitter response time. For extreme noise conditions select high filter; however, in doing this the update rate of the transmitter is doubled.

Smart Smoothing

The Model 343 has the ability to average successive A/D readings to achieve a high level of accuracy. The Smart Smoothing feature is different from damping, and it normally does not interfere with operation in a control loop. Smart smoothing works by establishing a narrow tolerance band which defines an acceptable deviation from one A/D reading to the next. The magnitude of this tolerance band is ± 5 microvolts. With smart smoothing turned on, as long as a reading is within the tolerance band, it is averaged with previous readings and passed through to the transmitter output. However, if the reading is outside the tolerance band it is immediately passed through to the output and the smart smoothing is reset around this new reading. This ensures that any significant process change is reflected in the transmitter output without delay.

The magnitude of the smart smoothing tolerance band can not be altered by the user; however, the length of the smoothing time (number of readings to average) can be adjusted. Reducing the smart smoothing time constant will improve the transmitter response time to small changes within the tolerance band. The tradeoff is greater process noise.

The factory default for smart smoothing is 10 seconds, adjustable between 0 and 32 seconds.

Validation Time

The validation time defines the length of time the transmitter will attempt to validate information from the sensor. Validation time is the amount of dead time before the transmitter will respond to a variation in the input signal. The signal must be received longer than the validation time before the transmitter will recognize it as valid. This feature can be useful in configuring the transmitter to ignore process spikes and/or electrical noise.

The factory default for the validation time is 0.5 seconds and can be adjusted anywhere between 0.25 and 10 seconds.

Active Input

The feature allows the user to configure the LRV and URV using a temperature calibrator or other plant standard calibration device.

The measured value will be displayed on screen with the option to accept this value as the LRV or URV, or take a new measurement.

IMPORTANT

For thermocouple sensor types the Model 343 uses a technique of sending a small pulse current through the T/C to detect breaks in the sensor. This feature can cause measurement errors when used with some T/C calibrators. It is recommended that Sensor Failsafe Detection be disabled while the transmitter is calibrated with a T/C calibrator.

A.3 CHARACTERIZER

A 22-point characterizer is included for performing sensor matching or linearization of non-supported sensor types. The following parameters are used.

Number of Points 0 to 22
 Point Coordinates X0-X21, Y0-Y21

Number of Points

This parameter determines the number of points used in the characterizer. 0 points indicates the characterizer is “off.” Once characterizer points are configured they will be “remembered” as the characterizer is turned on/off. To clear a characterizer point it must be entered as 0,0.

X0, X21

The x-coordinates (input) of the characterizer in MV Units.

Y0, Y21

The y-coordinates (output) of the characterizer in MV Units.

A.4 OPERATOR DISPLAY BLOCK

The Operator Display Block is used to configure operation of the SmartDisplay. Operator Display Block parameters are listed below with a description of each following.

Display SettingPV, %, mA, Alternate PV
 Display Label 7 Character
 Display Language English, German, French, Spanish
 Local Pushbuttons..... Enabled/Disabled

Display Setting

This parameter determines which variable will be shown on the local SmartDisplay.

Display Label

This is a 7 character label which will be displayed on the bottom line of the display when the Display setting is configured for PV. When the display is configured for % or mA the appropriate label will automatically be displayed.

Display Language

Set the language for the display as English, German, French or Spanish.

Local Pushbuttons

This parameter enables or disables the local display pushbuttons.

A.5 TRANSMITTER ID BLOCK

This function block contains information pertinent to the transmitter's identity. The following parameters are available.

Tag	8 Character
Descriptor	16 Character
Message	32 Character
Sensor Serial Number.....	10 Character
Date	MM/DD/YY
Polling Address	0, analog; 1-15, digital

Tag, Descriptor, Message and Sensor Serial Number

These four parameters are ASCII text and have no bearing on transmitter output. Up to an 8-character tag, 16-character descriptor, 32-character message and 10-character sensor serial number (of connected temperature sensor) may be entered for the transmitter.

Date

The date parameter uses the international DD/MM/YY format. This date can be selected by the user to indicate any date or event, such as the date of installation or last date of service.

Polling Address

The polling address is used to place the transmitter in either analog or digital mode.

A polling address of 0 indicates the transmitter is in analog mode and will output 4-20mA current according to its calibrated range. In analog mode, a single transmitter is connected to a point-to-point network.

A polling address between 1 and 15 indicates the transmitter is in digital mode and will output a constant 4mA current. In digital mode up to 15 transmitters can be multi-dropped in a multi-drop network using single twisted pair cable. Each multi-drop transmitter must have a unique address. For information on multi-drop mode refer to Section 4.

A.6 OUTPUT BLOCK

The Output Block configures the failsafe options for the transmitter. The following parameters are used. A description of each follows.

Sensor Failsafe Detection.....Enable/Disable
FailsafeOff, Low, High, Other

Sensor Failsafe Detection

This parameter turns sensor failsafe detection on or off. When failsafe detection is on, the transmitter can detect and report T/C burnout as well as RTD opens/shorts.

IMPORTANT

For thermocouple sensor types the Model 343 uses a technique of sending a small pulse current through the T/C to detect breaks in the sensor. This feature can cause measurement errors when used with some T/C calibrators. It is recommended that Sensor Failsafe Detection be disabled while the transmitter is calibrated with a T/C calibrator.

Failsafe

This parameter defines what the transmitter output will be in the event of a failsafe condition. The selections are low (3.6mA), high (23mA) or other (user defined between 3.6 and 23mA). The Model 343 will enter failsafe mode if a sensor failure is detected or is transmitter failure is detected.



APPENDIX B - TRANSMITTER CONFIGURATION DOCUMENTATION

B.1 HOW TO USE THIS APENDIX

Use this appendix to record a transmitter's configuration. The transmitter may be on-site or it may be a pending purchase. Copy this appendix as necessary. Clearly record needed data as follows:

On-Site Transmitter Configuration Record

1. Copy transmitter nameplate information into the first table below.
2. Enter Customer Name and P.O. Number information into the second table below.
3. Record the transmitter's configuration data in the "Configured Value" column in the table on pages B-2, B-3, and B-4.

Data for Factory Configuration at Time of Purchase

1. Write the transmitter model number and tag on the simulated nameplate on the next page. Other information is factory supplied at the time of order.
2. Enter Customer Name and P.O. Number information in the box at the bottom of the next page.
3. Record the desired configuration on pages B-2, B-3, and B-4.
4. Attach a copy of these pages to your purchase order. Keep a copy for your files.

TRANSMITTER CONFIGURATION RECORD

MODEL NUMBER:
BILL OF MATERIAL:
SERIAL NUMBER:
INPUT TYPE:
FACTORY CALIBRATION:
TRANSMITTER TAG:

For Factory Configuration

Please enter your name and transmitter purchase order number if providing information for factory configuration of a transmitter.

Customer Company:
Customer P.O. Number:
Configuration Data Entered By:
<i>The Sales Order Number below will be entered by Moore Products Co.</i>
Moore Products Co. Sales Order Number:

These pages contain the following information for each function block: name, parameter(s), default(s), and blank space(s) to record specific transmitter data.

PARAMETER	RANGE OF VALUE	DEFAULT VALUE	CONFIGURED VALUE
Sensor Input Block			
Sensor Type	Pt100 DIN IEC, Pt100 SAMA, Ni120 DIN, SAMA Ni, Minco Ni120, B, C, E, J, K, DIN L, N, R, S, T, DIN U, ohm, mV, RTD Special, T/C Special	Pt100 DIN IEC	
Sensor Connection	ohm, mV, T/C, T/C Diff, 2-W, 3-W, 4-W, 2-W Diff, 2-W Ind, 2- W Secure, 2-W Avg	3-Wire RTD	
Linearization	Linearization/Off	Linearization	
Cold Junction Compensation	Actual, Without, Fixed, External	Actual CJ Temp	
Internal Temperature Units	°C, °F	°C	
Measure Variable Units	°C, °F, °R, °K, mV, ohm	°C	
Measured Variable Low		0	
Measured Variable High		100	
Damping	0-32 Sec	1 Sec	
Line Frequency Filter	50Hz, High Speed 50Hz, High Filter 60Hz, High Speed 60Hz, High Filter	60Hz, High Speed	
Smart Smoothing	0 to 32 Sec	10 Sec	
Validation Time	0.25 to 10 Sec	0.5 Sec	
Characterizer Block			
Number of Points	0 to 22	0	
X0		0	
X1		0	
X2		0	
X3		0	
X4		0	
X5		0	
X6		0	
X7		0	

PARAMETER	RANGE OF VALUE	DEFAULT VALUE	CONFIGURED VALUE
X8		0	
X9		0	
X10		0	
X11		0	
X12		0	
X13		0	
X14		0	
X15		0	
X16		0	
X17		0	
X18		0	
X19		0	
X20		0	
X21		0	
Y0		0	
Y1		0	
Y2		0	
Y3		0	
Y4		0	
Y5		0	
Y6		0	
Y7		0	
Y8		0	
Y9		0	
Y10		0	
Y11		0	
Y12		0	
Y13		0	
Y14		0	
Y15		0	
Y16		0	
Y17		0	
Y18		0	
Y19		0	
Y20		0	
Y21		0	
Operator Display Block			
Display Setting	MV, %, mA, Alternate MV		
Display Label	7 Character	MeasVar	
Display Language	English, German, French, Spanish	English	
Display Mode Setup	Enabled/Disabled	Disabled	

PARAMETER	RANGE OF VALUE	DEFAULT VALUE	CONFIGURED VALUE
Transmitter ID Block			
Tag	8-Character	TT	
Descriptor	16-Character	Model 343	
Message	32-Character	Moore Products Co. XTC	
Sensor Serial Number	10-Character	0000000000	
Date	MM/DD/YY	date of manufacture	
Polling Address	0 to 15	0	
Output Block			
Sensor Failsafe Detection	Enable/Disable	Enable	
Failsafe	Low, High, Other, Off	High	



WARRANTY

The Company warrants all equipment manufactured by it and bearing its nameplate, and all repairs made by it, to be free from defects in material and workmanship under normal use and service. If any part of the equipment herein described, and sold by the Company, proves to be defective in material or workmanship and if such part is within twelve months from date of shipment from the Company's factory, returned to such factory, transportation charges prepaid, and if the same is found by the Company to be defective in material or workmanship, it will be replaced or repaired, free of charge, f.o.b. company's factory. The Company assumes no liability for the consequence of its use or misuse by Purchaser, his employees or others. A defect in the meaning of this warranty in any part of said equipment shall not, when such part is capable of being renewed, repaired or replaced, operate to condemn such equipment. This warranty is expressly in lieu of all other warranties, guaranties, obligations, or liabilities, expressed or implied by the Company or its representatives. All statutory or implied warranties other than title, are hereby expressly negated and excluded.

Warranty repair or replacement requires the equipment to be returned to one of the following addresses.

1. Equipment manufactured or sold by MOORE PRODUCTS CO.

MOORE PRODUCTS CO.
Sumneytown Pike
Spring House, PA 19477 USA

2. Equipment manufactured or sold by MOORE PRODUCTS CO. (CANADA) INC.

MOORE PRODUCTS CO. (CANADA) INC.
2KM West of Mississauga Rd. Hwy 7
Brampton, Ontario Canada

3. Equipment manufactured or sold by MOORE PRODUCTS CO. (U.K.) LTD

MOORE PRODUCTS CO. (U.K.) LTD
Cope Road,
Lufton, Yeovil,
Somerset, BA22 8RN England

Warranty will be null and void if repair is attempted without authorization by Moore Products Co.

■




PARTS LIST

PL343-1
Rev.1
January 1998

XTC™ TEMPERATURE TRANSMITTER MODEL 343D AND 343F

NOTE: Item numbers in parenthesis are for locating part numbers in the list on the next page.



ITEM	PART NO.	DESCRIPTION	QTY
		- ENCLOSURE PARTS -	
1	16275-474	SmartDisplay™	1
2	16275-473	LCD Display	1
3	16275-470	Transmitter Module	1
4*	2938-68	O-Ring for Enclosure Cap, Model 343F only	1
5*	20027-83	Enclosure Cap Wrench (for Flush Cap), Model 343F only	1
6	-----	XTC Enclosure Cap Kits, Model 343F only	--
	16275-471	Crenelated - Includes blank enclosure caps (qty 2), enclosure cap with sightglass (qty 1), and O-rings.	1
	16275-472	Flush - Includes blank enclosure caps (qty 2), enclosure cap with sightglass (qty 1), and O-rings.	1
NS	3240-1	Pipe Plug, Electrical Entrance, 1/2-NPT, Model 343F only	1

Notes:

- Refer to User's Manual UM343-1 for accessory part numbers and for servicing a transmitter.
- See drawings on previous page for transmitter disassembly and item reference numbers.
- An * identifies a recommended on-hand spare part. Include transmitter nameplate information when ordering.
- NS = Not shown in exploded view.





Process Automation Solutions

For prompt, personal attention to your instrumentation and control needs, contact the Moore location nearest you. Information on other Moore representatives in your area is available from these regional locations.

www.moore-solutions.com

AUSTRALIA

(Australia) Pty. Ltd.
Federation Business Centre
Unit 27, 198 Young Street
Waterloo, NSW, 2017
Tel: +61 2 9319 4877
Fax: +61 2 9318 1743

THE BENELUX

Wagenmakerstraat 3
2984 BD RIDDERKERK
Tel: +31 180 461111
Fax: +31 180 461132

CANADA

P.O. Box 370
Brampton, Ontario L6V 2L3
Tel: +1 905 457 9638
Fax: +1 905 457 4182

CHINA

Kerry Everbright City
Unit 7, 12/f, Tower 1
218 Tian Mu Xi Lu, Zhabei District
Shanghai 200070
Tel: +86 21 6354 9879
+86 21 6354 5094
Fax: +86 21 6354 3017

FRANCE

Factory Systemes
22, rue Vladimir Jankelevitch
Emerainville
77437 Marne la Vallee cedex 2
France
Tel: +33 1 64 61 68 68
Fax: +33 1 64 61 67 34

INDIA

34/35, MIDC Estate
"H" Block
Pimpri, Pune 411 018
Tel: +91 212 770171
Fax: +91 212 777049

ITALY

Via S. Aleramo 2
20063 Cernusco sul Naviglio (Milano)
Tel: +39 02 929054 1
Fax: +39 02 92905454

MEXICO

Moore Products de Mexico S.A. de C.V.
Tintoreto No. 32-302
Col. Nonoalco Mixcoac
Mexico, D.F.
C.P. 03910
Tel: +52 5 611 9858
+52 5 615 1948
+52 5 615 0262
+52 5 615 0238
Fax: +52 5 611 4541

SINGAPORE

70 Bendemeer Road
#03-01 Hiap Huat House
Singapore 339940
Tel: +65 299 6051
Fax: +65 299 6053

SOUTH AFRICA

Moore House
39 Monza Place
Kyalami Business Park
Midrand
Tel: +27 11 466 1673/9
Fax: +27 11 466 1618

UNITED KINGDOM

Copse Road
Lufton Industrial Estate
Yeovil, Somerset BA22 8RN
Tel: +44 1935 706262
Fax: +44 1935 706969

UNITED STATES

1201 Sumneytown Pike
Spring House, PA 19477-0900
Tel: +1 215 646 7400
Fax: +1 215 283 6358



Printed on post-consumer recycled paper.

February 1999