

Errata

Title & Document Type: E6392B GSM MS Test Set User's Guide

Manual Part Number: E6392-90051

Revision Date: November 2001

HP References in this Manual

This manual may contain references to HP or Hewlett-Packard. Please note that Hewlett-Packard's former test and measurement, semiconductor products and chemical analysis businesses are now part of Agilent Technologies. We have made no changes to this manual copy. The HP XXXX referred to in this document is now the Agilent XXXX. For example, model number HP8648A is now model number Agilent 8648A.

About this Manual

We've added this manual to the Agilent website in an effort to help you support your product. This manual provides the best information we could find. It may be incomplete or contain dated information, and the scan quality may not be ideal. If we find a better copy in the future, we will add it to the Agilent website.

Support for Your Product

Agilent no longer sells or supports this product. You will find any other available product information on the Agilent Test & Measurement website:

www.tm.agilent.com

Search for the model number of this product, and the resulting product page will guide you to any available information. Our service centers may be able to perform calibration if no repair parts are needed, but no other support from Agilent is available

Agilent Technologies
E6392B GSM MS Test Set
User's Guide

Serial Numbers

This manual applies directly to instruments with serial number prefix JP5MG, or firmware revision B.03.00 and above.



Agilent Technologies

Agilent Part No. E6392-90051

Printed in Japan

Manual Part Number
E6392-90051

Edition/Print Date

All Editions and Updates of this manual and their creation dates are listed below.

First Edition.....February 2000
Second.....June 2000
Third.....July 2000
Fourth.....September 2001
Fifth.....November 2001

Notices

Copyright©
Agilent Technologies, Inc. 2000, 2001
All Rights Reserved

Information contained in this document is subject to change without notice.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Agilent Technologies.

Certification

Agilent Technologies certifies that this product met its published specifications at the time of shipment from the factory. Agilent Technologies further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology, to the extent allowed by the Institution's calibration facility, or to the calibration facilities of other International Standards Organization members.

Warranty

This Agilent Technologies instrument product is warranted against defects in material and workmanship for a period of one year from the date of shipment, except for certain components listed in Specifications section of this manual. During the warranty period, Agilent

Technologies will, at its option, either repair or replace products which prove to be defective.

For warranty service or repair, this product must be returned to a service facility designated by Agilent. Buyer shall prepay shipping charges to Agilent Technologies and Agilent Technologies shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to Agilent Technologies from another country.

Agilent Technologies warrants that its software and firmware designated by Agilent for use with an instrument will execute its programming instruction when properly installed on that instrument. Agilent Technologies does not warrant that the operation of the instrument, or software, or firmware will be uninterrupted or error free.

Limitation Of Warranty

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance. *No other warranty is expressed or implied. Agilent Technologies specifically disclaims the implied warranties of merchantability and fitness for a particular purpose.*

Exclusive Remedies

The remedies provided herein are buyer's sole and exclusive remedies. Agilent Technologies shall not be liable for any direct, indirect, special, incidental, or consequential damages, whether based on contract, tort, or any other legal theory.

Assistance

Product maintenance agreements and other customer assistance agreements are available for Agilent Technologies products.

For any assistance, contact your nearest Agilent Technologies Sales and Service Office. Addresses are provided at the back of this manual.

Agilent Technologies Japan, Ltd.
Kobe Wireless Test Development
1-3-2, Murotani, Nishi-ku, Kobe-shi,
Hyogo, 651-2241 Japan

Safety Information

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific WARNINGS elsewhere in this manual violates safety standards of design, manufacture, and intended use of the instrument. *Agilent Technologies assumes no liability for the customer's failure to comply with these requirements.*

NOTE:

The Agilent Technologies E6392B complies with INSTALLATION CATEGORY II and POLLUTION DEGREE 2 in IEC61010-1. Agilent E6392B is an INDOOR USE product.

Ground the Instrument

To minimize electric shock hazard, the instrument chassis and cabinet must be connected to an electrical protective earth ground. The instrument must be connected to ac power through a grounded power cable, with the ground wire firmly connected to an electrical ground (safety ground) at the power outlet. Any interruption of the protective (grounding) conductor or disconnection of the protective earth terminal will cause a potential shock hazard that could result in personal injury.

DO NOT Operate In An Explosive Atmosphere

Do not operate the instrument in the presence of flammable gasses or fumes. Operation of any electrical instrument in such an environment constitutes a definite safety hazard.

Keep Away From Live Circuits

Operating personnel must not remove instrument covers. Component replacement and internal adjustments must be made by qualified maintenance personnel. Do not replace components with the power cable connected. Under certain conditions, dangerous voltages may exist even with the power cable removed. To avoid injuries, always disconnect power and discharge circuits before touching them.

DO NOT Service Or Adjust Alone

Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present.

DO NOT Substitute Parts Or Modify Instrument

Because of the danger of introducing additional hazards, do not install substitute parts or perform unauthorized modifications to the instrument. Return the instrument to an Agilent Technologies Sales and Service Office for service and repair to ensure that safety features are maintained.

Safety Symbols

General definitions of safety symbols used on equipment or in manuals are listed below.



Refer to the instruction manual when you see this symbol.



Alternating current.



Direct current.



On (Supply).



Off (Supply).



In position of push-button switch.



Out position of push-button switch.

WARNING:

This WARNING notice denotes a hazard. It calls attention to a procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in injury or death to personnel.

CAUTION:

This CAUTION notice denotes a hazard. It calls attention to a procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the product.

NOTE:

NOTE denotes important information. It calls attention to a procedure, practice, condition or the like, which is essential to highlight.

DECLARATION OF CONFORMITY

According to ISO/IEC Guide 22 and CEN/CENELEC EN 45014

Manufacturer's Name: Agilent Technologies Japan, Ltd.

Manufacturer's Address: 1-3-2, Murotani, Nishi-ku, Kobe-shi,
Hyogo, 651-2241 Japan

Declares that the product:

Product Name: GSM Mobile Station Test Set

Model Number: E6392A, E6392B

Product Options: This declaration covers all options of the above product

Conforms to the following product standards:

EMC: IEC 61326-1:1997 +A1:1998 / EN 61326-1:1997 +A1:1998

Standard	Limit
CISPR 11:1990 / EN 55011:1991 / AS/NZS 2064.1/2	Group 1, Class A ⁽¹⁾
IEC 61000-4-2:1995 / EN 61000-4-2:1995	4 kV CD, 8 kV AD
IEC 61000-4-3:1995 / EN 61000-4-3:1996	3 V/m 80% AM 27 - 1000 MHz
IEC 61000-4-4:1995 / EN 61000-4-4:1995	0.5 kV signal lines, 1 kV power lines
IEC 61000-4-5:1995 / EN 61000-4-5:1995	0.5 kV line-line, 1 kV line-ground
IEC 61000-4-6:1996 / EN 61000-4-6:1996	3 V 80% AM 0.15 - 80 MHz
IEC 61000-4-11:1994 / EN 61000-4-11:1994	1 cycle, 100%

Safety: IEC 61010-1:1990 +A1:1992 +A2:1995 / EN 61010-1:1993 +A2:1995
CAN / CSA C22.2 No. 1010.1-92

Conformity / Supplementary Information:

The product herewith complies with the requirements of the Low Voltage Directive 73/23/EEC and the EMC Directive 89/336/EEC and carries the CE-marking accordingly.

LEDs in this product are Class 1 in accordance with EN 60825-1:1994.

⁽¹⁾ The product was tested in a typical configuration.

Kobe, Japan 1 February 2000

Date


Name Teruo Takeda / Quality Manager

For further information, please contact your local Agilent Technologies sales office, agent or distributor.

ACOUSTIC NOISE EMISSION

LpA < 70 dB
operator position
normal operation
per ISO 7779

GERXUSCHEMISSION

LpA < 70 dB
am Arbeitsplatz
normaler Betrieb
nach DIN 45635 T. 19

In this Book

This guide describes how to use the Agilent Technologies E6392B GSM MS Test Set. This Test Set provides a variety of test functions to validate the performances of GSM900, E-GSM, DCS1800, and PCS1900 mobile phones.

Throughout this manual the term "Test Set" is used to refer to the Agilent E6392B.

This guide contains the following information:

Chapter 1, "Preparing for Use"

This chapter provides a quick overview on the fundamentals required before starting actual tests with the Test Set.

Chapter 2, "Using Functions"

This chapter explains some of basic test procedures for the first time users to become familiar with the Test Set.

Chapter 3, "Screen Reference"

This chapter provides detailed information on each function of the screen displays and activated softkeys.

Chapter 4, "Functionality/Operation"

This chapter introduces the typical block diagram of a GSM mobile phone to relate some blocks with each test item done by the Test Set, especially from the perspective of incoming inspection and repair for GSM mobile phones.

Chapter 5, "Specifications"

This chapter lists the performance characteristics of the Test Set.

Appendix A, "General Information on the GSM System"

This appendix describes some major information on the GSM system for your reference.

Appendix B, "Input Fields and Allowable Ranges"

This appendix summarizes the allowable ranges and corresponding choices for the parameter input fields.

Appendix C, "Manual Changes"

This appendix provides a manual change history.

1. Preparing for Use	
Major Functions	14
Installing the Test Set	17
Checking the Shipment	17
Power Cable	18
Meeting Electrical and Environmental Requirements	20
Replacing the Line Power Fuse	21
Warm-Up Time	21
Preparation for Each Test	22
System Requirement	22
Installing the Test SIM	22
Adjusting the Display Contrast	23
UUT Connections	23
Entering Attenuations	24
Connecting a Printer (optional)	24
Troubleshooting	25
No Measurement after Start	25
Out of Order Internal Clock, Lost Settings, or Both	25
2. Using Functions	
Testing a Mobile Phone with the Test Set	28
Testing a Dual Band Mobile with AUTOMATIC TEST	29
Testing a Dual Band Mobile with MANUAL TEST (Synchronous mode)	34
Testing a Mobile with MANUAL TEST (Asynchronous mode)	40
Testing a Mobile with MANUAL TEST (GPRS mode)	44
Testing a Mobile with SPECTRUM MONITOR	48
3. Screen Reference	
General Operation Guide	52
Front Panel Overview	52
Rear Panel Overview	54
Display Annotation	55
Test Parameters, Test Items and Allowable Ranges	58
Initial Screen	61
AUTOMATIC TEST	63
Stand-by Screen	63
Talk Measuring Screen	69
Aborted Screen	71
Pass/Fail Screen	73
Pass/Fail Screen Examples	75
MANUAL TEST (Synchronous Mode)	80
Measurement Mode Selection	80

Test SIM	80
Stand-by Screen	81
MS Call or BS Call Measuring Screen	86
Talk/RF Test Measuring Screen	88
Measuring Screen Examples	90
MANUAL TEST (Asynchronous Mode)	102
Stand-by Screen	103
Measuring Screen	107
Measuring Screen Examples	108
MANUAL TEST (GPRS Mode)	118
Stand-by Screen	119
Attached Screen	124
Measuring Screen Examples	126
SPECTRUM MONITOR	136
Initial Screen	136
SIGNAL GENERATOR	143
SIGNAL GENERATOR Screen	143
CONFIGURATION	145
CONFIGURATION Screen	145
Test Setup: Test Condition Screen	148
Test Setup: Test Sequence Screen	153
File Management	160
How to Update the Firmware	165
4. Functionality/Operation	
GSM Mobile Block Diagram	168
GSM Measurements Selection	169
GPRS Overview	171
Difference from HSCSD	171
GPRS Network Topology	171
5. Specifications	
General Information	174
RF Input/Output	175
RF Signal Generator	175
RF Analyzer	176
Transmitter Carrier Peak Power Measurement	176
Power Ramp Measurement	176
Phase and Frequency Error Measurement	177
Spectrum Monitor	177
DC Power Supply	178
DC Current Measurement	178


Memory Card	178
Asynchronous Test (Option 002)	179
Spectrum Monitor	179
RF Signal Generator	179
GPRS Test (Option 040)	180
Specifications Unique for GPRS Measurement	180
Rear Panel	181
Frequency Reference	181
Serial Interface	181
Printer Interface	181
General Specifications	182
A. General Information on the GSM System	
The GSM System	184
RF Channels	184
Power Classes	184
Power Control Levels	185
RX Level	186
RX Quality	187
Limits for BER and FER	187
Limits for Frequency Error	187
B. Input Fields and Allowable Ranges	
C. Manual Changes	
Introduction	196
Serial Numbers	196
Manual Changes	196
Change 1	196
Change 2	196

1 Preparing for Use

This chapter is an overview of the Test Set's major functions. It also describes the fundamental requirements that must be met before starting your actual tests with the Test Set.

Major Functions

Figure 1-1 Agilent E6392B GSM MS Test Set



The Agilent E6392B GSM MS Test Set has many desirable features such as multi-band test capability, fast test speed, easy-to-use operation, flexibility, programmability and low cost ownership. These features allow the Test Set to be utilized at GSM/DCS mobile phone service stations and shops to test mobile phones with a short turn-around-time. This easy and quick testing ensures customers' satisfaction.

The Test Set acts as both a base station, to make a call with the mobile under test, and a measurement system to carry out testing. The Test Set is designed to provide the following function modes for testing GSM900, E-GSM, DCS1800 and PCS1900 mobile phones:

- The AUTOMATIC TEST mode automatically executes a test sequence that is configured properly for individual testing requirements. Testing on six different traffic channels or dc power voltages is allowed to test the overall operational characteristics of a mobile phone. Multi-band mobile phones such as GSM900 with DCS1800 and E-GSM with DCS1800 can be quickly tested with this feature. Pass/Fail test results are obtained for the call sequences from Location Update to BS/MS Release of a test flow, and for the test items in [Table 1-1 on page 15](#).
- The MANUAL TEST mode is designed to make real-time tests and measurements that facilitate troubleshooting and adjusting mobile phones, even with multi-band capability.

There are three test modes for the MANUAL TEST mode:

- o Synchronous mode: Tests are made while the Test Set and the mobile are networked to communicate with each other. This is used to test mobile phones during the Talk/RF Test step of a test flow, in a real-time manner.
- o Asynchronous mode: (requires Option 002) Tests are made without networking the Test Set and the mobile phone with each other. This is used to test the RF transmission characteristics of mobile phones in a real-time manner. Therefore, the receiver related characteristics such as sensitivity, RX quality and level are not measured.
- o GPRS mode: (requires Option 040) General Packet Radio Service (GPRS) is a GSM data service that provides higher data transfer rates. Tests are made while the Test Set and the mobile are attached to communicate with each other. This is used to test mobile phones during the Attached step of a test flow, in a real-time manner.

Table 1-1 Test Items available for Test Modes

Test Item	AUTOMATIC TEST	MANUAL TEST			
		Synchronous Mode	Asynchronous Mode		GPRS Mode
			Signal: Burst	Signal: CW	
Peak TX Power	×	×	×	×	×
Burst Timing	×	×			Power vs Time
Power Ramp	×	×	×		
Phase Error	×	×	×		×
Frequency Error	×	×	×	×	×
Sensitivity in BER and FER	×	×			×
RX Quality	×	×			
RX Level	×	×			
DC Current	×	×	×	×	×
Spectrum Monitor		×	×	×	×

- The SPECTRUM MONITOR mode (requires Option 002) allows you to measure each radio channel's spectrum transmitted from a mobile phone. The spans for 0 to 400 kHz and ± 100 kHz, relative to the traffic channel frequency, are provided.
- The SIGNAL GENERATOR mode (requires Option 002) generates an RF signal with or without modulation by a PN9 pseudo-random binary sequence or all-zero data.

NOTE

The MANUAL TEST Asynchronous mode, the SPECTRUM MONITOR and the SIGNAL GENERATOR functions are available for the Test Sets with Option 002.

The MANUAL TEST GPRS mode is available for the Test Sets with Option 040 .

Installing the Test Set

This section contains the following procedures for properly installing the Test Set:

- Checking the shipment
- Meeting electrical and environmental requirements
- Adjusting the display

Checking the Shipment

1. Inspect the shipping container for damage.

Look for any signs of damage such as a dented or torn shipping container, or cushioning material that shows signs of unusual stress or compacting given on the way of shipment.

2. Carefully remove all items contained in the shipping container and verify if your order is complete. Refer to [Table 1-2, “Shipment Verification List,”](#) for the items that are shipped standard with the Test Set. [Table 1-3, “Additional Option List,”](#) is the optional items you may also have ordered.

Table 1-2 Shipment Verification List

Item	Qty	Part Number
Memory Card (PCMCIA SRAM 512 kbyte)	1	E6392-85001
Universal DC Power Adapter	1	E6392-60001
CDR Manual	1	E6392-90500
Quick Start Guide Set	1	E6392-96020
AC Power Cord ^a	1	

a. The part number depends on where the instrument is used, see [“Power Cable” on page 18.](#)

Table 1-3 Additional Option List

Option	Description	Part Number
001	Antenna Coupler	E6392-60002
002	Add Asynchronous Test Capability	
007	Test SIM	08922-80029
008	Test SIM micro	08922-80030
010	Delete Memory Card	

Option	Description	Part Number
011	Delete Universal DC Power Adapter	
040	Add GPRS Test Capability	
0B0	Delete Manual Set	
0B1	Add Manual Set Programmer's Guide User's Guide	E6392-90042 E6392-90051
150	PoST Software for GSM/DCS/PCS Mobile Phones	Agilent E8292A
202	RF Cable for Nokia 51xx, 61xx, 71xx mobile phones	E6392-61603
203	RF Cable for Ericsson mobile phones	E6392-61601
AB0	Taiwan - Chinese localization (User's Guide; Traditional Chinese)	E6392-96631
AB2	China - Chinese localization (User's Guide; Simplified Chinese)	E6392-96531
UK6	Test Report	













Power Cable

In accordance with international safety standards, this instrument is equipped with a three-wire power cable. When connected to an appropriate ac power outlet, this cable grounds the instrument frame. The type of power cable shipped with each instrument depends on the country of destination. Refer to [Figure 1-2, "Power Cable Supplied,"](#) for the part number of the power cables available.

WARNING

For protection from electrical shock, the power cable ground must not be defeated. The power plug must be plugged into an outlet that provides a protective earth ground connection.

Figure 1-2 Power Cable Supplied

<p>OPTION 900</p>  <p>United Kingdom</p> <p>Plug : BS 1363/A, 250V, 10A Cable: 8120-1351</p>	<p>OPTION 901</p>  <p>Australia/ New Zealand</p> <p>Plug : AS 3112, 250V, 10A Cable: 8120-1369</p>
<p>OPTION 902</p>  <p>Continental Europe</p> <p>Plug : CEE 7 Standard Sheet VII, 250V, 10A Cable: 8120-1689</p>	<p>OPTION 903</p>  <p>U.S./ Canada</p> <p>Plug : NEMA 5-15P, 125V, 10A Cable: 8120-1378</p>
<p>OPTION 904</p>  <p>U.S./ Canada</p> <p>Plug : NEMA 6-15P, 250V, 6A Cable: 8120-0698</p>	<p>OPTION 906</p>  <p>Switzerland</p> <p>Plug : SEV Type 12, 250V, 10A Cable: 8120-2104</p>
<p>OPTION 912</p>  <p>Denmark</p> <p>Plug : SR 107-2-D, 250V, 10A Cable: 8120-2956</p>	<p>OPTION 917</p>  <p>India/ Republic of S.Africa</p> <p>Plug : IEC 83-B1, 250V, 10A Cable: 8120-4211</p>
<p>OPTION 918</p>  <p>Japan</p> <p>Plug : JIS C 8303, 125V, 12A Cable: 8120-4753</p>	<p>OPTION 920</p>  <p>Argentina</p> <p>Plug : Argentine Resolution 63, Annex IV, 250V, 10A Cable: 8120-6870</p>
<p>OPTION 921</p>  <p>Chile</p> <p>Plug : CEI 23-16, 250V, 10A Cable: 8120-6978</p>	<p>OPTION 922</p>  <p>China</p> <p>Plug : GB 1002, 250V, 10A Cable: 8120-8376</p>
<p>NOTE: Each option number includes a 'family' of cords and connectors of various materials and plug body configurations (straight, 90° etc.).</p>	

OPT9XXE

Meeting Electrical and Environmental Requirements

Line Settings

The available ac power source must meet the following requirements:

CAUTION

This product has an autoranging line voltage input. Be sure that the supply voltage is within the specified range.

Voltage:

- 100 to 240 volts nominal (90 to 264 volt range)

Frequency:

- 50/60 Hz (47 to 63 Hz range) nominal for 100 to 240 volts

Power:

- 135 VA maximum

Verify that the power cord is not damaged and that the power source socket outlet provides a protective earth contact.

WARNING

This is a Safety Class 1 product provided with a protective earthing ground incorporated in the power cord. The main plug shall only be inserted in a socket outlet provided with a protective earth contact. Any interruption of the protective conductor inside or outside of the product is likely to make the product dangerous. Intentional interruption is prohibited.

CAUTION

Always use the three-prong AC power cord supplied with this product. Failure to ensure adequate earth grounding by not using this cord may cause product damage.

Environment

This product is designed for use in the following environmental conditions:

- Indoor use
- 0° to 40°C operating temperature unless specified differently
- EMI: Complies with EN55011, EN61000-3-3, EN50082-1: 1992
- Safety: Certified to CSA C22.2 No.1010.1. Complies with IEC 1010-1, Amendment 1 and 2
- Altitude less than 2000 meters
- 80% maximum relative humidity for temperature up to 31°C, decreasing linearly to 50% relative humidity at 40°C

Providing Adequate Ventilation

Cooling holes are located on the bottom of the instrument cover and the rear panel of the instrument. Do not allow these holes to be obstructed as they facilitate air flow through the product.

CAUTION

Ventilation Requirement: When installing the product in a system cabinet, the convection into and out of the product must not be restricted. The ambient temperature (outside the cabinet) must be less than the maximum operating temperature of the product by 4°C for every 100 watts dissipated in the cabinet. If the total power dissipated in the cabinet is greater than 800 watts, then forced convection must be applied.

Instructions for Cleaning

For cleaning the surface of the instrument, gently wipe with soft, damp cloth.

Replacing the Line Power Fuse

The line power fuse holder is located on the right side of the Agilent E6392B's rear panel. Before replacing the fuse, disconnect the Agilent E6392B's line power. To replace the fuse, use a small flat blade screwdriver to push in on the fuse cap and rotate it counterclockwise. Remove the fuse cap and replace the fuse with the appropriate type. Reinstall the fuse cap and apply power.

The type and rating of this fuse are as follows.

UL/CSA type, time delay, 2 A, 250 Vac

Warm-Up Time

In order for the Test Set to meet its specifications, allow the Test Set to warm up for 30 minutes after being turned on before attempting to make any measurements.

Preparation for Each Test


The following procedures need to be executed before starting each test.

System Requirement

The following equipment is required to construct a test system:

- The Agilent E6392B GSM MS Test Set
- An RF cable to connect RF signals from/to the mobile phone under test,
An RF antenna coupler to connect RF signals from/to the mobile phone under test, or
A shield box (Agilent N4678A) to connect RF signals from/to the mobile under test
- Universal DC Power Adapter (P/N: E6392-61001) and appropriate cables between the adapter and the mobile phone under test (optional)
- A printer and a printer cable (optional)

Figure 1-3 Typical Test Setup for a Mobile Phone



Installing the Test SIM

Insert the test Subscriber Identity Module (SIM) in the mobile phone before performing any test, because the Test Set will attempt to perform measurements which are not generally permitted by normal SIMs.

Adjusting the Display Contrast

You can adjust the display contrast by controlling the CONTRAST knob located on the front panel.

Rotate the CONTRAST knob clockwise to cause the display background to gradually brighten in comparison to the text on the display. If the background does not appear to change, it is possibly set to the maximum contrast.

Rotate the CONTRAST knob counterclockwise to cause the display background to gradually darken in comparison to the text on the display. The minimum contrast setting is not a complete dark or black display, therefore some contrast between the background and the text will still be visible.

UUT Connections

Connect the mobile phone under test (UUT) to the Test Set using either of the following methods:

Using the RF Cable

Connect the RF cable, which is available as one of the options, to the RF IN/OUT port on the front panel of the Test Set. Insert the other end connector to the mobile phone's RF port.

Using the Antenna Coupler

Connect the Antenna Coupler connector to the RF IN/OUT port on the front panel of the Test Set. Insert the antenna of the mobile phone into the hole of the Antenna Coupler as deep as possible.

Using a User-Supplied Cable

If you have the cable which connects between the mobile phone's RF port and the RF IN/OUT port of the Test Set, use it instead of the Antenna Coupler.


Using the Shield Box

Connect the Antenna Coupler In/Out connector of the shield box (Agilent N4678A) to the RF IN/OUT port on the front panel of the Test Set. Place the mobile phone on the antenna coupler board inside the shield box using the horizontal and vertical holders.

Entering Attenuations

Determine and enter the appropriate attenuation values caused by the antenna coupler, RF cable, or shield box that you use to connect the mobile phone under test to the Test Set.

- Step 1.** By pressing the CONFIGURATION softkey, obtain the following CONFIGURATION screen:




- Step 2.** Set the Attenuation field to On by rotating and pressing the CURSOR CONTROL knob.
- Step 3.** Enter the appropriate loss values, depending on the radio systems, in the RF In and RF Out fields with the CURSOR CONTROL knob. These values are also used in other function modes.
- Step 4.** Press the Return softkey to reveal the initial screen with function modes.

Connecting a Printer (optional)

For obtaining screen hardcopies, connect a printer to the Test Set as follows using an appropriate interface cable between the PRINTER connector on the rear panel of the Test Set and the input connector of a printer:

Figure 1-4 Connecting a Printer



Troubleshooting

No Measurement after Start

Check if the 13 MHz Reference field of the CONFIGURATION screen is set to INT (internal). Press the **PRESET** key for the default settings and try once more. If your trouble still remains, contact your nearest Agilent Technologies service office.

Out of Order Internal Clock, Lost Settings, or Both

The internal battery may have run out. Contact your nearest Agilent Technologies service office.

2 Using Functions

In this chapter, a few testing examples are discussed. This may help the first time user get familiar with the basic testing techniques for using the Test Set.

Testing a Mobile Phone with the Test Set


In this chapter, the following testing examples are described for users to become familiar with the overall functions of the Test Set:

- “Testing a Dual Band Mobile with AUTOMATIC TEST” on page 29
- “Testing a Dual Band Mobile with MANUAL TEST (Synchronous mode)” on page 34
- “Testing a Mobile with MANUAL TEST (Asynchronous mode)” on page 40
- “Testing a Mobile with MANUAL TEST (GPRS mode)” on page 44
- “Testing a Mobile with SPECTRUM MONITOR” on page 48

Testing a Dual Band Mobile with AUTOMATIC TEST


The next procedure explains a test on a dual band (GSM900 and DCS1800) mobile phone with the AUTOMATIC TEST mode.

- Step 1.** Turn the Test Set on and wait for its selftest routine to finish.
- Step 2.** Refer to “Preparation for Each Test” on page 22 for the procedures required before starting the test.
- Step 3.** Press the AUTOMATIC TEST softkey in the initial screen.



- Step 4.** Press the Screen Simp/Detai softkey to select Detai (detailed screen).

The AUTOMATIC TEST: Stand-by detailed screen should be displayed as shown below.



- Step 5.** Rotate the CURSOR CONTROL knob and see how the circular cursor changes its position.

At one field, press the CURSOR CONTROL knob, then rotate it. You see that field changes its values. Press the CURSOR CONTROL knob to enter that value.

2. Using Functions

Step 6. Set the highlighted fields of the test parameters as shown in the above screen. The first three traffic channels in TCH are for GSM900 and the last three for DCS1800, respectively.

If you want to supply dc power from the Test Set to the mobile, set the DC Power field to Auto or On and enter your desired voltage value. To do this, use the Universal DC Power Adapter and an appropriate dc power cable to connect between the AUX connector of the Test Set and the mobile.

Step 7. Press Return, CONFIGURATION, Test Setup, then Test Sequence to obtain the Test Setup: Test Sequence screen shown below.

Step 10

Step 8

Test Setup : Test Sequence 2001/09/23 12:34

1 LOC. Update: Run Radio Standard: GSM900 Multi Band: DCS1800

2 MS Call: Run SCCH: 20: 894.0MHz DC Power: Auto 5.0V

3 Talk: Run TCH(Talk): 30: 896.0MHz Variable: TCH

4 RF Test: Run	TCH	1	62	124	512	698	885
5 MS Release: Run	Peak High	Run	Run	Run	Run	Run	Run
6 BS Call: Run	TX PWR Mid	Run	Run	Run	Run	Run	Run
7 BS Release: Run	Low	Run	Run	Run	Run	Run	Run
Choices: (----)	Burst Timing	Run	Run	Run	Run	Run	Run
Done	Power Ramp	Run	Run	Run	Run	Run	Run
Cancel	Phase Error	Run	Run	Run	Run	Run	Run
Position	Freq. Error	Run	Run	Run	Run	Run	Run
Over/Ins	Sensitivity	Run	Run	Run	Run	Run	Run
Delete	RX Quality	Run	Run	Run	Run	Run	Run
Del End	RX Level	Run	Run	Run	Run	Run	Run
	DC Current	Run	Run	Run	Run	Run	Run

-- Instruction: 5

End call (for MS Call) or wait for call to end.

meas_sequence

Print

Print All

File Management

Test Condition

Return

Step 11

Step 8. Enter BS in the second step of the test flow, then notice that the fifth step changes to BS Release, the sixth to MS Call, and the seventh to MS Release.

Enter MS in the second step of the test flow again.

Step 9. Enter GSM900 and DCS1800 in Radio Standard and Multi Band, respectively, and set other fields as shown in the illustration in [Step 7](#).

Step 10. Enter Run in each field of the LOC. Update, Talk and BS Call steps.

Step 11. Enter Run in each cell of the test item table.

- Step 12.** Press the Test Condition softkey to go to the next screen to set the detailed test condition including high and low test limits as shown below.

Test Setup : Test Condition 2001/09/23 12:34

Radio Standard: GSM900	Test Item	LO Limit	HI Limit	Unit	
MS Power Class: 04	Peak TX PWR	12	- 3.0	+ 3.0	dB
PWR CNTL	Burst Timing		-1.0	+1.0	Bits
High: 8 :+27dBm	Power Ramp		Template	Template	
Mid: 13 :+17dBm	Phase Error	RMS		5.0	deg
Low: 18 :+ 7dBm		Peak		10.0	deg
MANUAL TEST: 13 :+17dBm	Freq. Error		- 90	+ 90	Hz
Averaging: Off	BER			2.44	%
RF Output: Auto	FER			0.12	%
BS Level: - 55.0dBm	BLER			0.12	%
BER BS Level: -104.0dBm	RX Quality	0		1	
BER Frames: 13000	RX Level	8		9	
(1014000Bits)	DC Current	Camp On	50	200	mA
Loopback Delay: Short		Talk	250	700	mA

meas_condition_bslev

Step 13

Step 14

- Step 13.** Set the fields of the test parameters as shown in the left side of the above screen moving the circular cursor accordingly.
- Step 14.** Enter the appropriate limits in the cells of the test item table above.
- Step 15.** Repeat [Step 13](#) to [Step 14](#) to set the Test Condition screen by replacing GSM900 with DCS1800 in Radio Standard.
- Step 16.** After you have set all parameters as needed, press the Return, Return again, then AUTOMATIC TEST softkeys to obtain the AUTOMATIC TEST: Stand-by detailed screen shown below.

AUTOMATIC TEST : Stand-by 2001/09/23 12:34

LOC. Update:	Radio Standard: GSM900	Procedure: TEST900M	Multi Band: DCS1800
MS Call:	BCCH: 20 : 894.0MHz	DC Power: Auto 5.0V	
Talk:	TCH(Talk): 30 : 896.0MHz	Variable: TCH	
RF Test	TCH	1	62
MS Release			124
BS Call			512
BS Release			698
			885
IMSI:	Power Class:		
IMEI:	GSM Version:		
Dialed No.:			

RF ON

Turn off MS power, press [Start] to begin a test.

prepar1_auto_stdby_detail

- Step 17.** Turn the mobile phone on. Wait for the mobile to camp on and display 001-01.

If you set DC Power or RF Output in the Test Sequence screen to Auto, turn the mobile on after pressing the Start softkey.

- Step 18.** Press the Start softkey to begin your test.

The DC Current measurement at Camp On stage is measured at the LOC. Update step and its pass/fail result is displayed in the DC Current cells of the table, when DC Power is supplied from the Test Set to the mobile.

Step 19. At the MS Call step, you are asked to call from the mobile. For example, dial a number and press the **Call** key of the mobile.

Step 20. At the Talk step, make a talk test and press the Pass or Fail softkey according to the talk test result.

AUTOMATIC TEST : Measuring		2001/09/23 12:34						
LOC. Update: Pass	Radio Standard: GSM900	Procedure:				DCS1800		Pass
MS Call: Pass	BCCH: 20: 894.0MHz	DC Power: Auto 5.0V						Fail
Talk:	TCH(Talk): 30: 896.0MHz	Variable: TCH						Screen Simp/Detai
RF Test	TCH	1	62	124	512	698	885	
MS Release	Peak TX PWR							
BS Call	Burst Timing							
BS Release	Power Ramp							
	Phase Error							
	Freq. Error							
	Sensitivity							
	RX Quality							
	RX Level							
	DC Current	Pass	Pass	Pass	Pass	Pass	Pass	
IMSI: 001012345678901	Power Class: 4							
IMEI: 123456789012345	GSM Version: Phase 1							
Dialed No.: 12345678901234567890								RF ON Abort
Talk to the mobile and press [Pass] or [Fail] with the result.								

Step 21. As each step is running in the test flow, its corresponding test item field in the table will blink. While the RF Test step is blinking, each of the test items is measured. You can see how it is being done.

Step 22. At the MS Release step, you are asked to end call from the mobile. For example, press the **End** key of the mobile to terminate the call.

Step 23. At the BS Call step, you are asked to respond to the call from the Test Set. For example, respond to it by pressing the **Answer** key of the mobile.

Step 24. After completing the measurement, the next screen is displayed to show the test results. In this case there is not a failure at those channels in the GSM900 and DCS1800 bands.

AUTOMATIC TEST : Passed		2001/09/23 12:34						
LOC. Update: Pass	Radio Standard: GSM900	Procedure:				DCS1800		Start
MS Call: Pass	BCCH: 20: 894.0MHz	DC Power: Auto 5.0V						
Talk: Pass	TCH(Talk): 30: 896.0MHz	Variable: TCH						
RF Test: Pass	TCH	1	62	124	512	698	885	
MS Release: Pass	Peak TX PWR	Pass	Pass	Pass	Pass	Pass	Pass	
BS Call: Pass	Burst Timing	Pass	Pass	Pass	Pass	Pass	Pass	
BS Release: Pass	Power Ramp	Pass	Pass	Pass	Pass	Pass	Pass	
	Phase Error	Pass	Pass	Pass	Pass	Pass	Pass	
	Freq. Error	Pass	Pass	Pass	Pass	Pass	Pass	
	Sensitivity	Pass	Pass	Pass	Pass	Pass	Pass	
	RX Quality	Pass	Pass	Pass	Pass	Pass	Pass	
	RX Level	Pass	Pass	Pass	Pass	Pass	Pass	
	DC Current	Pass	Pass	Pass	Pass	Pass	Pass	
IMSI: 001012345678901	Power Class: 4							
IMEI: 123456789012345	GSM Version: Phase 1							
Dialed No.: 12345678901234567890								Return
Press [CURSOR CONTROL] to get a detailed result screen.								

Step 25. If a printer is available, print the test results.

Press the More (1 of 2) softkey and print as follows:


- Press the Print softkey to make a graphic image screen hardcopy.

- Press the Print All softkey to print the detailed measurement results as follows. Write the model number or name of the mobile and the customer name on the report.

```

Agilent E6392B GSM MS TEST SET  AUTOMATIC TEST: Result
DATE:2000/01/15 TIME:10:00
MODEL:          Model 1
CUSTOMER:       ABC Co.
IMSI:           [ 001012345678901 ]
IMEI:           [ 123456789012345 ]
-----
MS Power Class:      4
PWR CNTL
  High:              8:+27 dBm
  Mid:               13:+17 dBm
  Low:               18:+ 7 dBm
  MANUAL TEST:      13:+17 dBm
Averaging:           Off
RF Output:           Auto
Amplitude:           - 55 dBm
Sensitivity
    
```

Step 26. Place the circular cursor at Pass or Fail of any channel in the Burst Timing or Power Ramp cell, then press the CURSOR CONTROL knob to obtain the next screen. See where the marker appears in the graph and the failed result data is shown if any (highlighted in this text).



Step 27. Press the Return softkey to return to the previous screen.

The detailed test results for other test items can be obtained in the same manner.

Step 28. If you want to make the same test again, press the Start softkey.


If you want to change Test Sequence and Test Condition, select the CONFIGURATION mode to obtain the Test Setup screens.

If you want to do a different test, press the Return softkey to obtain the initial screen.


Testing a Dual Band Mobile with MANUAL TEST (Synchronous mode)

The following procedure explains a test on a dual band (GSM900 and DCS1800) mobile phone with the MANUAL TEST synchronous mode.

- Step 1.** Turn the Test Set on and wait for its selftest routine to finish.
- Step 2.** Refer to “Preparation for Each Test” on page 22 for the procedures required before starting the test.



- Step 3.** Press the MANUAL TEST softkey in the initial screen to obtain the MANUAL TEST: Stand-by screen shown below.



- Step 4.** If the Test Set is equipped with Option 002, make sure that Sync is selected (underlined) in the Mode Sync/Async softkey. (Note that this softkey is not available for the Test Set without Option 002.)
- Step 5.** Rotate the CURSOR CONTROL knob and see how the circular cursor changes its position.

At one field, press the CURSOR CONTROL knob, then rotate it. You see that field changes its values. Press the CURSOR CONTROL knob to enter that value.

Testing a Dual Band Mobile with MANUAL TEST (Synchronous mode)

Step 6. Specify the highlighted fields of the test parameters as shown in the above screen.

If you want to supply dc power from the Test Set to the mobile, set the DC Power field to On and enter your desired voltage value. To do this, use the Universal DC Power Adapter and an appropriate dc power cable to connect between the AUX port of the Test Set and the mobile.

Step 7. Press the Return, CONFIGURATION, then Test Setup softkeys to obtain the Test Setup: Test Condition screen shown below.

Test Setup : Test Condition 2001/09/23 12:34

Radio Standard: DCS1800
 MS Power Class: 02
 PWR CNTL
 High: 2:+26dBm
 Mid: 5:+20dBm
 Low: 8:+14dBm
 MANUAL TEST: 8:+14dBm
 Averaging: Off
 RF Output: Auto
 BS Level: -55.0dBm
 BER BS Level: -100.0dBm
 BER Frames: 10
 (780Bits)
 Loopback Delay: Mid

Test Item	LO Limit	HI Limit	Unit
Peak TX PWR			
PWR CNTL	9	-3.0	+3.0 dB
Burst Timing		-1.0	+1.0 Bits
Power Ramp		Template	Template
Phase Error			
RMS			5.0 deg
Peak			10.0 deg
Freq. Error		-350	+350 Hz
BER			2.44 %
FER			0.12 %
BLER			0.12 %
RX Quality		0	1
RX Level		10	11
DC Current			
Camp On	50		200 mA
Talk	250		700 mA

Print
Print All
File Management
Test Sequence
Return

Step 8 (points to highlighted fields on the left)

Step 9 (points to highlighted fields in the table)

Test_sync_condtn_bslev

Step 8. Specify the highlighted fields of the test parameters as shown in the left side of the above screen.

Step 9. Enter the appropriate limits in the cells of the test item table above.

Step 10. Repeat Step 8 to Step 9 to set the Test Condition screen by replacing DCS1800 with GSM900 in Radio Standard.

Step 11. After you have set all parameters as needed, press the Return, Return again, then MANUAL TEST softkeys to obtain the MANUAL TEST: Stand-by screen shown below. Check if the Mode Sync/Async softkey is set to Sync.

MANUAL TEST: Stand-by 2001/09/23 12:34

MS Call
BS Call
Talk
RF Test
MS Release
BS Release

Radio Standard: DCS1800
 BCCH: 512:1710.2MHz
 TCH: 534:1714.6MHz
 Signal: Burst
 Timing ADV: 0Bits

Procedure: GSM900
 Multi Band: GSM900
 PWR CNTL: 8:+14dBm
 DC Power: On 3.0V
 BS Level: -55.0dBm

Mode Sync/Async/GPRS
BS Call
MS Call
Test Setup
Return

Test Item	Unit
Peak TX Power, Burst Timing, Power Ramp	
Phase Error, Frequency Error	
Sensitivity, RX Quality, RX Level	
DC Current	
Spectrum Monitor	
RX Quality	-----%
RX Level	-----dBm
DC Current	-----mA
ACT Tim ADV	---Bits

IMSI:
IMEI:
Diald No.:
Power Class:
GSM Version:

Press [BS Call] or [MS Call].

RF ON

test_mnl_sync_stndby_ta

Step 12. Turn the mobile on and wait for it to camp on displaying 001-01.

Step 13. Press the BS Call or MS Call softkey, then the MANUAL TEST: Measuring screen is shown.

Testing a Dual Band Mobile with MANUAL TEST (Synchronous mode)

- If the BS Call softkey is pressed, you are asked to answer the call on the mobile. Then the following screen will be displayed.

```

MANUAL TEST: Measuring                               2001/09/23 12:34
  Procedure:
  Radio Standard: DCS1800 Multi Band: GSM900
  BCCH:          512:1710.2MHz PWR CNTL:  8:+14dBm
  TCH:          534:1714.6MHz DC Power:   On  3.0V
  Signal:       Burst   BS Level:  - 55.0dBm
  Timing ADV:   0Bits
  Test Item
  Peak TX Power, Burst Timing, Power Ramp
  Phase Error, Frequency Error
  Sensitivity, RX Quality, RX Level
  DC Current
  Spectrum Monitor
  IMSI:          001012345678901   RX Quality:  -----%
  IMEI:          123456789012345   RX Level:    -----dBm
  Dialed No.:    12345678901234567890 DC Current:   160mA
  Power Class:   4                 ACT Tim ADV:  ---Bits
  GSM Version:   Phase 1
  Processing...
  
```

Buttons: MS Call, BS Call, Talk, RF Test, MS Release, BS Release, RF ON, Abort

Footer: test svnc meas bscall ta

Testing a Dual Band Mobile with MANUAL TEST (Synchronous mode)

- If the MS Call softkey is pressed, the following screen is displayed. Dial and call from the mobile to proceed to the Talk/RF Test step. You can measure the DC Current at Camp On stage while the MS Call step is blinking.

```


MANUAL TEST: Measuring                               2001/09/23 12:34
Radio Standard: DCS1800 Procedure:
BCCH: 512:1710.2MHz Multi Band: GSM900
TCH: 534:1714.6MHz PWR CNTL: 8:+14dBm
Signal: Burst BS Level: - 55.0dBm
Timing ADV: 0Bits
Test Item
Peak TX Power, Burst Timing, Power Ramp
Phase Error, Frequency Error
Sensitivity, RX Quality, RX Level
DC Current
Spectrum Monitor
IMSI: 001012345678901 RX Quality: -----%
IMEI: 123456789012345 RX Level: -----dBm
Diald No.: 12345678901234567890 DC Current: 123mA
Power Class: 4 ACT Tim ADV: ---Bits
GSM Version: Phase 1
Executing a call setup from the mobile.
  
```

- Step 14.** Upon setting up the call setup, the Talk/RF Test screen is displayed as shown below. IMSI, IMEI, Power Class, GSM Version, RX Quality, RX Level are shown. For MS Call, Dialed No. is also included.

```

MANUAL TEST: Measuring                               2001/09/23 12:34
Radio Standard: DCS1800 Procedure: TEST900M
BCCH: 512:1710.2MHz Multi Band: GSM900
TCH: 534:1714.6MHz PWR CNTL: 8:+14dBm
Signal: Burst BS Level: - 55.0dBm
Timing ADV: 0Bits
Test Item
Peak TX Power, Burst Timing, Power Ramp
Phase Error, Frequency Error
Sensitivity, RX Quality, RX Level
DC Current
Spectrum Monitor
IMSI: 001012345678901 RX Quality: 1:0.2 to 0.4%
IMEI: 123456789012345 RX Level: 1:-110 to -109dBm
Diald No.: 12345678901234567890 DC Current: 330mA
Power Class: 4 ACT Tim ADV: 0Bits
GSM Version: Phase 1
Select an item column with [CURSOR CONTROL] to execute its test.
  
```


- Step 15.** While the Talk/RF Test step is blinking as above, you can select a test item by the CURSOR CONTROL knob to execute its test. Place the cursor at “Peak TX Power, Burst Timing, Power Ramp” and press the CURSOR CONTROL knob, for example, to obtain the next screen.



- Step 16.** Press the Abort softkey to get other softkey menus.


Testing a Dual Band Mobile with MANUAL TEST (Synchronous mode)

- a. Press the Trigger Sing/Cont softkey to change the trigger mode to Sing (single) and the Zoom Off/On softkey to change the zoom mode to On.
- b. Press the More (1 of 3) softkey to reveal another softkey menu, and press Knob MKR/Cursor to change the knob control to MKR (marker).




- c. Press the Return softkey to return to the previous screen.

Step 17. Select Spectrum Monitor in the test item table to display the Spectrum Monitor measuring screen. Press Abort, More (1 of 3), Knob MKR/Cursor to obtain the next screen with the marker.



Step 18. Press the Return softkey to reveal the next Measuring screen.



Step 19. Press the BS Release or MS Release softkey to finish your test.

Testing a Dual Band Mobile with MANUAL TEST (Synchronous mode)

- When you press the BS Release softkey, wait until the call from the Test Set ends.
- When you press the MS Release softkey, execute a call end from the mobile phone.


Testing a Mobile with MANUAL TEST (Asynchronous mode)

The following procedure explains a test on a dual band (GSM900 and DCS1800) mobile phone with the MANUAL TEST asynchronous mode.


NOTE

This section is applicable only for the Test Sets with Option 002.

- Step 1.** Turn the Test Set on and wait for its self test routine to finish.
- Step 2.** Refer to “Preparation for Each Test” on page 22 for the procedures required before starting the test.



- Step 3.** Press the MANUAL TEST softkey mode in the initial screen to obtain the MANUAL TEST: Stand-by screen.
- Step 4.** Press the Mode Sync/Async softkey to select the Async (asynchronous) mode.



- Step 5.** Rotate the CURSOR CONTROL knob and see how the circular cursor changes its position.

At one field, press the CURSOR CONTROL knob, then rotate it. You see that field changes its values. Press the CURSOR CONTROL knob to enter that value.

- Step 6.** Set the highlighted fields of the TEST parameters as shown in the above screen.

Testing a Mobile with MANUAL TEST (Asynchronous mode)

If you want to supply dc power from the Test Set to the mobile, set the DC Power field to On and enter your desired voltage value. To do this, use the Universal DC Power Adapter and an appropriate dc power cable to connect between the AUX port of the Test Set and the mobile.

- Step 7.** Press Return, then CONFIGURATION, then Test Setup to obtain the Test Setup: Test Condition screen shown below.

Test Setup : Test Condition 2001/09/23 12:34

Test Condition: DCS1800	Test Item	LO Limit	HI Limit	Unit	Print
MS Power Class: 4	Peak TX PWR				Print All
PWR CNTL	PWR CNTL	12	- 3.0	+ 3.0	dB
High: 2:+26dBm	Burst Timing		-1.0	+1.0	Bits
Mid: 5:+20dBm	Power Ramp		Template	Template	
Low: 8:+14dBm	Phase Error			5.0	deg
MANUAL TEST: 8:+14dBm	Peak			10.0	deg
Averaging: Off	Freq. Error		-171	+171	Hz
RF Output: Auto	BER			2.44	%
BS Level: - 55.0dBm	FER			0.12	%
BER BS Level: -100.0dBm	BLER			0.12	%
BER Frames: 10	RX Quality		0	1	
(780Bits)	RX Level		10	11	
Loopback Delay: Mid	DC Current	Camp	On	50	mA
	Talk			250	mA

Step 8

Step 9

mni_prepare_config_condition_bslev

- Step 8.** Specify the highlighted fields of the test parameters as shown in the left side of the above screen.

- Step 9.** Enter the appropriate limits in the cells of the test item table above.

- Step 10.** Repeat Step 8 to Step 9 to set the Test Condition screen by replacing DCS1800 with GSM900 in Radio Standard.

- Step 11.** After you have set all parameters as needed, press the Return, Return again, MANUAL TEST, then Mode Sync/Async softkeys to obtain the MANUAL TEST: Stand-by screen with the asynchronous mode.

MANUAL TEST: Stand-by 2001/09/23 12:34

Radio Standard: DCS1800	Procedure: GSM900	Mode Sync/ Async/GPRS
BCCH: -----MHz	Multi Band: GSM900	
TCH: 534:1714.6MHz	PWR CNTL: 8:+14dBm	Start
Signal: Burst	DC Power: On 5.0V	
	BS Level: - 55.0dBm	
	Midamble: TSC5	
Test Item		
Peak TX Power, Burst Timing, Power Ramp		
Phase Error, Frequency Error		


DC Current		
Spectrum Monitor		
	DC Current: ----mA	
		RF ON
		Return

Press [Start] to begin a test.


test_mni_async_stdby_ts

- Step 12.** Set the mobile phone to transmit the bursted RF power.

Step 13. Press the Start softkey, and the next MANUAL TEST: Measuring screen is shown.




Step 14. While the RF Test step is blinking as above, you can select a test item by pressing the CURSOR CONTROL knob to execute its test. Place the cursor at “Peak TX Power, Burst Timing, Power Ramp” and press the CURSOR CONTROL knob, for example, to obtain the next screen.



Step 15. Press the Abort softkey, to get other softkey menus.

- Press the Trigger Sing/Cont softkey to change the trigger mode to Sing (single) and the Zoom Off/On softkey to change the zoom mode to On.
- Press the More (1 of 3) softkey to reveal the next softkey menu, and press Knob MKR/Cursor to change the knob control to MKR (marker).



Step 16. Press the Return softkey to reveal the next Measuring screen.

```

MANUAL TEST: Measuring                               2001/09/23 12:34
-----
Radio Standard: DCS1800 Multi Band: GSM900
BCCH: -----MHz PWR CNTL: 8:+14dBm
TCH: 534:1714.6MHz DC Power: On 5.0V
Signal: Burst BS Level: -55.0dBm
Midamble: TSC5

Test Item
● Peak TX Power, Burst Timing, Power Ramp
Phase Error, Frequency Error
-----
DC Current
Spectrum Monitor

DC Current: 234mA

RF ON Abort
Select an item column with [CURSOR CONTROL] to execute its test.
test_mnl_async_measrng_ta

```


Step 17. Press the Abort softkey to finish your test.

Stop transmitting RF power from the mobile phone.


Testing a Mobile with MANUAL TEST (GPRS mode)

The following procedure explains a test on a GSM mobile phone with the MANUAL TEST GPRS mode, which is available with Option 040.

- Step 1.** Turn the Test Set on and wait for its selftest routine to finish.
- Step 2.** Refer to “Preparation for Each Test” on page 22 for the procedures required before starting the test.



- Step 3.** Press the MANUAL TEST softkey in the initial screen to obtain the MANUAL TEST: Stand-by screen shown below.



- Step 4.** If the Test Set is equipped with Option 040, make sure that GPRS is selected (underlined) in the Mode Sync/Async/GPRS softkey. (Note that this softkey is not available for the Test Set without Option 040.)
- Step 5.** Check the differences of the test flow, three more parameters for slot configurations, and less mobile related data fields from the MANUAL TEST Synchronous mode. RX Quality and RX Level are not included in the Sensitivity column in the test item table.
- Step 6.** Rotate the CURSOR CONTROL knob and see how the circular cursor changes its position.

At one field, press the CURSOR CONTROL knob, then rotate it. You see that field changes its values. Press the CURSOR CONTROL knob to enter that value.

Step 7. Specify the highlighted fields of the test parameters as shown in the above screen.

If you want to supply dc power from the Test Set to the mobile, set the DC Power field to On and enter your desired voltage value. To do this, use the Universal DC Power Adapter and an appropriate dc power cable to connect between the AUX port of the Test Set and the mobile.

Step 8. Press the Return, CONFIGURATION, then Test Setup softkeys to obtain the Test Setup: Test Condition screen shown below.

Test Setup : Test Condition 2001/09/23 12:34

Radio Standard: **GSM900**
 MS Power Class: **4**
 PWR CNTL
 High: **8: +27dBm**
 Mid: **13: +17dBm**
 Low: **18: +7dBm**
 MANUAL TEST: **15: +13dBm**
 Averaging: **Off**
 RF Output: **Auto**
 BS Level: **-50.0dBm**
 BER BS Level: **-104.0dBm**
 BER Frames: **10**
 (780Bits)
 Loopback Delay: **Short**

Test Item	LO Limit	HI Limit	Unit
Peak TX PWR			
PWR CNTL	13	-3.0	+3.0 dB
Burst Timing		-1.0	+1.0 Bits
Power Ramp		Template	Template
Phase Error			5.0 deg
			10.0 deg
Freq. Error		-90	+90 Hz
BER			2.44 %
FER			0.12 %
BLER			0.12 %
RX Quality	5		6
RX Level	1		2
DC Current		50	200 mA
Camp On		250	700 mA
Talk			

Step 9 points to the highlighted fields in the left column. Step 10 points to the highlighted limit values in the table.

Step 9. Specify the highlighted fields of the test parameters as shown in the left side of the above screen.

Step 10. Enter the appropriate limits in the cells of the test item table above. For testing BLER it is required to set the upper limit value.

Step 11. After you have set all parameters, press the Return, Return again, then MANUAL TEST softkeys to obtain the MANUAL TEST: Stand-by screen shown below. Check if the Mode Sync/Async/GPRS softkey is set to GPRS.

MANUAL TEST: Stand-by 2001/09/23 12:34

Idle
 Attached
 Connect

Radio Standard: **GSM900**
 BCCH: **20: 894.0MHz**
 PDTC: **1: 890.2MHz**
 Signal: **Burst**
 Timing ADV: **5Bits**

Procedure: **Off**
 Multi Band: **Off**
 PWR CNTL: **15: +13dBm**
 DC Power: **Off 3.0V**
 BS Level: **-50.0dBm**

Slot Config: **1x1**
 Measured Slot: **4**
 Sensitivity: **BLER**

IMSI:
 IMEI:
 Power Class:

DC Current: ----mA
 ACT Tim ADV: ---Bits

Test Item
 Peak TX Power, Power vs Time
 Phase Error, Frequency Error
 Sensitivity
 DC Current
 Spectrum Monitor


Mode Sync/Async/GPRS
 Start
 RF ON
 Return

Press [Start] to begin a test.


Step 12. Turn the mobile on and wait for it to camp on displaying 001-01.

Using Functions
 Testing a Mobile with MANUAL TEST (GPRS mode)


Step 13. Press the Start softkey, then the screen changes to the following MANUAL TEST: Measuring screen, while the mobile is being processed to attach to the Test Set. Power Class will be shown first.



Step 14. Upon completion of the attaching process, the MANUAL TEST: Measuring screen is displayed as shown below.




Step 15. While the Attached step is blinking as above, you can select a test item by the CURSOR CONTROL knob to execute its measurement. Place the cursor at “Peak TX Power, Power vs Time” and press the CURSOR CONTROL knob, for example, to obtain the next screen.



Step 16. Press the Abort softkey to get other softkey menus.


Testing a Mobile with MANUAL TEST (GPRS mode)

- a. Press the Trigger Sing/Cont softkey to change the trigger mode to Sing (single) and the Zoom Off/On softkey to change the zoom mode to On.
- b. Press the More (1 of 3) softkey to reveal another softkey menu, and press Knob MKR/Cursor to change the knob control to MKR (marker).




- c. Press the Return softkey to return to the previous screen.

Step 17. Select Spectrum Monitor in the test item table to display the Spectrum Monitor measuring screen. Press Abort, More (1 of 3), Knob MKR/Cursor to obtain the next screen with the marker.



Step 18. Press the Return softkey to reveal the following Measuring screen to make another measurements.




Step 19. Press the End softkey to finish your test.

Testing a Mobile with SPECTRUM MONITOR


This procedure describes a test on an E-GSM mobile phone using the SPECTRUM MONITOR mode.

NOTE This section is applicable only for the Test Sets with Option 002.

- Step 1.** Turn the Test Set on and wait for its selftest routine to finish.
- Step 2.** Refer to “Preparation for Each Test” on page 22 for the procedures required before starting the test.
- Step 3.** Set the mobile phone to transmit RF power.



- Step 4.** Press the SPECTRUM MONITOR softkey in the initial screen to obtain the next SPECTRUM MONITOR screen.




- Step 5.** Rotate the CURSOR CONTROL knob and see how the circular cursor changes its position.

At one field, press the CURSOR CONTROL knob, then rotate it. You see that field changes its values. Press the CURSOR CONTROL knob to enter that value.

- Step 6.** Set the highlighted fields of the test parameters as shown in the above screen.


If you want to supply dc power from the Test Set to the mobile phone, set the DC Power field to On and enter your desired voltage value. To do this, use the Universal DC Power Adapter and an appropriate dc power cable to connect between the AUX port of the Test Set and the mobile phone.

- Step 7.** Press the Trigger Sing/Cont softkey to change the trigger mode to Sing (single). Press the Start softkey to begin your test.
- Step 8.** Press the More (1 of 3) softkey to reveal another softkey menu, then press the Knob MKR/Cursor softkey to change the knob control to MKR (marker). Notice that the marker is displayed. Use the knob to move the marker.



- Step 9.** Press the Return softkey to reveal the Spectrum Monitor screen in Step 4.
- Step 10.** Place the cursor in front of the Span field and change it to ± 100 kHz with the CURSOR CONTROL knob.
- Step 11.** Press the Start softkey to view the graph with the new span setting.

See how the measured data of three peaks close to the graticules of M1, M2 and M3 are shown in the lower left screen.



Step 11

- Step 12.** Press the Return softkey to reveal the initial screen.
Stop transmitting RF power from the mobile phone.

3 **Screen Reference**

In this chapter, each screen of the Test Set is explained in detail including the operational features and the functional softkeys activated for screens.


General Operation Guide

This section outlines how to operate the Test Set.

Front Panel Overview

The Test Set is designed for easy operation, flexibility, dual band mobile testing, measurement speed, and so forth with a simple front panel.

Figure 3-1 Front Panel of Agilent E6392B GSM MS Test Set



1. The LCD screen is used to display all of the testing conditions and test results.
2. Five softkeys, adjacent to the softkey labels shown in the LCD screen, are individually defined depending on each test mode and test sequence.
3. The CURSOR CONTROL knob basically has three major roles as follows:
 - **Moving the cursor:** Rotating the CURSOR CONTROL knob moves the blinking cursor from one input field to another either upward or downward, right or left, depending on the input fields arrangement. Input fields are highlighted. If a field is not highlighted, it is a read-only field.
 - **Selecting an entry for an input field:** Pressing the CURSOR CONTROL knob once at an input field causes the input field to blink.

When the field is blinking, the CURSOR CONTROL knob is used to view the values defined for that input field by scrolling through the selections (rotating the knob).


When the desired selection is shown in the field, pressing knob causes the selected value to enter into that input field. The cursor can then be used to move to another input field.

- **Controlling the marker:** For the graphic displays in the MANUAL TEST and SPECTRUM MONITOR modes, the Knob MKR/Cursor softkey is defined to select either Cursor for cursor control or MKR for marker control, whichever is underlined. If MKR is selected, this knob controls the marker position on a graphic display.
4. The **PRESET** key is provided to reset the Test Set and display the initial screen with the function mode softkey menu.
 5. The RF IN/OUT N-type female connector is provided to connect the RF output signal to the mobile under test or to receive the input signal from the mobile. While the RF signal is output from this connector, the green lamp is lit. (This lamp is INSTALLATION CATEGORY I.)
 6. The AUX connector is provided for Universal DC Power Adapter (P/N: E6392-60001) to supply dc power to the mobile under test through a cable.
 7. The CONTRAST knob controls the brightness of the LCD screen.
 8. The MEMORY CARD slot and the **EJECT** key are provided to save to or load from an SRAM memory card. Using the firmware update card, the current firmware can be updated to the new revision.
 9. The **LINE** key toggles the power on and off. The green lamp is lit while the power is on. (This lamp is INSTALLATION CATEGORY I.)

Rear Panel Overview

The following illustration shows the rear panel of the Test Set:

Figure 3-2 Rear Panel of Agilent E6392B GSM MS Test Set




1. The 13 MHz IN/OUT BNC-type female connector is provided to input or output the 13 MHz reference frequency signal.
2. The DB-9 male connector is the RS-232 SERIAL INTERFACE port which can be used for remotely controlling the Test Set.
3. The DB-25 female connector is the PRINTER port which can be used to interface with a printer.
4. The fuseholder contains a slowblow-type line fuse.
5. The ac power receptacle accepts a three-pronged power cord which is shipped with the Test Set.

Display Annotation

Depending on functions and test situations there are several types of LCD screens. The following illustration shows the most common areas.

Figure 3-3 LCD Display Annotation



1. The current function mode is shown in this area.
2. The current operation status in the AUTOMATIC TEST, MANUAL TEST, and CONFIGURATION modes is shown in this place. This status includes Stand-by, Measuring, Aborted, Passed or Failed, and Test Condition and Test Sequence.
3. The current date and time are shown.
4. The softkey labels are shown in this area. Each label defines the function of the corresponding softkey immediately to the right of the label.
5. This area is used for multiple purposes to show and/or configure functions such as a test flow, a test item table, test parameters and input fields, a test result text and/or graph, and so forth.
6. Operation messages or customer configurable instruction messages for test flow steps are shown in this area.

Screen Flow Chart

The following illustrations show the screen flow charts according to each function mode. Each rectangle represents one screen with a different function mode, measuring step and status, measurement result, and so forth. [Figure 3-5 on page 57](#) is applicable only for Test Sets with Option 002 and Option 040.

Figure 3-4 Screen Flow Chart
 Standard (without options)





Figure 3-5 Screen Flow Chart



NOTE Refer to "MANUAL TEST (GPRS Mode)" on page 118 for Option 040.

Test Parameters, Test Items and Allowable Ranges


Depending on the function modes, the Test Set has a number of input fields to be specified or defined to configure a test flow, test sequence and test condition. The allowable ranges for those input fields depending on the radio standards are explained in the following parts of this guide. For a quick overview, refer to [Appendix B, “Input Fields and Allowable Ranges.”](#)

Selecting an Input Field and Specifying a Value


All input fields to be specified are highlighted and the circular cursor is blinking in front of one of them.

To start, first select an input field and then specify a value to that input field by the following procedure:

- Step 1.** Rotate the CURSOR CONTROL knob clockwise to move the cursor downward or right, or rotate it counterclockwise to go upward or left, and place it at the input field you want to change.




- Step 2.** Press the CURSOR CONTROL knob once. The input field blinks, while the circular cursor stops blinking.




- Step 3.** Rotate the CURSOR CONTROL knob clockwise or counterclockwise to see the values defined for it.
- Step 4.** Press the CURSOR CONTROL knob to enter the desired value in the input field. The input field stops blinking and the circular cursor begins blinking again.

Storing Two Numeric Values

For numeric input fields such as channel numbers, input/output levels and power controls, you can store two numeric values using the memory softkey menus with the following procedure:




- Step 1.** Move the cursor to one of the numeric input fields of channels, input/output levels, or power controls.
- Step 2.** Upon selecting the field by pressing the CURSOR CONTROL knob, the softkey menu shown in the following figure is activated. The two memory softkeys show the values previously stored in the memories if any.
- Step 3.** Select a numeric value in the input field with the CURSOR CONTROL knob.
- Step 4.** Press the Store Val to Memory softkey to reveal another softkey menu for Memory1 and Memory2.



- Step 5.** Press either of the memory softkeys where you desire to store that value.
- Step 6.** The memory softkey menu returns to the state in [Step 2](#) showing the value newly stored.
- Step 7.** Press the CURSOR CONTROL knob to determine the value into the field and the softkey menu returns to that of [Step 1](#).

Recalling the Numeric Values

- Step 1.** Move the cursor to one of the numeric input fields of channels, input/output levels, or power controls.
- Step 2.** Upon selecting the field by pressing the CURSOR CONTROL knob, the softkey menu shown in the following figure is activated. The two memory softkeys show the values previously stored in the memories if any.



- Step 3.** Press the Memory1 or Memory2 softkey to enter the stored value to the field.
- Step 4.** The value is entered to the field and the softkey menu returns to that of [Step 1](#).

Variable Increment Softkey

Upon placing the circular cursor at an input field, such as channel number or level, that accepts a numeric value, one softkey with the variable increments is activated as shown in the previous illustration.

Pressing this increment softkey changes the multiplier from 1 to 1000, and each click of the knob varies the value by an increment specified by the increment softkey. The following multipliers are available for selection:

- ×1: Enables an increment of 1.
- ×10: Enables an increment of 10.
- ×100: Enables an increment of 100.
- ×1000: Enables an increment of 1000.

Initial Screen

After power on, the initial screen can be used to select one of the function modes as shown in [Figure 3-6](#). Also, the firmware revision name currently installed and the procedure selection field are shown.

To update the current firmware with the most recent one, refer to ["How to Update the Firmware"](#) on page 165.

To recall one of the test procedures from your SRAM memory card, refer to ["Recalling a Test Setup File"](#) on page 163.


To return to the initial screen from any function mode, press the Return softkey (multiple times if necessary).

NOTE

For Test Sets without Option 002, the SPECTRUM MONITOR and SIGNAL GENERATOR softkeys are not available.

Figure 3-6

Initial Screen



Softkey Menu

- o AUTOMATIC TEST: Displays the AUTOMATIC TEST: Stand-by screen and its softkey menu. Refer to ["AUTOMATIC TEST"](#) on page 63.
- o MANUAL TEST: Displays the MANUAL TEST: Stand-by screen and its softkey menu. Refer to ["MANUAL TEST \(Synchronous Mode\)"](#) on page 80, ["MANUAL TEST \(Asynchronous Mode\)"](#) on page 102 if Option 002 is installed, or ["MANUAL TEST \(GPRS Mode\)"](#) on page 118 if Option 040 is installed.
- o SPECTRUM MONITOR: Displays the SPECTRUM MONITOR screen and its softkey menu if Option 002 is installed. Refer to ["SPECTRUM MONITOR"](#) on page 136.
- o SIGNAL GENERATOR: Displays the SIGNAL GENERATOR screen and its softkey menu if Option 002 is installed. Refer to ["SIGNAL GENERATOR"](#) on page 143.

- o CONFIGURATION: Displays the CONFIGURATION screen and its softkey menu. Screens for setting up the test sequence, test condition, file management, firmware update are available in this mode. Refer to ["CONFIGURATION" on page 145](#).

AUTOMATIC TEST

In this test mode, Pass/Fail test results on all test items in the table are automatically obtained by configuring the Test Setup: Test Sequence screen and the Test Setup: Test Condition screen in the CONFIGURATION mode. Once a measurement cycle has been completed, detailed test results can be displayed by selecting one of the Pass/Fail cells in the test item table.

NOTE

Insert the test Subscriber Identity Module (SIM) in the mobile phone before performing any test, because the Test Set will attempt to perform measurements which are not generally permitted by usual SIMs.

The default state at power on is the previous setting stored in the internal memory before power off.

When entering numeric values, the variable increment softkey menu is displayed. Refer to [“Variable Increment Softkey”](#) and ["Storing Two Numeric Values" on page 59](#).

Stand-by Screen

When the AUTOMATIC TEST softkey is pressed after power on, either of the AUTOMATIC TEST: Stand-by simplified screen ([Figure 3-7](#)) or the AUTOMATIC TEST: Stand-by detailed screen ([Figure 3-8](#)) is displayed, depending on the previous setting of the Screen Simp/Detai softkey.

Figure 3-7

Stand-by Simplified Screen





Figure 3-8 Stand-by Detailed Screen



Softkey Menu

- o Start: Begins testing the mobile with AUTOMATIC TEST.
- o Screen Simp/Detail: Toggles between Simp for simplified and Detail for detailed to select one Stand-by screen.
- o Return: Displays the initial screen with function modes.

Screen Fields

The test flow steps from LOC. Update to BS/MS Release are shown to display which steps are included in a test along with the callers and releasers specified to either MS or BS on the Test Setup: Test Sequence screen in the CONFIGURATION mode. The test flow steps with “----” are skipped. Pass/Fail results are also shown for the test flow steps executed.

The input fields of the following parameters need to be set for a new test:

Input Field	Description										
Procedure	Displays a list of files that are on an SRAM memory card. If an SRAM memory card containing setup files is used, a list of those file names is shown in this field for selection. If there are no files on the card, this field remains blank.										
Radio Standard	Selects either GSM900, E-GSM, DCS1800, or PCS1900.										
Multi Band	Selects another band in addition to one in Radio Standard for testing dual band mobile phones. The allowable combinations of radio standards are as follows: <table border="0" style="margin-left: 40px;"> <tr> <td style="text-align: center;"><u>Radio Standard:</u></td> <td style="text-align: center;"><u>Multi Band:</u></td> </tr> <tr> <td style="text-align: center;">GSM900</td> <td style="text-align: center;">OFF, DCS1800</td> </tr> <tr> <td style="text-align: center;">E-GSM</td> <td style="text-align: center;">OFF, DCS1800</td> </tr> <tr> <td style="text-align: center;">DCS1800</td> <td style="text-align: center;">OFF, GSM900, E-GSM</td> </tr> <tr> <td style="text-align: center;">PCS1900</td> <td style="text-align: center;">OFF</td> </tr> </table>	<u>Radio Standard:</u>	<u>Multi Band:</u>	GSM900	OFF, DCS1800	E-GSM	OFF, DCS1800	DCS1800	OFF, GSM900, E-GSM	PCS1900	OFF
<u>Radio Standard:</u>	<u>Multi Band:</u>										
GSM900	OFF, DCS1800										
E-GSM	OFF, DCS1800										
DCS1800	OFF, GSM900, E-GSM										
PCS1900	OFF										
BCCH ^a	Specifies the broadcast control channel. The frequency corresponding to the channel accompanies. The allowable range is as follows: <table border="0" style="margin-left: 40px;"> <tr> <td>GSM900: 1 to 124</td> </tr> <tr> <td>E-GSM: 0 to 124, and 975 to 1023</td> </tr> <tr> <td>DCS1800: 512 to 885</td> </tr> <tr> <td>PCS1900: 512 to 810</td> </tr> </table>	GSM900: 1 to 124	E-GSM: 0 to 124, and 975 to 1023	DCS1800: 512 to 885	PCS1900: 512 to 810						
GSM900: 1 to 124											
E-GSM: 0 to 124, and 975 to 1023											
DCS1800: 512 to 885											
PCS1900: 512 to 810											
DC Power	Selects a supply mode. The choices are Auto, On, and Off as follows: <ul style="list-style-type: none"> o Auto: Supplies dc voltage to the mobile only during a test cycle. o On: Always supplies dc voltage to the mobile. o Off:^b Disables to supply dc voltage to the mobile. If this is selected, the Variable field is automatically set to TCH. <p>Accepts a dc voltage value^a ranging from 3.0 to 11.0 V in 0.1 V steps. This value is used among the AUTOMATIC TEST, MANUAL TEST, SPECTRUM MONITOR, and SIGNAL GENERATOR modes in common.</p>										

Input Field	Description
TCH (Talk) ^a	<p>Specifies the traffic channel depending on the parameter selection in the Variable field. The frequency corresponding to the channel accompanies.</p> <p>If TCH is selected in the Variable field, this specifies one traffic channel to make Talk tests in addition to six traffic channels for RF tests.</p> <p>If DC Power is selected in the Variable field, this specifies one traffic channel to make both Talk tests and RF tests.</p>
Variable	<p>Selects either TCH or DC Power as follows:</p> <ul style="list-style-type: none"> o TCH: Enables to make six measurements on six traffic channels specified in the TCH input fields of the Test Item table, with or without one fixed dc voltage. o DC Power: Enables to make six measurements on one traffic channel with six dc voltages specified in the DCP input fields of the Test Item table.
TCH or DCP ^a (up to 6)	<p>According to the selection of Variable, either of the following parameters need to be specified for a new test:</p> <ul style="list-style-type: none"> o TCH: Accepts up to six traffic channels with regard to Multi Band. The allowable range is as follows: <ul style="list-style-type: none"> GSM900: 1 to 124 E-GSM: 0 to 124, and 975 to 1023 DCS1800: 512 to 885 PCS1900: 512 to 810 o DCP: Accepts up to six dc voltages ranging from 3.0 to 11.0 V in 0.1 V steps.

- a. The variable increment softkey is activated. Refer to "[Variable Increment Softkey](#)" on page 60.
- b. When DC Power is set to Off, DC Current cannot be measured and "----" is shown in the DC Current cells in the table of the AUTOMATIC TEST: Stand-by detailed screen.

If the Screen Simp/Detail softkey is selected, the test items in the table below are shown. Pass/Fail test results against the limits set on the Test Setup: Test Condition screen in the CONFIGURATION mode are also shown.

Test Item	Description
Peak TX Power	Measures and analyzes three peak transmission power levels at High, Mid, and Low.
Burst Timing	Measures and analyzes the power burst timing.
Power Ramp	Measures and analyzes the amplitude envelope in the timeslots of the RF burst signal.
Phase Error	Measures and analyzes the rms and peak phase errors over the active part of the timeslots between 0 to 147 bits.
Frequency Error	Measures and analyzes the frequency error over the active part of the timeslots.
Sensitivity	Measures and analyzes the receiver sensitivity in the BER and FER formats using the loopback function.
RX Quality	Measures and analyzes the received signal quality.
RX Level	Measures and analyzes the received signal level.
DC Current	Measures and analyzes the dc currents consumed at the Camp On and Talk steps of the test flow.

If some items are denoted to be skipped on the Test Setup: Test Sequence screen, or if the DC Power field is set to Off, “----” is shown in those table cells and the corresponding steps in the test flow.

The RF ON annunciator at the lower-right corner of the screen is displayed only when the RF signal from the Test Set is present at the RF IN/OUT connector.

Operation and instruction messages are displayed at the bottom screen. You can create up to 7 instruction messages corresponding to each test flow step using Instruction: # and the Choices: scrolling window on the Test Setup: Test Sequence screen in the CONFIGURATION mode. Refer to "[Test Setup: Test Condition Screen](#)" on page 148 and "[Test Setup: Test Sequence Screen](#)" on page 153.

The following display fields remain blank on the lower screen at this state:

Display Field	Description
IMSI:	Displays the International Mobile Subscriber Identity from the mobile.
IMEI:	Displays the International Mobile Station Equipment Identity from the mobile.
Dialed No.:	Displays the number dialed from the mobile.
Power Class:	Displays one of the defined factors. See "Power Classes" on page 184.
GSM Version:	Displays either Phase 1 or Phase 2 defined by the mobile.

Talk Measuring Screen

While the measurement is being done after pressing the Start softkey, either the AUTOMATIC TEST: Measuring simple (Figure 3-9) or detailed screen (Figure 3-10) is displayed, depending on the previous setting of the Screen Simp/Detai softkey. The following examples illustrate the screens testing up to the Talk step of the test flow.

Figure 3-9 Talk Measuring Simplified Screen





Figure 3-10 Talk Measuring Detailed Screen



Softkey Menu

- o Pass: Press this softkey if your voice is echoed back from the mobile with good quality. This softkey is activated at the time of the Talk step and erased if pressed.
- o Fail: Press this softkey if your voice is echoed back from the mobile with poor quality. This softkey is activated at the time of the Talk step and erased if pressed.
- o Screen Simp/Detai: Toggles between Simp for simplified and Detai for detailed to select one of the AUTOMATIC TEST: Measuring screens.
- o Abort: Stops the measurement and returns to the Stand-by screen.

Screen Fields

After the Start softkey is pressed in the Stand-by screen, the measurement is initiated and the Measuring screen is displayed.

While making a measurement, the operator must respond to operation or instruction messages by pressing the appropriate softkeys of the Test Set, or by pressing the mobile's keys. Also the circular cursor is not shown because you cannot modify any of the parameter values or test conditions during testing.

One of the test flow steps blinks to show which step is currently being tested. While the RF Test step is blinking, each of the test items blinks sequentially to obtain a test result.

The DC Current consumed at the camp on stage is measured at the LOC. The Update step and its result is displayed in the DC Current cells of the table in the Measuring Detailed screen, when DC Power is set to Auto or On and dc power is supplied from the Test Set to the mobile using the appropriate dc power cable.

The following display fields show the data from the mobile on the lower screen at this state:

Display Field	Description
IMSI:	Displays the International Mobile Subscriber Identity from the mobile.
IMEI:	Displays the International Mobile Station Equipment Identity from the mobile.
Dialed No.:	Displays the number dialed from the mobile.
Power Class:	Displays one of the defined factors. See " Power Classes " on page 184.
GSM Version:	Displays either Phase 1 or Phase 2 defined by the mobile.

Aborted Screen

If the measurement is aborted by pressing the Abort softkey, either the AUTOMATIC TEST: Aborted simplified screen (Figure 3-11) or detailed screen (Figure 3-12) is displayed, depending on the previous setting of the Screen Simp/Detai softkey.

Figure 3-11 Aborted Simplified Screen





Figure 3-12 Aborted Detailed Screen



Softkey Menu 1

- o Start: Begins a new test.
- o Screen Simp/Detai: Toggles between Simp for simplified and Detai for detailed to select one of the AUTOMATIC TEST: Aborted screens.
- o More (1 of 2): Displays softkey menu 2.
- o Return: Displays the initial screen with function modes.

Softkey Menu 2

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o Print All: Allows you to print a hardcopy set of the whole test parameters and the Pass/Fail test results with measured actual data.
- o More (2 of 2): Returns to softkey menu 1.

- o Return: Displays the initial screen with function modes.

Explanation

Detailed test results up to the aborted operation can be obtained for further analysis. Place the circular cursor at one of the Pass/Fail cells and press the CURSOR CONTROL knob once to get detailed test results.

The Test Set is reset to the state of the AUTOMATIC TEST: Stand-by screen. The MS Call state is not ensured, therefore the MS power-on process needs to be repeated for a new test.

Other information related to the mobile are also displayed in either simplified or detailed screen. Refer to "[Screen Fields](#)" on page 70.

Pass/Fail Screen

When a test is completed, either of the Pass/Fail simplified screen (Figure 3-13) or detailed screen (Figure 3-14) is displayed depending on the previous setting of the Screen Simp/Detail softkey. “Pass” is normally displayed in the table cells, however, any data indicating a failure is highlighted.

Figure 3-13 Pass/Fail Simplified Screen





Figure 3-14 Pass/Fail Detailed Screen



Softkey Menu 1

- o Start: Begins a new test.
- o Screen Simp/Detail: Toggles between **Simp** for simplified and **Detail** for detailed to select one of the AUTOMATIC TEST: Pass/Fail screens.
- o More (1 of 2): Displays softkey menu 2.
- o Return: Displays the initial screen with function modes.

Softkey Menu 2

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o Print All: Allows you to print a hardcopy set of the whole test’s parameters and the Pass/Fail test results with measured actual data.
- o More (2 of 2): Returns to softkey menu 1.

- o Return: Displays the initial screen with function modes.

Explanation

In the Pass/Fail detailed screen, the test item cells are filled with the conclusion of either Pass or Fail. If some items are denoted to be skipped in the Test Sequence screen or the DC Power field is set to Off, “----” is shown in those cells and the corresponding steps in the test flow.

Procedure to Obtain Each Pass/Fail Detailed Screen

Use the following procedure to obtain each Pass/Fail detailed screen:

- Step 1.** Place the circular cursor at one of the Pass/Fail result cells of the Test Item table by rotating the CURSOR CONTROL knob.
- Step 2.** Choose that test result cell by pressing the CURSOR CONTROL knob one time.
- Step 3.** Either a data list or a graph with a data list is displayed according to each test item.
- Step 4.** Repeat [Step 1](#) to [Step 3](#) to observe other Pass/Fail test results in the Test Item table.
- Step 5.** Press the Start softkey to execute a new test, or press the Return softkey to go to the initial screen.

Pass/Fail Screen Examples


The following illustrations show some of the typical detailed screens with Pass/Fail test results.

Pass/Fail: Peak TX Power

This function measures and analyzes three peak transmission power levels against the limits set on the Test Condition screen in the CONFIGURATION mode. The actual measured data are shown with vertically enlarged numerals. Any data indicating a failure is highlighted.

Figure 3-15

Failed: Peak TX Power Screen



Softkey Menu

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o Return: Displays the Pass/Fail screen.

Pass/Fail: Burst Timing/Power Ramp

This function measures and analyzes the power burst timing and the amplitude envelope in the timeslots of the RF burst signal, however, the Power Ramp result text is shown when the marker is placed at any point of its measured trace. If the actual data exceeds the limits in the graph, one (or two for two fails) white triangle marker indicates the failed position at the top of the graph frame. Any data indicating a failure is highlighted.

Figure 3-16 Passed: Burst Timing/Power Ramp Screen





Figure 3-17 Passed: Burst Timing/Power Ramp Zoomed Screen



Softkey Menu


- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o Marker Coars/Fine: Toggles the marker control between Coars for coarse and Fine to move the marker with 10 dots (coarse) or 1 dot (fine) resolution. The marker readouts for the amplitude and timeslot (in bits) are available at any point of the measured trace.
- o Zoom Off/On: Toggles the zooming function between Off and On. If On is selected, the rising and trailing edges of Power Ramp are expanded to observe the details as shown in [Figure 3-17](#).
- o Return: Displays the Pass/Fail screen.

Pass/Fail: Phase Error/Frequency Error

This function measures and analyzes the rms and peak phase errors and frequency error over the active part of the timeslots between 0 to 147 bits. The test data for RMS, Peak and Marker Phase errors, and Frequency error are displayed, and the graphic display with phase versus timeslots (in bits) is shown. If the actual data exceeds the limits in the graph, one (or two for two fails) white triangle marker indicates the failed position at the top of the graph frame. Any data indicating a failure is highlighted.

Figure 3-18

Passed: Phase Error/Frequency Error Screen




Softkey Menu

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o Marker Coars/Fine: Toggles the marker control between Coars for coarse and Fine to move the marker with 10 dots (coarse) or 1 dot (fine) resolution. The marker readouts for the phase error magnitude and timeslot (in bits) are available at any point of the measured trace.
- o Return: Displays the Pass/Fail screen.

Pass/Fail: Sensitivity/RX Quality/RX Level

This function measures and analyzes the receiver sensitivity in the BER (bit error rate) and FER (frame erasure rate) formats, and the received signal quality and level using the loopback function. The test data for BER, FER, RX Quality, and RX Level are shown as follows. Any data indicating a failure is highlighted.

Figure 3-19 **Passed: Sensitivity/RX Quality/RX Level Screen**



Softkey Menu


- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o Return: Returns to the Pass/Fail screen.

Pass/Fail: DC Current

This function measures and analyzes the dc currents consumed at the Camp On and Talk steps. The test data are shown as follows. Any data indicating a failure is highlighted.

Figure 3-20

Passed: DC Current Screen



Softkey Menu

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o Return: Displays the Pass/Fail screen.

MANUAL TEST (Synchronous Mode)

In the MANUAL TEST mode, each test item or a group of test items can be measured and analyzed with test limits defined in the Test Setup: Test Condition screen of the CONFIGURATION mode.

In the synchronous mode, tests are made while the Test Set and the mobile phone are networked to communicate with each other. This mode is used to test mobile phones during the Talk/RF Test step of a test flow, in a real-time manner.

Measurement Mode Selection

Depending on the installation of the currently available options, the measurement modes in MANUAL TEST are different as shown in the following table:

Option(s)	Selectable Measurement Modes
None (standard)	Not selectable but SYNC (default setting)
002	SYNC/ASYNC
040	SYNC/GPRS
002 and 040	SYNC/ASYNC/GPRS

Test SIM

Insert the test Subscriber Identity Module (SIM) in the mobile phone before performing any test, because the Test Set will attempt to perform measurements which are not generally permitted by normal SIMs.

NOTE

The default state is the last setting stored in the internal memory before power off.


NOTE

When entering numeric values, the variable increment softkey menu is displayed. Refer to [“Variable Increment Softkey”](#) and ["Storing Two Numeric Values"](#) on page 59.

Stand-by Screen

When the MANUAL TEST mode is selected, the following Stand-by screen is displayed:

Figure 3-21 Synchronous Mode Stand-by Screen



Softkey Menu

- o Mode Sync/Async/GPRS: Select either Sync for synchronous, Async for asynchronous, or GPRS for general packet radio service mode. This softkey is available only for Test Sets equipped with Option 002 and Option 040.
- o BS Call: Executes the Call Setup process from the Test Set. The operation message, “Processing...”, is shown and the mobile is called.
- o MS Call: Shows the operation message, “Executing a call setup from the mobile.”, is shown for a user to take action.
- o Return: Displays the initial screen with function modes.

Screen Fields

The input fields of the following parameters need to be set for a new test:

Input Field	Description										
Procedure	<p>Displays a list of files that are on an SRAM memory card.</p> <p>If an SRAM memory card containing setup files is used, a list of those file names is shown in this field for selection. If there are no files on the card, this field remains blank.</p>										
Radio Standard	<p>Selects either GSM900, E-GSM, DCS1800, or PCS1900.</p>										
Multi Band	<p>Selects another band in addition to one in Radio Standard for testing dual band mobile phones. The allowable combinations of radio standards are as follows:</p> <table data-bbox="703 768 1289 970"> <thead> <tr> <th><u>Radio Standard:</u></th> <th><u>Multi Band:</u></th> </tr> </thead> <tbody> <tr> <td>GSM900</td> <td>OFF, DCS1800</td> </tr> <tr> <td>E-GSM</td> <td>OFF, DCS1800</td> </tr> <tr> <td>DCS1800</td> <td>OFF, GSM900, E-GSM</td> </tr> <tr> <td>PCS1900</td> <td>OFF</td> </tr> </tbody> </table>	<u>Radio Standard:</u>	<u>Multi Band:</u>	GSM900	OFF, DCS1800	E-GSM	OFF, DCS1800	DCS1800	OFF, GSM900, E-GSM	PCS1900	OFF
<u>Radio Standard:</u>	<u>Multi Band:</u>										
GSM900	OFF, DCS1800										
E-GSM	OFF, DCS1800										
DCS1800	OFF, GSM900, E-GSM										
PCS1900	OFF										
BCCH ^a	<p>Specifies the broadcast control channel. The frequency corresponding to the channel accompanies. The allowable range is as follows:</p> <p>GSM900: 1 to 124 E-GSM: 0 to 124, and 975 to 1023 DCS1800: 512 to 885 PCS1900: 512 to 810</p>										
PWR CNTL	<p>Specifies one of the factors defined for Power Control Levels according to the Radio Standard. The allowable factor ranges are as follows:</p> <p>GSM900 and E-GSM: 2 (+39 dBm) to 19 (+5 dBm) DCS1800: 29 (+36 dBm) to 31 (+32 dBm), and 0 (+30 dBm) to 15 (+0 dBm) PCS1900: 30 (+33 dBm) to 31 (+32 dBm), and 0 (+30 dBm) to 15 (+0 dBm)</p>										
TCH ^a	<p>Accepts one traffic channel. The frequency corresponding to the channel accompanies. The allowable range is as follows:</p> <p>GSM900: 1 to 124 E-GSM: 0 to 124, and 975 to 1023 DCS1800: 512 to 885 PCS1900: 512 to 810</p>										

Input Field	Description
DC Power	<p>Selects a supply mode. The choices are On and Off as follows:</p> <ul style="list-style-type: none"> o On: Always supplies dc voltage to the mobile. o Off:^b Disables to supply dc voltage to the mobile. <p>Accepts a dc voltage value^a ranging from 3.0 to 11.0 V in 0.1 V steps. This value is used among the AUTOMATIC TEST, MANUAL TEST, SPECTRUM MONITOR, and SIGNAL GENERATOR modes in common.</p>
Signal	For synchronous mode tests, only Burst is valid and cannot be changed.
BS Level	Specifies the RF output level ^a of the Test Set, ranging from –110.0 to –50.0 dBm. The default value is set on the Test Condition screen in the CONFIGURATION mode.
Timing ADV	Accepts a value for the timing advance ^a ranging from 0 to 63 bits.

- a. The variable increment softkey is activated. Refer to "[Variable Increment Softkey](#)" on page 60.
- b. When DC Power is set to Off, DC Current cannot be measured.

The following test items are shown in groups in the table. The detailed test screens for the groups are displayed when selected by the CURSOR CONTROL knob.

Test Item	Description
Peak TX Power, Burst Timing, Power Ramp	The Measuring: Peak TX Power/Burst Timing/Power Ramp screen is shown with a result text and graphic display.
Phase Error, Frequency Error	The Measuring: Phase Error/Frequency Error screen is shown with a result text and graphic display.
Sensitivity, RX Quality, RX Level	The Measuring: Sensitivity/RX Quality/RX Level screen is shown with a result text display.
DC Current	The Measuring: DC Current screens for Camp On and Talk are shown with result text displays.
Spectrum Monitor	The Measuring: Spectrum Monitor screen is shown with a result text and graphic display.

The following display fields remain blank on the lower screen at this state:

Display Field	Description
IMSI:	Displays the International Mobile Subscriber Identity from the mobile.
IMEI:	Displays the International Mobile Station Equipment Identity from the mobile.
Dialed No.:	Displays the number dialed from the mobile.
Power Class:	Displays one of the defined factors. See "Power Classes" on page 184.
GSM Version:	Displays either Phase 1 or Phase 2 defined by the mobile.
RX Quality:	Displays the measurement result for the receiver characteristics.
RX Level:	Displays the measurement result for the receiver characteristics.
DC Current:	Displays the dc current consumed by the mobile at the connection state.
ACT Tim ADV:	Displays the number of bits for the actual timing advance data.

The RF ON annunciator at the screen lower right corner is displayed only when the RF signal from the Test Set is present at the RF IN/OUT connector.

The instruction message “Press [BS Call] or [MS Call].” is shown. By pressing the BS Call or MS Call softkey, the first Measuring screen is shown, and you can then execute a test.

MS Call or BS Call Measuring Screen

When the BS Call or MS Call softkey is pressed, the following Measuring screen is displayed before proceeding to the Talk/RF Test step:

Figure 3-22 MS Call Measuring Screen





Figure 3-23 BS Call Measuring Screen



Softkey Menu

- o Abort: Stops the measurement and returns to the MANUAL TEST: Stand-by screen.

Explanation

If the MS Call softkey is pressed, the MS Call step in the test flow starts blinking and the operation message “Executing a call setup from the mobile.” is shown. When a proper call setup is made, the Talk/RF Test step starts blinking as shown in "Talk/RF Test Measuring Screen" on page 88.

If the BS Call softkey is pressed, the BS Call step starts blinking, and the mobile needs to respond to the Test Set, for example by pressing the **SEND** key. The operation message “Processing...” is shown and then the test sequence goes to the Talk/RF Test step making it start blinking as shown in "Talk/RF Test Measuring


[Screen" on page 88](#). If the response from the mobile takes too much time, the message changes to “Time out error. Press [Abort].” Then, the measurement is cancelled and the screen returns to the Stand-by screen.

In both cases, you cannot change the DC Power supply mode field, however, the DC Power voltage field of the MS Call measuring screen can be changed for making DC Current tests at Camp On. The dc current measurement result for a call setup is shown under the test item table along with other mobile related information but the dialed number is shown only in the case of MS Call.

Talk/RF Test Measuring Screen

While the Talk/RF Test step is blinking as shown in Figure 3-24, you can make measurements on each test item before releasing the mobile. If you select a test item column with the CURSOR CONTROL knob, the corresponding measuring screen is displayed making real-time measurements.

Figure 3-24 Talk/RF Test Measuring Screen



Softkey Menu

- o BS Release: Executes Call End from the Test Set showing the operation message “Processing...”.
- o MS Release: Shows the operation message “Executing a call end from the mobile.” for a user to take action.

NOTE

For Call End from the mobile, both of pressing the MS Release softkey and executing the call end from the mobile are required.

- o Abort: Returns to the MANUAL TEST: Stand-by screen, and then to the initial screen with function modes.

NOTE

After pressing the Abort softkey, execute call end from the mobile; otherwise the call processing may be failed at the next measurement.

Explanation

While the Talk/RF Test step is blinking, one of the test items can be selected by rotating and pressing the CURSOR CONTROL knob, and its measurements are made in a real-time manner showing the changes in characteristics of the mobile under test.

In this state, DC Current under the test item table shows the dc current consumed at the Talk/RF Test step. RX Quality and RX Level are also shown in this place.

Procedure to obtain the Measuring screens

- Step 1.** Place the blinking cursor at one of the test items by rotating the CURSOR CONTROL knob.

Step 2. Choose that test item by pressing the CURSOR CONTROL knob.

Step 3. Either result text or text with a graph is shown according to the Test Item chosen.

Measuring Screen Examples


Measuring: Peak TX Power/Burst Timing/Power Ramp

The actual measurement data are shown in enlarged numerals but the Power Ramp result text is shown when the marker is placed at any point of its measured trace. If the actual data exceeds the limits in the graph, one (or two for two fails) white triangle marker indicates the failed position at the top of the graph frame. Any data indicating a failure is highlighted.

While making continuous measurements, the Trigger Sing/Cont softkey is blinking as shown in Figure 3-25. If Abort softkey is pressed, another softkey menu is shown to activate the trigger mode, zooming and marker functions as shown in Figure 3-26.

Figure 3-25

Measuring: Peak TX Power/Burst Timing/Power Ramp Screen



Softkey Menu

- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes if the Abort softkey is pressed. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle and the marker function is available with the Knob MKR/Cursor softkey.
- o Abort: Stops continuous measurements and shows another softkey menu as follows.

Figure 3-26

Aborted: Peak TX Power/Burst Timing/Power Ramp Screen





Figure 3-27

Aborted: Peak TX Power/Burst Timing/Power Ramp Zoomed Screen



Softkey Menu 1

- o Start: Begins a new measurement cycle with either single or continuous trigger mode.
- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle and the marker function is available with the Knob MKR/Cursor softkey.
- o Zoom Off/On: Toggles the zooming function between Off and On. If On is selected, the rising edge, between -8 bits to 0 bits, and trailing edge, between 147 and 155 bits, of Power Ramp are expanded to observe the detailed test result as shown in [Figure 3-27](#).
- o More (1 of 3): Displays softkey menu 2.
- o Return: Returns to the Talk/RF Test Measuring screen.

Softkey Menu 2

- o Knob MKR/Cursor: Toggles the function of the CURSOR CONTROL knob between Cursor and MKR for marker control.

- o Marker Coars/Fine: Toggles the marker control between Coars for coarse and Fine to move the marker with 10 dots (coarse) or 1 dot (fine) resolution. The marker readouts for the amplitude and timeslot (in bits) are available at any point of the measured trace.
- o More (2 of 3): Displays softkey menu 3.
- o Return: Returns to the Talk/RF Test Measuring screen.

Softkey Menu 3

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o More (3 of 3): Returns to softkey menu 1.
- o Return: Returns to the Talk/RF Test Measuring screen.


Measuring: Phase Error/Frequency Error

The RMS and Peak Phase Error and Frequency Error are shown along with the marker readout if the marker is activated. If the actual data exceeds the limits in the graph, one (or two for two fails) white triangle marker indicates the failed position at the top of the graph frame.

If there is no limit value set in either HI Limit or LO Limit, “-----” is shown for a value.

Figure 3-28

Aborted: Phase Error/Frequency Error Screen



Softkey Menu 1

- o Start: Begins a new test.
- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle and the marker function is available with the Knob MKR/Cursor softkey.
- o More (1 of 3): Displays softkey menu 2.
- o Return: Returns to the Talk/RF Test Measuring screen.

Softkey Menu 2

- o Knob MKR/Cursor: Toggles the function of the CURSOR CONTROL knob between Cursor and MKR for marker control.
- o Marker Coars/Fine: Toggles the marker control between Coars for coarse and Fine to move the marker with 10 dots (coarse) or 1 dot (fine) resolution. The marker readouts for the phase error magnitude and timeslot (in bits) are available at any point of the measured trace.
- o More (2 of 3): Displays softkey menu 3.
- o Return: Returns to the Talk/RF Test Measuring screen.

Softkey Menu 3


- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o More (3 of 3): Returns to softkey menu 1.
- o Return: Returns to the Talk/RF Test Measuring screen.

Measuring: Sensitivity/RX Quality/RX Level

The test data for BER, FER, RX Quality, and RX Level are shown as follows. Any data indicating a failure is highlighted.

Figure 3-29

Aborted: Sensitivity/RX Quality/RX Level Screen



Softkey Menu 1

- o Start: Begins a new test.
- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle.
- o More (1 of 2): Displays softkey menu 2.
- o Return: Returns to the Talk/RF Test Measuring screen.

Softkey Menu 2

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o More (2 of 2): Returns to softkey menu 1.
- o Return: Returns to the Talk/RF Test Measuring screen.

Measuring: DC Current


NOTE DC current measurements can be executed only when the DC Power field is set to On and dc power is supplied from the Test Set to the mobile phone.

Camp On DC Current is measured at the Camp On state for MS Call as shown in Figure 3-30.

NOTE Camp On DC Current can be measured when the MS Call softkey is pressed and before executing the call setup from the mobile.

Talk DC Current is measured at the Talk/RF Test state as shown in Figure 3-31. Any data indicating a failure is highlighted.


Figure 3-30 Measuring: Camp On DC Current Screen



Softkey Menu

- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle.
- o Abort: Stops continuous measurements and shows another softkey menu as follows.

Figure 3-31 Aborted: Talk DC Current Screen



Softkey Menu 1

- o Start: Begins a new test.
- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle.
- o More (1 of 2): Displays softkey menu 2.
- o Return: Returns to the Talk/RF Test Measuring screen.


Softkey Menu 2

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o More (2 of 2): Returns to softkey menu 1.
- o Return: Returns to the Talk/RF Test Measuring screen.

Measuring: Spectrum Monitor

The RF spectrum of the traffic channel can be measured with Spectrum Monitor. When aborted, the span from 0 Hz to +400 kHz relative to the traffic channel frequency is shown with the readouts at +200 kHz (M1) and +250 kHz (M2) offsets. The actual measured amplitudes at those frequencies are shown in enlarged numerals.

Figure 3-32 Measuring: Spectrum Monitor Screen




Softkey Menu

- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle.
- o Abort: Stops continuous measurements and shows another softkey menu.

If the Abort softkey is pressed, another softkey menu is shown to activate the trigger mode and marker functions as shown in [Figure 3-33](#).

Figure 3-33 Aborted: Spectrum Monitor Screen



Softkey Menu 1

- o Start: Begins a new test.

- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle and the marker function is available with the Knob MKR/Cursor softkey.
- o More (1 of 3): Displays softkey menu 2.
- o Return: Returns to the Talk/RF Test Measuring screen.

Softkey Menu 2

- o Knob MKR/Cursor: Toggles the function of the CURSOR CONTROL knob between Cursor and MKR for marker control.
- o Marker Coars/Fine: Toggles the marker control between Coars for coarse and Fine to move the marker with 10 dots (coarse) or 1 dot (fine) resolution. The marker readouts for the frequency and amplitude are available at any point of the measured trace.
- o More (2 of 3): Displays softkey menu 3.
- o Return: Returns to the Talk/RF Test Measuring screen.

Softkey Menu 3

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o More (3 of 3): Returns to softkey menu 1.
- o Return: Returns to the Talk/RF Test Measuring screen.

Screen Fields

The following test parameters need to be specified for a new test:

Input Field	Description
Channel ^a	<p>Specifies one traffic channel to be analyzed. The frequency corresponding to the channel accompanies. The allowable range is as follows:</p> <p>GSM900: 1 to 124 E-GSM: 0 to 124, and 975 to 1023 DCS1800: 512 to 885 PCS1900: 512 to 810</p>
PWR CNTL	<p>Specifies one of the factors defined for Power Control Levels according to the Radio Standard. The allowable factor ranges are as follows:</p> <p>GSM900 and E-GSM: 2 (+39 dBm) to 19 (+5 dBm) DCS1800: 29 (+36 dBm) to 31 (+32 dBm), and 0 (+30 dBm) to 15 (+0 dBm) PCS1900: 30 (+33 dBm) to 31 (+32 dBm), and 0 (+30 dBm) to 15 (+0 dBm)</p>
Span	0 to 400 kHz (fixed)
RBW	<p>Selects either 10 kHz or 30 kHz resolution bandwidth as follows:</p> <ul style="list-style-type: none"> o 10: Sets the resolution bandwidth to 10 kHz. o 30: Sets the resolution bandwidth to 30 kHz.
Averaging ^a	Specifies the averaging number of measurements from 2 to 99, unless Off is selected.
DC Power: ^a	<p>The supply mode is dependent on the setting in the Stand-by screens.</p> <p>Accepts a dc voltage value ranging from 3.0 to 11.0 V in 0.1 V steps. This value is used among the AUTOMATIC TEST, MANUAL TEST, SPECTRUM MONITOR, and SIGNAL GENERATOR modes in common.</p>
BS Level	Specifies the RF output level ^a of the Test Set, ranging from –110.0 to –50.0 dBm. The default value is set on the Test Condition screen in the CONFIGURATION mode.

a. The variable increment softkey is activated. Refer to "[Variable Increment Softkey](#)" on page 60.

The following display fields show the measurement results:

Display Field	Description
Peak	The absolute peak power and frequency are shown.
Marker ^a	<p>The frequency and amplitude readouts at the marker point are shown when activated by the Knob MKR/Cursor softkey as follows:</p> <ul style="list-style-type: none"> o ----- MHz ---- dBm: The absolute frequency and amplitude of the marker readouts are shown. o (---- kHz ---- dB): The relative frequency and amplitude of the marker readouts are shown.
M1: +200 kHz, M2: +250 kHz	The amplitude data at +200 kHz and +250 kHz offsets are also shown.

- a. The frequency resolution is 1 kHz or 2 kHz due to the measurement period of 1.59 kHz.

MANUAL TEST (Asynchronous Mode)

NOTE

The Asynchronous mode is only available for Test Sets with Option 002 which enables the signal generator and TX analyzer modes too. This option can be installed with Option 040 for GPRS Mode

In the MANUAL TEST mode, each test item or a group of test items can be measured and analyzed with the test limits specified in the Test Set: Test Condition screen of the CONFIGURATION mode.

In the asynchronous mode, tests are made without networking the Test Set and the mobile phone with each other. This mode is used to test the RF transmission characteristics of mobiles in a real-time manner. Therefore, the receiver related characteristics such as sensitivity, RX quality and RX level are not measured. Also, the mobile related information such as IMSI, IMEI and so forth are not available, however, DC Current is displayed under the test item table.

To test mobiles using the asynchronous mode, set the mobile to transmit RF power independently (without sending a special command from the Test Set to the mobile, for instance).

NOTE


When entering numeric values, the variable increment softkey menu is displayed. Refer to [“Variable Increment Softkey”](#) and ["Storing Two Numeric Values"](#) on page 59.

The default state is the last setting stored in the internal memory before power off.

Stand-by Screen

If the Mode Sync/Async/GPRS softkey is selected, the following Stand-by screen is displayed:

Figure 3-34 Asynchronous Mode Stand-by Screen



Softkey Menu

- o Mode Sync/Async/GPRS: Select either Sync for synchronous, Async for asynchronous, or GPRS for general packet radio service mode. This softkey is available only for Test Sets equipped with Option 002 and Option 040.
- o Start: Begins a new test.
- o Return: Displays the initial screen with function modes.

Screen Fields

The following parameters need to be specified for a new test:

Input Field	Description										
Procedure	<p>Displays a list of files that are on an SRAM memory card.</p> <p>If a SRAM memory card containing setup files is used, a list of those file names is shown in this field for selection. If there are no files on the card, this field remains blank.</p>										
Radio Standard	<p>Selects either GSM900, E-GSM, DCS1800, or PCS1900.</p>										
Multi Band	<p>Selects another band in addition to one in Radio Standard for testing dual band mobile phones. The allowable combinations of radio standards are as follows:</p> <table data-bbox="703 757 1286 959"> <thead> <tr> <th><u>Radio Standard:</u></th> <th><u>Multi Band:</u></th> </tr> </thead> <tbody> <tr> <td>GSM900</td> <td>OFF, DCS1800</td> </tr> <tr> <td>E-GSM</td> <td>OFF, DCS1800</td> </tr> <tr> <td>DCS1800</td> <td>OFF, GSM900, E-GSM</td> </tr> <tr> <td>PCS1900</td> <td>OFF</td> </tr> </tbody> </table>	<u>Radio Standard:</u>	<u>Multi Band:</u>	GSM900	OFF, DCS1800	E-GSM	OFF, DCS1800	DCS1800	OFF, GSM900, E-GSM	PCS1900	OFF
<u>Radio Standard:</u>	<u>Multi Band:</u>										
GSM900	OFF, DCS1800										
E-GSM	OFF, DCS1800										
DCS1800	OFF, GSM900, E-GSM										
PCS1900	OFF										
BCCH	<p>This is invalid showing “----”.</p>										
PWR CNTL	<p>Specifies one of the factors defined for Power Control Levels according to the Radio Standard. The allowable factor ranges are as follows:</p> <p>GSM900 and E-GSM: 2 (+39 dBm) to 19 (+5 dBm)</p> <p>DCS1800: 29 (+36 dBm) to 31 (+32 dBm), and 0 (+30 dBm) to 15 (+0 dBm)</p> <p>PCS1900: 30 (+33 dBm) to 31 (+32 dBm), and 0 (+30 dBm) to 15 (+0 dBm)</p>										
TCH: ^a	<p>Accepts one traffic channel. The frequency corresponding to the channel accompanies. The allowable range is as follows:</p> <p>GSM900: 1 to 124</p> <p>E-GSM: 0 to 124, and 975 to 1023</p> <p>DCS1800: 512 to 885</p> <p>PCS1900: 512 to 810</p>										

Input Field	Description
DC Power	<p>Selects a supply mode. The choices are On and Off as follows:</p> <ul style="list-style-type: none"> o On: Always supplies dc voltage to the mobile. o Off:^b Disables to supply dc voltage to the mobile. <p>Accepts a dc voltage value ranging from 3.0 to 11.0 V in 0.1 V steps. This value is used among the AUTOMATIC TEST, MANUAL TEST, SPECTRUM MONITOR, and SIGNAL GENERATOR modes in common.</p>
Signal	<p>Selects either CW or Burst of a MS transmission signal.</p> <ul style="list-style-type: none"> o CW: Selects this when a continuous wave is transmitted from the mobile under test. o Burst: Selects this when a bursted signal is transmitted from the mobile.
BS Level	<p>Specifies the RF output level^a of the Test Set, ranging from –110.0 to –50.0 dBm. The default value is set on the Test Condition screen in the CONFIGURATION mode.</p>
Midamble	<p>Selects the Training Sequence Code (TSC) 0 to 7, or None for the amplitude triggering.^c</p>

- a. The variable increment softkey is activated. Refer to "[Variable Increment Softkey](#)" on page 60.
- b. When DC Power is set to Off, DC Current cannot be measured.
- c. When None is selected, Phase Error/Frequency Error cannot be measured.

The following test items are shown in groups in the table. The detailed test screens for the groups are displayed when selected by the CURSOR CONTROL knob.

Test Item	Description
Peak TX Power, Burst Timing, Power Ramp	The Measuring: Peak TX Power/Burst Timing/Power Ramp screen is shown with a result text and graphic display.
Phase Error, Frequency Error	The Measuring: Phase Error/Frequency Error screen is shown with a result text and graphic display.
DC Current	The Measuring: DC Current screen is shown with a result text display without titling Camp On nor Talk.
Spectrum Monitor	The Measuring: Spectrum Monitor screen is shown with a result text and graphic display.

Explanation


The RF ON annunciator at the screen lower right corner is displayed only when the RF signal from the Test Set is present at the RF IN/OUT connector.

The operation message “Press [Start] to begin a test.” is shown. Refer to ["Measuring Screen" on page 107](#).

Measuring Screen

By pressing the Start softkey, the following measuring screen is shown. Only the RF Test step in the test flow is blinking and the cursor is placed on the first test item column. If you select a test item column with the CURSOR CONTROL knob, one of the measuring screens is displayed.

Figure 3-35 Measuring Screen



Softkey Menu

- o Abort: Returns to the asynchronous MANUAL TEST: Stand-by screen.

Explanation

In this mode you cannot change the Radio Standard, Procedure, Multi Band, and DC Power supply mode fields. Other highlighted fields can be modified for a new test.

The operation message “Select an item column with [CURSOR CONTROL] to execute its test.” is shown for making an RF test. Refer to ["Procedure to obtain the Measuring screens"](#) on page 88.

Only DC Current measurement data at RF Test is displayed under the test item table, but other mobile related information is not shown.

Measuring Screen Examples

Measuring: Peak TX Power/Burst Timing/Power Ramp


The actual measurement data are shown in enlarged numerals but the Power Ramp result text is shown when the marker is placed at any point of its measured trace. If the actual data exceeds the limits in the graph, one (or two for two fails) white triangle marker indicates the failed position at the top of the graph frame. Any data indicating a failure is highlighted.

NOTE

The Burst Timing cannot be measured and its value is not displayed with the asynchronous mode.

While making continuous measurements, the Trigger Sing/Cont softkey is blinking as shown in [Figure 3-36](#).

Figure 3-36 Measuring: Peak TX Power/Burst Timing/Power Ramp Screen



Softkey Menu

- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle.
- o Abort: Stops continuous measurements and shows another softkey menu.

If the Abort softkey is pressed, another softkey menu is shown to activate the trigger mode, zooming and marker functions as shown in [Figure 3-37](#).

Figure 3-37

Aborted: Peak TX Power/Burst Timing/Power Ramp Screen





Figure 3-38

Aborted: Peak TX Power/Burst Timing/Power Ramp Zoomed Screen



Softkey Menu 1

- o Start: Begins a new measurement cycle with either single or continuous trigger mode.
- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle and the marker function is available with the Knob MKR/Cursor softkey.
- o Zoom Off/On: Toggles the zooming function between Off and On. If On is selected, the rising edge, from -8 bit to 0 bit, and trailing edge, between bits 147 and 155, of the Power Ramp are expanded to observe the detailed test results as shown in [Figure 3-38](#).
- o More (1 of 3): Displays softkey menu 2.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-35](#).

Softkey Menu 2

- o Knob MKR/Cursor: Toggles the function of the CURSOR CONTROL knob between Cursor and MKR for marker control.
- o Marker Coars/Fine: Toggles the marker control between Coars for coarse and Fine to move the marker with 10 dots (coarse) or 1 dot (fine) resolution. The marker readouts for the amplitude and timeslot (in bits) are available at any point of the measured trace.
- o More (2 of 3): Displays softkey menu 3.
- o Return: Returns to the initial Measuring screen.

Softkey Menu 3

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o More (3 of 3): Returns to softkey menu 1.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-35](#).

NOTE

If the measurement is not triggered, consult the following items:


- * The Power Control Level (PWR CNTL) is properly set.
 - * The Midamble is properly set. If you don't know which Training Sequence Code (TSC) is used, set Midamble to None to use the amplitude trigger mode.
-

Measuring: Phase Error/Frequency Error

The RMS and Peak Phase Errors and Frequency Error are shown, along with the marker readouts if the marker is activated. If the actual data exceeds the limits in the graph, one (or two for two fails) white triangle marker indicates the failed position at the top of the graph frame. Any data indicating a failure is highlighted.

Figure 3-39

Aborted: Phase Error/Frequency Error Screen



Softkey Menu 1

- o Start: Begins a new test.
- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle and the marker function is available with the Knob MKR/Cursor softkey.
- o More (1 of 3): Displays softkey menu 2.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-35](#).

Softkey Menu 2

- o Knob MKR/Cursor: Toggles the function of the CURSOR CONTROL knob between Cursor and MKR for marker control.
- o Marker Coars/Fine: Toggles the marker control between Coars for coarse and Fine to move the marker with 10 dots (coarse) or 1 dot (fine) resolution. The marker readouts for the phase error magnitude and timeslot (in bits) are available at any point of the measured trace.
- o More (2 of 3): Displays softkey menu 3.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-35](#).

Softkey Menu 3

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o More (3 of 3): Returns to softkey menu 1.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-35](#).

NOTE

If the measurement is not triggered, consult the following items.

* The Power Control Level (PWR CNTL) is properly set.

* The Midamble is properly set. If None is selected, the Phase Error/Frequency Error measurement cannot be performed.

Measuring: DC Current


The test data for the DC Current is displayed as shown in [Figure 3-40](#). As this measurement is asynchronously made, the test result does not show Camp On nor Talk.

NOTE

DC current can be measured only when the DC Power field is set to On and power is supplied from the Test Set to the mobile under test.

Figure 3-40

Measuring: DC Current with Asynchronous Mode



Softkey Menu 1

- o Start: Begins a new test.
- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle.
- o More (1 of 2): Displays softkey menu 2.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-35](#).

Softkey Menu 2

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o More (2 of 2): Returns to softkey menu 1.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-35](#).


Measuring: Spectrum Monitor

The RF spectrum from 0 Hz to +400 kHz relative to the traffic channel frequency is shown with the readouts of the frequencies and amplitudes at +200 kHz (M1) and +250 kHz (M2) offsets. The actual measured data at those frequencies are shown in enlarged numerals.

The trigger conditions depend on the Signal field setting in the Stand-by Screen as follows:

- Burst: Amplitude triggering which uses the low-to-high amplitude transitions in pulsed carriers as the trigger source
- CW: Immediate triggering

Figure 3-41 Measuring: Spectrum Monitor Screen




Softkey Menu

- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle.
- o Abort: Stops continuous measurements and shows another softkey menu.

If the Abort softkey is pressed, another softkey menu is shown to activate the trigger mode and marker functions as shown in [Figure 3-42](#).

Figure 3-42

Aborted: Spectrum Monitor Screen



Softkey Menu 1

- o Start: Begins a new test.
- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle and the marker function is available with the Knob MKR/Cursor softkey.
- o More (1 of 3): Displays softkey menu 2.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-35](#).

Softkey Menu 2

- o Knob MKR/Cursor: Toggles the function of the CURSOR CONTROL knob between Cursor and MKR for marker control.
- o Marker Coars/Fine: Toggles the marker control between Coars for coarse and Fine to move the marker with 10 dots (coarse) or 1 dot (fine) resolution. The marker readouts for the frequency and amplitude are available at any point of the measured trace.
- o More (2 of 3): Displays softkey menu 3.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-35](#).

Softkey Menu 3

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o More (3 of 3): Returns to softkey menu 1.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-35](#).

Screen Fields

The following test parameters need to be specified for a new test:

Input Field	Description
Channel ^a	<p>Specifies one traffic channel to be analyzed. The frequency corresponding to the channel accompanies. The allowable range is as follows:</p> <p>GSM900: 1 to 124 E-GSM: 0 to 124, and 975 to 1023 DCS1800: 512 to 885 PCS1900: 512 to 810</p>
PWR CNTL	<p>Specifies one of the factors defined for Power Control Levels according to the Radio Standard. The allowable factor ranges are as follows:</p> <p>GSM900 and E-GSM: 2 (+39 dBm) to 19 (+5 dBm) DCS1800: 29 (+36 dBm) to 31 (+32 dBm), and 0 (+30 dBm) to 15 (+0 dBm) PCS1900: 30 (+33 dBm) to 31 (+32 dBm), and 0 (+30 dBm) to 15 (+0 dBm)</p>
Span	0 to 400 kHz (fixed)
RBW	<p>Selects either 10 kHz or 30 kHz resolution bandwidth as follows:</p> <ul style="list-style-type: none"> o 10: Sets the resolution bandwidth to 10 kHz. o 30: Sets the resolution bandwidth to 30 kHz.
Averaging ^a	Specifies the averaging number of measurements from 2 to 99, unless Off is selected.
DC Power ^a	<p>The supply mode is dependent on the setting in the Stand-by screens.</p> <p>Accepts a dc voltage value ranging from 3.0 to 11.0 V in 0.1 V steps. This value is used among the AUTOMATIC TEST, MANUAL TEST, SPECTRUM MONITOR, and SIGNAL GENERATOR modes in common.</p>
BS Level	Specifies the RF output level ^a of the Test Set, ranging from –110.0 to –50.0 dBm. The default value is set on the Test Condition screen in the CONFIGURATION mode.

a. The variable increment softkey is activated. Refer to "[Variable Increment Softkey](#)" on page 60.

The following display fields show the measurement results:

Display Field	Description
Peak	The absolute peak power and frequency are shown.
Marker ^a	<p>The frequency and amplitude readouts at the marker point are shown when activated by the Knob MKR/Cursor softkey as follows:</p> <ul style="list-style-type: none"> o ----- MHz ---- dBm: The absolute frequency and amplitude of the marker readouts are shown. o (---- kHz ---- dB): The relative frequency and amplitude of the marker readouts are shown.
M1: +200 kHz, M2: +250 kHz	The amplitude data at +200 kHz and +250 kHz offsets are also shown.

- a. The frequency resolution is 1 kHz or 2 kHz due to the measurement period of 1.59 kHz.

MANUAL TEST (GPRS Mode)

NOTE The GPRS mode is only available for Test Sets with Option 040 .

The general packet radio service (GPRS) is a GSM data service which is capable to provide mobile users with higher data transfer rates over the public switched telephone network (PSTN). The system can transfer data in packet over the air interface, and uses existing TCP/IP protocols to mate with the Internet and other data networks. With the GPRS mode in MANUAL TEST, each test item or a group of test items can be measured and analyzed with the test limits specified in the Test Set: Test Condition screen of the CONFIGURATION mode.

In the GPRS mode, like the synchronous mode, tests are made while the Test Set and the mobile phone are networked to communicate with each other. The required connection process is done by pressing the Start softkey.

The combinations of the slot configuration and the order of measurement slot are as follows :

Option	Slot Configuration	Slot Order Measured
040	Downlink 1 × Uplink 1	4 (fourth)
040	Downlink 2 × Uplink 1	4 (fourth)


NOTE When entering numeric values, the variable increment softkey menu is displayed. Refer to [“Variable Increment Softkey”](#) and ["Storing Two Numeric Values"](#) on page 59.

The default state is the last setting stored in the internal memory before power off.

Stand-by Screen

If GPRS is selected in the Mode Sync/Async/GPRS softkey, the following Stand-by screen is displayed. The input fields for Slot Config, Measured Slot, and Sensitivity are additionally available for GPRS measurements. Pressing the Start softkey activates the attaching process to the mobile under test.

Figure 3-43 Stand-by Screen



Softkey Menu

- o Mode Sync/Async/GPRS: Select either Sync for synchronous, Async for asynchronous, or GPRS for general packet radio service mode. This softkey is available only for Test Sets equipped with Option 002 and Option 040.
- o Start: Begins an attaching process through the idle state.
- o Return: Displays the initial screen with function modes.

Screen Fields

The following input fields of test parameters need to be set for a new test:

Input Field	Description										
Procedure	<p>Displays a list of files that are on an SRAM memory card.</p> <p>If an SRAM memory card containing setup files is used, a list of those file names is shown in this field for selection. If there are no files on the card, this field remains blank.</p>										
Radio Standard	<p>Selects either GSM900, E-GSM, DCS1800, or PCS1900.</p>										
Multi Band	<p>Selects another band in addition to one in Radio Standard for testing dual band mobile phones. The allowable combinations of radio standards are as follows:</p> <table border="0" data-bbox="703 761 1286 963"> <tr> <td style="text-align: center;"><u>Radio Standard:</u></td> <td style="text-align: center;"><u>Multi Band:</u></td> </tr> <tr> <td>GSM900</td> <td>OFF, DCS1800</td> </tr> <tr> <td>E-GSM</td> <td>OFF, DCS1800</td> </tr> <tr> <td>DCS1800</td> <td>OFF, GSM900, E-GSM</td> </tr> <tr> <td>PCS1900</td> <td>OFF</td> </tr> </table>	<u>Radio Standard:</u>	<u>Multi Band:</u>	GSM900	OFF, DCS1800	E-GSM	OFF, DCS1800	DCS1800	OFF, GSM900, E-GSM	PCS1900	OFF
<u>Radio Standard:</u>	<u>Multi Band:</u>										
GSM900	OFF, DCS1800										
E-GSM	OFF, DCS1800										
DCS1800	OFF, GSM900, E-GSM										
PCS1900	OFF										
BCCH ^a	<p>Specifies the broadcast control channel. The frequency corresponding to the channel accompanies. The allowable range is as follows:</p> <p>GSM900: 1 to 124 E-GSM: 0 to 124, and 975 to 1023 DCS1800: 512 to 885 PCS1900: 512 to 810</p>										
PWR CNTL	<p>Specifies one of the factors defined for Power Control Levels according to the Radio Standard. The allowable factor ranges are as follows:</p> <p>GSM900 and E-GSM: 2 (+39 dBm) to 19 (+5 dBm) DCS1800: 29 (+36 dBm) to 31 (+32 dBm), and 0 (+30 dBm) to 15 (+0 dBm) PCS1900: 30 (+33 dBm) to 31 (+32 dBm), and 0 (+30 dBm) to 15 (+0 dBm)</p>										
PDTCH ^a	<p>Accepts a value for packet data traffic channel. The frequency corresponding to the channel accompanies. The allowable range is as follows:</p> <p>GSM900: 1 to 124 E-GSM: 0 to 124, and 975 to 1023 DCS1800: 512 to 885 PCS1900: 512 to 810</p>										

Input Field	Description
DC Power	<p>Selects a supply mode. The choices are On and Off as follows:</p> <ul style="list-style-type: none"> o On: Always supplies dc voltage to the mobile. o Off:^b Disables to supply dc voltage to the mobile. <p>Accepts a dc voltage value^a ranging from 3.0 to 11.0 V in 0.1 V steps. This value is used among the AUTOMATIC TEST, MANUAL TEST, SPECTRUM MONITOR, and SIGNAL GENERATOR modes in common.</p>
Signal	For synchronous mode tests, only Burst is valid and cannot be changed.
BS Level	Specifies the RF output level ^a of the Test Set, ranging from –110.0 to –50.0 dBm. The default value is set on the Test Condition screen in the CONFIGURATION mode.
Timing ADV	Accepts a value for the timing advance ^a ranging from 0 to 63 bits.
Slot Config	Selects either 1 (downlink) × 1 (uplink) or 2 × 1 if Option 040 is installed.
Measured Slot	The order of measured slot is defaulted to 4 (fourth) if Option 040 is installed.
Sensitivity	Displays BLER (block error rate) to make a sensitivity measurement.

- a. The variable increment softkey is activated. Refer to "[Variable Increment Softkey](#)" on page 60.
- b. When DC Power is set to Off, DC Current cannot be measured.

The following test items are shown in groups in the table. The detailed test screens for the groups are displayed at the measuring state when selected by the CURSOR CONTROL knob.

Test Item	Description
Peak TX Power, Power vs Time	The Measuring: Peak TX Power/Power vs Time screen is shown with a result text and graphic display. If the marker function is active, the Power Ramp value is displayed according to the marker position.
Phase Error, Frequency Error	The Measuring: Phase Error/Frequency Error screen is shown with a result text and graphic display.
Sensitivity	The Measuring: Sensitivity screen is shown with a result text display for BLER which is fixed in the Sensitivity field.
DC Current	The Measuring: DC Current screen is shown with a result text display without titling Camp On nor Talk, if DC Power is set to On and the dc power is supplied to the mobile under test.
Spectrum Monitor	The Measuring: Spectrum Monitor screen is shown with a result text and graphic display.

The following display fields remain blank at this state on the lower screen:

Item	Description
IMSI:	In the GPRS mode, the International Mobile Subscriber Identity will not be displayed.
IMEI:	In the GPRS mode, the International Mobile Station Equipment Identity will not be displayed.
Power Class:	Displays one of the defined factors. See " Power Classes " on page 184.
DC Current:	Displays the dc current consumed by the mobile at the connection state, if DC Power is set to On and the dc power is supplied to the mobile under test.
ACT Tim ADV:	Displays the number of bits for the actual timing advance data.

The RF ON annunciator at the screen lower right corner is displayed only when the RF signal from the Test Set is present at the RF IN/OUT connector.


The instruction message “Press [Start] to begin a test.” is shown. By pressing the Start softkey, the following idle screen is shown automatically changing from the standby screen.

Idle Screen

In the attaching process after pressing the Start softkey, the following idle screen is displayed for a while prior to changing to the attached screen. The PWR CNTL field is changed from the standby screen for the appropriate measurement.

Figure 3-44

Measuring: Idle Screen



Softkey Menu

- o Abort: Returns to the initial state and displays the idle screen.


The following display fields show the data from the mobile under test:

Item	Description
IMSI:	In the GPRS mode, the International Mobile Subscriber Identity will not be displayed.
IMEI:	In the GPRS mode, the International Mobile Station Equipment Identity will not be displayed.
Power Class:	Displays one of the defined factors. See "Power Classes" on page 184.

Attached Screen

Upon completion of the attaching process, the following measuring screen is shown. The Attached step in the test flow is blinking and the cursor is placed on the first test item column.

Figure 3-45 Measuring: Attached Screen



Softkey Menu

- o End: Returns to the MANUAL TEST: Stand-by screen.
- o Abort: Returns to the MANUAL TEST: Stand-by screen.

NOTE

As the connection state becomes on to begin measurements for a short period immediately when one of the test items is selected, the Connect step stays unchanged but the Attached step is blinking.

Explanation

In this mode, you cannot change the input fields of the Radio Standard, Procedure, Multi Band, and DC Power supply mode. If the DC Power mode is set to On in the Stand-by screen, the dc voltage field can be modified and DC Current in the test item table is also highlighted to make measurements. Other highlighted fields can be modified for a new test.

The operation message “Select an item column with [CURSOR CONTROL] to execute its test.” is shown for making an RF test. Refer to ["Procedure to obtain the Measuring screens" on page 125](#).

The following display fields show the measurement data at this state on the lower screen:

Display Field	Description
DC Current:	Displays the dc current consumed by the mobile at the attachment state when the dc voltage is supplied to the mobile using Universal DC Power Adapter.
ACT Tim ADV:	Displays the number of bits for the actual timing advance data.

Procedure to obtain the Measuring screens

- Step 1.** Place the blinking cursor at one of the test items by rotating the CURSOR CONTROL knob.
- Step 2.** Choose that test item by pressing the CURSOR CONTROL knob.
- Step 3.** Either the result text or the text with a graph is shown depending on the Test Item chosen.

Measuring Screen Examples


Measuring: Peak TX Power/Power vs Time

The actual measurement data are shown in enlarged numerals but the Power Ramp result text is shown when the marker is placed at any point of its measured trace. If the actual data exceeds the limits in the graph, one (or two for two fails) white triangle marker indicates the failed position at the top of the graph frame. Any data indicating a failure is highlighted.

While making continuous measurements, the Trigger Sing/Cont softkey is blinking as shown in Figure 3-46.

Figure 3-46

Measuring: Peak TX Power/Power vs Time



Softkey Menu

- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle.
- o Abort: Stops continuous measurements and shows another softkey menu.

If the Abort softkey is pressed, another softkey menu is shown to activate the trigger mode, zooming and marker functions as shown in Figure 3-47 and Figure 3-48.

Figure 3-47 Aborted: Peak TX Power/Power vs Time Screen





Figure 3-48 Aborted: Peak TX Power/Power vs Time Zoomed Screen



Softkey Menu 1

- o Start: Begins a new measurement cycle with either single or continuous trigger mode.
- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle and the marker function is available with the Knob MKR/Cursor softkey.
- o Zoom Off/On: Toggles the zooming function between Off and On. If On is selected, the rising edge, from -8 bit to 0 bit, and trailing edge, between bits 147 and 155, of the Power Ramp waveforms are expanded to observe the detailed results as shown in Figure 3-48.
- o More (1 of 3): Displays softkey menu 2.
- o Return: Returns to the initial Measuring screen as shown in Figure 3-45.

Softkey Menu 2

- o Knob MKR/Cursor: Toggles the knob function of CURSOR CONTROL between Cursor and MKR for marker control.

- o Marker Coars/Fine: Toggles the marker control between Coars for coarse and Fine to move the marker with 10 dots (coarse) or 1 dot (fine) resolution. The marker readouts for the amplitude and timeslot (in bits) are available at any point of the measured trace.
- o More (2 of 3): Displays softkey menu 3.
- o Return: Returns to the initial Measuring screen.

Softkey Menu 3


- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o More (3 of 3): Returns to softkey menu 1.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-45](#).

Measuring: Phase Error/Frequency Error

The RMS and Peak Phase Errors and Frequency Error are shown, along with the marker readouts if the marker is activated. If the actual data exceeds the limits in the graph, one (or two for two fails) white triangle marker indicates the failed position at the top of the graph frame. Any data indicating a failure is highlighted.

Figure 3-49

Aborted: Phase Error/Frequency Error Screen



Softkey Menu 1

- o Start: Begins a new test.
- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle and the marker function is available with the Knob MKR/Cursor softkey.
- o More (1 of 3): Displays softkey menu 2.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-45](#).

Softkey Menu 2

- o Knob MKR/Cursor: Toggles the function of the CURSOR CONTROL knob between Cursor and MKR for marker control.
- o Marker Coars/Fine: Toggles the marker control between Coars for coarse and Fine to move the marker with 10 dots (coarse) or 1 dot (fine) resolution. The marker readouts for the phase error magnitude and timeslot (in bits) are available at any point of the measured trace.
- o More (2 of 3): Displays softkey menu 3.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-35](#).

Softkey Menu 3

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o More (3 of 3): Returns to softkey menu 1.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-45](#).

Measuring: Sensitivity in BLER

The test data for BLER (block error rate) is displayed as shown in [Figure 3-50](#) or [Figure 3-51](#).

Figure 3-50 Measuring: Sensitivity in BLER Screen





Figure 3-51 Aborted: Sensitivity in BLER Screen



Softkey Menu

- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle.
- o Abort: Returns to the initial Measuring screen as shown in [Figure 3-51](#).

Softkey Menu 2

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o More (2 of 2): Returns to softkey menu 1.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-45](#).

Measuring: DC Current


The test data for the DC Current is displayed as shown in [Figure 3-52](#). As this measurement is made at the attached state, the test result does not show any title but it is equivalent for the connect state.

NOTE

DC current can be measured only when the DC Power field is set to On and power is supplied from the Test Set to the mobile under test.

Figure 3-52

Measuring: DC Current



Softkey Menu 1

- o Start: Begins a new test.
- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle.
- o More (1 of 2): Displays softkey menu 2.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-45](#).

Softkey Menu 2

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o More (2 of 2): Returns to softkey menu 1.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-45](#).


Measuring: Spectrum Monitor

The RF spectrum from 0 Hz to +400 kHz relative to the traffic channel frequency is shown with the readouts of the frequencies and amplitudes at +200 kHz (M1) and +250 kHz (M2) offsets. The actual measured data at those frequencies are shown in enlarged numerals.

The trigger conditions depend on the Signal field setting in the Stand-by Screen as follows:

- Burst: Amplitude triggering which uses the low-to-high amplitude transitions in pulsed carriers as the trigger source
- CW: Immediate triggering

Figure 3-53 Measuring: Spectrum Monitor Screen




Softkey Menu

- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle.
- o Abort: Stops continuous measurements and shows another softkey menu.

If the Abort softkey is pressed, another softkey menu is shown to activate the trigger mode and marker functions as shown in [Figure 3-54](#).

Figure 3-54

Aborted: Spectrum Monitor Screen



Softkey Menu 1

- o Start: Begins a new test.
- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle and the marker function is available with the Knob MKR/Cursor softkey.
- o More (1 of 3): Displays softkey menu 2.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-45](#).

Softkey Menu 2

- o Knob MKR/Cursor: Toggles the function of the CURSOR CONTROL knob between Cursor and MKR for marker control.
- o Marker Coars/Fine: Toggles the marker control between Coars for coarse and Fine to move the marker with 10 dots (coarse) or 1 dot (fine) resolution. The marker readouts for the frequency and amplitude are available at any point of the measured trace.
- o More (2 of 3): Displays softkey menu 3.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-45](#).

Softkey Menu 3

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o More (3 of 3): Returns to softkey menu 1.
- o Return: Returns to the initial Measuring screen as shown in [Figure 3-45](#).

Screen Fields

The following input fields of the parameters need to be specified for a new spectrum test:

Input Field	Description
Channel ^a	<p>Specifies one traffic channel to be analyzed. The frequency corresponding to the channel accompanies. The allowable range is as follows:</p> <p>GSM900: 1 to 124 E-GSM: 0 to 124, and 975 to 1023 DCS1800: 512 to 885 PCS1900: 512 to 810</p>
PWR CNTL	<p>Specifies one of the factors defined for Power Control Levels according to the Radio Standard. The allowable factor ranges are as follows:</p> <p>GSM900 and E-GSM: 2 (+39 dBm) to 19 (+5 dBm) DCS1800: 29 (+36 dBm) to 31 (+32 dBm), and 0 (+30 dBm) to 15 (+0 dBm) PCS1900: 30 (+33 dBm) to 31 (+32 dBm), and 0 (+30 dBm) to 15 (+0 dBm)</p>
Span	0 to 400 kHz (fixed)
RBW	<p>Selects either 10 kHz or 30 kHz resolution bandwidth as follows:</p> <ul style="list-style-type: none"> o 10: Sets the resolution bandwidth to 10 kHz. o 30: Sets the resolution bandwidth to 30 kHz.
Averaging ^a	Specifies the averaging number of measurements from 2 to 99, unless Off is selected.
DC Power ^a	<p>The supply mode is dependent on the setting in the Stand-by screens.</p> <p>Accepts a dc voltage value ranging from 3.0 to 11.0 V in 0.1 V steps. This value is used among the AUTOMATIC TEST, MANUAL TEST, SPECTRUM MONITOR, and SIGNAL GENERATOR modes in common.</p>
BS Level ^a	Specifies the RF output level of the Test Set, ranging from -110.0 to -50.0 dBm. The default value is set on the Test Condition screen in the CONFIGURATION mode.

a. The variable increment softkey is activated. Refer to "[Variable Increment Softkey](#)" on page 60.

The following display fields show the measurement results:

Display Field	Description
Peak	The absolute peak power and frequency are shown.
Marker ^a	<p>The frequency and amplitude readouts at the marker point are shown when activated by the Knob MKR/Cursor softkey as follows:</p> <ul style="list-style-type: none"> o ----- MHz ---- dBm: The absolute frequency and amplitude of the marker readouts are shown. o (---- kHz ---- dB): The relative frequency and amplitude of the marker readouts are shown.
M1: +200 kHz, M2: +250 kHz	The amplitude data at +200 kHz and +250 kHz offsets are also shown.

- a. The frequency resolution is 1 kHz or 2 kHz due to the measurement period of 1.59 kHz.

SPECTRUM MONITOR

This function mode is specialized for testing mobile phones, therefore the settings for spectrum analysis are very much dedicated to make quick measurements.

To test mobile phones using the Spectrum Monitor, set the mobile phone to transmit RF power independently (without sending a special command from the Test Set to the mobile phone, for instance).

NOTE


This section is applicable only for Test Sets with Option 002.

When entering numeric values, the variable increment softkey menu is displayed. Refer to “[Variable Increment Softkey](#)” and “[Storing Two Numeric Values](#)” on page 59.

Initial Screen

If the SPECTRUM MONITOR softkey is pressed, the spectrum screen is shown with the frequency span in either 0 to 400 kHz or ± 100 kHz, along with the test conditions and result text.

Figure 3-55 Initial Screen of Spectrum Monitor



Softkey Menu 1

- o Start: Begins a new test.
- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle and the marker function is available with the Knob MKR/Cursor softkey.
- o More (1 of 3): Displays softkey menu 2.
- o Return: Displays the initial screen with function modes.

Softkey Menu 2

- o Knob MKR/Cursor: Toggles the function of the CURSOR CONTROL knob between Cursor and MKR for marker control.
- o Marker Coars/Fine: Toggles the marker control between Coars for coarse and Fine to move the marker with 10 dots (coarse) or 1 dot (fine) resolution. The marker readouts for the frequency and amplitude are available at any point of the measured trace.
- o More (2 of 3): Displays softkey menu 3.
- o Return: Displays the initial screen with function modes.

Softkey Menu 3

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o More (3 of 3): Returns to softkey menu 1.
- o Return: Displays the initial screen with function modes.

Explanation

When the Start softkey is pressed, the Test Set tries to synchronize with the bursted signal by amplitude triggering which uses the rising (low-to-high) amplitude transition in pulsed carriers as the trigger source. If this synchronization fails, for example when the signal is a continuous wave, the Test Set is triggered immediately.

NOTE

When you are measuring a bursted signal with the continuous trigger mode and the waveform disappears suddenly, the Test Set may lose synchronization with the burst signal. If this happens, press the Abort softkey, and then the Start softkey to restart the measurement. This resynchronizes the measurement because the Test Set determines the measurement timing for the burst signal when the Start softkey is pressed and repeats the measurements with every 8-slot timing.

Screen Fields

The following input fields of the test parameters need to be specified for a new test:

Input Field	Description
Radio Standard	Select either GSM900, E-GSM, DCS1800, or PCS1900. If Radio Standard is changed, Channel is also automatically changed accordingly.
Channel ^a	Specifies one traffic channel to be analyzed. The frequency corresponding to the channel accompanies. The allowable range is as follows: GSM900: 1 to 124 E-GSM: 0 to 124, and 975 to 1023 DCS1800: 512 to 885 PCS1900: 512 to 810
Measurement Range	Specifies one measurement range as follows. +39dBm: The maximum input level is +39 dBm. +29dBm: The maximum input level is +29 dBm. +19dBm: The maximum input level is +19 dBm. +9dBm: The maximum input level is +9 dBm. -3dBm: The maximum input level is -3 dBm.
Span	Selects either 0 to 400 kHz or ± 100 kHz as follows: <ul style="list-style-type: none"> o 0-400: Sets the span to 0 to 400 kHz relative to the channel frequency. o ± 100: Sets the span to ± 100 kHz centered at the channel frequency.
RBW	Selects either 10 kHz or 30 kHz resolution bandwidth as follows: <ul style="list-style-type: none"> o 10: Sets the resolution bandwidth to 10 kHz. o 30: Sets the resolution bandwidth to 30 kHz.
Averaging ^a	Specifies the averaging number of measurements from 2 to 99, unless Off is selected.
DC Power ^a	Selects a supply mode. The choices are On and Off as follows: <ul style="list-style-type: none"> o On: Always supplies dc voltage to the mobile. o Off: Disables to supply dc voltage to the mobile. Accepts a dc voltage value ranging from 3.0 to 11.0 V in 0.1 V steps. This value is used among the AUTOMATIC TEST, MANUAL TEST, SPECTRUM MONITOR, and SIGNAL GENERATOR modes in common.

- a. The variable increment softkey is activated. Refer to "Variable Increment Softkey" on page 60.

The following display fields show the measurement results:

Display Field	Description
Peak	The absolute peak power and frequency are shown.
Marker ^a	The frequency and amplitude readouts at the marker position are shown when activated by the Knob <u>MKR</u> /Cursor softkey as follows: <ul style="list-style-type: none"> o ----- MHz ---- dBm: The absolute frequency and amplitude of the marker readouts are shown. o (---- kHz ---- dB): The relative frequency and amplitude of the marker readouts are shown.
0-400 kHz span: M1: +200 kHz, M2: +250 kHz	The amplitude data at +200 kHz and +250 kHz offsets are also shown in the left lower screen corner.
±100 kHz span: M1: -67.7 kHz, M2: ±0 kHz, M3: +67.7 kHz	Three peak amplitudes at around the offsets M1, M2, and M3 from the center frequency are measured and shown with those corresponding frequencies ^b in the left lower screen corner.

- a. The frequency resolution is 1 kHz or 2 kHz due to the measurement resolution of 1.59 kHz.
- b. The frequency resolution is 1 kHz due to the measurement resolution of 0.79 kHz. This will cause to have two amplitude readouts at the same frequency.

Measuring Screens

If the Start softkey is pressed in the initial screen, the following Measuring screen with either 0 to 400 kHz or ± 100 kHz span is displayed with the continuous trigger mode.

Figure 3-56 Measuring: Span 0 to 400 kHz Screen





Figure 3-57 Measuring: Span ± 100 kHz Screen



Softkey Menu

- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle.
- o Abort: Stops continuous measurements and shows another softkey menu.

If the Abort softkey is pressed in the measuring screen, the following aborted screen is displayed with either 0 to 400 kHz (Figure 3-56) or ± 100 kHz (Figure 3-57) span.

Figure 3-58 Aborted: Span 0 to 400 kHz Spectrum Screen





Figure 3-59 Aborted: Span ± 100 kHz Spectrum Screen



Softkey Menu 1

- o Start: Begins a new test.
- o Trigger Sing/Cont: Toggles the trigger mode between Sing for single and Cont for continuous modes. In the continuous mode, this softkey is highlighted blinking until the Abort softkey is pressed. In the single mode, this softkey is highlighted for one measurement cycle and the marker function is available with the Knob MKR/Cursor softkey.
- o More (1 of 3): Displays softkey menu 2.
- o Return: Displays the initial screen with function modes.

Softkey Menu 2

- o Knob MKR/Cursor: Toggles the function of the CURSOR CONTROL knob between Cursor and MKR for marker control.

- o Marker Coars/Fine: Toggles the marker control between Coars for coarse and Fine to move the marker with 10 dots (coarse) or 1 dot (fine) resolution. The marker readouts for the frequency and amplitude are available at any point of the measured trace.
- o More (2 of 3): Displays softkey menu 3.
- o Return: Displays the initial screen with function modes.

Softkey Menu 3

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o More (3 of 3): Returns to softkey menu 1.
- o Return: Displays the initial screen with function modes.

SIGNAL GENERATOR

The Test Set is capable to generate RF signal dedicated to the radio standards GSM900, E-GSM, DCS1800, and PCS1900.


NOTE This section is applicable only for Test Sets with Option 002.

NOTE When entering numeric values, the variable increment softkey menu is displayed. Refer to “[Variable Increment Softkey](#)” and “[Storing Two Numeric Values](#)” on page 59.

SIGNAL GENERATOR Screen

When the SIGNAL GENERATOR softkey is pressed, the following screen is displayed to set the parameters required to generate a type of signal:

Figure 3-60 SIGNAL GENERATOR Screen



Softkey Menu

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o Return: Displays the initial screen with function modes.

Screen Fields

The following input fields of the test parameters need to be set to generate RF signal from the Test Set. The parameters can be set using the CURSOR CONTROL knob as explained in "[Front Panel Overview](#)" on page 52.

Input Field	Description
Radio Standard	<p>Selects either GSM900, E-GSM, DCS1800, or PCS1900.</p> <p>If Radio Standard is changed, Channel is also automatically changed accordingly.</p>
Channel ^a	<p>Specifies the transmitting traffic channel. The frequency corresponding to the channel accompanies. The allowable range is as follows:</p> <p style="padding-left: 40px;">GSM900: 1 to 124</p> <p style="padding-left: 40px;">E-GSM: 0 to 124, and 975 to 1023</p> <p style="padding-left: 40px;">DCS1800: 512 to 885</p> <p style="padding-left: 40px;">PCS1900: 512 to 810</p>
Level ^a	<p>Sets the RF output level. The allowable range is from –110.0 to –50.0 dBm in 0.5 dB steps.</p>
RF Output	<p>Toggles the RF power output between On and Off. When Off is selected, the RF output level from the RF IN/OUT connector is below –110 dBm.</p>
Modulation	<p>Selects one of the following modulation modes:</p> <ul style="list-style-type: none"> o Off: Outputs carrier wave without modulation. o PN9: Outputs RF signal modulated with a 9-step Pseudo-random binary sequence noise. o All 0: Outputs RF signal modulated with all-zero data.
DC Power ^a	<p>Selects a supply mode. The choices are On and Off as follows:</p> <ul style="list-style-type: none"> o On: Always supplies dc voltage to the mobile. o Off: Disables the dc voltage supply to the mobile. <p>Accepts a dc voltage value ranging from 3.0 to 11.0 V in 0.1 V steps. This value is used among the AUTOMATIC TEST, MANUAL TEST, SPECTRUM MONITOR, and SIGNAL GENERATOR modes in common.</p>

a. The variable increment softkey is activated. Refer to "[Variable Increment Softkey](#)" on page 60.

CONFIGURATION

In this mode there are three major functions of CONFIGURATION, File Management, and Test Setup: Test Sequence/Test Condition.

NOTE


When entering numeric values, the variable increment softkey menu is displayed. Refer to [“Variable Increment Softkey”](#) and [“Storing Two Numeric Values”](#) on page 59.

CONFIGURATION Screen

When the CONFIGURATION softkey is pressed, the following screen is displayed:

Figure 3-61

CONFIGURATION Screen



Softkey Menu

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o Print All: Allows you to print a hardcopy set of the whole contents for the CONFIGURATION, Test Sequence, and Test Condition screens for all radio standards.
- o File Management: Goes to the File Management screen. Refer to ["File Management" on page 160](#).
- o Test Setup: Reveals the Test Setup: Test Condition or Test Sequence screen. Refer to ["Test Setup: Test Condition Screen" on page 148](#) and ["Test Setup: Test Sequence Screen" on page 153](#).
- o Return: Displays the initial screen with function modes.

Screen Fields

The following input fields of the parameters need to be configured. The parameters are set using the CURSOR CONTROL knob as explained in "[Front Panel Overview](#)" on page 52.

Input Field	Description
Serial Port	<ul style="list-style-type: none"> o Baud Rate: Fixed to 9600 bit per second. o Data Length: Selects either 7 or 8 bits. o Stop Bits: Specifies to either 1, 1.5, or 2 bits. o Parity: Selects either None, Odd, or Even. o Xcontrol: Selects either None or Xon/Xoff. o Terminator: Selects either CR, LF, or CR+LF.
Printer	Toggles between HP PCL and ESC/P.
Beeper	Toggles between On and OFF. If On is selected, there is a beep for each step of operation. If Off is selected, beeps are suppressed except for noticing some errors and warnings.
Panel Key	Toggles between Lock and Unlock. If Lock is selected, the system settings are protected from any attempt to use the front-panel settings. The initial screen softkey menu includes only AUTOMATIC TEST and CONFIGURATION. The test parameters excluding Procedure are not allowed to change.
13 MHz Reference	Selects either INT (internal) or EXT (external). If EXT is selected, the 13 MHz reference signal must be supplied to the 13 MHz Reference connector on the rear panel.
Option	Displays the options installed.
Attenuation ^a	<p>Toggles the attenuation function between On and Off.</p> <p>Specifies the insertion losses caused by the coupler or cable you are using to connect the RF signals from/to the mobile with individual radio standards, respectively. Depending on transmitter testing and receiver testing it is required to set loss values in the RF In and RF Out fields as follows:</p> <ul style="list-style-type: none"> o RF In: Accepts the attenuations for transmitter testing. The allowable range is from 0.0 to 99.9 dB in 0.1 dB steps. o RF Out: Accepts the attenuations for receiver testing. The allowable range is from 0.0 to 99.5 dB in 0.5 dB steps.

Input Field	Description
Network Config	<p>Specifies the network parameters. Setting these parameter is required when you test a phone using a user SIM instead of a test SIM or when you want to test network capabilities.</p> <ul style="list-style-type: none"> o MCC: Accepts an entry for Mobile Country Code. The allowable range is from 0 to 999. o MNC: Accepts an entry for Mobile Network Code. The allowable range is from 0 to 99. o NCC: Accepts an entry for Network Color Code. The allowable range is from 0 to 7. o LAC: Accepts an entry for Location Area Code. The allowable range is from 0 to 65535. o BS_PA: Accepts an entry for the number of multiframes between two transmissions of the same paging message (BS_PA_MFRMS). The allowable range is from 2 to 9.
Date/Time ^a	<p>Specifies the current date and time with the following formats:</p> <ul style="list-style-type: none"> o YYYY: Accepts an entry for the year. The allowable range is from 1990 to 2089. o MM: Accepts an entry for the month. The allowable range is from 01 to 12. o DD: Accepts an entry for the date. The allowable range is from 01 to 31. o HH: Accepts an entry for the hour. The allowable range is from 00 to 23. o MM: Accepts an entry for the minute. The allowable range is from 00 to 59.
Firmware	Shows the current firmware revision name stored in the Test Set.
Update	Toggles between On (enable to update) and Off (disable to update). If On is selected, refer to "How to Update the Firmware" on page 165 .
New Firmware	When the Update: field is set to On, shows the new firmware revision name stored in the firmware update card.

a. The variable increment softkey is activated. Refer to ["Variable Increment Softkey" on page 60](#).

Test Setup: Test Condition Screen

If the Test Setup softkey in the CONFIGURATION screen is pressed, the Test Setup: Test Condition screen is displayed as follows:

Figure 3-62 Test Setup: Test Condition Screen

The screenshot shows the 'Test Setup : Test Condition' screen with a timestamp of 2001/09/23 12:34. The screen is divided into several sections:

- Radio Standard:** GSM900
- MS Power Class:** 4
- PWR CNTL:** High: 8: +27dBm, Mid: 13: +17dBm, Low: 18: +7dBm, MANUAL TEST: 13: +17dBm
- Averaging:** Off
- RF Output:** Auto
- BS Level:** -85.0dBm
- BER BS Level:** -104.0dBm
- BER Frames:** 13000 (1014000Bits)
- Loopback Delay:** Short

On the right side, there is a table of test items with their respective limits and units:

Test Item	LO Limit	HI Limit	Unit
Peak TX PWR			
PWR CNTL	12	-3.0	+3.0 dB
Burst Timing		-1.0	+1.0 Bits
Power Ramp		Template	Template
Phase Error			
RMS			5.0 deg
Peak			10.0 deg
Freq. Error		-300	+300 Hz
BER			2.44 %
FER			0.12 %
BLER			0.12 %
RX Quality	5		6
RX Level	1		2
DC Current			
Camp On		50	200 mA
Talk		250	700 mA

Softkey menu options on the right: Print, Print All, File Management, Test Sequence, Return.

Softkey Menu

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o Print All: Allows you to print a hardcopy set of the whole contents for the CONFIGURATION, Test Sequence, and Test Condition screens for all radio standards.
- o File Management: Allows you to go to the File Management screen to store a new test setup file into an SRAM memory card, or to load a test setup file from an SRAM memory card. Refer to "File Management" on page 160.
- o Test Sequence: This softkey toggles the screens between Test Sequence and Test Condition.
- o Return: Displays the CONFIGURATION screen and then the initial screen with function modes.

NOTE

For the GPRS mode with MANUAL TEST, the test limits for BER, FER, RX Quality, and RX Level will not be effective.

Screen Fields

The following input fields of the parameters need to be defined with the proper values for testing the mobile with AUTOMATIC TEST and MANUAL TEST. The parameters are set using the CURSOR CONTROL knob as explained in "Front Panel Overview" on page 52.

Input Field	Description
Radio Standard	Selects either GSM900, E-GSM, DCS1800, or PCS1900.
MS Power Class	Specifies one of the defined factors. The allowable factor ranges are as follows: GSM900 and E-GSM: 2 (+39 dBm) to 5 (+29 dBm) DCS1800: 1 (+30 dBm), 2 (+24 dBm), 3 (+36 dBm) PCS1900: 1 (+30 dBm), 2 (+24 dBm), 3 (+33 dBm)
PWR CNTL (High ^a , Mid, Low, MANUAL TEST)	For the AUTOMATIC TEST mode, specifies three defined factors for the High, Mid and Low levels according to the radio standard. For the MANUAL TEST mode, specifies one defined factor. The allowable factor ranges accompanied by the absolute power levels are as follows: GSM900 and E-GSM: 2 (+39 dBm) to 19 (+5 dBm) DCS1800: 0 (+30 dBm) to 15 (+0 dBm), or 29 (+36 dBm) to 31 (+32 dBm) PCS1900: 0 (+30 dBm) to 15 (+0 dBm), or 29 (+36 dBm) to 31 (+32 dBm) The maximum value is limited by the MS Power Class setting.
Averaging ^b	Specifies the averaging number of measurements from 2 to 99 for measuring Peak TX Power, Phase Error and Frequency Error, unless Off is selected.
RF Output	Selects a signal supply mode as follows: o Auto: Supplies the RF signal to the mobile only during a test cycle. o On: Always supplies the RF signal to the mobile.
BS Level ^b	Specifies the RF output level of the Test Set <i>except for</i> the Sensitivity test of which level is defined in the BER BS Level field. The allowable range is from -110.0 to -50.0 dBm in 0.5 dB steps.

Input Field	Description
BER BS Level ^b	Specifies the RF output level of the Test Set for the Sensitivity test. The allowable range is from –110.0 to –50.0 dBm in 0.5 dB steps.
BER Frames ^b	Specifies the number of test frames. The allowable range is from 1 to 13000. The number of test bits, derived from the equation “Test Frames multiplied by 78 bits”, is shown in the parentheses.
Loopback Delay	Selects a delay time from Short, Mid, or Long.

- a. In the AUTOMATIC TEST mode, the High value is used for the Burst Timing, Power Ramp, Phase Error, and Frequency Error tests.
- b. The variable increment softkey is activated. Refer to "[Variable Increment Softkey](#)" on page 60.

Setting Test Limits on Test Items

The LO Limit and HI Limit values for the test items in the table need to be set to execute Pass/Fail tests with AUTOMATIC TEST and MANUAL TEST. All test items can be specified with limits to make tests in the Test Setup: Test Sequence screen (even if some test items are skipped).

The variable increment softkey is activated to enter each limit. Refer to "[Variable Increment Softkey](#)" on page 60.


Test Item	Description
Peak TX Power	<p>Accepts a set of high and low test limits.</p> <p>The nominal limits are specified in the radio standard in conjunction with the power control level (PWR CNTL).</p> <p>You are allowed to modify the nominal limits by entering temporary limits ranging from -99.9 to +99.9 dB in 0.1 dB steps. However, once power control level is changed after this modification, the nominal limits are automatically applied also.</p>
Burst Timing	Accepts a set of high and low test limits. The allowable range is from -9.9 to +9.9 bits in 0.1 bit steps.
Power Ramp	The test limits are specified by the radio standard selected.
Phase Error	Accepts a set of high test limits for the rms and peak errors over the active part of the timeslots between 0 and 147 bits. The allowable range is from 0.0 to 99.9° in 0.1° steps.
Frequency Error	Accepts a set of high and low limits over the active part of the timeslots. The allowable range is from -999 to +999 Hz in 1 Hz steps.
BER	Accepts a high limit for the bit error rate. The allowable range is from 0.00 to 99.99% in 0.01% steps.
FER	Accepts a high limit for the frame erasure rate. The allowable range is from 0.00 to 99.99% in 0.01% steps. This is not effective for the Test Set installed with Option 040.
BLER	Accepts a high limit for the block error rate. The allowable range is from 0.00 to 99.99% in 0.01% steps. This is effective for the Test Set installed with Option 040.

Test Item	Description
RX Quality	Accepts a set of high and low limits. The allowable choices are 0 (<0.2%), 1 (0.2 to 0.4%), 2 (0.4 to 0.8%),, 6 (6.4 to 12.8%), and 7 (>12.8%). This is not effective for the Test Set installed with Option 040.
RX Level	Accepts a set of high and low limits. The allowable choices are 0 (<-110 dBm), 1 (-110 to -109 dBm), 2 (-109 to -108 dBm),, 62 (-49 to -48 dBm) and 63 (>-48 dBm). This is not effective for the Test Set installed with Option 040.
DC Current	Accepts a set of high and low limits at Camp On and Talk. The allowable range is from 3 to 1000 mA in 1 mA steps.

Test Setup: Test Sequence Screen

If the Test Sequence softkey in the Test Setup: Test Condition screen is pressed, the Test Setup: Test Sequence screen is displayed as follows. This screen allows you to make a test sequence for executing AUTOMATIC TEST.

Figure 3-63 Test Setup: Test Sequence Screen



Softkey Menu

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o Print All: Allows you to print a hardcopy set of the whole contents for the CONFIGURATION, Test Sequence, and Test Condition screens for all radio standards.
- o File Management: Allows you to go to the File Management screen to store a new test setup file into an SRAM memory card, or to load a test setup file from an SRAM memory card. Refer to "File Management" on page 160.
- o Test Condition: This softkey toggles the screens between Test Condition and Test Sequence.
- o Return: Displays the CONFIGURATION screen and then the initial screen with function modes.

Automatic Test Flow

For creating a test flow to execute AUTOMATIC TEST, refer to [Table 3-1](#).

Select either MS or BS in the second step of the sequence, then the fifth, sixth and seventh steps are automatically set accordingly.

Select Run to include a sequence in a test flow, or select --- (skip) to exclude that sequence from a test flow.

Table 3-1 **Setting an Automatic Test Flow**

Step	Sequence	Action	Test	Action
1	LOC. Update:		Run ---	<Select either Run or --->
2	MS BS Call:	<Select either MS or BS>	Run	
3	Talk:		Run ---	<Select either Run or --->
4	RF Test:		Run	
5	MS BS Release:	<Determined by Step 2>	Run	
6	BS MS Call:	<Determined by Step 2>	Run ---	<Select either Run or --->
7	BS MS Release:	<Determined by Step 2>	Run ---	<Determined by Step 6>

Place the cursor in front of the input field of a sequence and press the CURSOR CONTROL knob one time to activate this input field. Select either MS or BS, for example, by rotating the CURSOR CONTROL knob, and set it by pressing the knob.

Screen Fields

The following input fields of the parameters need to be set for a new test sequence for executing AUTOMATIC TEST.

Input Field	Description										
Radio Standard	Selects either GSM900, E-GSM, DCS1800, or PCS1900.										
Multi Band	<p>Selects another band in addition to one in Radio Standard for testing dual band mobile phones. The allowable combinations of radio standards are as follows:</p> <table border="0" data-bbox="730 634 1315 836"> <tr> <td style="padding-right: 20px;">Radio Standard:</td> <td>Multi Band:</td> </tr> <tr> <td>GSM900</td> <td>OFF, DCS1800</td> </tr> <tr> <td>E-GSM</td> <td>OFF, DCS1800</td> </tr> <tr> <td>DCS1800</td> <td>OFF, GSM900, E-GSM</td> </tr> <tr> <td>PCS1900</td> <td>OFF</td> </tr> </table>	Radio Standard:	Multi Band:	GSM900	OFF, DCS1800	E-GSM	OFF, DCS1800	DCS1800	OFF, GSM900, E-GSM	PCS1900	OFF
Radio Standard:	Multi Band:										
GSM900	OFF, DCS1800										
E-GSM	OFF, DCS1800										
DCS1800	OFF, GSM900, E-GSM										
PCS1900	OFF										
BCCH ^a	<p>Specifies the broadcast control channel. The frequency corresponding to the channel accompanies. The allowable range is as follows:</p> <p>GSM900: 1 to 124 E-GSM: 0 to 124, and 975 to 1023 DCS1800: 512 to 885 PCS1900: 512 to 810</p>										
DC Power	<p>Selects a supply mode. The choices are Auto, On, and Off as follows:</p> <ul style="list-style-type: none"> o Auto: Supplies dc voltage to the mobile only during a test cycle. o On: Always supplies dc voltage to the mobile. o Off^b: Disables to supply dc voltage to the mobile. If Off is selected, the Variable field is automatically set to TCH. <p>Accepts a dc voltage value ranging from 3.0 to 11.0 V in 0.1 V steps. This value is used among the AUTOMATIC TEST, MANUAL TEST, SPECTRUM MONITOR, and SIGNAL GENERATOR modes in common.</p>										

Input Field	Description
TCH (Talk) ^a	<p>Specifies one traffic channel depending on the parameter selection in the Variable field.</p> <p>If TCH is selected in the Variable field, this specifies one traffic channel to make Talk tests in addition to six traffic channels for RF tests.</p> <p>If DC Power is selected in the Variable field, this specifies one traffic channel to make both Talk tests and RF tests.</p> <p>The frequency corresponding to the channel accompanies. The allowable range is as follows:</p> <p style="padding-left: 40px;">GSM900: 1 to 124 E-GSM: 0 to 124, and 975 to 1023 DCS1800: 512 to 885 PCS1900: 512 to 810</p>
Variable	<p>Specifies to either TCH or DC Power as follows to make up to six measurements:</p> <ul style="list-style-type: none"> o TCH: Enables to make six measurements on six traffic channels specified in the TCH input fields of the Test Item table, with or without one fixed dc voltage. o DC Power: Enables to make six measurements on one traffic channel with six dc voltages specified in the DCP input fields of the Test Item table.
TCH or DCP	<p>According to the selection of Variable field, either of the following parameters need to be specified for a new test:</p> <ul style="list-style-type: none"> o TCH: Accepts up to six traffic channels. The frequency corresponding to the channel accompanies. The allowable range is as follows: <ul style="list-style-type: none"> GSM900: 1 to 124 E-GSM: 0 to 124, and 975 to 1023 DCS1800: 512 to 885 PCS1900: 512 to 810 o DCP: Accepts up to six dc voltages ranging from 3.0 to 11.0 V in 0.1 V steps.

- a. The variable increment softkeys are activated. Refer to "[Variable Increment Softkey](#)" on page 60.
- b. When DC Power is set to Off, the DC Current cannot be measured and “----” is shown in the DC Current cells in the table of the AUTOMATIC TEST: Stand-by detailed screen.

The following test items need to be set to either “Run” to execute a Pass/Fail test or to “---” (skip) not to execute a Pass/Fail test, for each channel or dc power, respectively:


Test Item	Description
Peak TX Power	Defines whether to run or skip the Peak TX Power test for the High, Mid, and Low levels. The MS power class and the power control levels for the High, Mid, and Low levels are defined in the Test Setup: Test Condition screen.
Burst Timing	Defines whether to run or skip the Burst Timing test. In the GPRS mode, this will be substituted by Power vs Time.
Power Ramp	Defines whether to run or skip the Power Ramp test. In the GPRS mode, this will be substituted by Power vs Time.
Phase Error	Defines whether to run or skip the Phase Error test.
Frequency Error	Defines whether to run or skip the Frequency Error test.
Sensitivity	Defines whether to run or skip the Sensitivity test in BER and FER. In the GPRS mode, BLER will substitute BER and FER. The BS level and the number of test frames are defined in the Test Setup: Test Condition screen.
RX Quality	Defines whether to run or skip the RX Quality test. In the GPRS mode, this can not be measured.
RX Level	Defines whether to run or skip the RX Level test. In the GPRS mode, this can not be measured.
DC Current	Defines whether to run or skip the DC Current test at Camp On and Talk steps.

When TCH is set in the Variable field and the all of test items are set to skip for one TCH, only the handover capability can be tested for that TCH.


Creating Instruction Messages

An instruction message with up to 69 characters including spaces and symbols can be created for each step of a test flow to execute AUTOMATIC TEST. The range of the step numbers is from 1 to 7 corresponding to each step of a test flow. Use the following procedure to create an instruction message:

Step 1. Place the circular cursor in front of the input field of Instruction.



Step 2. Press and rotate the CURSOR CONTROL knob until the desired step number is shown and press the CURSOR CONTROL knob to select it. Then, the whole message line is displayed with the rectangular cursor on the first position, showing a message if it is already stored. Check that the circular cursor is set to Done in the Choices scrolling window.



Step 3. Create a message by rotating and pressing the CURSOR CONTROL knob to select commands, alphanumeric characters, and some kinds of symbols from the scrolling window.


The available commands and characters are as follows:

- o Done: Enters the newly created instruction message in the instruction message field.
- o Cancel: Exits the editing function without any change of the message.
- o Position: Allows you to move the rectangular cursor to any position of the message for editing.

- o Over/Ins: Selects either Over (overwrite) or Ins (insert). Over enables you to overwrite (erase and replace) the selected alphanumeric character. Ins enables you to insert characters at the position of the rectangular cursor without erasing the existing characters.
- o Delete: Deletes the alphanumeric character selected by the rectangular cursor.
- o Del End: (Delete to the End) Deletes all alphanumeric characters from the rectangular cursor to the end of a message line.
- o Bk Space: (Backspace) Erases one alphanumeric character behind the rectangular cursor.
- o Available alphanumeric characters and symbols are as follows:

A B C D E F G H I J K L M N O P Q R S T U V W X Y Z _ 0 1 2 3 4 5 6 7 8 9
 (space) a b c d e f g h i j k l m n o p q r s t u v w x y z ! " # \$ % & ' () * + , - . /
 : ; < = > ? @ [\] ^ { | } ~

The following illustration shows the editing screen about to enter “g” to spell out “being” overwriting the default message.



Step 4. If the created message is right, move the circular cursor back to Done and press the CURSOR CONTROL knob once more to enter that message. The circular cursor returns in front of the step number. Then, the message line is highlighted.

The default instruction messages at factory shipment are as follows:

1. Turn on MS power, wait for Location Update.
2. Make MS Call or respond to BS Call.
3. Talk to the mobile and press [Pass] or [Fail] with the result.
4. Wait for the RF Test to complete.
5. End call (for MS Call) or wait for call to end.
6. Respond to BS Call or make MS Call.
7. Wait for call to end (for BS Release) or end (for MS Release).

File Management

When the File Management softkey is pressed with a proper SRAM memory card inserted in the MEMORY CARD slot, the following screen is displayed. All setup file names in the card are listed in the table.

You can save all of the test setup information into an SRAM memory card. Data and time are automatically added from the Test Set. Refer to ["Saving a Test Setup File" on page 161](#).

Figure 3-64 File Management Screen

File Management					2000/01/20 12:34	
Procedure:Test900A						
No.	Filename	Date	Time	Comment		
001	Test900B	2000/01/10	09:15	GSM900 Test B	Save	
002	Test-DCS	2000/01/12	10:20	DCS1800 Test A	Recall	
003					Delete	
004					Choices: (----)	
005					Done	
006					Cancel	
007					Position	
008					Over/Ins	
009					Delete	
010					Del End	
011					More	
012					(1 of 2)	
013					Return	
014						
015						

config_save_recall

Softkey Menu 1

- o Save: Stores a new test setup file into a SRAM memory card. Refer to ["Saving a Test Setup File" on page 161](#).
- o Recall: Loads one of the test setup files from a SRAM memory card into the Test Set. If a proper SRAM memory card is not inserted, this softkey is not activated. Refer to ["Recalling a Test Setup File" on page 163](#)
- o Delete: Deletes the file selected by the cursor. If a proper SRAM memory card is not inserted, this softkey is not activated.
- o More (1 of 2): Displays softkey menu 2.
- o Return: Displays the previous screen and then the initial screen with function modes.

Softkey Menu 2

- o Print: Allows you to print a hardcopy of a graphic image from the screen.
- o Print All: Prints all of the file list on the SRAM memory card.
- o Format: Initializes a new SRAM memory card or a used card erasing all information in it.

NOTE


The memory cards which contain the firmware update revisions for the Test Set can not be initialized using this Format softkey. A PC may be used to initialize such SRAM cards.

- o More (2 of 2): Returns to softkey menu 1.
- o Return: Displays the previous screen and then the initial screen with function modes.


Saving a Test Setup File

For saving a new test setup file, use the following procedure:

- Step 1.** If a new SRAM memory card is going to be used, initialize it by pressing the Format softkey.
- Step 2.** Insert your SRAM memory card into the MEMORY CARD slot.
- Step 3.** Move the cursor to the number next to the last filename. The Recall and Delete softkeys will be erased from the menu.




- Step 4.** Press the Save softkey, then the Filename and Comment fields are highlighted with the circular cursor in front of the Filename field.




Softkey Menu

- o Save Execute: Press this softkey after entering your filename and comment to store your file into a SRAM card.
- o Cancel: Cancels the save execute screen and return to the save screen in Step 3.

Step 5. Press the CURSOR CONTROL knob once to activate the Choices scrolling window with the blinking circular cursor at Done. The entry mode is automatically set to overwrite showing Over in the parentheses under Choices. The rectangular cursor is placed at the first position of the Filename field enabling to enter the first character of your filename.




Step 6. Select alphanumeric characters and other symbols by rotating and pressing the CURSOR CONTROL knob and create a filename.



Step 7. Rotate the CURSOR CONTROL knob counterclockwise to find Done and press the knob to enter the filename created.


Step 8. Rotate the CURSOR CONTROL knob one click clockwise and the Comment field should be highlighted with the circular cursor in front of it. Repeat Step 5 to Step 7 to complete entering your comment.



Softkey Menu

- o Save Execute: The operation message “OK to save?” is shown when this softkey is pressed, and the Yes and No response softkeys are displayed. Refer to [Step 9](#).
- o Cancel: Exits the save execute screen, and returns to the save/recall screen.

Step 9. Press the Save Execute softkey and respond to the operation message “OK to save?” by pressing the Yes softkey. If there is something to revise, press the No softkey to go back to [Step 4](#).



Softkey Menu

- o Yes: Stores a new setup file into an SRAM memory card. The operation message “Saving...” is shown while saving. After saving, the save/recall screen is displayed.
- o No: Returns to [Step 4](#) to restart editing File name and Comment.

Step 10. If the new filename and comment have been correctly created, the operation message “Saving....” is shown for a while, and then returns to the File Management screen.

Step 11. If saving is properly done, the new filename should be shown in the filename table with the Date and Time data that are automatically taken from the internal clock of the Test Set.

Step 12. If the Save Execute softkey and the Yes softkey are pressed when the filename has been left blank, the operation message “The filename is improper. Press [Cancel].” is shown and the Test Set beeps. Press the OK softkey to stop the beeps and go back to [Step 4](#).

Recalling a Test Setup File

For recalling one of the test setup files from an SRAM memory card, use the following procedure:

Step 1. Insert your SRAM memory card into the MEMORY CARD slot to obtain the setup file list.

Step 2. Move the cursor to the file number which you want to recall.

File Management					2000/01/20 12:34
Procedure:Test900A					Save
No.	Filename	Date	Time	Comment	
001	Test900B	2000/01/10	09:15	GSM900 Test B	
002	Test-DCS	2000/01/12	10:20	DCS1800 Test A	
003	GSM-Try1	2000/01/13	11:40	GSM900 Trial Test1	Recall
004	GSM-Try2	2000/01/13	12:20	GSM900 Trial Test2	
005	GSM-Try3	2000/01/13	13:40	GSM900 Trial Test3	
006	DCSATest	2000/01/14	09:45	DCS1800 Revision A	
007	DCSBTest	2000/01/14	10:20	DCS1800 Revision B	
008					Choices: (----)
009					Done
010					Cancel
011					Position
012					Over/Ins
013					Delete
014					Del End
015					More (1 of 2)
					Delete
					Return

config_recall_1

Step 3. Press the Recall softkey, then the Filename and Comment fields are highlighted.

File Management					2000/01/20 12:34
Procedure:Test900A					Yes
No.	Filename	Date	Time	Comment	
001	Test900B	2000/01/10	09:15	GSM900 Test B	
002	Test-DCS	2000/01/12	10:20	DCS1800 Test A	
003	GSM-Try1	2000/01/13	11:40	GSM900 Trial Test1	No
004	GSM-Try2	2000/01/13	12:20	GSM900 Trial Test2	
005	GSM-Try3	2000/01/13	13:40	GSM900 Trial Test3	
006	DCSATest	2000/01/14	09:45	DCS1800 Revision A	
007	DCSBTest	2000/01/14	10:20	DCS1800 Revision B	
008					Choices: (----)
009					Done
010					Cancel
011					Position
012					Over/Ins
013					Delete
014					Del End
015					

OK to recall?

config_recall_2

Step 4. Respond to the operation message “OK to recall?” by pressing the Yes softkey. If there is something to revise, press the No softkey to go back to [Step 2](#).

Step 5. If the new filename has been correctly recalled to the Test Set, the Procedure: field above the table shows that filename. The blinking cursor is placed in front of the file number. The softkey menu returns to the initial menu.

File Management					2000/01/20 12:34
Procedure:GSM-Try3					Save
No.	Filename	Date	Time	Comment	
001	Test900B	2000/01/10	09:15	GSM900 Test B	
002	Test-DCS	2000/01/12	10:20	DCS1800 Test A	
003	GSM-Try1	2000/01/13	11:40	GSM900 Trial Test1	Recall
004	GSM-Try2	2000/01/13	12:20	GSM900 Trial Test2	
005	GSM-Try3	2000/01/13	13:40	GSM900 Trial Test3	
006	DCSATest	2000/01/14	09:45	DCS1800 Revision A	
007	DCSBTest	2000/01/14	10:20	DCS1800 Revision B	
008					Choices: (----)
009					Done
010					Cancel
011					Position
012					Over/Ins
013					Delete
014					Del End
015					More (1 of 2)
					Delete
					Return


OK to recall?

config_recall_2b

How to Update the Firmware

If Update is set to On and a firmware update card is inserted in the MEMORY CARD slot, the version number of the firmware on the card is displayed in the New Firmware field. If a firmware update card is not inserted or an improper card is inserted, “?.?.?.?” is shown in this field.


Figure 3-65 Firmware Update Screen (1/2)



Softkey Menu

- o Yes: Initiates the updating process. When this softkey is pressed with the proper update card inserted, the screen shown in Figure 3-66 is displayed.
- o No: Changes from Update: On to Update: Off without updating the current firmware.

Figure 3-66 Firmware Update Screen (2/2)



Softkey Menu

- o OK: Begins updating the firmware to the new revision. Following the update card #1, it is required to insert the update card #2 according to the operation message.

After completing the update process, the Test Set reboots to display the initial screen.

If a proper update card is not inserted when the OK softkey is pressed, the operation message “Insert the proper update card. Press [Abort].” is shown with warning beeps.

- o Cancel: Returns to AUTOMATIC TEST: Stand-by screen with the initial screen with function modes.

NOTE

Before pressing the OK softkey, carefully check if the proper update card is inserted in the card slot.

4 **Functionality/Operation**


This chapter introduces the typical block diagram of a GSM mobile phone to relate some blocks with each test item done by the Test Set, especially from the perspective of incoming inspection and repair for GSM mobile phones.

Also, there is a technical information summary that may help you utilize the Test Set.

GSM Mobile Block Diagram

Figure 4-1 shows the typical block diagram of a GSM mobile phone. The upper part of this diagram represents the mobile's transmitter blocks and the lower part is the receiver blocks. For simplicity, the digital circuitry is eliminated even though there are important parts such as EEPROM's at I/Q Modulator and Ramp Control for compensating with correction coefficients.

Figure 4-1 Typical GSM Mobile Block Diagram



GSM Measurements Selection

It is worthwhile to consider which parts of the block diagram are being tested by each measurement with the Test Set. The following table lists the relationships between each test item, test step, or parameter of the Test Set and those related parts expected, or likely, to be functioning. Depending on the tests, however, some parts may be involved multiple times with more or less information. Pitfalls are descriptive examples suggesting where further investigation may be helpful.

Table 4-1 GSM Tests vs. Related Parts

	Test Item/Step/Parameter	Functioning Parts	Pitfalls
TX	Camp On & Call Setup	Micro-Processor	Low TX power?
		Battery connection	Poor modulation?
		Keyboard & Display	Channel Synth. not on all channels?
		Channel Coder	Poor receiver gain or sensitivity?
		SIM inserted	
		TX & RX	
	Specifying TCH & BCCH	Channel Synthesizer	Same ARFCN for BCCH & TCH?
	Audio Echo	Speaker & Microphone	Channel Synth. not on all channels?
		Audio Circuits	
		Speech Coder	
	Power Control Level	RF Detector	Unstable loop at some amplitudes?
		Power Calibration	Incorrect power vs. time burst shape?
		Power Level Loop	Power amplifier compensated?
	Power Ramp	Ramp Control	Incorrect power vs. time burst shape?
		PA Switch Timing	Power amplifier compensated?
		Power Level Loop	
	Phase & Frequency Errors	I/Q Modulator	Slight I/Q modulator imbalance?
		Pre-mod Gaussian Filter	Channel synthesizer spurious?
		PA Distortion	
		Channel Synthesizer	
	Spectrum Monitor	Channel Synthesizer	Channel synthesizer spurious?
Pre-mod Gaussian Filter		Slight I/Q modulator imbalance?	
I/Q Mod. Adjustment			

	Test Item/Step/Parameter	Functioning Parts	Pitfalls
RX	BER Sensitivity (BER 0% at -50 to -90 dBm)	Channel Synthesizer	
		I/Q Demodulation	
		Equalizer	
		AGC Amplifier/Control	
	RX Quality/Level (BER <2% at -102 dBm)	LNA Gain & Noise	
		AGC Amplifier Gain	
		IF & Filter Insertion Loss	
	Timebase Tuning	Reference Oscillator	
		Channel Synthesizer	

GPRS Overview

This section summarizes the functional features of the General Packet Radio Service, or GPRS, for the Test Set installed with Option 040.


Difference from HSCSD

A single user can establish a call on more than one timeslot for the data transfer using a GSM data service called HSCSD, or High Speed Circuit Switched Data. GPRS is an overlay for the current GSM system that requires only software and a couple of new network components to work, and it allows users to transmit and receive over more than one channel. Both schemes can achieve similar data transfer rates, but the fundamental differences to move data are as follows:

- GPRS:** Uses packet switching that transfers data in little chunks over several virtual connections.
- Applies only a loose relationship between the same number uplink and downlink timeslot, and allows multiple users to share a single timeslot.
- HSCSD:** Uses circuit switching that transfers data in a single big block over a dedicated point-to-point connection.

GPRS Network Topology

Focusing on one of the base transmission stations among other GPRS network the typical functional structure is illustrated as follows:



Abbreviations in the illustration:

- BSC:** Base Station Controller
- CSPDN:** Circuit Switched Public Data Network
- GGSN:** Gateway GPRS Support Node
- MSC:** Mobile-services Switching Center
- PLMN:** Public Land Mobile Network

PSPDN: Packet Switched Public Data Network

PSTN: Public Switched Telephone Network

SGSN: Serving GPRS Support Node

The BSC has a second path to choose from when sending and receiving user data.

Voice: Sent to the MSC

GPRS data: Sent to the Serving GPRS Support Node (SGSN)

5 Specifications

This chapter provides the specifications of the Agilent E6392B GSM MS Test Set. These specifications are the standard performance limits with which the Test Set is thoroughly verified at factory.

General Information

Specifications describe the test set's warranted performance and are valid over the entire operation and environmental ranges unless otherwise noted. All specifications are valid after a 30-minute warm up period of continuous operation, and within the frequency ranges defined below.

Supplemental characteristics are intended to provide additional information useful in applying the instrument by giving typical, but non-warranted performance parameters. These characteristics are shown in Italics and labeled as "nominal", "typical", or "supplemental."

RF Input/Output

<i>Maximum Safe Reverse Power (peak):</i>	+41 dBm (12.6 W; CW; supplemental characteristic)
<i>Impedance:</i>	50 Ω nominal
<i>Input SWR:</i>	$\leq 1.5:1$
<i>Connector:</i>	N-type, female

RF Signal Generator

<i>Frequency Range:</i>	935 MHz to 960 MHz (GSM downlink) 925 MHz to 960 MHz (E-GSM downlink) 1805 MHz to 1880 MHz (DCS1800 downlink) 1930 MHz to 1990 MHz (PCS1900 downlink)
<i>Frequency Resolution:</i>	200 kHz at channel frequency
<i>Frequency Accuracy:</i>	Same as frequency reference
<i>Output Level Range:</i>	-110.0 dBm to -50.0 dBm in 0.5 dB steps
<i>Output Level Accuracy:</i>	± 1.0 dB for GSM/E-GSM (± 0.6 dB typical at 25 °C) ± 1.3 dB for DCS1800 (± 0.6 dB typical at 25 °C) ± 1.5 dB for PCS1900 (± 0.8 dB typical at 25 °C)
<i>0.3 GMSK Modulation:</i>	PN9 (with training sequence), all 0, Off (CW sinewave)
<i>Phase Error</i>	$< 3^\circ$ rms supplemental characteristics
<i>Peak Phase Error:</i>	$< 6^\circ$ peak supplemental characteristics

RF Analyzer

Frequency Range:	890 MHz to 915 MHz (GSM uplink)
	880 MHz to 915 MHz (E-GSM uplink)
	1710 MHz to 1785 MHz (DCS1800 uplink)
	1850 MHz to 1910 MHz (PCS1900 uplink)

Transmitter Carrier Peak Power Measurement

Range:	-20 dBm to +39 dBm (0.3 GMSK at burst/continuous or CW)
Accuracy:	For GSM900/E-GSM/DCS1800: ± 1.0 dB at ≥ 0 dBm ± 2.0 dB at < 0 dBm (± 0.5 dB typical at all power ranges at 25 °C) For PCS1900: ± 1.3 dB at ≥ 0 dBm ± 2.0 dB at < 0 dBm (± 0.6 dB typical at all power ranges at 25 °C)
Resolution:	0.2 dB

Power Ramp Measurement

Range:	0 dBm to +39 dBm of peak power input (0.3 GMSK at burst)
Accuracy:	± 0.6 dB supplemental characteristics at 25 ± 5 °C at ≥ 0 dBm ± 1.6 dB supplemental characteristics at 25 ± 5 °C at < 0 dBm
Resolution:	0.2 dB
Dynamic Range:	≥ 40 dB supplemental characteristics

Phase and Frequency Error Measurement

Input Level Range:	-11 dBm to +39 dBm
Input Phase Error Range:	0 to 20° (0.3 GMSK at burst)
Phase Error	≤1.5 ° rms at phase error ≥2.5 °
Measurement Accuracy:	≤6.0 ° peak at phase error ≥2.5 °
Frequency Error Measurement Range:	±9 kHz (0.3 GMSK at burst/continuous or CW)
Frequency Error Measurement Accuracy: (average of 10 measurements)	For GSM900/E-GSM: ±(12 Hz + frequency reference accuracy) <i>[±(8 Hz + frequency reference accuracy) typical]</i> For DCS1800/PCS1900: ±(25 Hz + frequency reference accuracy) <i>[±(15 Hz + frequency reference accuracy) typical]</i>

Spectrum Monitor

Input Level Range:	-11 dBm to +39 dBm
Frequency Span: (from channel frequency)	0 Hz to +400 kHz
Resolution Bandwidth:	10 kHz or 30 kHz
<i>Amplitude Accuracy:</i>	<i>±2.0 dB supplemental characteristics</i>
<i>Amplitude Resolution:</i>	<i>0.4 dB supplemental characteristics</i>
<i>Dynamic Range:</i>	<i>≥40 dB supplemental characteristics at input ≥0 dBm</i>

DC Power Supply

Range:	3.0 Vdc to 11.0 Vdc
Resolution:	0.1 V
Accuracy:	± 0.1 V at 100 mA load
Maximum Current:	1 A, peak 2 A at 3.0 to 9.0 V, peak 1.5 A at 9.1 to 11.0 V
<i>Ripple Noise:</i>	<i>60 mV p-p supplemental characteristics</i>

DC Current Measurement

Range:	3 mA to 1000 mA
Accuracy:	$\pm(3 \text{ mA} + 2\%)$

Memory Card

Type:	PCMCIA (U.S.)
Memory Size:	SRAM 512 KB

Asynchronous Test (Option 002)

Spectrum Monitor

Frequency Range:	890 MHz to 915 MHz (GSM uplink) 880 MHz to 915 MHz (E-GSM uplink) 1710 MHz to 1785 MHz (DCS1800 uplink) 1850 MHz to 1910 MHz (PCS1900 uplink)
Input Level Range:	-11 dBm to +39 dBm
Frequency Span (from channel frequency):	0 Hz to +400 kHz or ± 100 kHz
Resolution Bandwidth:	10 kHz or 30 kHz
<i>Amplitude Accuracy:</i>	<i>± 2.0 dB supplemental characteristics</i>
<i>Amplitude Resolution:</i>	<i>0.4 dB supplemental characteristics</i>
<i>Dynamic Range:</i>	<i>≥ 40 dB supplemental characteristics at input ≥ 0 dBm</i>

RF Signal Generator

Frequency Range:	935 MHz to 960 MHz (GSM downlink) 925 MHz to 960 MHz (E-GSM downlink) 1805 MHz to 1880 MHz (DCS1800 downlink) 1930 MHz to 1990 MHz (PCS1900 downlink)
Frequency Resolution:	200 kHz at channel frequency
Frequency Accuracy:	Same as frequency reference
Output Level Range:	-110.0 dBm to -50.0 dBm in 0.5 dB steps
Output Level Accuracy:	± 1.0 dB for GSM/E-GSM (<i>± 0.6 dB typical at 25 °C</i>) ± 1.3 dB for DCS1800 (<i>± 0.6 dB typical at 25 °C</i>) ± 1.5 dB for PCS1900 (<i>± 0.8 dB typical at 25 °C</i>)
0.3 GMSK Modulation:	PN9 (with training sequence), all 0, Off (CW sinewave)
<i>Phase Error:</i>	<i>$< 3^\circ$ rms supplemental characteristics</i>
<i>Peak Phase Error:</i>	<i>$< 6^\circ$ peak supplemental characteristics</i>

GPRS Test (Option 040)

Specifications Unique for GPRS Measurement

Slot Configuration:	Downlink 1 × Uplink 1 Downlink 2 × Uplink 1
Slot Order Measured:	4 (fourth)
Sensitivity Measurement:	BLER (block error rate)
Changes in Test Item Table:	Peak TX Power, Power vs Time (Burst Timing and Power Ramp can be also displayed.) Sensitivity: Only BLER is displayed. (BER, FER, RX Quality, and RX Level can not be displayed.)

Rear Panel

Frequency Reference

Frequency:	13 MHz
Frequency Accuracy:	$\pm[(\text{Time since calibration} \times \text{Aging}) + \text{Temperature effects} + \text{Accuracy of calibration}]$
Aging:	± 0.1 ppm/year
Temperature Stability:	± 0.1 ppm (20 °C to 30 °C)
Reference Input:	<i>13 MHz, 0 to +10 dBm supplemental characteristics, 50 Ω nominal</i>
Reference Output:	<i>13 MHz, >+3 dBm supplemental characteristics, 50 Ω nominal</i>

Serial Interface

Interface:	EIA RS-232C
Baud Rate:	9600
Connector:	D-Sub 9-pin male

Printer Interface

Interface:	Centronics
Connector:	D-Sub 25-pin female

General Specifications

Size:	350 mm (W) × 150 mm (H) × 350 mm (D)
Weight:	10 kg ± 10%
Power Voltage:	90 V to 264 V
Power Frequency:	47 Hz to 63 Hz
Power Consumption:	≤135 VA at 100 Vac
Operating Temperature:	+15 °C to +35 °C
Storage Temperature:	-20 °C to +60°C

A **General Information on the GSM System**

For your reference, some major information on the GSM system is described in this appendix.

The GSM System

A GSM mobile phone transmits speech as bursts of encoded data. An RF carrier is modulated by the special form of frequency modulation known as the Gaussian Minimum Shift keying (GMSK). Signals are transmitted in short bursts (577 μ s each) using the method called Time Division Multiple Access (TDMA) on Absolute RF Channels (ARFCNs) spaced 200 kHz apart.

RF Channels

The next table shows the RF channel frequencies and channel numbers for each radio standard.

	GSM900	E-GSM	DCS1800	PCS1900
Uplink	890.2 to 914.8 MHz	880.2 to 914.8 MHz	1710.2 to 1784.8 MHz	1850.2 to 1909.8 MHz
Downlink	935.2 to 959.8 MHz	925.2 to 959.8 MHz	1805.2 to 1879.8 MHz	1930.2 to 1989.8 MHz
ARFCN Range	1 to 124	0 to 124, 975 to 1023	512 to 885	512 to 810

Power Classes

The power classes are defined as follows:

	1	2	3	4	5
GSM900, E-GSM		+39 dBm	+37 dBm	+33 dBm	+29 dBm
DCS1800	+30 dBm	+24 dBm	+36 dBm		
PCS1800	+30 dBm	+24 dBm	+33 dBm		

Power Control Levels

The power control levels, RF power levels and permissible tolerances are shown below:

#	GSM900,E-GSM		DCS1800		PCS1900	
29			+36 dBm	±2 dB		
30			+34 dBm	±3 dB	+33 dBm	±2 dB
31			+32 dBm	±3 dB ^a	+32 dBm	±2 dB ^a
0	+43 dBm	±2 dB	+30 dBm	±3 dB	+30 dBm	±3 dB
1	+41 dBm	±3 dB	+28 dBm	±3 dB	+28 dBm	±3 dB
2	+39 dBm	±3 dB ^a	+26 dBm	±3 dB	+26 dBm	±3 dB
3	+37 dBm	±3 dB ^a	+24 dBm	±3 dB ^a	+24 dBm	±3 dB ^a
4	+35 dBm	±3 dB	+22 dBm	±3 dB	+22 dBm	±3 dB
5	+33 dBm	±3 dB ^a	+20 dBm	±3 dB	+20 dBm	±3 dB
6	+31 dBm	±3 dB	+18 dBm	±3 dB	+18 dBm	±3 dB
7	+29 dBm	±3 dB ^a	+16 dBm	±3 dB	+16 dBm	±3 dB
8	+27 dBm	±3 dB	+14 dBm	±3 dB	+14 dBm	±3 dB
9	+25 dBm	±3 dB	+12 dBm	±4 dB	+12 dBm	±4 dB
10	+23 dBm	±3 dB	+10 dBm	±4 dB	+10 dBm	±4 dB
11	+21 dBm	±3 dB	+8 dBm	±4 dB	+8 dBm	±4 dB
12	+19 dBm	±3 dB	+6 dBm	±4 dB	+6 dBm	±4 dB
13	+17 dBm	±3 dB	+4 dBm	±4 dB	+4 dBm	±4 dB
14	+15 dBm	±3 dB	+2 dBm	±5 dB	+2 dBm	±5 dB
15	+13 dBm	±3 dB	+0 dBm	±5 dB	+0 dBm	±5 dB
16	+11 dBm	±5 dB				
17	+9 dBm	±5 dB				
18	+7 dBm	±5 dB				
19	+5 dBm	±5 dB				

a. This shall be ±2 dB when the power level corresponds to the power class of the mobile.

RX Level

The RX levels are defined as follows:

#	RX Level	#	RX Level	#	RX Level
0	≤110 dBm	22	-89 to -88 dBm	44	-67 to -66 dBm
1	-110 to -109 dBm	23	-88 to -87 dBm	45	-66 to -65 dBm
2	-109 to -108 dBm	24	-87 to -86 dBm	46	-65 to -64 dBm
3	-108 to -107 dBm	25	-86 to -85 dBm	47	-64 to -63 dBm
4	-107 to -106 dBm	26	-85 to -84 dBm	48	-63 to -62 dBm
5	-106 to -105 dBm	27	-84 to -83 dBm	49	-62 to -61 dBm
6	-105 to -104 dBm	28	-83 to -82 dBm	50	-61 to -60 dBm
7	-104 to -103 dBm	29	-82 to -81 dBm	51	-60 to -59 dBm
8	-103 to -102 dBm	30	-81 to -80 dBm	52	-59 to -58 dBm
9	-102 to -101 dBm	31	-80 to -79 dBm	53	-58 to -57 dBm
10	-101 to -100 dBm	32	-79 to -78 dBm	54	-57 to -56 dBm
11	-100 to -99 dBm	33	-78 to -77 dBm	55	-56 to -55 dBm
12	-99 to -98 dBm	34	-77 to -76 dBm	56	-55 to -54 dBm
13	-98 to -97 dBm	35	-76 to -75 dBm	57	-54 to -53 dBm
14	-97 to -96 dBm	36	-75 to -74 dBm	58	-53 to -52 dBm
15	-96 to -95 dBm	37	-74 to -73 dBm	59	-52 to -51 dBm
16	-95 to -94 dBm	38	-73 to -72 dBm	60	-51 to -50 dBm
17	-94 to -93 dBm	39	-72 to -71 dBm	61	-50 to -49 dBm
18	-93 to -92 dBm	40	-71 to -70 dBm	62	-49 to -48 dBm
19	-92 to -91 dBm	41	-70 to -69 dBm	63	≥48 dBm
20	-91 to -90 dBm	42	-69 to -68 dBm		
21	-90 to -89 dBm	43	-68 to -67 dBm		

RX Quality

The RX quality is defined as follows:

#	RX Quality	#	RX Quality
0	<0.2%	4	1.6 to 3.2%
1	0.2 to 0.4%	5	3.2 to 6.4%
2	0.4 to 0.8%	6	6.4 to 12.8%
3	0.8 to 1.6%	7	>12.8%

Limits for BER and FER

The permissible limits for BER and FER are defines as follows:

RF Level	Mobile	BER	FER
-100 dBm	all	0.00%	
-102 dBm	P>2 W	<2.44%	
-104 dBm	P≤2W	<2.44%	<0.10%

Limits for Frequency Error

The permissible limits for the Frequency Error are defined as follows:

$$\leq \pm 0.1 \text{ ppm}$$

B Input Fields and Allowable Ranges

Here is a table of the input fields and allowable ranges of values for test parameters and test items. This table is also useful for configuring the Test Setup: Test Sequence and Test Setup: Test Condition screens.

Table 0-1 Input Fields and Allowable Choices or Ranges

Test Mode	Test Item, Parameter	Radio Standard		
		GSM900/E-GSM	DCS1800	PCS1900
Automatic Test, Manual Test, Spectrum Monitor, Signal Generator	BCCH (Frequency):	GSM: 1 to 124 (890.2 to 914.8 MHz), E-GSM: 0 to 124 (890.0 to 914.8 MHz), 975 to 1023 (880.2 to 889.8 MHz)	512 to 885 (1710.2 to 1784.8 MHz)	512 to 810 (1850.2 to 1909.8 MHz)
	TCH (Talk) (Frequency):	GSM: 1 to 124 (890.2 to 914.8 MHz), E-GSM: 0 to 124 (890.0 to 914.8 MHz), 975 to 1023 (880.2 to 889.8 MHz)	512 to 885 (1710.2 to 1784.8 MHz)	512 to 810 (1850.2 to 1909.8 MHz)
	Procedure:	Default [previous setting], User		
	Multi Band:	OFF, DCS1800	OFF, GSM900, E-GSM	OFF
	DC Power:	Off, On, Auto [only for Automatic Test]; 3.0 to 11.0 V in 0.1 V steps		
	Variable: ^a	TCH, DC Power		
	TCH 1 to 6 or DCP 1 to 6	GSM: 1 to 124, E-GSM: 0 to 124, 975 to 1023	512 to 885	512 to 810
	3.0 to 11.0 V in 0.1 V steps			
Manual Test	PDTCH (Frequency): [GPRS mode]	GSM: 1 to 124 (890.2 to 914.8 MHz) E-GSM: 0 to 124 (890.0 to 914.8 MHz), 975 to 1023 (880.2 to 889.8 MHz)	512 to 885 (1710.2 to 1784.8 MHz)	512 to 810 (1850.2 to 1909.8 MHz)
	Signal: SYNC mode ASYNC mode GPRS mode	Burst [fixed] Burst, CW Burst [fixed]		
	Timing ADV: [SYNC and GPRS modes]	0 to 63 bits		
	PWR CNTL:	2: +39 dBm to 19: +5 dBm	29: +36 dBm to 15: 0 dBm	30: +33 dBm to 15: 0 dBm
	BS Level:	-110.0 to -50.0 dBm		
	Slot Config: [GPRS mode]	Downlink 1 × Uplink 1, or Downlink 2 × Uplink 1		
	Measured Slot: [GPRS mode]	4 (fourth)		

	Sensitivity: [GPRS mode]	BLER (FER, BER, RX Quality, and RX Level can not be displayed.)		
	Midamble: [ASYNc mode]	TSC0 to TSC7, or None (amplitude triggering)		
	Averaging:	Off, 2 to 99		
	Span:	0-400 kHz (fixed)		
	RBW:	10, 30 (kHz)		
Spectrum Monitor	Channel (Frequency):	GSM: 1 to 124 (890.2 to 914.8 MHz) E-GSM: 0 to 124 (890.0 to 914.8 MHz), 975 to 1023 (880.2 to 889.8 MHz)	512 to 885 (1710.2 to 1784.8 MHz)	512 to 810 (1850.2 to 1909.8 MHz)
	Measurement Range:	-3, +9, +19, +29, +39 dBm		
	Span:	0-400, ±100 (kHz)		
	RBW:	10, 30 (kHz)		
	Averaging:	Off, 2 to 99		
	DC Power:	Off, On; 3.0 to 11.0 V in 0.1 V steps		
Signal Generator	Channel (Frequency):	GSM: 1 to 124 (935.2 to 959.8 MHz), E-GSM: 0 to 124 (935.0 to 959.8 MHz), 975 to 1023 (925.2 to 934.8MHz)	512 to 885 (1805.2 to 1879.8 MHz)	512 to 810 (1930.2 to 1989.8 MHz)
	Level:	-110.0 to -50.0 dBm in 0.5 dB steps		
	RF Output:	Off, On		
	Modulation:	Off, PN9, All_0		
	DC Power:	Off, On; 3.0 to 11.0 V in 0.1 V steps		
Configuration	Baud Rate:	9600 (fixed)		
	Data Length:	7, 8		
	Stop Bits:	1, 1.5, 2		
	Parity:	None, Odd, Even		
	Xcontrol:	None, Xon/Xoff		
	Terminator:	CR, LF, CR+LF		
	Printer:	HP PCL, ESC/P		
	Beeper:	Off, On		
	Panel Key:	Lock, Unlock		
	13 MHz Reference:	INT, EXT		
	Option:	002, 040 [for example]		

Input Fields and Allowable Ranges

	Attenuation: RF In: RF Out:	Off, On 0.0 to 99.9 dB in 0.1 dB steps 0.0 to 99.5 dB in 0.5 dB steps		
	Network Config:	0 to 999 (MCC), 0 to 99 (MNC), 0 to 7 (NCC), 0 to 65535 (NCC), 2 to 9 (BS_PA)		
	Date/Time:	1990 to 2089 (YYYY), 01 to 12 (MM), 01 to 31 (DD) 00 to 23 (HH), 00 to 59 (MM)		
	Firmware: Update: New Firmware:	X.XX.XX Off, On Y.YY.YY [when Update is On]		
Configuration: Condition	MS Power Class:	2 to 5	1 to 3	1 to 3
	PWR CNTL High: Mid: Low: Manual Test:	2: +39 dBm to 19: +5 dBm	29: +36 dBm to 31: +32 dBm, 0: +30 dBm to 15: 0 dBm	30 +33 dBm to 31: +32 dBm, 0: +30 dBm to 15: 0 dBm
	Averaging:	Off, 2 to 99		
	RF Output:	Auto, On		
	BS Level:	-110.0 to -50.0 dBm in 0.5 dB steps		
	BER BS Level:	-110.0 to -50.0 dBm in 0.5 dB steps		
	BER Frames:	1 to 13000 frames in 1 frame steps [# of bits shown]		
	Loopback Delay:	Short, Mid, Long		
	Limit Setting:			
	Peak TX Power: PWR CNTL ^a	Template, or -99.9 to +99.9 dB in 0.1 dB steps		
		2: +39 dBm to 19: +5 dBm	29: +36 dBm to 31: +32 dBm, 0: +30 dBm to 15: 0 dBm	30 +33 dBm to 31: +32 dBm, 0: +30 dBm to 15: 0 dBm
	Burst Timing:	-9.9 to +9.9 bits in 0.1 bit steps		
	Power Ramp:	Template		
	Phase Error RMS/Peak:	0.0 to 99.9 ° in 0.1 ° steps		
	Frequency Error:	-999 to + 999 Hz in 1 Hz steps		
	BER:	0.00 to 99.99% in 0.01% steps		
	FER:	0.00 to 99.99% in 0.01% steps		
	BLER:	0.00 to 99.99% in 0.01% steps		
	RX Quality:	0: < 0.2%, 1: 0.2 to 0.4%, ..., 6: 6.4 to 12.8%, 7: > 12.8%		
	RX Level:	0: < -110 dBm, 1: -110 to -109 dBm, ..., 62: -49 to -48 dBm, 63: > -48		
DC Current Camp On: Talk:	3 to 1000 mA in 1 mA steps 3 to 1000 mA in 1 mA steps			

Configuration: Sequence	Test Steps: 1. LOC. Update: 2. 1st Call: 3. Talk: 4. RF Test: 5. 1st Release: 6. 2nd Call: 7. 2nd Release:	Run, --- MS, BS Run, --- (no entry required) MS, BS (determined by step 2) BS, MS (determined by step 2); Run, --- BS, MS (determined by step 2); Run, --- (determined by step 6)		
	BCCH (Frequency):	GSM: 1 to 124 (890.2 to 914.8 MHz), E-GSM: 0 to 124 (890.0 to 914.8 MHz), 975 to 1023 (880.2 to 889.8 MHz)	512 to 885 (1710.2 to 1784.8 MHz)	512 to 810 (1850.2 to 1909.8 MHz)
	TCH (Talk) (Frequency):	GSM: 1 to 124 (890.2 to 914.8 MHz), E-GSM: 0 to 124 (890.0 to 914.8 MHz), 975 to 1023 (880.2 to 889.8 MHz)	512 to 885 (1710.2 to 1784.8 MHz)	512 to 810 (1850.2 to 1909.8 MHz)
	Multi Band:	OFF, DCS1800	OFF, GSM900, E-GSM	OFF
	DC Power:	Off, On, Auto (only for Automatic Test); 3.0 to 11.0 V in 0.1 V steps		
	Variable:	TCH, DC Power		
	TCH 1 to 6 or DCP 1 to 6	GSM: 1 to 124, E-GSM: 0 to 124, 975 to 1023	512 to 885	512 to 810
		3.0 to 11.0 V in 0.1 V steps		

a. Valid only for AUTOMATIC TEST

C Manual Changes

Introduction

This appendix contains revision notes for adapting the information in this guide to correspond to the Test Set units that were manufactured before this guide was printed.

Serial Numbers

The serial number of your Test Set is marked on the serial number plate attached to the rear panel.

Manual Changes

After reviewing [Table C-1](#), write in this user's guide the necessary changes from the revision notes that correspond to the serial number of your Test Set.

Table C-1 Serial Number and Changes

Serial Prefix or Number	Changes
JP3MG	1
JP5MG	1 and 2

Change 1

“Phase and Frequency Error Measurement” on page 177

Change the “Frequency Error Measurement Accuracy” as follows:

Frequency Error Measurement Accuracy:	For GSM900/E-GSM at <33 dBm input at 25 ± 5 °C: $\pm(12 \text{ Hz} + \text{frequency reference accuracy})$ <i>[$\pm(8 \text{ Hz} + \text{frequency reference accuracy})$ typical]</i>
(average of 10 measurements)	For DCS1800/PCS1900 at <30 dBm input at 25 ± 5 °C: $\pm(25 \text{ Hz} + \text{frequency reference accuracy})$ <i>[$\pm(15 \text{ Hz} + \text{frequency reference accuracy})$ typical]</i>

Change 2

“MANUAL TEST (GPRS Mode)” on page 118

This section is added to make manual tests on the general packet radio service (GPRS) if the Test Set is installed with Option 040.

Numerics

- 13 MHz IN/OUT connector
 - rear panel 54
- 13 MHz Reference
 - input field 146

A

- Abort
 - softkey menu 69, 86, 88, 90, 96, 98, 107, 108, 114, 123, 124, 126, 130, 132, 140
- aborted screen
 - AUTOMATIC TEST 71
- ac power receptacle
 - rear panel 54
- ACT Tim ADV
 - display field 122
- adequate ventilation
 - environmental requirement 21
- adjustment
 - display contrast 23
- allowable range
 - test item
 - general operation guide 58
 - test parameter
 - general operation guide 58
- asynchronous mode
 - DC Current 113
 - MANUAL TEST 15, 102, 103, 107
 - testing examples 40
 - measuring screen 107
 - measuring screen example 108
 - Peak TX Power/Burst Timing/Power Ramp 108
 - Phase Error/Frequency Error 111
 - Spectrum Monitor 114
 - stand-by screen 103

- attached screen
 - stand-by screen 123
- Attenuation
 - input field 146
- attenuation values
 - preparation for each test 24
- AUTOMATIC TEST
 - aborted screen 71
 - initial screen 61
 - major functions 14
 - pass/fail screen 73
 - pass/fail screen example 75
 - screen reference 63
 - stand-by screen 63
 - talk measuring screen 69
 - testing examples 29
- automatic test flow
 - BS or MS Call 154
 - BS or MS Release 154
 - LOC. Update 154
 - MS or BS Call 154
 - MS or BS Release 154
 - RF Test 154
 - Talk 154
 - test sequence 154
- AUX connector
 - front panel 53
- Averaging
 - input field 100, 116, 134, 138, 149

B

- BCCH
 - input field 65, 104, 155
 - measuring screen 120
- Beeper
 - input field 146
- BER

- test limit 151
 - BER BS Level
 - input field 150
 - BER Frames
 - input field 150
 - Bk Space
 - command 159
 - BLER
 - test limit 151
 - BS Call
 - measuring screen 86
 - softkey menu 81
 - BS Level
 - input field 83, 100, 105, 116, 121, 134, 149
 - BS or MS Call
 - automatic test flow 154
 - BS or MS Release
 - automatic test flow 154
 - Burst Timing
 - pass/fail test 157
 - test item 67, 84, 105
 - test limit 151
 - Burst Timing/Power Ramp
 - pass/fail screen 76
- C**
- Cancel
 - command 158
 - softkey menu 163, 166
 - Channel
 - input field 100, 116, 134, 138, 144
 - chapter
 - preparing for use 13
 - screen reference 51
 - using functions 27
 - character

-
- instruction message 158
 - cleaning instruction
 - environmental requirement 21
 - command
 - Bk Space 159
 - Cancel 158
 - Del End 159
 - Delete 159
 - Done 158
 - instruction message 158
 - Over/Ins 159
 - Position 158
 - configurable instruction message
 - display annotation 55
 - CONFIGURATION
 - configuration screen 145
 - file management screen 160
 - firmware update 165
 - initial screen 62
 - screen field 146
 - screen reference 145
 - test condition screen 148
 - test sequence screen 153
 - configuration screen
 - CONFIGURATION 145
 - CONTRAST knob
 - front panel 53
 - controlling the marker
 - CURSOR CONTROL knob 53
 - creating
 - instruction message 158
 - CURSOR CONTROL knob
 - controlling the marker 53
 - front panel 52
 - moving the cursor 52
 - selecting a field entry 52
 - D**
 - date and time
 - display annotation 55
 - Date/Time
 - input field 147
 - DC Current
 - asynchronous mode 113
 - display field 122
 - GPRS mode 131
 - measuring screen 82, 96, 113, 131
 - pass/fail screen 79
 - pass/fail test 157
 - test item 67, 84, 105, 122
 - test limit 152
 - DC Current Measuring Screen
 - MANUAL TEST (Asynchronous Mode) 130
 - DC Power
 - input field 65, 83, 100, 105, 116, 121, 134, 138, 144, 155
 - DCP
 - Variable 66, 156
 - Del End
 - command 159
 - Delete
 - command 159
 - softkey menu 160
 - detailed screen
 - stand-by screen 63
 - Dialed No.
 - display field 68, 70, 85, 124
 - difference from HSCSD
 - GPRS 171
 - display annotation
 - configurable instruction message 55
 - date and time 55
 - function mode 55
 - general operation guide 55
 - multiple purpose 55
 - operation message 55
 - operation status 55
 - softkey label 55
 - display contrast
 - adjustment 23
 - preparation for each test 23
 - display field
 - ACT Tim ADV 122
 - DC Current 122
 - Dialed No. 68, 70, 85, 124
 - GSM Version 68, 70, 85
 - IMEI 68, 70, 85, 102, 122, 123
 - IMSI 68, 70, 85, 102, 122, 123
 - M1 +200 kHz 101, 117, 135, 139
 - M1 -67.7 kHz 139
 - M2 +/-0 kHz 139
 - M2 +250 kHz 101, 117, 135, 139
 - M3 +67.7 kHz 139
 - Marker 101, 117, 135, 139
 - Peak 101, 117, 135, 139
 - Power Class 68, 70, 85, 122, 123
 - screen field 68, 70, 85, 122, 123, 124
 - Done
 - command 158
 - E**
 - EJECT key
 - front panel 53
 - electrical requirement
 - installing the test set 20
 - line setting 20
 - environment
 - environmental requirement 20
 - environmental requirement
 - adequate ventilation 21
-

-
- cleaning instruction 21
 - environment 20
 - installing the test set 20
 - F**
 - Fail
 - softkey menu 69
 - FER
 - test limit 151
 - File Management
 - softkey menu 145, 148, 153
 - file management
 - recalling a file 163
 - saving a file 161
 - file management screen
 - CONFIGURATION 160
 - Firmware
 - input field 147
 - firmware update
 - CONFIGURATION 165
 - Format
 - softkey menu 160
 - Frequency Error
 - pass/fail test 157
 - test item 67, 84, 105, 122
 - test limit 151
 - front panel
 - AUX connector 53
 - CONTRAST knob 53
 - CURSOR CONTROL knob 52
 - EJECT key 53
 - general operation guide 52
 - LCD screen 52
 - LINE key 53
 - MEMORY CARD slot 53
 - PRESET key 53
 - RF IN/OUT connector 53
 - softkey 52
 - function mode
 - display annotation 55
 - fuseholder
 - rear panel 54
 - G**
 - general operation guide
 - display annotation 55
 - front panel 52
 - rear panel 54
 - screen flow chart 56
 - screen reference 52
 - test item
 - allowable range 58
 - test parameter
 - allowable range 58
 - GPRS
 - difference from HSCSD 171
 - introduction 171
 - GPRS mode
 - DC Current 131
 - MANUAL TEST 15, 118, 119, 124
 - testing examples 44
 - measuring screen 124
 - Peak TX Power/Power vs Time 126
 - Phase Error/Frequency Error 129
 - Sensitivity BER 130
 - Sensitivity BLER 130
 - Spectrum Monitor 132
 - stand-by screen 119, 123
 - GSM Mobile Block Diagram 168
 - GSM Version
 - display field 68, 70, 85
 - I**
 - IMEI
 - display field 68, 70, 85, 102, 122, 123
 - IMSI
 - display field 68, 70, 85, 102, 122, 123
 - initial screen
 - AUTOMATIC TEST 61
 - CONFIGURATION 62
 - MANUAL TEST 61
 - screen reference 61
 - SIGNAL GENERATOR 61
 - SPECTRUM MONITOR 61, 136
 - input field
 - 13 MHz Reference 146
 - Attenuation 146
 - Averaging 100, 116, 134, 138, 149
 - BCCH 65, 104, 155
 - Beeper 146
 - BER BS Level 150
 - BER Frames 150
 - BS Level 83, 100, 105, 116, 121, 134, 149
 - Channel 100, 116, 134, 138, 144
 - Date/Time 147
 - DC Power 65, 83, 100, 105, 116, 121, 134, 138, 144, 155
 - Firmware 147
 - Level 144
 - Loopback Delay 150
 - Measured Slot 121
 - Measurement Range 138
 - Midamble 105
 - Modulation 144
 - MS Power Class 149
 - Multi Band 65, 82, 104, 120, 155
 - Network Config 147
 - New Firmware 147
 - Option 146
-

-
- Panel Key 146
 PDTCH 120
 Printer 146
 Procedure 65, 82, 104, 120
 PWR CNTL 82, 100, 104, 116, 120, 134, 149
 Radio Standard 65, 82, 104, 120, 138, 144, 149, 155
 RBW 100, 116, 134, 138
 RF Output 144, 149
 screen field 65, 138, 146, 149, 155
 Sensitivity 121
 Serial Port 146
 Signal 83, 121
 Slot Config 121
 Span 100, 116, 134, 138
 TCH 82, 104
 TCH (Talk) 66, 156
 test limit 151
 Timing ADV 83, 121
 Update 147
 Variable 66, 156
 installing the test set
 electrical requirement 20
 environmental requirement 20
 line power fuse 21
 power cable 18
 preparing for use 17
 shipment check 17
 warm-up time 21
 instruction message
 character 158
 command 158
 creating 158
 screen field 67
 introduction
 GPRS 171
- K**
 Knob MKR/Cursor
 softkey menu 91, 93, 99, 110, 111, 115, 127, 129, 133, 137, 141
- L**
 LCD screen
 front panel 52
 Level
 input field 144
 LINE key
 front panel 53
 line power fuse
 installing the test set 21
 replacement 21
 line setting
 electrical requirement 20
 LOC. Update
 automatic test flow 154
 Loopback Delay
 input field 150
 lost settings
 troubleshooting 25
- M**
 M1 +200 kHz
 display field 101, 117, 135, 139
 M1 -67.7 kHz
 display field 139
 M2 +/-0 kHz
 display field 139
 M2 +250 kHz
 display field 101, 117, 135, 139
 M3 +67.7 kHz
 display field 139
 major functions
 AUTOMATIC TEST 14
 MANUAL TEST 14
 preparing for use 14
 SIGNAL GENERATOR 15
 SPECTRUM MONITOR 15
 manual changes 195
 MANUAL TEST 80
 asynchronous mode 15, 102, 103, 107
 GPRS mode 15, 118, 119, 124
 initial screen 61
 major functions 14
 Synchronous Mode 80
 synchronous mode 15, 80
 MANUAL TEST (Asynchronous Mode)
 DC Current Measuring Screen 130
 Peak TX Power/Burst Timing/Power Ramp Measuring Screen 126
 Marker
 display field 101, 117, 135, 139
 Marker Coars/Fine
 softkey menu 76, 77, 92, 93, 99, 110, 111, 115, 128, 129, 133, 137, 142
 Measured Slot
 input field 121
 Measurement Range
 input field 138
 measuring screen
 asynchronous mode 107
 BCCH 120
 BS Call 86
 DC Current 82, 96, 113, 131
 GPRS mode 124
 MS Call 86
 Peak TX Power/Burst Timing/
-

- Power Ramp 90, 108
- Peak TX Power/Power vs Time 126
- Phase Error/Frequency Error 93, 111, 129
 - screen field 100, 116, 134
 - Sensitivity BER 130
 - Sensitivity BLER 130
 - Sensitivity/RX Quality/RX Level 95
 - Spectrum Monitor 98, 114, 132
 - synchronous mode 86
 - Talk/RF Test 88
- measuring screen example
 - asynchronous mode 108
 - synchronous mode 90
- MEMORY CARD slot
 - front panel 53
- Midamble
 - input field 105
- Mode Sync/Async/GPRS
 - softkey menu 81, 103, 119
- Modulation
 - input field 144
- moving the cursor
 - CURSOR CONTROL knob 52
- MS Call
 - measuring screen 86
 - softkey menu 81
- MS or BS Call
 - automatic test flow 154
- MS or BS Release
 - automatic test flow 154
- MS Power Class
 - input field 149
- Multi Band
 - input field 65, 82, 104, 120, 155
- multiple purpose
 - display annotation 55
- N**
- Network Config
 - input field 147
- New Firmware
 - input field 147
- No
 - softkey menu 163, 165
 - no measurement
 - troubleshooting 25
- O**
- OK
 - softkey menu 165
- operation message
 - display annotation 55
 - screen field 67
- operation status
 - display annotation 55
- Option
 - input field 146
- out of order internal clock
 - troubleshooting 25
- Over/Ins
 - command 159
- P**
- Panel Key
 - input field 146
- Pass
 - softkey menu 69
- pass/fail screen
 - AUTOMATIC TEST 73
 - Burst Timing/Power Ramp 76
 - DC Current 79
 - Peak TX Power 75
 - Phase Error/Frequency Error 77
 - Sensitivity/RX Quality/RX Level 78
- pass/fail screen example
 - AUTOMATIC TEST 75
- pass/fail test
 - Burst Timing 157
 - DC Current 157
 - Frequency Error 157
 - Peak TX Power 157
 - Phase Error 157
 - Power Ramp 157
 - RX Level 157
 - RX Quality 157
 - Sensitivity 157
- PDTCH
 - input field 120
- Peak
 - display field 101, 117, 135, 139
- Peak TX Power
 - pass/fail screen 75
 - pass/fail test 157
 - test item 67, 84, 105, 122
 - test limit 151
- Peak TX Power/Burst Timing/Power Ramp
 - asynchronous mode 108
 - measuring screen 90, 108
- Peak TX Power/Burst Timing/Power Ramp Measuring Screen
 - MANUAL TEST (Asynchronous Mode) 126
- Peak TX Power/Power vs Time
 - GPRS mode 126
 - measuring screen 126
- Phase Error
 - pass/fail test 157
 - test item 67, 84, 105, 122
 - test limit 151
- Phase Error/Frequency Error

-
- asynchronous mode 111
 - GPRS mode 129
 - measuring screen 93, 111, 129
 - pass/fail screen 77
 - Position
 - command 158
 - power cable
 - installing the test set 18
 - Power Class
 - display field 68, 70, 85, 122, 123
 - Power Ramp
 - pass/fail test 157
 - test item 67, 84, 105
 - test limit 151
 - Power vs Time
 - test item 122
 - preparation for each test
 - attenuation values 24
 - display contrast 23
 - preparing for use 22
 - printer connection 24
 - system requirement 22
 - test SIM installation 22
 - UUT connection 23
 - preparing for use
 - installing the test set 17
 - major functions 14
 - preparation for each test 22
 - troubleshooting 25
 - PRESET key
 - front panel 53
 - Print
 - softkey menu 71, 73, 75, 76, 77, 78, 79, 92, 94, 95, 97, 99, 110, 111, 113, 115, 128, 129, 130, 131, 133, 137, 142, 143, 145, 148, 153, 160
 - Print All
 - softkey menu 71, 73, 145, 148, 153, 160
 - Printer
 - input field 146
 - printer connection
 - preparation for each test 24
 - PRINTER port
 - rear panel 54
 - Procedure
 - input field 65, 82, 104, 120
 - PWR CNTL
 - input field 82, 100, 104, 116, 120, 134, 149
 - R**
 - Radio Standard
 - input field 65, 82, 104, 120, 138, 144, 149, 155
 - RBW
 - input field 100, 116, 134, 138
 - rear panel
 - 13 MHz IN/OUT connector 54
 - ac power receptacle 54
 - fuseholder 54
 - general operation guide 54
 - PRINTER port 54
 - SERIAL INTERFACE port 54
 - Recall
 - softkey menu 160
 - recalling a file
 - file management 163
 - recalling the values
 - test parameter 60
 - replacement
 - line power fuse 21
 - Return
 - softkey menu 64, 71, 72, 73, 74, 75, 76, 77, 78, 79, 81, 91, 92, 93, 94, 95, 97, 99, 103, 109, 110, 111, 113, 115, 119, 127, 128, 129, 130, 131, 133, 136, 137, 141, 142, 143, 145, 148, 153, 160, 161
 - RF IN/OUT connector
 - front panel 53
 - RF ON annunciator
 - screen field 67, 85, 106, 122
 - RF Output
 - input field 144, 149
 - RF Test
 - automatic test flow 154
 - RX Level
 - pass/fail test 157
 - test item 67, 84
 - test limit 152
 - RX Quality
 - pass/fail test 157
 - test item 67, 84
 - test limit 152
 - S**
 - Save
 - softkey menu 160
 - Save Execute
 - softkey menu 161, 163
 - saving a file
 - file management 161
 - screen field
 - CONFIGURATION 146
 - display field 68, 70, 85, 122, 123, 124
 - input field 65, 138, 146, 149, 155
 - instruction message 67
 - measuring screen 100, 116, 134
 - operation message 67
 - RF ON annunciator 67, 85, 106,
-

-
- 122
- SPECTRUM MONITOR 138
- stand-by screen 65, 82, 104, 120
- talk measuring screen 70
- test condition screen 149
- test flow step 65
- test item 66
- test sequence screen 155
- screen flow chart
- general operation guide 56
- screen reference
- AUTOMATIC TEST 63
 - CONFIGURATION 145
 - general operation guide 52
 - initial screen 61
 - SIGNAL GENERATOR 143
 - SPECTRUM MONITOR 136
- Screen Simp/Detai
- softkey menu 63, 64, 66, 69, 71, 73
- selecting a field entry
- CURSOR CONTROL knob 52
- selecting an input field
- test parameter 58
- Sensitivity
- input field 121
 - pass/fail test 157
 - test item 67, 84
- Sensitivity BER
- GPRS mode 130
 - measuring screen 130
 - test item 122
- Sensitivity BLER
- GPRS mode 130
 - measuring screen 130
 - test item 122
- Sensitivity/RX Quality/RX Level
- measuring screen 95
- pass/fail screen 78
- SERIAL INTERFACE port
- rear panel 54
- serial numbers 196
- Serial Port
- input field 146
- shipment check
- installing the test set 17
- Signal
- input field 83, 121
- SIGNAL GENERATOR
- initial screen 61
 - major functions 15
 - screen reference 143
 - signal generator screen 143
- signal generator screen
- SIGNAL GENERATOR 143
- simplified screen
- stand-by screen 63
- Slot Config
- input field 121
- softkey
- front panel 52
- softkey label
- display annotation 55
- softkey menu
- Abort 69, 86, 88, 90, 96, 98, 107, 108, 114, 123, 124, 126, 130, 132, 140
 - BS Call 81
 - Cancel 163, 166
 - Delete 160
 - Fail 69
 - File Management 145, 148, 153
 - Format 160
 - Knob MKR/Cursor 91, 93, 99, 110, 111, 115, 127, 129, 133, 137, 141
- Marker Coars/Fine 76, 77, 92, 93, 99, 110, 111, 115, 128, 129, 133, 137, 142
- Mode Sync/Async/GPRS 81, 103, 119
- MS Call 81
- No 163, 165
- OK 165
- Pass 69
- Print 71, 73, 75, 76, 77, 78, 79, 92, 94, 95, 97, 99, 110, 111, 113, 115, 128, 129, 130, 131, 133, 137, 142, 143, 145, 148, 153, 160
- Print All 71, 73, 145, 148, 153, 160
- Recall 160
- Return 64, 71, 72, 73, 74, 75, 76, 77, 78, 79, 81, 91, 92, 93, 94, 95, 97, 99, 103, 109, 110, 111, 113, 115, 119, 127, 128, 129, 130, 131, 133, 136, 137, 141, 142, 143, 145, 148, 153, 160, 161
- Save 160
- Save Execute 161, 163
- Screen Simp/Detai 63, 64, 66, 69, 71, 73
- stand-by screen 64
- Start 64, 69, 70, 71, 73, 74, 91, 93, 95, 97, 98, 103, 109, 111, 113, 115, 119, 127, 129, 131, 133, 136, 141
- talk measuring screen 69
- Test Condition 153
- Test Sequence 148
- Test Setup 145
- Trigger Sing/Cont 90, 91, 93, 95,

-
- 96, 97, 98, 99, 108, 109, 111, 113, 114, 115, 126, 127, 129, 130, 131, 132, 133, 136, 140, 141
 - Yes 163, 165
 - Zoom Off/On 76, 91, 109, 127
 - Span
 - input field 100, 116, 134, 138
 - Specification 173
 - specifying a value
 - test parameter 58
 - SPECTRUM MONITOR**
 - initial screen 61, 136
 - major functions 15
 - screen field 138
 - screen reference 136
 - testing examples 48
 - Spectrum Monitor
 - asynchronous mode 114
 - GPRS mode 132
 - measuring screen 98, 114, 132
 - test item 84, 105, 122
 - stand-by screen
 - asynchronous mode 103
 - attached screen 123
 - AUTOMATIC TEST** 63
 - detailed screen 63
 - GPRS mode 119, 123
 - screen field 65, 82, 104, 120
 - simplified screen 63
 - softkey menu 64
 - synchronous mode 81
 - Start
 - softkey menu 64, 69, 70, 71, 73, 74, 91, 93, 95, 97, 98, 103, 109, 111, 113, 115, 119, 127, 129, 131, 133, 136, 141
 - storing two values
 - test parameter 59
 - Synchronous Mode 80
 - synchronous mode
 - MANUAL TEST** 15, 80
 - testing examples 34
 - measuring screen 86
 - measuring screen example 90
 - stand-by screen 81
 - system requirement
 - preparation for each test 22
 - T**
 - Talk
 - automatic test flow 154
 - talk measuring screen
 - AUTOMATIC TEST** 69
 - screen field 70
 - softkey menu 69
 - Talk/RF Test
 - measuring screen 88
 - TCH**
 - input field 82, 104
 - Variable 66, 156
 - TCH (Talk)**
 - input field 66, 156
 - Test Condition
 - softkey menu 153
 - test condition screen
 - CONFIGURATION** 148
 - screen field 149
 - test flow step
 - screen field 65
 - test item
 - Burst Timing 67, 84, 105
 - DC Current 67, 84, 105, 122
 - Frequency Error 67, 84, 105, 122
 - Peak TX Power 67, 84, 105, 122
 - Phase Error 67, 84, 105, 122
 - Power Ramp 67, 84, 105
 - Power vs Time 122
 - RX Level 67, 84
 - RX Quality 67, 84
 - screen field 66
 - Sensitivity 67, 84
 - Sensitivity BER 122
 - Sensitivity BLER 122
 - Spectrum Monitor 84, 105, 122
 - test limit
 - BER 151
 - BLER 151
 - Burst Timing 151
 - DC Current 152
 - FER 151
 - Frequency Error 151
 - input field 151
 - Peak TX Power 151
 - Phase Error 151
 - Power Ramp 151
 - RX Level 152
 - RX Quality 152
 - test parameter
 - recalling the values 60
 - selecting an input field 58
 - specifying a value 58
 - storing two values 59
 - variable increment softkey 60
 - Test Sequence
 - softkey menu 148
 - test sequence
 - automatic test flow 154
 - test sequence screen
 - CONFIGURATION** 153
 - screen field 155
 - Test Setup
 - softkey menu 145
 - test SIM installation
-

-
- preparation for each test 22
 - testing examples
 - AUTOMATIC TEST 29
 - MANUAL TEST
 - asynchronous mode 40
 - GPRS mode 44
 - synchronous mode 34
 - SPECTRUM MONITOR 48
 - using functions 28
 - Timing ADV
 - input field 83, 121
 - Trigger Sing/Cont
 - softkey menu 90, 91, 93, 95, 96, 97, 98, 99, 108, 109, 111, 113, 114, 115, 126, 127, 129, 130, 131, 132, 133, 136, 140, 141
 - troubleshooting
 - lost settings 25
 - no measurement 25
 - out of order internal clock 25
 - preparing for use 25
 - U**
 - Update
 - input field 147
 - using a user-supplied cable
 - UUT connection 23
 - using function
 - testing examples 28
 - using the antenna coupler
 - UUT connection 23
 - using the RF cable
 - UUT connection 23
 - UUT connection
 - preparation for each test 23
 - using a user-supplied cable 23
 - using the antenna coupler 23
 - using the RF cable 23
 - V**
 - Variable
 - DCP 66, 156
 - input field 66, 156
 - TCH 66, 156
 - variable increment softkey
 - test parameter 60
 - W**
 - warm-up time
 - installing the test set 21
 - Y**
 - Yes
 - softkey menu 163, 165
 - Z**
 - Zoom Off/On
 - softkey menu 76, 91, 109, 127