



isel – CNC-Joystick

User Manual for isel CNC-Joystick

isel[®]

www.isel.com

About this manual:

The information, technical data and dimensions contained in this print have been up-to-date when published. Any eventually existing misprints and mistakes cannot be excluded however. We are thankful for any suggestion for improvement and indication of mistakes.

Please note that the used software- and hardware descriptions of each individual company are generally subject to protection of trademarks and patent law.

All rights reserved. It is not permitted to reproduce or electronically process, duplicate or spread any part of our prints in any way (print, copy etc.) without written permission of **isel-**automation.

Manufacturer: **isel Germany AG**
Bürgermeister-Ebert-Straße 40
D-36124 Eichenzell

Tel.: (06659) 981-0
Fax: (06659) 981-776
Email: automation@isel.com
<http://www.isel.com>

Part.-No.: 970359 BE008

Status: 02/2014 CB

Contents

- 1 Introduction..... 1**
 - 1.1 Preamble..... 1

- 2 Description of the CNC-Joystick 1**
 - 2.1 Specifications 1

- 3 Connections and plug allocation 2**
 - 3.1 Integration in the security circuit (SK-Modul SKM-S1.2-E)..... 2
 - 3.2 Integration in the security circuit of external controller..... 2
 - 3.3 Function keys 3

- 4 Operating..... 4**
 - 4.1 Integration in the graphical user interface (ProNC, Remote)..... 4
 - 4.2 Joystick functions..... 7
 - 4.2.1 Joystick buttons and switches 7
 - 4.2.2 Activating the Joystick 7
 - 4.2.3 Moving the axis 8
 - 4.2.4 Changing Step Widths and Override 9
 - 4.2.5 Special functions 9

1 Introduction

1.1 Preamble

isel® has been known for many years for its driving systems and CNC controls with stepper and servo motors.

The isel-CNC-Joystick is the ideal supplement for controlling isel – machines. He has a robust and ergonomic molded plastic case. Up to four axes can be used with the joystick. He has a middle position and eight movement directions. Furthermore wear free mechanical contact elements are put into action.

The integrated LC-Display shows axis positions, incremental widths and the current Override value. It is no more necessary to observe the graphic surface of the control program when moving to machine axis to new positions.

For the connection of the CNC-Joystick to the control cabinet a special connector can be used. Furthermore all important and security-relevant control elements are integrated as buttons or switches.

2 Description of the CNC-Joystick

2.1 Specifications

- Data transfer via USB - bus without special software drivers
- Maximum 4 axes controlable
- 8 movement directions per plane
- automatic replacement to mid position when unleashed
- wear free mechanical contact elements
- integrated switch for continuous and stepwise movement of the axes
- defined step widths and override adjustable over the joystick
- well readable LC-Display
- Power supply voltage +5V over USB bus
- emergency stop, cover and acknowledge buttons integrated

3 Connections and plug allocation

3.1 Integration in the security circuit (SK-Modul SKM-S1.2-E)

The integration in the security circuit takes place over a connection with the security circle module in the control cabinet. The CNC-Joystick is plugged with a connector at the end of the spiral cable to the connection socket intended for it at the front of the control cabinet. The wires of the connection socket are connected with the security circuit module and the USB – bus of the control PC. You find the cable allocation in the wiring diagrams.

Note:

As soon as the CNC-Joystick is connected, the ACK-button of the joystick can only be used. That means the function key ACK at the Control panel is inactive.

3.2 Integration in the security circuit of external controller



CNC Joystick + Adapter Box for external CNC Controller Part-Nr. 359009

Phoenix contact, 6-pins

Pin	Description	Function
1-2	Emergency-Stop Channel 1 (break contact, Input)	Connection for an external safety circuit (emergency stop switch)
3-4	Emergency-Stop Channel 1 (break contact, Input)	Connection for an external safety circuit (emergency stop switch)
5 -6	ext. POWER ON (make contact, Input)	This contact is switched parallel to the ON button in the controller front. Use this button to switch on the power supply.

Note



The function of the right button on the CNC joystick case is different from the manuals description.

The button is configured as a POWER ON button!!!

Connection Adapter Box – Stepper Motor-Controller C142-4

X3 6-pin - Remote connector		6-polig Phoenix, Adapter Box
3-4 - ext. Emergency stop, 1-channel	----	3-4 - Emergency stop, channel 1
5-6 - ext. POWER ON	----	5-6 - POWER ON

Connection Adapter Box – Servo Motor-Controller CV Serie

10-pin Remote connector		6-polig Phoenix, Adapter Box
3-4 - ext. Emergency stop, 2-channels	----	1-2 - Emergency stop, channel 1
5-6 - ext. Emergency stop, 2-channels	----	3-4 - Emergency stop, channel 2
7-8 - ext. POWER ON	----	5-6 - POWER ON

3.3 Function keys



Emergency stop

Turn off the power supply for power amplifiers, inverter and work spindle.

ACK (acknowledge) button

This button must be pressed so that the axis can be moved in the TEST-mode with opened cover.

Cover-button

This button is used (if present) to open the cover of the machine. The cover can only be opened if the COVER button is illuminated. This is the case, if all axes are in the home position or the operating mode is switched to test mode.

4 Operating


4.1 Integration in the graphical user interface (ProNC, Remote)

The integration of the CNC-Joystick takes place over one 8 bits wide input port. To activate this port, you must bound the Joystick interface- DLL into the Input-/Output modules.

Normally one I/O-module is already used in the control environment. Therefore select, for example, the path to the Dll and initialization file for the IO - module 2.

Interface DLL and initialisation file are normally in the directory:


{appPath}CNCworkbench\Control\IO\UsbJoystick



Proceed as follows to get the CNC-Joystick in the module management:

- Choose an IO modul in the tree view, which is not in use and name it , meaningful with "Usb Joystick."
- Click on the button ">>" beside the edit field "Module DLL". Choose "UsbJoystick.DLL" in the directory "\CNCWorkbench\Control\IO\UsbJoystick". The Edit field "Modul initialisation file" shows automatically the "CNCWorkbench\Control\IO\UsbJoystick\UsbJoystick.ini" file. You needn't to rename the file name.

- Now click on the button, "Setup"(if nothing should happen, please mark shortly another IO module in the tree view and afterwards again the IO-module for IO-USB). Open the Setup-Dialog through click on the button "Setup".




If USB devices were found, they will be shown in the list field with information to serial number, product ID, type. If no USB device were found the list field is empty.

Hint:

Please note, that only those devices are shown which were connected to the USB-bus before starting the software (ProNC/Remote).

Now you must only assign the USB Joystick-Device to the Modul-DLL. Choose the device in the list field. Click on "OK" to save the settings and close the dialog. To check the settings for these Modul-DLL click on "Setup". The Setup-Dialog will be shown again:




The USB device you have selected has an yellow background colour. That means that the Modul-DLL with the device was correctly initialized.

Keep in mind that assignment from more than one module DLL to one USB-Device can result an undefined state.

Setting inside the Control-Administration


To get access to the USB Joystick inside the Control-Administration one setting in the top level must be change. Open the "Extended settings-IO" - Dialog as follows. Highlight in the tree structure "IO modules". Click on "Extended settings" on the right side. You can see following dialog:



The available IO modules will be shown in the upper part of the dialog window.


- Mark the entry "USB Joystick"
- Select the next free logical input port (in this case input port 2) in the list field.
- Click on "Assign selection" to assign the logical input port 2 to the local port of the USB Joystick module.
- Click on "OK" to close the dialog.

Close the dialog "Control modules and settings" over the button "Close & Initialize" to reinitialize the new modules. Now you must assign the logical port number of used input port to the Joystick-Teach dialog.

- Open the Joystick-Teach dialog over the button  in the toolbar "Control panels"
- Click on "Setup" and choose register card "Joystick".
- Activate "A Joystick is available". Fill in the logical port number of the input port you have chosen in the "Extended settings-IO" dialog. In this case the port number of the used logical input port is 2.
- Click on "OK" to overtake the settings.

4.2 Joystick functions

4.2.1 Joystick buttons and switches




Button/Switch	function
Joystick	→ moving 1 - 4 axis, 8 movement directions per plane (2x horizontal, 2x vertical, 4x transverse) per plane
FIRE-Switch	→ Switch to show the current position of the 3. and 4. Axis and move the 3 rd and 4 th axis instead of the 1 st or 2 nd axis.
MODE-Switch	→ Toggle switch between TEACH-MODE and SETUP-MODE
N/S-Switch	→ Toggle switch between stepwise and continuous moving of the axis

4.2.2 Activating the Joystick

To use the Joystick be sure that the Module-DII is correct integrated into the Modul-management. On the LC-Display of the Joystick should be shown the text "isel CNC Joystick".

- To activate the Joystick use the button  toolbar "Control panels". The following dialog will be shown:



After opening the dialog window there will be displayed the current mode and coordinates of the first two axes. With the button “Setup” you can change the default settings for Teach-velocities or step width.

If you have closed the Joystick-Teach-Dialog the message “Joystick –INACTIVE-” will be displayed on the LC-Display.

4.2.3 Moving the axis

Moving the axis is only possible if you are in “TEACH-MODE”. You can see it on the text “TEACH-MODE” in the first line of the LC-Display.

- 1. axis – X → Joystick Right or Left
- 2. axis – Y → Joystick Up or Down
- 3. axis – Z → FIRE- Button + Joystick Up or Down
- 4. axis – A → FIRE- Button + Joystick Right or Left

For the interpolation of two axis (1st and 2nd resp. 3rd and 4th) the Joystick will be moved to the middle positions. During moving of the axis the current axis positions will be shown on the LC-Display. Furthermore the current velocity will be shown. If you want to see the position of the 3rd and 4^t axis press and hold the FIRE-Button.

The switch N/S is used to toggle between stepwise and continuous moving of the axis. If the switch is in Stepwise-mode “-STEP- “ otherwise “-CONT-“ will be shown on the display.

4.2.4 Changing Step Widths and Override

If you want change the step width or the override value you must switch on the SETUP-MODE. To toggle between TEACH-MODE and SETUP-Mode you must use the MODE switch. If you have switched to SETUP-MODE in the first line of the LC-Display is displayed "SETUP-MODE". The following combinations are possible to change step width and override:

Following step width	→	Joystick Right
Previous step width	→	Joystick Left
Increase override value	→	Joystick Up
Decrease override value	→	Joystick Down

4.2.5 Special functions

Overtaking the current axis positions in a user programm

- 1) Set the cursor in the line of the user programm you wish to insert absolute machine positions.
- 2) Press the FIRE button twice, short one after another. The current coordinate values will be overtaken as absolute target coordinates.