


Motorsport Electronics Limited

MEITE User Manual

www.motorsport-electronics.co.uk

26/03/2015



CONTENTS:

[Introduction](#)

[Initial Installation](#)

[Online & Offline Modes Explained](#)

[Getting Connected](#)

[Firmware Updates](#)

[User Interface](#)

[Main Menu](#)

[File -> Load/Save Calibration](#)

[File -> Exit](#)

[About](#)

[Status Bar](#)

[Tabs](#)

[Tree View](#)

[Widgets](#)

[Moving & Resizing Widgets](#)

[Digital Readout](#)

[Two-Dimensional Table](#)

[Three-Dimensional Map](#)

[Configuration Widget](#)

ADDING TO MANUAL SOON:

-Datalogging

INTRODUCTION

The Motorsport Electronics Integrated Tuning Environment, or 'MEITE' for short, is the system used to monitor, tune and modify our range of engine management products. Designed for Windows 7, it is built using the latest technology to give a fluid user experience, allowing as much (or as little) control as you like, whilst still being flexible enough to grow as your knowledge and experience with the system improves.

The latest version can always be downloaded directly at www.motorsport-electronics.co.uk, and updates can also be performed automatically from within the MEITE itself. It also takes charge of updating the connected products inbuilt software (called firmware) to bring more features to the product as and when they are released.

Remember that as well as this manual, online video tutorials are constantly being released on the website - so be sure to check back often!

Please note that for specific products that use the MEITE, such as the ME221 ECU, there exists a separate manual (usually available from that product's support page on our website), detailing how its algorithms, options and functions work - this manual is designed to cover your interaction with the MEITE, not the featureset of the product it is being used to tune.

INITIAL INSTALLATION

After downloading the latest version from the website, double click the setup icon from the location where you downloaded it, and follow the on-screen prompts to install the software. During the install, if an older version is detected, it will automatically be updated to the latest version.

After installation, an icon will be placed on the desktop, as well as under the start menu 'All Programs/Motorsport Electronics/MEITE'.

Double clicking on either of these will open the MEITE.

ONLINE & OFFLINE MODES EXPLAINED

When using the MEITE, there are two made modes, online, and offline.

Online is when you are successfully connected to an Engine Management System, and the data shown is a live representation of what is contained within the ECU's memory. Offline is a mode used to edit basemaps and calibration files 'on the bench', which can at a later time be sent down to the ECU once connected.

The current connection status is shown in the status bar, at the lower right of the screen, a green tick shows you are connected to the ECU - note that the ECU requires power to be connected. If for whatever reason communications to the ECU are lost, then clicking the red disconnection icon will attempt to reconnect to the ECU.

GETTING CONNECTED

This example covers the ME221 Engine Management Platform.

The ME221 communicates over a 9 way serial connection. While some older (and industrial) laptops feature this connection, most modern laptops do not, and so a Serial-to-USB adapter, such as the one pictured below will be needed. The MEITE has been tested with genuine Prolific and FTDI adapter cables. Note that some cheaper chinese copies may not work as effectively, so be sure to either purchase a genuine adapter (around £25) or alternatively order direct from our website.



After connecting the comms lead to the ECU (shown in the ECU User Manual) and then via the adapter to the USB port on your laptop, Windows will look to install the drivers for the USB adapter automatically.

The next step, with the MEITE closed, is to turn on the ignition such that the ECU is powered. If the vehicle is fully wired then the fuel pump should prime (showing that the ECU is alive and well).


Now, you can launch the MEITE in the usual way, (Program Files>Motorsport Electronics>MEITE) and it should automatically locate the correct communications port, and a green tick should be shown in the comms status bar at the lower right of the MEITE, to show that the system is now connected to the controller. After a moment, a progress bar will display as the MEITE downloads the current calibration from the controller. You are now ready to tune the ECU, in 'online' mode.

If the green tick is now shown, then you use the drop down box in the lower right corner to select a different comm port, and then click the red circle to attempt reconnection.

FIRMWARE UPDATES

The MEITE includes the ability to update connected ME products with new firmware versions as they become available.

To access the Firmware Update Tool, ensure you are connected to a system in the usual manner above, then from the main menu Tools -> Firmware update, the following dialog will appear:



The connected devices details are shown on the left boxes, including its product code, type and definition file version, as well as the current firmware version on the device.

After selecting a new firmware file via the browse “...” button, (only *.mefw are supported), the new firmware information is shown in the rightmost boxes.


Newer versions of firmware for your product may be available from our website. Please check often. Automatic checking of new firmware versions will be coming soon to the MEITE.

Simply press ‘Update’ and follow the onscreen prompts. Note that any current calibration is saved to disk automatically.

If you are updating to a newer definition file of your product, the MEITE will automatically extract and store the new definition data from the MEFW file, and add it to its internal library of definition files.

USER INTERFACE

Below is a picture of the standard user interface with default, basic, tabs when working ONLINE with an ME221 Engine Management System.



MAIN MENU

The Main menu for the MIETE is along the top of the screen, and gives access to File Loading/Saving features as well as tools, datalogging and other MEITE features.

FILE -> LOAD/SAVE CALIBRATION

Calibration files can be loaded and saved from the File>Load/Save Calibration menus.

When saving a calibration, choose the filename and directory as per normal windows usage. The files will be stored with the ***.mecal** extension. Note that when a calibration is saved, its definition file version is also recorded, which is detailed further in the loading of calibrations.

Loading a calibration will first attempt to send it to the currently connected device, and if the connected device matches the definition file version of the calibration file, then it will load, and shortly after the MEITE will reconnect to the ECU to create a mirror image of the now updated ECU. If this definition differs, then some areas will be left unedited. For example, if you attempt to load on an older calibration which does not use AFR target table settings, onto a more modern firmware version which does, then those areas of the ECUs memory will be left untouched. When saving the file thereafter, the definition version of the calibration will be updated to that of the connected ECU, and all data will be saved to the file.

FILE -> EXIT

This exits the MIETE. The Comm Port (if connected) will be closed. Note that your current calibration file will not be saved, and, if the ECU has not had a burn command (by a widgets change of focus, or the 'S' button in the widgets' window) then the changes made on the ECU may be lost on the next power-cycle of the ECU. This has been changed on a new versions of MEITE (0.8.5+), such that the ECU is requested to store the changes on MEITE exit.

ABOUT

The About box, as well as presenting contact details for Motorsport Electronics, also displays the ECU Firmware version, definition file version and MEITE version information - critical for technical support issues - and required in any support discussions.

STATUS BAR

The status bar at the bottom of screen shows the connection & ECU status, comm port selection box as well as data logging status.

TABS

A tab is a selectable display mode which groups & shows widgets. Its used for grouping, such as having a 'Startup Tab' showing engine settings, and diagnostic data, or a 'Mapping' Tab that shows just the fuel and ignition table. This method allows grouping of widgets to make tuning and setup very straight forward. In most cases on PnP ECUs with a correctly loaded basemap, only the fuel and ignition mappings may need to be tuned.

The currently displayed, or active Tab is shown by the Tab title being highlighted. Clicking on a different tab will close the current tab (saving any changes you have made to the widgets or the layout) and will then open that tab. You can also add a new tab at anytime with the 'Add Tab' menu item.

Over time, your preferred way of working will form, with tabs set up as to how you like them, focusing on different areas within the ECU. This is the flexibility that the MEITE offers.

TREE VIEW

The tree view on the left of the main window, show all the user accessible variables, readouts, configuration controls and data tables that the current definition file holds, which of course relates to the areas you can view and configure within the ECU.

Any entity on the tree view can be double clicked, and its default widget type will be added to the current tab view. Note that some widget types are specific for a data type, such as a 3D mapping table can not be used to show current coolant temperature.

WIDGETS

Widgets are items that can be placed on the current view. They range from simple digital readouts, to complex 3D mapping tables and histograms.

Any entity on the tree view can be double clicked, and its default widget type will be added to the current tab view. Note that some widget types are specific for a data type, such as a 3D mapping table can not be used to show current coolant temperature...

For all data-entry widgets (such as the table, map and configuration views), a border is presented around the widget when data operations are happening. On changing a value, the border will turn red, to show the data is being sent to the ECU, and then green, to show the ECU has received and has confirmed the data. These changes will be lost however if you power cycle the ECU. To avoid this and to long term store this to the ECU, simply click the small 'S' in the top right, or change focus to another widget.

MOVING & RESIZING WIDGETS

Widgets can be moved by placing the mouse near the upper left corner, and the movement cursor should appear. Clicking and dragging will then allow the widget to be moved around the current tab. Likewise, you can resize the widget by moving the mouse cursor to one of its edges, and when the bar appears, click and drag to resize accordingly. Note that when moving between tabs, widget locations and sizes will be saved to each tabs layout.

DIGITAL READOUT

The most simple widget is the Digital ReadOut, or DRO. A DRO is used to show the value of a particular entity, such as current coolant temperature, or battery voltage. Its text size will re-scale when resizing the control.

To alter the DROs significant digits/decimal places, simple right-click, and select it from the context menu that appears. You can also set alarms here for high/low level warnings. Note that each individual DRO has its own alarms, so you can have two RPM DROs, and different alarm values for each one. Also, an RPM DRO on a different tab will also have its own alarm setpoints - bare this in mind when relying on alarms for notification of problems!

TWO-DIMENSIONAL TABLE

The Two-Dimensional Table (or 2DT) allows you to edit how an output variable relates to an input, for example, shown below, how the coolant correction amount relates to the engines coolant temperature input.



Yellow lines and text on the view show the current 'real' results that are being used in the ECU (when online).

Also, on the left of this widget is a table view where you can edit both inputs (by double clicking them) and the outputs (by pressing backspace on a selected cell).

You can also drag the blue boxes on the line view up and down to change the data in the graphical sense.

The 3D Map view offers the ability to view a map that is used to compute outputs based on two inputs. Typical uses for these type of views include the fuel and ignition maps.

The screenshot displays the MTE G3.5.25731 software interface, which is used for engine tuning and monitoring. The interface is divided into several sections:


- Top Bar:** Includes the software version "MTE G3.5.25731" and a menu bar with "File", "Logging", "Tools", and "Help".
- Left Sidebar:** Contains a tree view of the software's components, including "Open Loop Duty Table", "Target RPM Table", "Diagnostics", "AE Settings", "AE VE Trim", "Environmental", "Knock Control", "Limits", "Lambda Control", and "Startup".
- Main Display Area:**
 - Top Row:** Displays several key parameters in large digital readouts: 0 RPM, 97 MAP(kPa), 15 Coolant temperature(°C), 23 Intake Air Temp(°C), 100 TPS(%), 15.00 Ignition Adv. Angle, and 4 Ignition Dwell(ms).
 - Second Row:** Shows 0 Lost sync count, 7 Battery Voltage(V), 3.65 O2 Val(V), 1 Accelerator Delta(%/sec), 100 Secondary Load(%), 1.03 Fuel IAT Mod, and 1.00 Fuel Lambda Mod.
 - Third Row:** Displays 1.43 AE VE Trim and 198.53 Total VE(%).
 - Table:** A large data table titled "Base VE Table (RPM (1) X Primary Load (9) -> Base VE Output (582))". It has columns for "Pr. Load \ RPM" (500 to 7500) and rows for "Base VE" (20 to 170). The table is color-coded by load range.
 - Bottom Row:** Shows 56 Base VE, 23.52 Injector Pulse Width(ms), 0 Injector duty(%), and 90 Ignition Angle(°).
- Bottom Bar:** Includes a "Logging Stopped" button, a "Reconnect by pressing->" button, and a "COM1" port selection button.

You can move around this grid using the cursor keys, and hit backspace to enter a new number in the popup box for the current cell, or simply press 'Q' or 'W' keys to increase/decrease the current cursor locations cell by the fine amount. This can also be done with multiple cells, selected by clicking and dragging the mouse as per normal Windows operations (akin to Excel).

There is also a tick box named 'Follow' (shortcut, just hit the 'F' key to enable follow mode). With this mode on, the current edit cursor will move around the map as the yellow crosshairs do, moving to the most favoured cell - this is useful when in a steady state control mode such as on an engine dyno or rolling road.

Also, there is a '3D mode' which projects the table as a 3D wireframe, colour scaled image. In this case (shown below) you have a red dot which represents the engine/systems current real position, and a blue dot which represents the cursor. The interaction keys are the same as the 'grid view', with the addition of being able to

press 'Control+Cursor Arrow) to rotate the view in that direction. The follow mode also works in the same fashion in this view.



CONFIGURATION WIDGET

The config. widgets are specific modules to handle bespoke control settings on the ECU, such as engine configuration, boost control settings, idle valve setup, and so on.

To edit a value, either use a drop down box or edit the text directly. Once edited, remember to press the 'enter' key. The border of the Config Driver will turn red briefly (to indicate data has been sent to the ECU) then turn green to signify that the ECU has indeed received the data. Like the other data entry widgets, to permanently store the data to the ECUs memory (so it remains after a power cycle) either press the 'S' in the top right corner, or simply close the widget, or click on any other open widget.

Note that some settings require a power cycle of the ECU after making changes.