



singtrix

A FEW
QUICK TIPS
& **TRIXS** TO GET YOU **SINGING LIKE A ROCKSTAR!**



Singtrix® uses the same powerful vocal effects that the pros use and is designed to sound amazing when properly setup and the music and vocal volume mix set to optimal levels.

With Singtrix fully assembled, connected to your music device, and powered on, you're ready to start!

Setting Your Volume Is The Most Important Step!

Leave your Singtrix Studio at the default volume settings. The Speaker controls your overall mic volume and your music device controls the music mix. Start with the Speaker Volume, Treble and Bass set between 2 and 3 o'clock positions and sing into the mic. With your music device volume at 30%, play your music and slowly raise the music device volume while singing to achieve the ideal balance between the mic and music. Always adjust the music mix level from your music device ONLY and NOT at the Speaker or Studio. If you can't hear your voice well, turn down the music device volume. Raising the music device volume above 70-80% can cause distortion and will make it difficult to hear your singing over the music.

Where Do I Get My Karaoke Music?

Plug in any music device with a headphone output including smart phones, tablets, mp3 players and computers. For FREE karaoke tracks, log into YouTube® using your web browser and search "Karaoke" plus name of any song or artist for thousands of free karaoke videos or lyrics videos. As a secondary option, if you already know the words to your existing mp3 music library, use the "SONG VOICE" feature to lower vocals in standard songs to create karaoke tracks on the fly. Singtrix also works with some third party karaoke apps so the options are endless.

So Many Presets, So Little Time!

Start off with Preset #1, "BIG TRIO" and see how you sound. The MY VOICE button on "ENHANCED" will offer the highest levels of effects & pitch correction for that preset. Presets 1 - 15 are the best for beginners to get started! Need even more pitch-correction? Try using any preset with the word "TUNED" in the name. The Song Effects are more authentic but some can be harder for beginners.

As you start experimenting with other presets and skill levels, spin the effects dial quickly in any direction, you can jump 70-100 effects with 1 spin. Download our Preset Guide for more recommendations.

Vocal Tips: Belt It Out And Let Singtrix Do The Rest!

Singtrix sounds best when you "commit" to a song and try to hit those notes, even falsetto. Project your voice, not matter how off it may sound. Sing! However to avoid distortion and straining, do not scream. Singtrix makes your voice sound rich and full even when singing softly but projecting. Always start your Trixing™ sessions with easy songs in your natural range, to properly warm up. If you don't know your natural range, that's okay, just let it out and Singtrix will help. After singing a few songs, your voice and pitch will naturally improve. To really experience the full sound of our amazing vocal effects in stereo, try using headphones!


Want To Get The Most Out Of Your Singtrix?


Visit our Support Page on www.singtrix.com. Check out the "HOW IT WORKS" video for features and operation tour. The "UNBOXING & SETUP" video provides an informative view of the box contents and detailed set up information. The FAQ section provides answers to the most common customer questions, along with quick tips and troubleshooting.



***PARTY BUNDLE
QUICK-START GUIDE***

INPUT ► SINGTRIX ► OUTPUT







AC Power Adapter

RCA Speaker Input



THE MOST IMPORTANT STEP!

Setting the volume mix between the microphone and music track is the **MOST** important step. This will ensure that Singtrix performs properly & optimally.

Singtrix is a pure audio experience. Improper mix levels will cause distortion, low sounding vocals, weak mic dynamics, and overall poor quality sound & performance.

The goal is to have relatively equal volumes between your microphone voice and music track. **ONLY** use the volume adjustment on your Music Device (PC, smart phone, tablet etc.) to set the relative music volume mix to your mic volume. **DO NOT** use the studio unit's mic volume for this.

NEVER attempt to raise your Music Device's volume to achieve a louder overall performance. This will cause your vocals to be lower relative to the music & distort. To adjust overall performance volume, always use the volume controls on the speaker amplifier. This guide highlights the proper procedure in a few simple steps....



Adjust Music/Mic Mix – Use
Volume on Your Music Device



VS



Overall Performance Volume – Use
Volume on Speaker Amp



STEP 1

- A. After complete assembly as per the user's manual, check that ALL cables are connected and FULLY inserted into the proper inputs and outputs.**

Firmly press on all connections!

NOTE: Sometimes new cables are stiff and feel like they are fully inserted but are not. This is a common oversight made by many users. Improper connections will cause noise, feedback static and other performance issues (including vocal-tuning accuracy or pitch-correction problems).

- B. Power "ON" the Studio Console**



STEP 2

- A. Power “ON” the Speaker
- B. Start with the **VOLUME, BASS** and **TREBLE** knobs to 75% or 3 o’clock. This establishes your overall volume.

NOTE: The speaker needs to be loud for optimal performance and to hear your effected voice over your real ambient voice. You can fine-tune these settings later.



- C. Test by singing through the Singtrix Mic using preset “1) BIG TRIO”. *Do not play your background music yet!*

You should hear your voice loud and clear. Try the “HIT” Button on the mic or Studio Console to hear your vocal harmonies.



You can use headphones or other speaker/PA systems connected to the Studio Console speaker output. When using headphones, use the Studio Console Main Volume to set headphone levels. When using external speakers with amplifiers, like the Singtrix Speaker or PA system, keep the Studio Console Main Volume at default levels and adjust your overall performance volume on the external speaker amplifier. NEVER use your music device volume to increase overall system volume.


STEP 3


- A. With your Music Device (PC, tablet or phone) connected, lower your device's volume to approximately  30% before playing.
- NOTE:** If you play your Music Device at 100% volume, the signal going to the speaker will be too loud, distort and result in an improper vocal mix.
- B. Using YouTube™ on your device's web browser, search "KARAOKE" plus name of any song or artist. There will be thousands of FREE YouTube karaoke tracks.
- C. Play the karaoke track and slowly raise your Music Device  volume while singing to set the desired music/vocal mix. The louder the music, the more each effect (delay, reverb, harmonies etc.) will blend with the background track. Lower music volumes will result in more prominent sounding effects.

Computer



Smart Phone / Tablet



 Always adjust the music mix level from your Music Device ONLY and NOT at the Speaker or Studio. If you can't hear your voice well, turn down the Music Device volume. Raising the Music Device volume above 70-80% can cause distortion and will make it difficult to hear your singing over the music.

You can use your own music library, karaoke apps and other music sources. 95% of customers use YouTube.



YOUR FIRST SINGTRIX SESSION



Always start your “trixing™” sessions with easy songs in your natural range, to properly warm up your voice. After singing a few songs, your voice and pitch will naturally improve.

- Singtrix strengthens the sound of your natural voice. Sing softly using falsetto (your higher voice) to reach higher notes without straining.
- Your singing technique and note accuracy will greatly improve by just “singing” with Singtrix. Singtrix will naturally help make you a better singer!
- For best system performance & accurate pitch correction, ALWAYS use high-fidelity music with a quality audio device and quality audio cables.




Yes, Singtrix has A LOT of effects presets! Get familiar with “core universal fx” 1-15 first. They are most versatile and will work with most songs. You will find favorites” based on the unique tone and range of your voice, and the types of songs you prefer to sing.

- Start by singing your favorite song with preset “**1) BIG TRIO**”
- Press the MY VOICE button and test the “enhanced”, “semipro”, and “pro” skill levels.
- For the most pitch correction possible, try “**14) TUNED TRIO**” or other fx presets named “tuned _____”.

Preset effects are dynamic and will sound & feel differently in the context of different songs. Try “re-mixing” a favorite song using different preset & song combinations (e.g. “TUNED DUO” with a Classic Rock song).

- Enhanced song-styled presets with hard tune™ and big delays or reverbs will be easiest to use.
- Song-styled presets will sound great when used for songs in different genres.
- If using a PC or home theater system, disable all audio enhancements (like surround sound). Use a standard stereo output signal, not a digitally enhanced signal in your device’s audio settings.
- If pitch correction is too dominant for a song, use the MY VOICE button and switch to semi-pro level, or use the preset bank 30-37 named “semipro” (e.g. **SEMIPRO TRIO**).
- Don’t forget to print extra copies of the preset list for parties-download from our Support Page at singtrix.com.



As you improve and become more comfortable singing your favorite songs, challenge yourself by using each preset’s semi-pro and pro skill levels.

- Slightly increasing the mic volume level, allows for softer singing while maintaining good dynamics & tone control - make sure to sing further from the mic.
- One preset such as “**1) BIG TRIO**” can be used for an entire session. As you find cool presets, save them to your 1-10 favorites (hold the MIC VOLUME button down for 5 seconds) and also mark other favorites in the preset effects book.

www.singtrix.com

Go to [singtrix.com](http://www.singtrix.com) for technical support for answers to many common questions, downloads including preset guides, and links to a variety of videos including setup and independent customer video posts and demos.

Singtrix YouTube Channel: <https://www.youtube.com/user/singtrix>

- **User Posts – Friends & Fans Playlist:**
https://www.youtube.com/playlist?list=PL_3dlGnPgUZiud5j7mgbbmzkQYOO6geK4
Check out customer performances and see what songs and presets everyone is using

Singtrix.com Support Page: <http://www.singtrix.com/pages/support>

- **Quick Start Video:** <https://www.youtube.com/watch?v=0unrtD22w38>
- **Unboxing & Assembly Video:** <https://www.youtube.com/watch?v=NSnubfVZLSA>
- **Preset Effects Booklet** – offers a guide to usage and effects characteristics for universal and extreme presets. It will also make it easier to navigate and select from the entire list of 300+ effects. Download and print copies from our site.
- **Quick FAQs** – more detailed features and options on our support page
 - Most users will use 2-5 different presets for all their singtrix sessions. There is no right and wrong preset-song combination. Everyone has different tastes. Select the ones you think sound good with your voice and music you enjoy. Experiment and have fun!
 - Save 10 presets to the favorites bank – press and hold the MIC VOLUME button for 5 seconds
 - Using an instrument or with a live band - If you connect a live instrument to the "music in" input, press the SONG VOICE and MY VOICE buttons at the same time for 5 seconds. It will remove the latency/Audio delay. More details on our Support page.
 - Singtrix can be used with other mics. Recommendations for using wireless and other mic systems on our Support page.









TROUBLESHOOTING CHART

Step	Symptom / Cause	Check / Troubleshooting	Solution
No Audio from both Mic & Music Device			
1	Studio or Speaker not powered on	Check that you have turned on power to both the Studio and Speaker	Power all components
2	Cables plugged incorrectly or not fully inserted	Check all connections	Make proper connections
3	Speaker Cable not functioning	Check Speaker light is on. Plug headphones directly into Studio speaker output. Try Speaker output 1 and 2	If sound is heard on the headphones, replace Speaker Cable
4	Speaker not functioning	Check for lights on the Speaker and Speaker AC Adapter .	If no power, Speaker needs to be replaced or repaired.
5	Speaker AC Adapter not functioning	Check for lights on Speaker AC Adapter	If no power, Speaker the AC Adapter or plug connector needs to be replaced.
6	Studio speaker output not functioning	Plug Music Device directly into the Speaker using the Speaker Cable	If sound is heard, Studio needs to be replaced or repaired.
7	Speaker turns off after a period of time when system is not in use.	Turn Speaker power off for 5 seconds and then back on. An environmentally friendly energy saving feature may be active on your Speaker . Turning power off and on resets the power saving mode on some units.	Reset power
There is Music Device audio but no Mic audio			
1	Incorrect volume mix: Speaker too low and Music Device too loud	Raise Speaker volume to 75% while singing into the Mic	If Mic audio is heard, lower Music Device volume as per the Quick Start Guide .
2	Studio Mic input not functioning	Check for audio by plugging and unplugging Mic into the Studio while Speaker volume at 75%. Check both Mic inputs.	If you DO NOT hear audio from unplugging but no audio when singing into the Mic, Studio needs to be replaced or repaired.
3	Mic not functioning	Check for audio by plugging and unplugging Mic into the Studio while Speaker volume at 75%. You should hear audio from unplugging. Check both Mic inputs.	If you hear amplified unplugging noise but no audio when singing into the Mic , Mic needs to be replaced or repaired.
There is Mic audio but no music audio			
1	Music Device volume on mute or too low	Raise Music Device volume	Raise Music Device volume
2	Music Device speaker output not functioning	Confirm that Music Device speaker output works by plugging in headphones to your device.	Try different Music Device
3	3.5mm Music Audio Cable from Music Device to the Studio music input not functioning	Check for 3.5mm Music Audio Cable by touching one end of the plug while other end plugged into music input while Speaker volume at 75%. Check music input of the Studio by plugging and unplugging 3.5mm Music Audio Cable into the music input while Speaker volume at 75%.	If no amplified sound is heard when touching the end of the music audio plug but hear audio when unplugging cable from the music input, replace 3.5mm Music Audio Cable .
4	Studio music input not functioning	Check music input of the Studio by plugging and unplugging 3.5mm Music Audio Cable into the music input while Speaker volume at 75%.	If no amplified sound is heard when unplugging cable from the music input on the Studio , Studio needs to be repaired or replaced.

Step	Symptom / Cause	Check / Troubleshooting	Solution
Low Mic volume			
1	Your Music Device volume is set too high causing you to have a low Speaker volume	Follow proper mix level steps via quick start guide: -lower Music Device volume to 20% -raise Speaker volume to 75% -sing to check Mic volume is correct -raise Music Device volume until desired mix is achieved	Adjust proper mix levels
2	Using another brand of Mic with lower sensitivity		Raise Mic volume on Studio , or use a Mic preamp with Mic for independent volume control
Speaker distorted / static / hum / buzz			
1	Speaker Cable partially inserted into speaker output on Studio	Check Speaker Cable plug fully inserted into Studio console	Make proper connections
2	Your Music Device volume is set too high overdriving the audio signal	Follow proper mix level steps via quick start guide: -lower Music Device volume to 20% -raise Speaker volume to 75% -sing to check Mic volume is correct -raise Music Device volume until desired mix is achieved	Adjust proper mix levels
3	Speaker damaged during transit	Plug Music Device (tablet or phone) directly into the Speaker using the Speaker Cable	If sound is still distorted or static is heard, Speaker needs to be replaced or repaired.
Only music sounds distorted			
1	Your Music Device volume is set too high overdriving the audio signal	Follow proper mix level steps via quick start guide: -lower Music Device volume to 20% -raise Speaker volume to 75% -sing to check Mic volume is correct -raise Music Device volume until desired mix is achieved	Adjust proper mix levels
Only Mic sounds distorting			
1	Singing too close or loudly into Mic	Move away from the Mic and do not scream into the Mic	Lower Mic volume and/or move away from the Mic when singing. Review our " Tips and Trix " for pointers.
2	Mic volume set too high relative to your singing voice	Check Mic volume	Lower Mic volume and/or move away from the Mic when singing. Review our " Tips and Trix " for pointers.
Studio not tuning correctly			
1	Singing a cappella: There is no background music to set key / defaults to C-Major	Play music source and sing to test tuning	Tuning presets require background music to establish key, play music. See our Support FAQs for tips on how to set a fixed key and singing without music
2	When using presets with more subtle or natural tuning, it will only do 40%-60% of the work and the singer must do the rest	Experiment with presets that are named "TUNED _____" and make sure the My Voice is set to enhanced	Review our "Tips and Trix" for pointers. User must commit and try to hit the notes or melody. Use presets that have more tuning such as presets 1-15
3	Poor signal/ bad 3.5mm Music Audio Cable causing poor audio quality or sonic/subsonic interference	Replace 3.5mm Music Audio Cable and check performance	Replace 3.5mm Music Audio Cable
4	Low quality/resolution music	If using YouTube, check video quality	Set video quality to 360p or above

Step	Symptom / Cause	Check / Troubleshooting	Solution
Vocal effects too strong			
1	Music Device music mix too low	Raising the Music Device volume to Mic mix	Review our FAQs and other support resources. The louder the music, the more effects will blend into the background track.
2	My Voice: on Enhanced (full effects and pitch-correction)	Change My Voice setting to Semipro or Pro	Review our “ Tips and Trix ” for pointers.
3	You're using some of the more enhanced presets	Try presets Named Semipro _____ or Pro _____	Review our “ Tips and Trix ” for pointers.
4	HIT Button is on/active	Blue light indicates HIT Button is activated	Use HIT Button only on the chorus or bridge of a song

Component Reference Table						
Studio (Effects Console)	Studio AC Adapter	3.5mm Music Audio Cable	Speaker (2.1 Stereo Home Theater System)	Speaker AC Adapter	Speaker Cable (w/ Left & Right RCA plugs)	Mic with HIT Button
						
<ul style="list-style-type: none"> ▪ Music Device – refers to your background music source device such as a smart phone, tablet, computer, or other electronic music player with a headphone output that you can plug into the Singtrix Studio music input. ▪ Music Device Volume – refers to the headphone speaker volume adjustment on your smart phone, tablet, computer or other electronic music player. ▪ HIT Button – refers to the control on the Singtrix Studio Console and the Mic which controls and toggles between the (2) different sounds offered by each preset. 						



More Resources

VOXX Tech & Warranty Support

HOURS

9-5 EST (Mon-Fri)

CUSTOMER PORTAL

Create a customer account and log in for real-time support & incident tracking

<http://voxrightnow.custhelp.com/app/home>

Toll Free (800) 645-4994