



User's Manual	
Product	MTAMA5 (V Series Positioner PC Tool)
Model	SFV03

July 2005

TOSHIBA MACHINE CO., LTD.

Introduction

This document describes the operation and installation methods of the PC tool MTAMA5 for V-Series positioners.

Note: The specifications of MTAMA5 may be changed without a prior notice.

Some screen shots of MTAMA5 in this document may be slightly different from the corresponding actual screens depending on your software version.

Table of Contents

	Page
1. Overview	2
1. Main Functions	2
2. Operation Environment	2
3. Installation Method	2
4. Screen Names and Functions	3
2. Operation Method	4
1. MTAMA5 Main Display Screen	4
2. Environment Screen	6
(Monitoring)	
3. Unit Axis Monitor Screen	7
4. Free Monitor Screen	8
5. Real Alarm Screen	9
6. Alarm History Screen	10
7. System Information Screen	11
8. Version Screen	12
(Editing)	
9. NC Program Screen	13
10. High Sequence Screen	14
11. Edit Parameter Screen	15
12. Transfer Screen	16
(Others)	
13. Register Read/Write	18
14. (Waveform) Sampling	20
15. Initialize Screen	27
3. Others:Alarm message	28

1. Overview

This section describes the main functions, operation environment, installation method, and screen composition of MTAMA5.

1-1. Main Functions

MTAMA5 has the following major functions:

- * Monitoring each axis servo amplifier working status
- * Editing and transferring parameters and NC program, sequence programs
- * Reading from and writing to registers
- * Monitoring registers continuously and displaying waveforms in graphical charts
- * Initializing high sequence programs and parameters

1-2. Operation Environment

PC hardware and software requirements are as following:

- * CPU: Pentium 133 MHz or higher (recommended)
- * Memory: 32 MB or more (recommended)
- * Compatible operating system
 - Windows 95 (Note: Not compatible with early version and A version)
 - Windows 98 (including the Second Edition)
 - Windows Me
 - Windows 2000
- * Display monitor
 - Resolution: 1024 x 768, 1028 x 1024 or higher (recommended)

MTAMA5 has the monitor and edit screens independent of each other. A smaller display screen causes screen overlapping making it difficult for a user to view screens.

Note: See "2-2. Environment Screen" for changing serial ports and RS232C baud rates.

1-3. Installation Method

Click the "Setup.exe" file in the "MTAMA5" folder in the CD-ROM.
InstallShield wizard for MTAMA5 will be launched. Install MTAMA5 following the instructions in the displayed screens. Once installation is successfully over, the shortcut icon is prepared at the following position.

[Start] on the task bar -> [Program] -> [VELCONIC] -> MTAMA5 (Click the icon to start MTAMA5.)

1-4. Screen Names and Functions

MTAMA5 has the following screens with the described functions:

Screen No.	Screen name	Functions
000	MTAMA5 Main display screen	The screen has buttons for opening the Monitor and Transfer screens.
030	Environment screen	Communications baud rate and serial port settings may be changed on this screen.
(Monitoring)		
001 to 032	Unit AXIS monitor screen	This screen is used for monitoring working statuses (Unit Mode, Control Mode, Work Coordinate, actual positions, etc.) of the servo amplifier on each axis connected with the positioner.
040 to 047	Free monitor screen	This screen is used to conduct monitoring by combining AXIS monitor items. You may monitor up to ten items on one screen and up to eighty items on eight screens. Example: When the positioner is used on a system with an eight-axis unit, actual positions for axes 1 through 8 can be monitored.
049	Monitor Item Select screen	You may select monitor items for the Free Monitor screen on this screen. Set the unit number [Unit], axis name [Axis], and monitor item [Item] in this order.
060	Real Alarm screen	Up to 32 alarms currently issued with the positioner are displayed on this screen.
061	Alarm History screen	The latest alarm events are listed up to 256 entries.
062	System Information screen	The number of units with the number of axes in each unit of the positioner are displayed on this screen.
063	Version Display screen	Information such as the positioner NC unit's CPU version is displayed.
(Editing)		
100-107	Unit NC Program screen	This screen is used for editing NC programs. You may edit up to eight screens for each unit.
108	High sequence screen	This screen is used for editing high sequence programs.
109	User sequence screen	This screen is used for editing user sequence programs.
110	Edit parameter screen	You may edit NC and Interface parameters on this screen.
130	Transfer screen	This screen is used to send and receive NC programs, high sequence and user sequence programs to or from the positioner.
(Others)		
200-207	Register read/write screen	This screen is used to read from or write to registers. You may monitor or write to sixteen registers at the same time on one screen.
	(Waveform Display)	
220	Sampling Condition screen	Sampling condition may be set on this screen. Measurement data, sampling intervals, and trigger conditions on Channels 1 through 4 may be set.
221	Sampling results screen	Sampling results are displayed in graphic charts on this screen.
222	Graphic Information screen	Line colors and sizes of graphs and background colors on the Sampling result screen may be set on this screen.
223	Sampling Condition Change screen	Sampling items and trigger items for sampling channels may be set on this screen.
230	Initialize screen	The alarm history, NC parameters, Interface parameters, etc. are initialized on the positioner's memory.

Fig. 1-3. Screen List

2. Operation Method

This section describes how to use each screen of MTAMA5.

2-1. MTAMA5 Main Display Screen




Fig. 2-1. MTAMA5 Main Display Screen

The MTAMA5 Main display screen has buttons for opening various functional screens. Functions of each button are described below:

[Working Folder]: A working folder may be changed by entering in this field. Click the [NC Program], [High Sequence] or [User Sequence] button to open an NC program file or sequence program file under the Working Folder.

To select a newly created empty folder, navigate to the newly created folder and enter a file name on the File Select screen.

Example: TEST

[Environment]: Click this button to open the Environment screen. Here, you may set a serial port and a communication baud rate.

[All Disp. Close]: Click this button to close all screens except the MTAMA5 Main display screen.

[Disp.Posi.Clear]: Click this button to initialize all screen positions (to the upper left part of the screen).

This does not change the position of the currently active screen.

[Monitor Stop]: This button switches off or on the monitor that monitors the communications with the positioner.

(Monitoring)

[AXIS Monitor]: Click this button to open the UNIT AXIS monitor screen. This screen is used to monitor operational statuses (the Unit Mode, Control Mode, Work Coordinate, and Actual Position) of the servo amplifier on each axis connected to the positioner.

Use the list box on the left of the button to select an axis to be monitored (using Unit Number and Axis Name).

[Information]: Click this button to open the Information screen. The number of units with the number of axes in each unit of the positioner are displayed on this screen.

[Version]: Click this button to open the Version Display screen. Information such as the positioner NC unit's CPU version is displayed.

[Free Monitor]: Click this button to open the Free monitor screen. This screen is used to conduct monitoring by combining AXIS monitor items in various ways. You may monitor up to ten items on one screen and up to eighty items on eight screens.

Example: When the positioner is used on a system with an eight-axis unit, the actual positions for axes 1 through 8 can be monitored.

[Real Alarm]: Click this button to open the Real Alarm screen. Up to 32 alarms currently issued with the positioner are displayed on this screen.

[Alarm History]: Click this button open the Alarm History screen. The latest alarm events are listed up to 256 entries.

(Editing)

The following are buttons for editing NC program and sequence program files under the Working Folder.

[NC Program]: Click this button to open the Unit NC Program screen. Select a unit number (Units 1 to 8) in the list box on the left.

[High Sequence]: Click this button to open the High sequence screen.

[User Sequence]: Click this button to open the User sequence screen.

[NC Parameter]: Click this button to open the Edit parameter screen.

[I/F Parameter]: Click this button to open the Edit I/F Parameter screen.

[Transfer]: Click this button to open the Transfer screen.

(Others)

[Register]: Click this button to open the Register read/write screen. Up to sixteen registers on one screen and up to 128 registers may be monitored on eight screens at the same time.

[Sampling]: Click this button to open the Sampling Condition screen. Registers may be sampled on this screen.

[Initialize] : Click this button to open the Initialize screen. The positioner memory and the actual positions are cleared and alarms are reset on this screen.

2-2. Environment Screen




Fig. 2-2. Environment Screen

The serial port and RS232C baud rate are specified on this screen. Change the serial port number, baud rate, etc., and click [OK] to make the change effective with MTAMA5. Click the [Cancel] button to cancel changes.

The following are the descriptions of other screens:

[Set Date]: Click this button to set time periods for the positioner based on the PC internal clock.

2-3. Unit Axis Monitor Screen




Fig. 2-3. Unit Axis monitor Screen
 (This example shows the settings of 1 unit, the first axis, and the axis name "Z.")

You may monitor the operational status of the servo amplifier on each axis connected to the positioner on this screen. The unit number, axis number in the unit, and axis name are shown together with the window title. In Fig. 2-3, 1 unit, the first axis, and the axis name "Z" are specified. An axis to monitor may be changed using the list box on the left of the [AXIS Monitor] button on the Main display screen.

2-4. Free Monitor Screen




Fig. 2-4. Free Monitor Screen

This screen is used to conduct monitoring by combining AXIS monitor items on the AXIS Monitor screen (see Fig. 2-3) in various ways.

In the above example, 1 unit and 8 axes are specified. The actual positions for axes 1 through 8 may be monitored on one screen.

(Changing Monitor Items)

Click the [Moni n] button to open the Free Monitor Setup screen (Fig. 2-4-1 below) and set the [Unit] number, [Axis] name, and monitoring [Item] in this order.

2-4-1. Free Monitor Setup Screen (from Free monitor screen)




Fig. 2-4-1 Free Monitor Setup Screen

You may change monitoring items for the Free monitor screen on this screen. When changing the [Unit] number, [AXIS] name, and monitoring [Item], change them in this order.

2-5. Real Alarm Screen




Fig. 2-5. Real Alarm Screen

Currently issued alarms are displayed up to 32 entries on this screen. Alarm numbers and messages are also displayed.

2-6. Alarm History Screen




Fig. 2-6. Alarm History Screen

The latest alarm events are listed up to 256 entries on this screen. Alarm numbers, messages, and issuing time and date are also displayed.

The alarm history may be saved in a text file. Click the [Save] button to open the File Select screen where specify a file name and save the file.

2-7. System Information Screen




Fig. 2-7. System Information Screen

Positioner’s system configuration (the number of units, the number of axes in each unit, etc.) is displayed on this screen.

The above figure shows the state where one unit, two axes, axis names “Z and X” are specified.

The decimal “0.001” in the figure specifies the minimum value for each unit. This value is set with the NC Parameter 5.

Long dashes “00. 13” in the figure show the servo amplifier version of each axis.

2-8. Version Screen




Fig. 2-8. Version Screen

Information such as the positioner NC unit's CPU version is displayed.
Note: The CPU version is not the same as the MTAMA5 version.

2-9. NC Program Screen




Fig. 2-9. NC Program Screen

This screen is used for editing NC programs. You can edit text just like with Notepad.

You can edit multiple units on individual screens at the same time. Unit numbers are set using the list box on the left of the [NC Program] button on the Main display screen. Files listed under the [Working Folder] on the Main display screen may be edited.

(Files to be edited)

Unit 1	:	VPROG1.NC
Unit 2	:	VPROG2.NC
	:	
	:	
Unit 8	:	VPROG8.NC

2-10. High Sequence Screen




Fig. 2-10. High Sequence Screen

This screen is used for editing high sequence or user sequence programs. You can edit text just like with Notepad.

You can edit high sequence and user sequence programs on individual screens at the same time. Files listed under the [Working Folder] on the Main display screen may be edited.

(Files to be edited)

High Sequence:	VHIGH.SEQ
User Sequence:	VUSER.SEQ

2-11. Edit Parameter Screen




Fig. 2-11. Edit Parameter Screen (NC Parameter)

You may edit NC or I/F (Interface) parameters on this screen. You can edit text just like with Notepad. Files listed under the [Working Folder] on the Main display screen may be edited.

(Files to be edited)

NC Parameter: VNC.PAR
 I/F Parameter: VIF.PAR

Some parameters have only one value (e.g., NP001: Unit number), and some require values to be set for each unit (e.g., 04: Axis name). Separate values with a comma when specifying more than one value.

Example: NP003: Axis number in a unit

1. When specifying one unit and eight axes
 NP004 = 8, 0, 0, 0, 0, 0, 0, 0
2. When specifying four units and three axes
 NP004 = 3, 3, 3, 3, 0, 0, 0, 0

2-12. Transfer Screen




Fig. 2-12. Transfer Screen

This screen is used to transfer (send or receive) files. Files under the Transfer folder in the screen are transferred. Each file transfer (send and receive) is logged in a transfer history and the history is displayed the next time MTAMA5 is launched.

The function of each button is described in the following section:

- [Folder]: You may specify a folder to be transferred in this field.
- (Transfer item) Multiple files may be transferred together or individually by changing the list in the list box.
- [Send]: Click this button to send a file displayed under the [Folder] button. NC Program or Sequence Program files in the positioner will be overwritten.
- [Receive]: A file will be received under the Transfer folder in your PC. When there is no file under the folder, a new one will be created.

Type	File name	Compilation after transfer
NC Parameter	VNC.PAR	Yes
I/F (Interface) Parameter	VIF.PAR	Yes
Unit n NC Program n:1 to 8	VPROGn.NC	Yes
High Sequence	VHIGH.SEQ	Yes
User Sequence	VUSER.SEQ	Yes
Sequence Macro	VUSEQ.MAC	No
Backup register data	VBREG.DAT	No
Tiny Basic Program	VBASIC.TBA	No
Axis status monitor setting	VSTAT.MON	No
Register status monitor setting	VREG.MON	No
Cam table n n:2 to 7	VTBLn.CAM	Yes

Fig. 2-12-1. Transfer File List

2-13. Register Read/Write Screen




Fig. 2-13. Register Read/Write Screen

This screen is used to read from or write to registers. When MTAMA5 is launched the first time, generic bit registers are set.

List 1: H000 to H00F

List 2: H010 to H01F

:
:

List 8: H070 to H07F

Read from or write to registers following the steps on the next page:

* Read

1. Selecting [Read]
Select [Read] from the [Type] area. [Read] is selected in Fig. 2-13.
2. Entering a register name
Enter a register name.
3. Starting monitoring
Click the [Monitor] button to start monitoring.
Specifying a wrong register name causes the "Register name error."
Note: Registers may not be changed during monitoring. To change registers, stop monitoring and re-enter the new register name.
4. Stopping monitoring
Click the [Monitor Stop] button to stop monitoring.

* Write

1. Selecting [Write]
Select [Write] from the [Type] area. [Read] is selected in Fig. 2-13.
2. Entering a register name
Enter a register name. Keep the field blank when no write is required.
3. Entering write data
Enter data in the field next to a register name. Specify "1" or "0" in the write data to turn on or off a bit size register.
4. Writing to a register
Click the [Write] button to write to the register. Successful writing displays the message "Writing complete."
Specifying a wrong register name causes the "Register name error."
5. Clearing write data
Click the [Clear] button to clear the text entered.

2-14. Sampling(Condition setting and Sampling result display)

Registers may be sampled on this screen. There are two screens: one for setting sampling conditions and the other for displaying sampling graphics.

2-14-1. Sampling Condition Screen




Fig. 2-14-1 (Waveform) Sampling Condition Setup Screen

Sampling conditions for waveform analysis are set on this screen. Channels for measurement 1 to 4, sampling intervals, and trigger conditions may be specified on this screen.

Set sampling conditions for each measurement item.

* [Channel n] and [(Trigger)Data]

The sampling item setup screen will open where you may specify a register to be measured. When MTAMA5 is launched the first time, all Channels 1 through 4 are set to "None."
See "2-14-3. Sampling Graphics Screen."

* [Interval]

You may specify a sampling interval in this field. Only values in multiple of the positioner unit distribution cycle (NC Parameter 6) may be specified.

Example: When the unit distribution cycle is "3.2 ms"

Values such as 3.2, 6.4, ... 32.0, and so on may be specified.

* [Mode]

You may specify a trigger mode in this field.

None: No trigger condition is set. Sampling will start right after the [Start] button is clicked.

Delay: Specify duration after the trigger 0 condition event to start displaying waveforms.

Set the value to "0" when you want to start displaying waveforms right after a trigger condition event.

Sequence 1:

Waveforms right after a trigger-0 condition even following a trigger-1 condition event will be sampled.

Sequence 2:

Waveforms after a trigger-0 condition event are continuously sampled until a trigger-1 condition even takes place.

Note: When "Sequence 2" is specified, [Buffering] may be set to "after" only.

* [Buffer Size]

You may change buffer sizes for sampling in this field. You may select either "1/4," "1/2," "1," "2," or "4."

The following table shows the relationship between buffer sizes and the number of sampling channels:

Buffer Size	Number of Channels 1 channel	2 channels	3 or 4 channles
1/4	512 points	256	128
1/2	1024	512	256
1	2048	1024	512
2	4096	2048	1024
4	8192	4096	2048

Fig. 2-14-1-1. Number Of Sampling Items

* [Delay Time]

This field becomes active when the Trigger [Mode] is set to "Delay." Waveform measurement will start after elapse of time specified for [Delay Time] from the occurrence of a trigger-0 condition event.

You may specify delay time in multiple of the sampling interval time.

Example: When the sampling interval is set to "6.4 ms":

Enter "3" for the [Delay Time] field and press Enter key.

Time "19.2 ms" will be displayed to the right of the list box.

When you entered a value you liked, press Enter key to make the value effective.

* [Buffering]

The specification may be changed when [Trigger Mode] is selected. Select from the following values: "Before," "about," or "after."

(Trigger Data)

* [Type]

The following values are available for selection:

- ON EDGE: Measurement starts with the point where the bit register is turned ON as the trigger point.
- OFF EDGE: Measurement starts with the point where the bit register is turned OFF as the trigger point.
- +SLOPE: Measurement starts with the point where trigger data exceeds the trigger level as the trigger point.
- SLOPE: Measurement starts with the point where trigger data goes down below the trigger level as the trigger point.
- DATA: Measurement starts with the point where the trigger data equals to the trigger level as the trigger point.
- SLOPE: Measurement starts with the point where trigger data crosses the trigger level as the trigger point.

* [Data] (Register)

A trigger value is set. Click the [Data] button to open the Sampling condition screen.

Note: Floating point register (HF**) may not be selected for Trigger Data.

* [Level [%]]

You may set a trigger level using the list box. The actual trigger level is shown below the list box. A trigger level will vary depending on the register size.

2-14-2. Sampling result Screen




Fig. 2-14-2. Sampling Condition Screen

Sampling results are displayed in graphic charts on this screen. The function of each button is described in the following section:

* Checkbox for Channels 1 to 4
 Select or deselect the checkbox to switch between displaying and hiding a certain channel.

* Time Scale (Horizontal Axis of the graph) (Unit: a division of the grid)
 Change the value on the time axis below the graph. ("3.2 is selected in the above figure.)

Example: When the sampling interval is set to "0.8 ms":
 Set "0.8" on the time axis to display the data for 11 points.
 Set "8.0" on the time axis to display the data for 101 points.

Note: A value smaller than the value for sampling interval may not be specified on the time axis.

* Vertical Scale of the graph (Unit: a division of the grid)
 Change the value in the list box on the right of the graph. ("1.0" is selected in the above figure.)
 Different scales may be set for each channel.

* Graph's [Position Center]
 Change the value in the list box on the right of the graph. ("0.0" is selected in the above figure.)
 Different scales may be set for each channel.

* Checkboxes [Cursor 1] and [Cursor 2]

Select or deselect the checkbox to switch between displaying and hiding a cursor.

* [Setup]

The Graphic Information screen will open where you may specify line colors, sizes, background colors, and other properties of screen elements.

See "2-14-4. Graphic Information Screen."

2-14-3. (Waveform) Sampling Graphics Screen




Fig. 2-14-3. Sampling Graphics Screen

This screen is used to set sampling channels (CH1 to CH4) and trigger data (TRG0 and TRG1) for waveform sampling.

Measurement items and trigger data are displayed at the bottom of the screen.

Click the [Register] button to enter a register name. Register "HB00" is set in the above figure.

When MTAMA5 is launched the first time, all Channels (1 through 4) are set to "None."

2-14-4. (Waveform) Graphics Information Screen




Fig. 2-5-3 Sampling Graphics Setup Screen

Line colors and sizes of graphs and background colors on the Sampling result screen may be changed on this screen.

Note: The line types may be changed only when the line size is set to "1."

2-15. Initialize Screen




Fig. 2-15. Initialize Screen

This screen is used to clear the positioner memory (alarm history, parameters, etc.) and actual positions or reset alarms.

Note: Proper care is needed when clearing parameters, registers including the backup register, and High sequences.

Methods to clear memory and actual positions and reset alarms are described in the following section.

(Clearing Memory)

- [Flash Rom]: Click this button to clear flash ROM.
- [Alarm History]: Click this button to clear the alarm history.
- [NC Parameter]: Click this button to initialize the NC Parameter.
- [I/F Parameter]: Click this button to initialize the I/F Parameter.
- [Register]: Click this button to initialize register values.
The backup register will be also initialized.
- [High Sequence]: Click this button to initialize high sequence.

[Actual Position Clear]

: These fields are used to clear the actual position of each axis. Individual units, all axes, or single axis may be selected using the radio buttons.

To clear a value for each axis or each unit, select the item using the list boxes.

- [Alarm Reset]: Click this button to send an alarm reset signal to the positioner.

3. Additional Information: Alarm Messages

The following are descriptions on alarm detecting conditions, solutions, and terminology.

Type / Alarm No.	Alarm messages	Detecting conditions / solutions
Communication error		* Solution * See the solution for communications alarm .
1	RS232C initialize error	* Detective Condition The servo amplifier is not ready for communications.
2	RS232C cable error	* Detective Condition The communications cable may be broken or the positioner is not powered.
3	RS232C time out	* Detective Condition A reply message is not received from the positioner within a specified time after dispatching a command.
Data dispatch error		* Solution * See the solution for communications alarm .
4	RS232C dispatched data communication error	* Detective Condition Errors are found with the dispatch command (a framing error, etc.).
5	RS232C dispatched data Checksum error	* Detective Condition Errors are found with the checksum of dispatch command.
7	RS232C dispatched data Command number error	* Detective Condition Errors are found with the dispatch command.
8	RS232C dispatched data Excessive bytes error	* Detective Condition The dispatched command is longer than 256 bytes.
9	Dispatched	* Detective Condition The positioner failed in reading the dispatched command.
10	Dispatched data RS omunication write error	* Detective Condition The positioner failed in writing reply data.
11	Dispatched data RS communication time-over error	* Detective Condition Errors are found with the dispatch command.
12	Data dispatch error	* Detective Condition Errors are found with the dispatch command. The errors may be caused by communication noises.
13	Positioner Setup Mode error	* Detective Condition Files were sent in a mode different from the Edit Mode. * Solution Switch the positioner operation mode to the "Edit Mode."
Flash Rom Error		* Solution Open a file (NC Parameter, NC Program, etc.) in the positioner using the Teaching Unit. If you can open the file, the errors are likely caused by communication noises. If you could not open a file, consult the support desk of our company.
14	Positioner file open error	* Detective Condition The positioner failed to open a file. The error may be caused by a trouble with the flash ROM.
15	Positioner file read error	* Detective Condition The positioner failed to read a file. The error may be caused by a trouble with the flash ROM.
16	Positioner file write error	* Detective Condition The positioner failed to write a file. The error may be caused by a trouble with the flash ROM.
17	Positioner memory error	* Detective Condition The positioner failed to acquire memory space.
18	Register list undefined error	* Detective Condition Register read or write was attempted when a register list was not sent to the positioner. * Solution Check the register name and try to read from or write to

		the register. Close the Register Read/Write screen and open it again.
19	Register name error	* Detective Condition The register name is not valid. * Solution Make sure that a correct register name is entered.
20	Duplicate file read/write request error	* Detective Condition File transfer was attempted in wrong steps. * Solution Restart MTAMA5 and try the same steps again.
21	No file read/write request	* Detective Condition File transfer was attempted in wrong steps. * Solution Restart MTAMA5 and try the same steps again.
22	Wrong axis number setting	* Detective Condition Communications were attempted using the positioner to a servo amplifier on a non-existing axis. * Solution Make sure that a correct axis number is specified.
23	Invalid file number	* Detective Condition A wrong file number was specified when transferring a file. * Solution Restart MTAMA5 and try the same steps again.
24	Duplicate memory clear error	* Detective Condition The memory clear command was reiterated. * Solution Restart MTAMA5 and try the same steps again.
25	Message communication error	* Detective Condition Communications through the positioner to servo amplifiers on individual axes failed. • Solution Restart MTAMA5 and try the same steps again.
26	Security password not entered	* Detective Condition File transfer was attempted when the Security Password was set to NC Parameter 10. * Solution Clear the security password.
Received data error		* Solution * See the solution for communications alarm.
36	Reply data status error	* Detective Condition A reply data error was found. The errors may be caused by communication noises.
38	Reply data checksum error	* Detective Condition A reply data checksum error was found. The errors may be caused by communication noises.
39	Reply data framing error	* Detective Condition A reply data error (framing error) was found. The errors may be caused by communication noises.
40	Reply data parity error	* Detective Condition A reply data error (parity error) was found. The errors may be caused by communication noises.
41	Reply data overrun error	* Detective Condition A reply data error (overrun) was found. The errors may be caused by communication noises.
50	File open error	* Detective Condition No files exist under the Working Folder. * Solution Make sure that more than one file exists in the folder. When no file exists, receive files from the positioner to place files in the folder.
51	Insufficient memory	* Detective Condition Memory was insufficient for receiving a file or opening a new screen.

54	Compilation error	* Detective Condition An compilation error was issued after a file was sent. * Solution Check the error log and modify the relevant file accordingly.
55	Trigger register error	* Detective Condition A floating decimal register (HF nnn) was assigned to trigger data. * Solution Assign a different type of register.

Fig. 3. Alarm List

