

**KEDACOM**

# **User Manual for HD IP Camera of IPC Series**

---

Version 02

## **Trademark**

Kedacom™ and **KEDACOM**™ are trademarks of Suzhou Keda Technology Co., Ltd. in China and various other countries. All other trademarks mentioned in this document are the property of their respective holders.

## **Suzhou Keda Technology Co., Ltd.**

131 Jinshan Road

New District, Suzhou, 215011

People's Republic of China

<http://www.kedacom.com/en>

Tel: +86-512-68418188

Fax: +86-512-68412699

**© 2015 Suzhou Keda Technology Co., Ltd. All rights reserved.**

Without the prior written permission of Suzhou Keda Technology Co., Ltd., any reproduction, translation or retransmission of all or any part of this document for any purpose in either electronic or mechanical form is not allowed.

## **Notice**

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a

warranty of any kind, express or implied. Suzhou Keda Technology Co., Ltd. is not responsible for printing or clerical errors.

### Target Audience

Administrators and Operators of Video Surveillance Products

### Document Version

Version 02

### Applicable Models

IPC113 series, IPC123 series

IPC2151 series, IPC2251 series

IPC2152 series, IPC2252 series


IPC2110 series, IPC2210 series

IPC2111 series, IPC2211 series, IPC2411 series

### Related Document

*Quick Start Guide*

### Convention

Icon	Convention
	Notes
<i>italic</i>	Book or document name; Filling content
>	Connector between menus of different level
<b>BOLD</b>	Menu; Button; Option

# Contents

© 2015 Suzhou Keda Technology Co., Ltd. All rights reserved.....	2
<b>Notice.....</b>	<b>2</b>
<b>Target Audience.....</b>	<b>3</b>
<b>1. Product Brief.....</b>	<b>1</b>
<b>2. Appearance.....</b>	<b>2</b>
<b>3. Start Up.....</b>	<b>3</b>
3.1 Client Installation Conditions.....	3
3.2 Initial Configuration.....	3
3.2.1 Modify Parameter.....	3
3.2.2 Login Web Client.....	5
3.2.3 Focus.....	6
<b>4. Product Functions.....</b>	<b>8</b>
4.1 Live View.....	8
4.1.1 Toolbar Buttons.....	8
4.1.2 Image Adjustment.....	10
4.1.3 Auxiliary Function.....	12
4.2 Motion Detection.....	12
4.2.1 Set Area.....	13
4.2.2 Clear Area.....	13
4.2.3 Disable Function.....	13
4.3 Tempering Alarm.....	13
4.4 Alarm Linkage.....	14
4.4.1 Motion Detection Alarm Linkage.....	15
4.4.2 Tempering Alarm Linkage.....	15
4.4.3 Alarm Input Linkage.....	15

4.4.4	Abnormality Linkage .....	16
4.5	Privacy Mask.....	16
4.5.1	Set Area.....	17
4.5.2	Clear Area.....	17
4.5.3	Disable Function .....	17
4.6	Encoding Clipping .....	17
4.6.1	Set Area.....	18
4.6.2	Clear Area.....	18
4.7	ROI.....	18
4.7.1	Set Area.....	19
4.7.2	Clear Area.....	19
4.8	SDI Output .....	19
4.9	Snapshot.....	20
4.10	Playback .....	20
4.10.1	Playback .....	21
4.10.2	Download.....	21
4.11	Upgrade .....	21
4.11.1	Firmware Upgrade.....	21
4.11.2	Web Client Upgrade .....	23
<b>5.</b>	<b>Settings .....</b>	<b>24</b>
5.1	Network Access .....	24
5.1.1	Ethernet .....	24
5.1.2	PPPoE .....	24
5.2	Register to VMS.....	25
5.3	BNC Output.....	25
5.4	User Security.....	26

5.4.1	User Management .....	26
5.4.2	IP Filter .....	26
5.5	Text Overlay.....	27
5.6	Multi-stream .....	28
<b>6.</b>	<b>Appendix: Glossary of Terms.....</b>	<b>31</b>

## 1. Product Brief

HD IP Camera (hereinafter referred to as Camera) is a remote video surveillance device based on IP network technology. It encodes and transmits HD video.

Some features of the HD IP camera:

### **Live View**

Apply high-performance progressive scan sensor, with clear image and vivid color;

High-performance video processing chip and efficient video encoding, providing HD video image;

Dual-stream to fit different network bandwidth;

Configurable text overlay on video image;

### **Alarm**

With audio and alarm connectors, realize functions of talkback and alarm;

Motion detection and alarm linkage, make video surveillance intelligent;

Support alarm linkage edit: Alarm Text Overlay, Device Output, Live View Display and etc.

### **Networking**

Static address, DHCP or PPPoE;

NAT traversal, DNS and multicast technology

### **Storage**

With SD card slot, when the network breaks down, video can be stored in local SD card;

Support local snapshot, default format is .JPG;

Support local recording, user can query and playback recording on PC.

## 2. Appearance



Picture 2-1 IPC113 and IPC123 series



Picture 2-2 IPC2151 and IPC2251 series



Picture 2-3 IPC2152 and IPC2252 series



Picture 2-4 IPC2110 and IPC2210 series



Picture 2-5 IPC2111/ IPC2211/ IPC2411 series



## 3. Start Up

Please refer to the Quick Start Guide in the packing for device installation and wiring.

### 3.1 Client Installation Conditions

Requirements of PC for installing the client:

- ✚ Operating System: Windows XP or newer versions
- ✚ Browser: IE7.0 and above versions, Firefox, Google Chrome (41 and below)
- ✚ Processor: 3.3 GHz CORE®i3 series or other equivalent processors
- ✚ RAM Memory: 4GB or above
- ✚ DirectX: 9.0c

We will take IE7.0 as an example.

### 3.2 Initial Configuration

After installation and wiring, power on.

#### 3.2.1 Modify Parameter


- 1) Get IPCSearch from the attached CD.

No.	IP	Alias	Device Type	Mask	Gateway	MAC	Version	Serial nu...	Runtime
1	10.255.252.71	Camera	Camera	255.255.252.0	0.0.0.0	00-14-10-0E-EC...	7.1.3.239	1519006...	6 hr. 2 min. 57 sec.

Picture 3-1 IPCSearch


**i** Note: IPCSearch is green software free from installation. Camera name is subject to the search result.

- 2) Run IPCSearch: it will search devices in LAN automatically and display the list as shown in Picture 3-1.
- 3) Select the device and click “Batch processing”. In the popup interface, set admin user’s password and the email address to find back the password. Click “Active” and wait for rebooting.



Picture 3-2 Batch processing


- 4) Select a camera to be configured, click “**Modify Params**” or right click the mouse. Interface is shown in Picture 3-3. During the modification, the user name (admin) and the password set before activation should be entered.




Picture3-3 Modify Parameter


### 3.2.2 Login Web Client

- 1) After modification, camera will reboot automatically. Please wait patiently. After reboot, the button will be enabled again. Please select this device again and click “Login” or double click device name to enter web client. Interface is shown in Picture 3-4.

A screenshot of a web client login interface. It features two input fields: "User Name" and "Password". The "User Name" field has a small user icon on the right, and the "Password" field has a lock icon. Below these fields is a blue "Login" button.


Picture 3-4 Web Client Login Interface

 Note: If log in the non-activated device through web client for the first time, user can set admin password and activate the device in the login interface, as shown below. Complicated password is recommended, e.g. combination of letters and digits above 8 bits.

A screenshot of the first login interface. It includes a "User Name" field with "admin" entered, a "Password" field, a "Confirm Password" field, and a "Claim Email" field. Below the "Claim Email" field is a blue "Active" button. A note below the "Claim Email" field reads: "When admin's password gets lost, find it back through this email. Make sure this email address is safe and valid."

Picture 3-5 First login through web client

- 2) Enter user name and password: when log in successfully for the first time, download and install the plug-in. Close browser when installing and re-login afterwards. Interface after login is shown in Picture 3-6.







Picture 3-6 Web Client Interface

### 3.2.3 Focus

It is the process of imaging the target object clearly. Please focus according to the lens type of camera:

**Mechanical Focus:** View live video on web client and adjust the focus knob on the lens till the image is clear enough.

**Electrical Focus:** Click  in function buttons area of the web client, as the picture shows. Or click  or  for near or far focus. View live video on web client and adjust focus till the image is clear.



Picture 3-7 Focus

## 4. Product Functions

By the web client, user can not only view live video, but also perform local snapshot and recording.

**Note:** Functions of different cameras may differ, and this Manual will take camera with more functions as example. User operation is subject to the actual functions of the model. Disabled button in Web Client means the model doesn't support the function.

### 4.1 Live View

The default interface after user login is live video view, or user can click Live View to enter the interface.

#### 4.1.1 Toolbar Buttons



Picture4-1 Toolbar Buttons

**Play/Pause** 

Click this button to play or pause a viewing.

**Stop** 



Click this button to stop live view.

**Call** 

Click this button to call camera, and click again to stop calling. Not all cameras support this function.


**Snapshot** 

Click this button to snapshot an image.

Snapshot includes Camera Snapshot  and Local Snapshot . User can set in **Settings>Local**.

## Recording

Click this button to start recording and click again to stop recording. Recording is saved on local PC. User can set or modify save path in **Settings>Local**.

 Note: 1) Camera Snapshot: Camera snapshots an image and sends it to local client in .JPG format. The image quality is good, but there is some time delay caused by network.  
2) Local Snapshot: Client snapshots an image and save it locally. The image quality is ordinary, but there isn't any time delay.

Local Setting

---

**Play**

Protocol  TCP  UDP

Performance  Real-time  Balanced  Smooth

Enable Image Noise Reduction

Noise Reduction Level

Enable Vertical Synchronization  (Enabling this function will increase the CPU Utilization.)

Display Status Info

---

**Recording**

Packet size  256M  512M  1G

Local Recording Save Path	C:\IPCWeb\Rec	<a href="#">View</a>
Clipping Save Path	C:\IPCWeb\Video\PlayBackCut	<a href="#">View</a>
Download Save Path	C:\IPCWeb\RecPlayback	<a href="#">View</a>

---

**Snapshot**

Local Snapshot Save Path	C:\IPCWeb\Pic\Preview	<a href="#">View</a>
Camera Snapshot Save Path	C:\IPCWeb\Pic\PuGrab	<a href="#">View</a>
Snapshot Save Path	C:\IPCWeb\Pic\PlayBack	<a href="#">View</a>

---

**Download Plug-in**

Download Plug-in [Download Plug-in](#)

[Save](#)

Picture 4-2 Snapshot Setting

## EPTZ

Click this button to enable the e-PTZ function. Left click and drag toward lower right to draw an area. The pixels of this area will be amplified and will cover the whole

screen. Left click and drag toward upper left to draw an area, then image will recover.

**PTZ** 

Click the button to zoom. Left click and drag toward lower right to draw an area. The pixels of this area will be amplified and will cover the whole screen. Left click and drag toward upper left to draw an area, then the image will recover. Double click a point in the image and the point will be centered.

**Full Screen** 

Click this button to display full screen. Double click or press Esc to exit.



## 4.1.2 Image Adjustment

### 4.1.2.1 Brightness

Due to low light situation, the image will look completely or partially dark and hard to recognize. Web client provides the following functions to increase image brightness and ensure surveillance quality.

#### \*Enable IR Lamp

In low light situation, IR lamp can be started to get better surveillance images.

Click  to enable IR lamp. Click  to disable it.

#### Increase Image Brightness

Go to **Settings>Camera>Image>Image Adjustment**, drag **Brightness** slide bar to adjust image brightness.

#### Slower Shutter Speed

Camera shutter speed means the cycle of the sensor calculating light input amount. Therefore, the slower the speed is, the brighter the image will be.

 **Note:** If the target object is moving fast, this method is not applicable.

Go to **Settings>Camera>Image>Exposure**, user can set shutter mode as auto or manual, and set **Shutter Lower Limit**.

#### Increase Gain

Camera gain means the light sensitivity of a sensor. A high gain may reduce light exposure for low light situation.





Note: However, the higher the gain is, the worse the image will be. User is advised to select Auto for default values, or select Auto and set Gain Upper Limit in **Settings>Camera>Image**. If user selects “Manual”, drag the slide bar to adjust gain level.

#### \*Enable WDR

WDR can provide optimal exposure in intense backlight conditions.

Go to **Settings>Camera>Image>Image Enhancement**, enable WDR in the drop-down list of **Dynamic Adjustment** and drag the **WDR Sensitivity** slide bar to adjust.

#### 4.1.2.2 White Balance Adjustment

The basic conception of White Balance is “to make all colors white regardless of the color temperature of the light source”. It can compensate color rendition in pictures taken in specific light source.

Go to **Settings>Camera>Image>White Balance**, select white balance mode from the drop-down list.

If select “**Manual**”, drag the slide bar of White Balance R Gain (Red Gain) and White Balance B Gain (Blue Gain) to adjust image color.

#### 4.1.2.3 Night Cut

Day (Night) Mode means disabling (enabling) IR lamp (only some models support), and the image switches to color (B/W), thus to get optimal images for day (sufficient light source) and night (insufficient light source) conditions.

Go to **Settings>Camera>Image>Night Cut**, select Night Cut mode.

##### Day

Select Day mode, disable IR lamp (only some models support), and the image is colored.

##### Night

Select Night mode, enable IR lamp (only some models support), and the image is black and white.

##### Auto (Gain Triggered)

Select Auto mode and configure sensitivity and switch time, then the system will switch Day/Night modes automatically.

##### Scheduled Day/Night

In this mode, camera switches to day/night mode automatically in a specified period of time.

When select Scheduled Day/Night mode, click Edit Time, and check Start Time and End Time in the popup interface.

#### **Alarm Triggered Cut**

In this mode, night cut is triggered by alarm input.

#### **4.1.2.4 Noise Reduction**



When there are many noise points caused by environment and camera lens, Noise Reduction function can be enabled to adjust images.


Go to **Settings>Camera>Image>Image Enhancement**, enable 3D Noise Reduction. When user selects "Disable", the function will be disabled. When select "Enable", user can drag the slide bar to adjust 3D noise reduction level.

#### **4.1.3 Auxiliary Function**

##### **\*Wiper**


Wiper is used to clean the dome housing. In the PTZ control part of the Live View

interface, Click  to start the wiper. Click  again to stop the wiper. The

wiper will stop automatically after 10 brushes. Click  to enable wiper again if necessary.

## **4.2 Motion Detection**

Detect movements in the defined area. Once the movement exceeds the defined sensitivity, an alarm will be triggered by Web Client.



Picture 4-3 Motion Detection

#### 4.2.1 Set Area

Motion detection supports full area detection and maximum 4 user-defined areas.

- 1) Go to **Settings>Event>Video Analysis>Motion Detection**, check “Enable”.
- 2) Click “Edit” and the image will be divided into 16 columns and 12 rows of squares. Click a square and drag an area from it, then the area will turn purple and is the motion detection area. A camera can support maximum 4 areas.
- 3) Drag the slide bar to adjust Sensitivity.
- 4) Click “Edit”. On the popup page, check durations and set start time and end time.
- 5) Click “Copy” to copy the defined motion detection time to a certain day or the whole week.
- 6) Select “Linkage Type”. It is the alarm output method when an alarm is detected in the defined area.

#### 4.2.2 Clear Area


Start from an undefined square and draw an area that contains the defined area, or click the defined squares one by one to clear setting, or click “Clear” to clear setting. Save to make settings effective.

#### 4.2.3 Disable Function

To disable this function, uncheck the checkbox  Enable.

### 4.3 Tempering Alarm

Go to **Settings>Event>Video Analysis>Tempering Alarm**. Please refer to **4.2 Motion Detection**.



Picture 4-4 Shield Area Alarm

## 4.4 Alarm Linkage

Alarm Linkage is the system reaction after an alarm signal is received. It is to raise watch man's attention to handle the event.

The alarm signal comes from Motion Detection (details in Chapter 4.2) or Alarm Input Device (such as smoke detector) in the surveillance area.

Alarm Linkage reaction includes Alarm Text Overlay, Snapshot or triggering alarm output device (such as alarm bell). Explanations are as follows:

**Report to Management System:** when alarm is triggered, report to the central surveillance system.

**Text Overlay:** when alarm is triggered, display alarm text on screen.

**Acoustic Alarm:** when alarm is triggered, make a warning sound.

**Recording Linkage:** when alarm is triggered, start to record video automatically.

**Snapshot:** when alarm is triggered, take a snapshot of the alarm event.

**Alarm Output:** when alarm is triggered, link to the alarm output device.

#### 4.4.1 Motion Detection Alarm Linkage

- 1) Enable Motion Detection, and set the detection area and sensitivity. Please refer to Chapter 4.2 Motion Detection for details.
- 2) Check the Linkage Type for motion detection. For example, if user checks Snapshot, when alarm is triggered, the system will take a snapshot. In **Settings>Storage>Snapshot** interface, user can set picture format, resolution, interval and quantity.

#### 4.4.2 Tempering Alarm Linkage

- 1) Enable Tempering Alarm, and set the area and sensitivity. The method is the same as that of Motion Detection.
- 2) Check Linkage Type.
- 3) Click “Save” to finish setting.

#### 4.4.3 Alarm Input Linkage

The camera supports on/off alarming device.

Alarm Input

Enable	<input checked="" type="checkbox"/>
Parallel Port Extension	0 <span style="float: right;">▼ ?</span>
Alarm Input ID	1 <span style="float: right;">▼</span>
Alarm Name	Alarm1
Alarm Type	Always Enabled <span style="float: right;">▼</span>
Duration	<input type="button" value="Edit"/>

**Linkage Method(Common Linkage)**

Report to Management System	<input checked="" type="checkbox"/>
Text Overlay	<input checked="" type="checkbox"/>
Acoustic Alarm	<input type="checkbox"/>
Recording Linkage	<input type="checkbox"/>
Snapshot	<input type="checkbox"/>
Email Notification	<input type="checkbox"/>

**Linkage Method(Other Linkage)**

Alarm Output	<input type="checkbox"/> Alarm Output1
--------------	--

Picture 4-5 Alarm Input

- 1) Make sure the alarm input device is always enabled or disabled, and that it is rightly connected to the alarm input port of camera.
- 2) Go to **Settings>Event>Alarm Input**, and select an alarm input ID from the dropdown list (in accordance with the alarm input port).
- 3) Input alarm name, and select “Always Enabled” or “Always Disabled” from the dropdown list of alarm type.
- 4) Click “Edit” and set durations at the popup interface. Check durations and set “Start Time” and “End Time”. Check the week day(s) to copy the setting to the day(s).
- 5) Check “Linkage Method”.
- 6) Click “Save” to finish setting.

#### 4.4.4 Abnormality Linkage

It is triggered when something abnormal happens. Abnormality includes Disk Full, Disk Error and Internet Disconnected.

Abnormality Linkage

Enable

Abnormality Type

Linkage Method(Common Linkage)

Report to Management System

Text Overlay

Acoustic Alarm

Email Notification

Linkage Method(Other Linkage)

Alarm Output  Alarm Output1


Save

**Picture 4-6 Abnormality Linkage**

- 1) Select Abnormality Type from the dropdown list.
- 2) Check “Linkage Method”.
- 3) Click “Save”.

## 4.5 Privacy Mask

Mask sensitive and private part of the image so as to keep sensitive information private.



Picture 4-7 Privacy Mask

#### 4.5.1 Set Area

The image is divided into 16 columns and 12 rows of small squares. The maximum number of Privacy Mask area is 4.

- 1) Go to **Settings>Camera>Video >Privacy Mask**, and check “Enable”.
- 2) Click “Edit”, and the image is divided into 16 columns and 12 rows of small squares. Click any square and drag an area from this square, then this area is the privacy mask area, which is in purple red.
- 3) Select Mask Color from the drop-down list.
- 4) Click “Save” to make settings effective.

#### 4.5.2 Clear Area


Start from an undefined square and draw an area that contains the defined area, or click the defined squares one by one to clear setting, or click “Clear” directly. Click “Save” to make settings effective.

#### 4.5.3 Disable Function

To disable this function, uncheck  Enable.

## 4.6 Encoding Clipping

After user defines the encoding area, the system will encode and display the clipping area only, so as to save system resources and network bandwidth.



Picture 4-8 Encoding Clipping

#### 4.6.1 Set Area


Go to **Settings>Camera>Video >Encoding Clipping**, and check “**Enable**”. Click “**Edit**”, and drag an area as the clipping area. Click “**Save**” to make settings effective.

#### 4.6.2 Clear Area

Click “**Clear**” to clear edition and reset area.

### 4.7 ROI

Only encode specific area to ensure normal surveillance and constant resolution of key area under poor network.



Picture 4-9 ROI



#### 4.7.1 Set Area

Go to **Settings>Camera>Video >ROI**, and check “**Enable**”. Click “**Edit**”, and drag an area as the clipping area. Select encoding grade from the dropdown list. Click “**Save**” to make settings effective.

#### 4.7.2 Clear Area

Click “**Clear**” to clear edition and reset area.

**i** Note: When ROI Encode is enabled, if user modifies image resolution or aspect ratio (standard screen/widescreen), the device will quit ROI Encode automatically.

### 4.8 SDI Output


For cameras with HD-SDI output function, when the resolution is 1080P, frame rate supports 25 fps, 30 fps, 50 fps and 60 fps; when the resolution is 1080i, frame rate supports 50 fps and 60 fps; when the resolution is 720P, frame rate supports 50 fps and 60 fps. Go to **Settings>Camera>Video>Encoding Format** and set.

Encoding Format	Encoding Clipping	ROI	Privacy Mask
<b>Encoding Format</b>			
Multi-Stream	Dual-Stream	▼	Effective after reboot
Stream Type	Main Stream	▼	
Resolution	1280*720	▼	
Bit Rate Type	CBR	▼	
Image Quality	Middle	▼	
Frame Rate	20	1~25	Upper Limit
Bit Rate Upper Limit	4096	64~8192 (Kbps)	
Encoding Format	H.264	▼	
Encoding Complexity	Low	▼	
Max Key Frame Interval	75	1~250	
<b>Save</b>			

Picture 4-10 Encoding Format

**i** Note: Settings on resolution and frame rate are also effective to SDI output.


When user wants to set resolution as 1080i, please go to **Settings>Camera>Image>Image Quality**, and select “Interlacing (same as main stream resolution)” in **Rotate and BNC** part.




Picture 4-11 Image Quality

## 4.9 Snapshot

Click “**Snapshot**” to enter snapshot management interface. User can view or download snapshots in SD card.


 **Note:** If the Snapshot interface is disabled, please confirm the SD card is inserted and then login client again.


### Operation Steps

- 1) Search snapshots: search snapshots in accordance with the duration and format from the SD card.
- 2) On the snapshot list, select searched picture and click  to download

## 4.10 Playback

Click “**Playback**” to enter recording management interface. User can playback, clip and download recordings in SD card. (A SD card must be inserted in the camera.)

 **Note:** If the Playback interface is disabled, please confirm the SD card is inserted and then login client again.

 Note: User can set recording durations in Settings>Storage>Recording. Check “Enable” and click “Edit” to set durations.

Recording

**Recording Configuration**

Recording Type	<input type="text" value="Main Stream"/>	▼	
Code Stream Format	<input type="text" value="ES (VSIP/Onvif)"/>	▼	Effective after reboot.
Prerecord	<input type="text" value="30 s"/>	▼	
Recording Delay	<input type="text" value="20 s"/>	▼	

**Scheduled Recording**

Enable	<input checked="" type="checkbox"/>
Time Table	<input type="button" value="Edit"/>

**Picture 4-12 Recording**

#### 4.10.1 Playback

- 1) Select recording duration from the calendar.
- 2) If there is background color on a date, it means there is recording on that day. Select duration of the date and the video will be displayed directly in the right window.

#### 4.10.2 Download

Select recording duration from calendar and download recording to local PC. Download path can be configured in **Settings>Local Setting>Local Setting**.

## 4.11 Upgrade

#### 4.11.1 Firmware Upgrade

Contact dealer for upgrade file.

##### Method 1

- 1) Go to **Settings>System>System Maintenance>Upgrade**, as shown in Picture 4-13.

System Maintenance

---

**Reboot**

Reboot

**Auto Maintenance**

Enable

Maintenance Cycle

Maintenance Time

**Upgrade**

Upgrade

**Configuration Management**

Partial Restoration  All parameters restore to factory default except camera IP address and protocols.

Complete Restoration  Restore to factory default

Configuration Export  Export all settings to a file.


Import Parameter  All parameters are imported from the file except the network, device name and OSD setting.

**Advanced Configuration**

Advanced Configuration

**Picture 4-13 Firmware Upgrade**

- 2) Select local upgrade file (<\*.pkg> or <\*.img> format).
- 3) During upgrading, please do nothing but waiting.
- 4) After upgrading, please download ActiveX control again. After finishing it, reboot browser.

 Note: Please click “Upgrade” when upgrading, and the upgrade file is usually in <\*.pkg> format.

**Method 2**

- 1) Run IPCSearch.
- 2) Click "**Upgrade**" to upgrade firmware of cameras of the same model simultaneously.

**4.11.2 Web Client Upgrade**

After firmware upgrade, please login web client again. The page will prompt to download a new ActiveX control. After downloading it, client upgrade will be completed. Login again to enter the latest Web Client.

 **Note:** For detailed operation instructions of Web Client, please refer to the [help document](#).

## 5. Settings

### 5.1 Network Access

3.2 Initial Configuration has introduced how to modify parameters via IPCSearch to make camera access network. Camera accepts multiple network access methods (via Ethernet and PPPoE). The following introduces how to configure camera network parameters in Web Client.

#### 5.1.1 Ethernet

Go to **Settings>Network>IP and Port>IP Address**, as shown in Picture 4-1 to configure IP address, subnet mask and default gateway.

IP Version	IPv4
Mode	Static
IP Address	10.61.1.81
Subnet Mask	255.224.0.0
Default Gateway	10.62.0.254
Multicast Address	0.0.0.0
MAC Address	00-14-10-0F-41-09
MTU	1500

DNS Server Setting

Automatically Obtain DNS

Preferred DNS Server

Alternate DNS Server

Save

Picture 5-1 Ethernet Parameter

#### 5.1.2 PPPoE

Go to **Settings>Network>Other Protocols>PPPoE**, as shown in Picture 5-2 to enter user name and password, and save.

DDNS	PPPoE	K-SNMP	802.1X	QoS	UPnP	SMTP
Enable	<input checked="" type="checkbox"/>					
DHCP	<input type="text" value="0.0.0.0"/>					
User Name	<input type="text" value="root"/>					
Password	<input type="password" value="••••"/>					
<input type="button" value="Save"/>						

Picture 5-2 PPPoE Setting

## 5.2 Register to VMS

Go to **Settings>Network>Access Protocol>VSIP**, as shown in Picture 5-3 to enter VMS address and port. Save settings and reboot device.


VSIP	ONVIF	GB28181
<b>Registered VMS</b>		
Enable	<input checked="" type="checkbox"/>	
VMS Method	<input type="text" value="IP Address"/>	
VMS Address (IPv4)	<input type="text" value="224.1.1.1"/>	
VMS Port Number	<input type="text" value="5510"/>	1~65535
Camera UUID	<input type="text" value="00000000000000000000000000000000"/>	
Camera Password	<input type="password" value="••••••••••••••••••••••••••••"/>	
Send NAT Probe Packets	<input type="checkbox"/>	
<b>VSIP Service</b>		
Auto Networking	<input checked="" type="checkbox"/>	
<input type="button" value="Save"/>		

Picture 5-3 Register to VMS

## 5.3 BNC Output

Camera with BNC output can output analog image directly when local display function is enabled.

Go to **Settings>Camera>Image>Rotate and BNC**, select BNC output mode from the drop-down list, as shown below.



Picture 5-4 BNC Output

**i** Note: For cameras with HD-SDI output, when BNC is enabled, the web client will stop image output.

## 5.4 User Security

### 5.4.1 User Management

Go to **Settings>System>User Security>User**.

#### Add:

Click “Add”, and enter user name and password in the popup interface. Select user type from the dropdown list, and assign operation rights to newly added user from the Authorization List. After setting, click “Confirm”.

#### Delete:

Select user IP and click “Delete” to delete the user.

#### Modify:

Select user IP and click “Modify” to modify in the popup interface.

### 5.4.2 IP Filter

By setting IP address filtering, user can manage access limitation to the web client.

White List includes IP addresses able to access to the client, while Black List includes IP addresses unable to access to the client.



Enable IP Filter:

Select filter method from the dropdown list according to request, or select “Disable” to disable IP filter.

#### Add Black/White List:

After select filter method, click “Add” and input IP address in the popup interface, and click “Confirm”.

#### Modify Black/White List:

Select the IP address from the list and click “Modify” to modify the IP address in the popup interface, and click “Confirm”.


#### Delete Black/White List:

Select the IP address from the list and click “Delete” to delete the IP address. Click “Delete All” to clear all the IP addresses.

## 5.5 Text Overlay

Display preset text on the surveillance window, configuration steps as follows:

- 1) Go to **Settings>Camera>OSD**, as shown in Picture 5-5.



Picture 5-5 OSD

- 2) Check the options and preview the result in the window. For example, if user checks “Time”, time will be displayed in the window.
- 3) Edit positions: drag the items in the window with mouse to change their positions.

- 4) Edit OSD texts: for example, if user checks OSD1, double click OSD1 textbox and input characters in the popup interface. Click “OK”.
- 5) Click “Save” to save OSD setting.
- 6) Click “Load” to load default font or China GB font.
- 7) Click “Advanced” to set “Format”, “Font” and “Margin”.

The screenshot shows a dialog box titled "Advanced Setting of OSD". It is divided into three main sections: "Format", "Font", and "Margin".

- Format:** Contains a "Time Format" dropdown menu set to "YYYY-MM-DD". Below it are two checkboxes: "Display Time in 2 Lines" and "Alarm in front of tag", both of which are currently unchecked.
- Font:** Contains a "Type" dropdown menu set to "SimHei", a "Size" dropdown menu set to "Large", and a "Color" dropdown menu set to "White". A "Custom" button is located at the bottom right of this section.
- Margin:** Contains two dropdown menus: "Horizontal" set to "1" and "Vertical" set to "1".

At the bottom right of the dialog box, there are two buttons: "OK" and "Cancel".

Picture 5-6 Advanced Setting of OSD

## 5.6 Multi-stream


Camera supports multiple streams encoding and decoding. Multi-stream means the same video source is encoded into different streams of videos with different resolutions. User can select proper resolution to view or record according to the network bandwidth.



Note: Different camera models may have different numbers of streams.

Operation steps:

- 1) Go to Settings>System>System Maintenance; click “Configuration” under “Advanced Configuration”, and input password;
- 2) Select working mode from the dropdown list;



**Picture 5-7 Advanced Configuration**

- 3) Click “Save” and reboot camera to make setting take effect. After reboot, re-login;
- 4) Go to **Settings>Camera>Video>Encoding Format**, as shown in Picture 5-8. In Multi-stream option, select Single Stream, Dual-stream, Triple-stream or Quad-stream from the dropdown list, and the selection takes effect after reboot. After enable, user can set parameters below the option accordingly.

Encoding Format	Encoding Clipping	ROI	Privacy Mask
<b>Encoding Format</b>			
Multi-Stream	Dual-Stream	Effective after reboot	
Stream Type	Main Stream		
Resolution	1280*720		
Bit Rate Type	CBR		
Image Quality	Middle		
Frame Rate	20	1~25	Upper Limit
Bit Rate Upper Limit	4096	64~8192 (Kbps)	
Encoding Format	H.264		
Encoding Complexity	Low		
Max Key Frame Interval	75	1~250	
<b>Save</b>			

Picture 5-8 Stream Type

## 6. Appendix: Glossary of Terms

Term	Explanation
<b>720P</b>	Resolution of 1280*720 pixels
<b>CIF</b>	Resolution of 352*288 pixels
<b>QCIF</b>	Resolution of 176*144 pixels
<b>ROI</b>	Region Of Interest
<b>Key Frame Interval</b>	Key Frame defines the important frame when change happens in a video. This frame will be completely encoded. Key Frame Interval defines the maximum frames during the interval between key frames. If the video changes quite frequently, shorter Key Frame Interval will make video more real, but it will take more bandwidth.
<b>Quantization</b>	Set Min. and Max. Quantization, and image compression quantization will fluctuate in the range. During image compression, larger quantization brings higher compression ratio and higher distortion ratio. On the contrary, smaller quantization brings lower compression ratio and better image recovery, but meanwhile takes more bandwidth.