


GENIO

CAD/CAM for Morbidelli/SCM workcenters



SUMMARY

SUMMARY	1	
Introduction	4	
IN GENERAL		4
THE STRUCTURE OF THE VIDEO		5
THE GENIO TOOLBAR		6
GENIEDIT		6
Installation	7	
SETTING OF USER PRIVILEGES AND PROFILE		9
Configurations	10	
PREFERRED		11
FILE		13
DRAWING		14
EDGE BANDING DRAWING		16
DISPLAY		17
GEOMETRY		19
MACHINING		21
EDGE BANDING		23
NESTING		25
IMAGE IMPORT		27
Programming	29	
IMPORT TOOLS FROM XILOG		30
PROGRAMMING TOOL DATA		36
EDGE-BAND STORE DATA PROGRAMMING		42
EDGE-BANDING CONFIGURATION DATA PROGRAMMING		43
PROGRAMMING OF THE SUPPORTS DATA		45
MACRO PROGRAMMING		48
IMPORT OF CNC PROGRAMS AS PARAMETRIC MACROS		62
MANAGEMENT OF PASSING MACROS		64
Programming a mix	65	
NEW MIX		65
OPEN MIX		65
Panel data and machinings programming	68	
IN GENERAL		68
APPLY BUTTON		68
IF BUTTON		69
SUPPORTED GEOMETRIES		70
DEFINITION		71
SUPPORTS PROGRAMMING		75
ERGON MANAGEMENT		76

VERTICAL BORING	79
HORIZONTAL BORING	82
SLANTING BORING	84
VERTICAL MILLING	89
SLANTING MILLING	95
POCKETING	100
ENGRAVING	106
SAW CUT	109
CUTTING INSTRUCTIONS	112
EDGES XY MANAGEMENT	120
INTERNAL CORNER CLEANING	125
PARAMETRIC MACHINING PROGRAMMING	137
NESTING MACHINING REPORT	139
Edge-banding machining programming	140
IN GENERAL	140
EDGE BANDING	141
END TRIM	149
TRIMMING	151
SCRAPING	153
FINISH	155
RADIUSING	157
BLOWING	159
File	161
NEW	161
OPEN	161
PRINT ALL	162
Modify	163
INPUT MACRO	163
DRAWING VARIABLES	164
NEW PARAMETRIC GEOMETRY	167
EDIT PARAMETRIC GEOMETRY	168
IMPORT PARAMETRIC GEOMETRY	176
MODIFY REFERENCE ORIGIN	180
NEW WORKTOP	181
MODIFY WORKTOP	184
GEOMETRY DIRECTIONS	185
CHANGE	186
EXPLODE MACRO	187
JOIN MILLINGS	187
MODIFY PROFILE IN/OUT	189
Tools	191

DIMENSIONING	191
DRAW TEXT	193
CIRCLES ON ROUTE	196
OPPOSE	197
SORT MACHINING	198
CHANGE MACHINING	199
DISPLAY MACHINING LIST	202
LABEL EDITOR	205
LABEL PRINTING	213
GROUP	215
GROUP PAGE	217
Utility	218
3D VIEW	218
NORMAL VIEW	219
WIZARD PROGRAMMING	220
APPLY WIZARD	229
HEAD SIMULATION	230
VERIFY	232
OPTIMIZE	233
DEFAULT RESET	235
Nesting Geometric	235
PANEL LIST PROGRAMMING	238
SHEET LIST PROGRAMMING	239
Machining Nesting	240
PANEL LIST PROGRAMMING	245
SHEET LIST PROGRAMMING	246
NESTING PROCESSING	247
THE NESTING TREE VIEW	248
NESTING EXPORT	253
EXAMPLES OF NESTING	255
EXPORT PROGRAMS	258
IMPORT PROGRAMS	260
Hardware configuration	263

Introduction

In General

This document is a guide for the person using the Genio program. Genio is a Cad/Cam system for the remote programming of work centers, routing centres and edgebanders for shaped panels.


Genio is an AutoCad® OEM 2004 application and, therefore, the CAD environment is based on the AutoCad® 2004's motor and functions.

The advanced user who is already well aware of the Autocad environment can use the native CAD power to program his work center in a more flexible and personalized way, on the other hand, the user who has not yet acquired a great deal of familiarity with the AutoCAD environment can also take advantage of the numerous utilities placed at his disposal by the Genio Control Panel to program and export, both simply and quickly, the panel machining.

The structure of the video


The Genio video, as can be seen from the following images, has been divided up into two parts:

- The first, located regularly in the left-hand part of the screen, is AutoCAD's graphic motor window and contains the panel drawing with the machining facilities and geometry inserted at that point, the menu and the tool bar to personalize the machining environment, gain access to and change the graphic entities, open new files, gain access to the various CAD utilities available, etc.;
- The second, located regularly in the right-hand part of the screen, is Genio's Control Panel window, which contains a utility series for programming and organizing the work center's operations. You will find, in this manual, a detailed description of the Control Panel's utility functions. The AutoCAD's operating functions have been postponed to be examined in the relative user's guide.



The Genio toolbar

The Genio toolbar, shown below, is normally to be found at the top left of the screen and makes available the particular program functions as described below.



Description of Genio toolbar button functions:



Load and activate the Control Panel



Download the Control Panel (AutoCad mode)



Hide or show the machinings to be found on other sides of the panel than the active one



Update the active drawing, machining parameters and the CAD environment



Unite the geometries present in the drawing according to the parameters set in configuration



Open the window for managing the Layers



Display the machining tree



If disabled (grey), all the active machinings are displayed; if enabled (red), only the active machinings for which the condition (IF) has been checked are displayed.



Allows to create automatically a sequence of machining starting from a set of geometries (Wizard).




Allows to create parametric geometries with constraints assigned to existing geometries.



Generates the CNC code in respect of programmed machinings and of selected post-processor.

GeniEdit



Description of Genio toolbar button functions:



Used to add a tangent line at the end point of a geometry (Tangent line)



Used to add an arc tangent to the end point of a geometry (Arc tangent)

Installation

before starting the installation procedure, make sure that the computer is equipped with sufficient resources to correctly execute the program. if you have any doubts at all, consult the section “hardware configuration” in the manual. check that the following material has been supplied with the software:

- installation cd-rom;
- hw software protection key. the hardware protection key is a small plastic container with an extremity connector (one male and one female) that is similar to the following drawing, in which the correct direction for inserting the protection key is illustrated in the plug parallel (A) or USB (B) to the computer.



Note: if you have a USB protection key the system will ask for the key software drivers-> insert the supplied installation CD ROM, with windows 2000 or XP the drivers will automatically be installed, otherwise, if required, set the driver path to the “KEY” folder of the CD-ROM.

WARNING

- In computers that have adopted the Windows NT/2000 operating systems, start up Windows and LOGIN as ADMINISTRATOR prior to attempting the installation procedure.

Installation procedure:

1. **IMPORTANT:** In computers that have adopted the Windows NT/2000/XP operating system, LOGIN as the Administrator (insert the word, Administrator, into the user name field on receipt of the request by Windows).
2. Insert the CD-ROM into the specific player, the installation procedure will start up automatically after just a few moments if, however, it does not start up, digit <Unit name>:\Autorun.exe from the "Perform" heading from the Windows "Start" menu and press the OK button (<unit name > is the letter that identifies the CD-ROM player: D, E, etc...).
3. The Genio installation procedure displays a series of cascade windows; select FORWARD to go on to the next window or Undo to exit from the installation procedure.
4. Continue until the window "INSTALLATION/DISINSTALLATION OF GENIO R3", where one of the following Options must be selected:
 - **Add or remove functions:** to update just the CAM part (control panel).
 - **Install the new Genio R3:** to update also the CAD part (AutoCad environment).
 - **Remove Genio R3:** to uninstall the software from the computer.
5. Upon completion of the "INSTALLATION/DISINSTALLATION OF GENIO R3" procedure, click on the button "End"
6. At this point, unless disinstall the software has been selected, the "Control Panel" (CAM part) of Genio will be automatically installed; wait for the end of the procedure.
7. Upon completion of the installation procedure, a window is displayed with a message that shows the result of the installation; press "End" to exit from the utility.
8. Note: at the end of each installation, if requested, restart the PC.

Setting of user privileges and profile

During installation ensure that the user profile (User Account) of the computer is of the “Administrator” type in the operating systems Windows XP and Windows 2000 respectively.

Upon completion of installation, in order to use Genio 2004 there are two different procedures according to the operating system installed in the computer.

WINDOWS XP

Under Windows xp, Genio can also be used as a normal USER, but the folder where Genio is installed must be write-accessible by the user.

To make a folder write-accessible to a user in Windows xp, it is necessary

- 1) to open the explore resources with administrator type user profile
- 2) to go to the options of the window “Explore resources” and deactivate the simple display
- 3) to go to the properties of the Genio installation folder and a sheet will appear entitled "protection and sharing"; at this point give users who must use Genio full privileges for this folder.


WINDOWS 2000.

For Windows 2000 it is instead necessary to have a POWER USER, with the possibility of writing on the registry of the operating system. In addition to this there is the further requirement by Genio to have read-write access to the installation folder. (See procedures described above.)

Configurations

The Genio configuration parameter programming pages, which are all accessible under the heading OPTIONS that are contained in the Control Panel Utility menu, allow you to set the values relative to the working environment in which you are going to work and are as follows:

1. Preferred,
2. File,
3. Drawing,
4. Edge Banding Drawing,
5. Display,
6. Geometry,
7. Machining,
8. Edge Banding,
9. Nesting,
10. Image Import



Preferred

The preferred page allows you to set the type of machine, and the type of CNC control, the language used in messages and for the program windows, the unit of measurement used for the quotes, the origin of the axis predefined in the panel, offsets (BX,BY,BZ) for panel origin and the default values concerning the measurements and panel name, to Genio's loading.

Machine type Type of CNC machine

Control type Type of CNC control in the machine

N.B. To select both options click on the right arrow; a pull-down menu appears allowing you to choose the required item.

Vector axis Indicates whether or not the machine has the vector axis.

Language:

Click on the flag until you see the one displayed that corresponds to your selected language.

Languages available:

- Italian
- English
- French
- German

- Spanish
- American English

Units of measurement:

Choose the unit of measurement used for the quotes from among:

- **Millimeters** (precision to 0.001 mm)
- **Inches** (precision to 0.001 inch)

Predefined panel:

Name	Name of the predefined panel
• Description	Description of the predefined panel
• Panel width	Width of the predefined panel
• Panel length	Length of the predefined panel
• Panel thickness	Thickness of the predefined panel
• Field	The predefined field of the working area in which the program must be performed.
• Default tooling file	Name of the file that contains tooling data

Offset:


- **BX** Dimension in X of any shim placed under the panel.
- **BY** Dimension in Y of any shim placed under the panel.
- **BZ** Dimension in Z of any shim placed under the panel.

Predefined axis origin:




By simply clicking the mouse on one of the four angles, the origin of the axis is set.

A description of push-button functions




Save the changes



Cancel the changes

File


The page enables the programming of the default paths for the import or export of data from the machinery control, programs and panel design fields.




A description of the fields

Default path drawing panel file:	Set the folder in which the panel drawing files reside
Default path import tools data file:	Program the folder in which the files are contained for the import tools data
Default path import supports data file:	Program the folder in which the files are contained for the import supports data file
Default path import program file:	Program the folder in which the files are contained for the import programs file in format
Default path export program file:	Program the folder where the export programs file will be memorized

A description of the push-button functions




Save the changes



Cancel the changes

Drawing

The Drawing page allows you to set the colors with which the various entities inserted in the panel drawing will be displayed.






Description of the fields

Color of panel:	Program the panel color
Color selected machining:	Program the selected machining color
Color rendered machining:	Program the rendered machining color
Color machining speed signals:	Program the machine speed signals color
Color of geometry directions:	Program the geometry directions color
Color of dynamic geometry directions:	Program the color of dynamic geometry directions
Color of dynamic not-tangent signals:	Program the color of dynamic not-tangent signals
Color of macro:	Program the inserted macros color
Color tables:	Program the tables' color
Color suction cups:	Program the suction cups color
Color Profile In/Out:	Program the profile entry and exit color
Color boring on face 1:	Program the vertical boring color


Color boring on face 6:	Program the boring color in face 6
Color horizontal boring:	Program the horizontal boring color referred to face 1
Color parametric boring:	Program the parametric boring color
Color through boring:	Program the through boring color
Color routing:	Program the routing color
Color parametric routing:	Program the parametric routing color
Color through routing:	Program the through routing color

A description of the push-button functions

	Cancel the changes
	Save the changes
	Restore to the initial colors

Edge banding drawing




The Edge Banding Drawing page is used to set the colors with which the various edge-banding operations inserted in the panel drawing will be displayed.



Description of the fields


Edge banding color:	Program the edge banding color
Trimming color:	Program the trimming color
Scraping color:	Program the scraping color
Finish color:	Program the finish color
Blowing color:	Program the blowing color
End trim color:	Program the end trim color
Radiusing color:	Program the radiusing color
Color Edge-Banding In/Out:	Program the Edge-Banding entry/exit color (EIN-EOUT)

A description of the push-button functions

	Cancel the changes
	Save the changes
	Restore to the initial colors

Display

The Display page is used to set the modes of displaying certain program objects.



Description of the fields

Tools Data :

- **Phantom tools:** Enables or disable the ghost tools being displayed on the panel
- **Dimension of ghost tools:** The dimension of the phantom tool that will be displayed on the panel

Geometries direction:

- **Show geometry directions:** Enable or disable the visualization of static geometry directions.
- **Show dynamic geometry prperties:** Enable or disable the visualization of static geometry directions.

Panel text size:

- **Panel text Height:** Size of the text that describes the panel, sides, nesting codes.


Show code:

- **Show xilog code:** Enables or disables display of the program code editor at the end of Export

Toolbars:

- **Standard:** Activates the typical Autocad toolbars
- **Minimum:** Activates the minimum Autocad toolbars

A description of the push-button functions



Cancel the changes

A rectangular button with a light gray background and a thin black border, containing the text "Ok".

Save the changes

A rectangular button with a light gray background and a thin black border, containing the text "Apply".

Makes changes according to the selection

Geometry

The Geometries page is used to set parameters related to the geometries.

Description of the fields

- **Minimum arc-center distance:** Necessary minimum distance between the centers of two consecutive arcs so that they are converted into a single arc.
- **Max radius arcs:** Radius over which the arc is converted into a sequence of lines.
- **Min arc dimension:** Size below which the arc is converted into a line.
- **Approximate number line for arc:** Number of lines that approximate a 360° arc.

Geometry join:

- **Min. length for geometry entity** Geometries whose length is lesser than the programmed value will be removed after the join process
- **Min. distance for join geometry** Two geometries whose distance is lesser than the programmed value will be joined after the join process

Tangent:

Tangent tolerance (degrees) Threshold angle between to geometries: under this angle two consecutive entities will be considered as tangents

Geometry approximation:

- **Max cordal error on spline conversion:** Maximum distance between the center of the geometry (arc, line) that approximates a geometry and the actual geometry
- **Max length difference on spline conversion:** Maximum difference between the length of the geometry (arc, line) that approximates a geometry and the actual geometry

Automatic geometry filter:

If activated, a filter is carried out in the creation of machining connected with geometries.

Draw ellipses as Polyline:

If enabled the ellipses will be converted and saved as polylines otherwise as ellipses.

A rectangular button with a light gray background and a thin black border, containing the text "Cancel".

Cancel the changes

A rectangular button with a light gray background and a thin black border, containing the text "Ok".

Save the changes

Machining

The Image Machining page is used to set the maximum value for overmaterial.

Max Overmaterial

Value that may be assigned to the overmaterial parameter in the routing instructions.

Min. angle for edge management

Maximum angle value to consider in the edge management utility to perform a ring or a corner fit

Parametric Export

Carries out the Export in parametric way

Parametric Export IF

Carries out the Export of the condition IF in parametric way

Generate arc code as:

- **Arc for two point and center**
- **Arc for two point and radius**

Carries out the export of an arc with the instruction that takes into account two points and the center of an arc

Carries out the export of an arc with the instruction that takes into account two points and the radius of an arc

Delta through machining

Value that is added to the thickness of the panel for the through machining depth

Max Delta through machining

Maximum difference between the depth of one through machining and the thickness of the panel

Check machining during export

If enabled it carries out a check on machinings during export

Check machining during saving

If enabled it carries out a check on machinings during saving

Add null instruction

If enabled, it inserts a null instruction at the end of each program with coordinates equal to the values X and Y(N X=10.00 Y=10.00)

X Value:

Position of the head on axis X.

Y Value:

Position of the head on axis Y.

Ok

Save the changes

Cancel

Cancel the changes

Edge banding

The Edge Banding page is used to set parameters related to edge banding.

Genio Options

Preferred | File | Drawing | Edge banding drawing | Display | Geometry | Machining | **Edge banding** | Nesting | Image import

Tolerance corner degrees: 5,000

☒ Alternate edge banding

Default edge banding

Edge to shuttle: 0,000

Edge after shuttle: 0,000

Edge add to perimeter: 50,000

(L) Cut length: 50,000

(J) Shaft elevation: 10,000

Def. Aux. Mach.

Advance: 0,000

Postpone: 0,000

Automatic fillet radius: 0,000

Automatic update

☐ None

☒ Partial

☐ Full

Ok Cancel Restore

Description of the fields

Tolerance edge degrees:

Degrees within which two consecutive entities are considered tangents

Alternate edge banding:

If activated, edge banding is carried out alternately on the geometries. (odd edges first, then even edges).

Default edge banding:

- **Edge to shuttle** Edge to be supplied starting from the shuttle point of insertion
- **Edge after shuttle** Amount of edge after shuttle insertion
- **Edge add to perimeter** Parameter that will be algebraically added to the panel perimeter to be edge-banded, for checking the total quantity of supplied edge band at the inlet.
- **(L)Cut Length** Length of edge cut staring from the photocell reading
- **(J)Shaft elevation** Early shaft elevation in relation to point of closure of the edge band

Def. Aux. Job:

- **Advance** Advance in relation to the starting point of machining

- **Postpone** Deferment in relation to the starting point of machining
- **Automatic fillet radius** Radius of the fillet that is created in automatic on the corners of the geometries that regard the Planet version.

Automatic Update:

- **None** No automatic update will be performed (this setting increase programming speed, no control is performed)
- **Partial** The automatic update will be performed only when some routing paths linked to geometries have been modified.
- **Full** The automatic update will be performed when some routing paths linked to geometries have been modified and before the following operations: program export; head simulation, program optimization and program verify (this setting increase programming time, full control is performed).

Ok

Save the changes


Cancel

Cancel the changes

Nesting

The Nesting page is used to set the general Nesting management parameters.

The nesting page allows for the programming of the succession order in which the relative nesting operations will be carried out.



A description of the fields

Order Export Nesting: The order according to which the panel machining will be exported.

A description of the push-button functions



The selected heading moves upwards by one position



The selected heading moves downward by one position

Rectangular Nesting Origin: Defines the starting point of the panel-cutting path in the rectangular nesting. If Default, leave the AutoCAD programming unvaried.

Delta dist. I/U: Distance between pieces will be increased of this value when lead In / Lead Out are programmed

CNC program format:

- **Selected file format:** The format with which the file will be exported.
- **Automatic pocketing:** Activates automatic pocketing of the Nesting cell

Application type:

- **Nesting standard:** Export is carried out for Standard Nesting.
- **Nesting with label applicator:** Export for Nesting with automatic applicator.




Label display:	Label management display.
DimX:	Size in X of label.
OffX:	Shift in X coordinates in relation to the label position center.
DimY:	Size in Y of label.
OffY:	Shift in Y coordinates in relation to the label position center.
Unload:	Type of panel unloading in the presence of applicator.
Export null instruction:	If activated, export null instruction.
Pos. X:	Position of head on axis X.
Pos. Y:	Position of head on axis Y.
	Save the changes
	Cancel the changes

Image import

The Image Import page is used to set parameters related to any image import.



A description of the fields

- **Line center** Geometries are created following the center of the lines of the figure
- **Line edge** Geometries are created following the edges of the lines of the figure
- **Min. pixel dimension** The outlines that measure less than the set distance are eliminated
- **Edge distance** Distance of the line from the outline
- **Curve** If selected, the parameters that follow the lines are applied

Rounding off:

- **Iteration number** Number of iterations to represent a curve: the higher the value the more precise the curve but the longer the calculation time
- **Shift restriction** Enable the parameter to obtain precise curves
- **Shift tolerance** Tolerance of curve shift in relation to original outline

Representation:

- **Lines** Only lines are used to represent the outlines
- **Lines/arcs** Both lines and arcs are used to represent the outlines.

- **Arc tolerance** The higher the set tolerance the fewer the arcs obtained.
- **Lines** This allows the two following parameters to be considered.
- **Horizontal and Vertical** If enabled, the algorithm determines the greatest quantity of horizontal and vertical lines.
- **45 Degrees** If enabled, the algorithm determines the greatest quantity of lines at 45 degrees.
- **Arcs** If enabled, the circles will be described by closed arcs.
- **Angle precision** The higher this value the greater the number of calculated angles.
- **Tangent intersection** If enabled, the points of intersection between tangent lines are assessed correctly.

Ok

Save the changes


Cancel

Cancel the changes

Programming

The Genio programming parameters programming pages, which are accessible from the Control Panel File Menu, illustrated below, allows the programming of the following data:

- **Tools**
- **Edge Store (Only for edge banding)**
- **Edge configuration (Only for edge banding)**
- **Macro**
- **Supports**




Import tools from xilog

Instruction for Xilog 3


1. Execute Xilog3
2. Select **F8 (REPORT)**



3. Select **F4 (PARAMETER EDITOR)**




The following window will appear



4. Selection file **CAD.cfg** from the list

5. Select **F6** or Double Click on the selected file. The following window will appear :



6. Program the folder name in which the file will be saved

Directory: C:\XILOG3


7. Select **F2** (SAVE).



8. Select **EXIT** and exit from XILOG3.




9. Now the “Ext” tooling files are saved in the folder programmed as above and can be imported in Genio with the “import tooling from file” utility as shown below.




Instruction for Xilog Plus


1. Execute Xilog Plus
2. Select from the **File** Menu the voice **Configuration Machine**



3. The following window will appear . Select the page **Configuration**.



4. Select the voice **Settings DXF(CAD)**




5. Program the folder in which the file is contained.

Directory: C:\XILOG3

6. Save the modify.


7. Exit from XILOG PLUS.

8. Now the “Ext” tooling files are saved in the folder programmed as above and can be imported in Genio with the “import tooling from file ” utility as shown below.



Import tools file from Genio


1. From the Control Panel's **File** menu, select the voice **Tools**.



The following window will appear:

Tools : DEF														
A1		E1												
Numb.	Def	Code	Description	Type	Face	Length	Diameter	Angle	Rot.	Max.Speed	Rot.Spe	IdField	VelDef	
1	E1	<input type="checkbox"/>	Face 0 Normal	Face 0 Normal	F	0	44,000	4,000	90	1	90	18000	1	
2	E2	<input checked="" type="checkbox"/>	Linear shaped H1	Linear shaped H12	F	1	12	40,840	0	1	90	18000	1	
3	E3	<input checked="" type="checkbox"/>	Flat 10 mm	Flat 10 mm	F	1	30,000	10	0	1	90	18000	1	
4	E4	<input checked="" type="checkbox"/>			F	1	30,000	10,000	0	1	90	18000	1	13
5	E5	<input checked="" type="checkbox"/>	Curve shaped H 8	Curve shaped H 8	F	1	30,000	26,659	0	1	90	18000	1	
6	E6	<input checked="" type="checkbox"/>			F	1	30,000	10,000	0	1	90	18000	1	
7	E7	<input checked="" type="checkbox"/>			F	1	30,000	41,715	0	1	90	18000	1	
8	E8	<input checked="" type="checkbox"/>			F	1	30,000	10,000	0	1	90	18000	1	
9	E9	<input checked="" type="checkbox"/>			F	1	30,000	10,000	0	1	90	18000	1	
10	E10	<input checked="" type="checkbox"/>	Rad. Reduction	Rad. Reduction	F	1	30,000	6	0	1	90	18000	1	
11	E11	<input checked="" type="checkbox"/>	Conic 60 Degr.	Conic 60 Degr.	C	1	20	45	1	90	18000	1		
12	E12	<input checked="" type="checkbox"/>			F	0	30,000	10,000	45	1	90	18000	1	
13	E14	<input checked="" type="checkbox"/>	Conic 70,530 Deg	Conic 70,530 Degr.	C	0	51,000	10,160	35,265	1	11	18000	1	
14	E96	<input checked="" type="checkbox"/>	Face 0 45 Degr.	Face 0 45 Degr.	F	0	44,000	10,000	45	1	90	18000	1	
15	E39	<input checked="" type="checkbox"/>	SCM shaped H10	SCM shaped H10	F	1	96,2	40,840	0	1	90	18000	1	
16	E44	<input checked="" type="checkbox"/>	Rad. reductiot SC	Rad. reductiot SCM	F	1	30,000	4,3	0	1	90	18000	1	
17	E36	<input checked="" type="checkbox"/>	SCM conic 90 De	SCM conic 90 Degr.	C	1	30,000	20	45	1	90	18000	1	
18														
19														
20														
21														
22														
23														

2. Click on the button in the tool bar
3. Select the CAD/Xilog directory and select the file.




4. Select **Open**.

N.B.

Make sure that in the folder programmed in the **Directory** field exist the file **CONFIG.EXT**, if not check for the correct programming of the folder in Xilog.

Programming tool data

Permits the programming and display of the data relative to the tools available.



Functions available in the tool bar

Icon	Rapid selection	Function description
		Import a tool file
		Import general data
		Save the data programmed in the video
		Export general data
		Print the document
		Remove the lines from the spreadsheet selected
		Copy the lines from the spreadsheet selected
		Paste in the lines selected previously
		Add a line before the selected line
		Define a tool starting from a two-dimensional profile
		Exit the programming page

Tools : DEF													
A1	E1												
Numb	E	Def	Code	Description	Type	Face	Length	Diameter	Angle	Rot.	Max.Speed	Rot.Spe	IdField
1	E1	<input checked="" type="checkbox"/>	Face 0 Normal	Face 0 Normal	F	0	44,000	4,000	90	1	90	18000	1
2	E2	<input checked="" type="checkbox"/>	Linear shaped H1	Linear shaped H12	F	1	12	40,840	0	1	90	18000	1
3	E3	<input checked="" type="checkbox"/>	Flat 10 mm	Flat 10 mm	F	1	30,000	10	0	1	90	18000	1
4	E4	<input checked="" type="checkbox"/>			F	1	30,000	10,000	0	1	90	18000	1
5	E5	<input checked="" type="checkbox"/>	Curve shaped H 8	Curve shaped H 8	F	1	30,000	26,659	0	1	90	18000	1
6	E6	<input checked="" type="checkbox"/>			F	1	30,000	10,000	0	1	90	18000	1
7	E7	<input checked="" type="checkbox"/>			F	1	30,000	41,715	0	1	90	18000	1
8	E8	<input checked="" type="checkbox"/>			F	1	30,000	10,000	0	1	90	18000	1
9	E9	<input checked="" type="checkbox"/>			F	1	30,000	10,000	0	1	90	18000	1
10	E10	<input checked="" type="checkbox"/>	Rad. Reduction	Rad. Reduction	F	1	30,000	6	0	1	90	18000	1
11	E11	<input checked="" type="checkbox"/>	Conic 60 Degr.	Conic 60 Degr.	C	1	20	20	45	1	90	18000	1
12	E12	<input checked="" type="checkbox"/>			F	0	30,000	10,000	45	1	90	18000	1
13	E14	<input checked="" type="checkbox"/>	Conic 70,530 Deg	Conic 70,530 Deg.	C	0	51,000	10,160	35,265	1	11	18000	1
14	E96	<input checked="" type="checkbox"/>	Face 0 45 Degr.	Face 0 45 Degr.	F	0	44,000	10,000	45	1	90	18000	1
15	E39	<input checked="" type="checkbox"/>	SCM shaped H10	SCM shaped H10	F	1	96,2	40,840	0	1	90	18000	1
16	E44	<input checked="" type="checkbox"/>	Rad. reductiot SC	Rad. reductiot SCM	F	1	30,000	4,3	0	1	90	18000	1
17	E36	<input checked="" type="checkbox"/>	SCM conic 90 De	SCM conic 90 Degr.	C	1	30,000	20	45	1	90	18000	1
18													
19													
20													
21													
22													
23													

A description of the fields in the FLUTED MILLS sheet programming spreadsheet

Number: Tool number

E: Activates or deactivates the tool

Def: The selected tool is default for the category to which it belongs

Code: Tool code

Description: Tool description

Type: Tool point type


Tool types	
L	Lance/spud
P	Flat
S	Flared
C	Tapering
F	Mill
D	Disk
R	Trimmer
U	Scraper
V	Blowing

Face: Tool work face

Length: Tool length

Diameter: Diameter point

Angle: For inclined tools, this is the angle of inclination of the tool axis with the perpendicular to the working surface (angle A/B). For tapering tools, it is the angle of the tool cone as shown in the figure below



Rot: Type of rotation of the tool. 1=Clockwise; 2=Counter-clockwise

Max. speed: Maximum tool speed advance

Max. rot. speed: Maximum tool rotation speed

IdField: Indicates to which field the tool belongs

Tools : DEF

</

Functions available in the tool bar

Refer to the description above.

A description of the fields in the DISC MILLS sheet programming spreadsheet

Number: The disc number

E: Activates or deactivates the tool

Def: The selected tool is default for the category to which it belongs

Code: Tool code

Description: Tool description

Type: Tool point type

Radius: Disc radius

Thickness: Disc thickness

Rot: Type of rotation of the tool. 1=Clockwise; 2=Counter-clockwise


Working Crown: Disc crown


Max. speed: Maximum disc advance speed

Max. rot. speed: Maximum disc rotation speed

IdField: Indicates to which field the tool belongs

Definition of a forming tool

The button  in the tool bar is used to define a tool and open the following window:




A description of the fields

Tool: Tool selected from the active page


Tool type: Type of selected tool bit

Angle: Value of the coning angle of the selected tool (only enabled if the bit type is conical/tapering or if the bit type is changed)

Diameter: Value of the diameter of the selected tool

Color: Color of the tool that must be created. To change the color, just click on the button 


Description of button functions



Updates the tool with the new values of the parameters that have been edited. (Bit type, Angle or Color)



Used to select a profile created before opening this window on the active document of Genio, which will lead to the creation of a forming tool.



Saves the changes


N.B.

Selection of the profile envisages a single geometry of the open Polyline type.

The definition procedure requests selection of the geometry and then requests the low point on the axis of rotation. (See example below)

E.g. Definition of a tool


1. Open a new drawing or draw the profile of the tool to be defined using the drawing instrument ->Polyline




2. Click on the button  in the tool bar

3. Click on the button 

4. Select the geometry




5. Select the point on the geometry that defines the axis of rotation



6. The tool will be defined at this point according to the selected profile




.Note: upon completion of defining the new tool, the following message may be displayed:



Press **Yes** to update the tool diameter with the new value determined in accordance with the selected profile

Press **No** if the value of the tool diameter is not to be changed.



Functions available in the tool bar


Refer to the description above.

A description of the fields in the HEADS sheet programming spreadsheet

- Num:** Head number
- Type:** Head type
- Group:** Group of the head
- Ord.:** Order of the head inside the group.

Edge-band store data programming

This is used to set and display data related to the edge bands.(Only for edge banding)



Edge											
	Canal	Edge	Color	Height	thickness	Code	Remark	H	I	J	K
1	1	1	0	10	5	Brd1					
2	2	0	1	5	4						
3	3			50	10						
4	4				5						
5											
6											
7											

Functions available in the tool bar


Refer to the description above.

A description of the fields in the programming spreadsheet

Canal:	Canal on which the edge is to be found
Edge:	Identification of the edge
Color:	Color of the edge
Height:	Height of the edge
Thickness:	Thickness of the edge
Code:	Any code
Remark:	Any comment

Edge-banding configuration data programming

This is used to set and display data related to the edge-banding configuration.(Only for edge banding)



EDGE BANDING DATA						
A1 Slope down distance (X-EIN)						
	Parameter	Value	C	D	E	F
1	Slope down distance (X-EIN)	620,000				
2	Slope down angle (Y-EIN)	800,000				
3	Vector axis rotation (A-EIN)	18,000				
4	Edge increase (E-EIN)	1,000				
5	Multi-edge enable	True				
6	Distance rendez-vous-profile (D-EIN)	5,000				
7	Rendez-vous Angle (B-EIN)	8,000				
8	Vector angle in the point RV (R-EIN)	120,000				
9	Wait in the point R1 (TIN-EIN)	10,000				
10	Start point Lamp (LAMP-EIN)	50,000				
11	Slop down speed (V_CAR-EIN)	80,000				
12	Vector angle at point COINI (C_COINI-EIN)	20,000				
13	Dist. between p.ts R1INI-SBINI (D_R1INI-EIN)	15,000				
14	Vector Angle at point R1INI (C_R1INI-EIN)	15,000				
15	Dist. between p.ts R2INI-R1CI (D_R2INI-EIN)	10,000				
16	Vectro angle at point R2INI (C_R2INI-EIN)	32,000				
17	Dist. between p.ts SBINI-R1INI (D_SBINI-EIN)	2,000				
18	Entry quote con-roll (D-ECLOSE)	1,000				
19	Final point Offset (I-ECLOSE)	4,000				
20	Search angular reference	32,000				
21	Offset Vector axis (A-ECLOSE)	20,000				
22	Search axis speed (O-ECLOSE)	1,000				

Functions available in the tool bar

Refer to the description above.


A description of the fields in the programming spreadsheet

Parameter: Indicates the parameters related to the edge banding

Value: Indicates the values related to edge-banding parameters

Parameters

(For description see Xilog³MMI-RoutoLink user guide)



	Parameter name	Value	Description
1	Bordo	124	BORDO DA FORMARE
2	Prova2	12	Parametro di prova
3	Prova1	13	Nuovo parametro
4			
5			
6			

Functions available in the tool bar

Refer to the description above.

A description of the fields in the programming spreadsheet (parameters used only with Edge-Banding instructions EIN/EOUT/ECLOSE)

In the spreadsheets named EIN, EOUT and ECLOSE are programmed only supplementary parameters that will be automatically added for each Edge-Banding operation respectively to EIN, EOUT and ECLOSE section.


Parameter Name: Name of the supplementary parameter

Value: Value of the parameter

Description: Description of the parameter

Programming of the supports data

This is used to program and display data related to the supports available.



Supports			
B4 0.00			
	Parameter	Value	Description
2	Offset Y	0.00	
3	Quota minima del piano	0.00	
4	Quota massima del piano	0.00	
5	Dimensione X del piano	0.00	
6	Dimensione Y del piano	0.00	
7	Ingombro X lato sinistro	0.00	
8	Ingombro Y lato destro	0.00	
9	Num. massimo ventose	0	
10	Forma ventose	0	
11	Offset X quota del piano	0.00	
12	Offset Y quota del piano	0.00	
13	Posizione battute	0	
14	Posizione ventose	0	
15	Barre scorrimento	0	
16	Dimensione X barre scorrimento	0.00	
17	Dimensione X ventosa 1	0.00	
18	Dimensione Y ventosa 1	0.00	
19	Dimensione X ventosa 2	0.00	
20	Dimensione Y ventosa 2	0.00	
21	Dimensione X ventosa 3	0.00	

Functions available in the tool bar

Icon	Rapid selection	Function description
		Import a tool file
		Import general data
		Save the data programmed in the video



Export general data



Print the document



Remove the selected lines from the spreadsheet



Copy the selected lines



Paste in the lines selected previously



Add a line before the selected line



Exit the programming page

A description of the fields in the programming spreadsheet

Table number: Is selected by selecting one of the “Tables” on the bottom left of the work sheet

Parameter: Indicates the parameters relative to the supports

Value: Indicates the values relative to the supports' parameters

Comment: Any comments

Parameters: (Please refer to the Xilog/Xilog Plus user manual for a description)

Top number:

Offset Y:

Minimum top elevation:

Maximum top elevation:

X dimension of the top:

Y dimension of the top:

X volume left side:

Y volume right side:

Max. no. Suction cups:

Suction cups form

Offset X top elevation:

Offset Y top elevation:

Ledge position:

Suction cups position:

Sliding bar.

X dimension sliding bar.

X dimension suction cup number.

Y dimension suction cup number.


Suction cups elevation:

Min elevation suction cup number:

Max elevation suction cup number:

Macro programming

Allows you to program and display the data relative to the macro user as well as the variables relative to the macro user.



In general:

- A macro is identified by a name (for example, MACRO1). And each Macro is associated with a series of instructions until an empty line or another Macro name is reached.

The instructions have an identifier that is a string that belongs to a series of reserved words (->simple instructions) or they can, in turn, be a macro (a macro may contain another macro->composed instructions).

Every reserved word is followed by a sequence of parameters that can be:

- Numerical values
- The variables defined by the user in the variable sheets

Eg. Step = 32

BordDist = 20

- Simple expressions with Excel syntax

Eg. PanL/3 or A1 + PanW / Step

- Conditional expressions with Excel syntax

Eg. If (PanL < 100; Step/2; Step/2.2)

















The simple instructions' reserved words are listed and described in section 2.

N.B. There will be a TEST push-button in the Macro Worksheet that will allow the user to test the macro's result on an imaginary test panel.


- **Additions/Removals:** One or more macro, from the edited ones, can be associated with a panel, the macro can also be removed (please refer to “Macro inserts” modify menu). A macro can be repeated several times inside the same panel with the values of different variables.

- **Macro (parameters) variables:** a macro may contain instructions with variable values, the variables have an identifier that has been associated with a default value contained in the macro folder's variables file. The operator may modify the macro's variables' value when they are inserted among the panel machinings.

Functions available in the tool bar

Icon	Rapid selection	Function description
		Allows to open a spreadsheet stored in *.VTS or Excel *.XLS file format or to import CNC programs written in *.PGM or *.XXL Xilof format.
		Export data as *.VTS or Excel *.XLS spreadsheets.
		Save the data programmed in the video
		Search and replace words or items inside the spreadsheet
		Print the document
		Remove the lines from the spreadsheet selected
		Copy the lines from the spreadsheet selected
		Paste in the lines selected previously
		Associate an image with an instruction or a macro
		Show image preview
		Allows you to program and modify the data relative to the variables relative to the macro user.
		Conduct a pre-test of the macro selected in the MACRO sheet
		Add a line before the selected line
		Insert a page after the active page of the open file
		Delete the active page of the open file
		Exit the programming page

VARIABLES sheet



	Variable name	Value	Description
1	Dx	620	
2	Dy	800	
3	Dz	18	
4	FLD	1	
5	TOOLN	101	UTENSILE DI LAVORO
6	RADIUS	5	RAGGIO RACCORDO ANGOLI
7	DIAM	8	DIAMETRO PUNTA PER FORATURA OTTIMIZZATA
8	DISTR	120	DISTANZA CANALE DAL BORDO DEL PANNELLO
9	INDX	10	DX INGRESSO DAL BORDO PER LA MACRO TOEK
10	INDY	50	DY INGRESSO DAL BORDO PER LA MACRO TOEK
11	OUTDX	80	DX USCITA DAL BORDO PER LA MACRO TOEK

A description of the fields in the VARIABLES sheet's programming spreadsheet

Variable name: The variable's name


Value: The variable's value

Description: The variable's description

N.B. The names of the variables, Dx, Dy, Dz, correspond respectively with the length, width and thickness of the panel and cannot be used in that they are reserved words)

NOTE: The variables that have not been described are inserted by the user and, therefore, the description of their functions will be left to the discretion of the person inserting them.

MACRO sheet



	Macro name	Identifier	Par.1	Par.2	Par.3	Par.4	Par.5	Par.6	Par.7	Par.8	Par.9
1											
2	NSTMACRO1										
3		:001									
4		:									
5		:NESTING Q=0									
6		:LABEL X=310 Y=2100									
7		:LABEL X=950 Y=2100									
8		:LABEL X=950 Y=1280									
9		:LABEL X=310 Y=1280									
10		:LABEL X=310 Y=460 Q=1									
11		F	1								
12		: Lavorazioni									
13		C	2	0							
14		XG0	400	1700	20				101		XG_5
15		XL2P	620	1700							
16		XL2P	620	2500							
17		XL2P	0	2500							
18		XL2P	0	1700							
19		XL2P	400	1700							
20		C	0	0							
21		XG0	640	1671	4				101		XG_4
22		XL2P	1260	1671							

A description of the fields in the MACRO sheet programming spreadsheet

Macro name:	The macro name created by the user
Identifier:	The Macro's instruction code
Parameter number:	The parameters relative to the macro instructions

The instructions (reserved words) handled by the macro (the syntax is similar to the Xilog instructions):

Instruction column: The column where the macro instructions will be inserted. The column is number 2.

XB – Boring:	Carries out one or more non-optimized holes.
XBO – Optimized Boring:	Carries out one or more holes, making use of the boring optimization algorithm.
F – Work face:	Defines the active work face for the following instructions.
XBR – Slanting Boring:	Allows for the creation of one or more Slanting holes, compared to the squareness of the work surface.
C – Tool correction:	Allows for the correction of the path of the spindle, with reference to the characteristics of the mill that has been mounted.
XG0 – Start milling:	Defines a profile starting point.
G1 – Linear milling:	Defines a line segment.
G2 – Clockwise circular milling:	Defines a clockwise circular arc (which goes from the Y axis to the X axis of the system to which reference is made).
G3 – Counter-clockwise circular milling:	Defines a counter-clockwise circular arc (which goes from the X axis to the Y axis of the system to which reference is made).
G5 – Milling section at a tangent to the previous section:	Defines a milling section tangent to the previous one.
XN – Operation null:	Turn off the rotations and stop the spindles
XPL – Slanting plane:	Allows the Slanting plane absolute condition.
XO – Panel origin movement:	Moves the panel origin to the programmed position.
XL2P – Segment for two points:	Defines a line segment.
XA2P – Arc for two points:	Defines a circular arc given two points.
XA3P – Arc for three points:	Defines a circular arc given three points. The depth of the intermediate point may be different from the final point one.
XAR – Arc given the radius:	Defines a circular arc given the radius.

XAR2 – Arc given the radius 2:	Defines a circular arc given the radius.
XEA – Elipse arc:	Defines an elipse arc and also generates the start milling instruction.
XGFIL – Circular connecting milling:	Performs circular connecting milling between the milling programmed before this instruction and the one programmed after this instruction.
XGCHA – Circular rounding milling:	Performs circular rounding milling between the milling programmed before this instruction and the one programmed after this instruction.
XGIN – Automatic profile entry:	Defines a line or circular arc tangent to the profile in the point of entry.
XGOUT – Automatic profile exit:	Defines a line or circular arc tangent to the profile in the point of exit.
XG0R – Milling start with Slanting tool:	Allows a milling start with a Slanting tool on a table that is not square to the panel's surfaces.
XG1R – Linear milling with Slanting tool:	Allows for linear milling on a Slanting table compared to the squareness of the panel's surfaces; it should be used with Slanting tools, it always refers to face 1 (F=1).
XG2R – Circular clockwise milling with a Slanting tool:	Defines circular milling (or circular arc) on the Slanting table compared to the squareness of the panel's surfaces, with clockwise advance movement (which goes from the Y axis to the X axis of the reference system).
XG3R – Circular counter-clockwise milling with a Slanting tool:	Defines circular milling (or circular arc) on the Slanting table compared to the squareness of the panel's surfaces, with counter-clockwise advance movement (which goes from the X axis to the Y axis of the reference system).
XG5R – Milling section at a tangent to the previous one with Slanting tool:	Defines a milling section tangent to the previous one, with a Slanting tool.
PAR – Declaration of a parameter:	Declares a parameter inside a macro. The parameters may be passed as value to the macro from outside. (From another macro or macro parameters window).
VAR – Declaration/Change of variable:	Declares a variable inside a macro. A declared variable inside a macro may be changed inside the same macro, always through the VAR instruction
WHILE – Cycle start instruction:	Allows a cycle to be executed in the presence of a condition. As long as the condition is verified, the same operations will be carried out.
WEND – Cycle end instruction:	Instruction that takes the cycle back to the start (WHILE) for verification of the condition.

FileMsg – Name of parameter description file: Sets the name of the reading file for loading the description of the parameters associated with the macros

Visible – Display of macros: Allows the macros, among those that can be inserted, to be displayed or not in the macro insertion window. TRUE=Visible, FALSE=Invisible

DefaultCallSheet – Sheet name for macro reference: Sets the name of the sheet to examine for calls to macros that are not present on the same sheet or that require it.

1-Default sheet unnecessary because the call already includes the sheet name. E.g. SHEET1.Handle

2-Default sheet necessary only the Handle macro is not on the same sheet. E.g. Handle

If these situations are not present or you want the sheet being examined to be that of the starting macro, just set this instruction

DefaultCallSheet=THISSHEET or don't put anything.

@Numero Messaggio – Message associated with a parameter: Allows the description of a parameter to be displayed when the button "Modifica Variabili" (Change Variables) is pressed from the window "Lista Macro" (Macro List) and when the window "Dati Istruzioni" (Instruction Data) appears and the parameters are scrolled.

N.B.

If variables not declared in the Parametric Export are used in the formulas in Macro programming and Parametric machinings, they will not be declared in the automatic mode


Insertable functions or constants: See **F1BOOK.PDF**


E.g.

	Macro name	Identifier	Par.1	Par.2	Par.3	Par.4	Par.5
1		FileMsg	Assemblagg				
2		Visible	TRUE				
3		DefaultCallSheet	CABINETPR				
4	Camlock	:@1					
5		PAR	pD	15 @2			
6		PAR	pX	32 @3			
7		PAR	pY	50 @4			
8		PAR	pZ	13 @5			
9		PAR	pG	8 @6			
10		PAR	pL	8 @7			
11		PAR	pI	26,5 @8			
12		PAR	pJ	18 @9			
13		PAR	pH	10 @10			
14		PAR	pQ	1 @11			
15		PAR	pS	32 @12			
16		:Foratura faccia sini					
17		F	3				
18		XBO	10	50	26,5	8 P	
19		XBO	10	82	18	8 P	
20		XBO	10	300	18	8 P	
21		XBO	10	550	26,5	8 P	
22		XBO	10	518	18	8 P	

Wizard macro

It allows to modify or to program the values of the parameters of an instruction or of the parameters associated with a macro.



It is approached the window from the button  of the toolbar or with double click on the line of the instruction.



A description of the fields:

Parameter	Instruction parameters
Value	Value of the parameters

A description of the push-button functions

	Save the changes
	Cancel the changes

1. How to insert a variable into the Macro folder

The following variables have been inserted into the example given below:

Step which will be used for the distance between the holes of a barrier

XX1 which will be used for the distance of the holes from the left edge of the panel

YY1 which will be used for the distance of the holes from the top edge of the panel

Macro

A31

Passo

	Variable name	Value	Description
22	BORDA	1	
23	TESTR	50	
24	MDX	3,5	
25	NHX	486,5851722	
26	FXC	4,1299	
27	RIPFOR02	1	
28	DISTFOR	20	
29	XX1	30	
30	YY1	20	
31	Passo	32	

VARIABLES

Macro

DOORS

ASSEMBLY

STANDARD

HINGES

HARDWARE

CABINETPRIVATE

Foglio

H DX=3000

2. How to use the variable declared in a Macro.

The variables declared in the VARIABLES sheet for a parametric barrier of holes contained in the macro Barrier1 are used below.

The variables are used in a formula as shown below (the numerical result appears directly in the cell of the worksheet).
IMP.. The symbol “equals” (=) should be put before the formula

The screenshots illustrate the use of variables in a macro editor. Each screenshot shows a table with the following structure:


	Macro name	Identifier	Par.1	Par.2	Par.3	Par.4	Par.5	Par.6	Par.7	Par.8	Par.9	Par.10	Par.11
138	DRILL1	XB0	30	20	18	10					24.375	0	32

The screenshots show the following formulas being entered into the macro editor:

- C138:** $=XX1$ (Arrow points to Par.1 value 30)
- D138:** $=YY1$ (Arrow points to Par.2 value 20)
- E138:** $=Dz$ (Arrow points to Par.3 value 18)
- K138:** $=(Dy*YY1)/Passo$ (Arrow points to Par.9 value 24.375)
- M138:** $=Passo$ (Arrow points to Par.10 value 0)



3. How to insert the Macro.

The macro may be inserted from the Edit/Insert Macro menu of the Genio control panel (Ref.Guide).
In the example given below, two instances of the Macro Barrier1 (Barrier1_1 and Barrier1_2) have been inserted, changing the step between the holes (Passo Variable) and the distance from the left edge (XX1).



4. How to change the parameters of a macro.

The parameters of a macro may be changed by clicking on the button " Modify variables " (Change Variables) after having selected a macro from the "Selected" (Selected) list.




Description:	Description of the parameter
--------------	------------------------------

Macro										
D19		=2*PI()/CORNERS								
	Macro name	Identifier	Par.1	Par.2	Par.3	Par.4	Par.5	Par.6	Par.7	Par.8
10	STAR1	PAR	CX	400						
11		PAR	CY	300						
12		PAR	RADIUS	400						
13		PAR	CORNERS	6						
14		PAR	TOOL	101						
15		PAR	PROF	10						
16		PAR	PROP	0,5						
17		VAR	ANG	0						
18		VAR	RAD1	200						
19		VAR	INCANG	1,0471976						
20		WHILE	TRUE							
21		XG0	400	500	10				101	
22	Sintax used for variable declaration	XL2P	600	646,41016						
23		XL2P	573,20508	400						
24		VAR	ANG	2,0943951						
25		WEND	Name of variable							

Result of formula in the variable

Result of the STAR1 macro



Call of one macro inside another

Macro

B75 =FNNAME

	Macro name	Identifier	Par.1	Par.2	Par.3	Par.4	Par.5	Par.6	Par.7	Par.8
62	FIGLINE	PAR	PX1	0						
63		PAR	PY1	0						
64		PAR	PX2	800						
65		PAR	PY2	400						
66		PAR	SIZE	200						
67		PAR	STEPS	8						
68	Macro Name	PAR	FNNAME	"STARFIG						
69		VAR	PXINC	114,28571						
70		VAR	PYINC	57,142857						
71		VAR	PXV	0						
72		VAR	PYV	0						
73		VAR	VSTEP	1						
74		WHILE	TRUE							
75		STARFIG	114,28571	57,142857	200	101	10			
76		VAR	PXV	228,57143						
77	Call of the macro	VAR	PYV	114,28571						
78	STARFIG to the inside	/AR	VSTEP	3						
79	of the macro FIGLINE	NEND								
80										


Source Macro. Default Values

Parameters value to associate to the macro(STARFIG). If omitted will be use the default values of the of the source macro

VARIABLES DEMO1 MACRO FACCE MACRO_1 MACROSYS Macro1

=FNNAME


Result of the FIGLINE macro



Import of CNC programs as parametric Macros

It's possible to import programs written in the CNC language (i.e. *.PGM and *.XXL) as parametric macros by clicking the "Import" button of the toolbar of the Macro window as follow.


1. Select the spreadsheet where you want the programs will be imported as macros of Genio.
Note: do not select the "Variables" spreadsheet.




2. Click on the button "Import"



3. Select one or more program to import and then confirm with the "Open" button of the window (a macro will be written for each program successfully imported).




- Wait until the end of the import procedure, after this Genio will display a message with the number of macros and statements written, otherwise an error message will be displayed. The imported macros will be written starting from the first empty row of the selected spreadsheet.



Management of passing macros

These macros may be declared and called inside other macros. Genio acknowledges them, considers them valid and exports them, but graphically they have no effect. This management serves for those machines that support or require special macros. To insert and edit this type of macro, open the file **ExtMacro.ini** to be found under the folder **CFG** in the Genio main directory.



```
#Declare external macro used in CAM program visible by GENIO
#
#Usage:
#[EXTMACRO]
#NAME="MacroName"
#MACHINETYPE=N (n=0 Author n=6 Ergon , n=... view in SpaiOem.ini
#PAR="Parameter Name",
#      T (T=INT integer data, T=DBL double data, T=STR string data) ,
#      B (0=optional parameter , 1=required) ,
#      R (0=no misure, 1=misure)

#XCLEAN Q=... a=... s=...
#used only for Ergon machine type
[EXTMACRO]
NAME="XCLEAN"
MACHINETYPE=6
PAR="Q",DBL,1,1
PAR="a",INT,1,0
PAR="s",DBL,1,0
```

A description of the fields in the file


[EXTMACRO]	Name of macro section
NAME	Macro name
MACHINETYPE	Machine type
PAR	Parameter name
T	Parameter type
B	Indicates if the parameter is required or can be omitted 0/1
R	Indicates if the parameter is one measure or less 0/1

A simple example is given in the window shown above.

Programming a mix


New mix

Allows you to open a new programming mix spreadsheet.




Open Mix

Allows you to open an existing programming mix.







Programming mix spreadsheet



	Code	DX	DY	DZ	R	AREA	FTOOLS	C	T	UM	NF	BX	BY	BZ	V
1	C:\Documenti	5000,000	4000,000	18,000	1	A	DEF	0	0	MM		0,000	0,000	0,000	
2	C:\Documenti	5000,000	4000,000	18,000	3	A	DEF	0	0	MM		0,000	0,000	0,000	
3	C:\Documenti	5000,000	4000,000	18,000	4	A	DEF	0	0	MM		0,000	0,000	0,000	
4	C:\Documenti	5000,000	4000,000	18,000	1	A	DEF	0	0	MM		0,000	0,000	0,000	
5	C:\Documenti	5000,000	4000,000	18,000	5	A	DEF	0	0	MM		0,000	0,000	0,000	
6															
7															

Functions available in the tool bar

Icon	Rapid selection	Function's description
		Opens the list of possible dwg files that can be inserted.
		Import general data
		Save the data programmed in the video
		Export general data
		Print the document
		Removes the lines from the selected spreadsheet
		Copies the lines from the selected spreadsheet
		Pastes in the lines selected before.
		Inserts a line before the selected line.
		Carries out the export mix.
		Exit the programming page.

A description of the fields in the programming spreadsheet

Code:	the program name.
DX:	the panel's dimension in X.
DY:	the panel's dimension in Y.
DZ:	the panel's dimension in Z.
R:	the number of the same panels to be produced (max 9999).
AREA:	the working area in which the program is to be performed; the allowed values are A, B, C, D, AB, BA, CD, DC, AD, DA.
FTOOLS:	the name of the file with the tool data.
C:	the type of work; the values allowed are 0 for normal working and 1 for continuous working.
T:	activates (1) / deactivates (0) the lifters (if present).

- UM:** unit of measurement; the allowed values are MM (millimeters) and IN (inches); if the file is omitted, the unit of measurement specified in the machine's parameters is valid.
- NF:** the name of the file with environment variables.
- BX:** the X dimension of any shim located under the panel;
- BY:** the Y dimension of any shim located under the panel;
- BZ:** the Z dimension of any shim located under the panel;
- V:** activates / deactivates the blocking of the item and the control over the position of the automatic supports (if present), in compliance with the following table:

Field V	Blockage	Automatic Supports Control
Blank	Yes, using the system configured in XILOG3.CFG; if there Vacuum and pressure switches have been foreseen, the first are enabled.	Yes
0	Mechanical	No
1	Mechanical	Yes
10	Yes, using the vacuum switches	No
20	Yes, using the pressure switches	No
11	Yes, using the vacuum switches	Yes
21	Yes, using the pressure switches	Yes
30	Yes, using both vacuum and pressure switches	No
31	Yes, using vacuum and pressure switches	Yes

Panel data and machinings programming

Genio's working parameters programming pages, can be accessed from the Control Panel's Toolbar by means of the following push-buttons:

- Panel management
- Active work face
- Boring management
- Milling management



In general


The Tool Bar buttons contain those sub-headings that allow access to the functions provided by the machining class:

- The “Panel Management” contains the headings for programming the panel and supports' data;
- The “Active Work Face” button contains the headings for the choice of face to activate;
- The “Boring Management” button contains the headings for programming the boring working processes;
- The “Milling Management” button contains the headings for programming the milling, pocketing, carving, and cutting machining processes.

Just select the relative heading for programming the working process, program the relative pages on the Control Panel page, press the “APPLY” push-button: the working parameters will be applied to the corresponding geometry that has been drawn on the Genio video and can be sent to the work center.

Apply button


The APPLY button is present on all Control Panel programming pages and is used to confirm programming page data.




Introduces changes to the panel according to programmed data

N.B. The APPLY button function may be accessed directly from the keyboard using the keys <ALT> + <SEND>.


IF button




IF>>: Used to set a condition that enables or not the machining to be carried out. (The instruction IF is exported). If the IF button on the Genio Toolbar is enabled,  machining will only be displayed if the condition is satisfied

Remark: Eventual comment.

A description of the push-button functions



Cancel the changes



Save the changes

Supported geometries

The list of possible machinings is given below with the respective supported geometries:

<i>Machining</i>	<i>Geometries</i>							
	Line	Arc	Circle	Ellipse	Polyline	Lightweight Polyline	Polyline 3D	Spline
Vertical boring			X					
Horizontal boring			X					
Slanting boring (route)	X	X	X	X	X	X	X	X
Vertical milling	X	X	X	X	X	X	X	X
Slanting milling	X	X	X	X	X	X	X	X
Pocketing ^(*)	X	X	X	X	X	X	X	X
Engraving ^(*)	X	X	X	X	X	X	X	X
Cut	X	X	X	X	X	X	X	X
Edges XY management	X	X	X	X	X	X	X	X
Cleaning inside corners	X	X	X	X	X	X	X	X
Edge Banding	X	X	X	X	X	X	X	X
End Trim	X	X	X	X	X	X	X	X
Trimming	X	X	X	X	X	X	X	X
Scraping	X	X	X	X	X	X	X	X
Finish	X	X	X	X	X	X	X	X

^(*) The geometries must be closed for these machining processes.

Definition

The definition pages, that can be accessed from the Tool Bar's Description panel menu, will allow you to program the values and data relative to the characteristics of the panel that you wish to create.

The screenshot displays the 'CONTROL PANEL Ver. 3.0.0' window. The 'Definition' tab is selected in the left-hand menu. The main area shows the 'PANEL' configuration section. It includes a 3D visualization of a yellow rectangular panel with blue dashed lines indicating dimensions. Below the visualization, the following fields are present:

- Name:** Pannello1
- Description:** Descrizione Pannello1
- Length (Dx):** 620,000
- Width (Dy):** 800,000
- Thickness (Dz):** 18,000
- Field:** A
- BX:** 0,000
- BY:** 0,000
- BZ:** 0,000
- Tooling file:** def
- Macro:** Macro name

A description of the fields

Name: The panel name

Description: **The panel description**

Panel length: Panel length (DX)

Panel width: Panel width (DY)

Panel thickness: Panel thickness (DZ)

Field:



The working area in which the program must be performed; the allowed values are A,B,C,D,AB,BA,CD,DC,AD,DA

Bx: The X dimension of any shim located under the panel.

By: The Y dimension of any shim located under the panel.


Bz: The Z dimension of any shim located under the panel.

Tooling file: Used to select the file containing the tools for machining this panel

Macro:

Macro name: The name of the selected macro

A description of the push-button functions



Apply any changes to the panel on the basis of the data relative to the data indicated below




Start the **geometries normalization utility**.

This function is useful to resize panel in respect of the geometries of the AutoCad drawing , to center geometries on the panel and to normalize them with layer 0 and normalization z=0.


Note: the function has no effect on programmed routing path or blocks or text.

After having clicked the button the following window will be displayed




A description of the fields


Selected Geometries: Number of selected geometries in the graphic window



Exit from the geometries normalization utility



Store the selection set and open the following window



A description of the fields

Selected Geometries: Number of selected geometries in the graphic window

Center: If checked, the panel will be resized so that the minimum distances from selected geometries and panel edges will respect the parameters programmed below.

Left X: Minimum distance between the selected geometries and the left panel edge

Right X: Minimum distance between the selected geometries and the right panel edge

Top Y: Minimum distance between the selected geometries and the upper panel edge

Bottom Y: Minimum distance between the selected geometries and the lower panel edge



Select a rectangle for panel dimensions Used to select a rectangle on the Autocad window that will make up the new panel outside dimensions with set trims (rather than calculate the dimensions from the geometries)


Move all selected objects If selected, all the selected objects will be shifted

Move all but machinings If selected, all the selected objects will be shifted except the machinings


Move only geometries If selected, only the selected geometries will be shifted

Set Layer 0: If checked, all the selected geometries will be set on layer 0.

Set Z=0: If checked, all the selected geometries will be set with elevation Z=0.



Apply the changes



Stop the elaboration



Each time the panel is pushed the panel and the programmed machinings are rotated by 90 degrees counter-clockwise.




Each time the panel is pushed the panel and the programmed machinings are rotated by 90 degrees clockwise



Allow to program the coordinates of the point where the label will be attached (only for nesting with automatic label applicator)

Supports programming

The supports programming page, which can be accessed from the Tool Bar Description menu, allows for the programming of the values and data relative to the supports handling.



A description of the fields

- Panel:** The panel dimension
- Activate supports:** Activates or deactivate the support handling
- Table number:** The number of the active support table
- Suction cup number:** The number of the active suction cups
- X:** The value of the center of the active suction cup on the X axis
- Y:** The value of the center of the active suction cup on the Y axis

A description of the push-button functions

- APPLY** Apply any changes to the panel on the basis of the data relative to the data indicated below

Ergon management

If the options in configuration include "Ergon" for the machine type, the following will appear in the Boring and Milling pages:


For Vertical Boring (normal), Horizontal Boring (normal), Slanting Boring, Slanting Milling, Pocketing, Engraving, Cleaning of Corners



For Vertical Boring (Optimized), Horizontal Boring (Optimized))




For Vertical Milling, Cutting




A description of the pushbutton/field functions

Head



This pull-down window shows all the possible useable heads with the tool selected for synchronous machining.

Group



This pull-down window shows all the possible useable groups with the tool selected for synchronous machining.

Legend:

H: Head number

T: Type

G: Group

O: Order


E: In the selection of a tool this indicates that it is an External Tool. Consequently all the heads that have type T other than 9 are considered.

E.g.

Initial feeler pin: Sets the feeler pin gain value at the start of machining (only for vertical milling or cutting)




For synchronous machining (with several panels at a time) this button allows the following window showing all the available heads to be displayed. All these heads have equal type and order but different group compared to the one marked in red. To see which are being used at the time just see whether or not the corresponding boxes are enabled. The head in use at that moment is always marked in red.




A description of the pushbutton functions



Add a line that may be edited by the user, in which any tool and any head may be specified



Save the changes




Undo the changes



(Only for vertical milling or cutting)


When Inserisci (Insert) is selected from the menu, the following window appears





A description of the fields

Gain: Feeler pin gain (See Xilog manual)

A description of the pushbutton functions




The user may add the gain value by clicking on any point at will along the path of a machining.




Close the window



Whereas, when selecting Modifica (Edit) from the menu, the user must select a Gain previously inserted along the path of a machining.



The following window then appears



A description of the fields

- X:** Coordinate on the X axis of the Gain value
- Y:** Coordinate on the Y axis of the Gain value
- Gain:** Gain value.

A description of the pushbutton functions




Change the selected Gain value.



Close the window

Vertical boring

The vertical boring page, which can be accessed from the Tool Bar's boring File menu, allows the user to program the values and data relative to the handling of the vertical boring referred to the work face.



CONTROL PANEL Ver. 3.4.0B

File Modify Tools Utility

APPLY

VERTICAL BORING

Type: Normal

Tools: - DEF

4 8,000 P

☐ Coordinates on the screen
☒ Input starting point and end
☐ Input starting point and pitch

☒ Through boring
☐ Join

Diameter	Depth
8,000	19,000

X Initial: 156,972
 Y Initial: 112,480
 X Final: 404,056
 Y Final: 260,445

Pitch: 32,000

Drillings discharge

IF: =Dx>Dy

A description of the fields

Name of selected machining

Type

Normale

The type of boring to carry out. If normal, just choose the tool, whilst if it is optimised, you just have to choose the tool diameter and the type of point.

Tools

3 10 P

The tools available for non-optimised boring or point-type couples, the diameter available for the optimised boring

- **Coordinates on the screen:**

If allowed, the co-ordinates are not inserted manually but on the panel directly

- **Insert starting point and finish point:**

If allowed, it requires the insertion of the starting X, the starting Y and the final X and final Y

- **Input starting point and pitch:**

If allowed, requests the insertion of the initial X, the initial Y and the co-ordinates of the pitch to be maintained between one hole and another.

Through boring:

If activated, programs a greater boring thickness in the panel

Join:


If allowed, it transforms N boring in one single boring.

Diameter:

The diameter of the holes



If enabled, prior to carrying out a Slanting Boring (only possible on top face) or a Vertical Boring on inclined surface or on top face, this can be used to set a height from the working surface that will be the distance between the lowest point touched by the drill bit and the panel bottom.



A description of the push-button functions

OK


Recalculate the depth according to the set value of the height from the working surface

Cancel


Close the window

Depth

The depth of the holes

X Initial:	The initial boring point on the X axis
Y Initial:	The initial boring point on the Y axis
X Final:	The final boring point on the X axis
Y Final:	The final boring point on the Y axis
Pitch:	The distance between one boring and another
Drilling discharge:	The number of steps for drilling discharge
If allowed “Insert start and pitch point”:	
X Pitch:	The pitch to be maintained between one hole and another on the X axis
Y Pitch:	The pitch to maintain between one hole and another on the Y axis
Number holes:	The number of holes to perform
IF>>:	Used to set a condition that enables or not the machining to be carried out. (The instruction IF is exported). If the IF button on the Genio Toolbar is enabled,  machining will only be displayed if the condition is satisfied

A description of the push-button functions



Apply the changes to the panel on the basis of the relative data and data below



Display the data relative to the boring selected on the panel



Explode a boring barrier in single holes

Horizontal boring

The horizontal boring page, which can be accessed from the Tool Bar boring File menu, allows your to program the values and data relative to the horizontal boring that is referred to face 1.

The screenshot shows the 'CONTROL PANEL Ver. 3.0.0' window. The 'Tools' menu is open, showing options for 'Vertical boring', 'Horizontal boring' (selected), and 'Slanted boring'. Below the menu, the 'HORIZONTAL BORING' configuration panel is visible. It includes fields for 'Type' (Normal), 'Tools' (- DEF), and a dropdown for '62 Boring Bit 8,000 P'. The 'Face' section shows a 3D model with faces 2, 3, 4, and 5. The 'Coordinates on the screen' radio button is selected. The 'Diameter' is 8,000, 'Depth' is 12,000, and 'Z' is 9,000. The 'Initial distance' is 114,635, 'Final distance' is 530,635, and 'Pitch' is 32,000. An 'IF' field with a '>>' button is at the bottom.

A description of the fields

Name of the selected machining

Type

Normale ▼





The type of boring to perform. If normal, select the tool, whilst if optimized, just select the tool's diameter and the type of point.

Tools

60 8 P ▼

Tools available for non-optimized or point type couples boring, diameter available for optimized boring

Face:

-  **Face2** If selected, performs the milling on face2 of the panel
-  **Face3** If selected, performs the milling on face3 of the panel
-  **Face4** If selected, performs the milling on face4 of the panel
-  **Face5** If selected, performs the milling on face5 of the panel

Coordinates on the screen:

If allowed, the co-ordinates input does not occur manually but directly on the panel, clicking on the mouse on two points of the panel

Start and end distance:

The holes are programmed by setting the initial and the final distances from the selected face edges and the holes pitch

Start distance and step:

The holes are programmed by setting the initial distance from the selected face edges, the number of holes and the holes pitch.

Diameter:

Diameter of the holes

Depth:

Depth of the holes

Z:

Position of the hole of the horizontal axis of one of the panel faces

Initial distance:

Distance from the origin X axis, to the first boring.


Final distance:

Distance from the origin X axis, to the last boring.


Pitch:

Distance between one hole and another.

IF>>:

Used to set a condition that enables or not the machining to be carried out. (The instruction IF is exported). If the IF button on the Genio Toolbar is enabled,  machining will only be displayed if the condition is satisfied

A description of the push-button functions



Apply the changes to the panel on the basis of the relative data and data below



Display the data relative to the boring selected on the panel



Explode a boring barrier in single holes

Slanting boring

The Slanting boring page, which can be accessed from the Tool Bar boring File menu, allows you to program values and data relative to Slanting boring.



CONTROL PANEL Ver. 3.4.0B

File Modify Tools Utility

APPLY

SLANTING BORING

Tools - DEF

4 8,000 P

☒ Coordinates on the screen
☐ Input starting point and end
☐ Input starting point and pitch

☐ Join ☐ From drawing

Rotation angle

☒ A 34,000 ☐ B 45,000

Hole height

Rotation type

1

Diameter

8,000

Depth

14,142

Initial X

223,754

Initial Y

455,451

Final X

404,931

Final Y

587,174

Pitch

32,000

IF =Dx>Dy >>

A description of the fields

Name of selected machining

Tools:

3 10 P

Tools available for the Slanting boring

- **Coordinates on the screen:** If allowed, the input of the coordinates does not occur manually but directly on the panel
- **Input starting point and end:** If allowed, it requires the input of the initial X, the initial Y and the final X and final Y
- **Input starting point and pitch:** If allowed, requires the input of the initial X, the initial Y and the pitch coordinates to maintain between one hole and another.

Join:

If allowed, it transforms the N boring in one single boring.

From Drawing:

If allowed, executes a boring on one geometry .
The order of creation of the boring will follow the back of geometry

A description of the fields

Fixed angle:

Boring on assigned path


☒ Fixed angle
☐ Angle in respect of normal

Angle: 37


☒ Number of holes
☐ Distance between holes


Number: 32

OK Cancel



Angle in respect of normal:






Angle: The boring rotation angle (0-360).

Number of holes


Distance between holes

Number: The number of holes to perform or The distance between one boring and another

A description of the push-button functions



Executes the boring



Cancel the changes

Hole height: The hole height from the work table.

A Rotation angle: The boring rotation angle in respect of Z-Axis (the A angle: 0-360).


B Rotation angle: This parameter sets the tool angle in respect of Y-Axis (the B angle, enabled only if kind of machine is setted on X5).

Rotation type: If it amounts to 0, the A angle is added by means of algebra to the tool's R offset. If it amount to 1, the A angle replaces the tool's R offset.


Diameter: The tool's diameter.




If enabled, prior to carrying out a Slanting Boring (only possible on top face) or a Vertical Boring on inclined surface or on top face, this can be used to set a height from the working surface that will be the distance between the lowest point touched by the drill bit and the panel bottom.



A description of the push-button functions



Recalculate the depth according to the set value of the height from the working surface



Close the window

Depth:

The depth of the hole

Initial X:

The initial boring point on the X axis

Initial Y:

The initial boring point on the Y axis

Final X:

The final boring point on the Y axis

Final Y:

The final boring point on the Y axis

Pitch:

The distance between one boring and another

If allowed “Input starting point and pitch”:

X Pitch:

The pitch to maintain between one hole and another on the X axis.


Y Pitch:

The pitch to maintain between one hole and another on the Y axis.


No. holes:

The number of holes to perform.

IF>>:

Used to set a condition that enables or not the machining to be carried out. (The instruction IF is exported). If the IF button on the Genio Toolbar is enabled,  machining will only be displayed if the condition is satisfied

A description of the push-button functions



If pressed, applies the changes to the panel on the basis of the data below





Displays the data relative to the selected boring on the panel



Explodes a boring barrier in single holes

Vertical milling

The vertical milling page, which can be accessed from the Tool Bar milling File menu, allows you to program the values and data relative to the vertical milling.



A description of the fields

Name of selected machining

Tools

Tools available for the vertical milling

Side:



Left

Mills to the left of the geometry



Center

Mills to the center of the geometry



Right


Mills to the right of the geometry

If the cutter is disk-type:




Depth correction

(Only for disks) The machining will start and stop in the same start and stop points of the support geometry



No depth correction

(Only for disks) The disk tool will start and stop with its center aligned to start and end points of the support geometry.



Else:



Disabled outside



Outside

Mills to the outside of the geometry. (Applicable for a closed geometry)



Disabled Inside



Inside

Mills to the inside of the geometry. (Applicable for a closed geometry)

Direction:



Canonical

Mills in the same direction in which the geometry has been created



Inverted

Mills in the opposite direction to which the geometry has been created



Disabled Clockwise



Clockwise

Generate a clockwise milling. (Applicable for a closed geometry)



Disabled Counter Clockwise



Counter-clockwise

Generate a counter-clockwise milling. (Applicable for a closed geometry)

Overmaterial

Offset value for the tooling path in respect of the canonical path. It may be positive or negative depending on the direction of tool correction. (If the tool used for machining is a Disk and the multipass is the bi-directional type, in export the value of the overmaterial is set through the instruction SET USAW)

Join:

Joins all the milling with the distance minor one from another to the same one that has been programmed in the "distance" parameter

Distance:

The distance that is programmed for joining the milling

Bi-directional multi-passage:

Valid for non-closed profiles. If allowed, the tool performs the milling passages without always returning to the starting point; therefore, being able to work both forwards and backwards.



Bi-directional multipass





Normal multipass



Sloping. If enabled it carries out the machining, progressively increasing the depth.



Number of passages:

The number of passages that the tool must perform on the milling profile. After each passage, the depth of the machining increases until reaching the final one. The number of passes may be increased or decreased using the buttons  and  respectively.



Final passage depth:

Increase in depth for last pass. (See example)



Final passage speed:

Speed with which the tool carries out the last pass. If set, the pass will always be carried out at this speed. (See example)

E.g. The example shows a Milling with number of passages = 2, final passage = 5 and final passage speed=4.
The first pass will be carried out with these values:

$$\text{Initial depth} = (\text{Initial depth} - \text{Final passage depth}) / (\text{Number of passages} - 1) = (12 - 5) / 1 = 7$$

The Number of passages parameter is calculated taking into account the final pass (when it is set).

Value of the Number of passages parameter with set final passage:


$$\text{Number of passages} = \text{Number of passages} - 1$$

Value of the Number of passages parameter without final pass:

$$\text{Number of passages} = \text{Number of passages}$$

The final passage or pass will be carried out with a speed on the basis of the value set for the Final passage speed parameter. If the latter is omitted, the pass will be carried out considering any speeds inserted on the path.

1. First pass




2. Second pass

The second pass will be carried out with the following values:

$$\text{Initial depth} = \text{Initial depth} = 5$$

$$\text{Final depth} = \text{Final depth} = 5$$

$$\text{Final passage speed} = 4$$



Start/End Points If checked the program will ask for start point and end point of the routing path. This utility is useful to perform partial machinings on existing geometries. If not checked the start and end points of the routing path are the same start and end points of the selected geometrie(s).

From drawing: If allowed, the milling will be performed on one or more of the existing geometries, otherwise, it will be applied directly according to the following input controls



If pressed, it connects the machining to the geometry. Each time the geometry is edited, all machining connected to it is automatically updated


Starting point:

- **X** The initial milling point on the X axis.
- **Y** The initial milling point on the Y axis.
- **Z** The initial milling depth.


Finishing point:

- **X** The final milling point on the X axis.
- **Y** The final milling point on the Y axis.
- **Z** The final milling depth.

Radius: Used to set the radius of curvature (arc) of a circular bore.

IF>>: Used to set a condition that enables or not the machining to be carried out. (The instruction IF is exported). If the IF button  of the Genio Toolbar is enabled, machining will only be displayed if the condition is satisfied

A description of the push-button functions



If pressed, applies changes to the panel on the basis of the data below




Appears when no machining has been selected



Displays the data relative to the milling selected on the panel



Allows access to the following page for the programming of the parameters relative to the automatic entry/exit from the profile.



Automatic profile entry:

Enables automatic entry: Enables automatic entry to the panel (XGIN)

Type of entry: Line or Arc.

Approach: At position or downstroke

Multiplication factor: The tool radius' multiplication factor (default=2).

Automatic profile exit:


Enables automatic exit: Enables the automatic exit from the panel (XGOUT)

Type of exit: Arc or line


Move away: At position or upstroke

Multiplication factor: The tool radius' multiplication factor (default=2).

Profile overlap: Indicates how the profile overlap is performed with the exit entity.



Cancel the changes



Save the changes




Shifts the milling starting point



Insert or change the milling speed.

Slanting milling

The page that refers to Slanting milling, which can be accessed from the tool bar's milling File menu, allows you to program the values and data relative to the Slanting milling.



A description of the fields

Name of the selected machining

Tools

E1 10 Tools available for Slanting milling

Offset:

- **Left** Mills to the left of the geometry
- **Center** Mills to the center of the geometry
- **Right** Mills to the right of the geometry






If allowed By Drawing then Rotation:

- **Canonical** Mills in the same direction in which the geometry was created
- **Inverted** Mills in the opposite direction to which the geometry was created

Otherwise Rotation:

- **Clockwise** Mills in the same direction in which the geometry was created
- **Counter clockwise** Mills in the opposite direction to which the geometry was created









Entry side:


- 1a  **Offset Left.** If parameter **Ang=0**, the tool is perpendicular to the programmed trajectory on the left-hand side of the feed path. Values other than **0** for parameter **Ang** cause an angular offset in tool orientation. The tool remains perpendicular to the path during machining (interpolated position). (I=2)
- 1b  **Offset Right.** If parameter **Ang=0**, the tool is perpendicular to the programmed trajectory on the right-hand side of the feed path. Values other than **0** for parameter **Ang** cause an angular offset in tool orientation. The tool remains perpendicular to the path during machining (interpolated position). (I=1)
- 1c  **Offset Center.** If parameter **Ang=0**, the tool is parallel with the programmed trajectory. Values other than **0** for parameter **Ang** cause an angular offset in tool orientation. The tool remains parallel with the path during machining (interpolated position). (I=4)
- 2  If parameter **Ang=0**, the tool is parallel with the programmed trajectory. Values other than **0** for parameter **Ang** cause an angular offset in tool orientation. The angle of the tool remains fixed during machining (fixed position). (I=3)
- 3  If parameter **Ang=0**, the tool is parallel with the positive **X**-axis. Values other than **0** for parameter **Ang** cause an angular offset in tool orientation. The angle of the tool remains fixed during machining (fixed position). (I=0)

Hin: Initial height of the work table working process.

Hout: Final height of the work table working process.


Ang Rotation angle: The milling rotation angle in respect of **Z**-Axis (the **A** angle: 0-360).

B Rotation angle:	This parameter sets the tool angle in respect of Y-Axis (the B angle, enabled only if kind of machine is set on X5).
Join:	Joins all the milling with a minor distance one from another to the same distance programmed in the "Distance" parameter.
Distance:	Distance that is programmed to join the milling.
Bi-directional multi-passage:	Valid for non-closed profiles. If allowed, the tool performs the milling passages without always returning to the starting point; therefore, being able to work both forwards and backwards.
	Bi-directional multipass
	Normal multipass
 Number of passages:	The number of passages that the tool must perform on the milling profile. After each passage, the depth of the machining increases until reaching the final one. The number of passes may also be set using the two buttons increase  and decrease  .
 Final passage depth:	Depth with which the tool carries out the last pass (see example in vertical milling)
 Final passage speed:	Speed with which the tool carries out the last pass: if set, the pass will always be carried out at this speed. (See example in vertical milling)
Start/End Points	If checked the program will ask for start point and end point of the routing path. This utility is useful to perform partial machinings on existing geometries. If not checked the start and end points of the routing path are the same start and end points of the selected geometrie(s).
From Drawing:	If allowed, the milling will be performed on one or more existing geometries, otherwise the same will be applied directly, in compliance with the following programming controls.
Starting point:	
• X	The initial milling point on the X axis
• Y	The initial milling point on the Y axis
• Z	The initial milling depth
Ending point:	
• X	The final milling point on the X axis
• Y	The final milling point on the Y axis
• Z	The final milling depth
Radius:	Used to set the radius of curvature (arc) of a circular bore)
IF>>:	Used to set a condition that enables or not the machining to be carried out. (The instruction IF is exported). If the IF button on the Genio Toolbar is enabled,  machining will only be displayed if the condition is satisfied




When the flag **CAD Offset** is enabled Genio automatically computes the offset of the machining to make the mill working at the left or at the right in respect of the geometry, instead that centered on the geometry, as shown below.


CAD Offset not enabled



CAD Offset enabled



A description of the push-button functions



If pressed, applies changes to the panel on the basis of the data below




Appears when no machining has been selected



Displays the data relative to the milling selected on the panel



Allows access to the following page for the programming of the parameters relative to the automatic entry/exit from the profile.



Automatic profile entry:

Enables automatic entry: Enables automatic entry to the panel (XGIN)

Type of entry: Line or Arc.

Approach: At position or downstroke

Multiplication factor: The tool radius' multiplication factor (default=2).

Automatic profile exit:


Enables automatic exit: Enables the automatic exit from the panel (XGOUT)

Type of exit: Arc or line


Move away: At position or upstroke

Multiplication factor: The tool radius' multiplication factor (default=2).

Profile overlap: Indicates how the profile overlap is performed with the exit entity.



Cancel the changes



Save the changes





Shifts the milling starting point



Insert or change the milling speed.

Pocketing

The pocketing page, that can be accessed from the Tool Bar milling File menu, allows the programming of values and data relative to pocketing.



A description of the fields

Name of selected machining

Type

Concentric

The kind of pocketing that can be performed. (See example below)

Tools

E8 10

Tools available for the pocketing

Paths distance:

Distance between one milling and another

Overmaterial:

Distance left between the pocketing and the support geometry, can be a positive or negative value.

Side:

- **Inside** Mills inside the selected geometry
- **Outside** Mills outside the selected geometry

Rotation:

- **Canonical** Mills in the same direction in which the geometry was created
- **Inverted** Mills in the opposite direction from which the geometry was created

Pocketing angle

Angle of inclination of the pocketing

Z Start:

The depth with which the milling will be begun

Z Finish:

The depth with which the milling will be finished

No. Passes:

The number of passes to be performed in order to reach the programmed depth

Process start point:

- **Inside** Start the milling from the central part of the selected geometry
- **Outside** Finish the milling from the most external part of the selected geometry


Final pass:

- **None** No further, final pass is made on the geometry exterior
- **Complete** Performs one further, final pass on the geometry exterior


Precision arcs

The precision with which the in line arcs will be approached


IF>>:

Used to set a condition that enables or not the machining to be carried out. (The instruction IF is exported). If the IF button on the Genio Toolbar is enabled,  machining will only be displayed if the condition is satisfied

A description of the push-button functions



If pressed, it will apply changes to the panel on the basis of the data below



Appears when no process has been selected



Display the data relative to the pocketing selected on the on the panel



Allows access to the following page for the programming of the parameters relative to the automatic entry/exit from the profile.

Automatic profile entry:

Enables automatic entry: Enables automatic entry to the panel (XGIN)

Type of entry: Line or Arc.

Approach: At position or downstroke

Multiplication factor: The tool radius' multiplication factor (default=2).

Automatic profile exit:

Enables automatic exit: Enables the automatic exit from the panel (XGOUT)

Type of exit: Arc or line


Move away: At position or upstroke

Multiplication factor: The tool radius' multiplication factor (default=2).


Profile overlap: Indicates how the profile overlap is performed with the exit entity.



If pressed, it connects the machining to the geometry. Each time the geometry is edited, all machining connected to it is automatically updated



Cancel the changes




Save the changes


Examples of pocketing:

- Linear pocketing


With islands and pocketing angle at 0 degrees



With islands and pocketing angle more than 0 degrees




- **Concentric pocketing**




N.B. After a concentric pocketing have been programmed, if necessary a finish passage with a smaller tool can be added in order to remove regions not worked with the main passage.

Es. Pocketing + finish


1. Add first concentric pocketing (main passage)




2. Select a tool with diameter smaller then the diameter of the main tool.
3. Click on the “Select” button and then select the main passage and confirm with the “Apply” button.



4. The following window will be displayed





5. Click on “Yes”
(Note: If you click on “No” the main passage will be modified with the new parameters programmed in the pocketing page).
6. A new pocketing (finish) will be added as shown in the following picture (inside the red circles).



Engraving

The engraving page, which can be accessed from the Tool Bar milling File menu, allows you to program the values and data relative to the engravings.



A description of the fields

Name of selected machining


Tools

E1 10





Tools available for engraving


Maximum depth:

The maximum depth with which the tool point will enter the panel

Number of passages:	The number of passages with which the engraving will be performed
Pitch:	The pitch with which the tool's depth and positions are calculated
Maximum angle:	The engraving is not performed on the corners of the angles of an angle that has a higher value than this
Rotation:	
• Canonical	Mills in the same direction in which the geometry has been created
• Inverted	Mills in the opposite direction to which the geometry has been created
Side:	
• Internal	Mills on the inside of the geometry
• External	Mills on the outside of the geometry
Precision arcs:	The precision with which the line arcs will be approached
IF>>:	Used to set a condition that enables or not the machining to be carried out. (The instruction IF is exported). If the IF button on the Genio Toolbar is enabled,  machining will only be displayed if the condition is satisfied

A description of the push-button functions

	If pressed, it will apply changes to the panel on the basis of the data below
	Appears when no process has been selected
	Display the data relative to the engraving selected on the on the panel
	Allows access to the following page for the programming of the parameters relative to the automatic entry/exit from the profile.



The dialog box is titled "Automatic profile entry and exit". It contains two main sections: "Automatic profile entry" and "Automatic profile exit".

Automatic profile entry section:



- ☐ Enable automatic entry
- Type of entry:
 - ☒ Arc
 - ☐ Line
- Approach:
 - ☒ At position
 - ☐ Downstroke
- Multiplication factor:

Automatic profile exit section:

- ☐ Enable automatic exit
- Type of exit:
 - ☒ Arc
 - ☐ Line
- Move away:
 - ☒ At position
 - ☐ Upstroke
- Multiplication factor:
- Profile overlap:



At the bottom, there are "Ok" and "Cancel" buttons.

Automatic profile entry:

Enables automatic entry:	Enables automatic entry to the panel (XGIN)
Type of entry:	Line or Arc.
Approach:	At position or downstroke
Multiplication factor:	The tool radius' multiplication factor (default=2).
Automatic profile exit:	
Enables automatic exit:	Enables the automatic exit from the panel (XGOUT)
Type of exit:	Arc or line
Move away:	At position or upstroke
Multiplication factor:	The tool radius' multiplication factor (default=2).
Profile overlap:	Indicates how the profile overlap is performed with the exit entity.
	Cancel the changes
	Save the changes

Saw cut

The saw cut page that may be accessed from the milling management menu in the toolbar, allows you to set values and data for the saw cuts.



A description of the fields

Tools

E80 4,200 D

Tools available for cutting

Work plane

Piano_1

This allows you to select an existing slanting plane (If a slanting plane has not yet been created, a request to create one will be made when the command APPLY is executed)



This allows you to select an existing slanting plane from the Autocad window

Direction:



Canonical

Carries out the cut from left to right in relation to the slanting plane



Inverted

Carries out the cut from right to left in relation to the slanting plane

Bidirectional multi-passage:

Valid only for open profiles. If enabled, the tool carries out any milling passes without returning every time to the starting point and therefore machining both forwards and backwards.



Bidirectional multi-passage



Unidirectional multi-passage

Saw correction:

Center out

Carries out a cut on the slanting plane in the center of the saw

Cad offset

Carries out a cut on the slanting plane staggered by the equivalent of the thickness of the blade plus any overmaterial


Overmaterial

Offset value for the tooling path in respect of the canonical path. It may be negative or positive, depending on the direction of tool correction





Final passage saw offset

Offset value for the tooling path in respect of the canonical path when executing the return pass in a bi-directional Multipass. It may be negative or positive, depending on the direction of tool correction




Depth Offset


(For disk-type milling cutters only). The starting and finishing point of the machining are automatically offset according to the disk chord.




Scoring (first pass) depth Depth with which the first pass will be executed




Final cut depth Final depth with which the cutting will be executed



Extra depth Quantity added to the tool path in relation to the cutting depth.



IF>>: Used to set a condition that enables or not the machining to be carried out. (The instruction IF is exported). If the IF button on the Genio Toolbar is enabled,  machining will only be displayed if the condition is satisfied


A description of the push-button functions



If pressed, applies changes to the panel on the basis of the data below



Appears when no machining has been selected





Insert or change the cutting speed.

Cutting instructions

The cutting page, which can be accessed from the Tool Bar milling File menu, allows you to program the values and data relative to the cutting.

NOTE: CUTTING INSTRUCTION IS A SPECIAL MILLING MACHINING THINKEED ESPECIALLY FOR THE NESTING IN ORDER TO IDENTIFY THE PIECE SHAPE.
CUTTING INSTRUCTION DATA PROGRAMMED IN THIS PAGE WILL BE APPLIED TO THE NESTING IN ORDER TO CUT SHAPED PIECES (SEE RELATED ARGUMENT: =>NESTING)





A description of the fields

Name of selected machining

Tools

E2 23,9

Tools available for cutting

Side:



Left

Mills to the left of the geometry



Center

Mills to the center of the geometry



Right


Mills to the right of the geometry

If the cutter is disk-type:




Depth correction

(Only for disks) The machining will start and stop in the same start and stop points of the support geometry



No depth correction

(Only for disks) The disk tool will start and stop with its center aligned to start and end points of the support geometry.



Else:



Disabled outside



Outside

Mills to the outside of the geometry. (Applicable for a closed geometry)



Disabled Inside



Inside

Mills to the inside of the geometry. (Applicable for a closed geometry)

Direction:



Canonical

Mills in the same direction in which the geometry has been created



Inverted

Mills in the opposite direction to which the geometry has been created



Disabled Clockwise



Clockwise

Mills in the same direction in which the geometry has been created. (Applicable for a closed geometry)



Disabled Counter Clockwise



Counter-clockwise

Mills in the same direction in which the geometry has been created. (Applicable for a closed geometry)

Overmaterial

Offset value for the tooling path in respect of the canonical path. It may be positive or negative depending on the direction of tool correction

Join:

Joins all the milling with a minor distance one from another to the same distance programmed in the "Distance" parameter.

Distance:


The distance that is programmed for joining the cuts.

Bi-directional multi-passage:

Valid only in the case of non-closed profiles. If allowed, the tool will perform the milling passages without always returning to the starting point, therefore, working both backwards and forwards.



Bi-directional multipass





Normal multipass



Sloping. If enabled it executes machining progressively increasing the depth.



Number of passages:

The number of passages that the tool will have to perform on the milling profile. After each passage, the depth of the machining will increase until reaching the final one. The number of passes may be increased or decreased using the buttons  and  respectively.



Final passage depth:

Increase in depth for the last pass: (See example in milling)



Final passage speed:

Speed with which the tool carries out the last pass. If set, the pass will always be carried out at this speed. (See example in milling)

Start/End Points

If checked the program will ask for start point and end point of the routing path. This utility is useful to perform partial machinings on existing geometries. If not checked the start and end points of the routing path are the same start and end points of the selected geometrie(s).



If pressed it connects the machining to the geometry. Each time the geometry is edited, all machining connected to it is automatically updated

From Drawing:

If allowed, the milling will be performed on one or more existing geometries, otherwise the same will be applied directly, in compliance with the following programming controls.

Starting point:


- **X** The initial cutting point on the X axis
- **Y** The initial cutting point on the Y axis

- **Z** The initial cutting depth


Ending point:

- **X** The final cutting point on the X axis
- **Y** The final cutting point on the Y axis
- **Z** The final cutting depth

Radius Allows the programming of the circular cut radius of curvature (arc)

IF>>: Used to set a condition that enables or not the machining to be carried out. (The instruction IF is exported). If the IF button on the Genio Toolbar is enabled,  machining will only be displayed if the condition is satisfied

A description of the push-button functions



If pressed, applies changes to the panel on the basis of the data below




Appears when no machining has been selected



Displays the data relative to the cutting selected on the panel



Change input/output data



The dialog box titled "Automatic profile entry and exit" contains two main sections: "Automatic profile entry" and "Automatic profile exit".


- Automatic profile entry:**
 - ☐ Enable automatic entry
 - Type of entry:
 - ☒ Arc
 - ☐ Line
 - Approach:
 - ☒ At position
 - ☐ Downstroke
 - Multiplication factor:
- Automatic profile exit:**
 - ☒ Enable automatic exit
 - Type of exit:
 - ☒ Arc
 - ☐ Line
 - Move away:
 - ☒ At position
 - ☐ Upstroke
 - Multiplication factor:
 - Profile overlap:

At the bottom are "Ok" and "Cancel" buttons.


Automatic entry:

Enable automatic entry: Enables automatic entry to the (XGIN) panel.

Type of entry:	Line or Arc.
Approach:	In position or downstroke
Multiplication factor:	The multiplication factor of the tool radius (default=2).
Automatic exit:	
Enable automatic exit:	Enables automatic exit from the (XGOUT) panel
Type of exit:	Arc or line
Move away:	At position or in upstroke
Multiplication factor:	The multiplication factor of the tool radius (default=2).
Overlap profile:	Indicates how the profile is overlapped.



Cancel the changes



Save the changes



Shifts the milling starting point




Insert or change the cutting speed.

Tagging pieces (Nesting usage):

What's tagging ?


Tagging is special function used in the nesting in order to avoid the movement of small pieces during the cut process at the machine.

In fact with tagging one or more small rectangular bridges (tags) are left in the piece shape to make it jointed to the main board as shown in the picture below.





How to apply tags to the panel shape (Cut instruction)

1. Draw or import the panel shape
2. Apply Cut instruction as described in the previous section
3. Click on the “Tagging” button as shown below



4. The following window will be displayed



Tag length: is the length of the Tag (A)

Tag depth: is the depth of the (cut) milling of the tag (B)


C is the depth of the cut machining.

To Add a new tag click on the “**Add tag**” button

To remove all programmed tags click on the “**Remove tags**” button



To close the window and exit from tag programming mode click on the “**Close**” button

5. Once the “Add tag” button has been selected the system will prompt for the insertion point of the tag (please select a point in the cut instruction, AutoCad Osnap are allowed).
6. Click again on the “Add tag” button to insert more tags.



Edges xy management

The edges xy management page, which can be accessed from the Tool Bar milling File menu, allows you to program the values and data relative to the edges xy management.



A description of the fields

Tools

Tools available for the Edges xy management

Side:



Left

Mills to the left of the geometry



Right

Mills to the right of the geometry

Direction:



Canonical

Mills in the same direction in which the geometry has been created




Inverted

Mills in the opposite direction to which the geometry has been created

Type of corner management:


- **Linear**

The routing path performs a linear passage on the corners of the selected geometries




- **Fit**

The routing path performs a corner-fit on the corners of the selected geometries



- **Ring**

The routing path performs a ring on the corners of the selected geometries



Radius:

Is the radius for corner fit or ring in respect of the type of management programmed. Notes: a ring is not performed if it intersects the original geometry; no corner fit or ring are performed for angles smaller than the parameter programmed in the Genio options/machining page; if required, the function will split the machining in several profiles.

Join:

Joins all the Edges xy management with the distance minor one from another to the same one that has been programmed in the "distance" parameter

Distance:


The distance that is programmed for joining the Edges xy management

Bidirectional multi-passage:

Valid for non-closed profiles. If allowed, the tool performs the Edges xy management passages without always returning to the starting point; therefore, being able to work both forwards and backwards.





Bi-directional multipass



Normal multipass



Number of passage:

The number of passages that the tool must perform on the Edges xy management profile. After each passage, the depth of the machining increases until reaching the final one. The number of passes may be increased or decreased using the buttons  and  respectively.



Final passage depth:

Increase in depth for the last pass. (See example in milling)



Final passage speed:

Speed with which the tool carries out the last pass: If set, the pass will always be carried out at this speed. (See example in milling)

Start/End points

If checked the program will ask for start point and end point of the routing path. This utility is useful to perform partial machinings on existing geometries. If not checked the start and end points of the routing path are the same start and end points of the selected geometrie(s).

From Drawing:



If allowed, the Edges xy management will be performed on one or more of the existing geometries, otherwise, it will be applied directly according to the following input controls

If pressed, it connects the machining to the geometry. Each time the geometry is edited, all machining connected to it is automatically updated


Start point:

- **X** The initial Edges xy management point on the X axis.
- **Y** The initial Edges xy management point on the Y axis.


End point:

- **X** The final Edges xy management point on the X axis.
- **Y** The final Edges xy management point on the Y axis.
- **Z** Depth of the Edges xy management.


Radius: Allows the programming of the circular profile radius of curvature (arc)

IF>>: Used to set a condition that enables or not the machining to be carried out. (The instruction IF is exported). If the IF button on the Genio Toolbar is enabled,  machining will only be displayed if the condition is satisfied

A description of the push-button functions



If pressed, applies changes to the panel on the basis of the data below



Appears when no machining has been selected



Displays the data relative to the Edges xy management.selected on the panel



Allows access to the following page for the programming of the parameters relative to the automatic entry/exit from the profile.

Automatic profile entry:

Enables automatic entry: Enables automatic entry to the panel (XGIN)

Type of entry: Line or Arc.

Approach: At position or downstroke.

Multiplication factor: The tool radius' multiplication factor (default=2).

Automatic profile exit:


Enables automatic exit: Enables the automatic exit from the panel (XGOUT)

Type of exit: Line or Arc.


Move away: At position or upstroke.

Multiplication factor: The tool radius' multiplication factor (default=2).

Profile overlap: Indicates how the profile overlap is performed with the exit entity.



Cancel the changes



Save the changes



Change the starting point of the profile

Automatic profile entry:

Enables automatic entry: Enables automatic entry to the panel (XGIN)


Internal corner cleaning


The Corner Cleaning page is accessible from the Milling Management menu of the Genio toolbar and is used to set values and data relating to Cleaning inside corners.

This type of machining is particularly indicated for sharp edge machining typical of furniture doors or doors. Applying this machining to a geometry, the machinings are generated for obtaining a shaped profile with sharp edged interior angles.

Managed machinings:

- Main pass with form cutter or fluted mill
- Several passes to reduce internal radii
- Pass with tapering tool for cleaning inside sharp corners, of the sliding type or 90 degree type





A description of the fields

Cleaning type

Sloping


Allows the type of cleaning to be selected (sliding or 90 degrees).

- Sloping**


Generates a cleaning from forming tool profile (See **E.g.** below). The tapering tool follows a trajectory referred to the profile of the main tool. For the creation of a forming tool, see section->**Tool data programming**

Forming tool

Sliding Cleaning Type (Seen from above)



Sliding Cleaning Type (Seen from side)




- **90 degrees corner**


Generates a cleaning on internal corners of a machining with the non-forming main tool (See **E.g.** below)

Normal tool

90° Corner Cleaning Type (Seen from above)



90° Corner Cleaning Type (Perspective view)



Corner cleaning path

Complete corner


Allows the type of path to be selected for carrying out the corner cleaning

For 90° Corner type cleaning

- Corner only**

A simple cleaning on all corners is carried out (See **Corner Cleaning Parameters** and **E.g.** below)

E.g. The tool executes a path perpendicular to the surface of the panel without considering any set edge extension parameters for corner cleaning




- Complete corner**

Corner cleaning is carried out considering any set edge extension parameters and upper approach for corner cleaning (See **Corner Cleaning Parameters** and **E.g.** below)


E.g.

The tool executes a path perpendicular to the surface of the panel taking into account the set upper approach. Having arrived at the machining depth created by the first pass, it carries out any edge extension (in this example the edge extension is equivalent to 5 and the upper approach 2)

Edge extension Complete corner



Upper approach




Edge extension value

Upper approach value

N.B.

If the tapering tool touches the three faces of the corner, a single pass rather than two will be carried out. (See **E.g.**)

E.g. The example shows how the tool touches both sides of the resulting machining. In this case the tool will also touch the lower face that is not visible in this view




For **Sliding** type of cleaning

- **Complete geometry** All the joined corners for each level generated by the forming tool will be cleaned. (See **E.g.** below)

E.g.

The example shows how the corners are joined together, thereby creating a single machining over the whole profile (Machining in yellow).





- **Corner only** Only the corners of each level generated by the forming tool are cleaned. (See **Corner Cleaning Parameters** and **E.g.** below)

E.g.

The example shows that a single machining is carried out on each corner without considering any set edge extension parameters and upper approach for corner cleaning (Machining in yellow).

View from above

View from one side of a cleaning operation on one corner




- Complete corner** The corners of all the levels generated by the forming tool are cleaned considering any set parameters for corner cleaning. (See **Corner Cleaning Parameters** and **E.g.** below)


E.g.

The example shows that a single machining is carried out on each corner taking into account all the set parameters for corner cleaning. The created edge extensions can be seen. (Machining in yellow).

View from above



View from one side of a complete cleaning operation on one corner




Radius reduction path

Allows the type of path to be selected for carrying out radius reduction

- Complete geometry** Reduces the radii over the whole profile for each level generated. (See **E.g.** below)

E.g.

The example shows the radius reduction produced by the form of the tool over the whole profile.




- Complete corner**

Reduces the radii over all the levels generated, but only on the corners, considering any set parameters for radius reduction. (See **Radius Reduction Parameters** and **E.g.** below)

E.g.

The example shows the radius reductions produced by the form of the tool on the corners only.



Main machining

E23 SGROSSATURA 5

Tools available for the main pass




If enabled, it allows execution of the first pass

First pass parameters



Loads the window shown below for setting the data related to the Main Machining




A description of the fields

Overmaterial: Quantity by which the trajectory of the tool is offset in relation to the canonical trajectory. (Possibility of inserting parametric formulas) (See **E.g.**)

E.g.

The example shows a tool offset equivalent to 5



Speed: Speed of entry of the tool into the workpiece

Radius reduction n

E24 RIDUZ RAGGI 8,C

Available tools for radius reduction



Enabled reduction




Disabled reduction

If enabled, it allows execution of associated radius reduction

Radius reduction Parameters



Loads the window shown below for setting the data related to Radius Reduction



A description of the fields


Overmaterial: Quantity by which the tool trajectory is offset in relation to the canonical trajectory. (See above)

Tool speed: Speed of entry of the tool into the workpiece

Path extension: Quantity by which the tool trajectory is extended in relation to the canonical trajectory. (Possibility of inserting parametric formulas) (See **E.g.**)

E.g.

In the case of a radius reduction, when the tool reaches the machining depth, it shifts to the right or the left by the set edge extension value. (In this example the value is equivalent to 5)



Corner cleaning

1 CONICO 133,547 C ▼

Tools available for Corner Cleaning



Enabled cleaning




Disabled cleaning

If enabled, it allows execution of corner cleaning

Corner Cleaning Parameters



Loads the window shown below for setting data related to Corner Cleaning




A description of the fields

Upper approach:

Quantity by which the tool trajectory is anticipated at entry in relation to the start of machining.(See **E.g.**)

E.g.

(In this example it is equivalent to 2)




Lower approach:

Quantity by which the tool trajectory is deferred at outlet in relation to the end of machining. (See **E.g.**)

E.g.

(In this example it is equivalent to 2)




Path extension:

Quantity by which the tool trajectory is extended in relation to the canonical trajectory. (See above)

Tool height:

Quantity by which the tool is raised during operation on one level. (See **E.g.**)

E.g. with tool height = 1



Offset Z: Quantity by which the tapering tool trajectory is shifted in relation to the canonical trajectory. The parameter allows the trajectory of the tapering tool to be adjusted. Note: formulas may be inserted with parameters defined in the sheet -> Macro.Variables.

Offset:

- **Left** Carries out Cleaning Inside Corners to the left of the geometry
- **Right** Carries out Cleaning Inside Corners to the right of the geometry

N.B.


If the geometry is open the offset may be set manually, but if the geometry is closed the offset is calculated automatically inside the geometry.

Direction:


- **Canonical** Carries out milling in the same direction with which the geometry was created
- **Inverted** Carries out milling in the opposite direction to which the geometry was created

Offset computed by cad If enabled, the offset of the source geometry will be created and the tool will have a centered offset. Vice versa if disabled, the tool will have right or left correction in relation to the source geometry and no path will be produced. (See E.g.)

E.g. Enabled offset calculation by Cad



E.g. Disabled offset calculation by Cad




Join: Joins up all the milling operations with distance apart less than or equal to that set in the "Distance" parameter.


Dist.: Distance that is set for joining up the millings.

Start/end point If enabled it allows the starting and end point of a cleaning to be selected, acting directly on the existing geometry.

Z Depth of Cleaning Inside Corners.

IF>>: Allows a condition to be set that enables or disables machining. (The Instruction IF is exported). If the IF button on the Genio Toolbar is enabled  the machining will only be displayed if the condition is satisfied.

A description of the push-button functions



If pressed, it creates or changes the machinings according to the underlying data



Appears when no machining is selected




Displays the data related to the selected milling on the panel




Shifts the starting point of a milling



If pressed, it connects the machining to the geometry. At each change to the geometry, all the machinings connected with the same are automatically updated



Save the changes



Undo the changes

Parametric machining programming

It is possible to program Genio parametric machining, or rather that the machining depends on the user variables and the panel dimensions.

A parametric instruction always begins with the same symbol and then contains a formula with operators and variables.

A parametric instruction has a parametric exit towards the machine control.

The permitted operators are described below, the variables used have been drawn up in the "Variables" sheet of the "Macro" folder. An example of a macro instructions is as follows (step is declared in the variables sheet):

$$=Dx/2/Step$$

Only "." or "," may be used as decimal separator for the numerical data written in the formulas.

Toolbar for handling the parametric machining

The Tool Bar appears when a barrier of single holes is selected or a single tool path, whether it be an arc or segment (non-selected "screen co-ordinates") and allows for the handling of the commonest parametric functions.



If the panel dimensions vary, the machining will remain at a distance from the upper margin of the unvaried panel



If the panel dimensions vary, the machining will remain at a distance from the left margin of the unvaried panel.



If the panel dimensions vary, the machining will remain at a distance from the lower margin of the unvaried panel.



If the panel dimensions vary, the machining will remain at a distance from the right margin of the unvaried panel.



If the panel dimensions vary, the machining will remain at a distance from the center of the Y axis of the unvaried panel.



If the panel dimensions vary, the machining will remain at a distance from the center of the X axis of the unvaried panel.



Center the machining on the panel in respect of the X axis.



Center the machining on the panel in respect of the Y axis.



Create a copy of the previously existing machining symmetrically (mirror image) in respect of the Y axis.



Create a copy of the previously existing machining in a symmetrically (mirror image) in respect of the X axis .



Transform data from formulas into numerical data

Input functions and operators that are inseparable in the parametric formulas.


-	Minus unitary
+	Plus unitary
*	Multiplication
/	Division
()	Parenthesis
ABS	Absolute value
ACOS	Arc cosine.
ASIN	Arc sine.
ATAN	Arc tangent.
COS	Cosine.
SIN	Sine.
TAN	Tangent.
RD	Rounding up to the lowest full value
RU	Rounding up to the highest full value
EXP	Exponential.
LN	Natural logarithm
LOG	Logarithm in base 10.
SQR	Square root

NOTE:

The functions of each of these push-buttons is always the same for all the boring and milling machining processes on the path constituted by a segment or arc.

Nesting machining report

The machining report spreadsheet, which can be accessed from the Utilities menu of the control panel, allows the display of data regarding the machinings present on product nesting.



Machinings report					
	A	B	C	D	E
1	Optimised boring				
2	Diameter	Number of holes		Total time	Total cost
3					
4	Boring				
5	Tool	Number of holes		Total time	Total cost
6	62	14		10,1	0,00056
7	E12	9		6,5	0,00036
8					
9	Millings				
10	Tool	Linear met.	umber of approach.	Total time	Total cost
11	E80	0,612	1	41,8	0,002
12	E4	3,084	2	24,3	0,002
13					
14	EdgeBanding				
15	Edge type	Linear met.		Total time	Total cost
16					
17	Cut				
18	Tool	Number of approach.		Total time	Total cost
19					
20					
21				Total time	Total cost
22				82,7	0,005

Units of measurement

Distance Linear meters

Time Seconds

Cost Euro

Edge-banding machining programming

The Genio edge-banding programming pages are accessible from the Control Panel Toolbar using the following buttons:

- Edge Banding
- End Trim
- Trimming
- Scraping
- Finish
- Radiusing
- Blowing



In General


The Toolbar buttons are used to manage and program the various machining stages to be applied to an Edge-Banding operation

- the “Edge Banding” button displays the programming page of an edge-banding;
- the “End Trim” button displays the programming page of an end trim;
- the “Trimming” button displays the programming page of a trim;
- the “Scraping” button displays the programming page of a scraping of the edge band;
- the “Finish” button displays the programming page of a scraping of the glue;
- the “Radiusing” button displays the programming page of a radiusing;
- the “Blowing” button displays the programming page of a blowing;

To program a machining operation, just select the relative item, program the relative parameters on the page of the Control Panel and press the “APPLY” button: the machining parameters will be applied to the corresponding geometry drawn on the Genio display and may be sent to the machining center.

Edge Banding

The edge-banding page, accessible from the Control Panel Toolbar, is used to set values and data concerned with edge banding.



A description of the fields

Name of the selected machining

Automatic routing

Executes automatically a single routing on the same geometry where the edge banding is executed with through depth

Tools

E2 23,9

List of tools allowed for the automatic routing (enabled only if “Automatic routing” is checked).

Set:

- **Edge** Identification number of the banding material canal
- **Height** Height of banding material
- **Thickness** Thickness of banding material
- **Speed** Edge banding speed
- **Multi-edge** If checked, the parameter “Multi-edge” will be exported
- **Lato Sinistro** If enabled, the edge banding will be carried out on the left side


IN:

- **Entry Speed** Entry speed on panel edge
- **Elongation type** Used to establish if the shuttle should exit by a maximum or minimum amount in relation to the exclusion position
- **Edge until shuttle** Banding material to be supplied starting from the point of shuttle insertion
- **Edge after shuttle** Quantity of banding material after shuttle insertion
- **Edge added up to** Parameter that will be algebraically added to the panel perimeter to be edge banded, so that the total quantity of banding material supplied at inlet can be controlled.
- **Shuttle exclusion** Used to establish if the shuttle should return to the end to be edge-banded as soon as point R1_INI is reached or wait for positioning at R2_INI.
- **Rotation direction** Decides the direction of rotation of the edge-bander head
- **Autostart** Directly enables execution of edge-banding after routing and boring.
- **Cut** Enables/Disables the possibility of making an end trim of the banding material loaded with end trim unit mounted on end to be edge-banded.

OUT:

- **(L)Cut length** Length of banding material cut starting from the photocell reading
- **(J)Elevation bar** Early elevation of bar in relation to banding material closing point

IF>>:

Used to set a condition that enables or not the machining to be carried out. (The instruction IF is exported). If the IF button on the Genio Toolbar is enabled,  machining will only be displayed if the condition is satisfied

A description of the push-button functions

APPLY

If pressed, it creates or edits machining according to the data below

<<SELECT

Appears when no machining has been selected



Shifts the starting point or an edge banding that is closed and tangent at the end point



Allows access to the following page for the programming of the parameters relative to the automatic entry/exit from the profile.

From Drawing:

If checked allows programming directly on the graphic window, if not the parameters will be modified with the values programmed in the page.

EIn:

Modify

If enabled data will be modified according to programmed values

X

Measurement X of the point of descent of the group to be edge banded

Y

Measurement Y of the point of descent of the group to be edge banded

D

Distance between the start of the profile and the rendezvous height

B

Angle between the straight line that unites the start of the profile to the rendezvous height and the tangent to the profile at the starting point

EOut:

Modify:

If enabled data will be modified according to programmed values

X

Polar coordinate (X) of the glue roller in outlet segment 1

Y

Polar coordinate (Y) of the glue roller in outlet segment 1

q

Polar coordinate (Q) of the glue roller in outlet segment 2


r

Polar coordinate (R) of the glue roller in outlet segment 2


y

Polar coordinate (y) of the glue roller in outlet segment 3


- a** Polar coordinate (a) of the glue roller in outlet segment 3
- r** Polar coordinate (r) of the glue roller in output segment 4
- s** Polar coordinate (s) of the glue roller in output segment 4



Cancel the changes





Restore to the initial values



Save the changes




Manually inserts or edits the Pressure Glue Roller Stop through the window shown below that allows you to set the stop time



Inserts or edits the edge banding speed



Inserts or edits a light bulb in an edge banding




Inserts or edits a rotation of the tool in an edge banding



Inserts, edits or deletes a supply of edge in an edge banding

Advanced data

Press the button  to set other values and data related to edge banding (see next page).

Descent:

- **Slope down distance (X-EIN)** Measurement X of the point of descent of the group to be edge banded
- **Slope down angle (Y-EIN)** Measurement Y of the point of descent of the group to be edge banded
- **Vector axis rotation (A-EIN)** Vector axis value at the point of descent
- **Edge increase (E-EIN)** Quantity of banding material that will be algebraically added to the quantity of banding material to be supplied, to go to the head stock value up to the descent value
- **Enable multi edge banding** Enables multiple edge banding

Rendezvous:

- **Distance rendezvous-profile (D-EIN)** Distance between the start of the profile and the rendezvous height
- **Angle of rendezvous (B-EIN)** Angle between the straight line that unites the start of the profile to the rendezvous height and the tangent to the profile at the staring point
- **Angle vector in the R.V. point (R-EIN)** Vector axis height at rendezvous point
- **Wait at point R1 (TIN-EIN)** Waiting time for end to be edge-banded when, upon arriving with the Glue Roller at point R1_INI, Roller 1 has come into contact with the corner of the panel (G0 user)

- **Start point lamp (LAMP-EIN)** Value that represents the lamp switching on power when the Glue Roller arrives on G0 user
- **Descent speed (V_CAR-EIN)** Used to program a speed other than the one that may be programmed with the parameter V on positioning at the descent point

Start:

- **Vector angle at point COINI(C_COINI-EIN)** Angle c in CO_INI
- **Dist.between p.ts R1INI-SBINI(D_R1INI-EIN)** Variation in the distance between the point R1_INI and the parameter "Distance between the Glue Roller and Pressing Roller"
- **Vector angle at point R1INI(C_R1INI-EIN)** Angle C in R1_INI
- **Distance between p.ts R2INI-R1CI(D_R2INI-EIN)** Distance of point R2_INI from point R1_INI
- **Vector angle at point R2INI(C_R2INI-EIN)** Angle C in R2_INI
- **Distance between p.ts SBINI-R1INI(D_SBINI-EIN)**

Closing:




- **Entry height con-roll(D-ECLOSE)** Entry height of counter-pressure roller starting from the photocell reading
- **Offset final point (I-ECLOSE)** Offset for changing the coordinates of the final point of the profile
- **Search angle reference**
- **Offset vector axis (A-ECLOSE)** Axis C offset during edge search in respect of the inclination calculated automatically by the interface, which ensures perpendicularity of the rod with photocell in relation to the profile
- **Search axis speed (Q-ECLOSE)** Speed (mm/min) of axes during photocell search
- **Head rotation Angle(R-ECLOSE)** **Head-Angle in the edge banding closing section**
- **Speed axis from cut (V-ECLOSE)** Speed (mm/min) of axes from edge reading point through FC2, until close
- **Extra copying (B-ECLOSE)** **Edge over-quantity in the edge banding closing section.**

Exit:

- **Polar coordinates in the segment 1(X,Y-EOUT)** Polar coordinates (X,Y) of the glue roller in outlet segment 1
- **Vector angle in the segment 1(A-EOUT)** Vector axis rotation C(A) of the glue roller in outlet segment 1
- **Polar coordinates in the segment 2(Q,R-EOUT)** Polar coordinates (Q,R) of the glue roller in outlet segment 2
- **Vector angle in the segment 2(x-EOUT)** Vector axis rotation C(x) of the glue roller in outlet segment 2
- **Polar coordinates in the segment 3(y,a-EOUT)** Polar coordinates (y,a) of the glue roller in outlet segment 3

- **Vector angle in the segment 3(B-EOUT)** Vector axis rotation C(B) of the glue roller in outlet segment 3
 - **Polar coordinates in the segment 4(r,s-EOUT)** Polar coordinates (r,s) of the glue roller in output segment 4
 - **Vector angle in the segment 4(b-EOUT)** Vector axis rotation C(b) of the glue roller in output segment 4
 - **Outlet speed (VOUT-EOUT)** Outlet speed (mm/min) from panel edge
- Static rotation glue-roll** Static rotation of the Glue Roll on the edge
- **Time wait glue (TCSPI-EOUT)** With the end at the last point of contact between the secondary roller and the edge, wait this amount of time before positioning the remaining outlet points

A description of the push-button functions

	Cancel the changes
	Save the changes
	Restore to the initial values

End trim

The end trim page, accessible from the Control Panel Toolbar, is used to set values and data related to the end trim.

CONTROL PANEL Ver. 3.0.0

File Modify Tools Utility

APPLY

END TRIM

[...]

Tools - DEF

81

Corners End

Start corner

Type Center blade

Offset Center

Rotation

Leaving

F

X

Y

End corner

Type Center blade

Offset right

Rotation 270,000

Leaving 0,000

F

X 543,339

Y 272,798

IF >>

A description of the fields

Name of selected machining

Tools

E1 10 Available tools for end trimming.

Corners Indicates the position of the end trim in relation to an edge banding

Corner Start/End/Manual:

- **Type** Type of end trim
- **Offset** Side on which the end trim will be carried out in relation to the edge banding
- **Rotation** Blade inclination




With padlock closed, blade inclination is calculated automatically




With padlock open, blade inclination is calculated manually


- **Leaving** Offset of moving away from end trim point
- **f** Number of used end trim unit
- **X** Dimension X of the initial corner of the panel on which the end trim unit must descend
- **Y** Dimension Y of the initial corner of the panel on which the end trim unit must descend

IF>>: Used to set a condition that enables or not the machining to be carried out. (The instruction IF is exported). If the IF button on the Genio Toolbar is enabled,  machining will only be displayed if the condition is satisfied

A description of the push-button functions



If pressed it creates or edits the machining according to the underlying data



Appears when no machining has been selected

Trimming

The trimming page, accessible from the Control Panel Toolbar, is used to set values and data related to trimming

A description of the fields


Name of selected machining

Tools








E1 10 Available tools for trimming.

If allowed by the drawing, then order is:

- **Canonical** Trims in the same direction in which the geometry was created

<ul style="list-style-type: none"> • Inverted <p>Otherwise order is:</p>	Trims in the opposite direction to which the geometry was created
<ul style="list-style-type: none"> • Clockwise 	Trims in the same direction in which the geometry was created
<ul style="list-style-type: none"> • Counter-clockwise 	Trims in the opposite direction to which the geometry was created
Speed	Trimmer unit speed
A	Trimmer unit angle
<ul style="list-style-type: none"> • Advance 	Advance in relation to starting point of machining
<ul style="list-style-type: none"> • Postpone 	Deferment in relation to starting point of machining
From Drawing:	If enabled, trimming is carried out on one or more existing geometries, otherwise it is applied directly according to the control settings as below.
Starting point:	
<ul style="list-style-type: none"> • X 	Starting point of trimming on axis X
<ul style="list-style-type: none"> • Y 	Starting point of trimming on axis Y
Ending point:	
<ul style="list-style-type: none"> • X 	End point of trimming on axis X
<ul style="list-style-type: none"> • Y 	End point of trimming on axis Y
Radius:	Sets the radius of an arc
IF>>:	Used to set a condition that enables or not the machining to be carried out. (The instruction IF is exported). If the IF button on the Genio Toolbar is enabled,  machining will only be displayed if the condition is satisfied

A description of the push-button functions

	If pressed, applies the changes to the panel on the basis of the data below
	Appears when no machining has been selected
	Shifts the starting point of a closed trimming
 	Inserts or edits a trimming speed
 	Inserts or edits a tool rotation in a trimming

Scraping

The edge scraping page, accessible from the Control Panel Toolbar, is used to set values and data related to scraping the edge.

CONTROL PANEL Ver. 3.0.0

File Modify Tools Utility

APPLY

SCRAPING

Scraping SCRAPING_15

Tools - DEF

Direction

☒ Canonical

☐ Inverted

Speed 4,000

A 12,000

Advance 3,000

Postpone 1,000

☒ From drawing

Start. point

X 69,415

Y 278,798

End. point

X 65,415

Y 277,798

Radius 0,000

IF Dx<Dy >>


A description of the fields

Name of selected machining








Tools

E1 10 Available tools for scraping the edge.

If allowed by the drawing, then order is:


• Canonical	Scraping in the same direction in which the geometry was created
• Inverted	Scraping in the opposite direction to which the geometry was created
Otherwise order is:	
• Clockwise	Scraping in the same direction in which the geometry was created
• Counter-clockwise	Scraping in the opposite direction to which the geometry was created
Speed	Scraper speed
A	Scraper angle
• Advance	Advance in relation to starting point of machining
• Postpone	Deferment in relation to starting point of machining
From drawing:	If enabled, scraping is carried out on one or more existing geometries, otherwise it is applied directly according to the control settings as below.
Starting point:	
• X	Starting point of scraping on axis X
• Y	Starting point of scraping on axis Y
Ending point:	
• X	End point of scraping on axis X
• Y	End point of scraping on axis Y
Radius:	Sets the radius of an arc
IF>>:	Used to set a condition that enables or not the machining to be carried out. (The instruction IF is exported). If the IF button on the Genio Toolbar is enabled,  machining will only be displayed if the condition is satisfied

A description of the push-button functions

	If pressed, applies the changes to the panel on the basis of the data below
	Appears when no machining has been selected
	Shifts the starting point of a closed scraping
 	Inserts or edits a scraping speed
 	Inserts or edits a tool rotation in a scraping

Finish

The finish (or glue scraper) page, accessible from the Control Panel Toolbar, is used to set values and data related to scraping the glue.



A description of the fields


Name of selected machining

Tools






E1 10 Available tools for scraping

If allowed by the drawing, then order is:

- **Canonical** Scraping in the same direction in which the geometry was created


- **Inverted** Scraping in the opposite direction to which the geometry was created
- Otherwise order is:**
- **Clockwise** Scraping in the same direction in which the geometry was created
 - **Counter-clockwise** Scraping in the opposite direction to which the geometry was created
- Speed** Scraper speed
- A** Scraper angle
- **Advance** Advance in relation to starting point of machining
 - **Postpone** Deferment in relation to starting point of machining
- From drawing:** If enabled, scraping is carried out on one or more existing geometries, otherwise it is applied directly according to the control settings as below.
- Starting point:**
- **X** Starting point of scraping on axis X
 - **Y** Starting point of scraping on axis Y
- Ending point:**
- **X** End point of scraping on axis X
 - **Y** End point of scraping on axis Y
- Radius:** Sets the radius of an arc
- IF>>:** Used to set a condition that enables or not the machining to be carried out. (The instruction IF is exported). If the IF button on the Genio Toolbar is enabled,  machining will only be displayed if the condition is satisfied

A description of the push-button functions

- | | |
|---|---|
|  | If pressed, applies the changes to the panel on the basis of the data below |
|  | Appears when no machining has been selected |
|  | Shifts the starting point of a closed scraping |
|  <div style="border: 1px solid gray; padding: 2px; margin-top: 2px;"> Insert
Modify </div> | Inserts or edits a scraping speed |
|  <div style="border: 1px solid gray; padding: 2px; margin-top: 2px;"> Insert
Modify </div> | Inserts or edits a tool rotation in a scraping |

Radiusing

The radiusing page, accessible from the Control Panel Toolbar, is used to set values and data related to radiusing



A description of the fields

Name of selected machining

Tools

E1 10

Available tools for radiusing

Automatic

If enabled, Radius 1, Radius 2 and Working Dimension are calculated automatically

Radius1

Joining radius

Radius2

Start and end of machining radius

Working dimension


Distance of the start and end of machining from the corner of the geometry

Speed



Radiusing speed

Depth

Depth of radiusing

Inverted	If enabled the radiusing will be programmed with direction opposite to the canonic machining direction.
From drawing	If enabled, radiusing is carried out on one or more existing geometries, otherwise it is applied directly according to the control settings as below.
• X	Coordinate in X of the selected corner
• Y	Coordinate in Y of the selected corner
IF>>:	Used to set a condition that enables or not the machining to be carried out. (The instruction IF is exported). If the IF button on the Genio Toolbar is enabled,  machining will only be displayed if the condition is satisfied

A description of the push-button functions

	If pressed, applies the changes to the panel on the basis of the data below
	Appears when no machining has been selected

Blowing

The blowing page, accessible from the Control Panel Toolbar, is used to set values and data related to blowing.

CONTROL PANEL Ver. 3.0.0

File Modify Tools Utility

Tools -

Direction

☒ Canonical

☐ Inverted

Speed 4,000

A

Advance 3,000

Postpone 1,000

☒ From drawing

Start. point

X 69,415

Y 278,798

End. point

X 65,415

Y 277,798

Radius 0,000

IF Dx<Dy >>

A description of the fields


Name of selected machining

Tools






E1 10 Available tools for blowing

If allowed by the drawing, then order is:

- **Canonical** Blowing in the same direction in which the geometry was created

- **Inverted** Blowing in the opposite direction to which the geometry was created
- Otherwise order is:**
- **Clockwise** Blowing in the same direction in which the geometry was created
 - **Counter-clockwise** Blowing in the opposite direction to which the geometry was created
- Speed** Blower speed
- A** Blower angle
- **Advance** Advance in relation to starting point of machining
 - **Postpone** Deferment in relation to starting point of machining
- From drawing:** If enabled, blowing is carried out on one or more existing geometries, otherwise it is applied directly according to the control settings as below.
- Starting point:**
- **X** Starting point of blowing on axis X
 - **Y** Starting point of blowing on axis Y
- Ending point:**
- **X** End point of blowing on axis X
 - **Y** End point of blowing on axis Y
- Radius:** Sets the radius of an arc
- IF>>:** Used to set a condition that enables or not the machining to be carried out. (The instruction IF is exported). If the IF button on the Genio Toolbar is enabled,  machining will only be displayed if the condition is satisfied


A description of the push-button functions

- | | |
|--|---|
|  | If pressed, applies the changes to the panel on the basis of the data below |
|  | Appears when no machining has been selected |
|  | Shifts the starting point of a closed blowing |
| 
<div style="border: 1px solid gray; padding: 2px; display: inline-block;"> Insert
Modify </div> | Inserts or edits a blowing speed |
| 
<div style="border: 1px solid gray; padding: 2px; display: inline-block;"> Insert
Modify </div> | Inserts or edits a tool rotation in a blowing |

File


New

The New function, accessible from the Control Panel Menu, allows to create and open a new document (drawing).




Open


The Open function, accessible from the Control Panel Menu, allows to open an existing document (drawing).




After the Open function is selected, the following window will be displayed:



A description of the push-button functions




Open the selected file




Close the window and cancel the command


Print all

The “Print all” function, accessible from the Control Panel Menu, allows to print all open documents in the select printer.






A description of the push-button functions



Start printing




Cancel printing

Modify

Input macro

The macro page, which can be accessed from the Control Panel's Modify Menu, allows you to input existing user programs into the macro panel or those supplied freely by the constructor.



A description of the fields

System macro: Macro available supplied by the constructor

User macro:	Macro available programmed by the user
Selected:	Macro selected that will be programmed into the panel as machining processes

A description of the push-button functions



Moves the macro selected by either the system or the user into the "selected" field. You can change the position even by double click on wanted label.




Returns the selected macro in the "Selected" field to their respective fields. You can change the position even by double click on wanted label.



Move up the selected macro



Move down the selected macro




Change the value of the selected macro variables to the "Selected" field.



Window that display the image associated to a macro




Save the changes



Cancel the changes

Drawing variables

The "Drawing variables" page, which can be accessed from the Control Panel's Modify menu, allows to show and modify variables programmed for the active drawing or to create new variables that can be used in formulas for parametric geometries, machinings or macros.



Drawing variables

Global

A1 Prova

	Name	Value	Description
1	Prova	23	Minimum Distance X
2			
3			
4			
5			
6			
7			

Local

A21 DOORS.MACROPROVA1_1_1

	Source	Name	Value	Description
1	ASSEMBLY.FITTING_32_D	PX	80	Minimum distance in X direction default 80
2	ASSEMBLY.FITTING_32_D	PY	30	Minimum distance in Y direction default 30
3	ASSEMBLY.FITTING_32_D	PS	32	centre-to-centre between holes default 32mm
4	ASSEMBLY.FITTING_32_D	PZ	10	depth of holes default 10mm
5	ASSEMBLY.FITTING_32_D	PD	8	Diameter of holes default 5
6	ASSEMBLY.FITTING_32_D	PF	1	
7	ASSEMBLY.FITTING_32_D	PN	"P"	
8	DOORS.MACROPROVA1_1	PX	80	Minimum distance in X direction default 80
9	DOORS.MACROPROVA1_1	PY	30	Minimum distance in Y direction default 30
10	DOORS.MACROPROVA1_1	PS	32	centre-to-centre between holes default 32mm

OK Cancel

Description of fields of the Global spreadsheet

The global variables can be used in all formulas of the active drawing (inside machinings, macros and geometries). If a global variable is modified, all geometries, macros and machinings that use it will be modified.

Name: Variable name

Value: Variable value

Description: Variable description

Description of fields of the Local spreadsheet

The local variables can be used only in formulas inside macros or geometries they belong. If a local variable is modified, only the geometry, or the macro that contain the variable will be modified.


Variabili che sono utilizzabili solamente all'interno delle Macro e delle geometrie a cui appartengono. La modifica del valore modificherà solamente la geometria o la lavorazione o la macro che utilizza la variabile.

Source: Name of the Macro or geometry that is the owner of the variable.

Name: Variable name

Value: Variable value

Description: Variable description

A description of the push-button functions



Save changes



cancel changes

New parametric geometry




The new parametric geometry page, which can be accessed from the Control Panel's Modify menu, allows to save new parametric geometries programmed with the "Edit parametric geometry" utility.



A description of the fields

Name: The name of the drawing that will be saved with the additional profiles


A description of the push-button functions

	Add one or more profiles selecting the active panel
	Save the changes
	Cancel the changes

Edit parametric geometry

The Edit parametric geometry page, which can be accessed from the Control Panel's Modify menu, allows to obtain parametric geometries starting from existing entities such as lines, arcs, polylines, ellipses, circles by adding formula and constraints to the original geometries.

NOTE: formula for parametric geometry programming have the same rules seen for macro programming and parametric machinings programming, remember to begin formulas with the equal (=) symbol.



Parametric polyline

Name: Polyline_1

Point: 2 Closed: ☒

R: 313,349

Clockwise arc: ☒

X: 503,487

Y: 141,356

A1: 319,101

A2: 40,899

☐ Tangent

Name	Value	Description


OK Apply Close

A description of the fields

Name: Name of the selected geometry (line, arc, polyline, ellipse or circles).

Point: Number of the active vertex of the geometry, the active vertex can be changed with the two (arrows) buttons at the left of the point number.

Es. Active vertex



Closed: If enabled the processed geometry is closed or will be closed when updated.

Description of fields common to all points and entities:



Set the value of the coordinate as in the previous vertex



Unlock the vertex coordinate (disable constraints)



Lock the vertex coordinate (enable constraints)

N.B. The angles are positive in clockwise direction when the origin is upper-left, are positive in counter-clockwise direction when the origin is lower-left .

Es. Not-locked (floating) coordinate

Es. Locked (fixed) coordinate

A description of the push-button functions




End point:


Allows constraints programming for the final coordinates X,Y of a line

X	<input type="text" value="434,059"/>		
Y	<input type="text" value="243,262"/>		

Es. Original geometry



Es. Obtained geometry




Length + angle:


Allows constraints programming for length and angle in respect of x-axis of a line

L	<input type="text" value="313,296"/>	
A	<input type="text" value="300"/>	

Es. Original geometry



Es. Obtained geometry






End point + angle:


Allows constraints programming for end point coordinates and angle in respect of x-axis of a line

A	330,000		
X	462,561		
Y	224,977		

Es. Original geometry



Es. Obtained geometry




Arc for three point:


Allows constraints programming for intermediate point (X2, Y2) and end point (X3,Y3) coordinates of an arc.

X2	305,913		
Y2	143,690		
X3	$Dx-(462,561/2)$		
Y3	$Dy-(224,977*2)$		

Es. Original geometry




Es. Obtained geometry




Angle, angle and final point or radius: Allows constraints programming for initial angle A1, final angle A2 and end point (X,Y) coordinates of an arc. The direction is given with the check-box clockwise arc.

R	191,582		
Arco Orario	<input checked="" type="checkbox"/>		
X	550		
Y	224,977		
A1	330		
A2	54,851		

Es. Original geometry



Es. Obtained geometry




Mid point, radius:


Allows constraints programming for mid point (X,Y) coordinates and radius of an arc.

X	307,635		
Y	137,398		
R	300		

Es. Original geometry



Es. Obtained geometry



A description of the push-parametric button functions



Lock the coordinates of the point or polyline to the upper-left vertex of the panel.



Lock the coordinates of the point or polyline to the upper edge of the panel.



Lock the coordinates of the point or polyline to the upper-right vertex of the panel.



Lock the coordinates of the point or polyline to the left edge of the panel.



Lock the coordinates of the point or polyline to the right edge of the panel.



Lock the coordinates of the point or polyline to the lower-left vertex of the panel.



Lock the coordinates of the point or polyline to the lower edge of the panel.



Lock the coordinates of the point or polyline to the lower-right vertex of the panel.




Lock the x-coordinate of the point or polyline to the center of the panel.



Lock the y-coordinate of the point or polyline to the center of the panel.



Shift the active point or polyline in respect of the values programmed in the following window:



A description of the fields

X displacement Translation value along X-axis

Y displacement Translation value along Y-axis

Apply to:


Polyline If selected the translation will be applied to all points of the polyline

Selected point If selected the translation will be applied only to selected point of the polyline

Delete source object If enabled the source geometry will be erased, otherwise no



X-mirror the active point or polyline in respect of the values programmed in the following window:



A description of the fields

X position of mirror line Value of the x-coordinate of the vertical mirror line

Apply to:


Polyline If selected the mirror will be applied to all points of the polyline

Selected point If selected the mirror will be applied only to selected point of the polyline

Delete source object If enabled the source geometry will be erased, otherwise no



Y-mirror the active point or polyline in respect of the values programmed in the following window:



A description of the fields

Y position of mirror line Value of the y-coordinate of the horizontal mirror line

Apply to:

Polyline If selected the mirror will be applied to all points of the polyline


Selected point If selected the mirror will be applied only to selected point of the polyline

Delete source object If enabled the source geometry will be erased, otherwise no




A description of the push-button functions

	Save changes
	Cancel changes

When you push one of the buttons described above , ,  the following window will be displayed:





A description of the push-button functions

	Save changes
	Cancel changes and stop
	Cancel changes and continue



Lock the coordinates of the points of polyline to the edges of the panel.






Remove programmed constraints for a point  or for all points  of the active polyline.

Tangent


If enable the active vertex is a tangent point between two consecutive entities

A description of the push-button functions

	Save changes
	Apply changes temporarily for a preview of the final result
	Cancel changes


Import parametric geometry

The import parametric geometry page, accessible from the Modify menu of the control panel, is used to insert parametric geometries.




Es. How to insert a parametric geometry


1. After you have selected the parametric geometry from the library as in the above window you have to choose the insertion point (you can use o-snaps) and then confirm.





2. If required the operation can be repeated as shown below





3. Perform manual adjustments for inserted geometries.



4. If required, geometries can be joined by clicking the button  of the Genio toolbar.
5. Constraints of the polyline entities can be added or modified with the **Edit parametric geometry** function of the **Modify menu** (see the following window).





6. When constraints programming is ended you can save changes with the button 
7. The obtained parametric geometry can be saved in the parametric library with the **Save parametric geometry** function of the **Modify menu** (see the window below).
8. Give a name to the new polyline, select the parametric shape to save and then click on the Save button, or Cancel to abort.




9. In example above, the new parametric geometry “Gothic” will be saved in the parametric library and could be inserted in the drawings with the utility **Import parametric geometry** of the *Modify* menu.

Modify reference origin


The Origin page, which can be accessed from the Control Panel's Modify menu, allows you to change the origin of the axis'. The actual origin of the reference system is highlighted in red in the drawing.




A description of the push-button functions



Change the reference origin by going counter-clockwise. If one of the zeros located in the four angles is clicked on with the mouse, the origin will be changed without using the button.





Save the changes



Cancel the changes

New Worktop

The New worktop page, which can be accessed from the Control Panel's Modify menu, allows you to input an Worktop. An Worktop server to create machinings that are perpendicular to the surface itself.



A description of the fields

Name of the top: Name of the Worktop




Select line: It selects the line that identifies the worktop




Rotation axis X: Angle of rotation around axis X

A description of the push-button functions




Save the changes



Cancels the changes


Example

1. To create one line




2. Menu Modify→New Worktop→

3.  Select line




4. OK

5. Result



Modify Worktop

The New worktop page, which can be accessed from the Control Panel's Modify menu, allows you to change of machinings that are perpendicular to the surface itself.



A description of the fields

Name of the top: Name of the Worktop



Rotation axis Z: Angle of rotation around axis Z.



Rotation axis X: Angle of rotation around axis X.

Invert orientament: Rotate of 180° around axis Z

Movement parallel: It moves the inclined plan in way parallel regarding that one of origin.



X: Coordinate X of the origin of the plane (referred to the origin of the panel).



Y: Coordinate Y of the origin of the plane (referred to the origin of the panel).


A description of the push-button functions



Modification the inclined plane based to programmed data.




Delete the inclined plane



Cancel the changes

Geometry directions

The geometry directions, accessible from the Modify menu of the control panel, is used to edit geometry parameters or the direction






A description of the fields

Start point:



- **X** Starting point of the geometry on axis X
- **Y** Starting point of the geometry on axis Y
- **Clockwise** If enabled, the direction of the geometry will be clockwise. (Applicable for a closed geometry)
- **Counterclockwise** If enabled, the direction of the geometry will be counter-clockwise. (Applicable for a closed geometry)
- **Invert** If enabled, it reverses the current direction of a geometry.

A description of the push-button functions

	Changes the starting point of a geometry (Applicable for a closed geometry)
	Save the changes
	Cancel the changes

Change


The Change page, accessible from the Modify menu of the control panel, is used to convert machining to geometries



A description of the fields


- **Routing path** Number of selected machinings

A description of the push-button functions

	Save the changes
	Cancel the changes



Explode Macro

The “Explode Macro” function, accessible from the Modify menu of the control panel, allows to convert a parametric Macro in one or more machinings (parametric programming will be lost).



Join millings

The Join millings page, accessible from the Modify menu of the control panel, is used to join several millings in compliance with parameters.




A description of the fields


Selected machining Number of selected machinings

A description of the push-button functions

 Save the changes



Cancel the changes



A description of the fields


Depth:

- **Keep depths** Keeps the current depth values unchanged
- **Recalculate depths** Recalculates the depth values


Tolerance:

- **Maximum distance between millings** Maximum distance for which two millings will be joined
- **Depth tolerance** Minimum allowed variation in depth for joining two machinings

A description of the push-button functions





Save the changes



Cancel the changes

Modify profile In/Out

This function allows the programming/modification of the automatic profile In/Out parameters.



From Drawing: if checked allows programming directly on the graphic window, if not the parameters will be modified with the values programmed in the page.

Automatic entry parameters:

Type of entry:

None: No automatic entry in the profile

Unchanged:	The entry parameters will not be modified
Line:	The automatic entry geometry is a line
Arc:	The automatic entry geometry is an arc
Line + Arc:	The automatic entry is a line followed by an arc
Tangent entry:	If checked the automatic entry will be tangent to the profile (always checked)
Type of approach:	In quota or In descent
Tool radius multiplication factor:	The tool radius' multiplication factor (default=2).


Automatic exit parameters:

Type of exit:	
None:	No automatic exit from the profile
Unchanged:	The exit parameters will not be modified
Line:	The automatic exit geometry is a line
Arc:	The automatic exit geometry is an arc
Line + Arc:	The automatic exit is a line followed by an arc
Tangent exit:	If checked the automatic exit will be tangent to the profile (always checked)
Type of distancing:	In quota or Uphill
Tool radius multiplication factor:	The tool radius' multiplication factor (default=2).

Overlapping on profile: Indicates how the profile overlap is performed with the exit entity.



Cancel the changes





Save the changes


Tools

Dimensioning

The Dimensioning page, which can be accessed from the Control Panel's Tools menu, allows you to dimension the entities (machining) programmed in the panel itself, either automatically or manually. You access the Dimensioning heading from the Utility menu.



A description of the push-button functions



Performs the automatic dimensioning of the panel machining, in compliance with the input parameters in the page



Enables the "linear" dimensioning on the machining axis' selected manually



Enables the "aligned" or relative dimensioning of the machining selected manually



Enables the "coordinated" dimensioning of the machining selected manually.




Enables the angle dimensioning between two machining processes selected manually

A description of the fields

Print:

Allows you to select the type of automatic dimensioning that you wish to perform:

- **Absolute** Performs the absolute coordinate dimensioning of the entities contained in the panel, including its dimensions
- **Relative** Non abilitata: la quotatura "relativa" può essere effettuata manualmente con il bottone 

Entity to be dimensioned:

A series of controls that allows you to select the entities to dimension automatically.

- **Hole diameter** If allowed, the diameters of the hole barriers will be dimensioned.
- **Hole pitch** If allowed, the pitch of the hole barriers will be dimensioned:
- **Routing path vertex** If allowed, the routing path vertex will be dimensioned.
- **Routing path radius** If allowed, the routing path radius will be dimensioned.
- **Machining depth** If allowed, the machining depth will be dimensioned (Es. Z=10)

Text height tools:

sets the height of the text used for the tools table.

Text height:

programs the text height used for dimensioning.

Text color:


programs the text color used for dimensioning.



allows the dimension style to be set (ref: Autocad guide for details)

Draw text

The Draw Text page, which can be accessed from the Control Panel's Utility menu, allows you to insert wording on the panel using the Window True Type font.



A description of the fields

Character height: The input height of the characters written on the panel


Arcs tolerance: The precision with which the character arcs are approached

On Geometry If enabled it allows a writing to be inserted on a geometry


- **Justified** Inserts the writing, occupying the whole geometry proportionally from left to right
- **Right align** Inserts the writing on the right side of the geometry
- **Left align** Inserts the writing on the left side of the geometry

Character spacing: Distance between one character and the next.


E.g. Justified



E.g. Right-aligned



E.g. Left-aligned



- **Normal** The wording is inserted normally from left to right
- **From right to left** The wording is inserted from right to left
- **From top to bottom** Insert the wording from top to bottom


E.g. Normal



E.g. From right to left



E.g. From top to bottom




A description of the push-button functions



Allows for the choice of font





Confirms the draw text



Cancels the changes and, therefore, the draw text is not inserted

Circles on route



The Circles on route page, which can be accessed from the Control Panel's Utility menu, allows you to insert the circles on in the panel, by following the selected profile




A description of the fields

- **Distance between the circles** Enables or not the possibility of inserting a distance between the circles
 - **Number of circles** Enables or not the possibility of inserting n circles
- Diameter of circles:** Programs the circles' diameter
- Distance:** Programs the distance between the circles
- Number of circles:** Programs the number of circles to insert

A description of the push-button functions





Save the changes



Cancel the changes

Oppose

The Oppose heading, which can be accessed from the Control Panel's Utility menu, makes a copy of the machining on the face opposite the machining face selected




A description of the fields:

Selected machinings: Number of machinings selected

Selected geometries: Number of selected geometries




Confirm and open the Oppose table




Exit and de-select the machinings/geometries.

A description of the fields:




Oppose geometries: If enabled and then confirmed with the OK button, symmetrical will be created.

Oppose machinings: If enabled and then confirmed with the OK button, symmetrical machinings will be created.



Creates symmetrical geometries or machinings.





Cancels the changes.

Sort machining

The utility “Sort machining” can be accessed from the Control Panel's Utility menu and allows you to sort manually the sequence of the programmed machining.

The order in which machinings are executed can be changed simple by clicking on the graphic entities directly on the drawing window.





Change machining

The Change Machining utility, which can be accessed from the Control Panel's Modify menu, allows you to change the parameters of previously existing machining.

Clicking on the Check box to be found in front of every object of the tree activates/deactivates the unit to which it is referred.


The order of execution of machining may be changed by dragging an object of the tree by keeping the left mouse button pressed (drag and drop).



Functions available in the Tool Bar



Display the data relative to the selected machining in the modify machining page



The existing machining moves upwards



The existing machining moves downwards



Request the elimination of the machining list selected




Enables or not the display of machining selected from the panel



Makes a copy of the machining selected




Orders the machinings from the panel optimising the tool paths. The following windows will be displayed.




Moves the machining or tool selected upwards



Moves the machining or tool selected downwards



Save the changes



Cancel the changes

Criteria followed by ordering /optimization:

The operations concern all the machining present, whether enabled or not.

The optimization acts as follows:

When you click on the push-button, a window opens up that is similar to the one illustrated above, except for the fact that there are two tables: "Machining ordering" and "Tools ordering" in which there are indicated respectively the sequence ordered by the machining type (Boring, Optimized Boring, Milling, Pocketing, Engraving, Macro) and the ordered sequence (number) of the tools.

By pressing the window's OK push-button, the machining will be ordered strictly in compliance with the following criteria:



- 1) The type of machining according to the "Machining Order"
- 2) The machining inside the same type, firstly according to the "Tool Order" and then according to the face (1, 2, 3, 4, 5, 6) and, finally, optimizing the tool path.



This button allows the programming of additional CNC instruction. After clicking the button the following window will be displayed.



Parameters	Values
X	1500
Y	300
V	2
S	1000
T	E1

A description of the fields:

- Program Instruction** Name of the instruction that will be inserted in the program
- Parameters** Instruction parameters
- Values** Value of the parameters
-  Save the changes
-  Cancel the changes

Display machining list

The Machining Display page, accessible from the Tool menu of the control panel, is used to activate or not the machining layers.












- **Working:**




Routing/Boring Activates/deactivates the routing and boring layer








Edge-banding Activates/deactivates the edge-banding layer





	Trimming	Activates/deactivates the trimming layer
	Scraping	Activates/deactivates the edge scraping layer
	Finish	Activates/deactivates the finish layer
	Blowing	Activates/deactivates the blowing layer
	End trim	Activates/deactivates the end trim layer
	RADIUSING	Activates/deactivates the radiusing layer
	Geometry direction	Activates/deactivates the geometry direction layer
	Geometry	Activates/deactivates the geometry layer
	Panel limit	Activates/deactivates the panel size layer



• **Aux:**

	Lamp	Activates/deactivates the lamp layer
	Tool rotation	Activates/deactivates the tool rotation layer
	Banding material supply	Activates/deactivates the banding material supply layer
	Speed management	Activates/deactivates the speed control layer
	Ghost tools	Activates/deactivates the ghost tool layer

A description of the push-button functions

	Save the changes
	Activate/deactivate all layers of both pages
	Apply the changes without closing the page
	Cancel the changes


Label editor

The function is accessible from the *Label editor* in the Utilities menu.

Program overview

The window that appears upon opening the program presents the following fields.

Empty label on which to start defining the objects



Status bar containing the layout name + the label size and the number of labels for page.

Mouse position (coordinates)


The main aim of the program is to define a label model, all the objects making it up and the print page (layout) and to save the information on the disk to be able to use the label model with the program function *Print labels*. The method of defining the label is almost totally graphic.

Using the tool bar

The tool bar allows fast access to the most commonly used operations and commands.




All the operations available from the tool bar may also be carried out by using the commands in the pull-down menus located above the tool bar.




Inserting objects in a label

To create a label, the properties of reference of the basic objects are edited from the *Objects* menu; e.g. to set the type, size and direction of the barcode to be used, the following window appears:.




the objects (lines, images, barcode, text) are then arranged in the space inside the label area.



Definition of page layout.


To use these sheets, it is necessary to describe the dimensional characteristics of the labels



Using the menu commands

File Menu

The file menu contains the commands for saving, loading, creating and printing a label.



Certain menu commands are also available on the tool bar.



CAUTION: In order for Ottimo to be able to use all the labels, they must reside in the predefined directory “LABELS”, otherwise they are not found at the moment of use and therefore nothing is printed.

- New :** Create a new label, at the same time erasing, without asking confirmation, everything that is present in the current label.
- Open :** Display the disk directory with all the labels present; after selecting one of these, the data are loaded and all the constituent objects are displayed.
- Save :** Save the label that has been designed. It requests the file name if this has not yet been assigned.
- Save as :** Save the label that has been designed, requesting the file name.
- Print :** Print the label design complete with all the objects.
- Printers :** Display a window for selecting the predefined printer.


Parameters :Allow settings of language, application type, destination folder for labels and printer port for Zebra label printer.



Exit : Exit from the program.

Edit Menu

The edit menu contains the commands for cutting, copying and pasting objects, for setting the page layout and testing the label position in print.



Certain menu commands are also available on the tool bar.



The subsequent group of commands allow a minimum of label editing

Cut : delete and store the selected object by one left click.

Copy : store the selected object by one left click.


Paste : insert the last stored object in the same position in which it was removed or copied.

Page settings : define the sizes of the label sheets (see page layout).

Snap to grid: objects of the label will fit the grid.

Visualize Menu


The edit menu contains the commands for zooming, visualizing the characteristics and redrawing the label.



25%...600% : magnify or reduce the drawing area for better control of the actual drawing.

Font Info : display a second status bar with the characteristics of the barcode and the font currently being used for the design.

E.g. : BarCode of EAN128 type, rotated 90° and sized 20x40.



Arial font with font size 8




Whenever a text type or barcode type object is inserted, it takes on the characteristics in use at that time.

Redraw: redraw all the displayed objects in order to delete any impurities. This function may also be accessed by pressing the keys <Ctrl> + <R> simultaneously.

Objects Menu

The objects menu contains the commands for defining the label fields.



Certain commands of the menu are also available on the tool bar.



After having selected the type of object from the menu, it must be positioned on the label by shifting the cursor onto the drawing area and giving a left click. Each of the objects selected from the menu has characteristics which define the rectangular area of the label it will occupy; upon positioning the objects in the label, it will be seen that the rectangle of occupation varies from object to object.


In particular the head type objects that define an Ottimo variable field, have an area of occupation equal to the maximum number of characters of that field.

Horizontal line:

insert a horizontal line of fixed dimensions. To make a longer line, it must be constructed with several objects of the same type.

Vertical line: as above, except that the line is vertical.


Image : load a “.BMP” or “.ICO” type image with the dimensions foreseen by the same in pixel.



Free text: Allow the insertion of a fixed Image (logo, etc...) in the label.

User data: Allow the insertion of an Image from an external panel data of Genio (not used).

Fields of Genio : Allow the insertion of an Image wich name is given from one of the following fields (fields can be programmed in the nesting the panel list).:



Code DWG = DWG file name

Code 1 = Part code 1


Code 2 = Part code 2

Code 3 = Part code 3

Font.... : change the font in use for insertion of text fields. For further information, see the Windows guide.

Bar-Code... : change the current bar code setting.

The scheduled characteristics of the bar code are:




Type: the type of bar code

Rotation : the direction of the bar code on the label, setting the rotation at 90°, the bar code is placed vertically and the dimensions are reversed.


Length and Width: the actual dimensions of the bar code in mm, the number of characters which make it up does not change the size.

The scheduled types of bar code are: Code 11, Code 2 of 5, Code 2 of 5 Industrial, Code 3 of 9 (Code 39) , Code 3 of 9 (Code 39) Ascii, EAN8, EAN13, EAN128, Code 128, Code 128 (CharSet A) , Code 128 (CharSet B) , Code 128 (CharSet C), Code 49

Text : insert a string into the drawing, the string has a different meaning according to the type of sub-command selected, i.e. :




- Free text:** visualize a window for insertion of the text that is then displayed exactly as it has been inserted.
User data: visualize a window for insertion of the index of the external data item of the Ottimo key F5.
Fields of Genio :



- Size X** = Panel length (X)
Size Y = Panel width (Y)
Size Z = Panel thickness (Z)
Totale qty = Obtained quantity for the panel
Progressive qty. = Progressive quantity for the panel
Code DWG = DWG file name
Code 1 = Part code 1
Code 2 = Part code 2
Code 3 = Part code 3
Sheet name = Code of used material
Sheet colour = Color of material

- Date :** insert the date of printing.
Hour: insert the time of printing.

BarCode : insert a bar code that represents the string defined by the type of selected sub-command, i.e. :



- Free text:** visualize a window for insertion of the text that is then codified with the bar code
User data: visualize a window for insertion of the index of the external data item of the Ottimo key F5.


Fields of Genio: see below.

Composition : visualize a window that allows a string to be composed through all the Ottimo and fixed string fields.

Date : codify the printing date.

Hour: codify the printing time.

Fields of Genio: each of the Ottimo fields indicated in the underlying menu is substituted at the time of printing the labels (Appendix A) from the string of the job that the field represents:



Codice1 = Part code 1

Codice2 = Part code 2

Codice3 = Part code 3

Codice Materiale = Code of used material

Colore Materiale = Color of material

The resulting string is then displayed either as text or as bar code, according to the selected command.


Other functions

Page Layout

Upon selecting the command “Page layout” from the menu or from the tool bar, the window shown to the side appears. This window allows all the aspects of a normal sheet of labels for printer to be defined: label sizes, number and composition of the labels on the sheet, the space between one label and another in both directions and the margins between the labels and of the sheet.

Changing the name at the top right and confirming by means of the relative button, a sheet configuration is saved that at the same time becomes the one in use.

To eliminate old configurations, just use the trash button after having selected the configuration in: “Predefined layouts”.



CAUTION: after deletion the old configuration can no longer be recovered.

How to select an object

To select the object of a label, just position the focus on it, pressing the left mouse button.


How to shift an object

To shift a label object, just keep the left mouse button pressed down together with the key <CTRL> and then release it at the point in which the captured object is to be moved.

Label printing

The function is accessible from the item *Print* in the Utilities menu or through key F9 or from the tool bar when the button is activated.

This allows labels to be printed on the office printer, using one of the edited label formats.



Operation

Use of the program is very simple and intuitive; after having selected a label and one or more jobs for which the labels are to be printed, just confirm using the button OK.

The window is divided into 2 parts: the selection part and the configuration part.

Selection fields

Label: this allows the label to be selected from among those prepared with the editor.

File name: this indicates the name or names of the jobs for which the labels are to be printed; the names may be written manually in this field, but they must be inserted between "<" (inverted commas) and separated by a space.

Configuration fields:

- From to:** Print labels **from** pattern **to** pattern
- All :** Print labels for all patterns of the nesting
- Printer:** Allow the selection of the printer
- Windows:** Enable label printing with a windows printer.
- Zebra:** Enable label printing with the Zebra label printing.
- Print Mode:** Select the type of print from among one of the following:
 - **Direct Print:** No controls are performed on the label printer buffer, labels are printed continuously.
 - **Single Buffer:** Print only one label at a time.
 - **Multiple Buffer:** The program check for the "buffer full" before printing a label.

Images

- **Tx sing.:** Image data are sended and stored only at the beginning (recommened if you have a few of images to speed-up printing time).
- **Tx Mult.:** Image data are not stored, for each label the image data are sended again (recommened if you have a lot of images to print).

A description of the push-button functions



Save the changes



Cancel the changes

Group

The Group or Operating Unit page, accessible from the Tool menu of the control panel, is used to create a new machining unit.



A description of the fields:

Group Name	Name of the operating unit that will be inserted
IF	Condition that will be applied to the operating unit
Selected machining	Number of selected machinings that will form part of the operating unit

A description of the push-button functions

	Save the changes
	Cancel the changes


Operativity

Machinings may be inserted in an operating unit in two ways:

- When creating the operating unit, by selecting on the drawing the machining processes to be inserted;


After having created the operating unit, by opening the tree of machinings, they can be inserted into an existing unit or taken out of the unit to which they belong by dragging them with the mouse.

The example to the side shows the tree of machinings of a panel with two operating units: FLD1 and FLD2




Group page

The Group or Operating Unit page, displayed upon selecting a group or unit from the tree of machinings, is used to change the condition of the latter.




A description of the fields:

Group Name: Name of the group or operating unit

IF>>: Used to set a condition that enables or not the machining to be carried out. (The instruction IF is exported). If the IF button on the Genio Toolbar is enabled,  machining will only be displayed if the condition is satisfied

A description of the push-button functions





If pressed, applies the changes to the panel on the basis of the data below

Utility



3D View

The 3D View page, which can be accessed from the Control Panel's Utility menu, allows for a three-dimensional view of the panel with any machining results.




Normal view

Restores the normal view from high up on the panel, performing a total Zoom of the objects contained in the drawing



Wizard programming

The Wizard programming window, which can be accessed from the Control Panel's Utility menu, is a multi-page window that allows to program a group of parameters that can be saved in a *Wizard profile* in order to create automatically a sequence of machining starting from a set of geometries.



Description of fields of the BORING page

The boring page allows the programming of parameters for the creation of boring applied to the selected circular geometries

C:\Programmi\AutoCAD OEM 2004\Wiz\Prova1.gwz

PLANET OPTIMIZATION

BORING MILLING EDGE-BANDING

☒ Enable

☒ Normalize diameters


☒ Group

	From	To	Bit type	Diameter	Depth	Countersink height
1	12	16	P	14	15	3
2	12	18	P	14	15	3
3						
4						
5						
6						
7						
8						
9						
10						
11						
12						

Delete grid


Open Save Save as Delete Close

Enable	If enabled the borings will be created.
Normalize diameters	If enabled boring bits will have normalized diameters according to the values programmed in the Diameter column, otherwise the boring bit diameters will be the same of the circular geometries.
Group	If enabled borings will be joined in a single one.
Description of the spreadsheet columns:	
From/To	The normalization will be applied to all circular geometries with diameters between the first and the second value.
Bit type	Type of boring bit used for drilling.
Diameter	Diameter of the boring bit.
Depth	Drilling depth
Countersink height	Only for countersunk boring bits.



Delete all values of the spreadsheet.

Description of fields of the MILLING page



Enable	If enabled the millings will be created.
Link to geometry	The millings will be linked to the support geometries, if geometries are modified also linked millings will be modified.

Autojoin geometries

Autojoin geometries whose relative distance is lesser then the minimum programmed in the configuration.

NOTE:

The tool compensation and the milling direction can be programmed in different ways for open or close geometries

Tool compensation for open geometries:



Left

Left offset in respect of support geometry.



None

No tool compensation.



Right


Right offset in respect of support geometry.

For disks:




Depth correction

(Only for disks) The machining will start and stop in the same start and stop points of the support geometry



No depth correction

(Only for disks) The disk tool will start and stop with its center aligned to start and end points of the support geometry.



Tool compensation for close geometries:



Left

Left offset in respect of support geometry.



None

No tool compensation.



Right

Right offset in respect of support geometry.



Outside

External offset in respect of support geometry.



Inside

Internal offset in respect of support geometry.

Milling direction for open geometries:



Bottom-Up

Perform a bottom-up milling (only for vertical geometries)



Top-Down

Perform a top-down milling (only for vertical geometries)



Left

Perform a right to left milling (only for horizontal geometries)



Right

Perform a left to right milling (only for horizontal geometries)



Canonic

Perform the milling with the same direction of the support geometry



Inverted

Perform the milling with direction inverted in respect of the support geometry

Milling direction for close geometries:



Canonic

Perform the milling with the same direction of the support geometry



Inverted

Perform the milling with direction inverted in respect of the support geometry



Clockwise

Perform a clockwise milling.



Anti-clockwise

Perform a counter-clockwise milling.

Overmaterial

Offset value for the tooling path in respect of the canonical path. It may be positive or negative depending on the direction of tool correction.

Tools list

E4 10.000 F

Tool list available for millings.

Machining depth


Milling depth.

Automatic profile lead In/Out

If enabled automatic profile lead In/Out are assigned to the milling according to the parameters programmed in the “Advanced page”.

Advanced parameters:

By clicking the button  the following window will be displayed:



The dialog box titled "Automatic profile entry and exit" contains the following settings:

- Automatic profile entry:**
 - ☒ Enable automatic entry
 - Type of entry: ☒ Arc, ☐ Line
 - Approach: ☒ At position, ☐ Downstroke
 - Multiplication factor: 2.000
- Automatic profile exit:**
 - ☒ Enable automatic exit
 - Type of exit: ☒ Arc, ☐ Line
 - Move away: ☒ At position, ☐ Upstroke
 - Multiplication factor: 2.000
 - Profile overlap: 0.000
- Multipassage:**
 - Input speed: 3
 - Number of passes: 1 (with a minus/plus icon)
 - Number of passes: 3 (with a minus/plus icon)
 - Number of passes: 5 (with a minus/plus icon)

Buttons: Ok, Cancel

Automatic profile entry:

Enables automatic entry: Enables automatic entry to the panel (XGIN)

Type of entry: Line or Arc.

Approach: At position or downstroke

Multiplication factor: The tool radius' multiplication factor (default=2).

Automatic profile exit:

Enables automatic exit: Enables the automatic exit from the panel (XGOUT)

Type of exit: Arc or line

Move away: At position or upstroke

Multiplication factor: The tool radius' multiplication factor (default=2).

Profile overlap: Indicates how the profile overlap is performed with the exit entity.

Multipassage:

Bi-directional multi-passage:

Valid for non-closed profiles. If allowed, the tool performs the milling passages without always returning to the starting point; therefore, being able to work both forwards and backwards.





Bi-directional multipass



Normal multipass



Number of passages:

The number of passages that the tool must perform on the milling profile. After each passage, the depth of the machining increases until reaching the final one. The number of passes may be increased or decreased using the buttons  and  respectively.



Final passage depth:

Increase in depth for last pass. (See example in vertical milling section)




Final passage speed:


Speed with which the tool carries out the last pass. If set, the pass will always be carried out at this speed. (See example in vertical milling section)

Input speed

Tool entry speed



Cancel changes



Save changes

Description of fields of the EDGE-BANDING page

C:\Programmi\AutoCAD OEM 2004\Wiz\Prova1.gwz

PLANET OPTIMIZATION

BORING MILLING **EDGE-BANDING**

☒ Enable

☒ Alternate

☒ Multi-edge

☒ Automatic milling

Edge-banding min. length

Edge type

Tool

Open Save Save as Delete Close

Enable	If enabled the edge-banding will be created
Alternate	If enabled edge-banding will be created in alternate mode: first all odd edges and finally all even edges.
Multi-edge	If enabled the multi-edge function will be programmed
Automatic milling	Perform an automating routing, with inverted direction in respect of geometry, before to create the edge-banding
Tool E3 FRESA VERTICALE 23.400 F	Tools allowed for the automatic routing (if enabled).
• Edge type	Number of the edge channel
Edge banding min length	Edge-banding will be performed only for geometries not shorter then the parameter.

Description of fields of the PLANET page

The screenshot shows the PLANET configuration window with the following details:

- END-TRIM:** Enable checked. Tools list dropdown.
- TRIMMING:** Enable checked, Whole profile checked. Canonical selected. Tools list dropdown: E90 REF. 15 GRADI 51.000 R.
- SCRAPING:** Enable checked. Canonical selected. Tools list dropdown: E84 GRUPPO NUOVO DOPPIO 155.
- FINISHING:** Enable checked. Canonical selected. Tools list dropdown: E89 RASCHIATORE COLLA 72.500 U.
- RADIUSING:** Enable checked. Left tool dropdown: E2 FRESA VERTICALE 23.400 F. Right tool dropdown: E2 FRESA VERTICALE 23.400 F.
- BLOWING:** Enable checked. Canonical selected. Tools list dropdown.

End trim:

Enable If enabled the machining will be performed

Tools list

80 Disk 4.200 D Available tools

Trimming:

Enable

If enabled the machining will be performed

Whole profile

If enabled only one Trimming machining will be performed for the entire geometry, also if several edge-banding have been created.

Tools list

E96 REF. RAGGIO 3 51.000 R

Available tools

- Canonical
- Inverted

Perform the machining with the same direction of the geometry

Perform the machining with direction inverted in respect of the geometry

Scraping:

Enable

If enabled the machining will be performed

Tools list

E93 RAS. RAGGIO 2 50.000 U

Available tools

- Canonical
- Inverted

Perform the machining with the same direction of the geometry

Perform the machining with direction inverted in respect of the geometry

Finishing:

Enable

If enabled the machining will be performed

Tools list

E95 RAS. RAGGIO 3 50.000 U

Available tools

- Canonical
- Inverted

Perform the machining with the same direction of the geometry

Perform the machining with direction inverted in respect of the geometry

Radiusung:

Enable

If enabled the machining will be performed

Tools Left/Right

E5 10.000 F

Available tools

Blowing:

Enable

If enabled the machining will be performed

Tools list

E96 REF. RAGGIO 3 51.000 R

Available tools


- Canonical
- Inverted

Perform the machining with the same direction of the geometry

Perform the machining with direction inverted in respect of the geometry

Description of fields of the OPTIMIZATION page


The optimization page allows the choice of which machinings will be optimized. Optimization will be performed at the end of the automatic programming section (Xilog3 or Xilog Plus are required)




Enable

If enabled the optimization will be performed for the selected machinings


A description of the push-button functions



Open an existing wizard profile (file with extension *.gwz).




Save the parameters in the active wizard file.



Save the wizard parameters asking for the filename.




Delete the active wizard file.



Close the wizard programming window.

Apply wizard

The Apply wizard utility, which can be accessed from the Control Panel's Utility menu, allows to apply a programmed wizard profile to one or more geometries.



A description of the fields:

Wizard name Allows to select one of the programmed wizard profiles.




Selected geometries Is the number of selected geometries.

Apply to:


All geometries The wizard profile will be applied to all geometries.

Selected geometries The wizard profile will be applied only to selected geometries

A description of the push-button functions





Apply machinings



Close utility

Head simulation


The Head Simulation page, accessible from the Utilities menu of the control panel, is used to display existing machining simulations.



A description of the fields:

- **Job** Type of simulated machining
- **Tool** Machining tool
- **Diameter** Tool diameter
- **Accuracy** Precision with which the hypothetical tool will move each time when machining

A description of the push-button functions



Backwards



Stop



Forward



Step Forward




Step Backwards

Note: For Planet machines Xilog must be running on the same PC


Verify

(Only for edge banding)

The Verify or Check function, accessible from the Utilities menu of the control panel, checks whether existing machinings can be used correctly on the machine.




After selecting the utility from the menu as shown above, Genio sends the program and the control to Xilog and then open the following window that contains 2 progress bar



When the verification process is finished, Genio will display a successful message or an error message if errors are detected.

A description of the push-button functions




Stop the verification process

Note: For Planet machines Xilog must be running on the same PC


Optimize

(Only for edge banding)


The Optimize function, accessible from the Utilities menu of the control panel, executes controls on the possible carrying out of existing machinings and automatically creates the rotations in such a way as to avoid collisions between the end to be edge-banded and the panel.




After the “Optimize” menu is selected, Genio will display the following window



By enabling or disabling the check-boxes of the window the operator can choose the entities to import from the optimization process




Save the changes




Cancel the changes

By clicking the OK button Genio sends the program and the control to Xilog and then open the following window that contains 2 progress bar



When the optimization process is finished, all selected entities will be updated according to Xilog elaboration.

A description of the push-button functions




Stop the optimization


Note: For Planet machines Xilog must be running on the same PC

Default reset


This allows you to clear all the control panel pages except for the panel definition page, resetting the default values as for a new panel.



A description of the push-button functions




Reset default values




Undo operation

Nesting Geometric

The Nesting Geometric page, accessible from the Tool menu of the control panel, is used to insert panels, with machinings already programmed, in one or more sheets of material in such a way as to minimize the total waste.





Functions available in the Tool Bar



Open the panel list programming page



Open the material list programming page



Display the processed nesting statistics



Process (nesting)



Close the nesting page

A description of the fields:

Name Gns: Name of programmed nesting

Type of Nesting:

- **Free Form** The executed Nesting will be the Free Form type (for any shapes).
- **Rectangular** The executed Nesting will be the Rectangular type (for rectangular shapes only).
- **Guillotine cuts** The executed Nesting will be the type with Guillotine cuts (to be used for pieces of any shape saw cut).
- **Cutting optimizer** The executed Nesting will be the Cutting optimizer type for saw cut with max. 4 cutting

levels (guillotine cuts with head cuts, x, y, z cuts).

Nesting corner: Corner from where nesting panel insertion starts.

Nesting direction: Nesting panel insertion direction.

Rotation: Enables or disables the rotation of pieces in the panel

Step angle: Step angle with which the panels are inserted.

Distance between parts: Distance one panel and another


Distance between edges: Distance of panels from the edges of the sheet of material

Advanced

Advanced nesting options (see description below).











Panel list programming

This is used to program the data related to the list of useable panels to be cut. The panels may be: rectangular, in this case just insert the length and width of the sheet; any shape, in which case insert the DWG or DXF file name containing the closed poly-line that describes the panel outline..



	Code	Rect	DX	DY	Q.ty	Extra Q.ty	Angle	Priority
1	C:\TMP\BACOVERTICEARCO.DW...	<input checked="" type="checkbox"/>	620	800	12	5		
2	C:\TMP\BACOVERTICEARCO2.DWG	<input type="checkbox"/>	620	800	12	4		
3	C:\TMP\BACOVERTICEARCO1.DWG	<input type="checkbox"/>	620	800	12	0		
4	C:\TMP\BACOPOLYPAR.DWG	<input type="checkbox"/>	620	800	12	0		
5								
6								

Functions available in the tool bar

Icon	Rapid selection	Function description
		Open the list of possible dwg files that can be inserted.
		Import general data
		Save the data programmed in the video
		Export general data
		Print the document
		Remove the lines from the selected spreadsheet
		Copy the lines from the selected spreadsheet
		Paste in the previously selected lines
		Insert a line before the selected line
		Exit the programming page.


A description of the fields in the programming spreadsheet

Code:	complete name of the .dwg file containing panel data.
Rect:	If enabled, the panel is rectangular otherwise the outline of the dwg o dxf file is loaded.
DX:	dimension in X of the panel.
DY:	dimension in Y of the panel.
Quantity:	Number of equal panels to be produced.
Extra Quantity:	Maximum allowed surplus production.
Angle:	Angle increment step with which the panels are inserted.

Priority: Indicates the Nesting order. (0= max. priority)

Sheet list programming

Perm This is used to program data related to the list of useable materials to be cut. The material sheets may be: rectangular, in this case just insert the length and width of the sheet; any shape, in this case insert the name of the DWG or DXF file containing the closed poly-line that describes the sheet outline.



Functions available in the tool bar


Icon	Rapid selection	Function description
		Open the list of possible dwg files that can be inserted.
		Import general data
		Save the data programmed in the video
		Export general data
		Print the document
		Remove the lines from the selected spreadsheet
		Copy the lines from the selected spreadsheet
		Paste in the lines selected before
		Insert a line before the selected line
		Exit the programming page.

A description of the fields in the programming spreadsheet

Name:	name of the material or complete name of the .dwg or dxf file containing the description of the material.
Rect:	if enabled the material is rectangular otherwise the outline of the dwg or dxf file is loaded.
DX:	dimension in X of the sheet.
DY:	dimension in Y of the sheet.
Quantity:	number of sheets available in stock.

Machining Nesting

The Machining Nesting page, which can be accessed from the Control Panel's Utility menu, allows for panels to be inserted with the programmed machinings inside one or more materials in such a way as to minimize the total lost



A description of the ToolBar functions



Opens the panel list programming spreadsheet. **N.B. It is possible to insert the same panel several times with different dimensions. All the parametric machinings that will be inserted in the panel will consequently be updated automatically.**



Opens the sheet list programming spreadsheet



Shows statistics for the computed nesting



Start elaboration (Nesting)



Activates/deactivates the layer of the written



It decomposes the patterns in panels and machinings. **N.B. Nesting data will be lost if not saved**



Allows to insert in the active nesting pattern (drawing) a guillotine cut with the programmed tool and depth. Useful to obtain a rectangular waste



Close the Nesting page of Control Panel

A description of the fields

Nst name: Name of the mix in use

Tool: Tool that will be used for nesting

Depth: Depth to which the panels will be cut



Allows access to the following page for the programming of the parameters relative to the automatic entry/exit from the profile.

Automatic profile entry and exit

Automatic profile entry	Automatic profile exit
<input type="checkbox"/> Enable automatic entry	<input type="checkbox"/> Enable automatic exit
Type of entry <input checked="" type="radio"/> Arc <input type="radio"/> Line	Type of exit <input checked="" type="radio"/> Arc <input type="radio"/> Line
Approach <input checked="" type="radio"/> At position <input type="radio"/> Downstroke	Move away <input checked="" type="radio"/> At position <input type="radio"/> Upstroke
Multiplication factor: 2	Multiplication factor: 2
	Profile overlap: -1
Ok	Cancel

Automatic profile entry:

Enables automatic entry: Enables automatic entry to the panel (XGIN)

Type of entry: Line or Arc.

Approach: At position or downstroke

Multiplication factor: The tool radius' multiplication factor (default=2).

Automatic profile exit:


Enables automatic exit: Enables the automatic exit from the panel (XGOUT)

Type of exit: Arc or line


Move away: At position or upstroke

Multiplication factor: The tool radius' multiplication factor (default=2).

Profile overlap: Indicates how the profile overlap is performed with the exit entity.



Cancel the changes



Save the changes

Tooling file: Name of the tooling file used

Nesting panels cutting path: If enabled, the nesting will be performed on the programmed cutting path, otherwise rectangular overall dimensions of panels are nested

Cutting parameters from panels: If enabled, it will use the cutting parameters from panels otherwise it will use the ones programmed in the Control Panel Nesting page.

Correction:

- **Left** The panels will be milled (cut) with offset on the left
- **Center** The panels will be milled (cut) with offset in the center
- **Right** The panels will be milled (cut) with offset on the right

Direction:

- **Clockwise:** The panel will be milled in a clockwise direction
- **Anticlockwise:** The panel will be milled in a counter-clockwise direction

Nesting mode:

- **Free Form nesting** The nesting will be of the Free Form type.
- **Rectangular nesting** The nesting will be of the Rectangular type
- **Guillotine cuts** The nesting will be of the Guillotine-cut type. (it's recommended to use this kind of nesting with a disk tool)

- **Cutting Optimizer (not enable)** The nesting will be of the Optimizer type. Cut with blade, up to 4 cut levels (Head-Cut, Y,X,Z cuts)

Nesting corner: The corner where the input of the nesting panels will start

Nesting direction: The direction of nesting (nesting order).

Parts rotation: Enables or not the rotation of the parts inside the panel

Step angle: The interval rotation angle with which the panels are inserted


Distance between part: The distance between one panel and another

Distance from edges: The minimum distance between nested panels and sheet edges



Advanced nesting parameters (please refer to the following page).

The table of the advanced nesting patterns



A description of the fields:

Panels insert:

- **Fast** The panels are inserted with the first available orientation.
- **Center of gravity** The orientation of the parts that causes the minimum center of gravity will be used for the nesting.
- **Grid** The parts will be nested on the grid.
- **Advanced grid** When the advanced grid is used Slanting grids will not be formed.
- **Center of gravity 2** Advance grid of the center of gravity.


Common parts:

- **None** No nesting attempts are made for common edges or common points.
- **Common edges** Test the nesting with common edges.
- **Common cuts** Test the nesting with both horizontal and vertical common cuts.

- **Common vertical cuts** Test the nesting for common vertical cuts.
- **Common horizontal cuts** Test the nesting for common horizontal cuts.

Panel list programming












This utility allows the programming and view of the Nesting panel list.



The screenshot shows a software window titled 'Mix' with a toolbar and a table. The table has columns: Code, DX, DY, DZ, Type, Q.ty, Extra Q.ty, and Angle. The data is as follows:

	Code	DX	DY	DZ	Type	Q.ty	Extra Q.ty	Angle
1	AGE PEND AV TB	50,000	1113,000	18,000	MDF	10	0	90,000
2	AGE PEND AV BD	50,000	1113,000	18,000	MDF	10	0	90,000
3	PEND CAB AR TB	952,000	150,000	18,000	MDF	10	0	90,000
4	PEND CAB AR BD	952,000	150,000	19,000	BLACK	20	0	90,000
5	PEND CAB AV TB	952,000	150,000	19,000	BLACK	20	0	90,000
6	AGE PEND AR BD	900,000	1060,000	22,000	REDOAK	12	0	180,000
7	AGE PEND AV TB	915,000	1113,000	22,000	REDOAK	12	0	180,000
8	PEND CAB AR TB	952,000	150,000	22,000	REDOAK	12	0	180,000
9	PEND CAB AR BD	952,000	150,000	22,000	REDOAK	12	0	180,000
10								
11								
12								

A description of the ToolBar functions

Icon	Rapid selection	Description
		Open list of files in DWG format that contain panel machinings.
		Import general data
		Save the programmed panel list.
		Export general data
		Print the document
		Delete selected rows.
		Copy in a buffer selected rows.
		Paste previous copied rows at cursor position.
		Insert a new row at cursor position
		Lock the horizontal scroll of all columns at the left of the column of the active cell.
		Close part list programming spreadsheet.

Programming Spreadsheet fields

- Code:** Full-Path name of DWG file that contains panel data
- DX:** Panel length.
- DY:** Panel width.
- DZ:** Panel thickness.
- Type:** Material type of the panel (must match a type in the material archive)
- Q.ty:** Number of panels required.
- Extra Q.ty:** Maximum overproduction allowed.
- Angle:** Angle incremental step with which the panels are inserted.
- Priority:** Indicates the Nesting priority for the panels (0= max. priority)
- Ext1...Ext36:** Extra data for the panel (max. 36 fields) for usage with label printing.


N.B. In machining nesting panel list programming, in export, there are two in the list of possible formats of exportable files that generate files compatible with Ottimo

Formula One (*.vts)
Excel 5 (*.xls)
Tabbed Text (*.txt)
Tabbed Text Values Only (*.txt)
Excel 4 (*.xls)
Formula One 2.x (*.vts)
File testo Ottimo (*.txt)
File Testo Ottimo/Perfect Cut (*.MLC)

Sheet list programming

This utility allows the programming and view of the Nesting sheet list. The nesting utility can nest many sheets having different sizes, each sheet can be rectangular or not.

In case of rectangular sheet you have to input only sheet dimensions, in case of not-rectangular sheet you must insert in the column name the complete name of DWG or DXF file that contains the outline of the sheet. Non rectangular sheets can have one or more pre-cut holes.



	Name	Rect	On	DX	DY	DZ	Type	Q.ty	Color
1	SH1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	2600	1500	18	MDF	100	
2	SH2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	2800	1600	19	BLACK	100	
3	SH3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	2440	1220	19	MDF	100	
4	SH4	<input checked="" type="checkbox"/>	<input type="checkbox"/>	3050	1510	19	MDF	10	
5	SH5	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	2440	1220	22	REDOAK	20	
6									
7									
8									
9									
10									

A description of the ToolBar functions

Icon	Rapid selection	Description
------	-----------------	-------------



Open list of files in DWG or DXF format that contain sheet description (outline).



Import general data



Save the programmed sheet list.



Export general data



Print the spreadsheet data



Delete selected rows.



Copy in a buffer selected rows.



Paste previous copied rows at cursor position.



Insert a new row at cursor position



Close sheet list programming spreadsheet.

Programming Spreadsheet fields

Name: Full-Path name of DWG or DXF file that contains sheet outline

Rect: If enabled the material is rectangular otherwise the shape of the dwg o dxf file is loaded.

On: If enabled the material will be used in the nesting process

DX: Sheet length.

DY: Sheet width.

DZ: Sheet thickness.

Q.ty: Number of available sheets in stock.

Color: Color of the sheet.

Nesting processing

Once the material archive and the panel list have been filled , the nesting can be processed and optimized by clicking



the button.

After the button is pressed, the panel list will be exploded in several lists with panels of the same material type and thickness and the following window will be displayed:

E Explode Nesting

	Type	Thickness	On	Def	Tool	Depth	Piece dist.	Edge dist.	I
1	MDF	18	<input checked="" type="checkbox"/>	<input type="checkbox"/>	E2	19	10	10	
2	BLACK	19	<input checked="" type="checkbox"/>	<input type="checkbox"/>	E1	20	10	0	
3	REDOAK	22	<input checked="" type="checkbox"/>	<input type="checkbox"/>	E1	23	10	0	
4									
5									
6									
7									
8									
9									
10									
11									
12									
13									
14									
15									
16									
17									
18									
19									
20									

OK Restore Cancel

SPREADSHEET FIELDS

Type: Material type (read only).

Thickness: Material thickness (read only).

On: If enabled the panels with the same type and thickness will be optimized

Def: If enabled the nesting parameters of the table will be the same of the nesting page


Tool: Tool used for the nesting cuts.

Depth: Depth for the nesting cuts.

Piece dist.: Minimum distance between panels

Edge dist.: Minimum distance between panels and material edges

The Nesting tree view



A description of the push-button functions



Display the selected machining parameters.



Shift machinings upwards.



Shift machinings downwards.



Eliminate the selected panel(s) and the consequent machinings.



Activate/deactivate the machinings leaving the selected panel visible.




Activate/deactivates the selected panel leaving the machinings.

The report workbook:

The report workbook of the nesting will show a spreadsheet with the general statistics of the whole job and one spreadsheet with statistics for each type of material processed as shown below.

a) General report



A description of the fields:

Job	Job Name
No. of cutting patterns	The number of cutting patterns computed by nesting.
Used	The percentage of material used.
Lost	The percentage of material lost.
Sheets statistics:	
Dx	The width of the material.
Dy	The length of the material.
Dz	The thickness of the material.
Quantity	The quantity of material available.
Used	The quantity of material used.
Mq	Square meters used
Mc	Cubic meters used

Material	The name of the material used.
Panel statistics:	
Dx	The panel width.
Dy	The panel length.
Dz	The panel thickness.
Required	The number of panels required.
Obtained	The number of panels obtained.
Mq	Square meters used
Mc	Cubic meters used
Name	The full-path panel names.
Total square meters	Total amount of material used in square meters.
Total cubic meters	Total amount of material used in cubic meters.

b) Material report

Nesting report

D7

MDF

1	General statistics:																											
2	Used:	77,7																										
3	Lost:	22,3																										
4																												
5	Sheets statistics:																											
6	Dx	Dy	Dz	Type	Q.ty	Used	Sq.M.	Cub.M.	Name																			
7	2400,0	1800,0	18,0	MDF	1000	59	254,880	4,588	MDF181																			
8				Totals	1000	59	254,880	4,588																				
9																												
10																												
11	Panels statistics:									Patterns																		
12	Dx	Dy	Dz	Type	Obt.					Name	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	
13	620,0	800,0	18,0	MDF	100					ANTA1	96	4																
14	620,0	800,0	18,0	MDF	101					SAGOMATO													8	88	5			
15	400,0	300,0	18,0	MDF	101					ANTA1		1	16	1	33	1	3	1			3	25	16			1		
16	520,0	480,0	18,0	MDF	100					ANTA1		3	48				2	36	11									
17	700,0	500,0	18,0	MDF	100					RANT						6	88	6										
18	600,0	800,0	18,0	MDF	100					EMPTYMAC		2	96	2														
19	600,0	800,0	18,0	MDF	100					THOM	48				1	11	2	3	2	18	15							
20																												
21																												
22																												
23																												

Report 1

MDF 18.000

MDF 19.000

A description of the fields:

Panels statistics:

DX:	Panel length.
DY:	Panel width.
DZ:	Panel thickness.

Obtained	Number of nested panels.
-----------------	--------------------------

Name	Panel name.
------	-------------

Patterns	Number of panels nested in the above numbered pattern
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10
11	11
12	12
13	13
14	14
15	15
16	16
17	17
18	18
19	19
20	20
21	21
22	22
23	23
24	24
25	25
26	26
27	27
28	28
29	29
30	30
31	31
32	32
33	33
34	34
35	35
36	36
37	37
38	38
39	39
40	40
41	41
42	42
43	43
44	44
45	45
46	46
47	47
48	48
49	49
50	50
51	51
52	52
53	53
54	54
55	55
56	56
57	57
58	58
59	59
60	60
61	61
62	62
63	63
64	64
65	65
66	66
67	67
68	68
69	69
70	70
71	71
72	72
73	73
74	74
75	75
76	76
77	77
78	78
79	79
80	80
81	81
82	82
83	83
84	84
85	85
86	86
87	87
88	88
89	89
90	90
91	91
92	92
93	93
94	94
95	95
96	96
97	97
98	98
99	99
100	100

A description of the ToolBar functions

Icon	Rapid selection	Description
------	-----------------	-------------




The working parameters spreadsheet:


[illegible]

Nesting export


The program export page, which can be accessed from the File menu of the control panel, allows the export of data regarding a Nesting in an XXL (ASCII) or (PGM Binario) format file. The window that subsequently appears allows the destination directory of the export to be selected.



The Nesting is exported according to the order that is set in configuration (see figure). With this order, for example, the labels will be exported first followed by Machinings and Cuts.



The format of the Nesting Export file may be selected between the two configuration formats that may only be set in configuration:




The machinings are exported according to an order and precise criteria as follows:



Order:

1. Type of machining
2. Tool type

Criteria:

1. If machinings are equal, it will be checked in the Tools section which of these machinings has used the first tool on the list
2. If the tool used by the machinings is also the same, the machining will be selected that has the starting point nearest to the end point of the previous one.





N.B The order in which the Export will be carried out depends on the setting of the type of machining and the type of tool, which may be set in the MACHININGS and TOOLS sections using the arrows  (Shift up)  (Shift down).

A description of the fields:

Export name	Pattern name
Progressive	Progressive pattern number
Machinings	Type of machinings
Tools	Type of tools

A description of the pushbutton functions


	Save the changes
	Undo the changes

Examples of Nesting

Free-form Nesting:

Selecting this kind of nesting you can obtain any shape pieces starting from any shape sheets. Sheets can contain holes that the optimizer will skip.

Cut operations are performed with the programmed tool on the outline of the pieces (in red in the figure below).




Rectangular Nesting:

Special-Purpose for rectangular shapes only.


Selecting this kind of nesting you can obtain rectangular pieces starting from rectangular sheets.

Cut operations are performed with the programmed tool on the rectangular outline of the pieces (in green in the figure below).



Guillotine Cuts:



Selecting this kind of nesting you can obtain any shape pieces starting from rectangular sheets. Cut operations are performed with the programmed tool with guillotine cuts. A guillotine cut starts from an edge of the sheet and finishes to the opposite edge (in red in the figure below).



Connection with the machine

Export programs

The Export Programs Page, which can be accessed from the Control Panel's File menu, allows for the exportation of data concerning a drawing in file format XXL (ASCII) or PGM (Binary).




Operativity

The use of the window is intuitive, after having selected the file you wish to export from the list, just confirm the same by pressing the Save button.

The file will be filled with the data relative to the drawing that is active in the working area and will be in format XXL ore PGM, according to your selection.

TRIA7500 (always PGM format) according to the selection that has been made.

If the selected item on the Save As section is TRIA7500, the following editor window appears




If errors are detected after having closed the editor window, a further response window appears




Import programs

The import programs page, accessible from the control panel's file menu, allows for the importation of file data in format XXL or PGM and displays the machinings on the active drawing in the working area.



When the menu option has been selected, the following dialog window appears:



Operativity

The use of the window is intuitive, after having selected the file that we wish to import from the list, just confirm the same by pressing the Open button

The imported file will be in format XXL or PGM and will contain the machinings that will be translated and displayed in the active drawing's working area.

Xilog instructions handled by import:

B and XB – Boring:	Makes one or more holes.
BO and XBO – Optimized boring:	Makes one or more holes using the boring optimization algorithm.
F – Work face:	Defines the active work face.
BR e XBR – Slanting boring:	Allows for the making of one or more Slanting holes in respect of the squareness of the working surfaces.
C – Tool correction:	Enables the correction of the path of the spindle in relation to the characteristics of the mill that has been mounted.
GO e XG0 – Milling start:	Defines the profile start point.
VT – Opening supports program:	Indicates the start of the rows that describe the traverse position and supports.
GOR e XGOR – Start milling with Slanting tool:	Allows for milling to be started with a Slanting tool on a table that is not square to the panel surfaces
H – Heading:	Describes the panel.
O and XO – Panel origin movement:	Moves the panel origin to the programmed position.

Xilog instructions for milling handled by import:

XL2P – Segment for two points:	Defines a line segment.
XA2P – Arc for two points:	Defines a circular arc given two points.
XA3P – Arc for three points:	Defines a circular arc given three points. The depth of the intermediate point can be different from the final one.
XAR2 – Arc given the radius 2:	Defines a circular arc given the radius.
XAR – Arc given the radius:	Defines an arc given the radius.
XEA – Elipse arc:	Defines an elipse arc that also generates the instruction to start milling
GFIL e XGFIL – Circular connecting milling:	Performs circular connecting milling between the milling programmed before this instruction and the one programmed after it. This instruction connects any linear or circular milling with any other linear or circular milling.
GCHA e XGCHA – Circular rounding milling:	Performs circular rounding milling between the milling programmed before this instruction and the one programmed after it. The instructions given before and after the rounding instructions can be any linear milling.
GIN e XGIN – Automatic profile entry:	Defines a line or circular arc tangente to the profile at the point of entry.
GOUT e XGOUT – Automatic profile exit:	Defines a line or circular arc tangente to the profile in the exit point.
G1 – Linear milling:	Defines a line segment.
G2 – Circular, clockwise milling:	Defines a circular arc clockwise (which goes from the Y axis to the X axis of the reference system).
G3 – Circular, counter-clockwise milling:	Defines a circular arc counter-clockwise (which goes from the X axis to the Y axis of the reference system).

G5 e XG5 – Milling section at a tangent to the precious one: Defines a milling section at a tangent to the previous one.

G1R e XG1R – Linear milling with a Slanting tool: Allows for linear milling on a Slanting plane in respect of the squareness of the panel surfaces; it should be used with Slanting tools and is always referred to face 1 (F=1).

G2R e XG2R – Circular, clockwise milling with a Slanting tool: Defines circular milling (or circular arc) on a table Slanting in respect of the squareness of the panel surfaces, with a clockwise advance movement (which goes from the Y axis to the X of the reference system).

G3R e XG3R – Circular, counter-clockwise milling with a Slanting tool: Defines circular milling (or circular arc) on a table Slanting in respect of the squareness of the panel surfaces, with a counter-clockwise movement (which goes from the X axis to the Y axis of the reference system).

G5R e XG5R – Milling section at a tangent to the previous one with Slanting tool: Defines a milling section at a tangent to the previous one, with a Slanting tool.

NOTE: the import of CNC Xilog programs can be performed also with the “Open” utility of the toolbar in the Macro programming window (Menu file => Macro). In this case programs will be imported as parametric macros.

Hardware configuration

HARDWARE REQUIRED:

- PC PENTIUM III OR HIGHER WITH RAM ON BOARD 256 MB OR HIGHER (PENTIUM IV WITH RAM ON BOARD 512 MB RECOMMENDED)
- SPACE FREE ON THE HARD DISK 200 MB OR HIGHER
- GRAPHIC INTERFACE 800X600 65.000 COLOURS (1024X768 WITH COLOURS AT 24 BIT RECOMMENDED)
- CD ROM
- MOUSE.
- HARDWARE KEY.

OPERATIVE SYSTEMS:

- NT 4 / 2000 / XP.