

## IoT Demo on the Connected LaunchPad TM4C products

# **Smart Home Gateway**

There are countless resources in the IoT world today. Embedded system engineers are faced with a large variety of protocols, cloud services, platforms, techniques and solutions to choose from. Because most of these resources seem disjointed, we have tried most of them and put



together a complete set of resources that you will need to develop an IoT device in less time.

The purpose of this demo is to introduce you to the following resources of choice for the IoT:

- The Texas Instruments Connected LaunchPad TM4C platform.
- The IAR Systems Embedded Workbench for ARM.
- The 2lemetry ThingFabric<sup>™</sup> IoT platform.
- Micriµm embedded software and tools.

The following IoT demo simulates a series of home appliances that you can control and monitor from the web. The minimum hardware requirements include the following components:

- Windows PC
- Texas Instruments Connected LaunchPad (TM4C1294)
- Ethernet Cable
- Micro USB Cable
- IAR Systems Embedded Workbench for ARM
- Micriµm µC/Probe

#### Installing IAR Systems Embedded Workbench for ARM

The IAR Systems Embedded Workbench for ARM incorporates a compiler, an assembler, a linker and a debugger into one single integrated development environment (IDE).

In this step you will install the 32K Kickstart edition of IAR Systems Embedded Workbench for ARM by downloading the installer from the following link:

#### http://supp.iar.com/Download/SW/?item=EWARM-EVAL

The same installer is used for both the 30-day time-limited and the Kickstart (size-limited) evaluation edition.

### Step 2

### Installing Micriµm Software

#### 2.1. Installing Micriµm Embedded Software

The Micriµm Embedded Software includes  $\mu$ C/OS-III and  $\mu$ C/TCP-IP in pre-compiled linkable library form. The application level code is provided for free and solely as a reference to help engineers use Micriµm, Texas Instruments and 2lemetry products.

There are no express or implied copyright licenses granted hereunder to design or fabricate any IoT devices based on the information in this guide.

Micriµm, Texas Instruments and 2lemetry make no warranty, representation or guarantee regarding the suitability of this example for any particular purpose, nor does Micriµm, TI and 2lemetry assume any liability arising out of the application or use of any example design, and specifically disclaims any and all liability, including without limitation consequential or incidental damages.

You can download the Micriµm embedded software from the following link:

http://micrium.com/download/iot-tm4c1294-smarthomegateway

Simply extract the contents in your PC. This guide will make reference to this embedded software by calling it the Micrium folder at *\$Wicrium\\**.

### 2.2. Installing Micriµm µC/Probe

Micriµm µC/Probe is a Windows application designed to read and write the memory of any embedded target processor during run-time. Memory locations are mapped to a set of virtual controls and indicators placed on a dashboard. We will use µC/Probe to monitor and control the IoT device.

In this step you will install de Educational Edition of  $\mu$ C/Probe by downloading the  $\mu$ C/Probe *Windows Installer* from the following link:

#### http://micrium.com/tools/ucprobe/software-and-docs/

The Educational Edition of  $\mu$ C/Probe is available for free evaluation with a few limitations such as a limited amount of features and a limited amount of continuous run-time. This license can be upgraded to the Basic or Professional Editions at any time. For more information go to the following address:

http://micrium.com/tools/ucprobe/features/

### Step 3

### Connecting the Texas Instruments TM4C1294

The TM4C1294 shown below is an evaluation and demonstration board for the Connected LaunchPad TM4C microcontrollers.



All the jumpers should be connected except for JP1 which should be configured for ICDI.

### Installing the Windows Drivers for the Connected LaunchPad TM4C products

The first time you connect the board as described in the previous step, depending on your version of Windows and IAR Systems, Windows may not recognize the USB device. You have to actually install the drivers manually by opening the Device Manager in the Control Panel as shown below:









Update Driver Software - Stellaris Virtual Serial Port (COM30)	Wait for the success
Windows has successfully updated your driver software	message
Windows has finished installing the driver software for this device:	
Stellaris Virtual Serial Port	
	Close

Repeat the same process for the remaining two unrecognized USB devices until you get the following two success messages:





### Working with IAR Systems Embedded Workbench for ARM

**5-1.** The easiest way to open the IAR Systems Embedded Workbench for ARM is by either launching the shortcut on your desktop or by typing in the keyword IAR in the search box shown below:



**5-2.** Click *File*  $\rightarrow$  *Open*  $\rightarrow$  *Workspace...* and browse to the workspace file *uC-MQTT-SmartHomeGwy-Ether.eww* located at the following path in your Windows PC:



Depending on the version of IAR Embedded Workbench installed in your Windows PC, you may be asked to let the tool update your project to your version's format.

You can safely accept and let the tool bring up your project to the correct format. The workspace will open in a window similar to the one shown in the image below:

## Starts a Debugging Session

🚜 uC-MQTT-SmartHomeGwy - IAR Embedd	ded Workbench	IDE			
<u>File Edit View Project J-Link Tools</u>	Window Help	)			
□ ☞ 目 Ø   ●   本 陶 ■   ○ ○		>	h h 🕅 🖻 🖝 🖝 🖌	a 🖦   📭 🥨 D	A A
Workspace	× Jaroba trai	n h lonn c lhon in	t yest this is an effective and	matte	f0 <b>- x</b>
Debug			_vect_whic Tapp_crg.n_app_	indrac	
	58	********	*****	*****	***************************************
Files 800	59	*			LOCAL DEF
UC-MQTT-SmartHomeGwy	60	*** Ar	nlication-level	Code *	*****
	61	- */ ^\F	plication-level	Coue	Ξ.
The smart home gwy c	62				
Smart home gwy.e	63	=  /* 			
	* 65	+ The value	es below can be fou	and by loggin	g into the m2
📕 📙 🖽 💽 app.c	* 66	* Username	: Your email add	iress vou use	d to create t
📕 📙 🖬 app_cfg.h	67	* Password	: MD5 hash of vo	ur password	(32 character
app_mqtt.c	* 68	* Domain:	Randomly gener	ated. Can b	e found on Ac
App_mqtt.h	69	* Device I	ype: Can remain "th	ings". If t	his device is
bsp_ctg.h	70	*	device on the	m2m.io porta	l there may b
	71	* Device I	D: A string uniqu	ely identify	ing this devi
	72	*	devices. Only	needs to be	unique to yo
HT Cos app hooks c	73	*	Common example	s include de	vice's MAC ad
s_app_hooks.h	74		Device-1, Devi	.ce-2 are 11n	e too.
📗 🛏 🔂 os_cfg.h	75	- */			
📗 📙 🔚 os_cfg_app.h	77	· ·			
probe_com_cfg.h	78				
H → ⊕ 🖸 spin_led.c	* 79	#define A	PP_MQTT_M2MIO_USERN	AME	"juan.bena
Spin_led.h	80				
	* 81	#define A	PP_MQTT_M2MIO_PASSW	ORD	"5f4dcc3b5
	82				
			MQTT_M2MIO_DOMAI	N	"com.micri
	Ίμm μC/ S	Software	NOTT NONTO TODIC	CTUER DUD	I amo at h amo
			MOTT M2MIO TOPIC	STUFF SUB	"smarthome
📗 🛏 🗀 uC-Probe	* 87	Jacrine A			Shidt Grone
III - IIII - III - IIII - III	88	#define A	PP MQTT M2MIO BROKE	R HOST NAME	"q.m2m.io"
III - III III III III III	89	#define A	PP_MQTT_M2MIO_BROKE	R PORT	-
	90			_	
□ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □	91	#define A	PP_MQTT_RX_BUF_SIZE		
	92				
	93	#define A	PP_MQTT_JSON_PARSER	_HAYSTACK_MA	X_LEN
U uc-wight i-smarthomeGwy	•	111			<u>ب</u> با
					11

Executable File (ELF)

### **Executing the IoT Example**

In this step you will download the example code into Flash memory and start a debugging session using IAR Systems Embedded Workbench.

- **6-1.** Click  $Project \rightarrow Download and Debug$  to execute the example.
- 6-2. The project will be compiled and a debugging session will be launched.
- **6-3.** The debugger will start by halting the CPU at the main entry point as shown below. Simply press the *Go* button to start execution.



- **6-4.** The example will start  $\mu$ C/OS-III and  $\mu$ C/TCP-IP. The  $\mu$ C/DHCPc will negotiate an IP Address with the network's DHCP server in a process that can take between 1-30 seconds depending on network traffic.
- **6-5.** Use the IAR's Live Watch window to inspect the IP address that your IoT device was able to negotiate with the DHCP server. Click *View* → *Live Watch* and enter the variable name *AppTcpIpAddr* as shown below:



Similarly, inspect the value of the string *AppMQTT\_ThingID* as illustrated in the image above. This is your board's unique ID in the cloud and you are going to need this information later.

### Monitoring and Controlling the IoT Device from µC/Probe

The IoT example featured in this demo runs a simulator to create data for a Smart Home Gateway. The theory of operation can be described as follows:

The sun shines on the solar panels and they generate DC electricity.

This DC current is routed into an inverter that converts it to 120 volts AC, the same as the house's main supply.

Any surplus electricity generated by the system not used by the appliances is used to charge the battery bank or fed back into the mains electricity supply grid; for which a credit is received in the electric bill.

In this step you will use  $\mu$ C/Probe to control and monitor the simulation through a dashboard that contains controls to modify the sunlight intensity and the state of the electrical loads among others. At the same time, the dashboard will display the current output values (amps) calculated by the simulation algorithm as shown in the following image.



7-1. Open µC/Probe in your Windows PC and click *File* → *Open* to open the dashboard example file *SmartHomeGateway.wspx* located at the following path in your Windows PC:



**7-2.** The first time you open the workspace an error message will report that  $\mu$ C/Probe was unable to find the ELF file in your file system.

µC/Probe Mis	sing File	
µC/Probe is un	able to find the follow	ving file :
uC-MQTT-Sn	nartHomeGwy-Ether.out	
µC/Probe found	d the following files in	your working directory :
Name	Modified Date	
	Please select one of	f them to update your workspace
	Please select one of Selected File	f them to update your workspace Browse

You can update the path to the file depending on where you have your *Micrium* folder in your file system:



**7-3.** Click the **Settings** button located in the top toolbar of μC/Probe and configure the Communication Settings to **TCP/IP** and your IoT device's **IP address** as shown in the previous step 5-5.

µC/Pr	obe Settings		
	Endianness	Statistics	Data Collection
	Little Endian	symbols/sec	
TCP/IP	Big Endian	øytes/sec	Slowest Fastest
	Interfaces		Refresh
Cop	None	Settings	IP Addres
ANG	Cloud Only	Remote Ho	st 10.10.1.151
tion	Target Resident Code	Remote Por	t 9930
		✓ Time Ou	t (sec) enable
	🖉 RS-232	Error Han	dling Safe Mode
	🖉 USB	Ignore con	secutive errors for a Disabled
		maximum	time of:
<b>1</b>	Debug Interfaces		
enera	🏂 J–Link		
_	🟂 CMSIS-DAP		
	💣 Cypress PSoC Prog		

- **7-4.** Click the *Run* button located in the top toolbar of  $\mu$ C/Probe.
- 7-5. Click on the Dashboard tab of µC/Probe to go to the Smart Home Gateway dashboard screen. Press the buttons above each appliance to turn the household loads on and off. You can also increase or decrease the sunlight intensity with the vertical slider next to the solar panel.

#### Monitoring and Controlling the IoT Device remotely from the Web

2lemetry's ThingFabric<sup>™</sup> is the IoT platform where all the data generated by the embedded target is stored. The IoT device connects to this platform using MQTT; a simple publish/subscribe protocol. For more information about MQTT please visit <u>http://mqtt.org</u>

Your IoT device is periodically publishing the latest simulation data values to the MQTT broker at 2lemetry via MQTT. At the same time, the IoT device subscribes to a topic to receive any requests from a remote MQTT client to control the Smart Home Gateway.

In this step you will use your internet browser to control and monitor the simulation through a web page that contains controls to modify the sunlight intensity and the state of the electrical loads. At the same time, the webpage will display the current output values (amps) calculated by the simulation algorithm.

8-1. Open an internet browser such as *Google Chrome* and go to the following address:

http://micrium.com/iotdemos/smarthomegateway

8-2. The TM4C1294 board's MAC address will be used as a unique ID in the 2lemetry IoT platform. This unique ID is known as the *Thing ID* and it is displayed on previous step 5-5. Type in the Thing ID (e.g. 00305508....) in the text box to connect to your IoT device as shown below:

http://micriu		icriµm ×	$\widehat{\mathrm{th}} \Leftrightarrow \widehat{\mathrm{tf}}$
٢	Micriµm		٩
MQTT Broker Setting	IS		
Thing ID:			
001AB602A04B		×	
	Connect		
			)
			🔍 100% 🔻 🖽

**8-3.** Once connected to your IoT device you can turn On and Off the household loads as shown in the image below:

< 🔿 🖉 htt	p://micrium.co	m/iot 🔎 🗕 🤇	🏂 🩋 Mi	criµm	×	6 ☆ 5	}
C Micriµm S							
Family Room	ı						
	On On	1.00 1.00 0.75 0.25 0.00			$\neg$		
	Off	2:19:25 PM	2:19:30 PM	2:19:35 PM	2:19:40 PM	2:19:45 PM	
<ul> <li>Kitchen</li> </ul>	).000 Amps	2:19:25 PM	2:19:30 PM	2:19:35 PM	2:19:40 PM	2:19:45 PM	
+ Laundry							
Appliances		Solar Panel		Battery		Net Meter	
						🔍 100% 🔻	.41

Use the navigation bar at the bottom of the web page to go to other views that will display the state of the Solar Panel and Battery Bank. There is also other view labeled as Net Meter, that displays your power meter and how much of that demand is coming from the power company and your solar system.