




A Johnson Electric Company

# Micro Motor (MM)

## User Manual



MM01458000-01 REV: A

August 29, 2012

---

Nanomotion Ltd. POB 623, Yokneam 20692, Israel  
Tel: 972-73-2498000 Fax: 972-73-2498099  
Web Site: [www.nanomotion.com](http://www.nanomotion.com)  
E-mail: [nano@nanomotion.com](mailto:nano@nanomotion.com)

## Copyright

This document contains proprietary information of Nanomotion Ltd., and may not be reproduced in any form without prior written consent from Nanomotion Ltd.

No part of this document may be reproduced, translated, stored in a retrieval system or transmitted in any form and by any means, electronic, mechanical, photographic, photocopying, recording, or otherwise, without the written permission of Nanomotion Ltd.

Information provided in this document is subject to change without notice and does not represent a commitment on the part of Nanomotion Ltd.

Copyright December 2002-2012, Yokneam, Israel. All rights reserved.

All products and company names are trademarks or registered trademarks of their respective holders.

## Limited Warranty

Nanomotion Ltd. (hereinafter NM) warrants the product (other than software) manufactured by it to be free from defects in material and workmanship for a period of time of one year (except those parts normally considered as consumable/expendable components such as motor conditioning brushes). The warranty commences thirty (30) days from the date of shipment.

NM warrants those parts replaced under warranty for a period equal to the remaining warranty coverage of the original part.

NM's sole and exclusive obligation under this warranty provision shall be to repair, or at its sole option exchange defective products or the relevant part or component, but only if: (i) the Purchaser reports the defect to NM in writing and provides a description of the defective product and complete information about the manner of its discovery within ten (10) days of its discovery; (ii) NM has the opportunity to investigate the reported defect and to determine that the defect arises from faulty material, parts or workmanship; and (iii) the Purchaser returns the affected product to a location designated by NM. These provisions constitute the exclusive remedy of the Purchaser for product defects or any other claim of liability in connection with the purchase or use of NM products.

This warranty policy applies only to NM products purchased directly from NM or from an authorized NM distributor or representative.

This warranty shall not apply to (i) products repaired or altered by anyone other than those authorized by NM; (ii) products subjected to negligence, accidents or damage by circumstances beyond NM control; (iii) product subjected to improper operation or maintenance (i.e. operation not in accordance with NM Installation Manuals and/or instructions) or for use other than the original purpose for which the product was designed to be used.

NM shall not in any event have obligations or liabilities to the Purchaser or any other party for loss of profits, loss of use or incidental, increased cost of operation or delays in operation, special or consequential damages, whether based on contract, tort (including negligence), strict liability, or any other theory or form of action, even if NM has been advised of the possibility thereof, arising out of or in connection with the manufacture, sale, delivery, use, repair or performance of the NM products. Without limiting the generality of the preceding sentence, NM shall not be liable to the Purchaser for personal injury or property damages.

## Patent Information

Nanomotion products are covered under one or more of the following registered or applied for patents.

5,453,653; 5,616,980; 5,714,833; 111597; 5,640,063; 6,247,338; 6,244,076;  
6,747,391; 6,661,153; 69838991.3; 6,384,515; 7,119,477; 7,075,211;  
69932359.5; 1186063; 7,211,929; 69941195.5; 1577961; 4813708; 6,879,085;  
6,979,936; 7,439,652; 7061158 ;1800356; 1800356; 1800356; 2007-533057  
(pending); 2011-093431 (pending); 7,876,509; 10-2007-7009928 (pending);  
200780019448.6 ; 7713361.9 (pending); 12/294,926 (pending); GB2008000004178  
(pending); GB2009000003796 (pending); 12/398,216 (pending); GB2446428;  
12/517,261 (pending); 08702695.1 (pending); 10-2009-7017629 (pending); 12/524,164  
(pending); 12/581,194 (pending)

## Revision History

Ver/Rev	Date	Details
00/A	Feb 2009	New release
01/A	June 2010	Add "Mounting the Motor" section
NA	August 2012	Administrative change – added patent information to front matter.

## Table of Contents

<b>1 GENERAL</b>	<b>8</b>
1.1 Scope	8
1.2 Handling and Safety Precautions	8
1.3 Motor Grounding	8
<b>2 MOTOR MOUNTING</b>	<b>9</b>
2.1 Motor Nominal Description	9
2.2 Correct Flexure Position Verification	9
2.3 Flexure Position Correction	14
2.4 Motor Mounting	15
<b>3 MOTOR CONNECTION</b>	<b>20</b>
<b>4 MOTOR RUN-IN</b>	<b>21</b>
<b>5 SPECIFICATIONS</b>	<b>22</b>
5.1 Performance	22
5.2 Electrical	22
5.3 Environmental	22
5.4 Physical Properties	22
5.5 Envelope of Performance	23
5.6 Motor Layout	23
<b>6 CONTACT INFORMATION</b>	<b>24</b>
6.1 Customer Service	24
6.2 General Inquiries and Ordering	24

## List of Figures

Figure 1: Bracketed Motor – Top View .....	9
Figure 2: Inserting the Eccenter Pin .....	10
Figure 3: Turning the Eccenter Pin.....	11
Figure 4: The Leaf Spring is Retracted.....	11
Figure 5: Correct Flexure Position.....	12
Figure 6: Motor Bottom View.....	13
Figure 7: Correcting the Flexure Position .....	14
Figure 8: Mounting the Motor .....	15
Figure 9: Setting a Distance between the Ceramic Strip and the Motor.....	16
Figure 10: Using a Filler Gauge .....	16
Figure 11: Mounted Motor Correct Position.....	17
Figure 12: The Leaf Spring is Retracted.....	18
Figure 13: The rotated Eccenter Pin and the Leaf Spring Applies Pressure on the Element Holder .....	18
Figure 14: Removing the Eccenter Pin.....	19
Figure 15: Motor Moutned.....	19
Figure 16: Motor Connector Pinout .....	20
Figure 17: Motor Layout.....	23

# 1 General

---

## 1.1 Scope

The purpose of this user manual is:

- To introduce the user to the Nanomotion Micro Motor structure.
- To help the user verify motor's correct setting so that the mounting process is successful.
- To guide the user how to correctly mount the motor on the user stage and operate it.
- To provide the user with motor specifications.

## 1.2 Handling and Safety Precautions

Do not power on the motor unless it is properly mounted as explained in chapter 2 further in this user manual.

Ensure that the motor and specifically its tip are not subjected to mechanical shocks.

The mounting base and the method used for mounting should be designed for maximum mechanical rigidity and stiffness.



### **WARNING! HIGHT VOLTAGE!**

- For safety and EMI reasons, it is important to set the power to the motor only after it has been well encased and shielded inside a metal enclosure.

## 1.3 Motor Grounding


Be sure to ground the motor (or its conductive base plate) to the electrical network ground, before operating.



## 2 Motor Mounting

### 2.1 Motor Nominal Description

Nanomotion supplies a bracketed, mounted Micro Motor, see Figure 1.



#### Important:


- Nanomotion supplies an aligned and tested Micro Motor. However, before the removing from the bracket and mounting on the user stage, the user is required to verify the correct motor flexure position, described further in this manual.
- DO NOT remove the motor from the bracket prior to reading the instructions specifically listed in section 2.2.

### 2.2 Correct Flexure Position Verification

**Important:**


- The flexure screws are for factory use only. Opening them will impact motor's performance.
- Use a suitable flat screwdriver for the Eccenter Pin (other than for the mounting screws).

2.2.1 By using pincers, insert the Eccenter Pin (supplied by Nanomotion) between the Leaf Spring and the Element Holder, right under the flexure screws, with the groove facing up, see Figure 2.




**Figure 2: Inserting the Eccenter Pin**

2.2.2 Gently turn the Eccenter Pin (see Figure 3), by using a flat screwdriver, so the Eccenter Pin retracts the Leaf Spring (see Figure 4). Thus there is no contact between the Element Holder and the Leaf Spring. Ensure that the flat screwdriver




**Figure 3: Turning the Eccenter Pin**



**Figure 4: The Leaf Spring is Retracted**




- 2.2.3 Detach the motor from the bracket, by unscrewing the bracket screws.
- 2.2.4 Place the motor on a clean workplace.
- 2.2.5 Observe the motor before mounting. Verify that the flexure is parallel to the Reference Base Line when the Leaf Spring is retracted, see Figure 5. If not, refer to section 2.3 for correcting the flexure position.



**Figure 5: Correct Flexure Position**

- 2.2.6 Ensure that there is a contact between the element and the Element Holder surface at point (a). In case not, gently push the element toward point (a), see Figure 6.
- 2.2.7 Ensure that the element contacts the Element Holder at both points (b). If not: use pincers in order to place the element so it contacts points (b), see Figure 6.




**Figure 6: Motor Bottom View**

## 2.3 Flexure Position Correction

Motor's flexure position could be inclined toward the tip. In order to correct flexure position, perform the following steps:


- 2.3.1 Hold the motor with one hand.
- 2.3.2 **Gently** pull the flexure in the opposite direction to flexure inclination, by using pincers with Teflon tips. For instance, if the flexure is inclined toward the tip, pull the flexure toward the Leaf Spring, as shown in Figure 7.



- 2.3.3 Repeat step 2.3.2 until the flexure plane is parallel to the reference base line.
- 2.3.4 Proceed to step 2.2.6.

## 2.4 Motor Mounting

- 2.4.1 While the Leaf Spring is retracted, mount the motor on the base plate.
- 2.4.2 Insert both mounting screws into the mounting holes.
- 2.4.3 Loosely screw both mounting screws by using a flat screwdriver. (Refer to the motor layout drawing in section 5.6).



**Figure 8: Mounting the Motor**

2.4.4 Move the slide to the left side of the tip, until the end of the travel (see green arrow, Figure 10).

2.4.5 Assure a distance of  $0.8 \pm 0.05$  mm between the ceramic strip and the motor by using a standard filler gauge, refer to Figure 9 **or** alternatively, machine a cavity in the base, refer to Figure 9.




Figure 9: Setting a Distance between the Ceramic Strip and the Motor

2.4.6 Gently push the motor against the filler gauge.

2.4.7 While pushing the motor against the filler gauge (see yellow arrow, Figure 10), tighten both mounting screws.





Figure 10: Using a Filler Gauge




2.4.8 Ensure the following conditions are met:

- The reference base line is parallel to the ceramic strip..
- The element should be in contact with the Element Holder on its rear side (counter to the tip). The element should be in a full contact with the flexure and the Spring Holder.
- The flexure plane should be parallel to the Reference Base Line.
- The slide moves freely with the tip contacting the strip but without friction between the tip and ceramic strip.




In case, the conditions are not met, dismount the motor and proceed to section 2.3.

2.4.9 Gently turn the Eccenter Pin 90°, using a flat screwdriver, so the Leaf Spring now applies pressure on the Element Holder.




**Figure 13: The rotated Eccenter Pin and the Leaf Spring Applies Pressure on the Element Holder**

2.4.10 Pull the Eccenter Pin out of the motor, by using pincers.



**Figure 14: Removing the Eccenter Pin**



**Figure 15: Motor Mounted**

2.4.11 Proceed to chapter **Error! Reference source not found.** for connecting the motor.

**Note:**

- Before dismounting the motor, insert the Eccenter Pin and turn it, so that it retracts the Leaf Spring (refer to steps 2.2.1 and 2.2.2.).




### 3 Motor Connection

This section describes the MM connector pinout and the connections to the Nanomotion driver.

Extending the motor cable will not damage the motor, however it will affect its performance.

The motor - driver connection uses a standard 9-pin D-type female connector, refer to Figure 16 for connector pinout:



**Figure 16: Motor Connector Pinout**



**Important:**

- For safety reasons, the driver voltage is disabled, unless pins 1 and 6 are shorted, when the motor is connected.

## 4 Motor Run-in

---

In order to ensure proper Motor operation, reduce wear rate of the system and to increase its lifetime, it is important to run-in the motor before its normal use.

Following is the list of parameters for the MM Motor run-in.

- Velocity - 100 mm/sec.
- Duty cycle - 50%.
- Duration - 4 hours.

Once the run-in is completed, carefully clean the ceramic strip with a Q-Tip soaked in IPA, **without dismounting the motor**.

The run-in procedure should be repeated if the motor is disconnected and then remounted.



### **WARNING!**

- **Never run-in the motor in a vacuum environment.**

## 5 Specifications

---

### 5.1 Performance

Maximum Allowable Velocity:	250 [mm/sec]
Dynamic Stall Force:	170 [mN]
Static Holding Force	160 [mN] (reference value)
Non-Energized Stiffness	0.04 [N/ $\mu$ ]
Nominal Preload on Stage	0.9 [N]
Kf	25 to 35 [mN/Volt command] - Driver and command dependant
Kfv	0.5 to 0.8 [N • sec/m]
Offset	2 [V] - Driver dependant
Attainable Resolution	Better than 50 nm – See application notes
Nominal Lifetime	20,000 hours under nominal operating conditions

### 5.2 Electrical

Maximal Voltage:	70 Vrms, sine wave
Maximal Current consumption:	18 mA rms ( Cable length dependant)
Maximal Power Consumption:	350 mW

### 5.3 Environmental

Ambient Temperature:	0 - 50°C
Storage:	-40°C ÷ +70°C
Humidity:	0 - 80% non condensing
Residual Magnetism	0.22 nT
Vacuum compatibility	1E-7 Torr. Guaranteed after baking
Bake-out	Max 24 hrs at 120°C

### 5.4 Physical Properties

Weight:	5.5gr
---------	-------

## 5.5 Envelope of Performance


Maximum continues operation at 3.5-10V command	4 sec
Maximum Duty-Cycle at 10V command	10%



### Important:

- The MM driver has an internal protection that stops the driver after 4 seconds for command higher than 3.2V, so protecting the motor from overheating.

## 5.6 Motor Layout



**Figure 17: Motor Layout**

## 6 Contact Information

---

### 6.1 Customer Service

Contact your local distributor or email Nanomotion Ltd. Technical Support Department at **techsupport@nanomotion.com**, with detailed problem description.

### 6.2 General Inquiries and Ordering

- Outside the USA

Nanomotion Ltd. Headquarters

Nanomotion Ltd.

PO Box 223

Yokneam, Israel 20692

Tel: + 972-73-2498065

Fax: +972-73-2498099

Web site: [www.nanomotion.com](http://www.nanomotion.com)

Email: [nano@nanomotion.com](mailto:nano@nanomotion.com)

- In the USA

Nanomotion Inc. (US) Headquarters

Nanomotion Inc

1 Comac Loop, Ste. 14B2

Ronkonkoma, NY 11779

Tel: (800)821-6266

Fax: (631)585-1947

Web site: [www.nanomotion.com](http://www.nanomotion.com)

Email: [nanous@nanomotion.com](mailto:nanous@nanomotion.com)