



# Nilfisk C 120.2 Nilfisk C 125.2



(EN) User Manual

**Nilfisk**



1	Safety precautions and warnings .....	3
2	Description .....	5
3	Before you start using your pressure washer .....	6
4	Operating your pressure washer .....	8
5	Fields of Application and Working Methods .....	9
6	After using your pressure washer .....	11
7	Maintenance .....	12
8	Trouble Shooting .....	14
9	Further information .....	15
10	Main technical data .....	17
11	Declaration .....	18

## 1 Safety Precautions and Warnings

### Symbols used to mark instructions



Before starting up your high-pressure washer for the first time, this instruction manual must be read through carefully. Save the instructions for later use.



This symbol is used to mark safety instructions that must be observed to prevent damage to the machine and its performance.



Safety instructions marked with this symbol must be observed to prevent danger to persons.



This symbol indicates tips and instructions to simplify work and to ensure a safe operation.



Do not let people who have not been trained in the use of a high pressure washer nor read the instruction manual operate the machine.

This appliance is not intended for use by children or other persons without assistance or supervision if their physical, sensory or mental capabilities prevent them from using it safely. Children should be supervised to ensure that they do not play with the appliance.

Before starting up your machine please check it carefully for any defects. If you find any, do not start up your machine and con-

tact your Nilfisk distributor.

#### *Especially check:*

- The insulation of the electric cable should be faultless and without any cracks. If the electric cable is damaged, an authorized Nilfisk distributor should replace it.

#### **WARNING!**

- High pressure jets can be dangerous. Never direct the water jet at persons, pets, live electrical equipment or the machine itself.
- Never try to clean clothes or footwear on yourself or other persons.
- Hold the spray lance firmly with both hands. The spray lance is affected by a thrust

of up to 16.4 N during operation.

- The operator and anyone in the immediate vicinity of the site of cleaning should take action to protect themselves from being struck by debris dislodged during operation. Wear goggles and protection clothes during operation.
- This appliance has been designed for use with cleaning agents supplied or recommended by the manufacturer. The use of other cleaning agents or chemicals may adversely affect the safety of the appliance.
- Disconnect from electrical power supply before carrying out user maintenance.
- To ensure the appliance

safety only use original spare parts from the manufacturer or approved by the manufacturer.

- High pressure hoses, fittings and couplings are important for the safety of the appliance. Only use hoses, fittings and couplings recommended by the manufacturer.
- Do not use the appliance if a supply cord or important parts of appliance are damaged, e.g. safety device, high pressure hose and trigger gun.
- The appliance is intended to clean cars and garden etc..
- Appropriate ear protection has to be used.
- Never use the machine in an environment where there could be a danger of explosion. If any doubt arises, please contact the local authorities.
- It is not allowed to clean asbestos-containing surfaces with high pressure.
- This high pressure washer must not be used at temperatures below 0°C.

### WARNING!

Inadequate extension cables can be dangerous. Cables on drums should always be completely uncoiled to prevent the cable from overheating.

If an extension cable is used, the plug and the socket must be waterproof and comply with the below-mentioned requirements for length and cable dimensions.

1.0 mm <sup>2</sup>	max.	12.5 m
1.5 mm <sup>2</sup>	max.	20 m
2.5 mm <sup>2</sup>	max.	30 m

- If the electric cable is damaged, it must be replaced by the manufacturer or his service agent or similarly qualified person in order to avoid a hazard.

### Mains power connection



The following should be observed when connecting the high pressure washer to the electric installation:

- The electric installation shall be made by a certified electrician and comply with IEC 364.
- It is recommended that the electric supply to this appliance should include either a residual current device that will interrupt the supply if the leakage current to earth exceeds 30 mA for 30 ms.
- The permissible modulus of power supply impedance:  $\leq 0.332 \Omega$ .

### Water connection

- Connection to the public mains according to regulations.
- Inlet hose can be connected to the water mains with a max. inlet pressure of 10 bars.



This high pressure washer is only allowed to be connected with the drinking water mains, when an

appropriate backflow preventer has been installed, Type BA according to EN 1717. The backflow preventer can be ordered under number 106411177. The length of the hose between the backflow preventer and the high pressure washer must be at least 10 metres to absorb possible pressure peaks (min diameter ½ inch).

Operation by suction (for example from a rainwater vessel) is carried out without backflow preventer. Recommended suction set: 126411387.

As soon as water has flown through the BA valve, this water is not considered to be drinking water any more.

**IMPORTANT! Only use water without any impurities.** If there is a risk of running sands in the inlet water (i.e. from your own well), an additional filter should be mounted.

### Safety devices

*Pressure safety device:*

The unloader valve can reduce pressure if it exceeds pre-set values.

*Locking device on spray gun (7a)* (see illustration at the end of this manual):

The spray gun features a locking device. When the pawl is activated, the spray gun cannot be operated.

*Thermal sensor:*

A thermal sensor protects the motor against overloading. The machine will restart after a few minutes when the thermal sensor has cooled.

## 2 Description



### 2.1 Application

This high-pressure washer has been developed for domestic use within:

- Car, motorbike, boat, caravan, trailer, patio/drive/flagstones, woodwork, brickwork, barbecue, garden furniture, lawn mower

Section 5 describes the use of

the high-pressure washer for various cleaning jobs.

Only use the high-pressure washer for purposes described in this manual.

The safety precautions must be observed to prevent damage to the machine, the surface to be cleaned or severe personal injuries.

### 2.2 Operation elements and model survey



See illustration at the end of this manual.

- 1 Start/stop switch
- 2 Water inlet with filter (2a)
- 3 High pressure connection
- 4 High pressure hose
- 5 Electric cable
- 6 Click & Clean spray lance
- 7 Spray gun with lock (7a)
- 8 Click & Clean Tornado® PR nozzle
- 9 Click & Clean Powerspeed® nozzle


- 10 Click & Clean foam sprayer
- 11 Nozzle cleaning tool
- 12 Trolley handle
- 13 Hose hook
- 14 Model tag
- 15 Hook for electric cable

**Specifications:** See model tag (14) of machine.

We reserve the right to alter the specifications.


## 3 Before you start using your pressure washer

### 3.1 Mounting of trolley handle



1. Place the trolley handle (12) on the machine.
2. Secure the handle by mounting the 2 screws.

### 3.2 Mounting of quick coupling




1. Screw the quick coupling tight on to the water inlet (2).

**Note:** The inlet filter (2a) must always be fitted in the water inlet pipe to filter out sand, lime-stone and other impurities as these will damage the pump valves.



**Caution:** Failure to fit the filter will invalidate the guarantee.

### 3.3 Mounting of high pressure hose




Attach the high pressure hose (4) to the spray gun (7).

Detach the high pressure hose by pressing the pawl (A).

## 4 Operating your pressure washer

### 4.1 Connection of high pressure hose




1. Mount the high pressure hose on the outlet (3).

#### 4.2 Mounting of spray lance and Click & Clean nozzles

1. Push the spray lance (6) into the spray gun (7) and screw it on.

2. Attach the nozzle.



**Warning:** When attaching the Click & Clean nozzles, the pawl on the side of the spray lance (6) should come out again.



**Note:** The Tornado® PR nozzle (8) and the foam sprayer (10) feature a swivel lock, which must be positioned in the hole in the Click & Clean spray lance (6).


Press the pawl to detach the Click & Clean nozzle.



**Note:** The spray lance (6) has a built-in low pressure nozzle that can be used for flushing away dirt.

#### 4.3 Water connection

An ordinary 1/2" garden hose of **min. 10 m** and **max. 25 m** will be suitable.



**NOTE:** Connection to the public mains according to regulations.

**IMPORTANT! Only use water without any impurities.** If there is a risk of running sands in the inlet water (i.e. from your own well), an additional filter (106411231) should be mounted.

1. Let the water run through the water hose before connecting it to the machine to prevent sand and dirt from penetrating the machine.

**Note:** Check that the filter is fitted in the water inlet pipe and that it is not clogged up.

2. Connect the water hose to the water supply by means of the quick connector (inlet water, max. pressure: 10 bar, max. temperature: 40°C).

3. Turn on the water.

#### 4.4 Start and stop of the machine (when connected to a water supply)



The spray lance is affected by a thrust during operation - therefore always hold it firmly with both hands.

**IMPORTANT: Point the nozzle at the ground.**

1. Check that the machine is in upright position.
- NOTE:** Do not place the machine in high grass!
2. Release the trigger lock (7a).
3. Activate the trigger of the spray gun (7) and let the water run until all air has escaped from the water hose.
4. Press the Start/stop switch "I" (1).
5. Activate the trigger of the spray gun (7).

Always adjust the distance and thus the pressure of the nozzle to the surface, which is to be cleaned.

Do not cover the machine during operation or use it in a room without adequate ventilation !




**Note:** If the machine is left or not used for 5

minutes, it must be switched off on the start/stop switch "O" (1):

1. Press the start/stop switch "O" (1).
2. Disconnect the electrical plug from the socket.
3. Shut off the water supply and activate the trigger to relieve the machine of pressure.
4. Lock the spray gun (7a).

When releasing the trigger of the spray gun, the machine automatically stops. The machine will start again when you re-activate the spray gun.

#### 4.5 Pressure regulation on the TORNADO® PR-nozzle



The pressure can be regulated on the TORNADO® PR nozzle (8).



# 5 Fields of application and working methods



## 5.1 General

Efficient high pressure cleaning is achieved by following a few guidelines, combined with your own personal experience of specific cleaning tasks. Accessories and detergents, when correctly chosen, can increase the efficiency of your pressure washer. Here is some basic information about cleaning.

### 5.1.1 Detergent and foam

Foam or detergent should be applied onto dry surfaces so that the chemical product is in direct contact with the dirt. Detergents are applied from bottom to top, for example on a car bodywork, in order to avoid "super clean" areas, where the detergent collects in higher concentration and streams downwards. Let the detergent work for several minutes before rinsing but never let it dry on the surface being cleaned. **Note:** It is important that the detergents do not dry up. Otherwise the surface that has to be cleaned can be damaged.

### 5.1.2 Mechanical effect

In order to break down tough layers of dirt, additional mechanical effect may be required. Special wash brushes offer this supplementary effect that cuts through dirt (especially by car washing).

## 5.2 Typical fields of application

Below you will find a description of a lot of cleaning tasks which can be solved by a pressure washer from Nilfisk in association with accessories and detergents.

Task	Accessories 'Click & Clean'	Cleaning method
Car	Car nozzle, auto brush, undercarriage nozzle, Foam sprayer, Car Combi Cleaner	<ol style="list-style-type: none"> <li>1. Apply Car Combi Cleaner with the foam sprayer. Always start from the bottom and work upwards. Let Car Combi Cleaner act for at least 5 min.</li> <li>2. Wash the car with the car nozzle, which has been optimized for quick and gentle cleaning of enamelled surfaces (the jet is wider and not so sharp). Start at the front of the car and work backwards to avoid water from penetrating by the door mouldings.</li> <li>3. Use the brush for removal of traffic film which is not removed by the nozzle. If the car is very dirty, apply Car Combi Cleaner again.</li> <li>4. Attach the undercarriage nozzle and clean undercarriage and wheel arches.</li> <li>5. Remove water from the surface of the car with the scraper on the car brush. <b>Make sure</b> that all grains of sand etc. have been removed before using the scraper. Wipe with a wash leather where the scraper cannot reach.</li> </ol>
Rims, aluminium	Rim brush, auto nozzle, atomizer, Alu Cleaner	<p>Apply Alu Cleaner with an atomizer. Let it act for approx. 5 min. and wash with the rim brush. For steel rims, use Car Combi Cleaner. Use the foam sprayer and wash with rim brush.</p> <p><b>Be careful!</b> The high pressure jet may damage the tyres.</p>
Flagstones, concrete floors and other hard surfaces	Powerspeed® nozzle, Stone & Wood Cleaner, Patio Cleaner	<p>Wash towards outlets or the like. On surfaces with moss or algae you may start by applying Stone &amp; Wood Cleaner with the foam sprayer. Wash before the soap dries. Another more effective and quicker method is to use the Patio Cleaner. Thus you will also avoid splashes.</p>
Garden furniture, wood	Wood Cleaner Garden brush	<p>Apply Wood Cleaner and wash before the soap dries.</p> <p><b>NOTE:</b> Use the garden brush to clean off the dirt.</p>
Brickwork, Wood work	Powerspeed® nozzle, Stone & Wood Cleaner, Patio Cleaner	<p>Same method as for flagstones, but <b>be careful</b> - bad joints and wood may be damaged by high pressure. You may choose only to use the Tornado® nozzle. Adjust the distance (pressure) to the quality of the joints and the wood. Patio Cleaner can also be used on vertical surfaces.</p>
Gutter	Undercarriage nozzle	<p>Wash the gutter with the nozzle. Always wash towards downpipes. <b>Beware</b> not to spray under the roofing.</p>
Cleaning of drain pipes, outlets, down pipes etc.	Tube cleaner	<p>Push the tube cleaner approx. ½ m (to mark) into a tube or drain and activate the trigger of the spray handle. The nozzle opening turning backwards will pull the cleaner through the tube. The nozzle will break down the „plug“ and flush the dirt backwards.</p>
Rust, paint	Water/sandblasting equipment	<p>Mount the water/sand blasting equipment and rust and paint is efficiently and quickly removed. Beware not to damage the surface to be sandblasted.</p>
Greenhouse	Tornado® PR nozzle brush, Stone & Wood Cleaner	<p>Wash with high pressure and maybe a brush. You may use Stone &amp; Wood Cleaner to remove moss and algae.</p>
Garden tools, lawn mover	Tornado® PR nozzle, Powerspeed® nozzle, multiangle adaptor, Metal Cleaner	<p>Rinse the worst dirt off with the nozzle. Apply Metal Cleaner with the foam sprayer and let it act for approx. 5 min. Wash with the nozzle. You may use the multiangle adaptor for hard to get at areas to avoid splashing.</p>

## 6 After using your pressure washer



### 6.1 Storing the washer



**The machine should be stored in a frost-free room!**

Pump, hose and accessories should always be emptied of water prior to storing as follows:

1. Stop the machine (press the start/stop switch “O” (1) and detach water hose and accessory.
2. Restart the machine and activate the trigger. Let the machine run until no more water runs through the spray gun.



3. Stop the machine, unplug and wind up hose and cable.
4. Place spray handle, nozzles and other accessories in the holders of the machine.

Should the machine by mistake be frozen, it will be necessary to check it for damage.

**NEVER START-UP A FROZEN MACHINE.**

**Frost damages are not covered by the guarantee!**


### 6.2 Winding up of electric cable and high pressure hose



To avoid accidents, the electric cable and the high pressure hose should always be wound carefully up.

1. Wind up the electric cable on the appropriate hooks.

### 6.3 Storage of accessories



The standard accessories (nozzles (a), spray handle (b), spray lance (c), foam sprayer (d)) can be stored on the pressure washer.


The nozzle cleaning tool (e) can also be stored on the product.

## 7 Maintenance



**WARNING!** Always disconnect the electrical plug from the socket prior to maintenance or cleaning.


To ensure a long and problem free working life, please take the following advice:



- Wash out water hose, high pressure hose, spray lance and accessories before mounting.
- Clean the connectors of dust and sand.
- Make sure that no sand or dirt is blocking the movement of the pawl on the Click & Clean spray lance. Rinse according to requirement.
- Rinse the detergent spraying attachment after use.
- Clean the nozzles.

Any repair should always be made in an authorized workshop with original spare parts.

### 7.1 Cleaning of water inlet filter




Clean the water inlet filter regularly once a month or more frequently according to use. Carefully loosen the filter with a screwdriver and clean it. Check that it is intact before re-mounting it.

The inlet filter must always be fitted inside the water inlet pipe to filter out sand, limestone and other impurities, as they will damage the pump valves.

**CAUTION:** Failure to fit the filter will invalidate the guarantee.

## 7.2 Cleaning of nozzle



A clogging up in the nozzle causes a pump pressure which is too high. This is why cleaning is required immediately.

EN

1. Stop the machine and disconnect the nozzle.
2. Clean the nozzle. **IMPORTANT:** The cleaning tool (11) should only be used when the nozzle is detached!
3. Flush the nozzle backwards with water.

## 7.3 Cleaning of machine vents

The machine should be kept clean so as to let cooling air pass freely through the machine vents.

## 7.4 Greasing of couplings

To ensure an easy connection and that o-rings do not dry up, the couplings should be greased regularly.

## 8 Trouble-shooting

To avoid unnecessary disappointments, you should check the following before contacting the Nilfisk service organization:


Symptom	Cause	Recommended action
<b>Machine refuses to start</b>	Machine not plugged in Defective socket Fuse has blown Defective extension cable	Plug in machine. Try another socket. Replace fuse. Switch off other machines. Try without the extension cable.
<b>Fluctuating pressure</b>	Pump sucking air  Valves dirty, worn out or stuck Pump seals worn out	Check that hoses and connections are air-tight. Clean and replace or refer to local Nilfisk distributor Clean and replace or refer to local Nilfisk distributor.
<b>Machine stops</b>	Fuse has blown Incorrect mains voltage  Thermal sensor activated  Nozzle partially blocked	Replace fuse. Switch off other machines. Check that the mains voltage corresponds to specification on the model tag. Leave the washer for 5 minutes to cool down. Clean the nozzle (see section 7.2)
<b>Fuse blows</b>	Fuse too small	Change to an installation higher than the amp. consumption of the machine. You may try without the extension cable.
<b>Machine pulsating</b>	Air in inlet hose/pump  Inadequate supply of mains water  Nozzle partially blocked Water filter blocked Hose kinked	Allow machine to run with open trigger until regular working pressure resumes. Check that the water supply corresponds to specifications required (see model tag) <b>NB!</b> Avoid using long, thin hoses (min. 1/2") Clean the nozzle (see section 7.2) Clean the filter (see section 7.1) Straighten out hose.
<b>Machine often starts and stops by itself</b>	Pump/spray gun is leaking	Contact your nearest Nilfisk Service Centre.
<b>Machine starts, but no water comes out</b>	Pump/hoses or accessory frozen No water supply Water filter blocked Nozzle blocked	Wait for pump/hoses or accessory to thaw.  Connect inlet water. Clean the filter (see section 7.1) Clean the nozzle (see section 7.2)

In case problems other than the above occur, please contact your local Nilfisk distributor.

## 9 Further information



### 9.1 Recycling the washer



Make the old cleaner unusable immediately.

1. Unplug the cleaner and cut the electric cable.

Do not discard electrical appliances with household waste.

As specified in European Directive 2002/96/EC on old electrical and electronic appliances, used electrical goods must be collected separately and recycled ecologically.

Contact your local authorities or your nearest dealer for further information.

### 9.2 Warranty conditions

Nilfisk guarantees high pressure washers for domestic use for 2 years. If your high pressure washer or accessories are handed in for repair, a copy of the receipt must be enclosed. Guarantee repairs are being made on the following conditions:

- that defects are attributable to flaws or defects in materials or workmanship. (wear and tear as well as misuse are not covered by the guarantee).
- that the directions of this instruction manual have been thoroughly observed.
- that repair has not been carried out or attempted by other than Nilfisk-trained service staff.
- that only original accessories have been applied.
- that the product has not been exposed to abuse such as knocks, bumps or frost.
- that only water without any impurities has been used.

- that the high pressure washer has not been used for rental nor used commercially in any other way.

Repairs under this guarantee include replacement of defective parts, exclusive of packing and postage/carriage. Besides, we refer to your national law of sale.














The machine should be forwarded to one of the service centres of the Nilfisk organisation with description/specification of the fault.

Repairs not covered by the guarantee conditions will be invoiced. (I.e. malfunctions due to **Causes** mentioned in section **Troubleshooting Chart** of the instruction manual).

In order that Nilfisk can render you optimum service, you should register your product on our web site [www.nilfisk-alto.com](http://www.nilfisk-alto.com) under "PRODUCT REGISTRATION".

### 9.3 Accessories

Only use original accessories.

<b>Click &amp; Clean Car nozzle</b>		Special nozzle for enameled surfaces. Optimal distance: 30 - 50 cm.
<b>Click &amp; Clean Undershassis nozzle</b>		90° angled special nozzle for undercarriage and wheel arches. Integrated guide shoes.
<b>Click &amp; Clean Multiangle adaptor</b>		Adjusted in angles from 0° - 90° for better working posture and cleaning of hard to get at places as for instance barrels or the underside of the lawn mower. Fits all nozzles.
<b>Click &amp; Clean Brushes</b>		For cars and other surfaces. Available in more shapes.
<b>Extension hose</b>		7 m extension hose increasing the working range.
<b>Underchassis spray lance</b>		Special spray lance for washing your car underneath.
<b>Drain &amp; Tube cleaner</b>		15 m long tube cleaner for the cleaning of tubes and drains.
<b>Water-sand-blasting equipment</b>		For removal of paint and rust. Sand available from do-it-yourself shops.
<b>Patio Plus</b>		Equipment for quick cleaning of patio/drive/flagstones.
<b>Garden brush</b>		Rotary brush for cleaning of wooden surfaces.
<b>Rim brush</b>		Rotary brush for cleaning of wheel rims.
<b>Wall hook</b>		For storage of machine on wall.
<b>Rotary brush</b>		For cleaning vehicles and other surfaces.
<b>Water suction kit</b>		For removal of large amounts of water from e.g. garden pounds.




<b>Stone &amp; Wood Cleaner</b>	For flagstones, brick- and woodwork. Suitable for moss and algae.
<b>Plastic Cleaner</b>	For plastic and synthetic materials such as garden furniture.
<b>Metal Cleaner</b>	For cleaning of metal such as garden tools.
<b>Car Combi Cleaner</b>	For cars etc. With rinsing wax.
<b>Alu Cleaner</b>	For surfaces of aluminium. Applied with an atomizer.
<b>Oil &amp; Grease Cleaner</b>	For cleaning of grease and oil on motors for instance. Applied with an atomizer.
<b>Wood Cleaner</b>	For cleaning of wooden surfaces incl. of wooden garden furniture.

## 10 Main Technical Data

Type		C 120.2-6
Rated pressure	bar/MPa	100/10.0
Permissible pressure	bar/MPa	max. 120/12.0
Rated flow	l/min	5.9
Rated input	kW	1.65
Rated voltage	V	230-240
Max. water temperature	°C	40
Inlet pressure	bar/MPa	0.15-10/0.015/1.0
Sound pressure level	dB(A)	78
Guaranteed sound power level	dB(A)	92
Vibration according to ISO 5349	m/s <sup>2</sup>	max. 2.5

# 11 Declaration

 <b>Declaration</b>	
Manufacturer's name and address or his authorized representative in the Community	Nilfisk-Advance AG Nilfisk Business Unit Guido-Oberdorfer-Str. 10 89287 Bellenberg GERMANY
Name of the person responsible for the technical documentation	Wolfgang Nieuwkamp
Description of the equipment: Equipment name Model Dimension Rated output voltage Rated frequency Rated input power Other	High pressure washer Nilfisk C 120.2 280 x 270 x 820 mm AC 230-240 V 50 Hz 1.65 kW
Measured sound power level	90 dB(A)
Guaranteed sound power level	92 dB(A)
Declaration	The equipment refer in this document fulfils all the requirements of the Directive : <b>Machine Directive</b> <span style="float: right;">98/37/EC</span> <b>Low-voltage Directive</b> <span style="float: right;">73/23/EEC</span> EN 60335-2-79: 2004 EN 60335-1/A1: 2004 EN 50366: 2003 <b>EMC Directive</b> <span style="float: right;">89/336/EEC</span> EN 55014-1/A2: 2002 EN 55014-2/A1: 2001 EN 61000-3-2/A2: 2005 EN 61000-3-3/A1: 2001 <b>Outdoor Noise Directive</b> <span style="float: right;">2000/14/EC</span>
Place and date of the declaration	Bellenberg, November 10, 2005
Signature	