Mini-EPICa USB/IEEE 1394-to-SATA II RAID SUBSYSTEM

User Manual

Revision 1.2

Contents

Preface	3
Before You Begin	4
Chapter 1 Introduction	6
1.1 Technical Specification	7
1.2 Identifying Parts of the RAID Subsystem	8
1.2.1 Front View	8
1.2.1.1 Disk Drive Carrier	9
1.2.1.2 LED Indicators	9
1.2.2 Rear View	
1.3 RAID Concepts	11
1.3.1 Definition of RAID Levels	
1.3.2 RAID Levels Summary	14
Chapter 2 Getting Started	15
2.1 Installing Hard Drives	15
2.1.1 Installing the Rubber Feet	
2.2 Using the Key Token (Optional)	
2.3 Preparing the Subsystem and Powering On	
Chapter 3 Configuration Utility	20
3.1 Installing the AP in Microsoft Windows	
3.2 Starting the AP in Linux	
3.3 Starting the AP in Mac OS	25
3.4 Mini-EPICa Management GUI	
3.4.1 Other Buttons of the mini-EPICa Management GUI	27
Chapter 4 RAID Management	30
4.1 Basic Mode	
4.1.1 RAID and Disk Information	
4.1.2 Event Log Viewer	
4.1.3 Basic Raid Configuration	
4.2 Advanced Mode	
4.2.1 Email Notification and Event Settings	
4.2.2 Advanced Raid Configuration	
4.2.3 Firmware Information	43
4.2.4 RAID Settings	45
Chapter 5 Additional Information	46
5.1 How to Change the USB/1394 IO Interface Board to eSATA IO Interface Board	
5.2 How to Change the USB/1394 IO Interface Board to USB 3.0 IO Interface Board	

Preface

About this manual

his manual provides information regarding the quick installation and hardware features of the mini-EPICa USB/IEEE 1394-to-SATA II RAID subsystem. This document also describes how to use the storage management software. Information contained in the manual has been reviewed for accuracy, but not for product warranty because of the various environment/OS/settings. Information and specifications will be changed without further notice.

This manual uses section numbering for every topic being discussed for easy and convenient way of finding information in accordance with the user's needs. The following icons are being used for some details and information to be considered in going through with this manual:



NOTES:

These are notes that contain useful information and tips that the user must give attention to in going through with the subsystem operation.



IMPORTANT!

These are the important information that the user must remember.



WARNING!

These are the warnings that the user must follow to avoid unnecessary errors and bodily injury during hardware and software operation of the subsystem.



CAUTION:

These are the cautions that user must be aware of to prevent damage to the equipment and its components.

Copyright

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written consent.

Trademarks

All products and trade names used in this document are trademarks or registered trademarks of their respective holders.

Changes

The material in this document is for information only and is subject to change without notice.

3

Before You Begin

efore going through with this manual, you should read and focus on the following safety guidelines. Notes about the subsystem's controller configuration and the product packaging and delivery are also included. To provide reasonable protection against any harm on the part of the user and to obtain maximum performance, user is advised to be aware of the

following safety guidelines particularly in handling hardware components:

Upon receiving of the product:

- Place the product in its proper location.
- It should be handled with care to avoid dropping that may cause damage to the product. Always use the correct lifting procedures.

Upon installing of the product:

- Ambient temperature is very important for the installation site. It must not exceed 30°C. Due to seasonal climate changes; regulate the installation site temperature making it not to exceed the allowed ambient temperature.
- Before plugging-in any power cords, cables and connectors, make sure that the power switches are turned off. Disconnect first any power connection if the power supply module is being removed from the enclosure.
- Outlets must be accessible to the equipment.
- All external connections should be made using shielded cables and as much as possible should not be performed by bare hand. Using anti-static hand gloves is recommended.
- In installing each component, secure all the mounting screws and locks. Make sure that all screws are fully tightened. Follow correctly all the listed procedures in this manual for reliable performance.

Controller Configurations

This RAID subsystem supports single controller configuration.

Packaging, Shipment and Delivery

- Before removing the subsystem from the shipping carton, you should visually inspect the physical condition of the shipping carton.
- Unpack and verify that the contents of the shipping carton are complete and in good condition.
- Exterior damage to the shipping carton may indicate that the contents of the carton are damaged.
- ✤ If any damage is found, do not remove the components; contact the dealer where you purchased the subsystem for further instructions.

Unpacking the Subsystem

The package contains the following items:

RAID subsystem unit
One (1) power cord
One (1) USB cable
Two (2) IEEE 1394b cables
Key Token (Optional)
Two (2) screw handle
Four (4) Rubber Feet
Installation Reference Guide / CD

Chapter 1 Introduction



The RAID Subsystem

Unsurpassed Value

- Most cost-effective SATA II RAID subsystem.
- Compact Desktop size with stylish design.

Application Flexibility

- Extends useful life by adapting to future IT/SOHO requirements.

Easy Installation & Maintenance

- Provide a fast and easy way to install and manage the storage.

Low Power Consumption

- Cable-less backplane with integrated RAID processor. No more unnecessary components inside.

Features

- USB 2.0/IEEE 1394b host interface
- Supports RAID over 2TB
- Supports hot spare and automatic hot rebuild
- Local event notification
- Easy management via In-Band data bus
- Transparent data protection for all popular operating systems

RAID Management

- Real time drive activity and status indicators
- Graphical User Interface (GUI) management utility

1.1 Technical Specification

Model	EP-D501-CA
Form Factor	Compact Tower
RAID Processor	Integrated Micro-processor
RAID Levels	0, 1, 3, 5, 10, CLONE, and JBOD
Host Interface	USB 2.0 or IEEE 1394b
Number of Host Channel	1
Data Transfer Rate	Up to 480Mbit/s (USB 2.0)/800Mbit/s (1394b)
Disk Interface	SATAII (3Gb/s)
Number of Hot-swap Disk Trays	Five (5) 3.5-inch Disk trays
Cooling Fans	1
Failed Drive Indicators	Yes
Failed Drive Auto Rebuild	Yes
Environment Monitor	Yes
Data Encryption	Option
Auto Spare Support	Yes
Power Supply	180W (full range)
Environmental Relative Humidity: Operating Temperature:	10% ~ 85% Non-condensing 10°C ~ 40°C (50°F ~ 104°F)
Dimension	221(H) x 156(W) x 260(D)mm
Weight	7Kg (without disks)

Specification is subject to change without notice.

1.2 Identifying Parts of the RAID Subsystem

The illustrations below identify the various parts of the subsystem.

1.2.1 Front View





1.2.1.1 Disk Drive Carrier



HDD Status Indicator



Part	Function
HDD Access LED	This LED will blink blue when the hard drive is being accessed.
HDD Fault LED	Green LED means HDD is detected/good. Red LED indicates hard drive has failed. No LED light means no hard drive in the slot.

1.2.1.2 LED Indicators

Part	Function
Fan Fail LED	LED is off means Fan is good. Red LED means Fan has failed.
Over Temp LED	LED is off means Temperature is normal. Red LED means Temperature exceeded normal range.
Power On LED	White LED means RAID subsystem is powered on.

9

1.2.2 Rear View



USB 2.0 Port

The subsystem has one USB 2.0 port for connecting to Host/Server.

IEEE 1394b Port

The subsystem has one IEEE 1394b port for connecting to Host/Server.

Fan

The fan provides proper ventilation for the RAID subsystem.

Power On/Off Switch

Use the Power On/Off Switch to turn on or off the RAID subsystem.

Power Input Socket

Use the Power Input Socket for connecting the power cable.



NOTE: USB and IEEE 1394 ports use same channel. Only one host connection will work at a time. You cannot use both USB and IEEE 1394 ports at the same time.

Key Token Port

The subsystem has one key token port for inserting the key token.



NOTE: For more information about using the key token, refer to Section 2.2 Using the Key Token.

1.3 RAID Concepts

The basic idea of RAID (Redundant Array of Independent Disks) is to combine multiple inexpensive disk drives into an array of disk drives to obtain performance, capacity and reliability that exceeds that of a single large drive. The array of drives appears to the host computer as a single logical drive.

The RAID subsystem provides data striping, mirroring, XOR calculation and data verification. It supports RAID levels 0, 1, 3, 5, 10, LARGE and CLONE. All RAID levels' capacity can exceed 2 Terabytes. The RAID subsystem behaves as a full 48-bit addressing RAID drive and is 100% ATA compliance.

From (PC) host controller, each logical device (RAID volume) controlled by the RAID system acts just the same as single regular hard disk although a RAID system generally consists of more than one hard disk drives. Therefore, no extra BIOS, driver or software is needed.

1.3.1 Definition of RAID Levels



Striping (RAID 0) for High Performance

Striping or RAID 0 is the segmentation of logically sequential data, such as a single file, so that segment can be assigned to multiple hard disks in a round-robin fashion and thus written concurrently.

Advantage of RAID 0 is to achieve high performance by accumulating each individual hard disk performance. <u>However, if any one hard disk gets defective, information stored in this</u> <u>RAID 0 will become invalid.</u>

The RAID subsystem will just make use of the same disk space for each hard disk under RAID 0 condition. For example, if a RAID 0 consists of 5 different size hard disks, the total usable space of this RAID 0 will be [capacity of smallest size hard disk] * [the number of hard disks in this RAID 0].



Mirror (RAID 1) for High Security

Mirror or RAID1 is the replication of data onto separate hard disk in real time to ensure continuous availability. In a RAID 1 system with two hard disks, the data in one hard disk will be exactly the same as the data in the other hard disk.

The RAID subsystem will also make use of same size disk space in each hard disk in RAID 1. That is, the RAID controller will write data to the same disk space in each hard disk. When reading data, the RAID controller will read data from a specified hard disk. Failure in a hard disk will cause the RAID controller to enter into degraded mode. The host controller can still read/write data to the RAID without knowing any hard disk defect. Users have to replace the hard disk then the RAID controller will enter in on-line rebuild mode automatically.

Besides, if there is only partial defect in a hard disk, the RAID controller will read data from the other healthy hard drive.



Stripe + Mirror (RAID 10) for High Performance and High Security

RAID subsystem could be configured to support Stripe and Mirror at the same time, i.e. RAID 10. Take four hard drives in RAID 10 as an example. Hard drive 0 and hard drive 1 could act as Mirror 1. Hard drive 2 and hard drive 3 act as Mirror 1 too. The RAID controller then configures these two Mirrors as Stripe.

At least two drives (either one in each Mirror) can be allowed to fail without any impact to RAID data access. If two drives from the same Mirror are failed, the RAID data is not accessible and becomes invalid.



CLONE

Clone's action is similar to RAID 1. However, all of the hard disks will be the mirrors. For example, in a four hard drives Clone environment, data in each hard drive will be the same. This mode is useful especially when users would like to copy data from a hard drive to several hard drives at the same time.

The number of allowed failed drives is the total number of drives in the RAID minus one.



Concatenating (Large)

This mode is also named "Large". In this mode, the RAID controller will concatenate all of the hard drives into a single hard drive with larger capacity. For example, if three 500GB hard disks are connected to the RAID subsystem in Large Mode, user will get a single hard disk with capacity of 1,500GB.

If any one hard disk gets defective, information stored in this LARGE RAID will become invalid.



Parity Protection (RAID 3 and RAID 5)

The XOR engine in the RAID controller generates parity block. In RAID 3 mode, parity block will be stored in the same hard disk drive. In RAID 5 mode, parity block will be spread over all of the different hard drives.

The RAID controller will also make use of the same size disk space in each hard disk under RAID 3 / RAID 5 condition.

Failure in a hard disk will cause the RAID controller to enter into degraded mode. Host controller still could rear/write data thru the RAID normally without knowing any defects. Users have to replace the defective hard disk. The RAID controller will then enter into online-auto-rebuild mode automatically.

1.3.2 RAID Levels Summary

RAID Level	No. of Allowed Failed Drives	Description	Min. # of Drives
ο	None	Block striping is provided and yields higher performance than with individual drives. There is no redundancy.	2
1 (10)	1 (2)	Drives are paired and mirrored. All data is 100% duplicated on an equivalent drive. Fully redundant. RAID 1 if use 2 drives; RAID 10 if use 4 drives.	2
LARGE	None	Large is similar to RAID 0 in that it concatenates the capacity of all member drives. The data is written linearly starting with the first disk drive. When first disk drive becomes full, the next disk drive is used. Large can have 2 or more disk drives. There is no data redundancy.	1
CLONE	No. of drives minus 1	Clone provides multiple copies of data in a disk drive. Clone can have 2 or more disk drives.	2
3	1	Data is striped across several physical drives. Parity protection is used for data redundancy.	3
5	1	Data is striped across several physical drives. Parity protection is used for data redundancy.	3

Chapter 2 Getting Started

This section describes the physical locations of the hard drives supported by the subsystem and give instructions on installing a hard drive. The subsystem supports hot-swapping allowing you to install or replace a hard drive while the subsystem is running.

This also discusses on how to power-on the subsystem in preparation for operation.

2.1 Installing Hard Drives

a. Push the tray latch to release a disk tray.



b. Then pull out an empty disk tray.



c. Place the hard drive in the disk tray. Make sure the holes of the disk tray align with the holes of the hard drive.



d. Install the mounting screws on the bottom part to secure the drive in the disk tray.



e. Slide the tray into a slot until it reaches a full stop.



f. Press the lever in until you hear the latch click into place.



2.1.1 Installing the Rubber Feet

Four (4) rubber feet can be attached to the base of the unit to provide stable stand. The following are the steps in installing the rubber feet:

1. Prepare the four (4) rubber feet.



2. Remove the rubber feet by pulling it outward.



3. Attach the rubber feet on the base of the unit. The rubber feet can also be pasted on the unit anywhere the user prefers, but must be evenly spaced so that the unit will stand firm and stable.



2.2 Using the Key Token (Optional)



NOTE: The key token provides data encryption.

When key token is in the key token port, and the RAID subsystem is powered on and then the RAID volume is formatted and data is stored, the data is encrypted. If the key token is removed and RAID subsystem is powered off then powered on, the data cannot be accessed. The key token must be in the key token port during power on. However, the key token can be removed or kept while the RAID subsystem is in use.

When the RAID subsystem is powered on and used without the key token, and RAID volume is formatted and data is stored, the data is not encrypted. The RAID subsystem works like standard model.

Here are some steps and scenarios when using the key token:

Scenario 1: Data is accessed normally

- 1. While the RAID subsystem is powered off, insert the key token and eSATA cable.
- 2. Power on the RAID subsystem.
- 3. In host system, format the RAID volume and copy data.
- 4. Finish setup

Scenario 2: Data will not be accessible

- 1. After you do steps in scenario 1, data is accessible.
- If you power off the unit, remove the key token, power on, and rescan disk drives in OS, the RAID volume will be shown as "Unknown Disk". Data cannot be accessed.



WARNING: Do not initialize and format the unknown disk. If you do this, the previous data will be erased.

How to solve this issue?

- 1. Unmount/ uninstall the RAID volume.
- 2. Power off the RAID subsystem, insert the key token, and power on the unit.
- 3. RAID volume is online again and data can be accessed.

2.3 Preparing the Subsystem and Powering On

Here are the steps to prepare the RAID subsystem for use.

1. Connect the USB cable or IEEE 1394 cable from RAID subsystem to the USB port or IEEE 1394 port on Host/Server. Insert the key token into the key token port (if your RAID subsystem has Key Token).



NOTE: Only one host connection will work at one time. You cannot use both USB and IEEE 1394 ports at the same time.



NOTE: The Key Token is optional. The RAID Subsystem can be purchased with or without Key Token.



- 2. Connect the power cable to the power input socket. Plug the other end of power cord to the power source.
- 3. Turn on the Power On/Off Switch.

Chapter 3 Configuration Utility

The subsystem has a setup configuration utility containing important information about the configuration as well as settings for various optional functions in the subsystem. This chapter explains how to use and make changes to the setup utility.

Configuration Method

The RAID subsystem can be configured using the Application Program provided with the subsystem. There are three versions: Microsoft Windows version, Linux version, and Mac OS version.



IMPORTANT: The RAID subsystem must be connected to the Host system in order to configure the RAID subsystem. If the RAID subsystem is not connected to the Host system, the Application Program will show "No disks or RAID!"



NOTE: At least one disk drive must be inserted in the RAID subsystem. If there is no disk drive in the RAID subsystem, the Application Program will show "No disks or RAID!"

	۔ آس	niepica ,
	RAID and Disk Infor	mation
Iduanced Mode Basic Mode		Information No disks or RAID!



IMPORTANT: When hard disks are inserted in the disk slots, the first inserted hard disk is assigned "Port 0". Port 0 is the (in-band) channel that will be used by mini-EPICa AP to manage the RAID controller. Other hard disks will be assigned Port1, Port 2, etc. If the first hard disk assigned as Port 0 is removed, the AP cannot access and manage the RAID controller. When a RAID Set is already created, the first hard disk that was inserted and assigned Port 0 (whether or not it is part of the RAID Set) can then be removed and the AP can still manage the RAID controller.

3.1 Installing the AP in Microsoft Windows

1. To install mini-EPICa AP for Windows OS, copy the installation files to a local directory and open the **setup.exe** program.

🌀 Back 🔻 🕤 🝷 🏂 🔎 S	earch 🌔 Folders 📗	\$ D × 9 🖽		
Address 🛅 C:\Documents and	Settings\Administrator\[Desktop\windows AP 0.09	9.29	
Name 🔺	Size	Туре	Date Modified	Attrib
Application		File Folder	2/23/2009 5:38 PM	
🧱 setup.exe	904 KB	Application	1/22/2009 12:13 PM	А
🍓 setup.ini	1 KB	Configuration Settings	1/21/2009 9:52 PM	A
🔊 SetupCHS.dll	ं44 KB	Application Extension	10/14/2008 4:29 PM	А
SetupCHT.dll	44 KB	Application Extension	9/4/2008 12:17 AM	А
🔊 SetupENU.dll	44 KB	Application Extension	9/4/2008 12:15 AM	А
🔊 SetupJPN.dll	44 KB	Application Extension	10/14/2008 8:36 PM	А

2. Click Install to begin the installation. The setup wizard will start installing.



3. Click Finish to exit the wizard. The application will be launched immediately.



The mini-EPICa Application Program main screen will be displayed.



3.2 Starting the AP in Linux

To configure the RAID subsystem when connected to Linux system, go to the directory where the Application Program is saved and open the Application Program.

🗎 🛛 Linux	
<u>F</u> ile <u>E</u> dit <u>V</u> iew <u>P</u> laces <u>H</u> elp	
center.gif Company.bmp	EPICaRaidSetu p
Linux > "miniEPICaRaidSetup" selected (9.6 MB)	

This example is from Fedora Core 9.

Another way is to open terminal window, then at the command prompt type "./miniEPICaRaidSetup".

After running the Application Program, the mini-EPICa main screen will be displayed.



3.3 Starting the AP in Mac OS

To configure the RAID subsystem when connected to Mac OS X Server, go to the directory where the Application Program is saved and open the Application Program.



After running the Application Program, the mini-EPICa main screen will be displayed.

	Basic RAID Config			
	Controller 1 Configure RAID	No. Raid Name No RAID!	Raid Level Capacity	Disk No.
	RAID 1 LARGE	Disk1 465.75 GB	Unreleased 465.75 GB	
	CLONE	Disk2 465.75 GB	Unreleased 465.75 GB	
	RAID 5 RAID 10	Disk3 232.88 GB	Unreleased 232.88 GB	
	DELETE ALL RAID Support Password	Disk4 232.88 GB	Unreleased 232.88 GB	
,		Disk5 232.88 GB	Unreleased 232,88 GB	
			Apply	Cancel

3.4 Mini-EPICa Management GUI

The mini-EPICa management GUI contains the following menu options:

Basic Mode:

<u></u>	RAID and Disk Information	Provides information about RAID and disk drives. This also have Advanced information which shows System Information such as temperature, fan speed and voltage levels. This can also display SMART information of disk drives after RAID is created.
	Event Log Viewer	Shows the RAID controller event log.
Ô,	Basic Raid Configuration	Provides function for creating basic RAID configuration. This function will use all available disk drives.

Advanced Mode:

	Email Notification and Event Settings	This function provides option to configure email for sending event notifications when events happen.
O	Advanced Raid Configuration	This function provides option to customize RAID configuration and select disk drive members.
	Firmware Information	Shows information about current firmware and provides function to upgrade the firmware version.
	RAID Settings	Provides settings such as RAID Stand-by Timer and RAID Rebuild Priority.

3.4.1 Other Buttons of the mini-EPICa Management GUI

Minimize Window button – Used to minimize the mini-EPICa GUI into taskbar.



Close Windows button - Used to close the mini-EPICa GUI.



Note that the AP is still running in the background. To exit the AP, right-click the mini-EPICa icon in the task bar then select Quit from the pop-up menu.



About button – Used to display the current mini-EPICa AP version.







Turn Off the Buzzer – Use this to silence the alarm buzzer.

Chapter 4 RAID Management

This chapter provides details about configurations and options available in the RAID subsystem. There are two modes of operation: Basic Mode and Advanced Mode.

4.1 Basic Mode

Under Basic Mode, there are three menu options that can be selected: RAID and Disk Information, Event Log, and Basic Raid Configuration.

4.1.1 RAID and Disk Information

RAID and Disk Information provides information about RAID and disk drives.



RAID and Disk Information: No existing RAID configuration



Disk Information: Disk drive is "Unreleased" or not a RAID member.



RAID Information: Disk Drives are RAID 5 member.

RAID Information:

RAID Level – Shows the RAID Level of the RAID

Status – Shows the current status of the RAID. Status can be:

Normal – No failed disk drive.

Degrade – One or more disk drives failed in a RAID Level with data redundancy. The data is still accessible.

Broken – One or more disk drives failed in a RAID Level. The number of allowable failed disk drives in the RAID Level has been exceeded and data is not accessible.

Rebuilding (%) – The RAID is in rebuilding state. The completed rebuilding percentage is shown.

Capacity – Shows the capacity of the RAID

Plugged Member(s) - Shows the disk drive slots which are member of the RAID



Disk Information: Disk drive is a RAID member.

Disk Information:

Model Name – Shows the disk drive model Serial Number – Shows the disk drive serial number Firmware Version – Shows the disk drive's firmware version Capacity – Shows the capacity of the disk drive Unreleased Capacity – Shows the amount of unused or unreleased capacity in the disk drive

Disk Information . Advanced

This will show SMART information of the selected disk drive if SMART function is supported by the disk drive.



Controller 1: Controller Information

This will show the System Information screen contains hardware information about the RAID subsystem such as temperature, fan speed and voltage levels.

ок

System Informati	Controller 1
Temperature:	30 Celsius [Normal]
Fan Speed:	3308 RPM [Normal]
Voltage (+3.3V):	3.216¥ [Normal]
Voltage (+5¥):	5.016¥ [Normal]
Voltage (+12¥):	11.856¥ [Normal]
	ОК

4.1.2 Event Log Viewer

The RAID controller event log can be viewed from this menu. It will show the Number of Events, the Issued Module, Date, Type, and Message.



Event Log Buttons:

Save To File – This option allows the event logs to be saved as a log text file (.log). Enter the filename you want for the log file and click "Save".

O V 📕 « AP 🕨 windows		▼ 49	Search	
File <u>n</u> ame:				
Save as type: Log file (*.log	*.txt)			
Browse Folders			Save	Cancel

Clear – Selecting this option will clear the event log. When the dialog box shown below is displayed, select "Yes" to delete all event logs.

Do you want to continue it?	i	Pressing <clear> button will result in all previous event logs being deleted permanently.</clear>
		Do you want to continue it?

4.1.3 Basic Raid Configuration

This menu provides function for creating basic RAID configuration. This function will use all available disk drives in the RAID subsystem.

	Basic RAID Config	uration		
	Controller 1 Configure RAID	No. Raid Name No RAID!	Raid Level Capacity	Disk No.
	C RAID 1	Disk1 465.75 GB	Unreleased 465.75 GB	
\odot	CLONE	Disk2 465.75 GB	Unreleased 465,75 GB	
	RAID 5 RAID 10	Disk3 232.88 GB	Unreleased 232,88 GB	
	DELETE ALL RAID Support Password	Disk4 232.88 GB	Unreleased 232,88 GB	
		Disk5 232.88 GB	Unreleased 232,88 GB	
		_	Apply	Cancel

Basic Raid Configuration Options:

- **Configure RAID** Select the RAID Level from the list of options. The RAID Levels that can be selected for the number of available disk drives are enabled. When there is an existing RAID, the "DELETE ALL RAID(s)" option is enabled.
- Support Password This option provides RAID security. When this option is enabled and a password is entered in the corresponding box, deleting the RAID will require the password to be entered. Using a wrong password will not allow the RAID to be deleted. The password can be up to 8 characters.

Basic Raid Configuration Buttons:

Apply – Save the configuration and create the RAID.

Cancel – Undo the current operation.



NOTE: The RAID subsystem supports up to two RAIDs.

To create a RAID using Basic Raid Configuration:

1. In the Configure RAID option, select the RAID Level you want for the RAID. Click "Apply" to save the RAID configuration.

	– Mi	ini EP		× ⊗	?
Advanced Mode 🚦 Basic Mode	Basic RAID Configu Controller 1 Configure RAID RAID 0 RAID 1 LARGE RAID 3 CLONE RAID 3 CLONE RAID 5 RAID 5 RAID 5 RAID 10 DELETE ALL RAID	Disk1 Disk1 Disk1 Disk1 Disk2 Disk2 Disk3 Disk4 Disk4 Disk4 Disk4 Disk4 Disk4 Disk4 Disk4 Disk4 Disk5 Disk5	Raid Level Capacity RAID 5 931.38 GB Here: Yookine (Here: Yookine Here:	ion of Roma Ion of Roma	
	 			Apply Cancel	

2. When a dialog box is displayed, select "Yes" to confirm creating RAID.



3. A progress bar will be shown.

						٦
	3	Inform	ation M	essage	1	
			onfigur		eed	
	some t	ime. Pl	ease w	ait		I
1			52%			
10						

4. An information message will be displayed. Click "OK".



5. The RAID is created successfully. The RAID will be available to the Host/Server immediately and a new disk device will be detected.

	000 Basic RAID Config	ÎNÎ EP[uration		<u>()</u>	?
	Controller 1 Configure RAID	No. Raid Name 1. 5Bays H/W RAID5	Raid Level Capacity RAID 5 931.38 GB	Disk No. D1, D2, D3, D4, D5	
ni	 RAID 1 LARGE RAID 3 CLONE 	Disk1 465.72 GB Disk2 465.72 GB	M0(P0) 232,84 GB M1(P0) 232,84 GB	Unreleased 232.88 GB Unreleased 232.88 GB	
	RAID 5 RAID 10 DELETE ALL RAID Support Password	Disk3 232.84 GB Disk4 232.84 GB	M2(P0) 232,84 GB M3(P0) 232,84 GB		
		Disk5 232.84 GB	M4(P0) 232.84 GB App	ly Cancel	
6. Check the new disk drive in your Host/Server.

Example: Connection via USB





(Proware H/W RAID IEEE 1394 SBP2 Device) is displayed.

4.2 Advanced Mode

4.2.1 Email Notification and Event Settings

This function provides option to configure email for sending event notifications when events happen.

	- mini EPIC a	× 8 ?
_	Email Notification and Event Settings	
Advanced Mode Basic Mode	SMTP Server Name: SmTP Server Port: Sender E-mail: Sender Username: Sender Password: Recipient E-mail(s): Select event(s) for notification: Image: Select event(s) for notification: <t< th=""><th>COPYRIGHT© ALL RIGHTS RESERVED.</th></t<>	COPYRIGHT© ALL RIGHTS RESERVED.
Advar		Save To Profile Apply Cancel

Email Notification Options:

SMTP Server Name – Enter the SMTP Server name or IP address SMTP Server Port – Enter the SMTP Server port number; normally it is '25'. Sender E-mail – Enter the sender's email address

- Sender Username Enter the sender's username
- **Sender Password** Enter the sender's password which is authenticated by the specified mail server.
- **Recipient E-mail(s)** Enter one or more recipient email addresses. Multiple email addresses are separated by `;'.
- Select event(s) for notification Tick the events which you want to be included in the list of events for email notification. When selected events happen, the email recipient(s) will receive the event notification.

Email Notification Buttons:

Send Mail Test – Use this send a mail to the specified recipient(s) for testing.
Load From Profile – Use this button to load mail settings from a profile.
Save To Profile – Use this button to save the mail settings to a profile.
Apply – Use this button to apply changes to the configuration.
Cancel – Undo any changes made.

Check Mark – Select all events

Cross Mark – Clear all events

4.2.2 Advanced Raid Configuration

This function provides option to customize RAID configuration and select disk drive members.

 Advanced RAID Co	ni EPI	Ca	<u>()</u> ?
Controller 1 Configure RAID • Create RAID	No. Raid Name No RAID!	Raid Level Capacity	Disk No.
O Delete RAID Create RAID RAID 0 RAID 0	Disk1 465.75 GB	Unreleased 465,75 GB Unreleased	
RAID 1 LARGE RAID 3 CLONE		465.75 GB Linneleased 232.88 GB Linneleased	
RAID 5 RAID 10 Support Password	Disk5 232.88 GB Disk5 232.88 GB	Unreleased 232:88:68 Unreleased 232:88:68	
		Apply	Cancel

Advanced Raid Configuration Options:

- **Configure RAID** Select option whether to Create RAID or to Delete RAID. When Create RAID is selected, the RAID Level options are displayed. When Delete RAID is selected, the list of available RAIDs that can be deleted is displayed.
- **Create RAID** Select the RAID Level from the list of options, and select the disk drives in the right pane. When the minimum number of disk drives for the RAID Level has been selected, the Apply and Cancel buttons will become active and can be used.
- **Delete RAID** Select the RAID from the list of RAIDs displayed, and click Apply to delete the selected RAID.
- Support Password This option provides RAID security. When this option is enabled and a password is entered in the corresponding box, deleting the RAID will require the password to be entered. Using a wrong password will not allow the RAID to be deleted. The password can be up to 8 characters.

Advanced Raid Configuration Buttons:

Apply – Save the configuration and create the RAID. **Cancel** – Undo the current operation.



To create a RAID using Advanced Raid Configuration:

- 1. In the Configure RAID option, select Create RAID.
- 2. Select the RAID Level you want for the RAID.
- 3. Select the disk drives you want to become member of the RAID.

	Advanced RAID C	onfigura	ntion			-
5	Controller 1 Configure RAID Create RAID	No.	Raid Name New Volume	Raid Level Capacity RAID 5 698.53 GB	Disk No. D2, D3, D4, D1	
OT_	O Delete RAID Create RAID RAID 0		Disk1 465.72 GB	New Volume (Mile 2021;04:52	Unreleased 232.88 GB	
) 	RAID 1 LARGE RAID 3		Disk2 465.72 GB Disk3 232.84 GB	New Yolkine (150) 122,04,68 (Pil) 232 (Pil) 232		
1	CLONE RAID 5 RAID 10 		Disk4 232.84 GB	50000 000 (042) 232		
	Support Password		Disk5 232.88 GB GB	Unrele: 252.8		
		_			Apply Cancel	

- 4. If you want security for the RAID, enable Support Password and enter a password.
- 5. Click "Apply" to save the RAID configuration. A dialog box will be displayed. Select "Yes" to proceed.



6. A progress box will be displayed.



7. An information message will be displayed. Click "OK".



8. The RAID is created successfully. The RAID will be available to the Host/Server immediately and a new disk device will be detected.

	Advanced RAID C	onfigur	ation			Ċ
5	Controller 1 Configure RAID • Create RAID	No. 1	Raid Name 5Bays H/W RAID5	Raid Level Capaci		
OT_	Create RAID		Disk1 465.72 GB	M3(P0) 232.84 GB	Unreleased 232.88 GB	
	RAID 1 IARGE RAID 3		Disk2 465.72 GB Disk3 232.84 GB	M0(P0) 232.84 GB M1(F 232.84		
1	CLONE RAID 5 RAID 10	╞	Disk4 232.84 GB Disk5	M2(F 232.84 Unrele:	ŧ GB	
			232.88 GB	232.8		
					Apply Cancel	

9. Check the new disk drive in your Host/Server.



Example: Connection via IEEE 1394



(Proware H/W RAID IEEE 1394 SBP2 Device) is displayed.

4.2.3 Firmware Information

Shows information about current firmware and provides function to upgrade the firmware version.

		- mi	ni EPICa	× 🔇 ?	
Advanced Mode		Firmware Informati	on Controller 1: Firmware Information 5 Bays RAID V0.955 [6/11] 2	Browse Update	COPYRIGHT© ALL RIGHTS RESERVED.
	_				J

Firmware Information – shows the Product Name, Firmware version, Manufacturer, and Flash Number.

Firmware Upgrade Buttons:

- **Browse** Use this button to browse and select the firmware file. After selecting the firmware file, the Select Firmware box will show the selected firmware file.
- **Update** Use this button to upgrade the selected firmware file.

To upgrade firmware:

- 1. Select "Browse" and locate the firmware file.
- 2. Select "Update" to proceed with firmware upgrade.

		- × mini EPICa × 8 ?	
		Firmware Information	
υ		Controller 1: Firmware Information	
Poμ		1. Product Name 5 Bays RAID	RESERVED
Basic Mode		2. Firmware Version V0.955 [6/11]	
ä		3. Manufacturer	3HTS
mini	<u>-</u>	4. Flash Number 2	L RIG
Mode		Select Firmware: are-Work/miniEpica/Firmware/PRO5110_1031_test2.8IN Browse	сорукіснт© аll rights
Σp	2		GHT(
Advanced	1		ΡΥRΙ
Hdua		100%	CO

3. The firmware will be upgraded. Click "OK".



4. To reboot the RAID subsystem, uninstall the disk drive from the host system then power cycle the RAID subsystem. The new firmware will be loaded in the RAID controller.

4.2.4 RAID Settings

The RAID Settings provides options such as RAID Stand-by Timer and RAID Rebuild Priority.

	- × mini EPICa	8	
	RAID Settings		
Basic Mode	Controller 1 : 5Bays H/W RAID5 (PO) RAID Stand-by Timer Settings Please enter a value between 0 and 10922 (minutes):		RESERVED.
Advanced Mode	Image: Constraint of the state of the s	¢ High	COPYRIGHT© ALL RIGHTS
	Apply	Cancel	

- **RAID Stand-by Timer Settings** Use this option to select time option, in minutes, before the RAID comes into stand-by mode. When there is no host access to the RAID, after the preset time (minutes), the RAID will be in standby mode.
- **RAID Rebuild Priority Settings** Use this option to set the RAID Rebuild Priority, which is the amount of system resource allotted to rebuilding process. Low priority means rebuilding process will take less system resource and more time to complete; and High priority means rebuilding process will be completed faster but access to RAID will be slower.

Apply – Save the settings made.

Cancel – Undo the changes made.

Chapter 5 Additional Information

5.1 How to Change the USB/1394 IO Interface Board to eSATA IO Interface Board



NOTE: Prepare the eSATA IO Kit. Disconnect the host, power off the RAID subsystem, and remove the USB or IEEE 1394 cable from the USB or 1394b port.

Contents of the eSATA IO Kit:



One (1) eSATA IO Interface Board

One (1) eSATA cable

Steps:

1. Prepare the screw handle that is shipped with the RAID subsystem.



2. Remove 2 screws from the USB/1394 IO interface board.



3. Insert the screw handle into the middle hole of the USB/1394 IO interface board and tighten the screw handle.



- 4. Carefully pull the screw handle to remove the USB/1394 IO interface board.
- 5. Insert the eSATA IO interface board into the IO interface slot. Take note of the proper position of the IO interface board. If inserted in the wrong position, it will not attach to the IO interface.
- 6. Tighten the two screws that were removed before.



5.2 How to Change the USB/1394 IO Interface Board to USB 3.0 IO Interface Board



NOTE: Prepare the USB3.0 IO Kit. Disconnect the host, power off the RAID subsystem, and remove the USB or IEEE 1394 cable from the USB or 1394b port.

Contents of the USB3.0 IO Kit:



One (1) USB 3.0 IO Interface Board



One (1) USB 3.0 cable

Steps:

1. Prepare the screw handle that is shipped with the RAID subsystem.



2. Remove 2 screws from the USB/1394 IO interface board.



3. Insert the screw handle into the middle hole of the USB/1394 IO interface board and tighten the screw handle.



- 4. Carefully pull the screw handle to remove the USB/1394 IO interface board.
- 5. Insert the USB 3.0 IO interface board into the IO interface slot. Take note of the proper position of the IO interface board. If inserted in the wrong position, it will not attach to the IO interface.
- 6. Tighten the two screws that were removed before.

