

**Operator's Manual** 



# Modem DC 56 K

Copyright © 2003 EVI Audio GmbH

Every copy of this manual as well as the enclosed software is not allowed. All rights at this documentation and at the modems lie with EVI Audio GmbH, Straubing (Germany).

Restriction of warranty

This handbook contains a as concise as possible description of the modem. Whilst every care has been taken in compiling the text, errors can not be completely ruled out. No guarantee can therefore be given for the accuracy of the contents. We accept no legal or other liability for incorrect information given and any consequences thereof. Suggestions for improvements and notification of errors are gladly accepted.

#### Trademarks

The use of a trademark not shown below is not an indication that it is freely available for use.

MNP is a registered trade mark of Microcom Inc.

IBM PC, AT, XT are registered trade marks of International Business Machine Corporation

Windows<sup>™</sup> is a registered trademark of Microsoft Corporation.

Publisher:

EVI Audio GmbH Hirschberger Ring 45 94315 Straubing Germany

Tel.: +49 (9421) 706-0 Fax: +49 (9421) 706-265

website: www.telex.com

1	INTRODUCTION	1
1.1	SCOPE OF DELIVERY	1
1.2	GENERAL	1
2.	TECHNICAL DATA	1
2.1	Mechanical Features	1
2.2	INTERFACES AND DISPLAY ELEMENTS	1
2.3	Serial Interface	2
2.4	Phone Interface	3
2.5	TRANSMISSION STANDARDS / PROTOCOLS	4
2.6	ITU STANDARDS (CCITT)	5
3	START-UP	6
21	INSTALLATION STEDS	6
2.1		7
J.Z		/
4.	FUNCTIONS	8
4.1	Settings	8
4.1.1	Factory settings	8
4.1.2	Storing The Current Configuration Into A User Setting	9
4.1.3	Restoring The Initial Delivery State	9
4.2	Reset	10
4.3	ERROR CORRECTION AND DATA COMPRESSION	10
4.3.1	Error Correction	10
4.3.1.1	V.42 Error Correction	10
4.3.1.2	MNP 2/3/4 Error Correction	10
4.3.2	V 42bis Data Compression	11
4.3.2.2	MNP 5 Data Compression	11
4.4	DIALING DELAY	11
4.5	Flash Update	12
4.6	REMOTE CONFIGURATION	13
4.6.1	Functionality	13
4.6.2	Starting The Remote Configuration	13
4.6.3	Proceeding Of A Remote Process	13
4.6.4	<b>Reduced Command Set During Remote Configuration</b>	13

4.6.5	Terminating The Remote Configuration Process	13
4.7	SECURITY CALLBACK	14
4.7.1	Functionality	14
4.8	PASSWORD FOR CONNECTION SET-UP	15
4.9	SMS FUNCTIONALITY	15
4.10	Serial Data Transmission	16
4.10.1	Automatic Baudrate Detection	16
4.10.2	Data Buffering For Serial Data Transmission	16
4.10.3	Direct Mode	16
4.10.4	Hardware Data Flow Control With RTS/CTS (CT133/C	T106) 17
4.10.5	Software Data Flow Control With The ASCII	Control
4 4 0 7	Characters XON And XOFF (CHR(17) And CHR(19))	18
4.10.6	Data Flow Control Between Wodems	
4.10.7	From Corrected Data Transmission (V.42, MNPA)	10 ms
4 10 8	Interface Lines Influenced BY AT Commands	19
4.10.0		17
5	AT COMMAND SET	20
5.1	OVERVIEW BASIC COMMANDS	20
5.2	DESCRIPTION AT COMMANDS	22
5.2.1	Overview About AT Commands	22
5.3	<b>OVERVIEW FAX- AND VOICE COMMANDS</b>	38
5.4	AT Messages	38
6	S REGISTER	41
6.1	OVERVIEW S REGISTER	41
6.2	DESCRIPTION S REGISTER	43
GLOS	SARY	51
FAQS		53

# 1 Introduction

This manual serves as a basis for operating the modem type DC 56 K from EVI Audio GmbH.

# 1.1 Scope of Delivery

Before installation and operation please check that the box contains all of the following parts:

DC 56K			
1x	Device		
1x	TAE cable		
1x	RS232 cable (9 pin plug / 9 pin jack)		
1x	Power supply 910 V DC		
1x	User's Manual		

If the content is incomplete, please contact your supplier. Please also inspect the modem for transport damage and in the event of damage, consult your supplier.

Please keep packaging for future dispatch or storage.

# 1.2 General

You have some advantages with the analogue desktop devices of EVI Audio and you can not think about the past without this unit. The Modems support the following functions, which are described in detail in the following:

- Password request at connection set-up
- Remote configuration after escape sequence and password entry
- Security Callback to definable phone number
- SMS dispatch via AT command

Both desktop devices described in this manual differ from each other in the following features:

DC 56K			
Dimensions in mm (b x l x h)	71 x 128 x 22		
Status display	2 LEDs		
RS232 interface	SubD9F		
Power supply	910 V DC		
Data rate	up to 56 kbps		
Functions:	-		
Miscellaneous:	-		

# 2. Technical Data

# 2.1 Mechanical Features

DC 56K			
Weight:	150 g		
Dimensions in mm (b x l x h)	71 x 128 x 22		
Temperature range:	0°C 55°C		
Protection class:	Housing IP40 / Terminal IP 20		
Humidity:	0 – 95 % not condensing		

*Note:* The DC 56K may not be used in wet environments.

# 2.2 Interfaces and Display Elements

## 2.2.1 DC 56K



front view

The DC 56K has two LEDs for status display.

These have the following importance:

Importance	Color	Description
Power	green	On, when power supply exists.
Off Hook	red	On, when modem is off hook (this makes line busy!)

# 2.3 Serial Interface

Layout of the 9 pin D-Sub jack

9 pin D-Sub jack

Description of the signals at the 9 pin D-SUB jack of the DCE:

9 pin D-SUB DCE	Description	Function	CCITT	EIA	DIN	E/A DCE
Pin No.			V-24	RS232	66020	to DTE
1	DCD	Data Carrier Detect	109	CF	M5	Ο
2	RXD	Receive Data	104	BB	D2	0
3	TXD	Transmit Data	103	BA	D1	
4	DTR	Data Terminal Ready	108	CD	S1	
5	GND	Ground	102	AB	E2	
6	DSR	Data Set Ready	107	CC	M1	0
7	RTS	Request To Send	105	CA	S2	
8	CTS	Clear To Send	106	СВ	M2	0
9	RI	Ring Indication	125	CE	M3	0

\_\_\_\_\_

Interface speeds of the DC 56K:

Baudrate in bps
300
600
1.200
2.400
4.800
9.600
14.400
19.200
28.800
38.400
57.600
115.200

# 2.4 Phone Interface



# Layout of the Western plug and the RJ 45 jack

Pin	Description
1	NC
2	E
3	LA1
4	LA
5	LB
6	LB1
7	W
8	NC

# 2.5 Transmission Standards / Protocols

DC 56k				
V.21	yes			
V.22A/B	yes			
V.22bis	yes			
V.23	yes			
V.23 half-duplex	no			
V.32bis	yes			
V.34	yes			
V.34+	yes			
V.90	yes			
56k flex	yes			
Bell 212A and 103	yes			
V.29	yes			
V.27ter	yes			
V.21 channel 2	yes			
V.17	yes			
Fax Group 3 send/receive	up to 14.400 bps			
Fax Class 1 command set	yes			
Fax Class 2 command set	yes			
V.42LAP-M error correction	yes			
MNP 2-4 error correction	yes			
MNP 10 error correction	yes			
V.42bis data compression	yes			
MNP 5 data compression	yes			
Voice functions	yes			
ASVD	no			
Remote Control	yes			
Automatic callback	yes			

# 2.6 ITU Standards (CCITT)

Bps represents the number of transmitted bits per second. Duplex is simultaneous transmission in both directions

ITU standard (CCITT)	Importance					
V.21	Transmission with 300 bps duplex.					
V.23	Send with 75 bps and receive with 1.200 bps or reverse.					
V.23	Send and receive with 1.200 bps.					
Half-duplex						
V.22	Transmission with 1.200 bps duplex.					
V.22bis	Transmission with 2.400 bps duplex.					
V.32	Transmission with 9.600 bps or (fallback) 7.200, 4.800 bps.					
V.32bis	Transmission with 14.400 bps or (fallback) 12.000, 9.600, 7.200, 4.800 bps.					
V.FC Transmission with 28.800 bps or (fallback) 26.400, 24.000, 21.600						
	16.800, 14.400 bps.					
V.34	Transmission with 28.800 bps or (fallback) 26.400, 24.000, 21.600, 19.200,					
	16.800, 14.400 bps.					
V.34+	Transmission with 33.600 bps or (fallback) 31.200, 28.800, 26.400, 24.000,					
	21.600, 19.200, 16.800, 14.400 bps.					
K56flex	Transmission with 56.000 bps or (fallback) 54.000, 52.000, 50.000, 48.000,					
	46.000, 44.000, 42.000, 40.000, 38.000, 36.000, 34.000, 32.000 bps.					
V.42	Error protection method for DCEs with asynchronous-synchronous-					
	conversion					
V.42bis	Data compression method					
V.25bis	Alternative command set to AT command set					
V.90	Transmission with 56.000 bps or 54.667, 53.333, 52.000, 50.667, 49.333,					
	48.000, 46.667, 45.333, 42.667, 41.333, 40.000, 38.667, 37.333, 36.000,					
	34.667, 33.333, 32.000, 30.667, 29.333, 28.000 bps.					

(bis = french: second) = extended

# 3 Start-Up

# 3.1 Installation Steps

On the back of the external modems you find three terminals:

- The power supply jack
- The phone line jack
- The 9 pin jack for the connection with the serial interface of your computer.

Please proceed as follows for starting-up the external version:

 Connecting the power supply Connect the delivered power supply plug into the modem and then the mains adapter plug into the wall socket. If you switch on the modem now, the **POW** LED has to be on.

Important Note: Using a different mains adapter may result a damage of the modem; the manufacturer can not take any liability for this.

- Connecting the PC Connect the 9 pin jack at the modem with the serial interface of your computer.
- 3. Now, start the terminal program at your PC and set it to the used COM interface. The modem adapts automatically to the baudrate of your PC.
- 4. Connecting to phone network Now, connect the delivered phone cable to the jack at the back of the modem. The plug of the cable has to snap-in.

Connect the other side of the phone cable into the phone socket. When connecting the modem to older phone sockets, it may be necessary that you have to buy an adapter in a phone accessories store or request the installation of a multiple TAE/N socket from your phone network provider.

5. Test of a successful installation:

The short test takes place via your terminal program (TeraTermPro, ProComPlus). Enter the command  $\mathbf{AT}$  and press "Enter". If the message **ok** appears at your screen then, the device is installed successful.

- 6. Connection test:
  - Set up a connection either to another modem OR like in this example to Freenet
  - Dial with ATD the following number 0101901929 (ATD0101901929)

Attention: For PABXs, which require a "0" for connection set-up, please enter **ATX3DT0,0101901929** 

- OFF Hook LED is on
- Modem dials
- After some time (max. 1 min.) the **CONNECT** message appears
- Freenet tries to establish a contact now
- The connection will be terminated after max. 1 minute
- 7. Driver installation

When using the modem under operating system Windows 95/98, a corresponding standard driver has to be selected. For this refer to the menu entry *Start – Settings – Control Panel* and select *Modem*.

# 3.2 Optimizing the Modem Connection

In most of the cases, you can leave the connection set-up to the automatic functions of the modem.

If you have a look at the settings with the AT command **AT+MS**?, you get e.g. **56**, **1**, **300**, **56**.000, **0**, **0**, **33**.600.

This means that a connection between 300 and 33.600 bps, preferably according to V.90 will be established, depending on the line quality and the abilities of the partner modem.

#### Importance of AT%Q and AT%L

You can request a value for quality with **AT%Q**, and a value for the receive level with **AT%L** for an existing connection.

In case of an existing connection, you have to change the modem to command mode before with +++.

Quality values between 0 and 10 are good. For values above 50, the modem will reduce the data rate (for automatic setting) automatically.

# 4. Functions

# 4.1 Settings

The modem knows three different setting sets:

- Factory setting
- User setting 0
- User setting 1

The user can store configurations in the user settings 0 and 1, which he wants to use for certain purposes in future again.

Each setting stores a part of the S registers. The registers concerned are marked with a \*) in the description of the S registers.

## 4.1.1 Factory Settings

With the factory setting you are able to achieve a defined initial state of the modem. From this "basis", you can adapt the modem according to your requirements. If the modem is completely misadjusted some time, loading the factory settings enables you to restore a ready to run state without any problems. The factory settings of your modem type can be displayed in your terminal program with the AT command AT&F&V. Here is the example of a type 56k:

at&v

ACTIVE PROFILE

B0 E1 L1 M1 N1 Q0 T V1 W0 X3 Y0 &C1 &D2 &G0 &J0 &K3 &Q5 &R1 &S0 &T5 &X0 &Y0 S00:000 S01:000 S02:043 S03:013 S04:010 S05:008 S06:003 S07:060 S08:002 S09:006 S10:020 s11:095 S12:050 S18:000 S25:005 S26:001 S36:007 S37:000 S38:020 S46:138 S48:007 S95:047 STORED PROFILE 0: BO E1 L1 M1 N1 QO T V1 WO X4 YO &C1 &D2 &GO &JO &K3 &Q5 &R1 &S0 &T5 &X0 S00:000 S02:043 S06:003 S07:060 S08:002 S09:006 S10:020 S40:104 S11:095 S12:050 S18:000 S36:007 S37:000 S41:195 S46:138 S95:047 STORED PROFILE 1: B0 E1 L1 M1 N1 Q0 T V1 W0 X4 Y0 &C1 &D2 &G0 &J0 &K3 &Q5 &R1 &S0 &T5 &X0

S00:000	S02:043	S06:003	S07:060	S08:002	S09:006	S10:020
s11:095	S12:050	S18:000	S36:007	S37:000	S40:168	s41:195
S46:138	S95:000					
TELEPHON	E NUMBERS	:				
	0=		1=			
	2=		3=			
The feete	mi a a ttim ara	-f				antikan far

The factory settings of your modem may differ from the shown setting for technical reasons.

#### 4.1.2 Storing the Current Configuration Into A User Setting

If the modem has been adjusted for specific user requirements, it is possible to save this setting in user configuration 0 or 1 by using the commands **AT&WO** or **AT&W1** respectively. These settings are then automatically loaded as the current modem configuration at the next reset. For a user configuration 0 or 1 to be loaded on a hardware reset, depends upon whether a command **AT&Y0** or **AT&Y1** respectively has been previously given.

A software reset **ATZ** or **ATZ0** command results loading the user setting 0, an **ATZ1** command results loading the user setting 1.

#### 4.1.3 Restoring the Initial Delivery State

AT&F Restoring the initial delivery state
 If the modem is to be reset to delivery state, the factory setting
 has to be loaded to the current modem configuration first. This
 takes place with the command AT&F.

 AT&WO Then, the current modem configuration will be transferred to the
 current user setting 0 with the command AT&WO.
 AT&W1 corresponds with user setting 1.

 AT&YO An AT&YO command results finally that the user setting 0 (now
 identically with the factory setting) is loaded to the current
 modem configuration for every following hardware reset.

AT&Y1 corresponds with user setting 1.

**ATZ** A software reset is executed.

# 4.2 Reset

There are two types of resets, hardware reset and software reset:

- A hardware reset takes place when connecting the power supply or performing a warm/cold start at the PC.
- A software reset is performed with the command **ATZ**.

Both possibilities of the reset result that a complete test of the modem hardware is performed (duration approx. three seconds). During this time, some control LEDs light up.

- In case of a hardware reset (switching on, RESET key or start of the PC for plug-in board), a user setting is loaded to the current modem configuration. It depends on an eventually preceding AT&Y command, whether user setting 0 (AT&Y0) or user setting 1 is loaded (AT&Y1).
- In case of a software reset the user setting 0 or 1 is taken over to the current modem configuration. ATZ and ATZ0 result loading the user setting 0, ATZ1 result loading the user setting 1.

# 4.3 Error Correction and Data Compression

The Modems support the V.42 error correction protocol, including Microcom Networking Protocol (MNP) Levels 2/3/4 (MNP2, MNP3, MNP4), and data throughput optimization MNP10.

## 4.3.1 Error Correction

#### 4.3.1.1 V.42 Error Correction

V.42 error correction contains the LAP-M and MNP4 protocols. LAP-M is the preferred error correction. (Link Access Procedure for Modems)

MNP4 is supported for reasons of compatibility with other MNP modems. Both methods lay frames around the actual data to be transmitted and employ CRC (Cyclic Redundancy Check) 16 checksums for error checking.

In V.42 the possibility exists, to make the modem detect, whether the partner is a V.42 modem, an MNP modem, or a modem without error correction. Then, the modem can adapt to the partner independently.

(See chapter 8 "AT command set", command **AT**\**N**.)

#### 4.3.1.2 MNP 2/3/4 Error Correction

MNP error correction can either be operated in block or stream mode. In stream mode the maximum block size can be set to 64, 128, 192 or 256 bytes.

(See chapter 8 "AT command set", command AT\A.)

The MNP error correction can be either used automatically or activated with AT-commands.

(See chapter 8 "AT command set", command **AT**\**N**.)

# 4.3.2 Data Compression

The modem detects automatically, depending on the **AT%C** command, the type of data compression, the remote modem is using, or it can be set to specific type of compression or no compression.

Data compression is only possible for error corrected connections.

The use of data compression assumes that the remote modem supports the same data compression mode.

## 4.3.2.1 V.42bis Data Compression

V.42bis data compression can only operate on a V.42 connection (LAP-M or MNP4). For data compression V.42bis first compiles a so-called dictionary with often-used character sequences. Then subsequently only markers for these sequences are sent to the receiving modem, not the complete character sequences.

Packed data can not be packed again by V.42bis.

## 4.3.2.2 MNP 5 Data Compression

The modem supports Microcom Networking Protocol Level 5 data compression. MNP5 data compression can only be used on an error corrected MNP4 connection. MNP5 replaces often used characters with shorter "tokens".

Packed data can not be packed again by MNP5.

# 4.4 Dialing Delay

Only valid for devices with BZT approval.

According to the regulations of Deutsche Telekom, any further dialing is locked after 12 unsuccessful dialing attempts. The modem has to be switched off for a moment in this case. After a successful dialing attempt, the counter is reset automatically.

If the connection is established, a dialing pause of 5 seconds will be made.

# 4.5 Flash Update

This function enables a software update of the modem without changing the EPROM. You receive the new software from your service partner if necessary.

#### **Requirements:**

A PC and a terminal program are required for the flash loading function. The terminal program must be capable of conducting an ASCII upload (ASCII data transmit protocol). It is necessary to set hard flow control. Also any interpretation of characters by the ASCII upload protocol must be switched off (e.g., interpretation of TAB, CR, BS...).

The baudrate must be set between 9.600 baud and 57.600 baud. Any other baudrates can cause errors or damages. Loading lasts approximately 2-3 minutes with a baudrate of 57.600 baud, longer with lower baudrates.

#### Activation and process:

The flash load function is started with the command AT\*\*.

The modem reports "Download initiated". The ASCII upload of the flash load program HS\_LADER.S37 (is delivered together with the firmware file for the upload) is now conducted. The progression of the transmission is indicated by dots on the monitor screen. When the loading process is complete the message "Download Flashcode" appears. Now a new ASCII upload is initiated with the firmware file (xxxxxxx.S37). From this moment onwards the transmission must not be interrupted because this would mean that flash EPROM has been fully deleted but not completely reloaded. The progression of this upload process is also indicated by dots.

#### Checking the success:

When the process is complete the message "Device successfully programmed" appears. With this the flash upload is finished.

#### AT commands for the flash loading function:

Command	Description
AT**	Starting the flash loading function

#### Note:

When using Telix, set the time delay between signs and lines for the ASCII protocol to  $_{,0^{"}}$ . Furthermore switch off the local echo.

# 4.6 Remote Configuration

# 4.6.1 Functionality

To change into remote configuration mode a data connection must exist between the modems. A specific protocol is not recommended, however it is recommended to use an error corrected connection to avoid transmission errors with the commands.

It isn't necessary that the local modem has a remote configuration function.

Modem 1 ----- Modem 2

(local modem) (remote modem)

# 4.6.2 Starting the Remote Configuration

Remote configuration is started by entering the sequence **\*\*\*\*** (four asterisks), with at least 1 second break in the data stream in front of and after the **\*\*\*\*** sequence. The remote initial character can be changed with **\$17**.

# 4.6.3 Proceeding of a Remote Process

If the remote modem is opened for remote configuration (AT\*R1), it reports with the request for the password. (Default is QWERTY). If the entered password and the password stored in the remote modem with the command AT\*C are equal, the remote modem sends the prompt ">''. Now commands can be sent to the remote modem in the same way as it is a local modem.

## 4.6.4 Reduced Command Set during Remote Configuration

Some commands can not be executed during remote configuration and lead to a return message ERROR (ATA, ATD, ATO, AT/B, AT\*C, AT&F).

If the entered password is wrong, the modems went back to the data transmission mode.

## 4.6.5 Terminating the Remote Configuration Process

The commands AT\*E, AT\*X or ATZ can be used to terminate the remote configuration. The 3 commands have the same function. With ATZ, the remote modem executes a software reset and interrupts the connection with this. All entered commands, which have not been saved with AT&W before, are deleted and the modem loads the user configuration 1.

#### For the new devices:

The remote configuration can be finished with the commands  $\mathbf{AT*E}$  und  $\mathbf{AT*X}$ , so the modem goes back to data transmission mode.  $\mathbf{ATZ}$  starts a software reset.

# 4.7 Security Callback

The feature security callback is used for a callback of the called modem to a predefined number.

This function is executed after entering a password and is a safe protection for unauthorized access.

# 4.7.1 Functionality

## Activation:

Save the callback number in the register of phone numbers of the remote modem (place 1, with the standard AT command **AT&Z1**).

## Incoming call:

When the modem answers an incoming call (ATSO <> 0 is set, or acceptance with ATA), approximately 2 seconds after the message "CONNECT", you will see the message "SECURITY CALLBACK" und "REMOTE PASSWORD:". Now the Remote Password must be entered (the security callback password is identical with the remote access password, that means it is entered with the command AT\*C).

## Wrong password entry:

The modem immediately disconnects the connection and stops a forbidden access to the attached device.

## Correct password entry:

The modem reports **"OK"** to the calling terminal, disconnects the connection and dials the phone number stored with the command **AT&Z1** after approx. 10 seconds. 3 call attempts are executed at all, each with 10 seconds break between this.

## Data connection:

If the connect takes place, approx. 2 seconds after the Connect the callback modem reports "CALLBACK IN PROGRESS" and the serial interface is opened. Now a normal data connection exists.

## Outgoing data connections:

Security-callback-modem initiated connections with **ATD** are not influenced by the security callback function.

## Deactivation:

Deactivation of the callback function is made by deleting the return phone number with the command "AT&Z1=".

AT commands for the security callback:

Command	Description	
AT*C	Set the password in the callback modem	
AT&Z1=xxx	Enter the callback no. in the callback modem (xxx stands for the phone no.)	

# 4.8 Password for Connection Set-Up

If the password request is switched on with **AT\*P1**, the password request takes place after the **CONNECT** message. After entering the password correctly, the actual connection is established and data can be transferred.

If an incorrect password has been entered, the modem hangs up. The password is the same as for remote control and set with **AT\*C**.

# 4.9 SMS Functionality

#### Short description:

The modem can not only send the alarm message to another analogue modem, but also as SMS to a mobile phone. At the moment only D1, D2, and E network phones are supported.

## Proceeding of the SMS dispatch:

The text is entered with the command  $\mathbf{AT*V}$  the usual way. The maximum length of the alarm text is 160 characters.

To send the message to a mobile phone the following settings must be made, depending on your provider:

D1 network: AT\*M1 AT&Z0=01712521002 AT&Z2=number of the mobile phone in the format 49171xxxxx

D2 network: AT\*M4 AT&Z0=01722278000 AT&Z2= number of the mobile phone in the format 0172xxxx

E network: AT\*M1 AT&Z0=01771167 AT&Z2= number of the mobile phone in the format 49177xxxx

Command	Description	
AT&ZO	Sets the service center number of the mobile phone provider. The numbers given	
	here assume that no outside line has to be accessed.	
	When using a PABX, the number must be completed with the according access	
	sequence.	
AT&Z2	Defines the number of the mobile phone to which the SMS will be sent. The	
	different network providers support, like shown above, different formats for	
	transmitting the phone number.	
AT*Mn	Defines the protocol for sending the alarm string to the network provider.	
AT*M0	Sets a standard analogue modem as remote terminal (alarm function so far).	

#### AT commands for the SMS dispatch:

AT*M1	Sets D1 or E network as remote terminal.	
AT*M4	Sets D2 network as remote terminal.	
AT*V	Enters the alarm text (max. 160 characters).	
AT%A	Triggers the alarm function, text message or SMS.	
S13	Sets the number of dialing attempts in case of alarm.	

# 4.10 Serial Data Transmission

# 4.10.1 Automatic Baudrate Detection

The modem detects the baudrate of the connected PC from the AT characters preceding every command. This is also known as DTE or interface speed, that is the speed between the modem and the computer. The modem can communicate with the baudrates (according to type) 300, 600, 1.200, 2.400, 4.800, 9.600, 19.200, 38.400, 57.600, 115.200 and 230.400 bps with the PC.

The adaptation to the transmission speed of the phone line takes place automatically as well, if not set differently. (See chapter 8 "AT command set").

Here both modems try to achieve the highest speed at the phone line *together* at connection set-up.

 Possible speeds at the phone line data transmission (up to four times as much by data compression!):

DC 56k 300 to 56.000

Possible speeds at the phone line for fax transmission: 2.300, 2.400, 4.800, 7.200, 9.600 and 14.400 bps. The baudrate to the PC is for fax transmissions always 19.200 bps.

## 4.10.2 Data Buffering for Serial Data Transmission

The modem provides fast send and receive intermediate memory (so-called buffers), in order to match the modem to the PC's processing speed. It is possible to deactivate this data buffering with the **AT\N1** command and revert to direct mode.

When working with buffers, handshaking has to be used, because otherwise a overflow of the modem buffer may occur which leads to data transmission failures.

## 4.10.3 Direct Mode

In this mode, eleven bits are sent. They consist of eight data bits, a parity bit, a start bit and a stop bit. Direct mode is activated by the command **AT\N1**. The modem has no influence in direct mode on the transmission format. Data is transferred without buffering.

Data compression or error correction does not function in direct mode. Only the disconnect sequence is recognized by the modem (+++ preset).

## 4.10.4 Hardware Data Flow Control with RTS/CTS (CT133/CT106)

Hardware data flow control via the mode (CTS)



If the input buffer of the modem exceeds a certain XOFF fill state, the modem sets the CTS line to OFF. This indicates the PC that he shall send no data anymore.

# Note:The CTS line is only served by the modem when the commandsAT&K or AT&R are executed accordingly.

After the modem has worked off the input buffer so far that it falls below a certain buffer XON fill state, it sets the CTS line back to ON and indicates the PC that is ready to receive data again.

## Hardware data flow control via the PC (RTS)



The PC sets the RTS line to OFF to request the modem to interrupt the data transmission.

- **Note:** It depends on the respective software of the PC, whether the RTS/CTS lines are served from the PC.
  - The PC sets the RTS line to ON to request data from the modem.
  - In depends on the setting of the modem with the commands AT&K or AT&R, whether the RTS/CTS lines are served from the modem.

## 4.10.5 Software Data Flow Control With The ASCII Control Characters XON And XOFF (CHR(17) And CHR(19))

	Send Data	
Modem	XON or XOFF character	PC

When the input buffer of the modem has exceeded a predetermined XOFF fill level, the modem inserts an XOFF character into the data stream to the connected device. This character causes the connected device to stop sending data.

**Note:** Support of XON/XOFF flow control by the modem depends on the setting of the command AT&K.

Support of XON/XOFF flow control by the PC depends on the software currently running on the PC.

Once the modem has processed the contents of the buffer such, that it falls below a predetermined XON fill level, the modem includes the XON character in the data stream. This character causes the connected device to start sending data again to the modem. In a similar manner, the connected device can control the data flow from the modem to the connected device.

The XON/XOFF process is only possible if the XON or XOFF characters are not present in the transmitted data, as a rule only for ASCII texts. When transmitting programs, e.g. using XMODEM transmission protocol, any XON or XOFF characters appearing randomly, would interrupt operation.

## 4.10.6 Data Flow Control between Modems

Software data flow control between two modems for non-error corrected data transmission (without V.42 or MNP4).



For non-error corrected data transmission (V.42 and MNP4 inactive), one modem can interrupt the other by inserting a XOFF character into the data stream when the XON/XOFF protocol is activated by the command **AT\G1**.

New data can be requested by inserting a XON character into the data stream.

The XON/XOFF characters are inserted depending on the fill state of the modem buffer.

Normally, the XON/XOFF characters received from the other modem are evaluated by the modem and not forwarded to the PC. However, there is the possibility to evaluate XON/XOFF characters received from the other modem and to forward them transparently to the PC. (For this see chapter 8 "AT command set, command AT&K). Errors may occur when data contains the characters for XON and/or XOFF accidentally. This is only impossible when pure text files are transferred.

## 4.10.7 Software Data Flow Control Between Two Modems With Error Corrected Data Transmission (V.42, MNP4)

Error corrected data transmissions (V.42 or MNP 4) have their own method of data flow control.

A possibly activated XON/XOFF data flow control between two modems (AT\G1) is ignored.

## 4.10.8 Interface Lines Influenced BY AT Commands

RS232 line	AT command
DCD	AT&C
DTR	AT&D
RTS/CTS	AT&R, AT&K
DSR	AT&S

# 5 AT Command Set

Not all AT commands are available for the different modems (see table "Technical Data" or enclosed short description)

# 5.1 Overview Basic Commands

Command	Description	
AT**	Start the flash loading function	
ATA	Answer mode	
Α/	Repeat last command	
AT\A	Select maximum MNP block size	
AT%A	Alarm triggering	
ATB	CCITT or Bell	
AT\B	Send "break" to other modem	
AT%C	Enable data compression	
AT*C	Remote configuration password	
AT&C	DCD (CT109) behavior	
ATD	Dialing	
AT&D	DTR (CT108/2) behavior	
ATE	Command input echo	
AT%E	Automatic retrain	
AT*E	End the remote configuration	
AT&F	Load factory settings	
AT\G	Data flow control between modems (XON/XOFF)(not for	
	56k versions)	
ATH	Terminate connection	
AT*H	Negotiate speed of set-up protocol (MNP 10)	
ATI	Identification	
AT&K	Select data flow control between PC and Modem	
AT\K	Break control	
AT-K	Extended MNP functions (MNP 10)	
ATL	Speaker volume	
AT%L	Display level of received signal	
AT\L	Select block or stream mode for MNP connection (not for	
	56k versions)	
ATM	Speaker control	
AT+MS	Select modulation type	
AT*M	Select remote terminal	
AT\N	Select error correction	
ATO	Return to online data mode	
AT*P	Password request	
ATQ	Quiet control	
AT-Q	Fallback to V.22bis and V.22	

AT%Q	Display quality of phone connection
AT&R	RTS/CTS behavior
AT*R	Switch remote control on/off
ATS	Write/read S register
AT&S	DSR behavior
ATT	Switch on tone dialing
AT*U	Select protocol of serial interface
ATV	Form of modem messages
AT\V	Form of connect messages
AT&V	Display configuration
AT*V	Define alarm text
AT*V?	Request alarm text
ATW	Messages for error correction
AT&W	Store configuration
ATX	Extended result messages, dial tone detection
AT*X	End remote configuration
ATY	Long break
AT&Y	Select user configuration at hardware reset
ATZ	Software reset / load setting
AT&Z	Store phone numbers

# 5.2 Description AT Commands

When the modem receives an AT command, it adapts automatically to the baudrate, the number of data bits, and the byte length of the data from the PC.

Every AT command starts with the characters **AT** and ends with a carriage return character (CR). Capitalization is ignored, but the leading characters have to be either **AT** or **at**. The command line is evaluated as soon as the modem has received the carriage return character. A parameter given in parentheses (**n**) means in the description that this is optional. For example **ATL(n)**, where **n** can take on the values 0 to 3, e.g. **ATL2** (medium volume). For commands, which expect a parameter, but are entered without parameter, the modem assumes the value 0 automatically. The command **ATZ** for example causes the same effect like the command **ATZ0**.

## 5.2.1 Overview About AT Commands

Command	Description		
AT**	Starting the flash-loading-function		
ΑΤΑ	<u>Answer mode</u> The modem is set into answer mode (manual answer). In certain countries such as Germany this is only effective, when the parallel connected telephone is picked-up, or a call comes in.		
A/	Repeat last command The last command entered is repeated.		
AT\A	Select maximum Determine the m AT\A0 AT\A1 AT\A2 AT\A3	<u>MNP block size</u> aximum block size for an error corrected MNP transmission. 64 characters 128 characters 192 characters 256 characters	
AT%A	<u>Alarm triggering</u> Triggers an alarm message (SMS dispatch).		
АТВ	CCITT or Bell ATB0 ATB1	Select CCITT modulation Select Bell modulation	

Command	Description			
AT\B	Send break to th	e remote modem		
	On a link without error correction (reliable link), the modem sends a break signal			
	to the remote r	to the remote modem. The signal length is: the parameter given times 1/10		
	seconds.			
	On a link with e	error correction the modem sends a signal according to the		
	active error corre	ection protocol, without consideration of any parameter given.		
	If no link is opera	tional, or a fax link is active, an error message is given.		
	AT\B1	1/10 second break signal, up to		
	AT\B9	9/10 second break signal.		
ΑΙ%	Enable data compression			
	Enable or disable a certain type of data compression			
	The modem can	only carry out data compression on an error corrected link.		
	AT%C0	No data compression enabled		
	AT%C1	Enable MNP5 data compression		
	AT%C2	Enable V.42bis data compression		
	AT%C3	Enable MNP5 and V.42bis data compression		
AT*C	Remote Control	Password		
	With this comm	and you can save a password for remote control into the		
	modem. After the <b>AT*C</b> command you are asked for the old password: <b>OLD</b>			
	<b>PASSWORD</b> (default is QWERTY or BEISPIEL). An incorrect input leads to <b>ERROR</b> .			
	If the input was right, you can enter the new password. It must be between 6			
	and 12 charact	ers in length. Then the modem asks you to confirm the new		
	password: CONFI	RM		
AT&C	DCD (CT109) opt	tions		
	Behavior of RS23	2 DCD output of the modem		
	AT&C0	DCD is always on		
	AT&C1	DCD follows the telephone line carrier signal		

Command	Description		
ATD	Dial (dialing string)		
	The modem lifts up and dials in accordance with the dialing string given by the		
	ATD command. After dialing the modem attempts to establish a connection. If		
	the <b>ATD</b> comma	nd is sent without a dialing string, then the modem opens the	
	line and attemp	ts to make a connection with the remote modem (without	
	dialing). The bet	navior of the modem is dependent upon whether or not line	
	current detection	n is activated (see <b>ATX</b> command).	
	Operation of the	<b>ATD</b> command is also dependant upon when the last dialing	
	attempt was ma	de (see chapter "Dial delay).	
	In FCLASS=0 mo	de the modem acts as a data modem. It attempts to make	
	contact with an	other data modem. The attempt is continually repeated until	
	the waiting time	limit set in the S7 register has expired.	
	Should this time I	imit be exceeded then the modem hangs up and displays the	
	error message: <b>N</b>	CARRIER.	
	In FCLASS=1 or F	CLASS=2 the modem acts as a fax modem. It will attempt to	
	make a connec	ction to another fax modem or fax machine. (The modem	
	adopts HDLC V.21 Channel 2 receive status, acting as though the AT+FRH		
	command had been executed).		
	The following cha	aracters may be sent as parameters (parentheses, space, and	
	dashes are ignor	ed):	
	0 to 9	Digits 0 to 9 inclusive	
	*	*: only with tone dialing	
	#	# : only with tone dialing	
	A - D	Tone dial characters A, B, C, D	
	Р	Specify pulse dialing: tone or pulse dialing may be necessary	
		depending upon location.	
	Т	Specify tone dialing: tone or pulse dialing may be necessary	
		depending upon location.	
	W	Await Dial tone: The modem waits for the dial tone before	
		commencing dialing. If no dial tone is received within the time	
		limit set in the S6 register, the modem hangs up and no error	
		message is displayed.	
	@	Await silence: the modem waits for at least 5 seconds silence	
		on the line before executing the next character in the	
		parameter string. If this 5 second silence is not detected and	
		the break-off time specified in the S7 register is not exceeded,	
		the modem ends the call with the message: NO ANSWER.	
		If the engaged tone detection is activated the modem ends	
		the call with the message : <b>BUSY</b> .	
		If a reply tone is received from the remote modem during the	
		waiting period, a connection is made.	
	,	biaing pause: the modern inserts a pause before it executes	
		the next character in a dialing string. The pause length is set in	
		the so register.	
	L	Redial the last number dialed.	

Return to input mode after dialing. This is placed at the end of
a dialing string, and causes the modem to be returned to
input mode when the ; is reached (with response: $o\kappa$ ). This
allows AT commands to be entered, even with the handset
off-hook. Any additional AT commands can be included in the
same line as the ; character or sent as additional input lines.
The connection can be broken with the ATH command and
the <i>handset</i> can be replaced.
Dial the n <sup>th</sup> number from the number memory that was
entered with the AT&Z command.
Flash. If the flash character is in a dialing string the modem
hangs up after the time specified in the S29 register, and then
goes off hook again.
If the > character is in a dialing string, the modem acts as
though the earth key was pressed, thereby putting one of the
two phone lines to <i>earth</i> . Some telephone systems require this
to access an exchange line.
Suppresses the transmission of a calling tone.
Default is: Call tone sent on fax operation, no call tone for
data operation.
Ignored, these are only used to assist clarity
Ignored, these are only used to assist clarity
Spaces are ignored, they are only used to assist clarity.
Dial the telephone number 12345
Dial with pulse dialing the number 12345
Dial with tone dialing the number 12345
With the semicolon, the modem gets back to the command
mode after dialing
5
for private branch exchanges, which get the local loop with a
0 or a 9: First blind dialing must be activated with "x3" (look
also <b>"ATX3</b> command"), to dial the leading 0, without hearing
a dial tone. After the dialing of the 0 with "D0", the dial tone
detection can be reactivated with the parameter "w". Though
the modem waits for the dial tone AND finalizes the dialing
(with "12345") only, if the dial tone was heard. The waiting for
the dial tone can be dropped with the command
ATX3D012345.
For private branch exchanges, which get the local loop by
irst blind dialing must be activated with "x3" (look also "ATX3
obey the earth function without hearing the dial tone. After the
arth by >, the dial tone detection can be reactivated with the
Though the modem waits for the dial tone AND finalizes the
345") only, if the dial tone was heard. The waiting for the dial
pped with the command ATX3D12345.

Command	Description			
AT&D	DTR (CT108/2) operation			
	DTR (CT108/2)	operation - monitoring of On/Off state changes of RS232		
	connections on the PC.			
	AT&D0	DTR is ignored, permits operation with PC's that do not support		
		DTR.		
	AT&D1	A DTR On/Off change causes the modem to act as though it		
		had received a +++ break sequence. The modem goes into		
		input mode without hanging up.		
	AT&D2	A DTR On/Off change causes the modem to hang up.		
		Automatic pick-up is not possible.		
	AT&D3 A DTR On/Off change causes the modem to exec			
	as if an AT&Y command had been given. A prece			
	command decides whether one of the two configur			
		or 2, should be loaded.		
ATE	Echo command input			
	This command	switches on or off the repeat display of commands that the		
	modem carries out in response to commands generated by the PC.ATE0Echo off			
	ATE1	Echo on		
AT%E	The modem exe	ecutes the retrain process when a transmission problem occurs.		
	After three unsue	ccessful retrain attempts, the modem hangs up.		
	AT%E0	Retrain disabled		
	AT%E1	Retrain enabled		
	AT%E2	Fall-back, fall-forward enabled		
	AT%E3	Fast fall-back, fall-forward. Not supported by all modem		
		models.		
AT*E	End remote con	trol		
	The command A	T*E command finishes the remote control		

Command	Description			
AT*Fn	Select the transm	ission speed at the serial interface.		
	The speed can be preselected with this command. But this does not switch off			
	the automatic detection. As soon as an AT is detected, the serial interface			
	changes to the detected speed and protocol.			
	If no <b>AT</b> is sent, the selected speed is kept until a hardware reset. If the selected			
	speed is to be ke	pt beyond this, it has to be stored with AT&W.		
	Attention:	The register S23 is not changed with this command! It only		
		changes with automatic speed detection.		
	AT*F0	keep current speed.		
	AT*F1	300 bps		
	AT*F2	600 bps		
	AT*F3	1.200 bps		
	AT*F4	2.400 bps		
	AT*F5	4.800 bps		
	AT*F6	9.600 bps		
	AT*F7	19.200 bps		
	AT*F8	38.400 bps		
	AT*F9	57.600 bps		
	AT*F10	115.200 bps		
ΔΤ&.Ε	Load factory cor	figuration		
	The modem loads the factory configuration from the internal non-volatile			
	memory. This allows the modem to be put into defined basic state. A portion of			
	the S register can also be stored using the <b>AT&amp;F</b> command.			
	(Our model range is fitted with two different factory configurations, AT&F0 and			
	AT&F1).			
	,			
AT\G	Data flow contro	between modems (XON/XOFF)		
	Disables or enabl	es flow control on non-error-corrected links (reliable links).		
	Flow control is selected by the ASCII characters XON and XOFF. The modem			
	interrupts the data transmission upon receipt of an XOFF character, and re-starts			
	the transmission on receipt of an XON character. Error corrected transmissions			
	employ their own form of flow control.			
	On error corrected links, therefore, any previously entered flow controls are			
	ignored. The XC	N/XOFF flow control should be disabled for BTX operations		
	mode.			
	AT\G0	Modem/modem flow control disabled		
	AT\G1	Modem/modem flow control enabled via XON/XOFF		
ATH	Disconnect			
	The modem hand	gs up.		
		· ·		

Command	Description		
AT*H	Synchronize speed of connection set-up protocol		
	AT*H	specifies the speed at which synchronization is handled when	
		setting up an MNP10 link, before the modem goes into MNP10	
		mode.	
	AT*HO	Set-up takes place at highest possible speed	
	AT*H1	Set-up at 1.200 bps	
	AT*H2	Set-up at 4.800 bps	
ATI	Identification		
	The modem send	ds an identifier to the PC in accordance with the parameter.	
	ATI0	Product code	
	ATI1	Previously calculated checksum of the EPROM	
	ATI2	Calculation of EPROM's checksum and comparison with the	
		previously calculated checksum stored in the EPROM. Output	
		of <b>ok</b> if comparison correct.	
	ATI3	EPROM firmware version number	
	ATI4	Modem version number	
	ATI5	Country code parameter (Germany = 006 / Europe = 253)	
	ATI6	Data pump version number and revision.	
AT&K	Select flow contr	ol between modem and PC	
	Default for fax operation is RTS/CTS		
	T-Online requires	AT&KO.	
	AT&KO	No flow control	
	AT&K3	Select flow control RTS/CTS	
	AT&K4	Select flow control XON/XOFF	
	AT&K5	Select transparent flow control XON/XOFF	
	AT&K6	Select RTS/CTS and XON/XOFF flow control	

Command	Description						
AT\K	Break control						
	The modem reacts to a break command from a remote modem or from the PC,						
	or to an <b>AT\B</b> command in accordance with the parameter n. <b>1st Situation:</b>						
	In the case of a	break originating from the PC during a data connection to a					
	remote modem:						
	AT\K0	Modem goes into command mode, does not send a break					
		signal to the remote modem.					
	AT\K1	Modem clears the data buffer, sends					
		break signal to the other modem.					
	AT\K2	As at\k1					
	AT\K3	Send back to remote modem immediately					
	AT\K4	As at \KO					
	AT\K5	The modem places a break signal in the					
		data transmitted to the remote modem.					
	2nd Situation:						
	The modem is p	ut into command mode during a data connection with the					
	escape sequend	ce +++. In this condition an $AT \ B$ command leads to the					
	transmission of a	break signal to the remote modem. The parameter n has the					
	following effect in	n this situation:					
	AT\KO	Modem clears the data buffer, sends break signal to the other					
		modem.					
	AT\K1	As AT\KO					
	AT\K2	Modem sends break signal immediately to					
		the remote modem.					
	AT\K3						
	AT\K4	The modem places a break signal in the					
		data transmitted to the remote modem.					
	AT\K5	As AT\K4. Return from Online command					
		mode is achieved with an <b>ATO</b> command.					
	3rd Situation:						
	in the case of the	e reception of a break signal from the remote modem during a					
	non-error-correct	ed link, the parameter has the following effect:					
	AT\K0	Ine modem clears the putter, send a					
	AT\K1	As AT\KO					
	AT\K2	The modern sends a break to the PC					
	AT\K3						
	AT\K4	sends a break to the PC embedded in the					
		data received from the remote modem.					
	AT\K5	As AT \K4 (default).					

Command	Description	Description		
AT-K	Extended MNP f	Functions (MNP10)		
	This command	determines whether a V.42 LAP-M link can be changed to an		
	MNP10 link.	MNP10 link.		
	AT-KO	Prevents V.42 LAP-M to MNP10 change.		
	AT-K1	Allows V.42 LAP-M to MNP10 change.		
ATL	<u>Speaker volume</u>			
	This command c	controls the speaker volume (see <b>ATM</b> ).		
	ATL1	speaker low volume		
	ATL2	speaker medium volume		
	ATL3	speaker high volume		
	Note:	The speaker output is optional and not supported in the		
		standard version.		
AT%L	Display level of received signal			
	The value indicated by the modem is the amplified signal in the modem, not the			
	level on the phone line.			
	Large AT%L values indicate a low signal level; small values a large signal level.			
	(009 = -9 dB, 043 = -43 dB.)			
ATM	Speaker control			
	This command controls the activity of the speaker			
	(see command	ATL).		
	ATM0	speaker always OFF		
	ATM1	speaker ON when dialing and connection set-up		
	ATM2	speaker always ON		
	ATM3	speaker ON at connection set-up		
	Note:	The speaker output is optional and not supported in the standard version.		

Command	Description			
AT+MS	Select modulation type			
	The modulation type is set with the <b>AT+MS</b> command. The command enables or disables automatic modulation detection and sets the highest and lowest possible connection speed. The command is in the form <b>AT+MS=MODULATION</b> ,			
	[Automode],	[Receive: Min	baud, Maxbaud]; [μ-Law, A-Law],	
	[reserved], [Send Speed: Maxbaud]			
	AT+MS? displays the current setting.			
	AT+MS=? displays a list of possible parameters.			
	Modulation parameter:			
	The modulation parameter sets the preferred (automode = 1) or the specified			
	(Automode = 0) modulation type.			
	The following values are available:			
	0	V.21 300		
	1	V.22	1.200	

	2	V.22bis	2.400 or 1.200
	3	V.23	1.200
	9	V.32	9.600 or 4.800
	10	V.32bis	14.400, 12.000, 9.600, 7.200 or 4.800
	11	V.34	33.600, 31.200, 28.800, 26.400, 24.000, 21.600,
			19.200, 16.800, 14.400, 12.000, 9.600, 7.200,
			4.800 or 2.400
	12	V.90	56000, 54667, 53333, 52000, 50667, 49333, 48000,
			46667, 48000, 46667, 45333, 42667, 41333, 40000,
			38667, 37333, 36000, 34667, 33333, 32000, 30667,
			29333, 28000
	56	K56flex	56000 54667 53333 52000 50667 49333 48000
		Roonox	46667 48000 46667 45333 42667 41333 40000
			38667 37333 36000 34667 33333 32000
	64	Bell 103	300
	69	Bell 212	1 200
	Automode n	arameter:	1.200
	With the opt	ional automode	parameter it is possible to determine if the modern
	can automa	tically adapt to t	the required modulation type
	The following	values are acce	epted:
	0	Automatic	adaptation to modulation disabled.
	1	Automatic	adaptation to modulation enabled.
	Receive Min	baud parameter	:
	The optional	minbaud parar	meter sets the lowest possible baud rate at which
	the modem	receives.	'
	Receive Max	baud paramete	r:
	The optional	maxbaud para	meter sets the highest possible baud rate at which
	the modem	receives.	0
	Parameter m	Law, A-Law	
	Selection of	the ISDN-coding	
	Reserved pa	rameter	
	= always 0		
	Send Speed	Maxbaud param	neter
	The optional	maxbaud para	meter sets the highest possible baud rate at which
	the modem	sends data.	
	Example:		
	AT+MS=12,1	,300,56000,0,0	0,33600 (automatic adaptation to remote
	terminal, mir	nimum speed of	300 bps. The maximum receive speed is 56.000bps
	and the may	imum send spee	ed is 33.600bps).
AT*M	Selection of	<u>the remote termi</u>	nal
	Determines t	he protocol with	which the alarm string is to be sent to the network
	provider.		
	AT*M0	remote terr	ninal normal line-modem
	AT*M1	remote terr	ninal D1 Net or E-Net
	AT*M4	remote terr	ninal D2 Net
AT\N	Select error of	correction	

	This command determines which type of error correction is the preferred choice				
	to be employed for future connections.				
	AT\N0	Disable error correction.			
	AT\N1	direct mode (only for special data formats)			
	AT\N2	Selects V.42 LAPM or MNP4 error correction. If an error			
		corrected link can not be made, it causes a hang-up.			
	AT\N3	Selects V.42 LAPM or MNP4 error correction. If such a link is not			
		possible, a reliable link is attempted .			
	AT\N4	Exclusively selects V.42 LAPM link.			
	AT\N5	Exclusively selects MNP4 link.			
ATO	Return to on-line	data mode.			
	ATO0	If the modem is in online command mode it returns to online			
		data mode. If the modem is in online data mode it sends an			
		ERROR message.			
	ATO1	Causes retrain process, before the modem goes into online			
		data mode.			

Command	Description			
AT*P	Password request			
	AT*P0	turns off the password request after the dial-up		
	AT*P1	turns on the password request after the dial-up		
	If the password r	equest is turned on, the modem asks for it after the <b>CONNECT</b> .		
	After the right inp	out of the password, the intrinsic connection is established and		
	data can be trar	nsmitted.		
	If the password was wrong, the modem hangs up. It's the same password as the			
	one of the remote control and can be set with <b>AT*C</b> .			
	(S register 14, Bit 6	6)		
ATO	Quiet control			
	This command sy	witches on or off the sending of messages from the modem to		
	the PC.			
	ATQ0	Send messages to the PC		
	ATQ1	Send no messages to the PC.		
AT-Q	Fall-back to V.22	bis and V.22		
	AT-Q0	prevents fall-back to V.22bis and V.22		
	AT-Q1	enables fall-back to V.22bis or V.22 respectively.		
ΑΙ%Ο	Display phone co	onnection quality		
	A modem messa	ae with a value between 000 and 007 denotes a good quality		
	telephone connection. The lower the value, the better the quality.			
	High values indic	ate poor quality. These values are constantly updated during a		
	call. If the value increases much during a call i.e. the quality has deteriorated,			
	an <b>Autoretrain</b> is	executed, providing a preceding <b>AT%E</b> command has enabled		
	this facility.			
AT&P	PTS/CTS options			
Allan	This command d	etermines how the modem responds to RIS/CIS (CI105/CI106)		
	flow control connections.			
	(see also the AT&	<b>x</b> command).		
	AT&R0	CTS reaction as V.25bis		
	AT&R1	RTS signals are ignored. CTS only goes to off if required by flow		
		control.		
AT*R	Turn on/off remot	te control		
	AT*R0	Turns off remote control		
	AT*R1	Turns on remote control		

Command	Description		
ATS	Write to/read from S register Some S registers can only be changed within certain limits. The modem still give		
	an <b>oĸ</b> , even if th	e value has not been altered as shown. Some registers can only	
	be read. It is, th	herefore, recommended to check the results of a write to the	
	register with the	ATSn? command.	
	ATSn=x	Sets the S register n to the value x.	
	ATSn?	Shows the value of the S register n.	
AT&S	DSR options		
	This command determines how the modem responds to its DSR (CT10		
	&S0	DSR always on	
	&S1	DSR <i>on</i> , once a reply tone is detected,	
		DSR off once carrier is no longer detected.	
ATT	Enable tone dial	ing	
	Once this command has been executed, all subsequent calls will be dialed		
	using tone dialin	g, until either an ATP or ATDP command is executed to revert to	
	pulse dialing.		

Command	Description			
AT*Un	Select the protoc	col at the serial int	terface	
	You can pre select the protocol with this command. But the auto detection will			
	not be turned off. If an AT command is detected, the serial interface triggers			
	automatically th	e detected speed	d and detected p	rotocol.
	If no AT comma	nd is sent, the sel	lected protocol re	ests until a hardware reset. If
	you wanted to st	tore the used prot	tocol, you have to	save it with <b>AT&amp;W</b> .
	Important: The S-register S23 will not be changed with this comma			
	will only be changed with the auto speed-			auto speed- and protocol-
		detection.		
	AT*U0	8 data bits,	no parity,	1 stop bit
	AT*U1	7 data bits,	parity ODD,	1 stop bit
	AT*U2	7 data bits,	parity EVEN,	1 stop bit
	AT*U3	7 data bits,	no parity,	1 stop bit
	AT*U4	7 data bits,	parity ODD,	2 stop bits
	AT*U5	7 data bits,	parity EVEN,	2 stop bits
	AT*U6	7 data bits,	no parity,	2 stop bits
	AT*U7	8 data bits,	parity ODD,	1 stop bit
	AT*U8	8 data bits,	parity EVEN,	1 stop bit
	AT*U9	8 data bits,	no parity,	2 stop bit
ATV	Style of modem	message		
	This command o	determines wheth	ner the modem se	ends messages to the PC in
	long form or shor	t form.		
	ATV0	Messages to the	PC in short form, i	.e. only the error number.
	ATV1	Messages to the	PC in long form, i	.e. the error text.
ΔΤ\ \/	Form of the conr			
	This command e	<u>heet messages</u> anables the displa	av of the connect	message in one (\v1) or in
	three (\ <b>v</b> 0) lines			
AT&V	Display configurations			
	This command	activates the dis	splay of current	active configuration of the
	modem, the stor	ed user configura	tions, and stored t	telephone numbers 0 to 3.
AT*V	Defines the alarr	<u>n text</u>		
	After you call this command, the modem asks for the alarm text. In the remote			
	mode you can n	ot use this comm	and.	
AI*V?	Requests the ala	<u>rm text</u>		
	With this command you can check the alarm text			

Command	Description				
ATW	Error correction messages				
	This command defines which specification of data transmission rates are made				
	for a <b>connect</b> message				
	ATW0	The modem sends the baudrate between the modem and the PC			
	ATW1	The modem sends the speed of the telephone cable, the			
		mistake protection protocol and the PC-baudrate.			
	ATW2	The modem sends the speed of the telephone cable.			
AT&W	Store configurations				
	This command saves the actual configuration of the modem including				
	registers in one o	f the both user-defined defaults.			
	AT&WO	Saving in user default 0			
	AT&W1	Saving in user default 1			
ΔΤΧ	Extended result re	eporting dial tone detection			
,,	This command d	etermines which group of messages are sent to the PC by the			
	modem. This is in	portant on PBX's, as a leading 0 or 9 must be dialed before a			
	dial tone is heard	dial tone is heard on the line. <i>Blind dialing</i> (dialing without having a dial tone) is			
	activated or deactivated depending on parameter. Dial tone detended however, can always be forced with the W parameter in an <b>ATD</b> dial string <b>ATD</b> command). In <b>AT+FCLASS=1,2</b> mode, the modem always sended				
	CONNECT message	CONNECT message to the PC on call set-up without giving the transmissio			
	speed. The table	in chapter eleven shows the messages with reference to the			
	ATX parameter.				
	ATX0	No dial tone detection, this means that an unsuccessful dial			
		attempt leads to the message <b>NO CARRIER</b> .			
		No engaged tone detection, this means that on a busy line			
		the message shown is <b>NO CARRIER</b> .			
	ATX1	As atxo			
	ATX2	Dial tone detection active, this means that a dial attempt			
		without the presence of a dial tone being detected leads to			
		the message <b>NO DIAL TONE</b> .			
		No engaged tone detection, this means that on a busy line			
		the message shown is <b>NO CARRIER</b> .			
	ATX3	No dial tone detection, this means that an unsuccessful dial			
		attempt leads to the message <b>NO CARRIER</b> .			
		Engaged tone detection active, this means that when calling			
	_	a busy line the message <b>BUSY</b> is given.			
	ATX4	Dial tone detection active, this means that a dial attempt			
		without the presence of a dial tone being detected leads to			
		Ine message NO DIAL TONE.			
		Engaged tone detection active, this means that when calling			
		a busy line the message <b>BUSY</b> is given.			

Command	Description			
AT*X	Ending the remot	e configuration		
	The <b>AT*X</b> command ends a remote configuration.			
ΑΤΥ	Long space (Brea This command de (BREAK), or in wha ATY0 ATY1	ak) etermines the action of the modem on receipt of a long space at form the modem produces a long space. No break processing Break processing active. On reliable links the modem sends a break of 4 seconds before <i>hanging up</i> . The modem responds to the receipt of a break (longer than 1.6 seconds) by <i>hanging</i> <i>up</i> .		
ΑΤ&Υ	Select user config AT&YO AT&Y1	guration for hardware reset On a hardware reset following the command AT&YO, user configuration 0 (produced with the AT&WO command) is loaded as the current modem configuration. On a hardware reset following the command AT&Y1, user configuration 1 (produced with the AT&W1 command) is loaded as the current modem configuration.		
ATZ	Software reset / le This command c loads the config configuration 0 is ATZ0 ATZ1	bad configuration causes the modem to execute a software reset. The modem uration saved by the user. If no parameter is given, then user loaded. Software reset followed by loading user configuration 0. Software reset followed by loading user configuration 1.		
AT&Z	Store phone num This command sa may be up to 35 correspond to the AT&Zn=x n x AT&Z0=xxx AT&Z1=xxx AT&Z2=xxx	aves four entries (0 to 3) permanently in the EPROM. Each entry o characters in length. The entries can be overwritten and must e dial string as specified in the <b>ATD</b> command. is the number of the entry in the list (from 0 to 3) is the dial string with the phone number sets the service number of the mobile provider (xxx stands for number) entry of the reply phone number into the modem calling back (xxx stands for the phone number) phone number of the mobile phone (xxx stands for number) for SMS alarm		
<pause> **** <pause></pause></pause>	starts the remote	configuration of the local modem		

# 5.3 Overview Fax- And Voice Commands

Please refer to your supplier for more detailed documents about the commands of Fax Class 2 as well as a documentation of the voice commands.

# 5.4 AT Messages

List of the message numbers and texts depending on the **ATX** command.

Message number short form	Message text in long form	ATXn n=0	n=1	n=2	n=3	n=4
+F4	+FCERROR	Х	Х	Х	Х	Х
0	ОК	Х	Х	Х	Х	Х
1	CONNECT	Х	Х	Х	Х	Х
2	RING	Х	Х	Х	Х	Х
3	NO CARRIER	Х	Х	Х	Х	Х
4	ERROR	Х	Х	Х	Х	Х
5	CONNECT 1200	1	Х	Х	Х	Х
6	NO DIAL TONE	3	3	Х	3	Х
7	BUSY	3	3	3	Х	Х
8	NO ANSWER	1	Х	Х	Х	Х
9	CONNECT 600	1	Х	Х	Х	Х
10	CONNECT 2400	1	Х	Х	Х	Х
11	CONNECT 4800	1	Х	Х	Х	Х
12	CONNECT 9600	1	Х	Х	Х	Х
13	CONNECT 7200	1	Х	Х	Х	Х
14	CONNECT 12000	1	Х	Х	Х	Х
15	CONNECT 14400	1	Х	Х	Х	Х
16	CONNECT 19200	1	Х	Х	Х	Х
17	CONNECT 38400	1	Х	Х	Х	Х
18	CONNECT 57600	1	Х	Х	Х	Х
19	CONNECT 115200	1	Х	Х	Х	Х
20	CONNECT 230400	Х	Х	Х	Х	Х
22	CONNECT 75TX/1200RX	1	Х	Х	Х	Х
23	CONNECT 1200TX/75RX	1	Х	Х	Х	Х
24	DELAYED	4	4	4	4	Х
32	BLACKLISTED	4	4	4	4	Х
33	FAX	Х	Х	Х	Х	Х
35	DATA	Х	Х	Х	Х	Х
40	CARRIER 300	Х	Х	Х	Х	Х
44	CARRIER 1200/75	Х	Х	Х	Х	Х
45	CARRIER 75/1200	Х	Х	Х	Х	Х
46	CARRIER 1200	Х	Х	Х	Х	Х

Message	Message text in long form	ATXn				
number short form		n=0	n=1	n=2	n=3	n=4
47	CARRIER 2400	Х	Х	Х	Х	Х
48	CARRIER 4800	Х	Х	Х	Х	Х
49	CARRIER 7200	Х	Х	Х	Х	Х
50	CARRIER 9600	Х	Х	Х	Х	Х
51	CARRIER 12000	Х	Х	Х	Х	Х
52	CARRIER 14400	Х	Х	Х	Х	Х
53	CARRIER 16800	Х	Х	Х	Х	Х
54	CARRIER 19200	Х	Х	Х	Х	Х
55	CARRIER 21600	Х	Х	Х	Х	Х
56	CARRIER 24000	Х	Х	Х	Х	Х
57	CARRIER 26400	Х	Х	Х	Х	Х
58	CARRIER 28800	Х	Х	Х	Х	Х
59	CONNECT 16800	1	Х	Х	Х	Х
61	CONNECT 21600	1	Х	Х	Х	Х
62	CONNECT 24000	1	Х	Х	Х	Х
63	CONNECT 26400	1	Х	Х	Х	Х
64	CONNECT 28800	1	Х	Х	Х	Х
66	COMPRESSION: CLASS 5	Х	Х	Х	Х	Х
67	COMPRESSION: V.42 bis	Х	Х	Х	Х	Х
69	COMPRESSION: NONE	Х	Х	Х	Х	Х
70	PROTOCOL: NONE	Х	Х	Х	Х	Х
77	PROTOCOL: LAP-M	Х	Х	Х	Х	Х
78	CARRIER 31200	Х	Х	Х	Х	Х
79	CARRIER 33600	Х	Х	Х	Х	Х
80	PROTOCOL: ALT	Х	Х	Х	Х	Х
81	PROTOCOL: ALT-CELLULAR	Х	Х	Х	Х	Х
84	CONNECT 33600	Х	Х	Х	Х	Х
91	CONNECT 31200	Х	Х	Х	Х	Х
150	CARRIER 32000	Х	Х	Х	Х	Х
151	CARRIER 34000	Х	Х	Х	Х	Х
152	CARRIER 36000	Х	Х	Х	Х	Х
153	CARRIER 38000	Х	Х	Х	Х	Х
154	CARRIER 40000	Х	Х	Х	Х	Х
155	CARRIER 42000	Х	Х	Х	Х	Х
156	CARRIER 44000	Х	Х	Х	Х	Х
157	CARRIER 46000	Х	Х	Х	Х	Х
158	CARRIER 48000	Х	Х	Х	Х	Х
159	CARRIER 50000	Х	Х	Х	Х	Х
160	CARRIER 52000	Х	Х	Х	Х	Х
161	CARRIER 54000	Х	Х	Х	Х	Х
162	CARRIER 56000	Х	Х	Х	Х	Х
165	CONNECT 32000	Х	Х	Х	Х	Х

Message number short form	Message text in long form	ATXn n=0	n=1	n=2	n=3	n=4
166	CONNECT 34000	Х	Х	Х	Х	Х
167	CONNECT 36000	Х	Х	Х	Х	Х
168	CONNECT 38000	Х	Х	Х	Х	Х
169	CONNECT 40000	Х	Х	Х	Х	Х
170	CONNECT 42000	Х	Х	Х	Х	Х
171	CONNECT 44000	Х	Х	Х	Х	Х
172	CONNECT 46000	Х	Х	Х	Х	Х
173	CONNECT 48000	Х	Х	Х	Х	Х
174	CONNECT 50000	Х	Х	Х	Х	Х
175	CONNECT 52000	Х	Х	Х	Х	Х
176	CONNECT 54000	Х	Х	Х	Х	Х
177	CONNECT 56000	Х	Х	Х	Х	Х
178	CONNECT 230400	Х	Х	Х	Х	Х
180	CARRIER 28000	Х	Х	Х	Х	Х
181	CARRIER 29333	Х	Х	Х	Х	Х
182	CARRIER 30667	Х	Х	Х	Х	Х
183	CARRIER 33333	Х	Х	Х	Х	Х
184	CARRIER 34667	Х	Х	Х	Х	Х
185	CARRIER 37333	Х	Х	Х	Х	Х
186	CARRIER 38667	Х	Х	Х	Х	Х
187	CARRIER 41333	Х	Х	Х	Х	Х
188	CARRIER 42667	Х	Х	Х	Х	Х
189	CARRIER 45333	Х	Х	Х	Х	Х
190	CARRIER 46667	Х	Х	Х	Х	Х
191	CARRIER 49333	Х	Х	Х	Х	Х
192	CARRIER 50667	Х	Х	Х	Х	Х
193	CARRIER 53333	Х	Х	Х	Х	Х
194	CARRIER 54667	Х	Х	Х	Х	X

#### Notes to the table

An **X** in the column means that a message is sent either in long form or in short form (according to **ATV** command). The numbers 0 to 4 in the heading mean the parameters for the commands **ATX0** to **ATX4**.

If a number is in a column, this means that an error message according to this error number is put out.

# 6 S Register

S-registers can be read and written with the **ATS** command (See chapter 8 "AT command set", command **ATS**). Certain S-registers can only be read, while others can only be set within a limited range of values.

If a value limit is exceeded, the modern will respond **OK**, even though the value is not accepted. Therefore, it is recommended to check the contents of a register, after changes have been made by use of the **ATSn**? command.

Register	Function	Units	stored in EEPROM
			with AT&W
S0	Rings to Auto-Answer	Rings	*
S1	Ring Counter	Rings	
S2	Escape Character	ASCII	*
S3	Carriage Return Character	ASCII	
S4	Line Feed Character	ASCII	
S5	Backspace Character	ASCII	
S6	Wait Time for Dial Tone	S	*
S7	Wait Time for Carrier	S	*
S8	Pause Time for Dial Delay	S	*
	Modifier		
S9	Carrier Detect Response Time	0.1 s	*
S10	Carrier Loss Disconnect Time	0.1 s	*
S11	Data Transmit Control	1s	*
S12	Escape Prompt Delay	0.02 s	*
S13	Number of dial attempts for		*
	alarm		
S14	General Bit Mapped Options	-	*
	Status		
S17	Remote-initial character	ASCII	
S21	V.24/General Bit Mapped	-	*
	Options Status		
S22	Speaker/Results Bit Mapped	-	*
	Options Status		
S25	Delay to DTR Off	0.01 s	
S26	RTS-to-CTS Delay	0.01 s	
S29	Flash Dial Modifier Time	10 ms	
S30	Disconnect Inactivity Timer	10 s	
S31	General Bit-Mapped Options	-	*
	Status		

# 6.1 Overview S Register

Register	Function	Units	stored in EEPROM
S32	XON Character	ASCII	
S33	XOFF Character	ASCII	
S36	LAPM Failure -control	-	*
S38	Delay Before Forced Hang-up	S	
S39	Flow Control Bit Mapped	-	*
	Options Status		
S40	General Bit-Mapped Options	-	*
	Status		
S41	General Bit-Mapped Options	-	*
	Status		
S46	Data Compression Control	-	*
S48	V.42 Negotiation Control	-	*
S86	Call Failure Reason Code	-	
S91	Send level	-	*
S95	Result Code Messages	-	*
	Control		

These registers are stored to the EEPROM with the command **AT&W**.

# 6.2 Description S Register

- **Note:** Registers marked with \*) are stored to the user settings with **AT&W**.
- S0\*Rings to Auto-AnswerThe number of call ring signals before the modem answers.A value of S0=0 means that the modem will not answer. S0 can<br/>accept a value between 0 and 5.

#### **S1** <u>Ring Counter</u>

Counter for call rings.

S1 can only be read. S1 resets to zero when the modem is waiting for a call.

#### S2\* Escape Character

Escape character, which effects a switch from data mode to online command input mode. Values greater than 127 have the effect that an escape character is not recognized.

- S3 Carriage Return Character
- S4 Linefeed Character
- **S5** <u>Backspace Character</u>
- **S6\*** <u>Wait Time for Dial Tone</u> (Before Blind Dialing)

Maximum time to wait for a dial tone.

After the modem has picked up, it waits for a dial tone for the set time. If a dial tone is detected during the wait period, dialing begins.

If no dial tone is detected, the modem checks whether dial tone detection is activated, or whether the parameter W (chapter 8 "AT command set", **ATD** command) is present in the dial string. If the dial tone detection is inactive, the modem waits for the time given in S6 (in seconds) for the dial tone. S6 can have a value between 4 and 7.

**S7**\* Wait for Carrier

Waiting for a carrier frequency from the remote modem. S7 determines the maximum time, that the modem waits for a reply from the remote modem. The time begins to run when the modem has finished dialing. S7 can have a value between 0 and 100 seconds.

#### **S8**\* Pause Time for Dial Delay Modifier

Dial pause time if a comma is in the dial string.

The modem waits during dialing for the time specified in S8 (in seconds) if a comma is present in the dial string. S8 can have a value between 1 and 7 seconds.

#### \$9\* <u>Carrier Detect Response Time</u>

DCD reaction time for a carrier frequency received from the remote modem.

The DCD output of the modem's RS232 interface (CT109) goes to **on** if a carrier frequency is detected from the remote modem within the time defined in S9 (in tenths of a second). S9 must be less than S10.

#### **S10\*** <u>Carrier Loss Disconnect Time</u>

The time of a carrier loss required for the modem to terminate the connection.

S10 gives the time, in tenths of a second, which the modem waits when the carrier from the remote modem is no longer detected before disconnecting the connection.

#### **S12\*** Escape Prompt Delay

Minimum time period, in tenths of a second, that must be maintained before, between, and after two characters so that the modem correctly detects an escape sequence (normally +++).

#### **S13\*** Number of dial attempts for alarm

Bit	Signification		
Bit 0 – 3	Number of dialing attempts	Value range: 112	
		Default value: 3	
		<ul> <li>S13 determines the dial attempts for an alarm message.</li> <li>Note: The limit to a maximum of 12 attempts is required for reasons of certification (blacklisting).</li> </ul>	
Bit 4 – 7	Reserved		

#### **S14\*** <u>General Bitmapped Options Status</u>

Bit	Signification		
Bit 0	Reserved		
Bit 1	Echo input	Command echo	
		0: Echo off	
		1: Echo on	
Bit 2	Reserved		
Bit 3	Results format	Result codes:	
		0: Message numbers	(ATVO)
		1: Message texts	(ATV1)
Bit 4	Reserved		
Bit 5	Tone / pulse dialing	Tone / pulse	
		0: Tone dialing	(ATT)
		1: Pulse dialing	(ATP)
Bit 6	Reserved		
Bit 7	Call / answer	Originate / answer	
		0: Answer mode	
		1: Call mode (originate	e)

#### **S17\*** <u>Remote initial character</u>

In S17, the ASCII code of the character, used to start the remote configuration, is defined. Values >127 switch off remote configuration completely. Default setting of S17 is "42", which is ASCII character "\*", i.e. the remote configuration is started with the escape sequence <**Pause>** "\*\*\*\*" <**Pause>**.

(Note: The number of characters in the escape sequence is fix set to "4")

**S21\*** <u>General Bitmapped Options Status</u> – settings for V24

Bit	Signification	
Bit 0, 1	Reserved	
Bit 2	CTS behavior	CT106 (CTS) behavior:
		0: as for AT&RO
		1: as for AT&R1
Bit 3 - 4	DTR behavior	CT108 (DTR) behavior:
		0: as for AT&DO
		1: as for AT&D1
		2: as for AT&D2
		3: as for AT&D3
Bit 5	DCD behavior	CT109 (DCD) behavior:
		0: as for AT&CO
		1: as for AT&C1
Bit 6	DSR behavior	CT107 (DSR) behavior:
		0: as for <b>AT&amp;SO</b>
		1: as for <b>AT&amp;S1</b>
Bit 7	Long space disconnect	Long space disconnect:
		0: as for ATYO
		1: as for <b>ATY1</b>

Bit	Signification		
Bit 0, 1	Speaker volume	Speaker volume:	
		0: Off	(ATLO)
		1: Quiet	(ATL1)
		2: Medium	(ATL2)
		3: Loud	(ATL3)
Bit 2 – 3	Speaker function	Speaker control:	
		0: Off	(ATMO)
		1: Off till carrier	(ATM1)
		2: Always on	(ATM2)
		3: On during set-up	(ATM3)
Bit 4 – 6	Error message group	Limit results codes:	
		0: Like <b>atx0</b>	
		4: Like <b>atx1</b>	
		5: Like <b>atx2</b>	
		6: Like <b>ATX3</b>	
		7: Like <b>ATX4</b>	
Bit 7	Reserved		

#### **S22\*** <u>Speaker/Results Bitmapped Options Status</u>

#### S25 Delay to DTR Off

The time that the modem permits the DTR signal to remain off before hanging up (in hundredths of a second).

#### S26 <u>RTS-to-CTS Delay</u>

Time between the activity of RTS and CTS in 1/100 second.

#### S29 Flash Dial Modifier Time

Sets the time, in tenths of a second, that the modem takes to hang up if a flash is included in the dial string.

#### S30 Disconnect Inactivity Timer

The time that the modem waits without activity before it hangs up. The unit is seconds (fax class 1 only).

#### S31\* <u>General Bitmapped Options Status</u>

Bit	Signification	
Bit 0		
Bit 1	Representation	0: 3-line message (\vo)
	Connect message	1: extended 1-line message (\v1)
Bit 2 - 3	Error correction messages	Error correction messages:
	-	0: PC baud rate only (ATWO)
		1: PC and phone baud rate
		(ATW1)
		2: Phone baud rate only (ATW2)
Bit 4 - 7	Reserved	

#### S32 XON Character

ASCII code of the character that is recognized by the modem as XON.

#### **S33** <u>XOFF Character</u>

ASCII code of the character that is recognized by the modem as XOFF.

#### \$36\* LAPM Failure Control

This register determines what happens when an attempt to set-up a V.42 LAPM connection fails. It is connected with register S48.

Bit	Signification	
Bit 02	This register determines	0 The modem hangs up.
	what happens if an	1 The modem stays online and sets up
	attempt to set up a V.42	a direct mode connection.
	LAP-M connection fails. It	2 Reserved
	is used in conjunction with	3 The modem stays online and sets up
	the S48 register.	a normal mode connection.
		4 The modem tries to set up an MNP
		connection. It hangs up if this fails.
		5 The modem tries to set up an MNP
		connection. A direct mode
		connection is made if this fails.
		6 Reserved
		7 The modem tries to set up an MNP
		connection. A normal mode
		connection is made if this fails.
Bit 35	Reserved	
Bit 7		1: call answer unlocked (AT*A1)
		0: call answer locked (AT*A0)

#### S38 Delay Before Forced Hang-up

Maximum time in seconds that remains for the buffers to erase their data after the command to hang up has been received. Only valid for error corrected links.

#### **\$39\*** <u>PC / Flow Control Modem</u>

Selection of the data flow control between PC and modem.

- S39=0 No flow control (AT&KO)
- S39=3 RTS/CTS flow control (AT&K3)
- S39=4 XON/XOFF flow control (AT&K4)
- S39=5 Transparent XON flow control (AT&K5)
- S39=6 RTS/CTS and XON/XOFF flow control

S40*	General Bitmapped Options Status	
	• •	

Bit	Signification	
Bit 0	V.42 to MNP 10	MNP 10 Extended Service
	conversion	0: No V.42/MNP 10 (Ат-ко)
		1: V42 to MNP10 conv. (ат-к1)
Bit 1	Power level	Power Level Adjustment for
	Adjustment MNP10	Cellular MNP 10
	for 56k version reserved	0: No powerl. adj. (AT)MO)
		1: Powerl. adjustm. (AT)M1)
Bit 2	MNP speed	MNP link negotiation speed
	for 56k version reserved	0: highest speed (AT*H0)
		1: 1.200 bps (AT*H1)
Bit 3-5	Break behavior	Break Handling
		0: like at\ko
		1: like at\k1
		2: like at\k2
		3: like at\k3
		4: like at\k4
		5: like at\k5
Bit 6-7	MNP block size	MNP Block Size
		0: 64 characters (AT\A0)
		1: 128 characters (AT\A1)
		2: 192 characters (AT\A2)
		3: 256 characters (AT\A3)

#### General Bitmapped Options Status S41\*

Bit	Signification		
Bit 0, 1	Select compression type	Compression selection	
		0: No compression (AT%CO)	)
		1: MNP5 (AT%C1)	)
		2: V.42bis (AT%C2)	)
		3: MNP5 or V.42bis (AT%C3)	)
Bit 2	Auto retrain	Auto retrain control	
		0: No auto retrain (AT%E0)	)
		1: Auto retrain (AT%E1)	)
Bit 3	Flow control modem /	Modem to modem flow co	ntrol
	modem	0: Off (AT\G0)	)
	for 56k version reserved	1: On (AT\G1)	)
Bit 4	MNP block mode	Block mode control MNP	
	for 56k version reserved	0: Stream mode (AT\L0)	)
		1: Block mode (AT\L1)	)
Bit 5	Reserved		
Bit 6	Fallback / fall forward	Fallback/fall forward control	ol
		0: No fallback/fall forward	
		1: FB/FF (AT%E2)	)
Bit 7	Reserved		

#### S46\* V.42bis Data Compression

S46=136 No data compression.S46=138 V.42bis data compression on.

# \$48\* <u>V.42 Negotiation Control</u> \$48=0 Only LAP-M connection possible \$48=7 LAP-M or MNP 4 connection \$48=128 Connection protocol as specified in \$36 \$86 <u>Call Failure reason Code</u> On a connection break (NO CARRIER) an occurrence (ERROR) code is written to this register. \$86=0 normal connection set-up, no error

- S86=4 carrier lost
- S86=5 an error corrected (V.42) connection could not be established
- \$86=6 extensions could not be negotiated
- \$86=7 remote site only supports synchronous mode
- S86=8 no mutual framing found
- S86=9 no protocol at all could be established
- \$86=10 invalid response when negotiating extensions
- S86=11 no synchronous marks received from remote site
- \$86=12 normal connection termination by remote site
- \$86=13 remote site does not react any longer (ten attempts)
- S86=14 protocol error
- S86=15 DTR drop
- S86=16 remote site required termination (GSTN cleardown)
- S86=17 inactivity timer timed out
- S86=18 required speed not supported
- S86=19 long space disconnect
- S86=20 key abort (characters have been sent during connection set-up)
- S86=22 no connection set-up possible
- S86=23 termination after 3 retrains
- S86=26 remote site hung up

#### S91\* <u>Send level</u>

In register S91, the value for the send level of the modem is stored. The value can be set between 0 and 15. The connection can be improved by decreasing the send level in some cases.

- S91=0 Send level –1 dBm
- S91=5 Default setting for DC 56K
- S91=15 Send level -26 dBm

## **\$95\*** <u>Result Code Control</u>

Bit	Signification
Bit 0	CONNECT message with line speed
Bit 1	CONNECT / ARQ message on error corrected connection
Bit 2	CARRIER message enabled (messages 40 - 47)
Bit 3	PROTOCOL message enabled (messages 70 - 80)
Bit 4	Reserved
Bit 5	COMPRESSION message enabled (messages 66 - 69)
Bit 6	Reserved
Bit 7	Reserved

# Glossary

Analogue	Opposite of Digital. Analogue variables can represent any value.
Answer	In a modem communication always one modem is receiver (Answer-Mode)
	and one is sender (Originate-Mode).
ARQ	Automatic Retransmission reQuest – Only for error corrected protocols.
ASCII	American Standard Code for Information Interchange assigned to each
	letter, number and special sign an 8-bit value, limiting it to 256.
Asynchronous	Data transmission mode where data bits of each character are transmitted
	together with additional bits (Start-, Stop-, Parity bit) so that the other side can
	detect when a new character begins and if the last one was transmitted error
	free.
AT-Command	All commands that a modem understands start with AT (AT for attention)
Auto Answer	Modems ability to answer incoming calls automatically after a preset (SO-
	Register) number of rings.
Baud	Step speed unit per second on the phone line or between Modem and
	Computer. On the serial Interface this is the transmission rate in bits/s. On the
	phone line usually several bits are transmitted per step.
BBS	Bulletin Board System - Mailbox. Software, that is able to send and receive
	messages and files over modems or several modems.
bis	French: second, or second Revision.
BPS	Bit rate unit; Bits per Second.
BTZ	Federal German Office for Telecommunication Approvals.
CCITT	Comité Consultatif International Telephonique et Telegraphique; was
	replaced with ITU-TSS (International Telecommunications Union).
CD	Carrier Detect (data carrier signal was detected).
CEPT	Commission Européenne Postale et Telephonique. The CEPT transmission
	protocol is being used for BTX (Datex-J) e.g.
Class 2	Fax transmission standard.
COM-Port	Serial PC interface.
CRC	Cyclic redundancy check - A procedure, with which errors are detected
	during transmission.
CTS/RTS	Serial interface control lines according to RS232. In assistance with those lines
	Hardware-Handshake is.
Data	Reducing information in less information units. E.G. frequent character
compression	sequences are replaced with short codes to be transmitted as replacement.
Data- pump	Modem internal module that is responsible for transmission speed.
DCD	Data Carrier Detected.
DCE	Data Communications Equipment (e.g. a Modem).
DIE	Data-Terminal-Equipment - The DTE-speed is the interface speed between
DEÜ	Computer and Modern.
Domodulation	Date nationshipsion with Computer
	Re-conversion of analogue signals to digital signals.
	Deta Set Deady, this social interface control line signals "ready to reactive" to
DOK	bata set keady – this senarimenace control line signals "ready to receive" to

DTR	Data Terminal Ready - this serial interface control line signals "ready to
	Electrically Programmable Pead Only Memory - a permanent memory chin
	which can be deleted only with UV light. The modem firmware is often stored
	in EPROMS.
Error	Transmission errors caused by poor line quality are recognized with the error
Recognition	correction method (MNP4 or V.42bis) and are corrected through the modem
	not noticeable for the PC.
FIFO	First-In-First-Out-Puffer (included in UART 16550) is recommended for fast
	transmission rates and/or multitasking operating systems
Firmware	Modem operating software
Handshake	In order to establish a data communication the two modems have to
	negotiate a common speed and protocol. This phase is called Handshake.
ITU	International Telecommunications Union new name for the standardizing association CCITT.
LAPM	Link Access Procedure for Modems – an error corrected protocol
LED	Light Emitting Diode.
MNP	Error correction- and date compression protocol.
Modem	MOdulator DEModulator -converts digital computer signals into analogue
	phone line signals. (Onto the opposite site analogue in digital.)
offline	Modem not connected.
online	Modem connected.
Parity	Test method to check data integrity on asynchronous transmissions
Redundant	Availability of duplicated data
Reset	Return to a defined initial state.
RTS / CTS	Interface control lines for dataflow control.
RXD	Received Data - interface control line for receiving data.
S-Register	Status register - here are the Modem operating parameters stored
SREJ	Selective Reject - SREJ is an error correction-protocol V.42bis expansion.
ter	French: three, and/or third revision.
Terminal-	Program, that can send an receive date using a modem.
program	
X-Modem	Older, but very common protocol. Often selected as only common choice.
	MA. Block size only 128 Bytes, low transmission rates, no transmission of file
	names.
XON/XOFF	See Chapter "Serial Data transmission"
Z-Modem	Standard protocol for computer data transmission, high transmission speed,
	transmission of file names and paths, reconnection of interrupted
	transmissions. Z-Modem-G is an advanced, but uncommon version.

# FAQs

In the following some questions are described which may occur at installation.

Problem:	The modem does not react on an <b>ATZ</b> command.
Possible	The Com port number or the interrupt number, set in the software, does not
reason:	fit match with the modem interface number.
	The modem has no power supply or is switched off.
	The modem is not connected to the PC / PLC interface.
	(See chapter 3 "Start-Up".)
Problem:	The modem does not dial after the ${\tt ATD}$ dial command and displays an error
	message.
Possible	The modem is operated at a PABX. The PABX requires that a 0 or 9 must be
reason:	dialed first or the ground key must be pressed before getting a dial tone. But
	the modem requires a dial tone before dialing any digit.
	The solution is to activate blind dialing (dialing without dial tone) with the
	$\tt ATX3$ command or by adding the > sign to the dial string. (see chapter 5 "AT
	Command Set" <b>ATX</b> command, <b>ATD</b> command.)
	After dialing the first digit without dial tone, or after executing the ground
	function, you can reactivate the dial tone detection by adding a ${\bf w}$ to the
	dial string
	(Example <b>ATD0W12345</b> )
Problem:	The modem does not dial immediately after the ATD dial command
Possible	The dialing delay of 30 seconds is active.
reason::	(See chapter 4.4 "Dialing Delay").
Problem:	The modem can send data, but not receive.
Possible	The setting of the hardware handshake line DTR is not correct. In most cases
reason:	the setting AT&D2 is correct.
	(See chapter 4.10.6 "Data Flow Control")
Problem:	The modem does not work with a particular communication program.
Possible	The communication program expects a certain type of dataflow control.
reason:	The modem setting is not accordingly. Setting the modem to the required
	dataflow control type solves this problem. Usually the communication
	program in use allows an initialization string, where the required settings can
	be added. When starting the program this string is transferred to the modem.
	(See communications software users manual and chapter 4.10.6 "Data Flow
	Control".)

Problem:	The modem can not communicate with another modem or only with
	failures.
Possible	The other modem uses a communication protocol that the local modem
reason:	does not understand.
	The solution is to select the right data compression type and error protocol.
	(See chapter 4.3 "Error Correction And Data Compression")
Problem:	A telephone connection can not be established.
Possible	The modem uses pulse instead of tone dialing.
reason:	Change settings with the commands ATDP or ATDT. You can determine, if
	your phone uses pulse or tone dialing. If you hear it clattering while dialing, it
	is pulse dialing. You can change the dialing type with the commands <b>ATDP</b>
	Or <b>ATDT</b> .
	(See chapter 5 "AT Command Set", commands ATDP, ATDT, ATP, ATT.)



 Image: Construction of the sector of the