



Specification Comparison Chart			
Item	A1S68AD	Q68ADV	Q68ADI
Analog input	-10 to 0 to 10VDC (Input resistance : 1MΩ) 0 to +20mA (Input resistance : 250Ω)	Selectable by switch setting	-10 to 10V DC (Input resistance : 1MΩ) 0 to +20mA (Input resistance : 250Ω)
Digital output	Signed 16-bit binary	Signed 16-bit binary (normal resolution mode : -4096 to 4095 high resolution mode : -12288 to 12287, -16384 to 16383)	-
I/O characteristics	Analog input	Digital output	
	0 to +10V -10 to 10V 0 to 5V or 0 to 20mA 1 to 5V or 4 to 20mA	0 to +4000 -8000 to +2000 0 to +4000 0 to +4000	
Maximum resolution	Analog input	Digital output	
	0 to +10V -10 to 10V 0 to 5V 1 to 5V or 4 to 20mA	2.5mV 5mV 1.25mV 1.0mV	
Overall accuracy	Analog input	Digital output	
	0 to +10V -10 to 10V 0 to 5V 1 to 5V or 4 to 20mA	±1% (Digital output value ±40)	
Maximum conversion time	0.5 ms/channel	80 μs/channel	(When there is temperature drift, the time calculated by adding 160μs will be used regardless of the number of channels used)
Absolute maximum input	Voltage : ±35 V Current : ±30 mA	±15 V ±30 mA	
Analog input points	8 channels/module	8 channels/module	
Insulation method	Between the I/O terminal and programmable controller : Photocoupler insulation Between channels : Non-insulation	Photocoupler insulation Non-insulation	
No. of occupied points	32 points	16 points	
Connected terminal block	20-points terminal block	18-points terminal block	
Current consumption	0.4 A	0.64 A	

- POINT**
- Q68ADV/Q68ADI has a greater conversion speed as compared with A1S68AD. This can make it possible for Q68ADV/Q68ADI to pick up noise, which A1S68AD would not, as an analog signal. In such case, eliminate the effects of noise by using the average processing function that is provided.
  - A1S68AD and Q68ADV/Q68ADI differ from each other in the way input/output signals (X, Y) and buffer memory addresses are allocated. Therefore, you need make necessary changes to the sequence program that is used.



5

## 4. Mounting and Installation


### 4.1 Handling Instructions

- Before attempting to install the Unit or carry out the necessary wiring, make certain that the external power supply, used in the system, is shut off on all three phases. Failure to do so may result in electric shock or damage to the product.
- Do not touch live terminals. There is a danger of electric shock or malfunction.
- Do not modify the Conversion Adapter or take it apart. Doing so will cause failure, malfunction, personal injury, or fire.
- Do not touch the energized part of the Conversion Adapter directly. Contact will cause malfunction or failure in the system.
- Fasten the Conversion Adapter and the Fittings securely with retaining screws, and tighten the screws by applying torque within specified limits. Loose screws can lead to the dropping of the converter adapter, or fittings, possibly causing breakage thereof. Excessive tightness of the screws can lead to breakage of the screws, converter adapter, fittings, or MELSEC-Q Series Module, possibly causing the dropping, shorting, and malfunction thereof.
- Use care to prevent foreign materials including cuttings and wiring debris from entering the Conversion Adapter or the MELSEC-Q Series module. These will be cause for fire, failure or malfunction.
- Do not drop the Conversion Adapter, and the Fittings, and avoid giving a strong impact to them. Otherwise, breakage will result.
- If the existing system is installed on a DIN rail, the Base Adaptor is not necessary. The MELSEC-Q Series Base Module you use can be mounted onto the DIN rail.

### 4.2 Instructions for Use

Item	Description
Width dimension of module	Because the module is reduced in width dimension (34.5mm→27.4mm) and thus in area available for wiring, check dimensional data before installing the module. 
Depth dimension of module	Because the module is increased in depth dimension, check dimensional data before installing the module. 


6

Item	Description
Terminal block cover	The terminal block cover for MELSEC-AnS Series is bigger than the width of the MELSEC-Q Series Module. Therefore, it is necessary to replace it with the terminal block cover supplied with the converter adapter. 

### 4.3 Installation Environment


For detail information, see the user's manual furnished with the MELSEC-Q Series CPU module you use.

## 5. Part Names and Installation Procedure



7

### 5.1 Installation Procedure

- Secure the MELSEC-Q Series Base Module to the Base Adapter with the supplied attaching screws (M4 x 10). (Secure it in four places.)
- Mount a compatible module under the MELSEC-Q Series onto the MELSEC-Q Series Base Module.  
Also, remove the terminal block installed to the MELSEC-Q Series Module by undoing the terminal block attaching screws (one at the top and the other at the bottom).  

- Secure the mounting bracket to a compatible module under the MELSEC-Q Series with retaining screws (M3.5 x 6). (Secure it in two places, top and bottom.)
- Mount the Conversion Adapter onto the mounting bracket and secure it with the Conversion Adapter attaching screws (M3 x 25). (Secure it in two places, top and bottom.)

**Precaution**  
Before tightening the installation screws, check that the Conversion Adapter has been securely installed on the MELSEC-Q Series module. Tightening the screws in floating-off state or tilting state will damage the Conversion Adapter installation screws and the mounting bracket.

- Secure the Base Adapter to the panel with the supplied attaching screws (M5 x 12). (Secure it in four places.)
- Secure the MELSEC-AnS Series terminal block to the Conversion Adapter with the supplied attaching screws (M4).
- Remove the terminal block cover from the MELSEC-AnS Series terminal block and fit the terminal block cover supplied with the Conversion Adapter in place.
- Secure the FG wire in place with the FG terminal screws (M3 x 6).

### 5.2 Tightening Torque


Tighten the module attaching screws by applying torque listed in the table blow. Application of improper tightening torque will cause dropping, short-circuit, failure, or malfunction.

Component attached with screw	Range of tightening torque
Base Adaptor attaching screw (M5)	2.75 to 3.63N·m
Q Series module attaching screw (M4)	1.39 to 1.89N·m
Mounting bracket securing screw (M3.5)	0.68 to 0.92N·m
Conversion Adapter attaching screw (M3)	0.43 to 0.57N·m
MELSEC-AnS Series terminal block attaching screw (M4)	0.78 to 1.18N·m
FG terminal screw (M3)	0.42 to 0.58N·m


8

## 6. Dimensional Outline Drawing

### (1) ERNT-ASQT64AD



### (2) ERNT-ASQT68AD



9

## Product Warranty Details

Please confirm the following product warranty details prior to product use.

### Gratis Warranty Terms and Gratis Warranty Range

If any fault or defect (hereinafter referred to as "Failure") attributable to Mitsubishi Electric Engineering Company Limited (hereinafter referred to as "MEE") should occur within the gratis warranty period, MEE shall repair the product free of charge via the distributor from whom you made your purchase.

#### ■ Gratis Warranty Period

The gratis warranty period of this product shall be one (1) year from the date of purchase or delivery to the designated place.  
Note that after manufacture and shipment from MEE, the maximum distribution period shall be six (6) months, and the gratis warranty period after manufacturing shall be limited to eighteen (18) months. In addition, the gratis warranty period for repaired products shall not exceed the gratis warranty period established prior to repair.

#### ■ Gratis Warranty Range

The gratis warranty range shall be limited to normal use based on the usage conditions, methods and environment, etc., defined by the terms and precautions, etc., given in the instruction manual, user's manual and caution labels on the product.

### Warranty Period after Discontinuation of Production

- MEE shall offer product repair services (fee applied) for seven (7) years after production of the product has been discontinued. Discontinuation of production shall be reported via distributors.
- Product supply (including spare parts) is not possible after production has been discontinued.

### Exclusion of Opportunity Loss and Secondary Loss from Warranty Liability

Regardless of the gratis warranty period, MEE shall not be liable for compensation for damages arising from causes not attributable to MEE, opportunity losses or lost profits incurred by the user due to Failures of MEE products, damages or secondary damages arising from special circumstances, whether foreseen or unforeseen by MEE, compensation for accidents, compensation for damages to products other than MEE products, or compensation for other work carried out by the user.

### Changes in Product Specifications

The specifications given in the catalogs, manuals and technical documents are subject to change without notice.

This document is a new publication, effective September 2014. Specifications are subject to change without notice.