

NETWORK 1275 Danner Dr Tel:330-562-7070 TECHNOLOGIES Aurora, OH 44202 Fax:330-562-1999 INCORPORATED www.networktechinc.com

SPLITMUX-3GSDI-4

3G/HD/SD-SDI Quad-view Video Processor

User Manual





Safety and Notice

The **SPLITMUX-3GSDI-4 (SPLITMUX) 3G/HD/SD-SDI Quad-view Video Processor** has been tested for conformance to safety regulations and requirements, and has been certified for international use. However, like all electronic equipments, the **SPLITMUX** should be used with care. Please read and follow the safety instructions to protect yourself from possible injury and to minimize the risk of damage to the unit.

- Follow all instructions and warnings marked on this unit.
- Do not attempt to service this unit yourself, except where explained in this manual.
- Provide proper ventilation and air circulation and do not use near water.
- Keep objects that might damage the device and assure that the placement of this unit is on a stable surface.
- Use only the power adapter and power cords and connection cables designed for this unit.
- Do not use liquid or aerosol cleaners to clean this unit. Always unplug the power to the device before cleaning.



TABLE OF CONTENTS

INTRODUCTION	1
FEATURES	1
PACKAGE CONTENTS	1
SPECIFICATIONS	2
PANEL DESCRIPTIONS	3
HARDWARE INSTALLATION	4
CONNECTION DIAGRAM	5
Operation Software	6
WARRANTY	13

INTRODUCTION

The **SPLITMUX 3G/HD/SD-SDI Quad-view Video Processor** is an advanced video processor for multimedia presentations. It is an ideal solution for some application such as surveillance, where up to four SDI video signals must be displayed on a single display. It supports up to 4 SDI video inputs, of which all can be output simultaneously with the desired display layout through software control. The advanced video processor allows you to manipulate the output images into any position or size you want for viewing 4 computers or four video signals or a combination.

The embedded processor converts signals from input sources to match the native resolution of monitors, flat panel displays, projectors as well as user-selectable output settings up to WUXGA (1920x1200). Dual outputs are provided in both digital (SDI and DVI) formats with one connected to a remote display and the other is connected to on-site display for real time monitoring.

FEATURES

- Supports 3G/HD/SD SDI video formats
- Input resolutions support interlaced or progressive video under SMPTE
- Dual outputs DVI (640x480 to 1920x1200) / SDI (720P, 1080P)
- Each SDI channel has 1 re-clocked SDI loop-out
- Adjustable size & position through software
- Image parameters and layouts are automatically saved in flash memory and can be recalled for later use
- User-selectable output settings, up to 1920x1200 (Only for DVI)
- Perfect as a video screen splitter, a video converter and a video switcher
- Software control through RS-232 and Ethernet
- 1U size

PACKAGE CONTENTS

- 1x SPLITMUX
- 1x USB to RS-232 cable
- 2x 1U rack mounting-ear
- 1x Installation software CD
- 1x UL 12V power adapter
- 1x UL AC power cord
- 1x User Manual

SPECIFICATIONS

Technical			
Role of usage		Multiplexer / video processor	
Dual output	support	Yes (DVI & SDI)	
Video bandv	width	2.25Gbps	
DVI connec	ctor	DVI-I Female	
BNC conne	ector	75 ohm interlocked socket	
RS-232 Cor	nector	DB9 Female	
Ethernet cor	nnector	WE/SS 8P8C (RJ45 Female)	
Input		4x SDI; 1RJ45	
Output		4 x SDI loop-out ; 2 x SDI; 1 x DVI	
Supported Resolutions		Up to 1920x1080p (1920x1200)	
Audio suppo	ort	Surround sound (up to 7.1ch) or stereo digital audio	
Mechanical			
Housing		Metal enclosure	
Dimensions [L x W x H]		236 x 440 x 45mm (9.3" x 17.3" x 1.8")	
Weight	Model	2100g (4.6lbs)	
weight	Package	5000g (11 lbs)	
Mounting m	ethod	1RU rack-mounting case with ears	
Power supp	ly	5V 4A DC (CE/FCC/UL Certified)	
Power cons	umption	30W Maximum	
Operation te	emperature	0~40°C (32~104°F)	
Storage tem	perature	-20~60°C (-4~140°F)	
Relative hur	nidity	20~90% RH (non condensing)	

PANEL DESCRIPTIONS

Front Panel



1. Power LED: Power indicator

Rear Panel



- 2. Power Switch: Power On/Off
- 3. RS-232: RS-232 control port
- 4. +12V DC: Connect to the +12VDC power supply unit.
- 5. Dip Switch: NOT SUPPORTED
- 6. Device ID
- 7. USB
- 8. Ethernet: Ethernet control port.
- 9. SDI output
- 10. DVI output
- 11. Input 1-4: SDI inputs
- 12. SDI local loop out (provides local output connection for this input)

HARDWARE INSTALLATION

Safety Precautions

- 1. To prevent fire or shock hazards, do not expose this device to rain or moisture.
- The product should be placed more than one foot away from heat sources such as radiators, heat registers, stoves, and other products (including amplifiers) that produce heat. In addition, do not place any material or device on the top of the SPLITMUX.
- 3. Do not use immediately after moving from a low temperature to high temperature, as this causes condensation.
- 4. Do not place this product on an unstable cart, stand, or table. The product may fall, causing serious injury to a child or adult and serious damage to the product.
- 5. Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use only a damp cloth for cleaning.
- 6. Do not allow the same still picture to be projected for a long time or an abnormally bright video picture to be projected. The video image could be burned into the display device.

Installation Procedures

Unpacking

Remove the SPLITMUX from the shipping container and examine it for any signs of shipping damage or missing items (check with package contents above). All shipping items should be saved if the product is to be moved or returned for service. Shipping unit back to dealers for service not in the original box may result in voiding warranty or incurring additional costs.

Placement

The unit will maintain a proper operating temperature provided it is installed without having anything blocking the sides and top of the unit.

Connections

We recommend the highest quality cables for both input and output connections.

- 1. Switch OFF the SPLITMUX and all devices that you want to connect.
- 2. Connect a monitor, a projector or other displays that comes with DVI / SDI inputs
- Connect a device equipped with SDI output including SD/HD/3G to the BNC input connector of the SPLITMUX.
- 4. Connect a device equipped with composite video output to the BNC input connector of the SPLITMUX.
- 5. Connect your computer to the SPLITMUX with a 9-pin RS-232 cable and then install the software.
- 6. Plug in AC Adapter power cord into AC power socket.
- 7. Execute the control software and establish the connection between PC/Laptop and SPLITMUX.
- 8. For detailed software control operation, please refer to the software instruction section.

CONNECTION DIAGRAM



Operation Software

System Requirement and Precautions

- 1. The device provides a software control program, "SDIMultiviewer" (provided on the CD), which runs under Microsoft Windows 98, 2000, XP, Vista, 7 through the interface of RS-232 serial control.
- 2. Before you click the icon of the software, make sure you have made an RS232 connection between your computer COM port and the device and switched on the device (indicated by the illuminated LED on the front panel).

Support Software: Ver. 2.1 Support Firmware: Ver. 2.1

Start the Operation Software

When you click-on to open the *Setup_SDI Multiviewer.exe* file, the below dialog will pop-up. You can use two ways to control the SPLITMUX, RS-232 or Ethernet TCP/IP (under Microsoft Windows 7, see your network administrator to setup this program).

the "Connect" B	election conrectly, and push utton.
Port Selection:	R\$232 -
Serial COM Po	ot
Senar COM 10	
Port Number:	-
Port Number: Ethernet TCP/I	P Client Port:

RS-232 mode: Select the correct serial COM port (Port Number) and click the "**Connect**" button. --**OR**--

Ethernet (TCP/IP) mode: Enter the device IP address and click the "Connect" button.

With a successful connection the control interface will open.

Control Interface

1	}												
		Control Percent:	100 -	% 🖂		P 1	234		ut Resolu				3
	:						^		x 720 @	b0Hz			
								Audio	:		Ø		4
								BKG P	icture:		•		5
							E						
													6
								8	511 8	•	8		
								0	Window 1				
									Window 2		•		7
									Window 3		•	4	
								0	Window 4		-		
								Imag	e Visible:	🔲 Visible		- A	
							-	H Sta	urt:	0			
		< <u> </u>				1997000099701999	4	V Sta	ırt:	0	*		8
2			1 State		177			Widtl		200	* *		
			Sugar .					Heigl	ht:	200	A V		
	••••	•••••	•••••	•••••	•••••			\$	•••••	•••••			

1. PAP Panel

Display and adjust the window size, position.

In this part find several control tools for PAP panel setting:

- Output 1: 100 % Control percent: 10~100% to set the PAP panel display/control size.
- > Stretch: Fix the size ratio when the window is resizing.
- PAP mode (for customization)
- Window 1 in full screen
- Window 2 in full screen
- Window 3 in full screen
- > Window 4 in full screen

2. Tool Bar list:



- (1) Status: Get all information of the device and update this software state.
- (2) Port Setting: For setting up network connection.
- (3) Advance Setting: In this function, user can set the no signal color, fade in/out effect, background picture, window text, input text, OSD border, Clock, audio and factory reset.

-	trol Label Text Clock&Aud	lio OS · ·	System Output Control Lab	el Text Clock&Audio OS 🔸
System			-Output Control	
No Signal Co	lor:		Audio Mute:	Mute
📃 Display no	signal Label		Audio Selection:	Input 1 👻
📄 Fade In/Ou	ıt (Input Signal)			Apply
📄 Fade In/Ou	tt (Background Image)		Background Picture Con	
			10.57	Enable
	Арр	oly	Picture Enable:	
-All Windows C			Picture Selection:	Picture 1
Windows OSI		ff	Horizential Position:	Left •
Borders Blink	ing: On O	ff	Vertical Position:	Top 👻
				Apply
dvance Setting	[Advance Setting	
rstem Output Con	trol Label Text Clock&Aud			Close
rstem Output Con Window Custo	m Label			
stem Output Con Window Custo Window 1:	m Label Window		Label Text Clock&Audio	OSD Window Rotation Fac
stem Output Con Window Custo Window 1: Window 2:	m Label Window Window		Label Text Clock&Audio () Window Selection:	OSD Window Rotation Fac
stem Output Con Window Custo Window 1: Window 2: Window 3:	m Label Window Window Window		Label Text Clock&Audio Window Selection: Window OSD Control	OSD Window Rotation Fac
stem Output Con Window Custo Window 1: Window 2:	m Label Window Window		Label Text Clock&Audio Window Selection: Window OSD Control Window OSD:	DSD Window Rotation Fac
stem Output Con Window Custo Window 1: Window 2: Window 3:	m Label Window Window Window Window		Label Text Clock&Audio Window Selection: Window OSD Control Window OSD: Border:	OSD Window Rotation Fac
stem Output Con Window Custo Window 1: Window 2: Window 3: Window 4:	m Label Window Window Window Window		Label Text Clock&Audio Window Selection: Window OSD Control Window OSD: Border: Blinking (Tally):	OSD Window Rotation Fac
stem Output Con Window Custo Window 1: Window 2: Window 3: Window 4: Input Custom	m Label Window Window Window Window		Label Text Clock&Audio Window Selection: Window OSD Control Window OSD: Border: Blinking (Tally): Border Color:	OSD Window Rotation Fac
stem Output Con Window Custo Window 1: Window 2: Window 3: Window 4: Input Custom Input 1:	m Label Window Window Window Window		Label Text Clock&Audio Window Selection: Window OSD Control Window OSD: Border: Blinking (Tally): Border Color: Label Position:	DSD Window Rotation Fac
stem Output Con Window Custo Window 1: Window 2: Window 3: Window 4: Input Custom 1: Input 1: Input 2:	m Label Window Window Window Window		Label Text Clock&Audio Window Selection: Window OSD Control Window OSD: Border: Blinking (Tally): Border Color: Label Position: Window Text:	OSD Window Rotation Fac

➢ Clock and Audio:

User can set up the position of clock and other audio control.

Label 7	ext	Clock&A	udio	OSD	Window	Rotation	Fac	4
	Cloci	k Control						-
	Digi	tal Clock E	nable:		Enal	ole		
	Digi	tal Clock H	[Start:		0			
	Digital Clock VStart:				0			
						Apply		
	Digi	tal Back Co	olor:					
	Digi	tal Fore Co	lor:					
	Ana	log Clock H	Enable	:	Enable			
	Ana	log Clock H	HStart:		0			
	Ana	log Clock V	VStart:		0			
						Apply		
Ľ								

➤ Factory Reset:

Click the Factory Reset button to perform a factory default reset. This default reset process will take about 10~15 seconds and will initialize all settings to original system state.

Clock&Audio	OSD Window	Rotation	Factory Reset	4.3
The "Facts status, Am	ory Reset" will be I the process wou	e initial all s Id be cost l	etting to orignal 0~15 seconds.	
	32		2	
	Factory	Reset]	

3. Output Resolution:

Set the output resolution. When setting the different resolution, the parameters of PAP and custom layout (position and size) will change accordingly.

Output Resolution:
1280 x 720 @ 60Hz
1920 x 1200@60Hz
1920 x 1080@60Hz (SDI)
1920 x 1080@59.94Hz (SDI)
1920 x 1080@50Hz (SDI)
1920 x 1080@30Hz (SDI)
1920 x 1080@24Hz (SDI)
1680 x 1050@60Hz
1600 x 1200@60Hz
1440 x 900@60Hz
1366 x 768@60Hz
1280 x 1024@60Hz
1280 x 720@60Hz (SDI)
1280 x 720@59.94Hz (SDI)
1280 x 720@50Hz (SDI)
1024 x 768@60Hz
720 x 480@60Hz
800 x 600@60Hz
640 x 480@60Hz

4. Audio, analog clock and digital clock

Audio:	-	- C
	Mute	
	Input 1	
	Input 2	
	Input 3	
	Input 4	

5. Background picture:

BKG Picture:	-	
	Disable Picture	
	Enable Picture 1	
	Enable Picture 2	
	Enable Picture 3	
	Enable Picture 4	

6. Default layout and Custom layout:



layouts.



Custom layout: Use custom pre-saved video layouts.

Here you can adjust the size and position of the output screen. If you want to save the layout, click the right mouse button to save this layout to the SPLITMUX.



7. Window selection and input mapping

For each display window, user can assign arbitrary video input here. Besides, user also can adjust the order of windows.



8. Window setting

Here you can adjust the size, position or other settings of the specified window.

Image Visible:	🔲 Visible
H Start:	0
V Start:	0
Width:	200 🚔
Height:	200 🄶
	Apply
Window OSD:	📃 Enable
Border:	🔲 Visible
Blinking (Tally):	On Off
Border Color:	
Label Position:	Top - Left 🛛 👻
Window Text:	🔲 Visible
Custom WText:	📄 Enable
Input Text	🔲 Visible
Custom IText:	📄 Enable

WARRANTY

The warranty period on this product (parts and labor) is two (2) years from the date of purchase. Please contact Network Technologies Inc at **(800) 742-8324** (800-RGB-TECH) or **(330) 562-7070** or visit our website at <u>http://www.networktechinc.com</u> for information regarding repairs and/or returns. A return authorization number is required for all repairs/returns.