

User Manual

iTRAK System

Bulletin Number 2198T



Important User Information

Read this document and the documents listed in the additional resources section about installation, configuration, and operation of this equipment before you install, configure, operate, or maintain this product. Users are required to familiarize themselves with installation and wiring instructions in addition to requirements of all applicable codes, laws, and standards.

Activities including installation, adjustments, putting into service, use, assembly, disassembly, and maintenance are required to be carried out by suitably trained personnel in accordance with applicable code of practice.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



WARNING: Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence.

IMPORTANT

Identifies information that is critical for successful application and understanding of the product.

Labels may also be on or inside the equipment to provide specific precautions.



SHOCK HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.



BURN HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.



ARC FLASH HAZARD: Labels may be on or inside the equipment, for example, a motor control center, to alert people to potential Arc Flash. Arc Flash will cause severe injury or death. Wear proper Personal Protective Equipment (PPE). Follow ALL Regulatory requirements for safe work practices and for Personal Protective Equipment (PPE).

	Preface	
	About This Publication.....	5
	Audience.....	5
	Conventions Used in This Manual.....	5
	Studio 5000 Environment.....	5
	Appropriate Use.....	6
	For More Information.....	6
	Chapter 1	
Start	About the iTRAK System.....	7
	Typical Hardware Configuration.....	8
	Power Control Module Description.....	9
	Motor Module Description.....	11
	Mover Description.....	13
	Catalog Number Explanation.....	14
	Chapter 2	
Installation	Plan Your System Installation.....	15
	Before You Begin.....	15
	Protection Against Magnetic and Electromagnetic Fields During Mounting.....	16
	Avoid Accidents, Injury, and Property Damage.....	16
	Risk Assessment.....	17
	Install Your iTRAK System.....	17
	Before You Begin.....	17
	Install Track.....	18
	Install Power Control Module.....	19
	Install Gateway.....	20
	Connect Cables.....	20
	Chapter 3	
Connector Data	PCM Connectors.....	21
	Chapter 4	
Commission	Introduction.....	25
	Before You Begin.....	25
	Protection Against Magnetic and Electromagnetic Fields During Operation.....	26
	Configuration.....	27
	General.....	27
	Motion Group.....	28
	Ethernet Communication.....	30
	Understanding the iTRAK Sample Starter Project.....	32
	iTRAK Motion Task.....	32

	Main Task	35
	Trending.....	36
	Chapter 5	
Maintenance	Before You Begin.....	37
	Protection Against Contact with Hot Parts	37
	Add or Replace Components	38
	Install or Remove a Mover.....	38
	Replace a Motor Module	41
	Replace Mover Lubricators	44
	Replace Mover Bearing.....	45
	Lubrication	46
	Circuit Breakers.....	47
	Chapter 6	
Troubleshooting	Errors	49
	Appendix A	
Specifications and Dimensions	Environmental Specifications.....	55
	Weights	55
	Dimensions	57
	Appendix B	
Tags	Control Command Tags.....	65
	Appendix C	
Label Placement	Safety Labels	69
Index	71

About This Publication

This manual provides installation instructions for mounting, wiring, integration with a Logix5000™ controller, and troubleshooting for the iTRAK® system.

Audience

This manual is intended for engineers or technicians that are directly involved in the installation and wiring of the iTRAK system, and programmers who are directly involved in the operation, field maintenance, and integration of this system with the EtherNet/IP communication module or controller.

If you do not understand the basics of the iTRAK system, contact your local Rockwell Automation sales representative for information on available training courses.

Conventions Used in This Manual

These conventions are used throughout this manual: Bulleted lists provide information, not procedural steps. Numbered lists provide steps or hierarchical information.

Studio 5000 Environment

The Studio 5000 Automation Engineering & Design Environment™ combines engineering and design elements into a common environment. The first element is the Studio 5000 Logix Designer™ application. The Logix Designer application is the rebranding of RSLogix™ 5000 software and will continue to be the product to program Logix5000 controllers for discrete, process, batch, motion, safety, and drive-based solutions.



The Studio 5000® environment is the foundation for the future of Rockwell Automation® engineering design tools and capabilities. The Studio 5000 environment is the one place for design engineers to develop all of the elements of their control system.

Appropriate Use



ATTENTION: Incorrect use of the products can cause personal injury and property damage.

- Read and understand the safety instructions before using the iTRAK system and review [Label Placement on page 69](#).
- Hardware must remain in its original state; never make structural changes.
- Do not de-compile software or alter source codes.
- Do not use damaged or faulty components.
- Install the system in the manner that is described in this manual.
- Operate the system in the ambient conditions that are described in [Environmental Specifications on page 55](#).

For More Information

These resources contain information about related products from Rockwell Automation.

Resource	Description
1769 CompactLogix™ Controllers User Manual, publication 1769-UM011	Details how to configure, program, and operate a 1769 CompactLogix system, and provides technical specifications
ControlLogix® System User Manual, publication 1756-UM001	Details how to configure, program, and operate a 1756 ControlLogix system, and provides technical specifications
Industrial Automation Wiring and Grounding Guidelines, publication 1770-4.1	Provides general guidelines for installing a Rockwell Automation industrial system.
Product Certifications website, http://www.ab.com	Provides declarations of conformity, certificates, and other certification details.

You can view or download publications at <http://www.rockwellautomation.com/literature/>. To order paper copies of technical documentation, contact your local Allen-Bradley distributor or Rockwell Automation sales representative.

Start

Topic	Page
About the iTRAK System	7
Typical Hardware Configuration	8
Power Control Module Description	9
Motor Module Description	11
Mover Description	13
Catalog Number Explanation	14

About the iTRAK System

The iTRAK system is designed to provide an integrated Rockwell Automation motion solution. It combines the drive and motor/actuator into one component to simplify integration into your application

Table 1 - System Component Overview

iTRAK System Component	Description
Motor Module	The motor module is an integrated drive and motor coil unit, it is referred to as a section in the firmware. Motor modules are available in straight and curved orientations.
Track Frame	The track frame is designed for your specific application. The track frame in combination with straight and curved modules, and bearing rails creates the track.
Mover	The movers are passive magnetic components. They move along the track in response to the magnetic fields generated by the motor modules. You attach your application end effector to the mover.
Gateway	The Gateway provides communication interface between the Logix controller and all motor modules. It also provides more motion processing for the motor modules.
Logix5000 Controller Platform	CompactLogix 5370 controllers with Integrated Motion on the EtherNet/IP network, catalog numbers 1769-L3xERM. ControlLogix controllers, catalog number 1756-L7X with an Ethernet card.
Power Control Module (PCM)	The PCM accepts mains power and provides bus power for the motor modules and logic power for the Gateway and the motor modules. It has E-stop, guard, reset, monitoring functions. The PCM also has external connectors for connecting to a remote E-stop and monitoring station.
Studio 5000 Environment	Studio 5000 Logix Designer application, version 21 or later, provides support to program, commission, and maintain the CompactLogix and ControlLogix controller families that you use with iTRAK system.
Cables	Each motor module in the system has a communication cable that is connected directly to the Gateway. The power bus cables are daisy chained between the motor modules. The number of motor modules on one daisy chain is system-dependent. Use only the cables that are provided with your system and referenced in this user manual.

Typical Hardware Configuration

Figure 1 shows a typical iTRAK system. Your system can vary in the quantity and layout of each component, but all follow the same concept.

Figure 1 - Typical iTRAK System Configuration




Table 2 - System Component Description

Item	Description
1	Mover
2	Bearing rail
3	Straight motor module
4	Curved motor module
5	Power control module (PCM)
6	Gateway
7	Controller (sold separately)
8	Computer (not supplied with system)
9	EtherNet/IP communication cables
10	Communication cable to motor module (one cable per motor module)
11	PCM to Gateway power and communication
12	Motor module power bus (number of cables vary by system)
13	External monitoring, reset, guard stop, E-stop connections
14	Mains power (460V nominal)
15	Track frame

Power Control Module Description

[Figure 2](#) shows a typical power control module (PCM). Your system can differ in the layout and the number of connectors, but has the same components.

Figure 2 - Power Control Module





Table 3 - PCM Component Description

Item	Description
1	Emergency stop switch
2	Status indicators (x5)
3	Power cable in
4	Main power switch
5	Exhaust vent
6	Power bus connectors (quantity is system-dependent)
7	External emergency stop switch connector
8	External guard-switch connector
9	External reset-switch connector
10	External monitoring connector
11	PCM to Gateway communication connector
12	Intake vent (not shown)

Figure 3 - PCM Status Indicators**Table 4 - PCM Status Indicator Description**

Status Indicator	Description
RESET	This blue status indicator is off when bus power is unavailable or when the E-stop button is pressed or Shutdown routine is performed. After an E-stop condition, reset the E-stop button and press the Reset button to enable restoration of the bus power.
iTRAK "ON"	This yellow status indicator is on when iTRAK_Start command is executing in Logix Application Designer. It turns off after the iTRAK_Stop command is executed, E-stop is pressed, or shutdown operation is performed.
DC-CB	This blue status indicator lights when DC Line is high or when iTRAK system has 24V DC. It turns off when relays R1C and R2C are open or when circuit breakers CB02, CB03, or CB04 are tripped.
AC-CB	This blue status indicator lights when the AC Line is high. It turns off when relays R1B and R2B are open or when circuit breakers CB05, CB05A, CB06, or CB07 are tripped.
POWER "ON"	This white status indicator lights when the AC input line is high. It turns off when ESR, GSR, IC1 or IC2 are tripped.

If any of the status indicators do not light when expected, check the associated circuit breakers. See [PCM Circuit Breakers on page 48](#).



ATTENTION: The DC power bus capacitors have residual voltage for 5 minutes. Wait 5 minutes before attempting to service the PCM or the bus power cables.



ATTENTION: If the ESR and GSR safety relays appear to be faulty, contact Rockwell Automation for service. Do not attempt to service or repair ESR and GSR safety relays.



ATTENTION: If the braking resistors or the power supplies overheat, contact Rockwell Automation for service.

Motor Module Description

Your system has two types of motor modules. [Figure 4](#) shows the features of the straight and curved motor module.

Figure 4 - Straight and Curved Motor Modules





Table 5 - Motor Module Component Description


Item	Description
1	Straight motor module
2	Curved motor module
3	Position sensing surface (similar on curved motor module, not shown)
4	Motor module status indicator (similar on curved motor module, not shown)
5	Vent
6	Communication connector
7	Incoming bus connector
8	Outgoing bus connector
9	Drive and position sensor housing
10	Motor coil assembly

Figure 5 - Motor Module Status Indicators**Table 6 - Motor Module Status Indicator Description**

Item	Color	Status
A	Green	24V present
B	Blinking green	Module communicating
C	Orange	Voltage greater than 48V present

Mover Description

Figure 6 - Mover



Shown here is a one style of 50W x 100L mover. Your mover may look slightly different.

Table 7 - Mover Component Description

Item	Description
1	Lower bearing rail lubricator ⁽¹⁾
2	Bearing (x6)
3	Magnet assembly
4	Bumper (x3)
5	Upper-outer bearing rail lubricator ⁽¹⁾
6	Upper-inner bearing rail lubricator ⁽¹⁾
7	Position feedback magnet

(1) Your system specifications determine the number of movers with lubricators.




ATTENTION: Health hazard for persons with heart pacemakers, metal implants, and hearing aids in proximity to magnetic components.



ATTENTION: There is a pinch point hazard while handling a mover. A mover can have sudden and fast movement due to magnetic attraction. Do not put fingers between the mover, the motor module or other ferrous surfaces.

Catalog Number Explanation

Use the following key to identify your iTRAK system and its options.



Installation

Topic	Page
Plan Your System Installation	15
Before You Begin	15
Install Your iTRAK System	17

Plan Your System Installation

Choose the location for system components following these considerations:

- operator access to emergency stop switch on the power control module (PCM)
- operator and maintenance access to movers, motor modules, power control module, and gateway
- cable lengths
- vibration free surfaces

Before You Begin

Before you start the installation of the system, read the following to reduce the risk of injury and property damage.



WARNING: Improper use of these components, failure to follow the safety instructions, tampering with the product, or disabling of safety devices could result in property damage, injury, electric shock, or death.

- Proper transport, storage, mounting and installation, and care in operation and maintenance are prerequisites for optimal and safe operation of the system.
- Only qualified persons can work with components of the system or within their proximity.
- Use only Rockwell Automation approved accessories and spare parts.
- Use the components of the system only in the manner that is defined as appropriate. See [Appropriate Use on page 6](#)
- Follow the safety regulations and requirements of the country in which the system is operated.
- Commission the system only when the installation complies with the national regulations, safety specifications, and standards of the application.
- Only operate if the national Electromagnetic Compatibility (EMC) regulations for the application are met.

- In accordance with EMC requirements, the machine or installation manufacturer is responsible for compliance with the limit values as prescribed in the national regulations.

Protection Against Magnetic and Electromagnetic Fields During Mounting

See [Safety Label Placement on page 69](#) for location of [Strong Magnets](#) label.

The motor modules, when in use, and permanent motors magnets pose a danger to persons with heart pacemakers, metal implants, and hearing aids.



ATTENTION: There is a risk of health hazard for persons with heart pacemakers, metal implants, and hearing aids while in proximity of magnetic and magnetic-field producing components.

- The movers have strong magnets.
- The track creates strong magnetic fields while energized during operation.
- Persons with heart pacemakers, metal implants, or hearing aids must not enter the following areas.
 - Where components of the drive and control systems are mounted, commissioned, and operated.
 - Where parts of motors with permanent magnets are stored, repaired, or mounted.

Avoid Accidents, Injury, and Property Damage

- Mount emergency stop switches in the immediate reach of the operator.
- Keep free and clear of the range of motion of the machine and parts that move. Prevent personnel from accidentally entering the range of motion by using:
 - Safety fences
 - Protective coverings
 - Safety guards
- Safety fences and protective coverings must be strong enough to resist maximum kinetic energy of the system, See [Machine Guarding on page 17](#) and [Safety Label Placement on page 69](#) for location of [Automated Machinery](#) labels.
- Light barriers are not recommended without detailed risk assessment, due to the high kinetic energy of the movers.
- Secure vertical axes against falling after switching off the drive power by:
 - Mechanically securing the vertical axes
 - Adding an external braking, arrester, or clamp mechanism
 - Having sufficient equilibrium of the vertical axes.

- Avoid the operation of high-frequency, remote control, and radio equipment near system electronics and their power supply leads. If the use of these devices is necessary, check that they do not interfere or cause malfunctions in the machine operation. We recommend performing an electromagnetic compatibility test before putting the system into service.

Machine Guarding

The movers can have high acceleration and carry application loads. The movers experience more acceleration in the curved sections of the track due to vector directional changes. Machine guards and safety enclosures must be implemented to offer protection to personnel. The shielding and enclosure must be designed to protect against tangential projectiles along the system perimeter.

Risk Assessment

A risk assessment must be prepared for the installation of the machine, within its application conditions, and with the system components installed. As a result of the risk assessment, you must provide for monitoring functions and higher-level measurement for personal safety. The safety regulations applicable to the installation of the machine must be considered. Unintended machine movements or other malfunctions are possible if safety devices are disabled, bypassed or not activated.

Install Your iTRAK System

Use the following sections as guide for the installation. Your system can contain combinations of the panel cabinets that are shown in these procedures. See the system diagram that shipped with your equipment for details.

Before You Begin



ATTENTION: There is a risk of injury by improper handling. Injury by crushing, shearing, cutting, hitting can occur while handling system components.

- Observe the relevant statutory regulations of accident prevention.
- Use protective equipment such as hard hat, safety goggles, safety shoes, safety gloves while handling system.
- Use suitable equipment for mounting and transport.
- Use proper tools and use special tools if specified.
- Use hoist equipment and tools in the correct manner.
- Avoid jamming and crushing by using safety measures.
- Do not stand under loads.

Install Track


Do the follow to install the track or track sections.

1. Calculate the weight of the track or track section. See [Weights on page 55](#).


IMPORTANT Be sure that the lifting machinery can lift the load.

2. Make sure that the mounting surface supports the track evenly so that it is free of mechanical stress and distortion. Evenness of the mounting surface must be within 0.0508 mm (0.002 in.).
3. Unpack track sections within the crate so that the lifting slots are easily accessible.
4. Thread lifting straps through lifting slots as necessary for your installation and secure them to lifting machinery.

Lifting Strap Position for Horizontal Installation




Lifting Strap Position for Vertical Installation



5. Lift and transfer track section to its intended location.
6. Mount by using the M14 x 2 threaded holes or the slots in mounting plate.

We recommend using leveling feet at each mounting point. For example, Misumi Adjuster Feet - Resin Rubber Type, Misumi part number AJPDR16-100E.



7. If your system was shipped multiple segments, do the following, otherwise skip to next step.
 - a. Align track sections by using the shoulder bolt holes of the motor modules and the track frame.
 - b. Apply Loctite 243 (blue) to threads of M10 x 8 socket head cap screw shoulder bolts and secure the motor module to the adjacent track section.
 - c. Torque shoulder bolts to 13 N•m (9.6 lb•ft).
 - d. Insert bearing rail key in the end of a pre-installed bearing rail.
 - e. Place bearing rail on locator pins.

Bearing rails are scribed with the location identifiers. See mechanical installation drawing that is shipped with your system for placement.
 - f. Apply Loctite 243 (blue) to threads of M8 x 25 socket head cap screws, quantity as required, and secure the bearing rail.
 - g. Torque all bearing rail screws to 22 N•m (11.8 lb•ft).
8. Remove shipping clamps.

Install Power Control Module

IMPORTANT The 10 kVA PCM weighs approximately 100 kg (220 lb). Be sure the lifting machinery that is used can lift the load.

- Mount PCM to a solid vibration-free vertical surface.
- Secure by using all mounting holes inside the enclosure. See [Dimensions on page 57](#).
- Connect the system ground conductor to the main power supply.

- Before switching on the equipment, cables with a ground conductor must be permanently connected to all electric components in accordance with the connection diagram.
- Do not use residual-current-operated circuit breakers for drives.

Install Gateway

IMPORTANT	The gateway cabinet weighs approximately 27 kg (60 lb). Be sure to use a two man lift when installing the gateway cabinet.
------------------	--

- Mount the gateway cabinet to a solid vibration-free surface.
- Secure by using all four mounting holes in the enclosure.
- See [Dimensions on page 57](#).

Connect Cables

Your system comes with the power bus and communication cabling that is already connected to the motor modules. You make the final connections to the PCM and Gateway by using the system diagram that was delivered with your system.

1. Route power-bus cables to the PCM.

Use best practices to help protect cables from stress and damage during use of the system.

2. Connect power bus cables to the PCM.

Power bus cables are labeled with the PCM connector identifier on the end of each cable next to the SpeedTec connector.

Cap unterminated output power-bus connectors.

3. Route communication cables to the gateway.

Use best practices to help protect cables from stress and damage during use of the system.

4. Connect the communication cables to the gateway.

The communication cables are labeled with the gateway connector identifier on the end of each cable next to the RJ45 connector.

5. Secure the communication cables to the cable gland by using the cube modules.

6. Connect the PCM to mains power line.

Use minimum of 10 mm² (8 AWG) copper for the ground wire.

7. Connect your personal computer and your Allen-Bradley controller to the Gateway.

Connector Data

Topic	Page
PCM Connectors	21


PCM Connectors

The PCM has external connections to the E-stop, guard, reset switches, and monitoring capabilities. This section shows the wiring information that you can use to add more safety switches and monitoring capability.

The PCM connectors for external E-stop switch (P5), guard switch (P4), reset switch (P3), and monitor (P2), use the connectors that are supplied with the system.


[Figure 7](#) shows the pinouts for the reset connector.

Figure 7 - Reset Connector Pinout (P3)




[Figure 8](#) shows the schematic for the reset circuit.

Figure 8 - Reset Switch Circuit Schematic




[Figure 9](#) shows the pinout for the E-stop and guard connectors.

Figure 9 - E-Stop and Guard Connector Pinout (P4 and P5)




[Figure 10](#) shows the schematic for the E-stop circuit.

Figure 10 - E-Stop Switch Circuit Schematic (P5)



[Figure 11](#) shows the schematic for the reset circuit.

Figure 11 - Guard Switch Circuit Schematic (P4)



[Figure 12](#) shows the pinout for the monitor connector.

Figure 12 - Monitor Connector Pinout (P2)




Figure 13 shows the schematic for the monitor circuit.

Figure 13 - Monitor Circuit




Table 8 - Monitor Circuits Descriptions

Monitor (PCM status indicator)	Description
A	Bus voltage (0, 160V and 320V) is on
B	AC circuit breaker tripped
C	DC circuit breaker tripped
D	PCM main circuit breaker (CB01) is on

Figure 14 - PCM (P7) to Gateway (P6) Cable Connector Pinout

Pin	Signal
1	24V (CB 05, Gateway 1)
2	24V (CB 05A, Gateway 2)
3	24V (CB 06, Ethernet Hub)
4	PS02 Undervoltage
5	PS02 Option COM
6	PS02 Power Fail
7	PS02 Logic Return
8	PS01 Undervoltage
9	PS01 Option COM
10	PS01 Power Fail
11	PS01 Logic Return
12	PS01 Logic Inhibit
13	PS02 Logic Inhibit
14	iTRAK Power On/Off
15	24V (TB05, I/O USB)
16	24V Common (TB05C I/O USB)





Figure 15 - Power Bus Connector Pinout (IPxx)

Pin	Signal
A	320V DC
B	160V DC
C	0V DC
D	—
E	24V
F	24V Common
GND	PE



Commission

Topic	Page
Introduction	25
Configuration	27
Understanding the iTRAK Sample Starter Project	32

Introduction

Your iTRAK system Logix Designer application software includes a sample starter project that is called iTRAK_Start_XXXXX, for controller integration. This sample project was developed using the Studio 5000 environment Logix Designer application, version 21. The iTRAK system is compatible with Allen-Bradley controllers with built-in Ethernet or an Ethernet card that supports time synchronization or Integrated Motion on the EtherNet/IP network such as Bulletin numbers EN2T, EN2TR, EN3TR.

The controller implementation was designed for easy use by a Logix Designer application programmer. Each mover operates as one virtual axis within the system. One track loop is one revolution of a rotary axis and the coordinate system is mapped to millimeters. The mapping lets you use Logix Designer motion moves, jog, or stop commands, which normally control a rotary axis, to control the movers.

Before You Begin



ATTENTION: Before commissioning, verify that the emergency stop equipment works. Do not operate the machine if the emergency stop switch is not working.

Dangerous movements can occur immediately after power is applied or after an unspecified time of operation. The monitoring functions of the system are normally sufficient to avoid malfunction of the drives. Safety devices, for the protection of personnel from injury and property damage, cannot be relied upon until the integrated monitoring functions are made effective. Until integration is complete, you must assume that faulty drive movements can occur at anytime.



ATTENTION: The iTRAK system can produce dangerous movements. There is a danger to life and risk of serious injury while integrating the system.

See [Safety Label Placement on page 69](#) for location of [Automated Machinery](#) label.

Faulty control of motors can cause dangerous movements. Common examples are:

- Improper or wrong wiring or cable connection
- Operator errors
- Wrong input of parameters
- Malfunction of sensors and encoders
- Defective components
- Software or firmware errors

Protection Against Magnetic and Electromagnetic Fields During Operation

See [Safety Label Placement on page 69](#) for location of [Strong Magnets](#) label.

The motor modules, when in use, and permanent motors magnets pose a danger to persons with heart pacemakers, metal implants, and hearing aids.



ATTENTION: There is a risk of health hazard for persons with heart pacemakers, metal implants, and hearing aids while in proximity of magnetic and magnetic-field producing components.

- The movers have strong magnets.
- The track creates strong magnetic fields while energized during operation.
- Persons with heart pacemakers, metal implants, or hearing aids must not enter areas where components of the drive and control systems are mounted, commissioned, and operated.


Configuration

This section explains the steps required for integrating the iTRAK system into your control system. If you are using the sample starter project, these steps have already been completed and are shown for your information.

The communication between the controller and the Gateway is made via an Ethernet connection by using EtherNet/IP protocol.

General


1. Start the Logix Designer application.
2. From the Controller Organizer, double-click Controller iTRAK.



3. Click the Date/Time tab.
4. Check Enable Time Synchronization.

Checking Time Synchronization lets the controller participate in the ControlLogix TimeSynchronization or CIP Sync. The controller also participates in the election in the Logix5000 system for the best Grandmaster clock.

5. Click OK.




Motion Group


The movers are virtual axes in the Logix Designer application software.

IMPORTANT It is important that the number of axes in the Motion Group Axes match the number of axes set in iTRAK_Control.Data.ActiveMovers tag in the Controllers Tags.


1. From the Motion Group category, drag the number of axes that are needed from the Ungrouped Axes into your motion group.

In this Figure, 10 axes were moved to the Motion Group Axes.




2. Double-click Axes.


The Motion Group Properties - Axes dialog box is displayed.

3. Click the Attribute tab.**4. From the Coarse Update Period selector, choose a coarse update rate for the motion group.**

The sample application uses a 12 ms Coarse Update Period but your application can have much higher rates. The maximum estimated time of the Coarse Update Period is 24 ms because of reduced control capability.

5. Double-click Mover_00.

6. Click the Conversion tab.



7. Type 1000 in Conversion Constant field.

This sets an effective command resolution of 1 μm .

8. Type the value for Position Unwind.

The Position Unwind is the track length in microns.


9. Repeat steps 5 and 8 for all axes in the Motion Groups.

Other non-iTRAK system axes can be added to this Motion Group, such as the master axis used for camming. The sample starter project is configured in this way.

Ethernet Communication

Each generic Ethernet module connection type can accommodate up to 16 movers. Do the following steps to configure the number of Ethernet modules that are required for your system.


1. From the Controller Organizer, expand I/O configuration, then expand Ethernet.




2. Double-click ETHERNET-MODULE Gateway_Movers0to15.

3. Type Connection Parameters as follows.

Name	Assembly Instance			Size			IP Address
	Input	Output	Configuration	Input	Output	Configuration	
Gateway_Movers0to15	769	770	771	44	44	0	192.168.1.249
Gateway_Movers16to31	779	780	781	44	44	0	192.168.1.248
Gateway_Movers32to47	789	790	791	44	44	0	192.168.1.247
Gateway_Movers48to63	799	800	801	44	44	0	192.168.1.246
Gateway_Movers64to79	809	810	811	44	44	0	192.168.1.245
Gateway_Movers80to95	819	820	821	44	44	0	192.168.1.244



4. From the Comm Format pull-down menu, select Data DINT.
5. Click the Connection tab.
6. From the Requested Packet Interval (RPI) pull-down menu, select interval that is the same time as you are using for the coarse update rate for the iTRAK axes in the motion group.



7. Repeat steps 1 through 6 for ETHERNET-MODULE Gateway_Movers16to31 and the other ETHERNET-MODULES until you assign enough connections to accommodate the number of movers in the system.

Understanding the iTRAK Sample Starter Project


This section describes the iTRAK sample starter project.

iTRAK Motion Task

An Add-On Instruction that is named iTRAK_IO controls the iTRAK program communication to the Gateway. The iTRAK_IO Add-On Instruction is called by the HighSpeedTask task within the R00_iTRAK_IO routine. The parameters for this Add-On Instruction include the iTRAK_Control tag structure, all 16 axes, the Motion Group, and the input/output buffers of the Ethernet layer. This event is called every Coarse Update Period.

IMPORTANT Set the Coarse Update Period time high enough so the event calls do not overflow. Putting other programs in this event can cause the task to overflow and can cause errors such as #10 Headway Faults. We recommended that you place other user routines in another task with lower priority.

Figure 16 - HighSpeedTask



Normally, the headway checks are done in the Gateway to save processor time. The headway error is the difference between two axes command positions. You can do the same check within the controller, by going to routine R02_Headway Task Properties and setting Priority to 1. The check executes in this routine. Logging can be added to help debug the end-user program. Doing the check in the controller requires a much higher coarse update rate, otherwise overlaps occur. This routine also checks for overlaps.

Figure 17 - HighSpeedTask Task Properties





Figure 18 - Ladder Logic for R00_iTRAK_IO



All settings that control the iTRAK system are specified in the iTRAK_Control.Data tag which is automatically imported with the iTRAK_IO Add-On Instruction. These settings include important configuration data sent to the Gateway such as the track length, the number of movers, coarse update rate, and parameter in/out buffers.

Status information is in the iTRAK_Control.Status tag, such as the actual positions and position errors of the movers. More status data can be configured via the TraceData tag including torque and velocity.

Figure 19 - Controller Tags

Controller Organizer

- Controller iTRAK
 - Controller Tags
 - Controller Fault Handler
 - Power-Up Handler
- Tasks
 - HighSpeedTask
 - P01_iTRAK_Communications
 - Program Tags
 - R00_iTRAK_IO
 - R01_Headway
 - MainTask
 - P01_MainProgram
 - Unscheduled Programs / Phases
- Motion Groups
 - Axes
 - Ungrouped Axes
- Add-On Instructions
 - iTRAK_IO
 - LINTSUB
- Data Types
 - User-Defined
 - Strings
 - Add-On-Defined
 - Predefined
 - Module-Defined
- Trends
- I/O Configuration

Scope: iTRAK Show: All Tags

Name	Value	Force Mask	Style	Data Type
- iTRAK_Control	{...}	{...}		UDT_iTRAK_Control
+ iTRAK_Control.Cmd	{...}	{...}		UDT_iTRAK_Cmd
+ iTRAK_Control.Status	{...}	{...}		UDT_iTRAK_Status
- iTRAK_Control.Data	{...}	{...}		UDT_iTRAK_Data
+ iTRAK_Control.Data.TrackLength	4800000		Decimal	DINT
+ iTRAK_Control.Data.AxisUnwind	4800000		Decimal	DINT
+ iTRAK_Control.Data.ActiveMovers	10		Decimal	DINT
- iTRAK_Control.Data.MotionPolarity	0		Decimal	BOOL
+ iTRAK_Control.Data.NumberOfZones	1		Decimal	SINT
+ iTRAK_Control.Data.ZoneStartPosition	{...}	{...}	Decimal	DINT[2]
+ iTRAK_Control.Data.ZoneBeginReportOffset	{...}	{...}	Decimal	DINT[2]
+ iTRAK_Control.Data.ZoneBeginCommandOffset	{...}	{...}	Decimal	DINT[2]
+ iTRAK_Control.Data.ZoneBeginHoldOffset	{...}	{...}	Decimal	DINT[2]
+ iTRAK_Control.Data.ZoneEndReportOffset	{...}	{...}	Decimal	DINT[2]
+ iTRAK_Control.Data.ZoneEndCommandOffset	{...}	{...}	Decimal	DINT[2]
+ iTRAK_Control.Data.ZoneEndHoldOffset	{...}	{...}	Decimal	DINT[2]
+ iTRAK_Control.Data.ZoneLength	{...}	{...}	Decimal	DINT[2]
+ iTRAK_Control.Data.ParameterStatus	0		Decimal	SINT
+ iTRAK_Control.Data.ParameterCode	56		Decimal	INT
+ iTRAK_Control.Data.ParameterSize	6		Decimal	SINT
+ iTRAK_Control.Data.ParameterData	{...}	{...}	Decimal	INT[12]
- iTRAK_Control.Data.ParameterStatusReturn	1		Decimal	BOOL
+ iTRAK_Control.Data.ParameterCodeReturn	56		Decimal	INT
+ iTRAK_Control.Data.ParameterSizeReturn	0		Decimal	SINT
+ iTRAK_Control.Data.ParameterDataReturn	{...}	{...}	Decimal	INT[12]
+ iTRAK_Control.Data.MoverOffset	{...}	{...}	Decimal	DINT[96]
- iTRAK_Control.Data.RenumberMoversAtStart	1		Decimal	BOOL
+ iTRAK_Control.Data.SetGainsSectionNumber	0		Decimal	DINT
+ iTRAK_Control.Data.HeadwayTolerance	3		Decimal	DINT
+ iTRAK_Control.Data.StandstillWindow	0		Decimal	DINT
+ iTRAK_Control.Data.PositionErrorTolerance	75		Decimal	DINT
+ iTRAK_Control.Data.GainsAllVelocityBandwidth	10		Decimal	DINT
+ iTRAK_Control.Data.GainsAllVelocityIntegrator...	20		Decimal	DINT
+ iTRAK_Control.Data.GainsAllPositionBandwidth	50		Decimal	DINT
+ iTRAK_Control.Data.GainsAllPositionDerivative	2		Decimal	DINT
+ iTRAK_Control.Data.GainsAllAccelerationFeed...	50		Decimal	DINT

Monitor Tags Edit Tags

Main Task

The MainTask is where most of the motion programming occurs. The sample project contains routines under the MainTask task that are required to manage certain aspects of the iTRAK system. The following is a description of each routine and the routine function.

Figure 20 - Main Routine





Table 9 - Routine Description

Routine	Description
R00_Main	This routine is the jump point to the other routines in the program.
R01_PowerUP	This routine runs on first program scan and sets default conditions and parameters.
R02_Monitor	This routine monitors status of the track such as system faults and system readiness and can initiate actions as required.
R03_Start	This routine performs initialization tasks that are related to the start of the iTRAK system. It writes the gain values, rennumbers the movers, sets the trace data, and more. On completion of the routine the servo loops enables, DC Bus power is supplied to the track motor modules and the system is readied for motion.
R04_Stop	This routine initiates ServoOff and shutdown tasks that are related to the stop of the iTRAK system such as performing a controlled Group Stop of all axes.
R05_ParameterExchange	This routine configures data for writing down to the Gateway via the iTRAK_IO Add-On Instruction in the HighSpeedTask Task.

Trending

The Logix Designer application Trending feature is used with the iTRAK system. When using the Trending feature, it is important that you trend the feedback members in the iTRAK_Control tag for actual values.

Figure 21 - Trending Screen



IMPORTANT The Logix Designer application is a motion planner. The values from the axis tags are in future time. Feedback tags from the Gateway are actual values and are timed in the past. This scenario can create a lag between the two that appears in the trend. To synchronize them, use time interpolations and trend user tags.

Maintenance

Topic	Page
Before You Begin	37
Add or Replace Components	38
Lubrication	46
Circuit Breakers	47

Before You Begin

Before you attempt maintenance on the system do the following.

- Make sure that the movers are motionless.
- Disconnect electrical power to the system by using the master switch and lockout.

Protection Against Contact with Hot Parts



BURN HAZARD: Some components of the system have hot surfaces.

See [Safety Label Placement on page 69](#) for location of [Hot Surface](#) label.

- Do not touch hot surfaces such as brake resistors, heat sinks, power supply units, drive controllers, motors, windings, and laminated cores.
- Temperatures of the track motor-stator covers can be higher than 60° C (140° F) during or after operation.
- After powering down the motor modules, let them cool before touching. Motor modules can require 140 minutes to cool.
- After powering down switching chokes, power supply units, and drive controllers, let them cool for 15 minutes before touching.

Add or Replace Components

The following procedures show you how to install or replace system components.

Install or Remove a Mover

Follow this procedure to install or remove a mover.

Before You Begin



ATTENTION: Lockout and tagout input power before servicing.



ATTENTION: The mover uses strong magnets. The magnetic field that is generated can disrupt the functionality of automatic- implantable cardioverter defibrillators (AICD). People with cardiac pacemakers must not work near the iTRAK system. The strong magnets of the mover can attract metal objects that are in its proximity. When you handle and install, maintain distance between the mover and ferrous metal mounting surfaces or structures.

Maintenance personnel must avoid the use of metallic tools and secure items such as badge clips other personnel effect that could be attracted to the strong magnetic field.

Strong magnets can erase magnetic media. Never let credit cards or electronic media contact or come near the mover or iTRAK system.



ATTENTION: There is a pinch point hazard while installing a mover. A mover can have sudden and fast motion due to magnetic attraction. Do not put fingers between the mover and motor module.


What You Need

- 2.5 and 5 mm Allen-keys, and Phillips screwdriver
- Loctite 243
- Two mover installation fixtures
- A mover


Do the following to install a mover.

1. Prepare the mover for installation by doing the following.
 - a. Remove the position indicator magnet holder by using 2.5 mm Allen-key.

- b. Remove the felt lubricators by using 2.5 mm and Phillips screwdriver.



2. From one end of the track. Remove all socket head cap screw from the curved bearing rails on both sides of the track by using a 5 mm Allen-key.




IMPORTANT Do not loosen the four set screws at the ends of the curved bearing rail that hold the bearing rail keys in place.

3. Remove the curved bearing rails by pulling parallel to the track away from the straight bearing rails.




ATTENTION: Avoid bending the bearing key. Do not lift the curve bearing rail up until the bearing keys have cleared the ends of the straight bearing rail.




4. Attach mover installation fixtures.

At the end of straight bearing rails, attach mover installation fixtures to the track frame by using two socket head cap screws from the curved bearing rail.



5. Install mover.

Align the mover with the mover installation fixture and slide the mover on to the track.



6. Reinstall the position indicator magnet holder.

Check that the polarity of position magnets alternate between north and south on adjacent movers. You can check the polarity by examining the color of the magnets.

7. Reinstall the felt lubricators.

8. Remove the mover installation fixtures.

9. Clean all bearing rail screws and apply fresh Loctite 243.

10. Reinstall the curved bearing rail.

11. Torque all bearing rail screws to 22 N•m (11.8 lb•ft).

12. Align the straight and curve bearing rails by using the set screws on the ends of the curve bearing rail to within 0.0127 mm (0.0005 in).

Replace a Motor Module

Follow this procedure to replace a motor module.

Before You Begin



ATTENTION: Lockout and tagout input power before servicing.



BURN HAZARD: Do not touch hot surfaces such as motors, windings, and laminated cores.

Temperatures of the track motor module-stator covers can be higher than 60° C (140° F) during or after operation.

After powering down the motor modules, let them cool before touching. Motor modules can require 140 minutes to cool


See [Safety Label Placement on page 69](#) for location of [Hot Surface](#) label.

What You Need

- 6 mm Allen key
- Loctite 243
- A replacement motor module

Do the following to replace a motor module.

1. Remove the socket head cap screw that secure rails above and below the module you are replacing.




Item	Description
1	Upper rail
2	Module to be replaced

Item	Description
3	Lower rail
4	Socket head cap screws

2. Remove the socket head cap screws that secures the motor module to the top and bottom frames.

Support motor module while performing this step.



Item	Description
1	Motor module
2	Motor module shim
3	Shoulder socket head cap screws (x4)
4	Socket head cap screws (x4)

3. Remove motor module shim.
4. Slide motor module from frame and disconnect the communication and motor power-bus cables.
5. Clean all screws and apply Loctite 243.
6. Install new module by reversing these steps.
7. Torque shoulder bolt screws to 13 N•m (9.6 lb•ft) and torque M8 socket head cap screws to 22 N•m (16.2 lb•ft).

Replace Mover Lubricators

Before You Begin



ATTENTION: Lockout and tagout input power before servicing.



ATTENTION: The mover uses strong magnets. The magnetic field that is generated can disrupt the functionality of automatic- implantable cardioverter defibrillators (AICD). People with cardiac pacemakers must not work near the iTRAK system. The strong magnets of the mover can attract metal objects that are in its proximity. When you handle and install maintain distance between the mover and ferrous metal mounting surfaces or structures.

Maintenance personnel must avoid the use of metallic tools and secure items such as badge clips other personnel effect that could be attracted to the strong magnetic field.


Strong magnets can erase magnetic media. Never let credit cards or electronic media contact or come near the mover or iTRAK system.

What You Need

- 2.5 mm Allen key
- Loctite 243
- A set of replacement lubricators

Lubricators are replaced or added while the mover is on the track. Do the following to replace the lubricators.

1. Remove all three lubricators by using a 2.5 mm Allen-key.




Install lubricators while mover is on the track,
track not shown here for clarity.

2. Clean all screws and apply Loctite 243.
3. Install new lubricators.

Replace Mover Bearing

1. Remove mover by using [Install or Remove a Mover on page 38](#) as a guide.
2. Remove bearings by using a 17 mm socket wrench.



3. Clean all bolts and apply Loctite 243.
4. Attach new bearings to the mover.
5. Torque all bolts to 33 N•m (24 lb•ft).
6. Follow steps in [Install or Remove a Mover on page 38](#) to reinstall mover.

Lubrication

The bearings are an open system that requires continuous lubrication. To avoid breakdown of the lubrication, the bearings must have a film of oil on them. Typically indications of breakdown are discoloration and excessive wear on the inner and outer bearing surfaces. The interval to resupply the lubrication depends on the length of stroke, duty cycle, and environmental factors. Use 68 viscosity mineral oil, such as Kluber 4 UH1-68N, to lubricate the bearing rails.

To provide continuous lubrication we recommend that you design and supply an oil bleed system. The bearing rails come equipped with fittings for you to attach 4.0 mm O.D. x 2.5 mm I.D. tubing.

[Figure 22](#) shows the location of features that are provided for you to install your oil bleed lubrication system.

Figure 22 - Top Track Oil Bleed Fittings and Access




Figure 23 - Bottom Track Oil Bleed Fitting and Access




Table 10 - Oil Weep System Features

Item	Description	Item	Description
1	Bleed fitting	4	Oil tube feed through, between motor modules
2	Access to bleed fitting	5	Top frame
3	Bearing rail	6	Bottom frame

Circuit Breakers

Use [Figure 24](#) to locate circuit breakers in the PCM. Before accessing the PCM, read the following.



BURN HAZARD: Some components of the system have hot surfaces.

- Do not touch hot surfaces such as brake resistors, heat sinks, power supply units, drive controllers.
- After powering down switching chokes, power supply units, and drive controllers, let them cool for 15 minutes before touching.




SHOCK HAZARD: Before accessing electrical components with voltage potentials higher than 50V, disconnect them from the mains or power supply.

Wait 5 minutes after switching off power to let capacitors discharge. See [High Voltage \(capacitors\) on page 70](#).

Measure the voltage before working on components to make sure that they are safe to touch.

- Do not connect, disconnect, or touch electrical connections or components when power is applied.
- Only take measurements or test the operation of the system if a ground conductor is properly connected.

Figure 24 - PCM Circuit Breakers



Item	Description
7	CB01 AC Main Disconnect ⁽¹⁾
8	CB02, CB03 High-Voltage Supply Lines

Item	Description
4	CB06 24V Ethernet Switch
5	CB07 Fan
6	CB08...CB12 24V to Track Motor Modules

(1) Location is dependent on the presence of a panel disconnect interlock.

Troubleshooting

Topic	Page
Errors	49

Use the system reported errors in this section to diagnose iTRAK system problems.

Errors

The iTRAK system can generate errors from the Gateway or from the motor modules. The error codes are pushed from those devices to tags in the control structure. These error codes are in addition the Logix Designer application generated codes. Error codes from the motor module are displayed in iTRAK_Control.Status tag.

The codes are created from the following tags.

Table 11 - Error Code Tags

Tag	Description
iTRAK_Control.Status.GatewayFaultCode	This tag contains the error codes from the Gateway. In Table 12 it is referred to as the Gateway Code.
iTRAK_Control.Status.SectionFaultCode	This tag contains the error codes from the motor module. In Table 12 it is referred to as the Device Code.
iTRAK_Control.Status.FaultMessageLine1	This tag contains the first line of displayed text in the error code description.
iTRAK_Control.Status.FaultMessageLine2	This tag contains the second line of displayed text in the error code description.
iTRAK_Control.Status.SectionNumberFaulted	This tag indicates the motor module that failed.
iTRAK_Control.Status.SectionDeviceFaulted	This tag indicates if a motor module error is power-related or position related. 0 - position-related 1 - power-related
iTRAK_Control.Status.SectionFaultData	Helpful data to troubleshoot the error.

The error codes are described in [Table 12](#).

Table 12 - iTRAK System Error Codes

Gateway Code ⁽¹⁾	Device Code ⁽²⁾	Displayed Text ⁽³⁾	Description and Solution
3	20	ERR_VOLTS_LO: Section voltage is too low or off. Check Power Supply, Power Cables, Power Supply IO, etc. IF problem persists, Call FOR Service.	<p>This error indicates that the motor module has lost high voltage on one or both of its buses. The following are possible causes:</p> <ul style="list-style-type: none"> Loose cables Module incorrectly wired Power supply has faulted <p>The iTRAK_Control.Status.SectionNumberFaulted tag contains the motor module that is reporting this fault.</p> <p>The iTRAK_Control.Status.SectionFaultData tag indicates the bus that has failed.</p> <p>If the iTRAK_Control.Status.SectionFaultData tag =</p> <p>0, then the high voltage rail is lower than 35V.</p> <p>1, then the common rail is lower than 17V.</p> <p>3, then the voltage of the common rail is less than ¼ of the high voltage rail.</p> <p>Other values, then the PWM board in this motor module has no current, call for service.</p> <p>Check power supply and power cables. Reset power supply.</p>
	21	ERR_VOLTS_HI: Section voltage is too high. Emergency shunting has been activated. Check Power Supply AND Shunt Regulator. Call FOR service	<p>This error indicates that the motor module voltage is too high.</p> <p>The iTRAK_Control.Status.SectionNumberFaulted tag contains the motor module that is reporting this fault.</p> <p>If the iTRAK_Control.Status.SectionFaultData tag =</p> <p>0, then the high voltage rail is higher than 509V.</p> <p>1, then the common rail is higher than 254V.</p> <p>2, then the voltage of the common rail is greater than 9/10 of the high voltage rail.</p> <p>Other values, then the voltage of motor module exceeds the safety range.</p> <p>Check power supply and power cables. Reset power supply.</p>
9	0	Fault_FieldBusSys - Sign of Life between controller and gateway has been lost. Increase sync period AND check cables.	<p>This error indicates the EtherNet/ IP connection between the controller and the Gateway has dropped. The following are possible causes:</p> <ul style="list-style-type: none"> The Ethernet module's time Sync is not configured for Time and Motion in the .acd file. The controller is not configured for Time Synchronization in the .acd file. The Ethernet connection to the gateway may need to be manually reset. <ul style="list-style-type: none"> a. Unplug the Ethernet cable from the gateway. b. Cycle the power on the gateway, wait 3...4 minutes until the gateway powers up. c. Reconnect the Ethernet cable. Unshielded cables Bad switch Faulty hardware Overuse of Logix Designer application trending <p>Turn off application trending. Check cabling.</p>
10	0	Headway Fault. Two movers cmd or actual pos is under headway setting. Increase amt	<p>This error indicates that at the end of the next Coarse Update Period two movers can crash into each other. The follow are possible causes:</p> <ul style="list-style-type: none"> Two motion commands are not synchronized to run in the same Coarse Update Period. A mover was applied over another mover. Tasks have overlapped and cannot finish in allocated time. <p>The iTRAK_Control.Status.SectionNumberFaulted tag contains the motor module that is reporting this fault.</p> <p>If the iTRAK_Control.Status.SectionFaultData tag =</p> <p>0, then the headway fault happened between mover 0 and the mover with the largest mover number.</p> <p>7, then the fault is not triggered by neighbor movers.</p> <p>Check for task overlaps. Verify proper motion instruction execution order.</p>
11	0	Wrong Number of movers reported. A mover has been lost on the system or the wrong number specified in the active axis tag. Check magnets or re-number with HMI tag.	<p>This error indicates the following:</p> <ul style="list-style-type: none"> The number of movers exceeds the maximum number that is specified in the iTRAK_Control.Data.ActiveMovers tag. A mover was lost in the middle of the track. <p>If the iTRAK_Control.Status.SectionFaultData tag =</p> <p>0, then the number of movers specified in the Logix Designer application doesn't match the number of movers actually found.</p> <p>7, then upon start-up, the movers were not found in the same positions as they were when the track was shut down. Renumber the movers.</p> <p>Check position magnets. Check specified movers and licenses. Check track for debris.</p>

Table 12 - iTRAK System Error Codes

Gateway Code ⁽¹⁾	Device Code ⁽²⁾	Displayed Text ⁽³⁾	Description and Solution
12	0	Fault_InternalComm - Data could not be written to sections.	<p>This error indicates that a motor module is not responding to commands. The following are possible causes:</p> <ul style="list-style-type: none"> • Low-voltage power loss • Communication cables are not connected • Communication cables are loose <p>The iTRAK_Control.Status.SectionNumberFaulted tag contains the motor module that is reporting this fault.</p> <p>If the iTRAK_Control.Status.SectionFaultData tag = 0, then writing data to a motor module failed.</p> <p>1, then the motor module received too many communication errors.</p> <p>2, then the force command was not received or the neighborhood command was not received.</p> <p>Check power connections. Cycle power.</p>
	2	ERR_OVERCURRENT_FAULT: Section has an overcurrent fault. Reset system.	<p>This error indicates that the current in the motor module has risen to an unacceptable level.</p> <p>The iTRAK_Control.Status.SectionNumberFaulted tag contains the motor module that is reporting this fault.</p> <p>The iTRAK_Control.Status.SectionDeviceFaulted tag is the PWM board number.</p> <p>The iTRAK_Control.Status.SectionFaultData tag is the bad coil.</p> <p>Verify that the sizing of system is correct. Reduce the acceleration and deceleration.</p>
	6	ERR_WAYWARD_ISR: Section is reporting an Wayward ISR fault. Call FOR service.	<p>This error indicates an electronics failure in a motor module.</p> <p>The iTRAK_Control.Status.SectionNumberFaulted tag contains the motor module that is reporting this fault.</p> <p>Replace the failed module.</p>
	7	ERR_SENSOR_TIMEOUT:Section is reporting a sensor hardware fault.Call for service.	<p>This error indicates a failure in the position sensing hardware.</p> <p>The iTRAK_Control.Status.SectionNumberFaulted tag contains the motor module that is reporting this fault.</p> <p>Replace the failed module.</p>
	8	ERR_INVALID_PKT: Section received an invalid packet. Reset system.	<p>This error indicates a failure in communication from the Gateway to the motor module.</p> <p>The iTRAK_Control.Status.SectionNumberFaulted tag contains the motor module that is reporting this fault.</p> <p>If the iTRAK_Control.Status.SectionFaultData tag < 12, then the iTRAK_Control.Status.SectionFaultData tag has a gain which is 0.</p> <p>If the iTRAK_Control.Status.SectionFaultData tag ≥ 12, then the default gains are being used.</p> <p>Check the cable and reset the system.</p>
	12	ERR_UART_BREAK: Section communication error. Check. cable. Reset system.	<p>This error indicates communication failure between the Gateway and a motor module.</p> <p>The iTRAK_Control.Status.SectionNumberFaulted tag contains the motor module that is reporting this fault.</p> <p>The iTRAK_Control.Status.SectionDeviceFaulted tag = The PWM board number.</p> <p>Check the cable. Reset the system.</p>
	14	I2T Error: A coil or all coils have been on for too long for heat. ExtraData=Coil	<p>This error indicates that there is something physically wrong with the track. The following are possible causes:</p> <ul style="list-style-type: none"> • The movers path is physically impeded • Bearings are binding • A motor module is loosely mounted • General over all performance is low <p>The iTRAK_Control.Status.SectionNumberFaulted tag contains the motor module that is reporting this fault.</p> <p>If the iTRAK_Control.Status.SectionFaultData tag < 12, then the coil with number equal to iTRAK_Control.Status.SectionFaultData is overheated, stop the system.</p> <p>If iTRAK_Control.Status.SectionFaultData tag = 12, then overcurrent has run for too long.</p> <p>Check track path and cables or reduce motion profile demands.</p>

Table 12 - iTRAK System Error Codes

Gateway Code ⁽¹⁾	Device Code ⁽²⁾	Displayed Text ⁽³⁾	Description and Solution
12	15	ERR_CHECKSUM: Section communication error. Check comm. cable. Reset system.	<p>This error indicates a communication failure between the Gateway and a motor module. The iTRAK_Control.Status.SectionNumberFaulted tag contains the motor module that is reporting this fault.</p> <p>If the iTRAK_Control.Status.SectionFaultData tag = 2, 4, 6, 7, 8, 9, 10, or 11, then iTRAK_Control.Status.SectionFaultData is the communications packet ID number on which the checksum error occurred.</p> <p>If the iTRAK_Control.Status.SectionFaultData tag =</p> <p>3, then the packet is not from the gateway.</p> <p>5, then the packet received is not for this motor module.</p> <p>13, then the packet received is not good.</p> <p>14, then the size of the packets exceeds maximum size.</p> <p>100, then there were ten communication errors in a row.</p> <p>109 ... 112, then replace motor module.</p> <p>Check the communication cable and reset the system.</p>
	16	ERR_POS_RANGE: Position Sensor error. Indicates electrical fault. Extra Data indicates which sensor. Call FOR service.	<p>This error indicates a failed position sensor.</p> <p>The iTRAK_Control.Status.SectionNumberFaulted tag contains the motor module that is reporting this fault.</p> <p>The iTRAK_Control.Status.SectionFaultData tag is the number of the sensor whose analog-to-digital converter is out of range.</p> <p>Replace the failed motor module.</p>
	17	ERR_CUR_RANGE: Current Sensor error. Indicates electrical fault.	<p>This error indicates a failed current sensor.</p> <p>The iTRAK_Control.Status.SectionNumberFaulted tag contains the motor module that is reporting this fault.</p> <p>The iTRAK_Control.Status.SectionFaultData tag contains the failed sensor.</p> <p>If iTRAK_Control.Status.SectionFaultData < 20, then iTRAK_Control.Status.SectionFaultData is the number of the coil that has a failed sensor.</p> <p>If iTRAK_Control.Status.SectionFaultData >= 20, then (iTRAK_Control.Status.SectionFaultData - 20) is the number of the coil that has a failed sensor.</p> <p>Replace the failed motor module.</p>
	18	ERR_PCB_TEMP: Drive overtemperature fault. Check mover bearings, venting, reduce motion profile demands. IF problem persists, call FOR service.	<p>This error indicates that the electrical boards are warm. This error is usually the result of failed mechanical part that caused the motor to over work and transfer heat.</p> <p>The iTRAK_Control.Status.SectionNumberFaulted tag contains the motor module that is reporting this fault.</p> <p>The iTRAK_Control.Status.SectionFaultData tag is the temperature of the device.</p> <p>Check mover bearings, vents, or reduce motion profile demands.</p>
	22	ERR_PWRSTAGE_TEMP: Power stage is overtemperature. Check mover bearings, venting, reduce demands. IF problem persists, call FOR service.	<p>Power stage is overtemperature.</p> <p>The iTRAK_Control.Status.SectionNumberFaulted tag contains the motor module that is reporting this fault.</p> <p>The iTRAK_Control.Status.SectionFaultData tag is the amplifier module reporting this fault.</p> <p>Check mover bearings, venting or reduce demands.</p>
	23	ERR_ONE_BAD_COIL: Power on Self Test indicates at least one coil is bad. Extra daa indicates Coil. System may still run. Call FOR servicet	<p>There is a bad coil.</p> <p>The iTRAK_Control.Status.SectionNumberFaulted tag contains the motor module that is reporting this fault.</p> <p>The iTRAK_Control.Status.SectionFaultData tag contains the number of the bad coil.</p>
	24	ERR_TOO_MANY_BAD_COILS: Power on Self Test indicates at multiple coils are bad. System will NOT run. Call FOR Service	<p>There are too many bad coils.</p> <p>The iTRAK_Control.Status.SectionNumberFaulted tag contains the motor module that is reporting this fault.</p> <p>The iTRAK_Control.Status.SectionFaultData tag contains the number of the first bad coil. Call service to replace the module.</p>

Table 12 - iTRAK System Error Codes

Gateway Code ⁽¹⁾	Device Code ⁽²⁾	Displayed Text ⁽³⁾	Description and Solution
12	25	N/A	Nonvolatile memory operations failed. The iTRAK_Control.Status.SectionNumberFaulted tag contains the motor module that is reporting this fault. If the iTRAK_Control.Status.SectionFaultData tag = 30, then the erase Hold Buffer failed. 31, then the received data is too small, missed block, changed in the number of blocks, wrong block size, or wrong byte size. 32, then the burn Hold Buffer failed. 33, then the received data did not match.
16	0	The gateway EIP connection was interrupted. If persists repower gateway.	The gateway has been restarted, either internally, or by your request via the iTRAK_Control.Cmd.ResetGateway tag. If the gateway continues to reset itself after the first time, cycle the power. If the problem persists after a power cycle, call for service.
17	0	Position Window Err: a mover is outside its position window. Check or increase win	This error indicates that a mover is no longer within the window between the command and actual position as specified by the position window tag in the HMI. The causes can be the following: <ul style="list-style-type: none"> • Mechanical failure • Over-aggressive programming • The following error set too low in the HMI. The iTRAK_Control.Status.SectionNumberFaulted tag contains the mover that is reporting this fault. Check or increase the position window.
18	0	Sections are not connected correctly or too many movers reported or NOT communicating or wrong track length	This error indicates that there is a difference in track length or number of active axes as downloaded from the control structure than what the Gateway is reporting. It could be caused by any of the following conditions: <ul style="list-style-type: none"> • The control tags are set incorrectly. • The motor modules are improperly cabled. • Foreign magnetic material on the track is adding an extra mover. • If there is a newly installed motor module on the track, this error can indicate the firmware in the newly-installed motor module does not match the firmware for the mover type that is specified for that track. If the iTRAK_Control.Status.SectionNumberFaulted tag = 0, then the track length specified in iTRAK_Control.Data.TrackLength doesn't match the track length calculated by the gateway. Otherwise, iTRAK_Control.Status.SectionNumberFaulted tag contains the motor module reporting this fault.

(1) Error codes from the Gateway are displayed in iTRAK_Control.Status.GatewayFaultCode.

(2) Error codes from the motor module are displayed in iTRAK_Control.Status.SectionFaultCode.

(3) Displayed text is from iTRAK_Control.Status.FaultMessageLine1 and iTRAK_Control.Status.FaultMessageLine2.

Notes:

Specifications and Dimensions

Topic	Page
Environmental Specifications	55
Weights	55
Dimensions	57

Environmental Specifications

Table 13 - Environmental Specifications for Straight and Curve Modules

Attribute	Value
Ambient temperature	0...40 °C (32...104 °F)
Storage temperature	-30...70 °C (-22...158 °F)
Relative humidity	5...95% non condensing
Shock	15 g peak, 11 ms duration ⁽¹⁾
Vibration	2 g sine peak @ Hz, 5...500Hz ⁽²⁾

(1) Tested to operate with 3 pulses in the positive direction, 3 pulses in the negative direction, along the X,Y, and Z axes.

(2) Tested to operate for 2 hours along the X,Y, and Z axes.

Weights

Table 14 - Straight Modules Weights, Approx

Frame Size	Weight, approx
50	15 kg (33 lb)
100	20 kg (43 lb)
150	25 kg (54 lb)

Table 15 - Curve Modules Weights, Approx

Frame Size	Weight, approx
50	17 kg (38 lb)
100	23 kg (51 lb)
150	29 kg (64 lb)

Table 16 - Track Weights, Approx

Frame Size	Weight, approx
50	123 kg/m (83 lb/ft)
100	156 kg/m (105 lb/ft)
150	189 kg/m (127 lb/ft)

Table 17 - Other Component Weights, Approx

Component	Weight, approx
Power Control Module	100 kg (220 lb)
Gateway	27 kg (60 lb)

Dimensions

Figure 25 - Power Control Module Dimensions

Dimension are in mm (in.)




Figure 26 - Gateway Dimensions




Figure 27 - Straight Motor Module Dimensions





Figure 28 - Curved Motor Module Dimensions

Dimension are in mm (in.)



Motor Width	Assembled Width mm (in.)
50 mm	114.3 (5.0)
100 mm	151.3 (6.0)
150 mm	201.3 (7.9)

Figure 29 - 50 Length Mover Dimensions

Mover	A	B	C	D
50W x 050L	242.5 (9.6)	120 (4.7)	60 (2.4)	177.4 (7.0)
100W x 050L	279.5 (11.0)	150 (5.9)	75 (3.0)	214.4 (8.4)
150W x 050L	329.5 (13.0)	180 (7.1)	90 (3.5)	264.4 (10.4)

Ref dimensions are approximate




Figure 30 - 100 Length Mover Dimensions

Mover	A	B	C	D
50W x 100L	248.5 (9.8)	120 (4.7)	60 (2.4)	177.4 (7)
100W x 100L	285.5 (11.2)	150 (5.9)	75 (3.0)	214.4 (8.4)
150W x 100L	335.5 (13.2)	180 (7.1)	90 (3.5)	264.4 (10.4)

Ref dimensions are approximate





Figure 31 - 150 Length Mover Dimensions

Mover	A	B	C	D
50W x 150L	249.5 (9.8)	120 (4.7)	60 (2.4)	177.4 (7)
100W x 150L	286.5 (11.3)	150 (5.9)	75 (3.0)	214.4 (8.4)
150W x 150L	336.5 (13.2)	180 (7.1)	90 (3.5)	264.4 (10.4)

Ref dimensions are approximate

Dimension are in mm (in.)



Notes:

Tags

Topic	Page
Control Command Tags	65

Control Command Tags

The following tags are in the iTRAK_Control.Cmd structure, they describe the tracks configuration and operation.

Table 18 - iTRAK_Control.Cmd Tags

Tag Name	Description
TrackStart	No longer used (legacy).
TrackStop	No longer used (legacy).
ServoOn	Enable servo. Power up the track and hold mover position.
ServoOff	Disable servo. Power down the track and remove mover control. This tag is not a controlled stop. If controlled stop is desired, use motion group stop instructions.
ReportPositionOutsideZone	This tag is used for hybrid tracks. It tells the Gateway to report back to the Virtual Axis position if it is outside a zone. It lets you track positioning all round the track by gearing movers to other axes in simple areas of the track.
FeedbackUpdateOff	This tag tells the Add-On Instruction to report only the Actual Position to the Control Tags. By not updating other feedback tags, the Add-On Instruction scan time is greatly reduced.
FaultReset	Reset active fault.
RunMoverRegistration	Run mover registration (Future).
TraceSelect	Select trace data.
iTRAK_Stop	Initiate shutdown tasks and disable track.
iTRAK_Start	Start initialization tasks and enable track.
ResetGateway	Initiate a Gateway reset and the power-on self-test. It can take several minutes for the Gateway to reset.
RenumberMovers	Initiate a renumbering of the track movers. Perform after homing if you need to start with a particular mover number, if there are odd and even movers, or if multiple zones exist and they cleared all simple areas except the first movers. Only the first simple area after the first smart zone can have movers on it at startup.
FlashSections50mm	Update track motor modules with 50 mm firmware.
FlashSections100mm	Update track motor modules with 100 mm firmware.
FlashSections150mm	Update track motor modules with 150 mm firmware.
SetGainsAll	Initiate download of tuning values to all straight and curved motor modules.
SetGainsCurves	Initiate download of tuning values to all curved motor modules.
SetGainsSections	Initiate download of tuning values to an individual motor module.
GetGainsAll	Read gain values.

Table 19 - TRAK_Control.Data Tags

Tag Name	Description	Range
TrackLength	Total track length in μm .	—
AxisUnwind	Axes unwind length in μm . Set to same value as axis unwind in the axis properties dialog.	—
ActiveMovers	Total number of active movers on the track.	1...96
MotionPolarity	This tag controls the direction of motion for the track. 0 - forward motion 1 - reverse motion	—
ReverseMoverNumbering	This tag controls the numbering order of the movers on the track. 0 - The mover with the greatest initial position on the track is labeled as Mover 0, the second greatest as Mover 1, movers are labeled consecutively with mover numbers continuing in this manner until all movers are numbered. 1 - The mover with the smallest initial position on the track is labeled as Mover 0, the second smallest as Mover 1, movers are labeled consecutively with mover numbers continuing in this manner until all movers are numbered.	—
PositionOffset	This tag is used to change the zero position of the track. This tag value, in μm , is added the mover positions.	- TrackLength ... + TrackLength
MoverNumberingOffset	This tag can be used to change the mover numbering. This tag value is added to each of the mover numbers.	- ActiveMovers ... + ActiveMovers
NumberOfZones	This tag tells the number of zones in the track. For all intelligent tracks, there is only one zone. The limited is two zones.	—
ZoneStartPosition	Start position of zone in μm .	—
ZoneBeginReportOffset	Position movers are reported in zone in μm . In most cases, this value is zero.	—
ZoneBeginCommandOffset	Position movers start to accept commands in zone in μm .	—
ZoneBeginHoldOffset	The position that movers start to hold position in zone in μm .	—
ZoneEndHoldOffset	The position that a mover no longer hold position in zone in μm .	—
ZoneEndCommandOffset	The position that a mover no longer accept commands in zone in μm .	—
ZoneEndReportOffset	The position that a mover no longer be reported in zone in μm .	—
ZoneLength	Zone length in μm .	—
ParameterStatus	Parameter data ready for downloaded to Gateway.	—
ParameterCode	Parameter data code.	—
ParameterSize	Parameter data size.	—
ParameterData	Parameter data.	—
ParameterStatusReturn	Parameter data ready for upload from Gateway.	—
ParameterCodeReturn	Parameter data return code.	—
ParameterSizeReturn	Parameter data return size.	—
ParameterDataReturn	Parameter data return.	—
MoverOffset	Mover offset of magnet sensor relative to motor magnet stack.	—
HeadwayTolerance	Mover to mover tolerance in mm. If movers are commanded less than this value, an error occurs.	—
RenumberMoversAtStart	Renumber movers at start.	—
SetGainsSectionNumber	Individual motor module number to set gains.	—
StandstillWindow	Standstill window setting in μm . The difference that is acceptable to begin reducing the gains until the power driving the mover shuts off.	—

Table 19 - TRAK_Control.Data Tags (continued)

Tag Name	Description	Range
PositionErrorTolerance	Position error tolerance setting in mm. The difference between command position and actual position.	—
GainsAllAccelerationFeedForward	This gain is a multiple of the difference between two velocity commands. The normal value is 50.	3...90
GainsAllPositionDerivative	This gain is a constant multiple of the position error. The normal value is 5.	0...8,
GainsAllPositionBandwidth	This gain is a constant gain multiple of the position error. The normal values are 75...125.	50...275
GainsAllVelocityIntegratorBandwidth	This gain is a percentage of the velocity error, usually twice the Velocity Bandwidth. The normal values are 10...30.	3...40
GainsAllVelocityBandwidth	This gain is a multiple of the velocity error. The normal values are 5...15.	3...20
GainsCurvesPositionDerivative	This gain is a constant multiple of the position error. The normal value is 5.	0...8
GainsCurvesPositionBandwidth	This gain is a constant gain multiple of the position error. The normal values are 75...125.	50...275
GainsCurvesVelocityIntegratorBandwidth	This gain is a percentage of the velocity error, twice the Velocity Bandwidth. The normal values are 10...30.	3...40
GainsCurvesVelocityBandwidth	This gain as a multiple of the velocity error. The normal values are 5...15.	3...20
GainsCurvesGravityKg	For vertical tracks, specify the weight of the mover, the tooling, and the payload here. If the zero position of the track is on the bottom, this value can be negative. If the zero position of the track is on the top, this value can be positive. On a flat or horizontal track, enter zero for this value. This value is used to offset the effect of gravity.	—
GainsSectionPositionBandwidth	This gain is constant gain multiple of the position error. The normal values are 75...125.	—
GainsSectionVelocityIntegratorBandwidth	This gain is a percentage of the velocity error, usually twice the Velocity Bandwidth. The normal values are 10...30.	—
GainsSectionVelocityBandwidth	This gain as a multiple of the velocity error. The normal values are 5...15.	—

Table 20 - iTRAK_Control.Status Tags

Tag Name	Description
CoarseUpdatePeriod	Motion Group coarse update period in μ s. Set to the same as in the Motion Group properties dialog.
GatewayFaultCode	Gateway fault code.
SectionNumberFaulted	Motor module that has a fault.
SectionFaultCode	Motor module fault code.
SectionDeviceFaulted	Motor module fault pointer. Values are 0 - position-related, 1 - power related.
SectionFaultData	Motor module additional fault data.
FaultMessageLine1	Fault message line 1.
FaultMessageLine2	Fault message line 2 (if necessary).
CSTTimeActualPositionRecorded	This tag is a CST time that the Actual Position data was captured in the groups of 16 movers. Use this time to synchronize with other EtherNet/IP time-based devices.
ActualPosition	This tag is the Actual Position that was last reported to the Add-On Instruction in the Ethernet buffer.
PositionError	Difference between Command Position and Actual Position.
TraceData	Trace data-data is not synchronized.
GatewayRunning	Gateway running and communicating.

Table 20 - iTRAK_Control.Status Tags

Tag Name	Description
Faulted	Track has a fault.
ReadyForMotion	Track is ready for motion commands.
DCBusContactor	Command status of DC bus contactor.

Label Placement

Topic	Page
Safety Labels	69

Safety Labels

The following safety-identification labels are affixed to the iTRAK system. To prevent injury and damage to the system, review the safety labels, their details, and locations before using the system.

Figure 32 - Safety Label Placement










Table 21 - System Components with Safety Labels

Item	Component Name
1	Straight Motor Module
2	Curved Motor Module (left and right modules are labeled the same)
3	Mover
4	Power Control Module

Table 22 - Safety Labels

Title	Location	Label	Details
Hazardous Voltage	A		Do not open motor module covers or right angle connectors while the cables are connected. Lock out-tag out if access to the motor module is required during maintenance while the connectors are installed.
Strong Magnets	B		<p>The mover uses strong magnets. The magnetic field that is generated can disrupt the functionality of automatic- implantable cardioverter defibrillators (AICD). People with cardiac pacemakers must not work near the iTRAK system. The strong magnets of the mover can attract metal objects that are in its proximity. When you handle and install maintain distance between the mover and ferrous metal mounting surfaces or structures.</p> <p>Maintenance personnel must avoid the use of metallic tools and secure items such as badge clips other personnel effect that could be attracted to the strong magnetic field.</p> <p>Strong magnets can erase magnetic media. Never let credit cards or electronic media contact or come near the mover or iTRAK system.</p>
Hot Surface	C		Indicates that the surface can be hot enough to burn if touched.
Automated Machinery	D		Movers and make as sudden and unexpected movements while the system is powered. Lock-out/tag out before servicing.
High Voltage	E		The power control module can have voltages greater than 240V present inside the cabinet and at the connectors.
High Voltage (capacitors)	F		The capacitors inside the PCM can have high voltage present for 5 minutes. Do not attempt to service the PCM until 5 minutes after power has been removed.

A

application mounting 61, 62, 63
**automatic implantable cardioverter
defibrillator (AICD)** 70

B

bearing
installation 45
bus reset 10

C

cable installation 20
circuit breaker
10 kVA power control module type 2 48
coarse update 32
component description
curved motor module 8, 11
gateway 7, 8
mover 8, 13
power control module 7, 8, 9
straight motor module 7, 8, 11
configuration
Ethernet connection 27
motion group 28
contoller
tags 34

D

dimensions
gateway
24 x 24 58
motor module
straight 59
mover 61, 62, 63
power control module
10 kVA horizontal 57
10 kVA vertical 57
7.5 kVA 57
step down transformer 57

E

error codes 49
e-stop
circuit schematic 22
pinout 21, 22
Ethernet communication
setup 30

G

gateway
24 x 24 dimensions 58
installation 20
weights 56
guard
circuit schematic 22
pinout 21, 22

I

instructions
installation 15
bearings 45
cables 20
gateway 20
lubricators 44
motor module 41
mover 38
planning 15
power control module 19
track 18

L

labels
automated machinery 26, 70
high voltage 70
hot surface 70
strong magnets 16, 26

M

monitor
circuit schematic 23
pinout 21, 22
motor module
curved motor module
dimensions 59
curved section
weight 55
replacement 41
straight section
dimensions 60
weight 55
mounting 17
mover
description 13
dimensions 61, 62, 63
installation 38

P

pinout
e-stop 21, 22
guard 21, 22
monitor 21, 22
reset 21, 22

power control module

- 10 kVA
 - horizontal dimensions 57
 - vertical dimensions 57
- 7.5 kVA
 - dimensions 57
- circuit breaker
 - 10 kVA type 2 48
- description 9
- installation 19
- weight 56

programming

- Ethernet communication 30
- general 27
- main task 35
- motion event 32
- motion group 32

R**requirements**

- environment 55

reset

- bus 10
- circuit schematic 21
- pinout 21, 22

S**safety**

- automated machinery 26, 70
- handling 17
- heat 70
- high voltage 70
- machine guarding 17
- pacemaker 13, 16, 26
- strong magnets 16, 26

schematic

- e-stop circuit 22
- guard circuit 22
- monitor circuit 23
- reset circuit 21

step down transformer

- dimensions 57

T**tags**

- controller 34

track

- installation 18
- weight 56

trending 36**V****virtual axes** 28**W****warning**

- automatic implantable cardioverter
defibrillator (AICD) 70
- powerful forces 70

Notes:

Rockwell Automation Support

Rockwell Automation provides technical information on the Web to assist you in using its products.

At <http://www.rockwellautomation.com/support> you can find technical and application notes, sample code, and links to software service packs. You can also visit our Support Center at <https://rockwellautomation.custhelp.com/> for software updates, support chats and forums, technical information, FAQs, and to sign up for product notification updates.

In addition, we offer multiple support programs for installation, configuration, and troubleshooting. For more information, contact your local distributor or Rockwell Automation representative, or visit <http://www.rockwellautomation.com/services/online-phone>.

Installation Assistance

If you experience a problem within the first 24 hours of installation, review the information that is contained in this manual. You can contact Customer Support for initial help in getting your product up and running.

United States or Canada	1.440.646.3434
Outside United States or Canada	Use the Worldwide Locator at http://www.rockwellautomation.com/rockwellautomation/support/overview.page , or contact your local Rockwell Automation representative.

New Product Satisfaction Return

Rockwell Automation tests all of its products to help ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned, follow these procedures.

United States	Contact your distributor. You must provide a Customer Support case number (call the phone number above to obtain one) to your distributor to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for the return procedure.

Documentation Feedback

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete this form, publication [RA-DU002](#), available at <http://www.rockwellautomation.com/literature/>.

Rockwell Automation maintains current product environmental information on its website at <http://www.rockwellautomation.com/rockwellautomation/about-us/sustainability-ethics/product-environmental-compliance.page>.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444
Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640
Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication 2198T-UM001A-EN-P - March 2015

Supersedes Publication IT3-UM001A-EN-P - May 2014

Copyright © 2015 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.