




# EtherNet/IP and ControlNet to FOUNDATION Fieldbus Linking Device

Catalog Numbers 1788-EN2FFR, 1788-CN2FFR



## Important User Information

Solid-state equipment has operational characteristics differing from those of electromechanical equipment. Safety Guidelines for the Application, Installation and Maintenance of Solid State Controls (publication [SGI-1.1](#) available from your local Rockwell Automation® sales office or online at <http://www.rockwellautomation.com/literature/>) describes some important differences between solid-state equipment and hard-wired electromechanical devices. Because of this difference, and also because of the wide variety of uses for solid-state equipment, all persons responsible for applying this equipment must satisfy themselves that each intended application of this equipment is acceptable.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



**WARNING:** Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.



**ATTENTION:** Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence.



**SHOCK HAZARD:** Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.



**BURN HAZARD:** Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.

---

### IMPORTANT

Identifies information that is critical for successful application and understanding of the product.

---

Allen-Bradley, Rockwell Software, Rockwell Automation, FactoryTalk AssetCentre, FactoryTalk View, RSLogix 5000, ControlLogix, RSNetWorx, ControlNet, and TechConnect are trademarks of Rockwell Automation, Inc.

Trademarks not belonging to Rockwell Automation are property of their respective companies.

<b>Preface</b>	Introduction.....	7
	About the Linking Device.....	7
	Network Diagrams.....	7
	1788-EN2FFR EtherNet/IP Network .....	7
	1788-CN2FFR ControlNet Network.....	8
	Features .....	8
	General Precautions.....	9
	Additional Resources.....	10
	 <b>Chapter 1</b>	
<b>Installation</b>	Hardware .....	11
	Power Connection .....	11
	H1 Network Connections .....	12
	ControlNet and EtherNet/IP Connections.....	13
	Shielding .....	13
	Set the Linking Device Network Address.....	14
	Hardware Switches Location .....	14
	Set the ControlNet Node Address .....	14
	Set the EtherNet/IP Address .....	15
	Ethernet Switch Settings .....	16
	Software Installation .....	17
	AOP Version .....	17
	Firmware Version .....	17
	 <b>Chapter 2</b>	
<b>Set Up in RSLogix 5000 Software</b>	Add the 1788-EN2FFR Linking Device to the I/O Tree .....	19
	Add the 1788-CN2FFR Linking Device to the I/O Tree .....	20
	RSNetWorx for ControlNet Configuration .....	21
	Linking Device Configuration using the AOP.....	24
	Master Configuration.....	26
	Add and Manage Device Description Files.....	29
	Field Device Configuration .....	30
	Field Device Block Configuration.....	34
	Field Device Class .....	40
	Scheduling and the LAS .....	41
	Redundant Master Setup .....	41
	Redundant Master Mismatch.....	43
	Redundant Master Disabled.....	43
	MultiMaster Connecting Procedures .....	44
	Connect Safe Mode .....	44
	Start the Back-up LAS Master (already configured).....	44
	Reconnect Two Separate Running LAS Devices.....	45
	Swap Out Linking Devices .....	45

<b>Logix Assemblies</b>	<b>Chapter 3</b>	
	Input .....	47
	Master Device Tag Structure .....	47
	Field Device Tag Structure .....	49
	Output .....	51
	Field Device Output Values .....	51
<b>Diagnostics</b>	<b>Chapter 4</b>	
	Status Screen .....	53
	PV Data Screen .....	55
	Oscilloscope Screen .....	55
	The Web Server .....	56
	Device Type Manager (DTM) .....	57
<b>Technical Specifications and Certifications</b>	<b>Chapter 5</b>	
	Technical Specifications .....	59
	Certifications .....	60
<b>Linking Device Display Status</b>	<b>Appendix A</b>	
	Main Page .....	61
	H1 Master Page .....	62
	Field Device Page .....	62
<b>HSPProcessUtility</b>	<b>Appendix B</b>	
	Use the HSPProcessUtility .....	65
<b>Field Device Block Configuration Examples</b>	<b>Appendix C</b>	
	Overview .....	67
	AO Function Block Example .....	68
	DO Function Block Example .....	78
<b>H1 Topology</b>	<b>Appendix D</b>	
	Master Mode 0 .....	83
	Master Mode 1 .....	83
	Master Mode 2 .....	83
	Master Mode 3 .....	84
	Master Mode 4 .....	84
	Master Mode 5 .....	84
	Master Mode 6 .....	84
	Master Mode 7 .....	85
	Master Mode 8 .....	85
	Master Mode 9 .....	85
	Master Mode 10 .....	85
	Master Mode 11 .....	86

	Master Mode 12 .....	86
	Master Mode 13 .....	86
	Master Mode 14 .....	86
	Master Mode 15 .....	87
	Master Mode 16 .....	87
<b>Glossary</b>	.....	89
<b>Index</b>	.....	95

## Notes:

## Introduction

This user manual describes the installation and operation of the 1788-EN2FFR and 1788-CN2FFR linking devices.

### About the Linking Device

The 1788-EN2FFR linking device provides a gateway between EtherNet/IP and a single segment FOUNDATION Fieldbus H1 layer.

The 1788-CN2FFR linking device provides a gateway between ControlNet and FOUNDATION fieldbus (FF).

Hereafter, both modules are referred to as the linking device.


The linking device can support 16 field devices and is configurable through RSLogix™ 5000 by a dedicated add-on-profile (AOP). Multiple levels of media redundancy are supported, including ring, split, and redundant trunk, plus options for H1 media, redundant linking devices, redundant controllers, and ControlNet.

The linking device has full FOUNDATION fieldbus host capability, including link active scheduler (LAS) capability.

## Network Diagrams


### 1788-EN2FFR EtherNet/IP Network

The diagram below is an example of an EtherNet/IP network.



## 1788-CN2FFR ControlNet Network

The diagram below is an example of a ControlNet network.



## Features

The AOP provides an intuitive graphical interface for configuring devices. A predefined data structure for each field device provides eight input process variables (PVs), eight output PVs, and eight PVs for inter-device communication for full distributed control.

The linking device uses four controller connections. The data for the 16 field devices is distributed over the four CIP connections. Connection A has the data for the linking device as well as four field devices. Connection B, C, and D have the data of four field devices each. The minimum requested packet interval (RPI) is 100 ms, and the maximum is 3000 ms.

The HSProcessUtility is used to manage and register the field device description (DD) files. The utility is launched from the AOP in RSLogix 5000, or directly in Microsoft Windows.

Field Device Tool/Device Type Manager (FDT/DTM) technology is supported, allowing access to field device configuration and diagnostics via FDT Frames such as FactoryTalk® AssetCentre. In addition, the Rockwell Automation FDT ThinFrame (read only) can be launched from a FactoryTalk View or via the AOP providing access to each field devices status and extended diagnostics.



Built-in power conditioners and protection are provided, helping to minimize installation space requirements. The H1 segment is divided between two physical ports (A and B) with individual protection and a supply of 500 mA per port. See [H1 Network Connections on page 12](#).

The basic diagnostics of the linking device, as well as the field devices, is found in the input assemblies. The advanced configuration is found only through the AOP.

To assist with troubleshooting a 128 x 128 pixel display provides access to the status of the linking device including network voltages and currents, internal temperature, and communication quality to each field device.

A built-in Web server also provides remote access to network and field device data.

## General Precautions

Read and understand all precautions before using the linking device.



### ATTENTION: Environment and Enclosure

This equipment is intended for use in a Pollution Degree 2 industrial environment, in overvoltage Category II applications (as defined in IEC 60664-1), at altitudes up to 2000 m (6562 ft) without derating.

This equipment is considered Group 1, Class A industrial equipment according to IEC/CISPR 11. Without appropriate precautions, there may be difficulties with electromagnetic compatibility in residential and other environments due to conducted and radiated disturbances.

This equipment is supplied as open-type equipment. It must be mounted within an enclosure that is suitably designed for those specific environmental conditions that will be present and appropriately designed to prevent personal injury resulting from accessibility to live parts. The enclosure must have suitable flame-retardant properties to prevent or minimize the spread of flame, complying with a flame spread rating of 5VA or be approved for the application if nonmetallic. The interior of the enclosure must be accessible only by the use of a tool. Subsequent sections of this publication may contain additional information regarding specific enclosure type ratings that are required to comply with certain product safety certifications.

In addition to this publication, see the following:

- Industrial Automation Wiring and Grounding Guidelines, publication [1770-4.1](#), for additional installation requirements.
- NEMA Standard 250 and IEC 60529, as applicable, for explanations of the degrees of protection provided by enclosures.

**ATTENTION: Prevent Electrostatic Discharge**

- This equipment is sensitive to electrostatic discharge, which can cause internal damage and affect normal operation. Follow these guidelines when you handle this equipment:
- Touch a grounded object to discharge potential static.
- Wear an approved grounding wrist strap.
- Do not touch connectors or pins on component boards.
- Do not touch circuit components inside the equipment.
- Use a static-safe workstation, if available.
- Store the equipment in appropriate static-safe packaging when not in use.



**ATTENTION:** Do not place the module in direct sunlight. Prolonged exposure to direct sunlight could degrade the LCD.

## Additional Resources

These documents contain additional information concerning related products from Rockwell Automation.

Resource	Description
ControlLogix Enhanced Redundancy System User Manual, publication <a href="#">1756-UM535</a>	Provides information specific to enhanced redundancy systems including design and planning considerations, installation procedures, configuration procedures, and maintenance and troubleshooting methods.
ControlLogix EtherNet/IP Module Installation Instructions, publication <a href="#">1756-IN603</a>	Provides hardware installation instructions for the ControlLogix EtherNet/IP.
EtherNet/IP Modules in Logix5000 Control Systems User Manual, publication <a href="#">ENET-UM001</a>	Describes how you can use EtherNet/IP communication modules with your Logix5000 controller and communicate with various devices on the Ethernet network.
ControlNet-to-FOUNDATION Fieldbus H1 Linking Device User Manual, publication <a href="#">1788-UM051</a>	Provides information for hardware and software installation and configuration, inputs and outputs, alarms, and technical specifications.
RSNetWorx for ControlNet Getting Results Guide, publication <a href="#">CNET-GR001</a>	Provides information on how to install and navigate the RSNetWorx™ for ControlNet™ software. It explains how to effectively use the RSNetWorx for ControlNet software and how to access and navigate the online help.
NetLinx Selection Guide, publication <a href="#">NETS-SG001</a>	Provides information for planning and implementing NetLinx Open Network Architecture networks, including ControlNet and EtherNet/IP networks.
Industrial Automation Wiring and Grounding Guidelines, publication <a href="#">1770-4.1</a>	Provides general guidelines for installing a Rockwell Automation industrial system.
Product Certifications website, <a href="http://www.ab.com">http://www.ab.com</a>	Provides declarations of conformity, certificates, and other certification details.

You can view or download publications at <http://www.rockwellautomation.com/literature/>. To order paper copies of technical documentation, contact your local Allen-Bradley distributor or Rockwell Automation sales representative.

## Installation

### Hardware




**ATTENTION:** Do not wire more than one conductor on any single terminal.

### Power Connection

The power supply must be compliant with CE safety extra low voltage (SELV) or protected extra low voltage (PELV), and UL Class 2 or limited voltage/current requirements.

We recommend a 24...32V DC power supply for the linking device to operate correctly. No additional power supplies or power conditioners are required. The power supply connection is described here.




**IMPORTANT** Do not use additional power supplies or power conditioners with the 1788-EN2FFR and 1788-CN2FFR linking devices.


## H1 Network Connections

The H1 network must be connected via the H1 terminal on the linking device. The H1 network connection and pin-out is described here.

Pin	Description
Right/Top (red)	FF +
Middle (green)	FF -
Left/Bottom	Shield




The H1 Segment is split between two physical ports, A and B.



## ControlNet and EtherNet/IP Connections

Two BNC connectors on the base of the 1788-CN2FFR linking device provide connections for single or dual ControlNet media. The dual port EtherNet/IP switch provides connections for multiple EtherNet topologies, including Device Level Ring (DLR). The EtherNet/IP port can also be used as a connection point in the field to access the Web server or asset manage tools.

The ControlNet connections are described here.




## Shielding

Ground the linking device shield connection to a clean earth connection.

Connect the shield to the H1 media so that connectivity runs through all junction boxes, but is not connected to the field device shield or grounded at the device.

Do not attach the H1 media shield to the field device. Tape the media shield back to avoid accidental contact with other conductors or ground.




## Set the Linking Device Network Address

This section describes the network address switches.


### Hardware Switches Location

The hardware switches are located under the front cover of the linking device. Use the Page button to toggle between different diagnostics on the display.




### Set the ControlNet Node Address

To set the ControlNet node address of the 1788-CN2FFR linking device, use the hardware switches behind the front cover.



## Set the EtherNet/IP Address

The linking device uses an RJ45 connector to connect to an Ethernet network. The linking device ships with BOOTP enabled. To set the IP address of the 1788-EN2FFR linking device, use a BOOTP server or use the hardware switches.







---

**IMPORTANT** Power down the linking device before changing the Ethernet switch settings. The IP address is set during powerup.

---

## Ethernet Switch Settings

This table describes the Ethernet switch settings.

Ethernet Switch Setting	Description
	To set the IP address of the linking device to the 192.168.1.xxx sub net, set the switches to the required last three digits. In this example, the linking device will start up with IP address: 192.168.1.123.
	To set the IP address of the linking device via a BOOTP server, set the switches to 888 (factory default setting). Power up the linking device and set the IP address using any BOOTP server. Once the new IP address has been set, power down the linking device, return the switches to 000, and power up the linking device.
	Normal setting after setting IP address with BOOTP. The 000 setting disables BOOTP and holds the IP address.
	The linking device has the option to run the firmware that it was originally shipped with. If the power was cycled while upgrading the firmware, the linking device may not start up because the firmware was corrupted. Set the switches to 777 to set the linking device into Safe mode and upgrade the firmware again.



## Software Installation

You need the AOP for RSLogix 5000 to configure and manage the linking device.

The installation of the AOP includes the HSProcessUtility that is used to manage DTMs and DD service libraries. See [Appendix B](#).

The AOP install file is available on the accompanying CD, or you can download the file from the product website [www.hiprom.com](http://www.hiprom.com).

Go to the page for your linking device and click the link for the AOP Setup software on the right side of the page (1788-EN2FFR linking device shown).



### Software

- EN2FFR EDS File
- EN2FFR AOP Setup x.xx.xx

### Firmware

- Flashkit vx.xx.xx

### Example Code

- Example Code A
- Example Code B

### DTM


- Process DTM vx.xx

### Documents

- EN2FFR Brochure
- EN2FFR User Manual - English

## AOP Version

The AOP version of the linking device is located on the display during the start up process, or via the web server.



**TIP** You can also click the upper-left corner of the profile window and click About Module Profile to view the AOP version.

## Firmware Version

The firmware version is printed on the linking device and displayed on the screen during power up. The web server also provides the firmware version.

## Notes:


## Set Up in RSLogix 5000 Software

### Add the 1788-EN2FFR Linking Device to the I/O Tree


The 1788-EN2FFR linking device must be added to the I/O tree of the Logix controller. The linking device must be added to an Ethernet bridge module, such as an Allen-Bradley 1756-EN2T or 1756-EN2TR module.

Follow these steps to add the linking device to the I/O tree of the Logix controller. This example uses the 1756-EN2TR module.

1. Right-click the Ethernet bridge and choose New Module.



2. Select the linking device that you want to add to the Ethernet bridge.



3. Click the General tab and set the name, description, and IP address.
4. Set the RPI for the linking device.

#### IMPORTANT

The recommended RPI is 1/2 the macrocycle time. Calculate the macrocycle by calculating the total response time of all field devices on the segment and then add 100...200 ms for class 2 (DTM message) data. Setting the RPI too low causes the class 1 data (PVs and status) to not update each cycle, and causes class 2 data responses to be very slow.


5. Click OK to add the linking device to the I/O tree.

## Add the 1788-CN2FFR Linking Device to the I/O Tree


The 1788-CN2FFR linking device must be added to the I/O tree of the Logix controller. The linking device must be added to a ControlNet bridge module, such as an Allen-Bradley 1756-CNB or 1756-CNBR module.

Follow these steps to add the linking device to the I/O tree of the Logix controller. This example uses the 1756-CNBR/A module.

1. Right-click the ControlNet bridge and choose New Module.



2. Select the linking device to add to the ControlNet bridge.



3. Click the General tab and set the name, description, and ControlNet node address.
4. Set the RPI for the linking device.

---

**IMPORTANT** The recommended RPI is 1/2 the macrocycle time. Calculate the macrocycle by calculating the total response time of all field devices on the segment and then add 100...200 ms for class 2 (DTM message) data. Setting the RPI too low causes the class 1 data (PVs and status) to not update each cycle, and causes class 2 data responses to be very slow.

---


5. Click OK to add the linking device to the I/O tree.

## RSNetWorx for ControlNet Configuration


Refer to the RSNetWorx for ControlNet Getting Results Guide, publication [CNET-GR001](#), for more details.

Follow these steps to configure the ControlNet network.

1. Launch RSNetWorx™ for ControlNet and create a new file.




2. Click the Online button.




The Browse for Network window appears with the drivers you have installed on your system.

3. Select the communication path to the ControlNet network, select the ControlNet port, and click OK.




The following pop-up window appears while RSNetWorx browses the network.




Once complete all the devices on the network are displayed in the graphic window on the right side of the window.

4. Right-click any white space around the graphics and select Enable Edits.




5. Right-click any white space around the graphics and select Properties.


6. On the Networks Parameters Tab, update the Max Unscheduled Address if you are sure that the allocated range is less than 99.




7. Click OK.
8. Right-click any white space around the graphics and choose Download to Network.
9. Select the correct save option for your configuration and click OK.



10. Enter a suitable file name.
11. Click Yes to download the configuration.



The ControlNet network is now scheduled and the graphics display green plus signs.



## Linking Device Configuration using the AOP


Once the linking device has been added to the config tree, you can access the property settings. Right-click the linking device and select Properties. Then click the Configuration tab as shown below.

Once the linking device is connected to the controller you can see the linking device in the Configuration tab.

- Master **green** in the config tree = linking device is **online**
- Master **grey** in the config tree = linking device is **offline**

The layout of the Configuration tab is shown below.

Figure 1 - Module Properties Configuration Tab



### Live List

Once a field device is found and has an address between 16 (0x10) and 247 (0xF7), the device appears in the live list. You can configure this device.

### Visitor List

Once a field device is found and has an address above 247 (0xF7), the device appears in the visitor list. You cannot configure this device until an address between 16 (0x10) and 247 (0xF7) is given to the field device. See Live List above.



## LAS

The LAS icon indicates if the master is the LAS that requests and receives live data from each field device, or if the master is the back-up LAS (the back-up LAS has a red X over the icon). See [Redundant Master Setup on page 41](#) for more information.






## Config Tree

Once you have configured the slot for a device (even if not downloaded yet) the device appears in the config tree. Use the config tree to navigate between configuration and status pages for each master and field device.

## Shortcuts

These shortcuts are located above the live list on the configuration tab.

**Table 1 - Configuration Tab Shortcuts**

Shortcut Button	Description
	Used to open the HSPProcessUtility, or to refresh the device catalog.
	The Overview page displays a list of configured and attached field devices.
	Export configuration for entire linking device, (including all field devices configured under linking device).
	Import configuration for entire linking device, (including all field devices configured under linking device).
	Used to synchronize the back-up link active scheduler (LAS) to the current LAS. You first need to export the project from the LAS AOP. Note that this button is only available to the back-up LAS and is disabled on the LAS.

You have the ability to export or import the configuration for either a field device or linking device (with all field devices connected).


**TIP** If you want to replicate the configuration to many devices, the synchronize shortcut can speed up the process.

## Master Configuration

1. Open the master configuration page from the config tree to access the linking device master configuration settings.
2. Choose the Topology for the master linking device.
3. Enter the configuration values.
4. Click the Download Config button to download the settings to the linking device.

The settings are stored in nonvolatile memory in the linking device.

5. Click the Apply button to store the configuration in the project file.



## Topology

You must choose the correct Topology mode for the application. The graphical representation must be used to match the topology. See [Appendix D](#) for available options. Use this setting to configure redundant linking devices, redundant H1 media, and the internal H1 segment terminators.

## FF Master Node

The H1 Master (linking device) needs a node number to operate on the H1 network. The default is node number 16 (0x10).

---

**IMPORTANT** Do not modify the default node number; doing so may result in loss of communication.

---

### Max Scan Address

When the linking device is operating, a background scan constantly probes each unused node number to see if any new field devices were connected. The background scan runs to the max scan address, then restarts at one.

### Slave Retry Limit

The slave retry limit sets the number of times the H1 Master re-requests data before dropping the connection. The default setting is 5.

---

<b>IMPORTANT</b>	Do not modify the default setting. Setting the limit above 5 can slow down communication.
------------------	---

---

### MacroCycle (ms)

The amount of time between data compels (process variables). Making this number too low results in poor performance when downloading and going online with a field device.

### Auto Reset Trip

Selects the option to reset H1 bus trips due to over-current.

- If the check box is selected, the trip automatically resets. The linking device resets the trip every 5 seconds. If the trip is still persistent, the bus will trip again.
- If the check box is not selected, you must reset the bus via the reset button on the master status page.

### Fail Status in Prog/Fault Mode

The fail status is used when field devices use output blocks (AO or DO) that are receiving data from the Logix controller via the linking device. When the linking device loses connection to the Logix controller, or the Logix controller goes into program or fault mode, you can choose one of two operations:

- If the check box is selected, the linking device detects that there is a comms fault on the ethernet and forces all output PV status to Bad:NoComms. If the field device is setup correctly, this forces the field device to go to fail-safe value.
- If the check box is not selected, the linking device keeps sending the last received data.

**TIP** When Logix is in Prog/Fault mode, you can still go into the tags and change values as the linking device is still connected.

### Upload Config

Uploads the configuration store on the attached linking device.

### **Auto MacroCycle**

Calculates the Macro Cycle based on the configured field devices and the number of PVs configured. A window is also added for class II data communication.

### **Advanced**

Opens the Advanced Settings window.

### **Load Defaults**

Resets the configuration settings to their default values.

### **Update Master Time**

Update the master time to local computer's time.

### **Download Schedule**

Download schedule to linking device.

**TIP** This task is performed automatically when field devices are added or edited.

### **Enable Schedule**

The default is enabled. Used only when the schedule is disabled by the Disable Schedule function.

### **Clear Schedule**

Clear the schedule from the linking device and the AOP.

---

**IMPORTANT** This will cause the module to stop compelling data.

---

### **Disable Schedule**

Disable the schedule from executing in the linking device.

### *Advanced*

The Advanced button on the master configuration page launches the Master Advanced configuration dialog box (see [Master Configuration on page 26](#)).

---

**IMPORTANT** We recommend that you do not alter these settings; doing so may result in loss of communication.

---

**Figure 2 - Master Advanced Configuration Screen**

The screenshot shows the 'Master Advanced' configuration window. It is divided into several sections. The top section contains a 'Tagname' field with the value '1788-EN2FFR'. Below this are two columns of fields: 'Slot Time' (8), 'Max Response Delay' (8), 'Min Inter PDU Delay' (16), 'Inter Channel Skew' (0), 'Post Transmission Gap' (0), 'Preamble Extension' (1), 'Phil Overhead' (0), 'Max Scheduling Overhead' (63), and 'Min Token Delegation Time' (32) on the left; and 'Token Hold Time' (276), 'Target Token Rotation Time' (60000), 'Link Maintenance Token Hold Time' (299), 'Time Distribution Period' (10000), 'Max Inactivity to Claim LAS' (90), and 'LAS Database Status Update Period' (10000) on the right. There are three groups of buttons: 'Operational' with 'Yes' and 'No' buttons, 'Primary Link Master' with 'Yes' and 'No' buttons, and 'Primary Time Publisher' with 'Yes' and 'No' buttons. Below the 'Primary Time Publisher' buttons are 'Time Publisher Node' (1) and 'AP Sync Interval (s)' (10). At the bottom right, there is a 'Device Class' section with 'Link Master' and 'Basic Device' buttons. At the very bottom are 'Ok' and 'Cancel' buttons.

### *Auto MacroCycle*

Click the Auto MacroCycle button on the master configuration page to calculate the recommended MacroCycle for the current linking device (see [Master Configuration on page 26](#)).

### *Auto MacroCycle Calculation*

Macrocycle = [(time needed for request + receive) x (configured field devices) x (configured PVs for each field device)] + [(configured field devices) x (time for one token exchange)] + [fixed amount of unscheduled time].

---

**IMPORTANT** The Auto MacroCycle only takes effect after you download it to the master and field devices.

---

## **Add and Manage Device Description Files**

Before field devices can be added to the 1788-CN2FFR/1788-EN2FFR linking device, you must first add a copy of the DD file to the field device catalog using the HSProcessUtility as described in [Appendix B](#).

The DD file defines the capabilities and configuration parameters of the field device.

### Field Device Configuration

The overview page on the configuration tab displays the field device live list with the colored icons depicting the current status of each field device (see page 24). If RSLogix 5000 is online with the 1788-CN2FFR/1788-EN2FFR link master correctly configured, the attached field devices appear in the live list.

The field device index (00→15) provides a unique index for each of the 16 possible field devices that can be connected to the 1788-CN2FFR/1788-EN2FFR linking device, and corresponds with the index in the linking device data structure located in the controller tags.

The H1 node address and physical tag are also displayed together with the device ID and serial number of the field device.

A right-click menu in the overview page displays functions for adding, configuring, and diagnosing field devices.






Figure 3 - Overview Page on the Configuration Tab



### Field Device Status

The icon color indicates the current status of the field device.

Table 2 - Field Device Status Icons

Icon	Description
	Green – Field device is online, allocated to a field device index and configured, producing process variables.
	Yellow – Field device is online, not allocated to a field device index and not configured.
	Blue – Field device is online, allocated but not configured or producing process variables.
	Red – Field device is not online.
	Light blue – Field device identification mismatch (occurs when the field device identity [ident] that is downloaded to the linking device is different than the actual field device).

The color of the text indicates if the online device has the same node address and tag as the offline configured device.

- If the text is **black**, the online and offline node address and tag name match.
- If the text is **red**, the online and offline node address and tag name do not match.

### Add New

Use this function to add field devices when the linking device is not connected to the field device. The Select Device dialog box displays a list of devices from the field device catalog. Set the H1 Node Address and Tagname.

**Figure 4 - Select Device Dialog Box**

The dialog box titled "Select Device" contains the following elements:

- Device Instance:**
  - Node Address:** A dropdown menu with "0x11" selected.
  - Tagname:** An empty text input field.
- Device Description:**
  - Manufacturer:** A dropdown menu with "(All)" selected.
  - Device:** A dropdown menu with "(All)" selected.
  - Table:** A table with 6 columns: Index, Manufacturer, Device, DeviceID, Rev, and DDRev.
 

	Manufacturer	Device	DeviceID	Rev	DDRev
0	Rosemount Inc.	848	0x0848	6	1
1	Rosemount Inc.	3051	0x3051	23	17
2	Rosemount Inc.	8800	0x8800	5	2
3	Endress+Hauser	Cerabar S	0x1007	2	3
4	Endress+Hauser	TMT85	0x10CE	1	4
- Buttons:** A "Cancel" button at the bottom right.

## Configure

Launches the field device block configuration screen used to configure each field device.

## Auto Configure Online

---


**IMPORTANT** Requires the field device to be online.

---

You can right-click on a device (of which the DD files are registered) and choose the Auto Configure Online option. A configuration is applied that represents the basic operation of the field device.

- The AOP adds a resource block and sets the target mode to auto.
- A transducer block is added and the mode block is set to auto.
- An analog input block (if available) is added with the target mode set to auto.
- The channel is set to 1 (in most cases the primary value).

**Figure 5 - Field Device Configuration Screen**



## Advanced Configuration

Used for assigning DTM to the field device and launching the Thin-Frame DTM viewer.

## Oscilloscope

Displays an oscilloscope trace of the response message from the field device.



### **Copy and Paste**

After the device configuration is done you can copy and paste the configuration to speed up the configuration process.

### **Move**

You can move a device in the live list to a different field device index even if the devices have been configured and are providing process variables.

### **Remove**

A device configuration can also be removed (deleted).

---

<b>IMPORTANT</b>	If a configuration is stored in the linking device at the specific field device index, it is also removed (deleted).
------------------	--

---

### **Set H1 Node Address**

Used to change the H1 node address on the field device. The node address should be set between 17 and 247. The linking device uses 16, and node addresses above 247 are placed in the visitor List.

### **Set H1 Physical Tag**

Use to change the tag name stored in the field device.

### **Merge Online and Offline**

The device merge option is used when you want to merge an online device with the offline configuration of a certain device index. Use this when performing a device exchange for a faulty device.

### **Mapping Report**

Produces a report that describes in detail the configuration of the field device.

### **Export Device and Import Device**

A device configuration can be exported to a file which can later be imported again. This is help when you have multiple devices with the same configuration.

### Field Device Block Configuration

You can configure the field device blocks from the block configuration view. Choose the Configuration option of the device in the config tree, or from the right-click menu in the live list.

Configuration is device-centric and performed in a graphical view using blocks, wires, and connectors (see [Figure 5 on page 32](#)). The graphical interface also provides access to parameters for each block for detailed configuration of each device.

See [Appendix C, Field Device Block Configuration Examples on page 67](#) for detailed information about configuring AO and DO function blocks.









Table 3 - Field Device Configuration Tools


Icon	Description
	Select and move objects.
	Draw wire.
	Go online with device.
	Download configuration to device.
	Print.

Add a Block

Blocks are defined by the field device manufacturer and described in the DD files.

There are three classes of blocks:

- R – Resource Block
- T – Transducer Block
- F – Function Block



Only function blocks have ports that are used to transfer data to and from the block:

- Ports on the left of the function blocks are inputs.
- Ports on the right of the function blocks are outputs.

For detailed descriptions and uses of each block, refer to the user manual of the field device.

Follow these steps to add a block.

1. To add (instantiate) a block, right-click in the window and choose New Block.

A list of all available blocks for the specific device appears.

2. Choose the block that you want to use.

The block appears on the screen.

Block Select							
Idx	Class	Full Name	#P	#I	DD Item	Profile	Revision
0	R	Resource 2	0	0	0x80020AF0	0x0133	0x0101
1	T	TMT162 Sensor Transducer 1	1	0	0x000200A2	0x8400	0x0001
2	T	TMT162 Sensor Transducer 2	1	0	0x000200A3	0x8401	0x0001
3	T	TMT162 Display Transducer	1	0	0x000200A4	0x8402	0x0001
4	T	TMT162 Adv Diag	1	0	0x000200A5	0x8403	0x0001
5	F	Analog Input	3	3	0x800201D0	0x0101	0x0101
6	F	Proportional Integral Derivative	1	0	0x800202B0	0x0108	0x0001
7	F	Input Selector	1	0	0x80028070	0x0126	0x0001

Adjust Block Parameters

To change the parameters of a block, right-click the title portion of the block and choose Parameters.




To enable a parameter for editing, click the box in the En column. A green check mark indicates the parameter is enabled for editing. Different parameters will have different classes as shown in Table 4.

Table 4 - Parameter Class Descriptions

Icon	Parameter Class Description
	Configurable parameter but non output
	Input port
	Read-only
	Tune
	Output port
	Alarm
	Parameter help (provides information about the parameter)

1. Click a parameter that is enabled for editing to display a list of options to choose from.
2. Select a new value in the pop-up dialog box and click OK.




### Add a Connector

Connectors provide a means for transferring data between the block of the field device and the data structure in the controller, as well as data transfers between field device blocks on the same segment. Data transfers between segments are performed via the controller.



Follow these steps to add a connector.

1. To add a connector, right-click in the window and choose New Connector.
2. Set the desired options in the Add Connector dialog box to configure the connector, and click OK.



**TIP** The configuration of input and output connectors requires the definition of the data being transferred. Refer to user manual of the field device for data type, length, offset, and number of status bytes. The default is the most common.


[Table 5](#) describes the four types of connectors.

**Table 5 - Connector Types**

Connector Type	Data Transfer Use	Icon
Input : I.PV	From a field device to the controller.	
Output : O.PV	From the controller to the field device.	
Network Publication	From a field device to another field device on the same segment.	
Network Subscription	From another field device on the same segment to the field device.	

The field device index, PV slot, and data type define where the connector points to in the data structure of the controller tags.

**Figure 6 - Example of a Field Device Index**



- For **Input : I.PV** connectors, the data types of float and integer both connect to `PVReal` in the input image, while binary data types connect to `PVBinary`.
- For **Output : O.PV** connectors, the output image of the linking device provides separate data types for float, integer, and binary.
- **Network Publication** and **Network Subscription** are used for control in the field where data is sent from one field device to another without any intervention from the LAS (master).

Each Network Publication connector must be given a unique name that is used as the reference for the Network Subscription connectors.

---


**IMPORTANT** Network Publication connectors must be defined first.

---


### Add Wires

Wires are used to connect input and output ports on the blocks to other ports or connectors.

Follow these steps to add a wire.




1. To add a wire, right-click in the window and choose New Wire.
2. Drag the ends of the wires to the docking points on the block and the connectors.



### Download the Configuration



When the configuration is complete, click the Download button to download the configuration to the field device. The download status is displayed in the progress bar.

**IMPORTANT**

The first configuration download for a device requires more time than subsequent downloads due to additional data required for setting up the communication links (virtual communication relationship [VCR]).

After the communication links are setup, the configuration downloads are quicker.

Once the download is done and the device is providing process variables the device will be **green** in the configuration tree as well as the live list.




If the device is not producing data (for example, incorrect configuration) the device will be **blue** in the configuration tree as well as the live list.



Go Online



Click the Go Online button to see process variables and change parameters in real time.




✓	5	ⓘ	MODE_BLK			
✓	5.1	ⓘ	TARGET	Auto		Auto
✓	5.2	ⓘ	ACTUAL	Auto		IMan
✓	5.3	ⓘ	PERMITTED	Auto + OOS		Auto + OOS
✓	5.4	ⓘ	NORMAL	Auto		Auto

Click a parameter to change it in real time. If the block is in Auto mode, you are prompted to change the mode to out of service (OOS), as some parameters cannot be changed while the block is in Auto mode.

See [Appendix C, Field Device Block Configuration Examples on page 67](#) for detailed information about configuring AO and DO function blocks.

Field Device Class

A field device can have one of two classes. It can be a basic device (normal operation) or it can be a link master (LAS capability). Choose Basic or Link Master on the block configuration screen. Power cycle the field device for the changes to take effect.




**IMPORTANT** We recommend that you set up all field devices as basic (default).



## Scheduling and the LAS

The 1788-CN2FFR/1788-EN2FFR linking device generates the LAS schedule, which determines when each function block executes and transmits data. Newly added field devices are automatically added to the schedule, and removed from the schedule when removed from the live list.


**Figure 7 - Master Configuration Dialog Box**



The Download Schedule function is only needed when the 1788-CN2FFR/1788-EN2FFR linking device has been replaced.

## Redundant Master Setup

You can set up a second 1788-CN2FFR/1788-EN2FFR linking device to act as a backup. There are various architectures that you can choose from (see [Appendix D](#)). Below is an example of MultiMaster, A bus only, with a shared termination architecture.




---

**IMPORTANT** When connecting to running linking devices you must follow the procedures in [MultiMaster Connecting Procedures on page 44](#) to avoid losing the connection to certain devices.

---



---

**IMPORTANT** You must not have any other back-up LAS devices. Be sure that all the field devices have been configured with the class set to basic. See [Field Device Class on page 40](#).

---



---

**IMPORTANT** You must test and verify that the specific field devices that are connected to the MultiMaster operate correctly when one of the linking devices fails.

---

We recommend you use the given AOI when using redundant masters. The AOI swaps between masters when one fails and automatically updates the destination PV with the back-up master data.


Only one of the masters is the LAS that requests and receives live data from each field device.

- If the device is the **LAS**, the device icon is displayed without a cross (see page 24).
- If the device is the **back-up LAS**, the device icon is displayed with a cross.



Follow these steps to set up one master to take priority as the primary master.


1. Set the back-up master Primary Link Master to No in the Master Advanced options (see Figure 2 on page 29).



2. Set up the network on the LAS.
3. Click the Export button to export the bridge configuration.
4. On the back-up LAS, click the Sync Masters button and choose the file that was exported.




All the scheduled configurations are downloaded to the back-up LAS. Once this is done the status indicates **Active - Backup LAS** as shown below.



## Redundant Master Mismatch


If the two masters are not synchronized (for example, there is a configuration mismatch) one of the following errors on the back-up LAS is displayed.



- **Master + Device Config Mismatch** indicates that there is a difference between the LAS and back-up LAS master configuration.
- **Device Config Mismatch** indicates that there is a difference in at least one of the field devices between the LAS and back-up LAS configuration.

## Redundant Master Disabled

If a redundant master is not in use, the Multi-Master status is disabled.



## MultiMaster Connecting Procedures


To avoid communication loss, or a field device going to the visitor address range, follow the MultiMaster connecting procedures in this section.

### Connect Safe Mode

The Connect Safe mode is used in the [Reconnect Two Separate Running LAS Devices on page 45](#) and [Swap Out Linking Devices on page 45](#) procedures.

To enter the **Connect Safe mode** hold the Page button for at least 5 seconds. The LCD displays the time remaining until communication is re-established to the linking device (10 seconds).

Figure 8 - Location of the Page Button for Connect Safe Mode



### Start the Back-up LAS Master (already configured)

Follow these steps to start the Back-up LAS master.

1. Plug in all communication connectors (H1, EtherNet/IP or ControlNet cables), but not the power.
2. Once all communication connectors are plugged in, connect the power to the linking device.

The linking device starts in Back-up LAS mode and does not disturb communication.

## Reconnect Two Separate Running LAS Devices

If two masters are configured on a network (one on each end) and the cable between them is broken, some devices will be connected to one master, and the remaining devices will be connected to the other master.

See master modes 9, 12, and 15 in [Appendix D](#).

Follow these steps to connect the two H1 segments.

1. Hold the Page button for 5 seconds to put one of the masters into **Connect Safe mode** (see [Connect Safe Mode on page 44](#)).

You have 10 seconds to reconnect the segments.

---

**IMPORTANT** Failing to enter Connect Safe mode can result in a loss of communication, or devices going to the visitor range.

---

2. Reconnect the cable between the masters.

## Swap Out Linking Devices

Follow these steps to swap out a linking device.

1. Plug in all communication and power connectors, but not the H1 segment.
2. Once the linking device is connected to Logix, change the node address to anything other than the node address of the running master.
3. Hold the Page button for 5 seconds to put the linking device into **Connect Safe mode** (see [Connect Safe Mode on page 44](#)).

You have 10 seconds to reconnect the segments.

---

**IMPORTANT** Failing to enter Connect Safe mode can result in a loss of communication, or devices going to the visitor range.

---

4. Click the Master Sync button in the overview window to synchronize the new master with the current running master (see [Redundant Master Setup on page 41](#)).

## **Notes:**

## Logix Assemblies

### Input

The linking device uses four CIP connections for the 16 field devices. Connection A has the master instance as well as four field devices, while the other connections (B, C, and D) have only the four field devices. All device assemblies are identical.

**Figure 9 - Example of Linking Device Connections Tag Data Structure**

FFR:IA	(...)	(...)	HT:1788HP_EN2FFR_0_3:IA:0
+ FFR:IA.CommStatusA	16#0000_0000	Hex	DINT
+ FFR:IA.Master	(...)	(...)	HT:1788HP_EN2FFR_MasterIrm
+ FFR:IA.FieldDevice00	(...)	(...)	HT:1788HP_EN2FFR_DeviceIrm
+ FFR:IA.FieldDevice01	(...)	(...)	HT:1788HP_EN2FFR_DeviceIrm
+ FFR:IA.FieldDevice02	(...)	(...)	HT:1788HP_EN2FFR_DeviceIrm
+ FFR:IA.FieldDevice03	(...)	(...)	HT:1788HP_EN2FFR_DeviceIrm
- FFR:IB	(...)	(...)	HT:1788HP_EN2FFR_4_7:IB:0
+ FFR:IB.CommStatusB	16#0000_0000	Hex	DINT
+ FFR:IB.FieldDevice04	(...)	(...)	HT:1788HP_EN2FFR_DeviceIrm
+ FFR:IB.FieldDevice05	(...)	(...)	HT:1788HP_EN2FFR_DeviceIrm
+ FFR:IB.FieldDevice06	(...)	(...)	HT:1788HP_EN2FFR_DeviceIrm
+ FFR:IB.FieldDevice07	(...)	(...)	HT:1788HP_EN2FFR_DeviceIrm
- FFR:IC	(...)	(...)	HT:1788HP_EN2FFR_8_11:IC:0
+ FFR:IC.CommStatusC	16#0000_0000	Hex	DINT
+ FFR:IC.FieldDevice08	(...)	(...)	HT:1788HP_EN2FFR_DeviceIrm
+ FFR:IC.FieldDevice09	(...)	(...)	HT:1788HP_EN2FFR_DeviceIrm
+ FFR:IC.FieldDevice10	(...)	(...)	HT:1788HP_EN2FFR_DeviceIrm
+ FFR:IC.FieldDevice11	(...)	(...)	HT:1788HP_EN2FFR_DeviceIrm
- FFR:ID	(...)	(...)	HT:1788HP_EN2FFR_12_15:ID:0
+ FFR:ID.CommStatusD	16#0000_0000	Hex	DINT
+ FFR:ID.FieldDevice12	(...)	(...)	HT:1788HP_EN2FFR_DeviceIrm
+ FFR:ID.FieldDevice13	(...)	(...)	HT:1788HP_EN2FFR_DeviceIrm
+ FFR:ID.FieldDevice14	(...)	(...)	HT:1788HP_EN2FFR_DeviceIrm
+ FFR:ID.FieldDevice15	(...)	(...)	HT:1788HP_EN2FFR_DeviceIrm

### Master Device Tag Structure

This section describes the values on the elements in the master device status tag structure.

Scope:	TestnewAQP	Show:	All Tags	
Name	Value	Force Mask	Style	Data Type
FFR01:IA	(...)	(...)		HT:1788HP_EN2...
+ FFR01:IA.CommStatusA	16#0000_0000		Hex	DINT
- FFR01:IA.Master	(...)	(...)		HT:1788HP_EN2...
- FFR01:IA.Master.FFBusVoltageA	0.0		Float	REAL
FFR01:IA.Master.FFBusCurrentA	0.0		Float	REAL
FFR01:IA.Master.FFBusVoltageB	0.0		Float	REAL
FFR01:IA.Master.FFBusCurrentB	0.0		Float	REAL
FFR01:IA.Master.ExternalVoltage	0.0		Float	REAL
FFR01:IA.Master.Temperature	0.0		Float	REAL
FFR01:IA.Master.BusAEnabled	0		Decimal	BOOL
FFR01:IA.Master.BusBEnabled	0		Decimal	BOOL
FFR01:IA.Master.BusATripped	0		Decimal	BOOL
FFR01:IA.Master.BusBTripped	0		Decimal	BOOL
FFR01:IA.Master.BusATerminated	0		Decimal	BOOL
FFR01:IA.Master.BusBTerminated	0		Decimal	BOOL
FFR01:IA.Master.NewFieldDevice	0		Decimal	BOOL
FFR01:IA.Master.LinkActiveScheduler	0		Decimal	BOOL
+ FFR01:IA.Master.MasterMode	0		Decimal	SINT
FFR01:IA.Master.RedundantMediaOK	0		Decimal	BOOL
+ FFR01:IA.Master.ConnectionStatus	2#0000 0000 0000 0000 0000 0000 0000 0000		Binary	DINT

**Bus A/BTripped**

If too much current is drawn ( $> 500$  mA) on Bus A or Bus B, a trip occurs and the bus is no longer functional. The trip is indicated in the input image.

**NewFieldDevice**

If a new field device is found which is not in the configuration of the H1 master, a new field device bit is set.

**LinkActiveScheduler**

This bit indicates if the current device is the LAS or the back-up LAS (set indicating that the linking device is the LAS).

**MasterMode**

N/A

**LinkingDeviceStatus**

This is currently reserved.

**ConnectionStatus**

If a field device is online and running (exchanging cyclic data) then its field device index bit (in the connection status) is set. If the device goes offline, the bit is cleared.

**FFBusVoltageA/B**

The voltage on the H1 bus measured at port A and port B on the linking device.

**FFBusCurrentA/B**

The current being drawn by the H1 bus through port A and port B.

**ExternalVoltage**

The voltage of the external power supply.

**Temperature**

The internal temperature of the linking device.

**BusA/BEnabled**

The H1 ports A and B are enabled/disabled by the master mode setting. For example, in Master Mode 0 - Single Master, A Bus Only, A is enabled and B is disabled (see page [83](#)).



## BusA/BTerminated

The H1 ports A and B termination is set by the master mode setting. For example, in Master Mode 0 - Single Master, A Bus Only, A is enabled and terminated (see page [83](#)).

## Field Device Tag Structure

This section describes the elements of the field device tag structure.

[- EN2H1R01:IA.FieldDevice00	{...}	{..}	
+ EN2H1R01:IA.FieldDevice00.FFNode	24		Decimal
- EN2H1R01:IA.FieldDevice00.Allocate	1		Decimal
- EN2H1R01:IA.FieldDevice00.Compel	1		Decimal
- EN2H1R01:IA.FieldDevice00.Live	1		Decimal
+ EN2H1R01:IA.FieldDevice00.Tag	{...}	{..}	

### FFNode

This is the node number of the field device.

### Allocate

Indicates that this specific field device index has been allocated for a specific field device and cannot be used by another.

### Compel

If this bit is set, the linking device is requesting process variable data from the field device.

### Live

A connection has been established to the field device and the linking device is receiving live data.

### Tag

This is the tag name of the field device.

### PVReal1...PVReal8

This is the process variable (PV) float or integer value from the field device. Each field device can have a maximum of eight real PVs.

EN2H1R01:IA.FieldDevice00.Data.PVReal1	50.0	Float
EN2H1R01:IA.FieldDevice00.Data.PVReal2	0.0	Float
EN2H1R01:IA.FieldDevice00.Data.PVReal3	0.0	Float
EN2H1R01:IA.FieldDevice00.Data.PVReal4	0.0	Float
EN2H1R01:IA.FieldDevice00.Data.PVReal5	0.0	Float
EN2H1R01:IA.FieldDevice00.Data.PVReal6	0.0	Float
EN2H1R01:IA.FieldDevice00.Data.PVReal7	0.0	Float
EN2H1R01:IA.FieldDevice00.Data.PVReal8	0.0	Float

### PVBinary1...PVBinary8

This is the process variable (PV) Boolean value from the field device. Each field device can have a maximum of eight binary PVs.

EN2H1R01:IA.FieldDevice00.Data.PVBinary1	0	Decimal
EN2H1R01:IA.FieldDevice00.Data.PVBinary2	0	Decimal
EN2H1R01:IA.FieldDevice00.Data.PVBinary3	0	Decimal
EN2H1R01:IA.FieldDevice00.Data.PVBinary4	0	Decimal
EN2H1R01:IA.FieldDevice00.Data.PVBinary5	0	Decimal
EN2H1R01:IA.FieldDevice00.Data.PVBinary6	0	Decimal
EN2H1R01:IA.FieldDevice00.Data.PVBinary7	0	Decimal
EN2H1R01:IA.FieldDevice00.Data.PVBinary8	0	Decimal

### PVStatus

The PV status indicates these quality values:

- Bad
- Uncertain
- GoodNonCascade
- GoodCascade

The PV status indicates these limit values:

- NotLimited
- LowLimited
- HighLimited
- Constant

EN2H1R01:IA.FieldDevice00.Data.PV1_Bad	0	Decimal
EN2H1R01:IA.FieldDevice00.Data.PV1_Uncertain	0	Decimal
EN2H1R01:IA.FieldDevice00.Data.PV1_GoodNonCascade	1	Decimal
EN2H1R01:IA.FieldDevice00.Data.PV1_GoodCascade	0	Decimal
EN2H1R01:IA.FieldDevice00.Data.PV1_NotLimited	0	Decimal
EN2H1R01:IA.FieldDevice00.Data.PV1_LowLimited	0	Decimal
EN2H1R01:IA.FieldDevice00.Data.PV1_HighLimited	0	Decimal
EN2H1R01:IA.FieldDevice00.Data.PV1_Constant	1	Decimal

## PV Diagnostics

This is the diagnostics information that is associated with each PV.

FFR01:1A.FieldDevice00.Data.PV1Diagnostics	{...}	{...}		HT:178
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.Bad_NonSpecific	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.ConfigurationError	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.NotConnected	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.DeviceFailure	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.SensorFailure	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.NoCommWithLastUsableValue	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.NoCommWithNoLastUsableValue	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.OutOfService	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.Bad_TransducerInManual	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.Uncertain_NonSpecific	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.LastUsableValue	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.Substitute	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.InitialValue	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.SensorConvNotAccurate	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.EngUnitRangeViolation	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.SubNormal	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.Uncertain_TransducerInManual	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.ActiveBlockAlarm	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.ActiveAdvisoryAlarm	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.ActiveCriticalAlarm	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.UnAckBlockAlarm	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.UnAckAdvisoryAlarm	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.UnAckCriticalAlarm	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.GoodNonCasade_InitialFaultState	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.GoodCasade_NonSpecific	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.InitAcknowledge	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.InitRequest	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.NotInvited	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.NotSelected	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.LocalOverride	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.FaultStateActive	0		Decimal	BOOL
FFR01:1A.FieldDevice00.Data.PV1Diagnostics.GoodCasade_InitialFaultState	0		Decimal	BOOL

## Output

This section describes the values on the field device output status screen.

## Field Device Output Values

### PVReal1...PVReal8

If you are using a field device that requires an output, the data must be updated in the output image of that field device. If the connector data type is set to **Float**, then the data (for that specific connector) is read from the real value in the output image.

### PVInt1...PVInt8

If you are using a field device that requires an output, the data must be updated in the output image of that field device. If the connector data type is set to **Integer**, then the data (for that specific connector) is read from the integer value in the output image.

## PVBinary1...PVBinary8

If you are using a field device that requires an output, the data must be updated in the output image of that field device. If the connector data type is set to **Boolean**, then the data (for that specific connector) is read from the binary value in the output image.

## PVStatus1...PVStatus8

If the connector for the PV output is set to have a status, you need to put a status in the output image that will be sent with the process variable.

PV Status	Status
$PVStatus \geq 0x80$	Green = good
$0x40 \leq PVStatus < 0x80$	Orange = uncertain
$PVStatus < 0x40$	Red = bad

Figure 10 - Example of Field Device Output Screen

	{...}	{...}		HT:178
- FFR01:0A.FieldDevice00				
- FFR01:0A.FieldDevice00.PVReal1	0.0	Float	REAL	
- FFR01:0A.FieldDevice00.PVReal2	0.0	Float	REAL	
- FFR01:0A.FieldDevice00.PVReal3	0.0	Float	REAL	
- FFR01:0A.FieldDevice00.PVReal4	0.0	Float	REAL	
- FFR01:0A.FieldDevice00.PVReal5	0.0	Float	REAL	
- FFR01:0A.FieldDevice00.PVReal6	0.0	Float	REAL	
- FFR01:0A.FieldDevice00.PVReal7	0.0	Float	REAL	
- FFR01:0A.FieldDevice00.PVReal8	0.0	Float	REAL	
+ FFR01:0A.FieldDevice00.PVInt1	0	Decimal	DINT	
+ FFR01:0A.FieldDevice00.PVInt2	0	Decimal	DINT	
+ FFR01:0A.FieldDevice00.PVInt3	0	Decimal	DINT	
+ FFR01:0A.FieldDevice00.PVInt4	0	Decimal	DINT	
+ FFR01:0A.FieldDevice00.PVInt5	0	Decimal	DINT	
+ FFR01:0A.FieldDevice00.PVInt6	0	Decimal	DINT	
+ FFR01:0A.FieldDevice00.PVInt7	0	Decimal	DINT	
+ FFR01:0A.FieldDevice00.PVInt8	0	Decimal	DINT	
- FFR01:0A.FieldDevice00.PVBinary1	0	Decimal	BOOL	
- FFR01:0A.FieldDevice00.PVBinary2	0	Decimal	BOOL	
- FFR01:0A.FieldDevice00.PVBinary3	0	Decimal	BOOL	
- FFR01:0A.FieldDevice00.PVBinary4	0	Decimal	BOOL	
- FFR01:0A.FieldDevice00.PVBinary5	0	Decimal	BOOL	
- FFR01:0A.FieldDevice00.PVBinary6	0	Decimal	BOOL	
- FFR01:0A.FieldDevice00.PVBinary7	0	Decimal	BOOL	
- FFR01:0A.FieldDevice00.PVBinary8	0	Decimal	BOOL	
- FFR01:0A.FieldDevice00.PV1_Bad	0	Decimal	BOOL	
- FFR01:0A.FieldDevice00.PV1_Uncertain	0	Decimal	BOOL	
- FFR01:0A.FieldDevice00.PV1_GoodNonCascade	0	Decimal	BOOL	
- FFR01:0A.FieldDevice00.PV1_GoodCascade	0	Decimal	BOOL	
- FFR01:0A.FieldDevice00.PV1_NotLimited	0	Decimal	BOOL	
- FFR01:0A.FieldDevice00.PV1_LowLimited	0	Decimal	BOOL	
- FFR01:0A.FieldDevice00.PV1_HighLimited	0	Decimal	BOOL	
- FFR01:0A.FieldDevice00.PV1_Constant	0	Decimal	BOOL	
+ FFR01:0A.FieldDevice00.PV1_SubStatus	0	Decimal	SINT	

# Diagnostics

## Status Screen

The diagnostic status provides basic device data as well as statistics. Click Status in the config tree to view basic data and statistics for the device.



### Status

The connectivity status of the linking device.

Value	Description
80...100	Good
41...79	Uncertain
0...40	Bad

### Tag

The tag name stored in the field device.

### Ident

The identity of field device.

### Device

The field device type.

### Vendor

The field device vendor.

### Good Packets

The count of good quality reply packets received from the field device. (Cyclic Redundant Code [CRC] check passed.)

**Bad CRC Packets**

The count of reply packets received from the field device that were rejected because the CRC check failed.

**No Replies**

The count of communication request to which the field device did not respond.

**Success Rate**

The rate of good replies to the number of requests for the last 100 requests.

**Signal Quality**

Displays the quality of the waveform for the field device using a mix of slew rate, amplitude, distortion, noise, and balance.

Value	Description
0...33	Bad
34...66	Poor
67...100	Good

**Allocated**

True if the field device has been allocated a field device index of 00 through 15. If a field device is in the visitor list, it has not been allocated.

**Compel**

True if the field device has been allocated and configured to compel data. The field device is also included in the schedule.

**Live Data**

True if the field device is allocated and configured, and is currently producing live data.


## PV Data Screen

If a field device has been configured and scheduled, its scheduled PV values are displayed here, along with the name of the function block parameter that is producing or consuming the data.

**Table 6 - PV Status Colors**


PV Status	Status Color
$PVStatus \geq 0x80$	Green = good
$0x40 \leq PVStatus < 0x80$	Orange = uncertain
$PVStatus < 0x40$	Red = bad

Click PV Data in the config tree to view the PV data for the device.



## Oscilloscope Screen

The last packet received (good or bad) is displayed in the oscilloscope trace. Click Oscilloscope in the config tree to view the last packet received for the device.



## The Web Server

To view detailed status and diagnostic information for the device in the Web server, enter the IP address of the device into the address field of a Web browser and press enter.

**HIPROM TECHNOLOGIES** 1788-EN2FFR

open all | close all

- Main
  - Home
  - Diagnostics
    - Overview
    - Network settings
    - Eventlog
    - Debug
  - Statistics
    - Ethernet
    - Foundation Fieldbus
  - Foundation Fieldbus
    - H1 Master**
      - Field Device Index 0
      - Field Device Index 1
      - Field Device Index 2
      - Field Device Index 3
      - Field Device Index 4
      - Field Device Index 5
      - Field Device Index 6
      - Field Device Index 7
      - Field Device Index 8
      - Field Device Index 9
      - Field Device Index 10
      - Field Device Index 11
      - Field Device Index 12
      - Field Device Index 13
      - Field Device Index 14
      - Field Device Index 15
      - Visitor
      - Visitor

### FOUNDATION FIELDBUS - H1 Master

General	
Tag	1788-EN2FFR
Ident	1788-EN2FFR_3511-6F1F
Node Address	16
Status	Ok
Logix Owned	True
PA Bus A Enabled	True
PA Bus B Enabled	True
PA Bus A Tripped	False
PA Bus B Tripped	False
PA Bus A Terminated	True
PA Bus B Terminated	True
Multi-master Mode	False
Primary Linking Device	True
MacroCycle	1000ms

Diagnostics	
External Voltage	26.70 V
PA Bus A Voltage	24.29 V
PA Bus B Voltage	24.01 V
PA Bus A Current	0.00 mA
PA Bus B Current	79.20 mA
Internal Temperature	35.75 C
Retry Limit	5
Response Timeout	15 ms

Copyright © 2011 Hiprom Technologies, Inc. All Rights Reserved.

**IMPORTANT** If data is not being updated, turn off page caching or try a different Web browser.




## Device Type Manager (DTM)

Use the HSThinFrame to open the device DTM in Logix. The DTM is read-only when opened in Logix.


**IMPORTANT** The correct DTM must be installed and the HSProcessUtility DTM Catalog must be updated for the correct DTM to display in the pull-down list.

Follow these steps to open the DTM.

1. Click Advanced in the config tree.
2. Choose the DD revision from the pull-down list.
3. Click Open DTM.



4. Choose the device information that you want to view.



5. View the selected device information.



## Notes:

## Technical Specifications and Certifications

### Technical Specifications

Attribute		1788-EN2FFR, 1788-CN2FFR
Power requirements		Operating voltage: 24...32V DC, 0.75 A, Class 2/SELV Foundation Fieldbus (FF): 0.5 A at 24V DC per trunk Power is connected to the linking device using the 2-way Phoenix connector.
Power consumption		260 mA at 24 V (with no field devices attached)
Power dissipation		12.24 W at 24V DC
Isolation voltage		30V (continuous), basic insulation type, network channels to power, and network channels to network channels. No isolation between redundant network channels. Type tested at 500V DC for 60 seconds.
Temperature	IEC 60068-2-1 IEC 60068-2-2 IEC 60068-2-14	Operating/Storage: 0...50 °C (32...122 °F) Surrounding air, max: 50 °C (122 °F)
Relative humidity	IEC 60068-2-30	5...95% noncondensing
Shock	IEC 60068-2-27	Operating: 15 g Nonoperating: 30 g
Vibration	IEC 60068-2-6	0.5 g at 10...500 Hz
Emissions	CISPR 11 IEC 61000-6-4	Group 1, Class A
Immunity		
ESD	IEC 61000-4-2	6 kV contact discharge 8 kV air discharge
Conducted RF	IEC 61000-4-6	10 V rms with 1 kHz sine-wave 80% AM from 150 kHz...80 MHz
Radiated RF	IEC 61000-4-3	10 V/m with 1 kHz sine-wave 80% AM from 80...2000 MHz 10 V/m with 200 Hz 50% Pulse 100% AM at 900 MHz 10 V/m with 200 Hz 50% Pulse 100% AM at 1890 MHz 3 V/m with 1 kHz sine-wave 80% AM from 2000...2700 MHz
EFT/B	IEC 61000-4-4	±4 kV at 5 kHz on power ports ±3 kV at 5 kHz on Ethernet and FF ports
Surge	IEC 61000-4-5	±1 kV line-line (DM) and ±2 kV line-earth (CM) on power ports ±2 kV line-earth (CM) on Ethernet and FF ports
Enclosure type rating		IP00, NEMA/UL Open Type

Attribute	1788-EN2FFR, 1788-CN2FFR
DC power connections	0.205... 0.823 mm <sup>2</sup> (24...18 AWG) Solid or stranded copper wire rated at 75 °C (167 °F) or greater 1.2 mm (3/64 in.) insulation max
Ethernet conductors	CAT5 STP/UTP
Terminal torque	0.22 ... 0.25 N•m (2.0 ... 2.2 lb•in)

## Certifications

Certification	1788-EN2FFR, 1788-CN2FFR
c-UL-us	UL Listed Industrial Control Equipment, certified for US and Canada. See UL File E320594.
CE	EN 61326-1: Meas./Control/Lab., Industrial Requirements EN 61000-6-2: Industrial Immunity EN 61000-6-4: Industrial Emissions EN 61131-2: Programmable Controllers (Clause 8, Zone A and B)
C-Tick	AS/NZS CISPR 11: Industrial Emissions
EtherNet /IP	ODVA conformance tested to EtherNet/IP specifications
FF	Foundation Fieldbus Test Campaign Number: CT0152FF
KC	Korean Registration of Broadcasting and Communications Equipment, compliant with Article 58-2 of Radio Waves Act, Clause 3

See the Product Certifications link at <http://ab.rockwellautomation.com/> for Declarations of Conformity, certificates, and other certification details.

## Linking Device Display Status

The display of the linking device provides status and diagnostic data using one of three page formats: main page, H1 master page, or field device page. Use the display Page button behind the front cover to scroll through the pages (see [Figure 8 on page 44](#) for location of the Page button).

### Main Page

The main page is the default display, and the linking device returns to this page after 10 seconds.

**H1 Bus A/B:** Displays the bus voltages on each port.

**IP:** Displays the current IP address or BOOTP if enabled.

**STS:** Displays the current status (see [Table 7](#)).

```
H1 Bus A: 24.4V B:24.7V
IP: 192.168.1.203

-----
STS: Ok
-----
00 → >
01 → >>>
02 → >>
03 → XXX
04 → ???
05 → OOS
06 → Off
07 → Err
```

**Table 7 - STS Status Descriptions**

Status	Description
Ok	No events
New device found	New device on the bus
Redundancy ok	Masters are synchronized
Redundancy err	Masters out of sync
Bus A Tripped	Bus A over current trip
Bus B Tripped	Bus B over current trip
SAFE MODE	linking device set to Safe mode

The lower portion of the main page shows the communication quality to each field device represented as a percentage of data packets sent compared to data packets received for each field device index (see [Table 8](#)).

**Table 8 - Field Device Communication Quality**

Display	Communication Quality	Display	Communication Quality
>>>	95+	???	Unknown
>>	80+	OOS	Allocated, On-line, not Compelling Data
>	60+	Off	Allocated, Off-line
XXX	Below 60	Err	Allocated, On-line, not producing Compelled Data

## H1 Master Page

The next page accessed by the Page button is the H1 Master page.

**Bus A/B:** Displays the bus voltages, currents, and bus status.

**Temperature:** Displays the internal temperature of the linking device.

**External Pwr:** Displays the power supply voltage.

**FF Node:** Displays the H1 node address for the master (default 16).

**BusA/B Enabled:** H1 Bus A and/or H1 Bus B is enabled for communication.

**BusA/B Tripped:** H1 Bus A and/or H1 Bus B has tripped indicating that there was an over-current on either port.

**BusA/B Term:** The linking device is configured to terminate H1 Bus A and/or H1 Bus B.

```

H1 Master
-----
Bus A: 21.5V 36.7mA
Bus B: 21.7V 20.7mA
Temperature: 34.50 C
External Pwr: 23.29V
-----
FF Node: 16
Bus A Enabled: True
Bus B Enabled: True
Bus A Tripped: False
Bus B Tripped: False
Bus A Term: True
Bus B Term: True
  
```

## Field Device Page

The next 16 FF Field Device pages display the status of each of the field device indices.

**FF Node:** Displays the H1 node address.

**Device Tag Name:** The tag name of the device.

**Status:** Displays the field device status (see [Table 9](#).)

```

FF Field Device - 0
-----
FF Node: 1A
Device Tag Name
Status: Online
-----
Success: 100
Pckt Send: 22409
Pckt Recv: 22209
Bad CRC: 98
No Reply: 102
-----
Signal Quality: 87
  
```

**Table 9 - Field Device Status**

Status	Description
Not Connected	Device cannot be seen
Online	Online - not configured
ConfigRunning	Device is configured and running

**Success:** Displays the data packets received as a percentage of packets sent for the previous 100 packets.

**Pckt Send:** Displays the total number of data packets sent from the field device.

**Pckt Recv:** Displays the total number of data packets received from the field device.

**Bad CRC:** Displays the total number of bad CRC packets received.

**No Reply:** Displays the total number of data requests to which the field device did not responded.

**Signal Quality:** Displays the quality of the waveform for the field device using a mix of slew rate, amplitude, distortion, noise, and balance.

Value	Description
0...33	Bad
34...66	Poor
67...100	Good

## **Notes:**




## HSPProcessUtility

### Use the HSPProcessUtility

Follow these steps to use the HSPProcessUtility to add a device description to a field device.


1. Click the HSPProcessUtility icon in the AOP and click Launch HSPProcessUtility.

**TIP** You can also click the refresh catalog option to refresh the device catalog once a DD file has been added.




The HSPProcessUtility opens. Because the same utility is used to register GSD files (Profibus PA) and DTMs, these options are still in the menu bar.

2. Select the Foundation Fieldbus option and choose Add Device Description. Three files are needed to update the library:
  - Binary file (.ffo)
  - Symbol file (.sym)
  - Capability file (.cff)
3. Select the binary file, the appropriate symbol file, and the correct version of the capability file.



A new file is generated and the library directory is updated.




**HSPProcessUtility 1.19**  
File Profibus-PA Foundation Fieldbus DTM

Foundation Fieldbus


	Manufacturer	Device	DeviceID	Rev	DDRRev	CFF Path	HDD Path
0	Endress+Hauser	TMT162	0x10CC	1	2	452B48\10CC\010103.cff	452B48\10CC\0102.hd
1	Endress+Hauser	TMT85	0x10CE	1	3	452B48\10CE\010103.cff	452B48\10CE\0103.hd
2	Endress+Hauser	TMT85	0x10CE	1	4	452B48\10CE\010105.cff	452B48\10CE\0104.hd
3	Endress+Hauser	Deltabar S	0x1009	6	3	452B48\1009\060104.cff	452B48\1009\0603.hdc
4	Endress+Hauser	Prowil 73	0x1057	1	1	452B48\1057\010101.cff	452B48\1057\0101.hdc
5	Metso Automation Inc.	ND9000F	0x2328	3	1	000E05\2328\030102.cff	000E05\2328\0301.hdc
6	SMAR	TT302	0x0002	6	1	000302\0002\060101.cff	000302\0002\0601.hdc

**TIP** Before the field device can be configured in the AOP, the catalog needs to be refreshed.

- Click the HSPProcessUtility icon and choose Refresh Catalog.




- Install the device DTMs from the vendors, then go to the DTM tab in HSPProcessUtility and click Update Catalog.



Each example starts from an empty live list, adds the device to the network, and configures an analog output (AO) or discrete output (DO) function.

See [Field Device Block Configuration on page 34](#) for general field device block configuration information.


### Figure 11 - Empty Live List




## AO Function Block Example

This example describes the steps used to configure an AO function block for the linking device. The linking device tag name in this example is SMAR FI302.


1. Add the linking device to the field bus network.



2. Right-click the linking device and choose Auto Configure Online.



3. Click the Go Online button.




4. Right-click the resource function block and choose Parameters.

Verify that the correct DD files were enabled.


5. Scroll down to Index rows 10, 11, 12, and 13.

6. Check the **En** column for Index rows 10, 11, 12, and 13.

A green check displays in the box.




7. Verify that the Dev\_Rev and DD\_REV in the Parameters screen matches the Rev and DDRev revisions in the HSProcessUtility (compare [Figure](#) and [Figure 7](#)).




	Manufacturer	Device	DeviceID	Rev	DDRev	CFF Path	HDD Path
0	SMAR	FI302	0x0005	4	2	000302\0005\040201.cff	000302\0005\0402.hdc
1	SMAR	IF302	0x0003	4	2	000302\0003\040201.cff	000302\0003\0402.hdc
2	SMAR	LD 302	0x0001	4	2	000302\0001\040201.cff	000302\0001\0402.hdc
3	SMAR	TT 302	0x0002	4	2	000302\0002\040201.cff	000302\0002\0402.hdc
4	Rosemount Inc.	3051	0x3051	7	2	001151\3051\070201.cff	001151\3051\0702.hdc
5	Rosemount Inc.	848	0x0848	5	9	001151\0848\050502.cff	001151\0848\0509.hdc
6	Rosemount Inc.	644	0x0644	2	1	001151\0644\020101.cff	001151\0644\0201.hdc
7	VEGA	EGAPULS 6	0x08FD	5	1	564748\08FD\050101.cff	564748\08FD\0501.hdc
8	Yokogawa Electric	EJX	0x000C	3	3	594543\000C\030102.cff	594543\000C\0303.hdc
9	Rosemount Inc.	848	0x0848	4	9	001151\0848\040906.cff	001151\0848\0409.hdc
10	StoneL	scrite and Ar	0x00F2	2	1	005774\00F2\020101.cff	005774\00F2\0201.hdc
11	Rosemount Inc.	8732	0x8732	2	1	001151\8732\020101.cff	001151\8732\0201.hdc
12	WTVC	OCK DISCRI	0x0001	1	1	574343\0001\010101.cff	574343\0001\0101.hdc
13	Rosemount Inc.	848	0x0848	6	1	001151\0848\060101.cff	001151\0848\0601.hdc
14	Rosemount Inc.	3051	0x3051	23	17	001151\3051\170309.cff	001151\3051\1711.hdc
15	Endress+Hauser	Cerabar S	0x1007	6	3	452B48\1007\060104.cff	452B48\1007\0603.hdc
16	Endress+Hauser	Cerabar S	0x1007	2	1	452B48\1007\020101.CFF	452B48\1007\0201.hdc
17	Endress+Hauser	Cerabar S	0x1007	6	1	452B48\1007\060101.cff	452B48\1007\0601.hdc
18	Endress+Hauser	TMT162	0x10CC	1	2	452B48\10CC\010103.cff	452B48\10CC\0102.hdc
19	Endress+Hauser	Prowirl 73	0x1057	1	1	452B48\1057\010102.cff	452B48\1057\0101.hdc
20	Endress+Hauser	Cerabar S	0x1007	5	1	452B48\1007\060102.cff	452B48\1007\0601.hdc

8. Use the tools in the Configuration screen to build the configuration as shown in [Figure](#).

See [Field Device Block Configuration on page 34](#) for general field device block configuration information.




9. Click the download button to download the AO function block to the linking device.




The download operation completes without errors.


10. Click OK.



11. Click the Go Online button.
12. Right-click the Analog Output function block.
13. Choose Parameters.




The linking device parameters are displayed.







- 14. Under MODE\_BLK > PERMITTED, right-click the Value column and select Cas.
- 15. Click OK to add the Cas mode.



- 16. Under MODE\_BLK > TARGET, right-click the Value column and select Cas and Auto.
- 17. Click OK to add the Cas+Auto mode.




18. Verify that the MODE\_BLK > TARGET value is Cas + Auto and the MODE\_BLK > ACTUAL value is Auto.



19. In the parameter screen scroll down to parameters CAS\_IN and BKCAL\_OUT.
20. Verify that the BKCAL\_OUT > STATUS in the Live column indicates a NotInvited condition.


Before the output control loop can be initialized, the NotInvited condition must be cleared.



21. Set the value of the controller tag associated with the quality of CAS\_IN (connector PV:O.1) status parameter (PVx\_GoodCascade) to the value 1.

FFR01:0A.FieldDevice00.PV1_Bad	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_Uncertain	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_GoodNonCascade	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_GoodCascade	1	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_NotLimited	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_LowLimited	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_HighLimited	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_Constant	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_SubStatus	0	Decimal	SINT

22. Verify that the NotInvited status has been replaced by the new status, InitializationRequest.



FFR01:0A.FieldDevice00.PV1_Bad	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_Uncertain	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_GoodNonCascade	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_GoodCascade	1	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_NotLimited	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_LowLimited	0	Decimal	BOOL

The InitializationRequested must receive a response.

23. Set the value of the Controller Tag associated with the sub-status of CAS\_IN (connector PV:O.1) status parameter (PV1\_SubStatus) to the value 1, which is InitializationAcknowledge.

The InitializationRequested status in BKCAL\_OUT > STATUS > Live column is cleared and replaced by the value, NonSpecific.

The CAS\_IN > STATUS > Live column displays a status of InitializationAcknowledge.

Module Properties: ENBT (1788-EN2FFR 2.1)

General

Connection

Module Info

Configuration

Internet Protocol

Port Configuration

Network

Vendor

Tag FI302 FBUS Only\_3743

Ident 0003020005 SMAR-FI302-0063400

Node 25

FDI 0

Class Basic

Parameters

En All

Dis All

X

En	Index	Class	Parameter	Value	Live
<input checked="" type="checkbox"/>	16.2		VALUE	0.0	
<input checked="" type="checkbox"/>	17		CAS_IN		
<input checked="" type="checkbox"/>	17.1		STATUS	Good Cascade: NonSpecific:NotLimit	Good Cascade: InitializationAcknowledge:NotLimit
<input checked="" type="checkbox"/>	17.2		VALUE	0.0	0.0
<input checked="" type="checkbox"/>	18		SP_RATE_DN	0.0	
<input checked="" type="checkbox"/>	19		SP_RATE_UP	0.0	
<input checked="" type="checkbox"/>	20		SP_HI_LIM	0.0	
<input checked="" type="checkbox"/>	21		SP_LO_LIM	0.0	
<input checked="" type="checkbox"/>	22		CHANNEL	1	1
<input checked="" type="checkbox"/>	23		FSTATE_TIME	0.0	
<input checked="" type="checkbox"/>	24		FSTATE_VAL	0.0	
<input checked="" type="checkbox"/>	25		BKCAL_OUT	Bad: NonSpecific:NotLimit	Good Cascade: NonSpecific:NotLimit
<input checked="" type="checkbox"/>	25.1		STATUS	Bad: NonSpecific:NotLimit	Good Cascade: NonSpecific:NotLimit
<input checked="" type="checkbox"/>	25.2		VALUE	0.0	0.0
<input checked="" type="checkbox"/>	26		RCAS_IN		
<input checked="" type="checkbox"/>	26.1		STATUS	Bad: NonSpecific:NotLimit	
<input checked="" type="checkbox"/>	26.2		VALUE	0.0	
<input checked="" type="checkbox"/>	27		SHED_OPT	Uninitialized	
<input checked="" type="checkbox"/>	28		RCAS_OUT		
<input checked="" type="checkbox"/>	28.1		STATUS	Bad: NonSpecific:NotLimit	

Status: Running

OK


Cancel

Apply


Help

FFR01:0A.FieldDevice00.PV1_Bad	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_Uncertain	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_GoodNonCascade	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_GoodCascade	1	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_NotLimit	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_LowLimit	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_HighLimit	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_Constant	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_SubStatus	1	Decimal	SINT

24. Verify that the AO function block **MODE\_BLK > ACTUAL > Live** column displays **Cas**.



25. Set the **CAS\_IN (PV:O.1)** value to 50%.
26. Verify that the **BKCAL\_OUT (PV:I.1)** and **OUT (PV:I.2)** values change as required (50% equals 12 mA at the **OUT** parameter).




The AO function block is now created, initialized, and operating correctly.


## DO Function Block Example

This example describes the steps used to configure a DO function block for the linking device. The device used in this example is FPAC\_2.

1. Add the linking device to the field bus network.




2. Add a DO function block to the configuration.




**TIP** Any other function blocks and connections may be deleted.

3. Make connections to CAS\_IN\_D, OUT\_D, and BKCAL\_OUT\_D.
4. Click the Download button to download the DO function block to the linking device.




The download operation completes without errors.


5. Click OK.



6. Click the Go Online button.
7. Right-click the Discreet Output function block.
8. Choose Parameters.




The linking device parameters are displayed.





9. In the Parameters screen, scroll down to parameters CAS\_IN\_D and BKCAL\_OUT\_D.
10. Verify that the BKCAL\_OUT\_D > STATUS in the Live column indicates a NotInvited condition.


Before the output control loop can be initialized, the NotInvited condition must be cleared.



11. Set the value of the controller tag associated with the quality of BKCAL\_OUT\_D (connector PV:O.1) status parameter (PVx\_GoodCascade) to the value 1.

- FFR01:QA.FieldDevice00.PV1_Bad	0	Decimal	BOOL
- FFR01:QA.FieldDevice00.PV1_Uncertain	0	Decimal	BOOL
- FFR01:QA.FieldDevice00.PV1_GoodNonCascade	0	Decimal	BOOL
- FFR01:QA.FieldDevice00.PV1_GoodCascade	1	Decimal	BOOL
- FFR01:QA.FieldDevice00.PV1_NotLimited	0	Decimal	BOOL
- FFR01:QA.FieldDevice00.PV1_LowLimited	0	Decimal	BOOL
- FFR01:QA.FieldDevice00.PV1_HighLimited	0	Decimal	BOOL
- FFR01:QA.FieldDevice00.PV1_Constant	0	Decimal	BOOL
+ FFR01:QA.FieldDevice00.PV1_SubStatus	0	Decimal	SINT

12. Verify that the NotInvited status has been replaced by the new status, InitializationRequest.



The InitializationRequest must receive a response.

13. Set the value of the Controller Tag associated with the sub-status of CAS\_IN\_D (connector PV:O.1) status parameter (PV1\_SubStatus) to the value 1, which is InitializationAcknowledge.

FFR01:0A.FieldDevice00.PV1_Bad	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_Uncertain	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_GoodNonCascade	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_GoodCascade	1	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_NotLimited	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_LowLimited	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_HighLimited	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_Constant	0	Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_SubStatus	1	Decimal	SINT

14. Verify that the DO function block MODE\_BLK > ACTUAL > Live column displays Cas.

Module Properties: ENBT (1788-EN2FFR 2.1)

Tag: FPAC\_2 Ident: 5743430001Westlock A00000370 Node: 27 FDI: 0 Class: Basic

En	Index	Class	Parameter	Value	Live
✓	1		ST_REV	0	
✓	2		TAG_DESC	FPAC_2_Disc3	FPAC_2_Disc3
✓	3		STRATEGY	0	
✓	4		ALERT_KEY	0	
✓	5		MODE_BLK		
✓	5.1		TARGET	Cas + Auto	Cas + Auto
✓	5.2		ACTUAL	Auto	Cas
✓	5.3		PERMITTED	Cas + Auto + OOS	Cas + Auto + OOS
✓	5.4		NORMAL	Auto	Auto
✓	6		BLOCK_ERR	-	
✓	7		PV_D		
✓	7.1		STATUS	Bad:NonSpecific:NotLimited	
✓	7.2		VALUE	Close	
✓	8		SP_D		

Controller Tags - Hiprom(controller)

Scope: Hiprom Show: All Tags

Name	Value	Force Mask	Style	Data Type
FFR01:0A.FieldDevice00.PV1_Bad	0		Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_Uncertain	0		Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_GoodNonCascade	0		Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_GoodCascade	1		Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_NotLimited	0		Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_LowLimited	0		Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_HighLimited	0		Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_Constant	0		Decimal	BOOL
FFR01:0A.FieldDevice00.PV1_SubStatus	1		Decimal	SINT

The DO function block is now created, initialized, and operating correctly.

## H1 Topology

### Master Mode 0

Single Master

A Bus Only

Terminated at the linking device.




### Master Mode 1

Single Master

A Bus Only

Not terminated at the linking device.



### Master Mode 2

Single Master

B Bus Only

Terminated at the linking device.




## Master Mode 3

Single Master

B Bus Only

Not terminated at the linking device.



## Master Mode 4

Single Master

Dual Bus

Terminated at the linking device.




## Master Mode 5

Single Master

Dual Bus

Not terminated at the linking device.




## Master Mode 6

Single Master

Split Bus

Terminated at the linking device.




**Master Mode 7**

Single Master


Split Bus

Not terminated at the linking device.

**Master Mode 8**

Single Master

Ring Bus

**Master Mode 9**

MultiMaster

A Bus Only


Terminated at the linking devices.

**Master Mode 10**

MultiMaster

A Bus Only

Shared termination at the linking devices.




## Master Mode 11

MultiMaster

A Bus Only

Not terminated at the linking devices.



## Master Mode 12

MultiMaster

B Bus Only

Terminated at the linking devices.




## Master Mode 13

MultiMaster

B Bus Only

Shared termination at the linking devices.




## Master Mode 14

MultiMaster

B Bus Only

Not terminated at the linking devices.



**Master Mode 15**


MultiMaster

Dual Bus

Terminated at the  
linking devices.**Master Mode 16**

MultiMaster

Dual Bus

Shared termination  
at the linking  
devices.

## Notes:



The following terms and abbreviations are used throughout this manual. For definitions of terms not listed here, refer to the Allen-Bradley Industrial Automation Glossary, publication [AG-7.1](#).

<b>1788-EN2FFR linking device</b>	Provides a gateway between EtherNet/IP and a single segment Foundation Fieldbus H1 layer.
<b>1788-CN2FFR linking device</b>	Provides a gateway between ControlNet and Foundation Fieldbus (FF).
<b>AO</b>	Abbreviation for an analog output; signal is generated by the host system and transmitted to a field device.
<b>AOP</b>	Abbreviation for add-on-profile; provides an intuitive graphical interface for configuring devices.
<b>basic device</b>	A device that can communicate on the fieldbus, but cannot become the LAS.
<b>block</b>	See <a href="#">function block</a> , <a href="#">resource block (RES)</a> , and <a href="#">transducer block</a> .
<b>BOOTP</b>	A protocol to boot a diskless workstation and receive the boot information from a server.
<b>bridge</b>	An interface in a fieldbus network that interconnects two or more H1 networks.
<b>bus</b>	An H1 fieldbus cable between a Host and field devices connected to multiple segments, sometimes through the use of repeaters.
<b>CAS</b>	Abbreviation for Cascade.
<b>channel</b>	A path for a signal.
<b>CIP</b>	Acronym for Common Industrial Protocol; a communication protocol, or language, between industrial devices. CIP provides seamless communication for devices on DeviceNet, ControlNet, and EtherNet/IP networks.
<b>configurable</b>	Capability to select and connect standard hardware modules to create a system; or the capability to change functionality or sizing of software functions by changing parameters without having to modify or regenerate software.
<b>configuration</b>	Physical installation of hardware modules to satisfy system requirements; or the selection of software options to satisfy system requirements.
<b>connector</b>	Coupling device used to connect the wire medium to a fieldbus device or to another segment of wire.
<b>control loop</b>	Group of function blocks that execute at a specified rate within a FOUNDATION Fieldbus device or distributed across the fieldbus network.

<b>ControlNet network</b>	An open control network that uses the producer/consumer model to combine the functionality of an I/O network and peer-to-peer network, while providing high-speed performance for both functions.
<b>cycle</b>	Scanning of inputs, execution of algorithms and transmission of output values to devices.
<b>device description (DD)</b>	Abbreviated as DD, this is a set of files (CFE, SYM, and FFO) that describes the parameter capabilities of a fieldbus device. The file information on these block parameters includes names, data types, and specifications.
<b>device</b>	The term in this manual refers to the instruments that make up the fieldbus system.
<b>device ID</b>	An identifier for a device that the manufacturer assigns. Device IDs must be unique to the device; no two devices can have the same device ID.
<b>device tag</b>	A character string name that uniquely identifies a device on a fieldbus network.
<b>DO</b>	Abbreviation for discrete output; signal is generated by the host system and transmitted to a field device.
<b>Ethernet</b>	Physical and data link layer defined by IEEE 802 standards used by EtherNet/IP.
<b>EtherNet/IP</b>	An open, industrial networking standard that supports both real-time I/O messaging and message exchange.
<b>fieldbus</b>	A digital, two-way, multi-drop communication link among intelligent measurement and control devices. It serves as a Local Area Network (LAN) for advanced process control, remote input/output, and high-speed factory automation applications.
<b>FOUNDATION Fieldbus</b>	The communication network that the Fieldbus Foundation created.
<b>function block</b>	A named block consisting of one or more input, output, and contained parameters. The block performs some control function as its algorithm. Function blocks are the core components with which you control a system. The Fieldbus Foundation defines standard sets of function blocks.
<b>gateway</b>	Translates another protocol to FOUNDATION fieldbus or vice versa, for example HART to FOUNDATION fieldbus or Modbus to FOUNDATION fieldbus.
<b>H1</b>	A FOUNDATION fieldbus segment that operates at 31.25 Kbps.

- host** Control system that has FOUNDATION fieldbus capabilities to configure and operate FOUNDATION fieldbus segments. There are several classes of Host systems:
- Class 61 - Integrated Host - Primary, or process Host that manages the communication and application configuration of all devices on the network.
  - Class 62 - Visitor Host - Temporary, on process Host with limited access to device parameterization.
  - Class 63 - Bench Host - Primary, off process Host for configuration and setup of a non-commissioned device.
  - Class 64 - Bench host - Primary, off process Host with limited access to device parameterization of an off-line, commissioned device.
  - Class 71 - Safety Integrated Host - Primary, on-process Host that manages the communication and application configuration of all safety and control and monitoring devices on a network.
- LAS** See [link active scheduler](#).
- link** A logical link is a connection between function blocks; a physical link is a connection between fieldbus devices.
- linking device** As a bridge, enables peer-to-peer communication between H1 devices without the need for host system intervention. As a gateway, connects the H1 network to other plant control and information networks, such as EtherNet/IP and ControlNet.
- link active scheduler** Abbreviated as LAS, this scheduler is responsible for coordinating all communication on the fieldbus; maintaining a list of transmission times for all data buffers in all devices that need to be cyclically transmitted. The LAS circulates tokens, distributes time, probes for new devices, and removes non-responsive devices from the link.
- link master** An LM is a device that contains [LAS](#) functionality that can control communication on a FOUNDATION fieldbus H1 fieldbus link. There must be at least one LM on the H1 link; one of those LM devices is chosen as the LAS.
- macrocycle** A calculated time for a fieldbus device to send and receive data. The AOP can automatically generate the value, or the value can be manually entered. The LAS is responsible for scheduling of the segment macrocycle.
- mode** Control block operational condition, such as manual, automatic, or cascade.
- network** A network as applied in this document is the termination of one or more fieldbus segments into an interface card of the Host system.
- node** The connection point at which media access is provided.

<b>offline</b>	Perform tasks while the Host system is not communicating with the field devices.
<b>online</b>	Perform tasks, such as configuration, while the Host system is communicating with the field devices.
<b>PV</b>	Acronym for Process Variable, which is the primary value.
<b>resource block (RES)</b>	This block controls the linking device. It contains data specific to the linking device's hardware. All data is modeled as contained, so there are no links in this block.
<b>redundancy</b>	The duplication of devices for the purpose of enhancing the reliability or continuity of operations in the event of a failure without loss of a system function.
<b>ring bus</b>	A network where signals are transmitted from one station and replayed through each subsequent station in the network. Signal can travel in either direction of the ring so it creates network redundancy; if the ring breaks in one place the nodes can still communicate.
<b>RSLogix</b>	Software that provides a programming environment for sequential, process, drive, and motion control programming. The RSLogix environment provides an IEC 61131-3 compliant interface for controls programming.
<b>segment</b>	A physical link (cable) between fieldbus devices and a pair of terminators on an H1 channel. Segments can be linked by repeaters to form a longer H1 fieldbus. A fully loaded (maximum number of connected devices) 31.25 Kbps voltage-mode fieldbus segment should have a total cable length, including spurs, between any two devices of up to 1900 m. There cannot be a non-redundant segment between two redundant systems.
<b>signal</b>	The event or electrical quantity that conveys information from one point to another.
<b>tag</b>	Unique alphanumeric code assigned to inputs, outputs, equipment items, and control blocks.
<b>terminator</b>	Impedance-matching module used at or near each end of a transmission line that has the same characteristic impedance of the line. Terminators are used to minimize signal distortion, which can cause data errors. H1 terminators convert the current signal transmitted by one device to a voltage signal that can be received by all devices on the network.
<b>topology</b>	The shape and design of the fieldbus network.
<b>transducer block</b>	The transducer block decouples function blocks from the local input/output (I/O) function required to read sensors and command output hardware. Transducer blocks contain information, such as calibration date and

sensor type. There is usually one transducer block for each input or output of a function block.

**trunk** The main communication highway between devices on an H1 fieldbus network. The trunk acts as a source of main supply to spurs on the network.

**VCR** Acronym for Virtual Communication Relationship. Configured application layer channels that provide for the transfer of data between applications. FOUNDATION Fieldbus describes three types of VCRs: Publisher/Subscriber, Client/Server, and Source/Sink.

## Notes:

## Numerics

1756-CNB ControlNet bridge 20  
 1756-CNBR ControlNet bridge 20  
 1756-EN2T Ethernet bridge 19  
 1756-EN2TR Ethernet bridge 19  
 1788-CN2FFR ControlNet network 8  
 1788-EN2FFR EtherNet/IP network 7

## A

add linking device to I/O tree 19, 20  
 add new field device 31  
 add-on-profile 17  
 advanced configuration 9  
 advanced settings 28  
 AO function block example 68  
 AOP  
   install file 17  
   version 17  
 Auto MacroCycle 28, 29  
 Auto MacroCycle calculation 29  
 auto reset trip 27

## B

background scan 27  
 backup linking device 41  
 backup master 42  
 backup-LAS mode 44  
 bad CRC packets received 63  
 binary file (.ffo) 65  
 block classes  
   F – function block 35  
   R – resource block 35  
   T – transducer block 35  
 block configuration  
   block classes 35  
   block parameters 36  
   connectors 37  
   download configuration to device 34  
   draw wire 34  
   go online with device 34  
   input I.PV connectors 38  
   network publication 38  
   network subscription 38  
   output O.PV connectors 38  
   print 34  
   select and move objects 34  
   wires 39  
 block parameters 36  
 block ports  
   input 39  
   output 39  
 bridge  
   ControlNet 20  
   Ethernet 19  
 bridge configuration, export 42  
 bus voltages, currents, and bus status 62

## C

capability file (.cff) 65  
 catalog  
   refresh 66  
   update 66  
 certifications 60  
 change parameters in real time 40  
 class description  
   alarm 36  
   configurable parameter but non-output 36  
   input port 36  
   output port 36  
   read-only 36  
   tune 36  
 clear schedule 28  
 conducted RF 59  
 conductors  
   Ethernet 60  
   power 60  
 config tree 25  
 configuration replication 25  
 configuration shortcuts  
   display list of configured and attached field devices 25  
   export configuration 25  
   import configuration 25  
   synchronize the backup LAS 25  
 configure  
   internal H1 segment terminators 26  
   redundant H1 media 26  
   redundant linking devices 26  
 Connect Safe mode 44, 45  
 ControlNet  
   connections 13  
   network 8, 21  
   node address 14  
   port 22  
 ControlNet bridge  
   1756-CNB 20  
   1756-CNBR 20

## D

data compels 27  
 data packets sent from field device 62  
 data requests not responded to by field device 63  
 default node number 26  
 determine the RPI 19, 20  
 device  
   config mismatch 43  
   description (DD) files 8  
   statistics 53  
 diagnostic and status information 56  
 diagnostic data 61  
 diagnostic status 53

**diagnostics**

- Device Type Manager (DTM) 57
- oscilloscope screen 55
- PV data screen 55
- status screen 53
- Web server 56

**disable schedule 28****display status**

- field device page
  - bad CRC 63
  - data packet transfer success rate 62
  - device tag name 62
  - FF node 62
  - field device status 62
  - no reply 63
  - pckt rcv 63
  - pckt send 62
  - signal quality 63
  - status 62
- H1 master page
  - bus A/B 62
  - busA/B enabled 62
  - busA/B term 62
  - busA/B tripped 62
  - external pwr 62
  - FF node 62
  - temperature 62
- main page
  - bus A tripped 61
  - bus B tripped 61
  - bus voltages 61
  - communication quality 61
  - H1Bus A/B 61
  - IP address or BOOTP 61
  - new device found 61
  - Ok 61
  - redundancy err 61
  - redundancy ok 61
  - SAFE MODE 61
  - STS 61

**D0 function block example 78****download schedule 28, 41****download settings to linking device 26****downloading the field device configuration 39****E****earth ground 13****EFT/B 59****emissions 59****enable schedule 28****ESD 59****Ethernet bridge**

- 1756-EN2T 19
- 1756-EN2TR 19

**Ethernet switch settings 16****EtherNet/IP address 15****EtherNet/IP network 7****export and import device configuration 33****export bridge configuration 42****F****FactoryTalk AssetCentre 8****fail status in prog/fault mode 27****FF master node 26****FF node 62****field device**

- adding 30
- configuring 30
- diagnosing 30
- index 30
- status 62
- status icons 30
- status, viewing 30

**field device block configuration**

- download configuration to device 34
- draw wire 34
- go online with device 34
- print 34
- select and move objects 34

**field device catalog 29, 31****field device class**

- basic device (normal operation) 40
- link master (LAS capability) 40

**field device configuration**

- add new field device 31
- advanced configuration 32
- auto configure online 32
- configure 32
- copy and paste 33
- export and import device configuration 33
- mapping report 33
- merge online and offline 33
- move device 33
- oscilloscope 32
- remove device configuration 33
- set H1 node address 33
- set H1 physical tag 33

**field device output image**

- boolean 52
- float 51
- integer 51

**field device tool (FDT) 8****fieldbus host capability 7****firmware version 17****firmware, flashing 16****function block configuration example**

- A0 68
- D0 78

**G****grounding 13****H****H1 network connection 12****H1 node**

- address 62
- address and physical tag 30

**H1 node address 33****H1 physical tag 33**



**H1 segment ports 9****H1 topology, multi-master**

- A bus only
  - not terminated 86
  - shared termination 85
  - terminated 85
- B bus only
  - not terminated 86
  - shared termination 86
  - terminated 86
- dual bus
  - shared termination 87
  - terminated 87

**H1 topology, single master**

- A bus only
  - mon-terminated 83
  - terminated 83
- B bus only
  - non-terminated 84
  - terminated 83
- dual bus
  - non-terminated 84
  - terminated 84
- ring bus 85
- split bus
  - non-terminated 85
  - terminated 84

**HSProcessUtility 17, 29****HSThinFrame 57****I****I/O tree 19**

- add linking device 19, 20

**immunity**

- conducted RF 59
- EFT/B 59
- ESD 59
- radiated RF 59
- surge 59

**import and export device configuration 33****input and output ports on blocks 39****input I.PV connectors 37, 38****instantiate a block 35****IP address**

- setting via BOOTP 16
- setting via Ethernet switches 16

**L****LAS 25****LAS device icon**

- LAS 42
- LAS backup 42

**LAS errors**

- device config mismatch 43
- master + device config mismatch 43

**LAS schedule 41****library directory 66****linking device**

- add to I/O tree 19, 20
- non-volatile memory 26
- offline status indicator 24
- online status indicator 24

**linking device property settings 24****live list 24****load defaults 28****Logix assemblies, input**

- field device
  - allocate 49
  - compel 49
  - FFNode 49
  - live 49
  - PVBinary1...PVBinary8 50
  - PVDiagnostics 51
  - PVReal1...PVReal8 50
  - PVStatus 50
  - tag 49

**master**

- bus A/B tripped 48
- BusA/BEnabled 48
- BusA/BTerminated 49
- ConnectionStatus 48
- ExternalVoltage 48
- FFBusCurrentA/B 48
- FFBusVoltageA/B 48
- LinkActiveScheduler 48
- LinkingDeviceStatus 48
- MasterMode 48
- NewFieldDevice 48
- Temperature 48

**Logix assemblies, output**

- field device
  - PVBinary1...PVBinary8 52
  - PVInt1...PVInt8 51
  - PVReal1...PVReal8 51
  - PVStatus1...PVStatus8 52

**Logix controller 19****M****MacroCycle 27****master**

- backup 42
- primary 42

**master + device config mismatch 43****master advanced configuration screen 28**

**master configuration**

- advanced 28
- Auto MacroCycle 28
- auto reset trip 27
- clear schedule 28
- disable schedule 28
- download schedule 28
- enable schedule 28
- fail status in prog/fault mode 27
- FF master node 26
- load defaults 28
- MacroCycle 27
- max scan address 27
- slave retry 27
- topology mode 26
- update master time 28
- upload config 27

**max scan address 27****media redundancy supported**

- redundant controllers 7
- redundant Ethernet media 7
- redundant linking devices 7
- redundant trunk 7
- ring 7
- split 7

**memory, non-volatile 26****module properties, configuration tab**

- config tree 25
- LAS 25
- live list 24
- shortcuts 25
- visitor list 24

**N****network**

- publication connectors 37
- subscription connectors 37

**network connection, H1 12****network diagrams**

- ControlNet network 8
- EtherNet/IP network 7

**network subscriptions 38****node address**

- ControlNet 14

**node address and tag name**

- online and offline do not match 31
- online and offline match 31

**node number**

- default 26

**non-volatile memory 26****O****oscilloscope trace 55****output and input ports on blocks 39****output image**

- boolean 52
- float 51
- integer 51

**output 0.PV connectors 37, 38****P****parameter class description**

- alarm 36
- configurable parameter but non-output 36
- input port 36
- output port 36
- read-only 36
- tune 36

**parameter help 36****ports, H1 segment 9****power**

- additional supplies 12
- conditioners 9, 11, 12
- conductors 60
- connection 11
- consumption 59
- supply 11
- supply connection 11
- supply voltage 62

**primary master 42****process variables 8**

- viewing online 40

**property settings**

- linking device 24

**publication connectors 37****PV data 55****PV status**

- bad 55
- good 55
- limit values
  - constant 50
  - HighLimited 50
  - LowLimited 50
  - NotLimited 50
- quality values
  - bad 50
  - good\_cascade 50
  - good\_noncascade 50
  - uncertain 50
- uncertain 55

**R****radiated RF 59****refresh catalog 66****remote access 9****replicate configuration 25****request packet interval 19, 20**

- minimum and maximum 8

**RF**

- conducted 59
- radiated 59

**RJ45 connector 15****RPI**

- determining 19, 20
- minimum and maximum 8

**RSNetWorx for ControlNet 21****S****Safe mode 16**

- set the H1 node address and tag name** 31
- shielding** 13
- slave retry** 27
- status and diagnostic information** 56
- status icons**
  - field device 30
- store configuration in project file** 26
- subscription connectors** 37
- symbol file (.sym)** 65

## **T**

- temperature of linking device** 62
- topology mode** 26
- troubleshooting** 9, 53

## **U**

- update catalog** 66
- update master time** 28
- upload config** 27

## **V**

- visitor list** 24





## Rockwell Automation Support

Rockwell Automation provides technical information on the Web to assist you in using its products.

At <http://www.rockwellautomation.com/support>, you can find technical manuals, technical and application notes, sample code and links to software service packs, and a MySupport feature that you can customize to make the best use of these tools. You can also visit our Knowledgebase at <http://www.rockwellautomation.com/knowledgebase> for FAQs, technical information, support chat and forums, software updates, and to sign up for product notification updates.

For an additional level of technical phone support for installation, configuration, and troubleshooting, we offer TechConnect<sup>SM</sup> support programs. For more information, contact your local distributor or Rockwell Automation representative, or visit <http://www.rockwellautomation.com/support/>.

## Installation Assistance

If you experience a problem within the first 24 hours of installation, review the information that is contained in this manual. You can contact Customer Support for initial help in getting your product up and running.

United States or Canada	1.440.646.3434
Outside United States or Canada	Use the <a href="#">Worldwide Locator</a> at <a href="http://www.rockwellautomation.com/support/americas/phone_en.html">http://www.rockwellautomation.com/support/americas/phone_en.html</a> , or contact your local Rockwell Automation representative.

## New Product Satisfaction Return

Rockwell Automation tests all of its products to ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned, follow these procedures.

United States	Contact your distributor. You must provide a Customer Support case number (call the phone number above to obtain one) to your distributor to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for the return procedure.

## Documentation Feedback

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete this form, publication [RA-DU002](#), available at <http://www.rockwellautomation.com/literature/>.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

**[www.rockwellautomation.com](http://www.rockwellautomation.com)**

### Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846