



INDUSTRIAL ELECTRIC VEHICLE



OWNER'S MANUAL AND SERVICE GUIDE

PC and PCT
SERIES

2012

NOTES, CAUTIONS AND WARNINGS

Throughout this guide NOTE, CAUTION, and WARNING will be used. Please observe these notes, cautions and warnings.

NOTE

A NOTE indicates a condition that should be observed.

CAUTION

A CAUTION indicates a condition that may result in damage to the vehicle.

WARNING

A WARNING indicates a hazardous condition that could result in severe injury or death.

Table of Contents

INTRODUCTION	5
SAFETY INFORMATION.....	6
Training.....	6
Operator Qualifications	6
Safety Guidelines.....	6
Loading and Unloading.....	7
Towing	7
Maintenance	7
Ventilation.....	7
INDUSTRY STANDARDS.....	8
OPERATING INSTRUCTIONS	13
Initial Checklist.....	13
Identification	13
Charging	13
Vehicle Controls, Meters, Switches	13
Driving	19
Coasting	19
Loading/Unloading.....	19
Parking	19
Towing	19
MAINTENANCE INSTRUCTIONS	20
Maintenance Schedule	20
Routine Maintenance.....	21
Batteries	21
Battery Safety	21
Battery Care	21
Electrolyte Levels.....	22
Battery Watering System	22
Cleaning Batteries	22
Battery Replacement	22
Lifting the Vehicle	23
Lubrication	23
Brakes	24
Tires and Wheels.....	24
COMPONENTS - ELECTRICAL.....	26
Basic Electrical Components	26
Onboard Battery Charger	27
Motor	29
Controller	29
Battery Discharge Indicator (BDI)	34
Speed Control Pedal.....	34

Solenoid.....	34
Wiring Diagram.....	35
Parts List – Electrical	36
Parts List – Available Options	36
COMPONENTS - MECHANICAL	37
Parts List – Front Wheel Steer Assembly	37
Transaxle Diagram for PC series.....	38
Parts List – Transaxle for PC series.....	39
Transaxle Diagram for PCT series.....	40
Parts List – Transaxle for PCT series.....	41

INTRODUCTION

Thank you for choosing a Pack Mule Industrial Electric Vehicle, proudly built by Wesley International in the USA. At Wesley International, we are committed to providing you the best quality product backed by exceptional customer service. This owner's manual and service guide is provided to help you get the most out of your new vehicle, for many years to come.

RECORD YOUR PRODUCT INFORMATION

Model #: _____

Serial #: _____

Purchase Date: _____

REGISTER YOUR PRODUCT

PRODUCT REGISTRATION IS REQUIRED FOR WARRANTY COVERAGE.

Registration is easy. Simply go to <http://www.packmule.com/support/warranty/> and complete the online form and click submit. That's it! And it will entitle you to free parts for any defective items, as outlined in our warranty document.

READ THIS MANUAL

Before operating or working on your new vehicle, read this manual to become familiar with the safety guidelines, operating instructions, and maintenance procedures.

IF YOU NEED HELP

You will find many answers to common problems within this manual or online at www.packmule.com. If you do not find what you need, we are always ready and willing to help. Just email us at info@wesleyintl.com or call (800) 241-2869 or (404) 292-7441.

Wesley International
3680 Chestnut Street
Scottsdale, GA 30079
Phone (404) 989-7441 • Toll Free (800) 241-2869 • Fax (404) 292-8469
info@wesleyintl.com
www.wesleyinternational.com

SAFETY INFORMATION

The responsibility of safety lies with four main groups: manufacturers, owners, operators and maintenance personnel. This manual has been designed to assist the owner-operator in operating and maintaining the vehicle in a safe manner, in accordance with the procedures and standards to which the vehicle was designed and intended for use.

TRAINING

Vehicle owners are responsible for instructing their personnel in its safe operation. Owners must explain the vehicle's characteristics, features, operation of its controls, and safe driving practices. We strongly recommend that owners first become familiar with the conditions of the place where the vehicle will be operated in order to assess its effect on safe operation. Training should occur under the conditions of the operating environment while adhering to the safety guidelines and include:

- Safety guidelines
- Operation of the vehicle under the conditions in which it will be operated
- Operation of all controls
- Safe driving practices
- A driving and operating test

OPERATOR QUALIFICATIONS

Operators should be selected based on their ability to safely operate the vehicle, including vision, hearing, physical and mental capabilities. Operators must:

- Demonstrate a working knowledge of all controls
- Understand all safety guidelines
- Be able to properly drive and park the vehicle under the conditions in which the vehicle will be used
- Know how to properly load and unload cargo and passengers
- Recognize maintenance problems

SAFETY GUIDELINES

All Pack Mule vehicles are designed for use on smooth surfaces in and around industrial plants, warehouses, nurseries and greenhouses. They are not intended for use outdoors, up and down steep grades, or on public roads and highways.

Follow these guidelines to safely drive the vehicle:

- Read this manual before operating the vehicle
- Read, understand and observe all labels affixed to the vehicle
- Do not start the vehicle without checking the brakes first
- Do not mount or dismount the vehicle when the key is in the ON position
- Do not drive the vehicle if the accelerator requires excessive pressure
- Do not park or operate the vehicle near flammable objects or in a flammable or hazardous environment
- Use only necessary power
- Keep both hands on the steering wheel while operating the vehicle
- Accelerate and decelerate slowly and in a controlled manner
- Always reduce speed to compensate for poor terrain or conditions
- Always maintain adequate distance between vehicles, people, and obstacles
- Do not use the vehicle to push objects
- Do not allow the tires to lose contact with the ground
- Proceed around low overhangs with caution. Be sure there is enough clearance for the operator's head and the highest point of the vehicle or any attached accessories.
- Never abruptly change direction
- Always drive directly up an incline; never across
- Never exceed the designated passenger, load or towing capacity

On grades, it is possible for vehicles to coast at greater than normal speeds encountered on a flat surface. To prevent loss of vehicle control and possible serious injury, speeds should be limited to no more than maximum speed on level ground.

Good common sense and prudent driving practices do more to prevent accidents and injuries than all of the warnings and instructions combined. Wesley International strongly suggests that the owner-operator read this entire manual paying particular attention to the CAUTIONS and WARNINGS contained therein.

SAFETY INFORMATION

Wesley International LLC reserves the right to make design changes without obligation to make these changes on units previously sold and the information contained in this manual is subject to change without notice.

Wesley International LLC is not liable for errors in this manual or for incidental or consequential damages that result from the use of the material in this manual.

LOADING AND UNLOADING

Follow these guidelines when loading and unloading cargo:

- Turn the vehicle off while loading
- Do not exceed the maximum passenger or cargo load capacity
- Carefully and evenly position all loads
- Secure cargo so that nothing can easily fall off of the vehicle
- Be extremely careful carrying loads that extend beyond the vehicle's deck

TOWING

Follow these guidelines when towing:

- Turn the vehicle off when connecting equipment that will be towed
- Always use a properly installed hitch (Optional hitches available from Wesley International)
- Do not exceed the maximum towing capacity
- Do not exceed 5 mph when towing
- Take extreme care when towing down an incline

MAINTENANCE

Always maintain your vehicle in accordance with the service schedule within this manual and keep complete records of the maintenance history of the vehicle. Ensure the maintenance personnel performing any service or repair work on the vehicle are trained and qualified to do so. Be sure to disable the vehicle before performing any maintenance including removing the key from the key switch and removal of a battery cable.



WARNING

Always insulate any tools used within the battery area in order to prevent sparks or battery explosion caused by shorting the battery terminals or associated wiring.

Be sure to check the polarity of each battery terminal and be sure to rewire the batteries correctly. Never install a wire instead of a proper fuse, even for a temporary fix. It may cause extensive damage and possible fire. Do not use a screwdriver or other metal object to remove fuses. Doing so may cause an electrical short and damage the system. Do not modify or tamper with any part of the operating or speed control systems. All inspections and adjustments must be made by a qualified technician.

Always support the vehicle using wheel chocks and safety stands. Never get under a vehicle that is supported by a jack. Lift the vehicle in accordance with the instructions in this manual.

Always test drive the vehicle after any repairs or maintenance in a safe area free of any other vehicles or pedestrians.

Wesley recommends that only OEM replacement parts be used. Using any parts other than those approved by Wesley may result in the warranty being made void.

VENTILATION



WARNING

Hydrogen gas is generated in the charging cycle of batteries and is explosive in concentrations as low as 4%. Because hydrogen gas is lighter than air, it will collect in the ceilings of buildings and therefore, proper ventilation is required. Five air exchanges per hour is considered the minimum ventilation required.

Always use a dedicated circuit for each battery charger. Do not permit other appliances to be plugged into the receptacle when the charger is in operation.

INDUSTRY STANDARDS

The following text is provided as recommended by Part II, "For the User", of ANSI/ITSDF B56.8-2011, Safety Standard for Personnel and Burden Carriers. The manufacturer strongly endorses the contents of this specification.

6 GENERAL SAFETY PRACTICES

6.1 Introduction

6.1.1 Like other machines, carriers can cause injury if improperly used or maintained. Part II contains broad safety practices applicable to carrier operation. Before operation, the user shall establish such additional specific safety practices as may reasonably be required for safe operation.

6.1.2 Premise review — The user shall periodically review their premises, and as conditions warrant, identify areas where carriers should not be operated and to identify possible hazards such as the following examples:

(a) Steep Grade — In areas where steep grades exist, carrier operation should be restricted to the designated vehicle's pathways where possible, and shall be identified with a suitable warning giving the following information: "Warning, steep grade."

(b) Wet Areas — Wet areas could cause a carrier to lose traction and could affect steering, stability and braking.

(c) Sharp Turns, Blind Spots, Bridge Approaches — Sharp turns, blind spots, bridge approaches, and other potentially hazardous areas shall be identified with a suitable warning to the operator of the nature of the hazard and stating the proper precautions to be taken to avoid the hazard.

(d) Loose Terrain — Loose terrain could cause a carrier to lose traction and could affect steering, stability, and braking.

6.2 Operation

Experience has shown that carriers, which comply with the provisions, stated in paragraphs 9.4, 9.5, and 9.6 are stable when properly operated and when operated in accordance with specific safety rules and practices established to meet actual operating terrain and conditions. However, improper operation, faulty maintenance, or poor housekeeping may contribute to a condition of instability and defeat the purpose of the standard. Some of the conditions which may affect stability are failure of the user to follow safety practices; also, ground and floor conditions, grade, speed, loading, the operation of the carrier with improper loads, battery weight, dynamic and static forces, and the judgment exercised by the carrier operator.

(a) The user shall train carrier operators to adhere strictly to the operating instructions stated in this Standard.

(b) The user shall survey specific operating conditions and environment, and establish and train carrier operators to comply with additional, specific safety practices.

6.3 Nameplates, Markings, Capacity, and Modifications

6.3.1 The user shall maintain in a legible condition all nameplates, warnings, and instructions, which are supplied by the manufacturer.

6.3.2 Except as provided in 6.3.4, no modifications or alterations to a carrier, which may affect the capacity, stability, or safe operation of the carrier, shall be made without the prior written approval of the original carrier manufacturer or a successor thereof. When the carrier manufacturer or its successor approves a modification or alteration, appropriate changes shall be made to capacity plates, decals, tags, and operation and maintenance manuals.

6.3.3 As required under paragraphs 6.3.1 or 6.3.2, the manufacturer shall be contacted to secure new nameplates, warnings, or instructions, which shall then be affixed in their proper place on the carrier.

6.3.4 In the event that the carrier manufacturer is no longer in business and there is no successor in interest to the business, the user may arrange for a modification or alteration to a carrier, provided however, the controlling party shall:

(1) Arrange for the modification or alteration to be designed, tested, and implemented by an engineer(s) expert in carrier(s) and their safety;

(2) Maintain a permanent record of the design, test(s), and implementation of the modification or alteration;

(3) Make appropriate changes to the capacity plate(s), decals, tags, and operation and maintenance manuals;

(4) Affix a permanent and readily visible label on the carrier stating the manner in which the carrier has been modified or altered together with the date of the modification or alteration, and the name of the organization that accomplished the tasks.

6.4 Fuel Handling and Storage

6.4.1 The user shall supervise the storage and handling of liquid fuels (when used) to be certain that it is in accordance with ANSI/NFPA 505 and ANSI/NFPA 30 or as required by local ordinance.

6.4.2 Storage and handling of liquefied petroleum gas fuels shall be in accordance with ANSI/NFPA 505 and ANSI/NFPA 58 or as required by local ordinance. If such storage or handling is not in compliance with these standards, the user shall prevent the carrier from being used until such storage and handling is in compliance with these standards.

6.4.3 Prevent fire and explosion caused by static electric discharge. Use only non-metal, portable fuel containers approved by the Underwriter's Laboratory (U.L.) or the American Society for Testing & Materials (ASTM). If using a funnel, make sure it is plastic and has no screen or filter.

INDUSTRY STANDARDS

Static electric discharge can ignite gasoline vapors in an ungrounded fuel container. Remove the fuel container from the bed of a carrier or the trunk of a car and place on the ground away from the carrier before filling. Keep nozzle in contact with container opening while filling.

When practical, remove equipment from trailers or truck beds and re-fuel them on the ground. If this is not possible, use a portable, plastic fuel container to refuel equipment on a truck bed or trailer.

6.5 Changing and Charging Storage Batteries for Electric Personnel and Burden Carriers

6.5.1 The user shall require battery changing and charging facilities and procedures to be in accordance with ANSI/NFPA 505 or as required by local ordinance.

6.5.2 The user shall periodically inspect facilities and review procedures to be certain that ANSI/NFPA 505 or as required by local ordinance, are strictly complied with, and shall familiarize carrier operators with it.

6.5.3 Maintenance and storage areas for carriers shall be properly ventilated to avoid fire hazards in accordance with applicable fire codes and ordinances. Ventilation for internal combustion engine powered carriers shall be provided to remove flammable vapors (gases), fumes and other flammable materials. Consult applicable fire codes for specific levels of ventilation.

Ventilation for electric powered carriers shall be provided to remove the accumulation of flammable hydrogen gas emitted during the battery charging process.

The amount of hydrogen gas emitted depends upon a number of factors such as the condition of the batteries, the output rate of the battery charger and the amount of time the batteries are on charge. Because of the highly volatile nature of hydrogen gas and its propensity to accumulate in pockets, a minimum number of air changes per hour is required during charging.

Consult applicable fire and safety codes for the specific ventilation levels required as well as the use of explosion proof electrical apparatus. SAE J1718 can be followed to check for hydrogen gas levels.

6.6 Hazardous Locations

6.6.1 The user shall determine the hazard classification of the particular atmosphere or location in which the carrier is to be used in accordance with ANSI/NFPA 505.

6.6.2 The user shall permit in hazardous areas only those carriers approved and of the type required by ANSI/NFPA 505.

6.7 Lighting for Operating Area

The user, in accordance with his responsibility to survey the environment and operating conditions, shall determine if the carrier requires lights and, if so, shall equip the carrier with appropriate lights.

6.8 Control of Noxious Gases and Fumes

When equipment powered by internal combustion engines is used in enclosed areas, the atmosphere shall be maintained within limits specified in the American Conference of Governmental Industrial Hygienists publication, "Threshold Limit Values for Chemical Substances and Physical Agents in the Workroom Environment." This may be accomplished by ventilation provided by the user, or the installation, use, and proper maintenance of emission control equipment recommended or provided by the manufacturer of the equipment.

6.9 Warning Device(s)

6.9.1 The user shall make periodic inspections of the carrier to be certain that the sound-producing and/or visual device(s) if so equipped are maintained in good operating condition.

6.9.2 The user shall determine if operating conditions require the carrier to be equipped with additional sound producing or visual devices or both and be responsible for providing and maintaining such devices, in accordance with the manufacturer's recommendations.

6.10 Safety Interlocks

The user shall make periodic inspections of the carrier to be certain that the safety interlock system, if so equipped, is operating properly.

7 OPERATING SAFETY RULES AND PRACTICES

7.1 Personnel and Burden Carrier Operator Qualifications

Only persons who are trained in the proper operation of the carrier shall be authorized to operate the carrier. Operators shall be qualified as to visual, auditory, physical, and mental ability to safely operate the equipment according to Section 7, all other applicable parts of this Standard and the operators' manual.

7.2 Personnel and Burden Carrier Operators' Training

7.2.1 The user shall conduct an operators' training program.

7.2.2 Successful completion of the operators' training program by the operator shall be required before operation of the carrier. The program shall be presented in its entirety to all-new operators and not condensed for those claiming previous experience.

INDUSTRY STANDARDS

7.2.3 The user shall include as a minimum in the operators' training program the following:

- (a) Instructional material provided by the manufacturer including the operators' manual;
- (b) Emphasis on safety of passengers, material loads, carrier operator, and other person(s);
- (c) General safety rules contained within this Standard and the additional specific rules determined by the user in accordance with this Standard, and why they were formulated;
- (d) Introduction of equipment, control locations and functions, and explanation of how they work when used properly and when used improperly; and surface conditions, grade, and other conditions of the environment which could affect carrier operation;
- (e) Operator competency evaluations.

7.3 Personnel and Burden Carrier Operator Responsibility

7.3.1 General Operator Responsibility

7.3.1.1 Read and follow operators' manual.

7.3.1.2 Do not operate carrier under the influence of drugs and alcohol.

7.3.1.3 Safeguard the pedestrians at all times. Do not drive carrier in a manner that would endanger other persons.

7.3.1.4 Riding on the carrier by persons other than the operator is authorized only on personnel seat(s) provided by the manufacturer. All parts of each person's body shall remain within the plan view outline of the carrier.

7.3.1.5 When a carrier is to be left unattended, stop the carrier, apply the parking brake, stop the engine or turn off power, turn off the control or ignition circuit, and remove the key if provided. Additionally, for electric carriers, the forward and reverse directional controls, should be neutralized if a means is provided. Block the wheels if the carrier is on an incline.

7.3.1.6 A carrier is considered unattended when the operator is 7.6m (25 ft) or more from the carrier which remains in his view, or whenever the operator leaves the carrier and it is not within his view. When the operator is dismounted and within 7.6m (25 ft) of the carrier still in his view, he still must have controls neutralized, and the parking brake(s) set to prevent movement.

7.3.1.7 Maintain a safe distance from potential hazards, such as edges of ramps and platforms.

7.3.1.8 Use only approved carriers in hazardous locations, as defined in the appropriate safety standards.

7.3.1.9 Report all accidents to the user.

7.3.1.10 Do not add to, or modify, the carrier.

7.3.1.11 Carriers shall not be parked or left unattended such that they block or obstruct fire aisles, access to stairways, or fire equipment.

7.3.1.12 Only operate carrier while within operator's station.

7.3.2 Traveling

7.3.2.1 Observe all traffic regulations, including authorized speed limits. Under normal traffic conditions keep to the right. Maintain a safe distance, based on speed of travel, from a carrier or vehicle ahead; and keep the carrier under control at all times.

7.3.2.2 Yield the right of way to pedestrians, ambulances, fire trucks, or other carriers or vehicles in emergency situations.

7.3.2.3 Do not pass another carrier or vehicle traveling in the same direction at intersections, blind spots, or at other dangerous locations.

7.3.2.4 Keep a clear view of the path of travel, observe other traffic and personnel, and maintain a safe clearance.

7.3.2.5 Slow down or stop, as conditions dictate, and activate the sound-producing warning device at cross aisles and when visibility is obstructed at other locations.

7.3.2.6 Ascend or descend grades slowly.

7.3.2.7 Avoid turning, if possible, and use extreme caution on grades, ramps, or inclines; normally travel straight up and down.

7.3.2.8 Under all travel conditions the carrier shall be operated at a speed that will permit it to be brought to a stop in a safe manner.

7.3.2.9 Make starts, stops, turns, or direction reversals in a smooth manner so as not to shift the load, endanger passengers, or lose control of the carrier.

7.3.2.10 Do not operate carrier in a dangerous manner.

7.3.2.11 Slow down when approaching, or on, wet or slippery surfaces.

7.3.2.12 Do not drive carrier onto any elevator unless specifically authorized to do so. Approach elevators slowly, and then enter squarely after the elevator car is properly leveled. Once on the elevator, neutralize the controls, shut off power, and set parking brakes. It is advisable that all other personnel leave the elevator before a carrier is allowed to enter or exit.

7.3.2.13 Avoid running over loose objects, potholes, and bumps.

INDUSTRY STANDARDS

7.3.2.14 Reduce carrier speed to negotiate turns.

7.3.2.15 Avoid any action verbal or physical by an operator or passenger, which could cause the operator to be distracted.

7.3.3 Loading

7.3.3.1 Refer to operators' manual for loading instruction.

7.3.3.2 Handle only stable and safely arranged loads. When handling off-center loads, which cannot be centered, operate with extra caution.

7.3.3.3 Handle only loads within the capacity of each cargo area of the carrier as specified by the manufacturer.

7.3.3.4 Avoid material loads exceeding the physical dimensions of the carrier or as specified by the carrier manufacturer.

7.3.4 Operator Care of Personnel and Burden Carriers

7.3.4.1 Read and follow operators' manual.

7.3.4.2 At the beginning of each shift during which the carrier will be used, the operator shall check the carrier condition and inspect the tires, warning devices, lights, battery(s), speed and directional controllers, brakes, safety interlocks, and steering mechanism. If the carrier is found to be in need of repair or in any way unsafe, the matter shall be reported immediately to the user and the carrier shall not be operated until it has been restored to safe operating condition.

7.3.4.3 If during operation the carrier becomes unsafe in any way, the matter shall be reported immediately to the user, and the carrier shall not be operated until it has been restored to safe operating condition.

7.3.4.4 Do not make repairs or adjustments unless specifically trained and authorized to do so.

7.3.4.5 Before refueling, the engine shall be stopped and allowed to cool. The operator and passengers shall leave the carrier before refueling.

7.3.4.6 Spillage of hazardous materials shall be contained immediately and addressed via appropriate hazardous materials regulations.

7.3.4.7 Do not operate a carrier with a leak in the fuel system or battery(s). Battery(s) shall be charged and serviced per manufacturer's instructions.

7.3.4.8 Do not use open flames for checking electrolyte level in storage battery(s) or liquid level in fuel tanks.

8 MAINTENANCE PRACTICES

8.1 Introduction

Carriers may become hazardous if maintenance is neglected. Maintenance facilities, trained personnel, and procedures shall be provided. Such facilities may be on or off the premises.

8.2 Maintenance Procedures

Maintenance and inspection of all carriers shall be performed in conformance with the following practices and should follow the manufacturer's recommendations.

(a) A scheduled preventive maintenance, lubrication, and inspection system shall be followed.

(b) Only trained and authorized personnel shall be permitted to maintain, repair, adjust, and inspect carriers.

(c) Before undertaking maintenance or repair, follow the manufacturer's recommendations for immobilizing the carrier.

(d) Chock wheels and support carrier, before working underneath it.

(e) Before disconnecting any part of the engine fuel system, be sure the shutoff valve, if so equipped, is closed and follow carrier manufacturer's recommended practice.

(f) Operation to check performance of the carrier shall be conducted in an authorized area where suitable conditions exist, free of vehicular and pedestrian traffic.

(g) Before returning carrier to service, follow the manufacturer's instructions and recommended procedures.

(h) Avoid fire hazards and have fire protection equipment present in the work area. Do not use an open flame to check level or leakage of fuel, battery electrolyte, or coolant.

(i) Properly ventilate the work area in accordance with applicable regulations or local ordinance.

(j) Handle fuel cylinders with care. Physical damage, such as dents, scrapes, or gouges, may dangerously weaken the tank and make it unsafe for use.

(k) Brakes, steering mechanisms, speed and directional control mechanisms, warning devices, lights, governors, guards, and safety devices shall be inspected regularly and maintained in accordance with manufacturer's recommendations.

(l) Special carriers or devices designed and approved for hazardous area operation shall be inspected to ensure that maintenance preserves the original approved safe operating features.

(m) Fuel systems shall be checked for leaks and condition of parts. If a leak is found, action shall be taken to prevent the use to the carrier until the cause of the leak has been repaired.

(n) The carrier manufacturer's capacity, operation, and maintenance instruction plated, tags, or decals shall be maintained in legible condition.

(o) Batteries, motors, speed and directional controllers, limit switches, protective devices, electrical conductors/insulators, and connections shall be inspected and maintained per carrier manufacturer's recommendation.

(p) Carriers shall be kept in a clean condition to minimize hazards and facilitate detection of components needing service

INDUSTRY STANDARDS

(q) Modifications and additions which affect capacity and safe carrier operation shall not be performed without manufacturer's prior written authorization; where authorized modifications have been made, the user shall ensure that capacity, operation, warning, and maintenance instruction plates, tags, or safety labels are changed accordingly.

(r) Care shall be taken to ensure that all replacement parts are interchangeable with the original parts and of a quality at least equal to that provided in the original equipment.

(s) Disconnect batteries, negative connection(s) first. When reconnecting, connect positive connection first.

(t) Hydraulic systems, if so equipped, shall be checked for leaks, for condition of parts. Keep body and hands away from pin-holes or nozzles that eject fluids under high pressure. Use paper or cardboard, not hands, to check for leaks.

OPERATING INSTRUCTIONS

INITIAL CHECKLIST

Use the following checklist to inspect and prep your vehicle prior to initial use.

- ☐ Check for evidence of leaking fluids, i.e. brake fluid, battery acid, or gear oil.
- ☐ Check condition of tires and tire air pressure. Maximum 90 psi Cold; 60 psi recommended. (Pneumatic tires only).
- ☐ Check to ensure wheel lug nuts are tight.
- ☐ Check that all battery connections are tight.
- ☐ Check for smooth operation of controls, switches, and brakes.
- ☐ Charge batteries.

IDENTIFICATION



FIGURE 1

The product model number, serial number, and year of manufacture is located on a silver label as shown in Figure 1, either on the front of the vehicle near the switches, on the underside of the plate where the seat is mounted, or inside the motor compartment attached to a side panel.

Whenever you correspond with Wesley International regarding your vehicle, be sure to include this information.

CHARGING BATTERIES

Our Pack Mule electric vehicles come standard with an onboard charger. They also come available with a slide out battery system, in which case, no onboard charger is included. If your unit comes with the onboard charger, place the vehicle in a well-ventilated area and follow these steps to charge the battery:

1. Position vehicle within reach of an electrical outlet.
2. Slide seat to the rear most position and tilt forward to open battery compartment.
3. Check all battery cells for proper acid level. Fluid should be above plates.
4. Plug the charger AC line cord into the IEC receptacle located on the rear of the vehicle (Figure 2), and the other end into the wall receptacle



FIGURE 2

CAUTION: Extension cords must be a 3-wire cord no longer than 30m (100') at 10AWG or 7.5m (25') at 16 AWG per UL guidelines. Only connect ONE charger to a single 15A circuit or the circuit

may become overloaded.

VEHICLE CONTROLS, METERS, SWITCHES

The controls, meters and switches consist of:

- Key Switch, Perma-Key Switch, or On/Off Switch
- FWD/REV Directional Selector Switch
- Battery Discharge Indicator (BDI)
- Headlight / Tail Light Switch (Optional)
- Parking Brake
- Speed Control Pedal
- Brake Pedal
- Horn Button
- Seat Presence Sensor Switch
- Foot Presence Switch (Optional)

Key Switch: For vehicles equipped with a key switch, Figure 3, the vehicle only operates when the key is in the switch. It has three positions – run, off, and charge only.



FIGURE 3

Perma-Key Switch (Optional): An optional Perma-Key switch is available to replace the standard key switch. It works the same way but eliminates the need for a separate key that may get lost. It has three positions – run, off, and charge only.

On/Off Rocker Switch (Optional): An optional 2 position on/off Rocker switch is available to replace the standard key switch. Figure 4.



FIGURE 4

OPERATING INSTRUCTIONS



WARNING

To prevent unexpected vehicle movement or unauthorized use, always turn the key switch to the OFF position and remove the key when the vehicle is not in use.

Programmable Security Switch (Optional): SAFE-T-LOCK™ is a programmable code switch, as shown in Figure 5, which prevents unauthorized use of the vehicle, and is



FIGURE 5

offered as an option, part number EV-E901. The SAFE-T-LOCK switch is installed in lieu of the standard switch to control access and operation of the vehicle within the customer's premises. It can be pre-installed at time of order, or purchased separately to upgrade existing vehicles.

The STL1000 switch allows plant and facility managers to input up to 99 different users/drivers to track vehicle usage. If an accident occurs, or the vehicle is damaged, the manager can easily identify the last operator. The switch also features an internal clock that records "on" hours and notifies the operator when the vehicle reaches the 250-hour mark.

Each user can select a four- to eight-digit personal access code and a separate supervisor user menu programs the unit. The switch will provide the last user ID code when prompted by the supervisor. In operation, only users with active ID codes can operate the vehicle, virtually eliminating all unauthorized use, the company said.

The switch operates in a voltage range from 9 to 120 volts DC and is enclosed in an IP65 rated housing. Two internal LEDs indicate operational status - red indicates an error or lock mode and green indicates key press or touch is active. The unit also provides user feedback with key beep and error tones.

Step-by-Step Programming Instructions:

1 – Log onto the Supervisor Mode. Press 0 0 1 2 3 4 ENTER. Red and Green LED flashes along with an up tone beep indicate you are in the Supervisor Mode and ready to enter a Supervisor Mode menu.

Note: As you enter each Supervisor Mode menu, the number of Red LED flashes will correspond to the menu number. For example, one Red LED flash for menu 1, two Red LED flashes for menu 2, etc.

Before changing the Supervisor PIN, you are first going to add User locations. For this example you will check on and add User location 01 as well as more User locations as

required. To do this you must go into the Add / Delete User Menu.

2 – Go into Add / Delete User Menu. Press 2 ENTER. There will be a beep along with two Red LED flashes indicating you are in Menu 2. Press 0 1 ENTER. If there is a Red flash and a low beep, it indicates that user location 01 has already been assigned. To remove location 01, press ENTER again. This will delete the location from use.

Add location 01. Press 0 1 ENTER. You should now get a Green flash along with an up tone beep indicating the location is ready to be added or assigned to a user. Press ENTER. You will get a Green LED flash along with a beep. The user location has been added.

At this point you can, in the same way, check on and add more user locations.

Before leaving Menu 2, check to make sure that location 01 and any others have been added. Press 0 1 ENTER. There should be a Red LED flash along with a low tone beep indicating the location has been assigned to the user. Check any other locations you've added the same way. A Red flash along with a low tone beep means the location has been assigned. A Green flash along with an up tone beep means the location is not assigned.

3 – Go out of Menu 2. Press CE. The switch will indicate you are back in Supervisor Mode. Press CE again to go out of Supervisor Mode. (CE can be pressed several times to make sure you are completely clear and ready to enter the next mode.)

4 – Log onto the User Mode. Press 0 1 1 2 3 4 ENTER. The switch will close and the Green LED will flash at a slow rate.

5 – Change User PIN. First decide on a new PIN. In this example use 5 4 3 2 1. Press 1, ENTER. (This puts you in the Change User PIN Menu.) Note that the switch will open when you go into this menu.

Note: The User has 1 minute after logging on the User Mode to use menu 1 before the menu function is locked out until the next User log on.

Press 5 4 3 2 1 ENTER, again press 5 4 3 2 1 ENTER. The switch will indicate that the new PIN has been accepted.

6 – Use the new PIN to close the switch. Press 0 1 5 4 3 2 1 ENTER. The switch will close. Press ENTER to open the switch and go out of User Mode. (Since this is an example, you may want to set the PIN for User location 01 back to the 1 2 3 4 default.)

7 – Log back onto the Supervisor Mode to change the Supervisor PIN. Press 0 0 1 2 3 4 ENTER. Press 1 ENTER to go into the Change Supervisor PIN Menu. The red LED will flash once. Now just you did in the User Mode, put the new PIN in twice and enter each time. Example: Press 5 4 3 2 1 ENTER, again 5 4 3 2 1 ENTER. The switch will give an indication that the PIN was changed.

OPERATING INSTRUCTIONS

8 – Go out of Menu 1. Press CE. Press CE again to Log Off the Supervisor Mode.

9 – Check out the new Supervisor PIN. Press 0 0 5 4 3 2 1 ENTER. You should be in Supervisor Mode. You can now go to any menu by pressing the menu number and ENTER. Remember: This is an example. You should change your Supervisor PIN to one known only to you.

10 – Determine Last user. While in Supervisor Mode press 3 ENTER. This places you in the Last User Menu as indicated by three red LED flashes. Press ENTER again. The LED flashes will indicate the last user. The Green LED is for the 10's digit. The Red LED is for the 1's digit. Example 1: A single Red LED flash indicates User 01 last operated the vehicle. Example 2: Two Green flashes and three Red flashes would indicate User 23 last operated the vehicle. Press CE to leave the menu.

11 – Enable or Disable Maintenance Alarm. Press 4 ENTER. There will be four red LED flashes. Press ENTER again. If the Green LED flashes, the alarm is enabled. Press ENTER again and the Red LED will flash showing the alarm to be disabled. Press ENTER again and the Green LED will flash showing the alarm to be again enabled.

12 – Listen to the maintenance alarm. While in Menu 4 press 1 ENTER. The maintenance alarm will sound. Press CE to leave the menu. Press CE again to Log Off the Supervisor Mode.

Note: If the switch is left unattended in Supervisor mode, it will automatically exit the mode after approximately one minute.

13 – If you are unable to get into the Supervisor mode after trying either the default PIN or a newly assigned PIN, go back to Step 1 and reset the switch.

If all else fails or if you have questions about programming or installing the SAFE-T-LOCK, call Tech Support at 1-800-241-2869.

Directional Switch: The directional rocker or toggle switch is used to place the vehicle in one of three operating modes – forward, reverse, or neutral. Figure 6 shows a rocker directional switch.

NOTE

The directional switch **MUST** be in NEUTRAL (center) position **BEFORE** selecting vehicle "ON" or a "Static Return to Off" (SRO) error code will be generated by the motor controller. The vehicle is temporarily immobilized as a standard safety feature. Also, if the unit is already turned on and in neutral position, the foot presence switch **MUST** be engaged before the directional switch is placed in forward or reverse mode, or the same error code will be displayed and the vehicle temporarily immobilized. If this error code is displayed, the operator simply needs to turn the directional switch back to neutral, ensure the foot presence switch is

engaged, and then switch the directional Switch to the desired forward or reverse position and the vehicle will operate.



FIGURE 6



WARNING To prevent unexpected vehicle movement when the vehicle is next driven, always place the directional switch in the NEUTRAL position when leaving the vehicle.

Battery Discharge Indicator (BDI): The battery discharge indicator, shown in Figure 7, communicates directly with the onboard controller and provides information on various system parameters, such as battery state-of-charge, operating hours (on some models), or maintenance status including error codes.



FIGURE 7

When powering on the vehicle, the BDI first indicates the hours (Note: The controller is programmed to indicated traction hours, which is the time that the motor is engaged and the vehicle is moving. The controller can be programmed to display "key-on" hours which records time that the key switch is in the on position, regardless of whether it is moving or not). It then cycles through to the state of battery charge, measured in percent charge remaining. If there are any faults recorded by the controller, the BDI will display an error code and the LED by the tool wrench symbol will illuminate.

OPERATING INSTRUCTIONS

Headlight / Tail-Light and Switch (Optional): Some vehicles may include the headlight (Figure 9) and/or tail-light (Figure 8) option. In which case, there will also be a rocker switch to turn the lights on or off. An example of this switch on the PC-300 model is shown in Figure 10.



FIGURE 8



FIGURE 9



FIGURE 10

Parking Brake (Optional): The parking brake lever is lifted up to place the parking brake on as shown in Figure 11 and it also disables the motor controller in the process. To release, simply push the lever forward and into the down position as shown in Figure 12.

The tension of the parking brake can be adjusted by simply twisting the parking brake handle, while the parking brake is in the forward and down, dis-engaged position. Turning the handle counter clockwise tightens the tension applied, as shown in Figure 13. Turning the handle clockwise loosens the tension. Be careful not to over tighten or the life of the brake cable may be shortened.



FIGURE 11



FIGURE 12




FIGURE 13

OPERATING INSTRUCTIONS

Speed Control Pedal: The speed control pedal, Figure 14, is located to the right of the brake pedal. It controls the speed of the vehicle and is operated with the right foot like the accelerator of an automobile. Depressing the pedal starts the motor. Releasing the pedal stops the motor. Reverse speed is half of forward speed.



FIGURE 14

Brake Pedal: The brake pedal, Figure 15, is located to the left of the accelerator pedal and is the smaller of the two. Applying pressure on the brake pedal will slow the vehicle down in addition to the motor braking. If driving down an incline, the brake pedal should be used to control the speed.



FIGURE 15

Where a separate parking brake is not included, the brake pedal has a brake lock feature which can lock the brake pedal into the down position as shown in Figure 16, thus acting as a parking brake. Simply push the brake pedal all the way down while pushing at the bottom edge of the brake pedal. This will engage the black pedal lock to latch onto the body frame, retaining the brake pedal in the engaged position.

To release, simply push the top edge of the brake pedal and the brake pedal will disengage and be free to move to its disengaged position, as shown in Figure 17.




FIGURE 16




FIGURE 17

Horn and Horn button: The horn button is either located on the right hand handle bar, or for tiller steering, on the left side of the floor board. Both work the same way and controls the horn which is located in the rear compartment, mounted to the top of the left rear wheel well. If mounted on the handle bars as shown in Figure 18, the horn button is operated by hand. If mounted on the floor board as shown in Figure 19, it is foot operated.



FIGURE 18



FIGURE 19

The horn (Figure 20) will not sound when the key or on/off switch is in the off position.

OPERATING INSTRUCTIONS



FIGURE 20

Back-Up or Proximity Alarm (Optional): Optionally, a back-up or proximity alarm may be installed on the vehicle if it was ordered with this option as shown in Figure 21. The back-up alarm only sounds when the directional switch is placed in the reverse position. The proximity alarm sounds when the directional switch is placed in either the forward or reverse position.




FIGURE 21

Seat Presence Sensor Switch: The presence sensor switch is located under the seat as shown in Figure 22 and is designed to prevent operation of the vehicle unless a person is sitting down on the seat. If the driver stands up or falls off the seat while the vehicle is in motion, the presence sensor switch will disable the vehicle, allowing it to come to a stop.




FIGURE 22

Foot Presence Switch (Optional): The foot presence switch, if present as shown in Figure 23, is located on the left side of the floor board. This is an added safety feature which may be used alone or in combination with the seat presence sensor switch, to prevent the vehicle from operating unless this foot switch is first depressed. The operator must use their left foot to depress the foot presence switch before the vehicle will move and should the operator's foot leave the foot presence switch during while the vehicle is moving, the motor will disengage and the vehicle will slow to a stop.



FIGURE 23

OPERATING INSTRUCTIONS

DRIVING

Follow these steps to operate your Pack Mule vehicle:

- 1) **Disconnect the battery charger.**
Remove the battery charger cord from the power outlet. Disconnect the charger cord from the charger receptacle located on the rear of the vehicle and place the charger cord in its holder under the rear cargo deck.
 - 2) **Check for correct tire inflation (pneumatic tires only).**
 - 3) **Inspect for fluid leaks.**
 - 4) **Ensure surrounding area is clear of all obstructions and everything properly stored and secured.**
 - 5) **Make sure you are properly seated in the operator's seat.**
 - 6) **Turn the key or on/off switch to the ON position.**
Be sure that the directional switch is in the neutral position and the accelerator pedal is not depressed. Insert the key into the ignition switch (if a key switch) located on the instrument panel. Turn the key completely to the right to the ON position, or push the rocker or toggle switch to the ON position. The indicator light on the BDI should come on. If not, do not attempt to operate the vehicle.
 - 7) **Move the directional switch to the desired setting.**
Push the rocker or toggle directional switch to either the forward or reverse position.
 - 8) **Press the speed control pedal.**
Depress the speed control pedal with your foot in a controlled manner. The speed of the vehicle will be proportional to the amount of pressure applied to the pedal. The controller converts the signal from the accelerator, regulating the speed, acting as an automatic transmission.
- NOTE** If the directional switch remains in the FORWARD or REVERSE position for more than 10 seconds without depressing the speed control pedal, the safety delay feature engages, and the vehicle will not move. The operator must place the directional switch to neutral, and then select the desired direction to resume motion.
- 9) **Stop**
Remove your foot from the speed control pedal and depress the separate brake pedal.

COASTING



WARNING

To prevent injury or death resulting from coasting at above recommended speeds, limit speed with service brake.

On steep ramps or hills, it is possible for the vehicle to coast at faster than normal speeds that may be encountered on a flat surface. To prevent loss of vehicle control, speeds should be limited to no more than the maximum speed on

level ground. Limit speed by removing your foot from the speed control pedal and applying pressure on the separate brake pedal.

LOADING/UNLOADING



WARNING

Make sure the vehicle has come to a complete stop before passengers embark/disembark or before loading/unloading any cargo. Turn off the vehicle when loading/unloading cargo. Do not exceed the specified number of passengers or load capacity of the vehicle. The maximum load capacity includes the combined weight of the passengers and cargo. Make sure the cargo is balanced and securely loaded. Do not load cargo that can easily fall off the vehicle, especially through turns. Be very careful when handling cargo that is longer or wider than the vehicle. Do not stack cargo so that the driver's view is obstructed.

PARKING

Place the directional switch in the PARK/NEUTRAL position. Turn the key switch to the OFF position. If parking on an incline, block the wheels to prevent the vehicle from rolling forward or backward.

TOWING

Attach one of the available hitches provided by Wesley International. Make sure the hitch is properly installed and secured. Attach the trailer to the hitch and the trailer safety chains to the provided safety chain holes. Do not exceed the specified towing capacity of the vehicle. The maximum tow capacity includes the combined weight of the trailers, the cargo on the trailers, and the combined weight of the passengers and cargo on the vehicle. Do not exceed 5 mph / 8 kph when towing.

MAINTENANCE INSTRUCTIONS

MAINTENANCE SCHEDULE

Safe trouble-free operation of your electric vehicle depends on regular and proper preventive maintenance. The following chart is a guide for servicing your Pack Mule electric vehicle.

SERVICE	DAILY	WEEKLY	MONTHLY 20 Hours	BI-ANNUAL 125 Hours	ANNUAL 250 Hours
Check all gauges, horn, and lights (if present)	X	X	X	X	X
Check BDI for battery charge	X	X	X	X	X
Plug-in battery charger when vehicle is not in service; Leave to charge overnight, if possible ¹	X	X	X	X	X
Check all battery cells for water levels after charging		X	X	X	X
Check tires for cuts, excessive wear, and pressure (check pressure when tires are cold ²)		X	X	X	X
Check wheels for bent rims, missing or loose lug nuts		X	X	X	X
Check brake linkage; Check brake linings and other components for wear and deterioration			X	X	X
Oil all moving parts that do not have fittings with an oiler or brush (SAE 30 oil)			X	X	X
Grease fork pivot fittings and gears with automotive grease using a grease gun			X	X	X
Check and tighten all loose nuts and bolts			X	X	X
Inspect steering, gear housing, and linkage Tighten as necessary			X	X	X
Check oil level in transaxle (SAE 80-90 oil)			X	X	X
Tighten any loose battery terminals and coat terminals with petroleum jelly			X	X	X
Clean batteries & terminals with ¼ cup (60 mL) baking soda to 1 ½ gal (6L) water; ensure charger is de-energized			X	X	X
Check electrolyte levels of all battery cells using hydrometer ³				X	X
Change oil in transaxle (SAE 80W-90 oil; 18 oz/0.5L)					X
Clean, inspect, & repack front axle and steering fork bearings with lithium based grease					X
Lubricate steering drive chain; Check for wear					X

¹ In freezing temperatures, recharge the batteries after adding distilled water to make sure the water mixes with the electrolyte properly. Otherwise, the water may freeze and damage the batteries.

² The recommended pneumatic tire pressure is 60 psi. Over- or under-inflation can reduce tire life and adversely affect vehicle handling. It may also lead to sudden tire failure, which can result in the driver losing control of the vehicle.

³ A hydrometer is used to determine if a battery is properly charged. It measures the specific gravity of the electrolyte (liquid) in the battery. The electrolyte is about 1.260 in specific gravity when the battery is fully charged and about 1.100 in specific gravity when the battery is fully discharged.

MAINTENANCE INSTRUCTIONS

ROUTINE MAINTENANCE

CAUTION

Before performing any maintenance or repair work, isolate the batteries from the motor and electronics by opening the circuit breaker shown in Figure 24. Simply push the red push button until the red side lever fully opens as shown in Figure 25. To close the circuit breaker, simply push the red side lever to its original closed position.



FIGURE 24



FIGURE 25

BATTERIES

The standard batteries used on Pack Mule vehicles are 6 volt lead acid. Other battery options are available such as AGM dry-cell batteries. This manual is written around the more common lead acid batteries. Batteries have a maximum life. Therefore, good maintenance is important to maximize the available life of the vehicle's batteries.

BATTERY SAFETY

Always observe the following warnings when working on or near batteries:



WARNING

To prevent burns or battery explosion that could result in severe personal injury or death, keep all smoking materials, open flame or sparks away from the batteries.

Hydrogen gas forms when charging batteries. Do NOT charge batteries without adequate ventilation. Only a 4% concentration of hydrogen gas is explosive.

Be sure the key switch or on/off switch is in the OFF position and all electrical accessories are off before starting work on the vehicle. Open the vehicle's circuit switch as shown in Figure 24 before starting work on the vehicle.

The electrolyte in a lead acid battery is an acid solution which can cause severe burns to the skin and eyes. Treat all spills to the body and eyes with extended flushing with clear water. Then contact a physician immediately.



Always wear approved safety goggles or face shield when handling or working around batteries.

Electrolyte spills will corrode the vehicle's structural frame and body if not properly treated immediately. In the event of a spill, wear proper protective clothing, gloves, and eye wear. Thoroughly clean all affected areas with a neutralizing solution of ¼ cup (60 mL) sodium bicarbonate (baking soda) dissolved in 1 ½ gallons (6 L) of water.



It is highly recommended that insulated wrenches be used when working on our electric vehicles. Alternatively, wrap wrenches with vinyl tape to prevent the possibility of a

dropped wrench onto the batteries terminals, which can short the battery, which could result in an explosion and severe personal injury or death.

BATTERY CARE

- 1) Place battery into service and complete a full discharge and charge cycle. Check and add approved water only (never acid) if needed only after this first cycle is completed.
- 2) Never discharge battery beyond 80% and do not operate battery if the specific gravity is below 1.150
- 3) If above 115° F (46° C) allow battery to cool before charging or operating
- 4) During shipment or prolonged storage the electrolyte levels may fall below the separator protector. Only after a complete discharge and charge cycle, check and keep electrolyte level above separator and 1/8" (3.175mm)

below vent well. Add approved water only when required and never add acid.

- 5) Keep battery top clean, dry and vent caps tightly in place.
- 6) Keep open flame and metal objects away from battery top.
- 7) Use only approved chargers of correct voltage and current output.
- 8) Keep battery compartment open and well ventilated during charge.
- 9) It is recommended that water be added to batteries near the end of the charge or after taking them to charge.
- 10) Be sure to replace the vent caps after watering so electrolyte does not splash out.

ELECTROLYTE LEVELS

Charge the batteries after each days use. Clean the batteries and wire terminals. Check that the electrolyte level is correct and add water as required. It is important that the water used be pure and free of contaminants that could reduce the life of the battery by reducing the chemical reaction. The water must be distilled or purified by an efficient filtration system.

Electrolyte level should be $\frac{1}{2}$ " (13 mm) above the plates in each cell. This level will leave about $\frac{1}{4}$ " – $\frac{3}{8}$ " (6 – 10 mm) of space between the electrolyte and the vent tube. The level of the electrolyte is important. Too low and the plates will be exposed to air, ruining them beyond repair. Too high and the electrolyte will be forced out of the battery due to gassing and the increased volume of the electrolyte resulting from the charging cycle.

BATTERY WATERING SYSTEM

Wesley International offers a battery watering system, shown in Figure 26, as an option on all its vehicles. This system is a fast, accurate, and safe means of maintaining precise electrolyte levels in the batteries.




FIGURE 26

To use the watering system, simply fill the gravity feed container shown in Figure 27 with a clean water source. Connect the blue connector at the end of the container flow tubing to the blue connector at the end of the battery

MAINTENANCE INSTRUCTIONS

watering system attached to the batteries (Figure 26). Elevate the gravity feed container at least 3 feet (1 m) to properly fill the batteries.


CLEANING BATTERIES

It is important to first neutralize any acid deposits with a solution of sodium bicarbonate (baking soda) and water. Spray the top and sides of the batteries with this solution which should consist of $\frac{1}{4}$ cup (60 mL) of sodium bicarbonate mixed with 1 $\frac{1}{2}$ gallons (6 L) of water. Allow the solution to sit for at least three minutes. Rinse the entire area with low pressure clear water.

BATTERY REPLACEMENT

Remove battery hold downs and cables. Lift out batteries with a commercially available lifting device.

Use care to connect the battery terminals in the proper manner as shown. Tighten the battery post hardware to 50-70 in. lbs. (6-8 Nm) torque. Protect the battery terminals and battery wire terminals with a commercially available lubricant.



MAINTENANCE INSTRUCTIONS


LIFTING THE VEHICLE



WARNING

To prevent possible injury or death resulting from a vehicle falling from a jack, be sure the vehicle is on a firm and level surface. Never crawl under a vehicle while it is supported by a jack. Use jack stands and test the stability of the vehicle. Always place chocks in front and behind the wheels not being raised. Use extreme care when lifting due to the 3-point wheel design which is extremely unstable when lifting, especially lifting the rear.

The vehicle should only be lifted high enough to remove the front axle or rear wheels. Position jacks and jack stands only on the areas indicated.




Lifting the front: To remove a front wheel or axle, first chock the front and rear of the rear tires. Loosen the front wheel hardware. Position the jack in the location indicated and carefully raise the front of the vehicle, taking care that the rear wheels do not move. Position jack stands in the locations indicated and slowly lower the vehicle to rest on the jack stands and test the stability of the vehicle.

Lifting the rear: To remove a rear wheel or axle, first raise the front of the vehicle as previously described and support on jack stands. Then position the jack in the position indicated at the rear of the vehicle. Carefully raise the rear of the vehicle with the jack and place two jack stands in the positions indicated. Slowly lower the vehicle to rest on the jack stands and test the stability of the vehicle.

Lower the vehicle by reversing the lifting sequence.

LUBRICATION

Proper lubrication will ensure maximum years of trouble free service from your Pack Mule.



Front Wheels and Fork: Lubricate wheel bearings and fork pivot, per the recommended maintenance schedule.

Rear Axle: Check fluid level in the rear axle per the recommended maintenance schedule. The rear axle is provided with a fluid level check/fill plug located at the bottom of the differential. With the vehicle on level ground, clean the area around the check/fill plug and remove plug. The correct fluid level is just below the bottom of the threaded hole. If fluid levels are low, add as required until it starts to seep from the hole. Install the check/fill plug.



To replace the fluid, lift the vehicle per the lifting procedures. Remove the rear axle cover and drain out the fluid into a container. Clean cover mating surfaces as required with proper scraping tool. Ensure cover lip is not bent. Apply thin bead of RTV sealant and torque cover bolts 16-24 lb-ft.

Add 10-14 oz. 80W-90 Hypoid gear oil through the check/fill plug hole or until fluid just starts to seep from the hole.

MAINTENANCE INSTRUCTIONS

BRAKES

Service brakes per the recommended maintenance schedule. The vehicle is equipped with mechanical drum brakes. These brakes are either mechanically or hydraulically actuated. For vehicles with the hydraulic upgrade, a $\frac{3}{4}$ " hydraulic piston is added between the cable coming from the brake pedal and the cables coming from the drum brakes on the transaxle as in Figure 27.




FIGURE 27

For the hydraulic brake upgrade, the master cylinder can be accessed by removing the floor plate on the floor board as shown in Figure 28.




FIGURE 28

Twist the top on the master cylinder to remove the cap (Figure 29) and check or re-fill the hydraulic brake fluid.



FIGURE 29

MAINTENANCE INSTRUCTIONS

TIRES AND WHEELS

The PC series is offered in two tow capacity versions: 2,000 pound (907 kg) tow capacity standard transaxle and 5,000 pound (2,268 kg) tow capacity tugger transaxle. The standard transaxle has a four bolt pattern for the wheels, whereas the tugger transaxle has a five bolt pattern.

The following tire options are offered with the PC series vehicle:

- 1) Pneumatic tires (standard)
- 2) Foam-filled tires
- 3) Solid tires (black)
- 4) Solid non-marking tires (off-white)

Pneumatic tires are tubeless tires filled with air and mounted on one piece rims. Pneumatic tires offer the smoothest ride but do require regular maintenance to ensure proper air levels are maintained and require immediate repair should they go flat.

Foam-filled tires replace the air inside pneumatic tires with a foam compound and are mounted on one piece rims. This retains the smoother ride of pneumatic tires but eliminate the regular maintenance associated with pneumatic tires. However, if a vehicle equipped with foam-filled tires sits for extended periods of time, flat spots may form.

Solid tires are solid rubber compound mounted on a two piece rim. They eliminate the possibility of flat spots and the

maintenance associated with pneumatic tires but because they are solid, they do not provide as smooth a ride as pneumatic tires. Solid non-marking tires operate in the same manner but are made of a rubber compound that prevents black marks on floors.

Replacing Front Tires/Wheels: To remove and repair the front tires and/or wheels, complete the following steps:

- 1) Remove the axle nut retaining clip.
- 2) Lift the front of the vehicle as explained in the "Lifting the Vehicle" Section.
- 3) Loosen the axle nuts and remove the entire wheel, hub and axle assembly from front fork.
- 4) Remove the lug nuts and remove the wheel from the axle assembly.
- 5) Completely deflate the tire, then remove from the wheel.
- 6) Reinstall the repaired or replacement tire by reversing the above sequence. Tighten to 70 to 80 ft. lbs. (95 to 108 Nm) torque.

Replacing Rear Tires/Wheels: To remove and repair the rear tires and/or wheels, complete the following steps:

- 1) Loosen the lug nuts on the wheel.
- 2) Lift the rear of the vehicle as explained in the "Lifting the Vehicle" Section.
- 3) Remove the lug nuts and remove the wheel from the transaxle.
- 4) Completely deflate the tire, then remove from the wheel.
- 5) Reinstall the repaired or replacement tire by reversing the above sequence. Tighten to 70 to 80 ft. lbs. (95 to 108 Nm) torque.


COMPONENTS - ELECTRICAL

BASIC ELECTRICAL COMPONENTS

Your Pack Mule electric vehicle is purposely designed around the “Keep it Simple” principal. Our philosophy at Wesley International is to engineer products with only the critical components necessary to meet the demanding industrial environment, cutting out any unnecessary “bells and whistles” which only increase ownership costs. The following core components make up the electrical portion of the vehicle:

- 1) Onboard Battery Charger
- 2) Batteries (shown on page 22)
- 3) Motor
- 4) Controller
- 5) Battery Discharge Indicator (BDI)
- 6) Speed Control Pedal (shown on page 34)
- 7) Solenoid
- 8) Circuit Breaker

This section will cover each of these core components (except batteries which is covered in the Maintenance section), including troubleshooting.



COMPONENTS - ELECTRICAL

ONBOARD BATTERY CHARGER

This section assumes your unit has the standard onboard Delta-Q Battery Charger as shown Figure 30.



FIGURE 30

If your vehicle has a previous model charger, please refer to the support section of our website at www.packmule.com for the applicable user's guide.

The onboard charger is air cooled, eliminating any moving parts for increased reliability and life span. Because of this, the mounting location has been designed to optimize air flow and it is important that this air flow is not inhibited in any way. Regularly check the cooling fins to ensure they are free of dirt, dust, or other contaminants.


The charger is an IP66 (NEMA4) enclosure and is designed for an operating temperature of -30°C to +50° C (-22° F to 122° F). It accepts AC input voltage range of 85 – 265 VAC with a nominal input voltage of 120 VAC or 230 VAC rms. The input frequency range is 45 – 65 Hz with a maximum input current of 12A and a nominal input current of 9.5A rms at 120 VAC or 5A rms at 230 VAC.

The charger includes an easy to read 10-LED display as follows:

LED Color	Indication (following "Power-On Self Test")		
Ammeter (Amber)		Solid:	Displays approximate scale of current output during bulk phase.
		Flashing:	High internal charger temperature. Output reduced.
80% Charge (Amber)		Solid:	Bulk charge phase complete, 80% charged. In Absorption phase.
		Flashing:	With no battery connected, indicates algorithm # selected by number of flashes.
100% Charge (Green)		Solid:	Charging complete. Charger in Maintenance Mode.
		Flashing:	Absorption phase complete. In Finish phase
AC On (Amber)		Solid:	AC power good.
		Flashing:	Low AC voltage. Check voltage and extension cord length.
Fault (Red)		Flashing:	Charger error. Reset charger power and refer to trouble shooting instructions.

COMPONENTS - ELECTRICAL

The optional charger Single-LED display, if included, would be located on the front panel, near the key-switch.



LED Color	Indication (following "Power-On Self Test")	
Green		Solid: Charging complete. Charger in Maintenance Mode.
		Flashing: Short: <80% Charge Long: >80% Charge
Amber		Flashing: Reduced power mode: Low AC voltage or High internal charger temperature.
Red		Flashing: Charger error. Reset charger power and refer to trouble shooting instructions.

- Do not expose charger to oil, mud or direct heavy water spray when cleaning vehicle.
- If the detachable input power supply cord set is damaged, replace with a cord that is:
 - For North America – UL or CSA listed/approved detachable cord, 3 conductor, 16AWG minimum, and rated SJT; terminating in a grounding type IEC 60320 C14 plug rated 250V, 13A minimum; or
 - For all other countries – a safety approved detachable cord, 3 conductor, 1.5mm² minimum, rated appropriately for industrial use. The cord set must terminate on one end with a grounding type input connector appropriate for use in the country of destination and, on the other end, an output grounding type IEC 60320 C14 plug.
- The enclosure of the charger has been tested successfully to EN60529, meeting IP66. The AC supply inlet is rated to IP20, which is suitable for indoor use only. Keep all AC connections clean and dry.

If a fault occurs, count the number of red flashes between pauses and refer to the following table:

Red Flashes	Cause	Solution
	Battery High Voltage	Check battery size and condition and reset charger (interrupt AC power for 15 seconds).
	Battery High Voltage	Check battery size and condition and reset charger (interrupt AC power for 15 seconds).
	Charge Timeout caused by battery pack not reaching required voltage. Charger output was reduced due to high temperatures.	Check connections. Operate charger at a lower ambient temperature.
	Check Battery: Battery could not be trickle charged up to minimum voltage	Check for shorted or damaged cells.
	Over-Temperature: Charger shut down due to high internal temperature.	Ensure sufficient cooling air flow and reset charger (interrupt AC power for 15 seconds).
	Charger Internal Fault	Reset charger (interrupt AC power for 15 seconds). If fault persists, likely needs to be replaced.

COMPONENTS - ELECTRICAL

MOTOR

All Pack mule electric vehicles are equipped with Advanced Motor and Drives "DL" Series Separately Excited DC motors as pictured in Figure 31. The motor Field and Armature are completely separate and are energized independently by the motor controller.



FIGURE 31

CONTROLLER

The PC Series electric vehicle is equipped with a Curtis separately excited (Sep Ex) motor speed controller. These programmable controllers are simple to install, efficient, and cost effective. The Curtis controller provides smooth precise control of motor speed and torque. A full-bridge field control stage is combined with a half-bridge armature power stage to provide solid state motor reversing and full regenerative braking without additional relays or contactors.

The controller's rugged IP53 housing and packaging are built to with-stand shock and vibration. The controller is fully programmable through the Curtis 13XX handheld programmer. In addition to configuration flexibility, the programmer provides diagnostic and test capability. The Curtis motor controller offers superior operator control of the vehicle's motor drive speed.

Features include:

- Interlock braking with load sensor to meet required braking distance without unnecessary harsh braking at light loads
- Maintenance monitor responds to preset vehicle operating hours and drive hours as programmed by the OEM
- Two hour meters—total KSI-on hours and traction hours—and the associated maintenance timers are built into the controller
- BDI calculations performed within controller
- Estimates motor temperature based on field resistance and cuts back maximum speed if the motor is overheated
- Diagnostic checks for field open and field shorted faults

- Supports PWM electromagnetic brake with maximum continuous current of 2 amps
- Supports Type 4 throttle
- Active pre-charge of controller capacitor bank extends life of main contactor
- Compatibility with Curtis 1307/1311 handheld programmers for quick and easy testing, diagnostics, and parameter adjustment
- Continuous armature current control, reducing arcing and brush wear
- Complete diagnostics through the handheld programmer, the built-in Status LED, and the optional 840 Spyglass display
- Two fault outputs provide diagnostics to remotely mounted displays
- Regenerative braking allows shorter stopping distances, increases battery charge, and reduces motor heating
- Automatic braking when throttle is reduced provides a compression braking feel and enhances safety
- Brake/Drive Interlock meets ISO stopping distance requirements
- Ramp restraint feature provides automatic electronic braking that restricts vehicle movement while in neutral
- Meets EEC fault detect requirements
- Linear cutback of motor drive current during over-temperature or under-voltage
- Linear cutback of regenerative braking current during overvoltage
- High pedal disable (HPD) and static return to off (SRO) interlocks prevent vehicle runaway at startup
- Internal and external watchdog circuits ensure proper software operation
- Fully protected inputs and short-circuit protected output drivers



This manual covers the most commonly required information as it pertains to the Pack Mule vehicles. For more detailed instructions, contact Wesley International for a copy of the complete manual for the Curtis motor controller, or download a copy from www.packmule.com.

COMPONENTS - ELECTRICAL

Your Pack Mule vehicle should be equipped with one of the following Curtis motor controller models:

24 Volt DC:	Curtis Model 1243
36 Volt DC:	Curtis Model 1243 or 1268
48 Volt DC:	Curtis Model 1268
36 Volt AC:	Curtis Model 1234
48 Volt AC:	Curtis Model 1234

If your vehicle is equipped with an older Sevcon motor controller, please contact Wesley International for a copy of the Sevcon controller manual, or download a copy from www.packmule.com. Upgrade kits are available from Wesley for those who wish to upgrade an older vehicle equipped with a Sevcon controller to a Curtis controller platform. Contact Wesley's parts department for more information.

Programmable Parameters: All Pack Mule vehicles leave the factory with standard default parameters programmed in the controller, unless specific parameter settings are requested at the time of order. These parameters can be reprogrammed in the field using a Curtis handheld programmer, available from Wesley. Generally, there are five parameters which owners may want to modify to suit their specific safety or user preferences as follows:

- a) Acceleration Rate
- b) Braking Rate
- c) Deceleration Rate
- d) Maximum Forward Speed
- e) Maximum Reverse Speed

Acceleration Rate: The acceleration rate defines the time it takes the controller to accelerate from 0% drive output to 100% drive output. A larger value represents a longer acceleration time and a gentler start. Fast starts can be achieved by reducing the acceleration time, i.e., by adjusting the accel rate to a smaller value. The acceleration rate is adjustable from 0.1 to 3.0 seconds. The default setting for this is 1.6.

Braking Rate: The braking rate defines the time it takes the controller to increase from 0% braking output to 100% braking output (as defined by the corresponding mode-specific brake current limit) when a new direction is selected. A larger value represents a longer time and consequently gentler braking. Faster braking is achieved by adjusting the braking rate to a smaller value. The braking rate is adjustable from 0.1 second to 3.0 seconds. The default setting for this is 0.1

Deceleration Rate: The deceleration rate defines the time it takes the controller to reduce its output to the new throttle request when the throttle is reduced or released. A lower value represents a faster deceleration and thus a shorter stopping distance. The decel rate defines the vehicle's

Braking characteristic for any reduction in throttle, including to neutral, that does not include a request for the opposite direction. The decel rate is adjustable from 0.1 to 10.0 seconds. The default setting for this is 2.5.

Maximum Forward Speed: The maximum forward speed parameter defines the maximum controller voltage output at full throttle, in the forward direction. The maximum forward speed parameter is adjustable from the programmed creep speed up to 100%. The default setting for this is 70, which equates to about 7 mph (12.9 kph).

Maximum Reverse Speed: The maximum reverse speed parameter defines the maximum controller voltage output at full throttle, in the reverse direction. The maximum reverse speed parameter is adjustable from 0% to 100%. The default setting for this is 35 or about 1/2 the forward speed.

Controller Maintenance: There are no user serviceable parts in the Curtis controller. No attempt should be made to open, repair, or otherwise modify the controller. Doing so may damage the controller and will void the warranty. It is recommended that the controller be kept clean and dry and that its fault history file be checked and cleared periodically.

Periodically cleaning the controller exterior will help protect it against corrosion and possible electrical control problems created by dirt, grime, and chemicals that are part of the operating environment and that normally exist in battery powered systems.

Use the following cleaning procedure for routine maintenance:

- 1) Remove power by disconnecting the battery.
- 2) Discharge the capacitors in the controller by connecting a load (such as a contactor coil or a horn) across the controller's B+ and B-terminals.
- 3) Remove any dirt or corrosion from the connector areas. The controller should be wiped clean with a moist rag. Dry it before reconnecting the battery. The controller should not be subjected to pressured water flow from either a standard hose or a power washer.
- 4) Make sure the connections are tight, but do not over-tighten them.

COMPONENTS - ELECTRICAL

Controller Wiring: Typical Controller wiring configuration of PC series vehicles. The interlock switch is a seat switch or foot switch and there is no emergency reverse.




FIGURE 8

Diagnostics and Troubleshooting: The controller provides diagnostics information to assist technicians in troubleshooting drive system problems. The diagnostics information can be obtained by observing the appropriate display on the handheld programmer, the fault message displayed on the Spyglass gauge, the fault codes issued by the Status LED, or the fault display driven by the controller's fault outputs.

Programming Diagnostics: The handheld programmer presents complete diagnostic information in plain language. Faults are displayed in the System Faults Menu, and the status of the controller inputs/outputs is displayed in the Monitor Menu. Accessing the programmer's Fault History Menu provides a list of the faults that have occurred since the fault history file was last cleared. Checking (and clearing) the fault history file is recommended each time the vehicle is brought in for maintenance. For information on 1311 programmer operation, contact Wesley for a user manual or download a copy of the manual from www.packmule.com.

Spyglass Diagnostics: The eight-character LCD on the Spyglass displays a continuous sequence of hour meter, battery state-of-charge, and fault messages. Fault messages are displayed using the same codes that are flashed by the LED. For example, the LED flashes 3,2 for a welded main contactor:

000 00 000 00 000 00
(3 , 2) (3 , 2) (3 , 2)

And the corresponding Spyglass message is: **CODE 32**

When a fault message is being displayed, the red Fault LED (labeled with a wrench symbol) flashes to catch the operator's attention.

COMPONENTS - ELECTRICAL

Fault Codes and Troubleshooting Chart:

Table 7 TROUBLESHOOTING CHART				
LED CODE	PROGRAMMER LCD DISPLAY	FAULT CATEGORY	POSSIBLE CAUSE	FAULT CLEARANCE
0,1	NO KNOWN FAULTS	0	n/a	n/a
1,1	CURRENT SHUNT FAULT	1	1. Abnormal vehicle operation causing high current spikes. 2. Current sensor out of range. 3. Controller failure.	Cycle KSL. If problem persists, replace controller.
1,2	HM FAILSAFE	1	1. Noisy environment. 2. Self-test or watchdog fault. 3. Controller failure.	Cycle KSL. If problem persists, replace controller.
1,3	M- SHORTED	1	1. Internal or external short of M- to B+. 2. Incorrect motor wiring. 3. Controller failure.	Check wiring; cycle KSL. If problem persists, replace controller.
1,4	SRO	3	1. Improper sequence of KSL, interlock, and direction inputs. 2. Interlock or direction switch circuit open. 3. Sequencing delay too short. 4. Wrong SRO or throttle type selected. 5. Misadjusted throttle pot.	Follow proper sequence; adjust throttle if necessary; adjust programmable parameters if necessary.
2,1	THROTTLE WIPER HI	1	1. Throttle input wire open or shorted to B+. 2. Defective throttle pot. 3. Wrong throttle type selected.	When Throttle Wiper High input returns to valid range.
2,2	EMR REV WIRING	1	1. Emergency reverse wire or check wire open.	Re-apply emergency reverse or cycle interlock.
2,3	HPD	3	1. Improper sequence of KSL, interlock, and throttle inputs. 2. Misadjusted throttle pot. 3. Sequencing delay too short. 3. Wrong HPD or throttle type selected. 5. Misadjusted throttle pot.	Follow proper sequence; adjust throttle if necessary; adjust programmable parameters if necessary.
	SRVC TOTAL	3	1. Total maintenance timer expired.	Reset with programmer.
	SRVC TRAC	3	1. Traction maintenance timer expired.	Reset with programmer.
	TOTAL DISABLED	3	1. Total disable timer expired.	Reset with programmer.
	TRAC DISABLED	3	1. Traction disable timer expired.	Reset with programmer.
2,4	THROTTLE WIPER LO	1	1. Throttle pot wire open or shorted to B+. 2. Wrong throttle type selected. 3. Defective throttle pot.	When Throttle Wiper Low input returns to valid range.
3,1	FIELD SHORT	1	1. Main contactor coil shorted. 2. Field winding shorted to B+ or B-. 3. Field resistance too low.	Check contactor coil and field winding; cycle KSL.
3,2	MAIN CONT WELDED	1	1. Main contactor stuck closed. 2. Main contactor driver shorted.	Check wiring and contactor; cycle KSL.
3,3	FIELD OPEN	1	1. Field winding connection open. 2. Field winding open.	Check wiring and cycle KSL.
3,4	MISSING CONTACTOR	1	1. Main contactor coil open. 2. Main contactor missing. 3. Wire to main contactor open.	Check wiring and cycle KSL.

COMPONENTS - ELECTRICAL

Fault Codes and Troubleshooting Chart:

Table 7 TROUBLESHOOTING CHART, <i>cont'd</i>				
LED CODE	PROGRAMMER LCD DISPLAY	FAULT CATEGORY	POSSIBLE CAUSE	FAULT CLEARANCE
4,1	LOW BATTERY VOLTAGE	2	1. Battery voltage < undervoltage cutback. 2. Corroded battery terminal. 3. Loose battery or controller terminal.	When voltage rises above undervoltage cutoff point.
4,2	OVERVOLTAGE	2	1. Battery voltage > overvoltage shutdown limit. 2. Vehicle operating with charger attached.	When voltage falls below overvoltage cutoff point.
4,3	THERMAL CUTBACK	2	1. Temperature > 85°C or < -25°C. 2. Excessive load on vehicle. 3. Improper mounting of controller.	Clears when heatsink temperature returns to within acceptable range.
4,4	ANTI-TIEDOWN	3	1. Mode switches shorted to B+. 2. Mode Select 1 "tied down" to select Mode 2 or Mode 4 permanently.	Release Mode Select 1.
	MOTOR HOT	3	1. Field resistance > motor hot setpoint.	When resistance < setpoint.
	MOTOR WARM	3	1. Field resistance > motor warm setpoint.	When resistance < setpoint.

COMPONENTS - ELECTRICAL

BATTERY DISCHARGE INDICATOR (BDI)

The Curtis BDI (Figure 32 shows the 24/36V version) displays various system parameters, such as battery state-of-charge, operating hours or maintenance status from the Curtis motor controller.


Features include:

- Attractive, easy-to-read, 8 character dot matrix Liquid
- Crystal Display.
- 6 LEDs -five green to indicate battery state-of-charge and one red to indicate that a fault has occurred.
- Displays hours of use, battery state-of-charge and messages from the Curtis motor controller.
- Molded-in rear Molex style connector provides a low-cost, rugged and reliable installation.
- Front sealed (IP65) for use in harsh environments.



FIGURE 32

BDI Connector Pin-Out



Pin Number	Function
1	N.C.
2	N.C.
3	B+ = 24V
4	B+ = 36V
5	Power In +
6	Receive
7	N.C.
8	Power In -

The BDI in 48 volt vehicles will display battery state-of-charge and operating/ Traction hours only. Figure 33:



FIGURE 33

SPEED CONTROL PEDAL

The speed control pedal is a rugged assembly with IP66 throttle sensor protection for reliable use in harsh industrial environments.

There are no user serviceable parts in the speed control pedal. No attempt should be made to open, repair, or otherwise modify the assembly. Doing so may damage the assembly and will void the warranty.



COMPONENTS - ELECTRICAL

SOLENOID

The Pack Mule is provided with a SPNO DC Power Contactor. This unit is sealed and is water resistant. The coil voltage is matched to your particular vehicle operating voltage, i.e. 36V or 48V. The AC option uses 24V coil regardless of vehicle system voltage. Figure 34



FIGURE 34

COMPONENTS - ELECTRICAL

PARTS LIST – ELECTRICAL


Part	Part Number
Key Switch, 3-position (standard)	EV-E100
Key Replacement, set of 2	EV-E160
Directional Switch, 3 position Rocker	EV-E156
Horn	EV-E130
Horn Button	EV-E041
BDI – 24 / 36 volt vehicles	EV-E241
BDI – 48 volt vehicles	EV-E241-802
Solenoid, 4-terminal 36V	EV-E064HD
Solenoid, 4-terminal 48V	EV-E204 HD
10 Amp Fuse	EV-E015
Fuse Holder	EV-E016
Charger Receptacle	EV-E027
Charger Cord	EV-E026
Onboard Battery Charger, 24 volt	EV-E801-24
Onboard Battery Charger, 36 volt	EV-E801-36
Onboard Battery Charger, 48 volt	EV-E801-48
Motor Controller, DC, 24 / 36 volt	EV-E189
Motor Controller, DC, 48 volt	EV-E189-48
Motor Controller, AC, 36 volt	EV-E181
Motor, DC	EV-D040-S
Motor, AC	EV-E185
Speed Control Pedal Assembly	EV-E
Directional Switch, 3 position Toggle	EV-E035
Seat Presence Sensor Switch	EV-E528

Part	Part Number
Perma-Key Switch	EV-E194PK
On/Off Switch	EV-E017
Programmable Code Security Switch	EV-E901
Headlight/Taillight Switch, Rocker	EV-E155
Single LED Charge Status Plate	EV-E808L
Foot Presence Switch	EV-E128
Battery Watering System – 24V GC135	EV-E900-6
Battery Watering System – 24V GC145	EV-E900-7
Battery Watering System – 36V GC135	EV-E900-2
Battery Watering System – 36V GC145	EV-E900-1
Battery Watering System – 48V FS8D	EV-E900FX-310
Headlight/Taillight – 24 / 36 volt	EV-E210-S
Headlight/Taillight – 48 volt	EV-E210-48-S
Headlight/Taillight/Brake light – 24 / 36 volt	EV-E191
Headlight/Taillight/Brake light – 48 volt	EV-E191-48
Flashing Safety Beacon – Amber	EV-E183
Flashing Safety Beacon – Blue	EV-E182B
Flashing Safety Beacon – Red	EV-E182R
Back-up Alarm	EV-E159A
Proximity Alarm	EV-E149
Curtis AC/DC Program/Diagnostic Handset	EV-E180
Hitch, Spring-Loaded Clevis, 1" pin	EV-F130H
Hitch, Spring-Loaded Clevis, 5/8" pin	EV-F178H
Hitch, Pin	EV-F134P
Hitch, Pintle	EV-F092
Hitch, Eye 2-3/8"	EV-F132
Hitch, Auto Coupling	EV-F133H
Hitch, 3-Tier Assembly with Pin	EV-F134


PARTS LIST – AVAILABLE OPTIONS

Parts List for Front Wheel Steering Assembly

#	Description	Part #	Qty
1	Dual Fork Assembly	EV-W016	1
1	Dual Fork Assembly, for PC series units (Not Shown)	EV-W016-PC	1
1	Dual Fork Assembly, for PMT series units (Not Shown)	EV-W016-PMT	1
2	Dual Front Wheel Axle, 1" X 18"	EV-W017	1
3	Sleeve	EV-W007	2
3	Sleeve, for PMT series/Wide Tire units (Not Shown)	EV-W007L	2
4	Spacer	EV-W014	2
4	Spacer, for PMT series/Wide Tire units (Not Shown)	EV-W011	2
5	1" Flat Washer	EV-W027	6
6	1" Lock Washer	EV-W026	2
7	1" Slotted Hex Nut	EV-W006	4
8	Hub with 4 Studs	EV-W001	2
8	Hub with 5 Studs	EV-W034	2
9	Race, Bearing	EV-W010	6
10	Tapered Roller Bearing	EV-W009	6
11	Bushing, 1" X 1.25" X 0.625"	EV-W011	1
12	Bushing, 1" X 1.25" X 0.5"	EV-W011-S	1
13	Seal, Oil	EV-W008	6
14	1" Thin Slotted Hex Nut	EV-W013	1
15	Pin, Cotter 3/16" – 1 1/4"	EV-W025	1
16	Lug Nuts	EV-W023	4 or 5



Owner's Manual and Service Guide - PC Series



Transaxle Parts List for PC Series

#	Part	Part Number	QTY
3	Gear, Input	See Kit	1
4	Ring, Retaining	EV-T016	3
5	O-Ring	EV-T014	3
6	Bearing, Ball	EV-T015	1
7	Bearing, Ball	EV-T013	1
8	Plug, End Cap	EV-T017	2
9	Bearing, Ball	EV-T011	2
10	Gear, Intermediate Assembly	See Kit	1
11	O-Ring	EV-T010	2
12	Gear, Final Drive	See Kit	
13	Bearing, Ball	EV-T008	2
15	Screw, Cap	EV-T006	4
16	Nut, Lock	EV-T007	4
17	Plate, Cover	EV-T018	1
18	Plug, Fill	EV-T020	1
19	Screw, Cover Plate	EV-T021	10
23	Brake Assembly, Left Hand Shoe Type	EV-T054	1
23	Brake Assembly, Left Hand Shoe Type (Stock Chaser)	EV-T054-S	1
24	Brake Assembly, Right Hand Shoe Type	EV-T055	1
24	Brake Assembly, Right Hand Shoe Type (Stock Chaser)	EV-T055-S	1
25	Shaft, Axle 29" Left Hand (15 1/4" length)	EV-T023-29	1
25	Shaft, Axle 32" Left Hand (18 1/8" length)	EV-T023-32	1
25	Shaft, Axle 36" Left Hand (23 1/4" length)	EV-T023-36	1
26	Shaft, Axle Right Hand	EV-T025	1
28	Seal, Oil	EV-T030	2
29	Ring, Retaining	EV-T029	4
30	Bearing, Ball	EV-T028	2
31, 32, 33	Hub and Drum – 4-lug assembly with studs	EV-T058	2
34	Nut, Flange Hex	EV-T064	2
Kit	Kit, Gear Set (Includes #3, #10, #12)	EV-T065	1

Transaxle Parts List for PCT Series

#	Part	Part Number	QTY
3	Gear, Input	See Kit	1
4	Retaining, Ring	EV-T016	3
5	O-Ring	EV-T014	3
6	Bearing, Ball	EV-T015	1
7	Bearing, Ball	EV-T013	1
8	Plug, End Cap	EV-T017	2
9	Bearing, Ball	EV-T011	2
10	Gear, Intermediate Assembly	See Kit	1
11	O-Ring	EV-T010	2
12	Gear, Final Drive	See Kit	1
13	Bearing, Ball	EV-T008	2
15	Screw, Cap	EV-T006	4
16	Nut, Lock	EV-T007	4
17	Plate, Cover	EV-T018	1
18	Plug, Fill	EV-T020	1
19	Screw, Cover Plate	EV-T021	10
23	Brake Assembly, Left Hand Shoe Type	EV-T054	1
23	Brake Assembly, Left Hand Shoe Type (Stock Chaser)	EV-T054-S	1
24	Brake Assembly, Right Hand Shoe Type	EV-T055	1
24	Brake Assembly, Right Hand Shoe Type (Stock Chaser)	EV-T055-S	1
25	Seal, Oil	EV-T076	2
26	Ring, Retaining	EV-T077	2
27	Ring, Retaining, Wheel Bearing	EV-T078	2
28	Ring, Retaining	EV-T079	4
29	Bearing, Ball	EV-T080	2
30	Drum, Brake (5 lug)	EV-T075	2
31	Shaft, Left Hand Axle 32"	EV-T081-32	1
31	Shaft, Left Hand Axle 36"	EV-T081-36	1
32	Shaft, Right Hand Axle	EV-T082	1
Kit	Kit, Gear Set (Input, Intermediate Assembly, Final Drive)	EV-T083	1
37	Drum Assembly (5 lug)	EV-T075	1



PACK MULE
PROUDLY BUILT IN THE USA