



Technical Manual
TesiMod Operating Terminal
BT5N LCD / BT5N VF
Field Bus Unit

Version 1.0 issued 12th November 1999

Sutron electronic GmbH
Kurze Straße 29
70794 Filderstadt
Tel.: ++49 7 11 / 77 09 80
Fax: ++ 49 7 11 / 77 09 86 0
Email: support@suetron.de

TesiMod BT5N

V1.0

19.11.1999

First Edition

Table of Contents

1	Explanation of Symbols	5
2	The Operating Terminal BT5N	5
2.1	Front View	6
2.2	Keyboard	7
2.2.1	Editing Keys	7
2.2.2	Control Keys	8
2.2.3	Special Keys	9
2.2.4	Function Keys	10
2.2.4.1	Function Key Arrangement	10
2.2.4.2	Slide-in Identification Strips for the Function Keys	11
2.3	Rear View	12
2.3.1	InterBus	12
2.3.2	SUKOnet K	13
2.3.3	PROFIBUS-DP	14
2.3.4	MPI	15
2.3.5	CAN-Bus	16
2.3.6	InterBus Optical Fibre	17
2.4	Mounting the Terminal	18
2.4.1	Front Panel Dimensions	19
2.4.2	Side View, Mounting Depth	20
2.4.3	Panel Cutout	21
2.5	Pin Assignments	22
2.5.1	Pin Assignment X1 Supply Voltage	23
2.5.2	Pin Assignment X2.1 / X2.2 InterBus	24
2.5.3	Pin Assignment X2.1 / X2.2 SUCOnet K	25
2.5.4	Pin Assignment X2 PROFIBUS-DP	26
2.5.5	Pin Assignment X2 MPI	27
2.5.6	Pin Assignment X2.1 / X2.2 CAN-Bus	28
2.5.7	Pin Assignment InterBus Optical Fibre	29
2.5.8	Pin Assignment X3 SER2 RS232c	30
2.6	Shielding	30
2.7	Display	31
2.7.1	Display Contrast Setting	32
2.7.2	Default Contrast Setting	32

TesiMod BT5N

2.7.3	Character Attributes	33
2.7.4	Font Normal	33
2.7.5	Displayable Character Set	33
2.7.6	Loadable Font Katakana	34
2.7.7	Loadable Font Cyrillic	35
2.8	User-Mode Switch	36
2.9	Battery	37
2.10	Fuse	38
2.11	Application Memory	38
3	Technical Data	39
4	Declaration of Conformity	41
5	Index	43
A	Appendix A	A-1
A.1	Shielding of SubminD - Interconnections	A-1

TesiMod BT5N

1 Explanation of Symbols

This manual uses the following symbols to indicate notes and hazardous situations.



Notes for the User



General Danger



Specific Danger

2 The Operating Terminal BT5N


The **BT5N** operating terminal is of small size that makes it suitable for installation wherever space is limited while being able to take advantage of all of the functions provided by larger operating terminals.

The unit is fitted with function keys that can be individually labelled with slide-in identification strips.

The communication with a controller and a logging printer is carried out via separate interfaces.

TesiMod BT5N

2.1 Front View



- | | | | |
|----|------------------------------|----|----------------------------------|
| 1 | Company Logo | 11 | Special Key Help |
| 2 | Front Panel | 12 | Control Key Page |
| 3 | Operating Terminal Type Logo | 13 | Editing Key Plus, Minus |
| 4 | Display | 14 | Special Key Enter |
| 5 | Front Cover | 15 | Key Cursor Home |
| 6 | Function Keys F1 to F6 | 16 | Key Cursor Right, Left, Up, Down |
| 7 | Status-LED Function Keys | 17 | Editing Keys 0 to 9, Alphabet |
| 8 | Status-LED Help | 18 | Special Key Clear |
| 9 | Status-LED Data Release | 19 | Special Key Print |
| 10 | Special Key Data Release | | |

TesiMod BT5N

2.2 Keyboard

The **BT5N** supports all important key functions in spite of the small measures. The keyboard consists of membrane keys. The stroke distance is 0.3 mm and the key area is 15 x 15 mm. The key elements are covered by an embossed polyester foil against environmental influences. The Status LEDs are positioned under or above the according key element and they illuminate green. The keyboard has a lifetime of 2 million switching cycles.

In transparent mode, the keys supply a fixed start and stop code. In standard mode, the function of the keys is as defined by the user.

2.2.1 Editing Keys



Key: **0 and () °** is used to edit data within the editor. If the system variable **Shift** or **ShiftCase** is programmed, the characters (and) and ° can be entered.



Key: **1 and STU** is used to edit data within the editor. If the system variable **Shift** or **ShiftCase** is programmed, the characters S and T and U can be entered.



Key: **2 and VWX** is used to edit data within the editor. If the system variable **Shift** or **ShiftCase** is programmed, the characters V and W and X can be entered.



Key: **3 and YZ%** is used to edit data within the editor. If the system variable **Shift** or **ShiftCase** is programmed, the characters Y and Z and % can be entered.



Key: **4 and JKL** is used to edit data within the editor. If the system variable **Shift** or **ShiftCase** is programmed, the characters J and K and L can be entered.



Key: **5 and MNO** is used to edit data within the editor. If the system variable **Shift** or **ShiftCase** is programmed, the characters M and N and O can be entered.



Key: **6 and PQR** is used to edit data within the editor. If the system variable **Shift** or **ShiftCase** is programmed, the characters P and Q and R can be entered.



Key: **7 and ABC** is used to edit data within the editor. If the system variable **Shift** or **ShiftCase** is programmed, the characters A and B and C can be entered.



Key: **8 and DEF** is used to edit data within the editor. If the system variable **Shift** or **ShiftCase** is programmed, the characters D and E and F can be entered.

TesiMod BT5N



Key: **9 and GHI** is used to edit data within the editor. If the system variable **Shift** or **ShiftCase** is programmed, the characters G and H and I can be entered.



Key: **Decimal Point and :?!** is used to edit data within the editor. If the system variable **Shift** or **ShiftCase** is programmed, the characters : and ? and ! can be entered.



Key: **Minus and */** can be used to enter negative values within the editor. In the increment editor, the variable value is decremented by 1. When the key is held down, the function is repeated at a rate of repetition that is automatically increased. If the system variable **Shift** or **ShiftCase** is programmed, the characters \ and * and / can be entered.



Key: **Plus and <=>** can be used to enter positive values within the editor. In the increment editor, the variable value is incremented by 1. When the key is held down, the function is repeated at a rate of repetition that is automatically increased. If the system variable **Shift** or **ShiftCase** is programmed, the characters < and = and > can be entered.

2.2.2 Control Keys



Key: **Cursor left** can be programmed to directly select I/O masks. In the editor, it moves the cursor to the left.



Key: **Cursor right** can be programmed to directly select I/O masks. In the editor, it moves the cursor to the right.



Key: **Cursor up** can be programmed to directly select I/O masks. In the editor, it moves the cursor upwards.



Key: **Cursor down** can be programmed to directly select I/O masks. In the editor, it moves the cursor downwards.

TesiMod BT5N



Key: **Cursor home** can be programmed to directly select I/O masks. In the editor, it moves the cursor to the position of the first input variable.



Key: **Page** is used to page through tables, recipes and messages. The functionality corresponds to the system variable “**TabPgDn**”. The key allows data contents towards the bottom of the table to be viewed. The key **Page** is programmed as function key F8.

2.2.3 Special Keys



Key: **Help** always displays the current help text (online help). When the status-LED help flashes, it signals that an error message is pending. The error or system message is always displayed in plain-text.



Key: **Data Release** is used to switch from a menu into the editor. The status-LED data release lights up when the editing mode is active. When the Data Release key is pressed within the editor, the editing mode is exited.



Key: **Enter** is used to conclude data entry. When pressed while in the startup mask, the key switches into the setup mask.




Key: **Clear** deletes the character beneath the cursor when it is used in an editor. Deletes the selected messages from the data memory. Key: **Acknowledge** is used as an acknowledge key for the message system.



Key: **Print** can be used as a soft key to activate various print processes. The key **Print** is programmed as function key F7.


TesiMod BT5N

2.2.4 Function Keys



The **function keys F1 to F6** with integrated LEDs for functional feedback. The keys can be freely assigned a soft key functionality; either for menu control or to trigger a function in the controller.

2.2.4.1 Function Key Arrangement



TesiMod BT5N

2.2.4.2 Slide-in Identification Strips for the Function Keys

The slide-in identification strips can be replaced without having to disassemble the terminal. One blank slide-in identification strip and one labelled with F1 through F6 are supplied. Various labelling methods are recommended, depending on the number of terminals involved.

Suitable labelling methods for:

custom-made terminals,

prototypes:


small number of terminals:

large number of terminals:

labelling with an indelible pen

transparency with laser printing

identification strips printed according to customer's needs



Position of the slide-in identification strip in the BT5N



blank slide-in identification strip




labelled slide-in identification strip, standard

TesiMod BT5N

2.3 Rear View


2.3.1 InterBus



- | | | | |
|----|--|----|-------------------------------------|
| 1 | Fastening Screw for Enclosure | 11 | Pin Assignment X2.1 (Remotibus In) |
| 2 | Female Connector X2.2 (Remotibus Out) | 12 | Pin Assignment X2.2 (Remotibus Out) |
| 3 | Female Connector X3 (SER2-RS232c) | 13 | Diagnosis LEDs |
| 4 | Male Connector X2.1 (Remotibus In) | 14 | CE Mark |
| 5 | Connector X1 (Power Supply) | 15 | Warning |
| 6 | Threaded Bolt for Protective Ground | 16 | Pin Assignment X3 (SER2-RS232c) |
| 7 | Front Panel | | |
| 8 | Pin Assignment Connector X1 | | |
| 9 | Switch Positions of User-Mode Switch | | |
| 10 | User-Mode Switch at the Side of the Unit | | |

TesiMod BT5N

2.3.2 SUKOnet K




- | | | | |
|----|--|----|--------------------------------------|
| 1 | Fastening Screw for Enclosure | 11 | Pin Assignment X2.1 (SUCOnet K) |
| 2 | Female Connector X2.1 (SUCOnet K) | 12 | Terminator Switch (X2.1 - SUCOnet K) |
| 3 | Female Connector X3 (SER2-RS232c) | 13 | Pin Assignment X2.2 (SUCOnet K) |
| 4 | Female Connector X2.2 (SUCOnet K) | 14 | Diagnosis LED |
| 5 | Connector X1 (Power Supply) | 15 | CE Mark |
| 6 | Threaded Bolt for Protective Ground | 16 | Warning |
| 7 | Front Panel | 17 | Pin Assignment X3 (SER2-RS232c) |
| 8 | Pin Assignment Connector X1 | | |
| 9 | Switch Positions of User-Mode Switch | | |
| 10 | User-Mode Switch at the Side of the Unit | | |

/001-0158/
BT5NB_grau_eng_V10.300000A0K0

TesiMod BT5N


2.3.3 PROFIBUS-DP



- | | | | |
|----|--|----|---------------------------------|
| 1 | Fastening Screw for Enclosure | 11 | Diagnosis LED |
| 2 | Female Connector X2 (PROFIBUS-DP) | 12 | CE Mark |
| 3 | Female Connector X3 (SER2-RS232c) | 13 | Warning |
| 4 | Connector X1 (Power Supply) | 14 | Pin Assignment X3 (SER2-RS232c) |
| 5 | Threaded Bolt for Protective Ground | | |
| 6 | Front Panel | | |
| 7 | Pin Assignment Connector X1 | | |
| 8 | Switch Positions of User-Mode Switch | | |
| 9 | User-Mode Switch at the Side of the Unit | | |
| 10 | Pin Assignment X2 (PROFIBUS-DP) | | |

TesiMod BT5N

2.3.4 MPI




- | | | | |
|----|--|----|---------------------------------|
| 1 | Fastening Screw for Enclosure | 11 | Diagnosis LED |
| 2 | Female Connector X2 (MPI) | 12 | CE Mark |
| 3 | Female Connector X3 (SER2-RS232c) | 13 | Warning |
| 4 | Connector X1 (Power Supply) | 14 | Pin Assignment X3 (SER2-RS232c) |
| 5 | Threaded Bolt for Protective Ground | | |
| 6 | Front Panel | | |
| 7 | Pin Assignment Connector X1 | | |
| 8 | Switch Positions of User-Mode Switch | | |
| 9 | User-Mode Switch at the Side of the Unit | | |
| 10 | Pin Assignment X2 (MPI) | | |

/001-0158/
BT5NB_grau_eng_V10.300000A0K0

TesiMod BT5N


2.3.5 CAN-Bus



- | | | | |
|----|--|----|---|
| 1 | Fastening Screw for Enclosure | 11 | Pin Assignment X2.1 (CAN-Bus) |
| 2 | Female Connector X2.2 (CAN-Bus) | 12 | Pin Assignment X2.2 (CAN-Bus) |
| 3 | Female Connector X3 (SER2-RS232c) | 13 | Diagnosis LEDs |
| 4 | Male Connector X2.1 (CAN-Bus) | 14 | CE Mark |
| 5 | Connector X1 (Power Supply) | 15 | Warning |
| 6 | Threaded Bolt for Protective Ground | 16 | Pin Assignment Interface X3 (SER2-RS232c) |
| 7 | Front Panel | | |
| 8 | Pin Assignment Connector X1 | | |
| 9 | Switch Positions of User-Mode Switch | | |
| 10 | User-Mode Switch at the Side of the Unit | | |

TesiMod BT5N

2.3.6 InterBus Optical Fibre



- | | | | |
|----|--|----|---|
| 1 | Fastening Screw for Enclosure | 11 | Fibre Optical Interface DI2 (Remotebus Out) |
| 2 | Female Connector X3 (SER2-RS232c) | 12 | Terminator Switch (InterBus) |
| 3 | Connector X1 (Power Supply) | 13 | Fibre Optical Interface DO2 (Remotebus Out) |
| 4 | Threaded Bolt for Protective Ground | 14 | Diagnosis LEDs |
| 5 | Front Panel | 15 | CE Mark |
| 6 | Pin Assignment Connector X1 | 16 | Warning |
| 7 | Switch Positions of User-Mode Switch | 17 | Pin Assignment X3 (SER2-RS232c) |
| 8 | User-Mode Switch at the Side of the Unit | | |
| 9 | Fibre Optical Interface DO1 (Remotebus In) | | |
| 10 | Fibre Optical Interface DI1 (Remotebus In) | | |

/001-0158/
BT5NB_grau_eng_V10.300000A0K0

TesiMod BT5N

2.4 Mounting the Terminal

The rear panel mounting is suitable for easy and sealed installation in places where the rear side of the appliance is accessible. The appliance is particularly suitable for mounting in control cabinets with a mounting wall plate thickness of approximately 1 to 14 mm.

The front panel permits sealed installation of the operating terminal in accordance with the IP65 degree of protection (at the front). At the rear side of the front panel a circumferential sealing is attached. All parts for mounting the appliance are given with the spare parts set.

Special care needs to be taken during installation to maintain this high degree of protection. The operating terminal is inserted from the front through the panel cutout and screwed to the mounting wall from the rear. The seal must be positioned evenly and the fastening elements tightened uniformly.

When installing the terminal, keep a minimum space of 30 mm around the terminal for adequate air circulation.

The tightness between the front panel and the mounting surface depends on the care during installation.



Mounting and maintenance may only be performed by qualified and authorized personnel!

Front Panel Dimensions	168.0 x 120.0 x 4.0 mm	(H x W x D)
Panel Cutout	160 x 112 mm	(H x W)

TesiMod BT5N


2.4.1 Front Panel Dimensions



/001-0158/
BT5NB_grau_eng_V10.300000AOK0

TesiMod BT5N

2.4.2 Side View, Mounting Depth




- 1 Front Panel
- 2 Foam Rubber Seal
- 3 Mounting Surface Thickness 1 bis 14 mm

- 4 Threaded Pin DIN 914 M4 x 35
- 5 Mounting Clamp

TesiMod BT5N

2.4.3 Panel Cutout



/001-0158/
BT5NB_grau_eng_V10.300000AOK0

TesiMod BT5N

2.5 Pin Assignments

The operating terminal is fitted with the following connectors:

Connector X1	24 VDC	Supply Voltage
Connector X3 / SER2	RS232c	Upload/Download/Logging Printer/Scanner

Optional the unit is fitted with this Connectors:

Connector X2.1 and X2.2	InterBus	Communication
Connector X2.1 and X2.2	SUCOnet K	Communication
Connector X2	PROFIBUS-DP	Communication
Connector X2	MPI	Communication
Connector X2.1 and X2.2	CAN Bus	Communication
Connector DO1/DI1	InterBus	
and DO2/DI2	Optical Fibre	Communication

TesiMod BT5N


2.5.1 Pin Assignment X1 Supply Voltage

The supply voltage is connected via the connector X1.

The unit is equipped with a reverse voltage protection. If the poling is wrong, the unit doesn't operate.

This unit confirms to the safety class I. For safe operation it is necessary to use safety extra-low voltage (SELV) in accordance with DIN EN 61131 for the supply voltage.

Connector in the terminal: 3-pin male connector strip Phoenix COMBICON MSTBV 2,5/3-GF

Pin	Designation	Function
1		Signal Ground
2	0 V	Supply Voltage 0 V
3	24 VDC	Supply Voltage 24 VDC

The supply voltage is connected via a plug-in 3-pin female connector strip. The cable is secured in the female connector strip by means of screw terminals. Cables with fine wires with a cross-section of up to 2.5mm² can be used. The female connector strip is secured in position by means of a screw-type locking.

The female connector strip of the type **Phoenix COMBICON MSTB 2.5/3-STF** is supplied.



Hazardous voltages can exist inside electrical installations that can pose a danger to humans. Coming in contact with live parts may result in **electric shock!**



Please note with respect to pin assignment:

If shielded connecting cables are used for the supply voltage, the shield should be connected to pin 1.



Threaded bolt for protective grounding

A separate ground conductor must be provided for the ground screw in each case. The minimum cross-section of the ground conductor must be 1.5 mm² and the length as short as possible. Compliance with this information increases the operational safety.

TesiMod BT5N

2.5.2 Pin Assignment X2.1 / X2.2 InterBus

The unit can be fitted with the bus interfaces X2.1 and X2.2 for connection to the InterBus instead of the standard interfaces TTY / 20 mA and RS422 / RS485. The InterBus connection is certified under the number 076. The connectors are of the 9-pin Submin D female and male connector strip type.

Connector in the terminal: 9-pin SubminD male connector strip for **Remotebus In**

Assignment:

Pin	Designation	Function
1	DO	Data Out
2	DI	Data In
3	GND	Signal Ground
4	nc	not connected
5	nc	not connected
6	/DO	Data Out Reverse
7	/DI	Data In Reverse
8	nc	not connected
9	nc	not connected

Connector in the terminal: 9-pin SubminD female connector strip for **Remotebus Out**

Assignment:

Pin	Designation	Function
1	DO	Data Out
2	DI	Data In
3	GND	Signal Ground
4	nc	not connected
5	+5 V	Power Supply +5 VDC
6	/DO	Data Out Reverse
7	/DI	Data In Reverse
8	nc	not connected
9	RBST	Remote Bus Status

A shielded cable with twisted pairs (Cable type LiYCY-TP) is used. The maximum cable length depends on the usage within the InterBus topology.

TesiMod BT5N

2.5.3 Pin Assignment X2.1 / X2.2 SUCOnet K

To integrate the unit into a network topology of the SUCOnet K it can be equipped with the special interfaces for SUCOnet K instead of the standard interfaces TTY / 20 mA and RS422 / RS485. The connectors are 9-pin SubminD female and male connectors. The pinning of either connectors is identical.

Termination:

Activate the **termination** of the physically first (master) and last station in the network at all times. The termination of the stations located in between remains inactivated. To activate the termination, the termination switch RD/TD must be set to **ON**.

Connector in the operating terminal: 9-pin SubminD female/male connector strip

Pin	Designation	Function
1	nc	not connected
2	nc	not connected
3	TA/RA	Transmit- / Receive Channel A
4	GND	Signal Ground
5	nc	not connected
6	nc	not connected
7	TB/RB	Transmit- / Receive Channel B
8	GND	Signal Ground
9	nc	not connected

A shielded cable with twisted pair wires (cable type LiYCY-TP) must be used.

The maximum cable length depends on the data transmission rate that is used.

For a transmission rate of 187.5 kbps the maximum cable length is 600 m, for a transmission rate of 375 kbps a cable length of 300 m should not be exceeded. If longer cable length are required, repeaters must be used for signal conditioning. Self-controlled repeaters may be used for this process.

TesiMod BT5N

2.5.4 Pin Assignment X2 PROFIBUS-DP

To integrate the unit into a network of the PROFIBUS-DP it can be equipped with the special interface for PROFIBUS-DP connection instead of the standard interfaces TTY / 20 mA and RS422 / RS485. A 9-pin SubminD female connector strip is used as a connector.

Connector on the operating terminal: 9-pin SubminD female connector strip

Assignment:

Pin	Designation	Function
1	nc	not connected
2	nc	not connected
3	RxD/TxD-P	Transmit / Receive Data Plus
4	CNTR-P	Control Signal Repeater Plus
5	DGND	Data Transmission Potential
6	VP	Power Supply of the Matching Resistors Plus
7	nc	not connected
8	RxD/TxD-N	Transmit / Receive Data Minus
9	CNTR-N	Control Signal Repeater Minus

Principally, all cable types specified in EN 50170 as cable type A can be used. This allows the following cable lengths (depending on the baud rate):

Baud Rate (bps)	Cable Length (m)
9 600	1200
19 200	1200
93 750	1200
187 500	1000
500 000	400
1 500 000	200
12 000 000	100

TesiMod BT5N

2.5.5 Pin Assignment X2 MPI

To integrate the unit into a network of the Siemens MPI Bus it can be equipped with the special interface for Siemens MPI connection instead of the standard interfaces TTY / 20 mA and RS422 / RS485. A 9-pin SubminD female connector strip is used as a connector.

The Termination of the bus cable is in the connector.

Termination for point-to-point connection:

For operation with point-to-point connection the **termination** must always be activated.

Termination for multipoint connection:

For operation with multipoint connections only the **termination** at the cable end must be activated.

Termination for spur lines:

For spur lines the **termination** must always be deactivated.

Connector on the operating terminal: 9-pin SubminD female connector strip

Assignment:

Pin	Designation	Function
1	nc	not connected
2	nc	not connected
3	RxD/TxD-P	Transmit / Receive Data Plus
4	CNTR-P	Control Signal Repeater Plus
5	DGND	Data Transmission Potential
6	VP	Power Supply of the Matching Resistors Plus
7	nc	not connected
8	RxD/TxD-N	Transmit / Receive Data Minus
9	CNTR-N	Control Signal Repeater Minus

Principally, all cable with the following parameters can be used:

- Loop resistance 110 Ohm/km
- Effective capacitance 30 nF/km
- Surge impedance 150 Ohm

The maximum length of a segment must be less than 50 meters. In the „Installation Manual S7-400, M7-400, C79000-G7000-C400-01” of Siemens you can gather more information about installation.

TesiMod BT5N

2.5.6 Pin Assignment X2.1 / X2.2 CAN-Bus

To integrate the unit into a network topology of the CAN bus it can be equipped with the special interfaces X2.1 and X2.2 for CAN Bus. The CAN bus is stated as a high-speed-bus according to ISO-DIS 11898.

Connector: 9-pin SubminD male connector strip X2.1

Pin	Designation	Function
1	nc	not connected
2	CANL	CAN_L bus line (dominant LOW)
3	CAN_GND	CAN Ground
4	nc	not connected
5	nc	not connected
6	CAN_GND	CAN Ground
7	CANH	CAN_H bus line (dominant HIGH)
8	nc	not connected
9	nc	not connected.

Connector: 9-pin SubminD female connector strip X2.2

Pin	Bezeichnung	Funktion
1	nc	not connected
2	CANL	CAN_L bus line (dominant LOW)
3	CAN_GND	CAN Ground
4	nc	not connected
5	nc	not connected
6	CAN_GND	CAN Ground
7	CANH	CAN_H bus line (dominant HIGH)
8	nc	not connected
9	nc	not connected

All signals of X2.1 to X2.2 are interconnected. The connecting cable has to be connected to all pins including the reserved ones. The intention is, that there shall be no interruption of any of the wires in the bus cable, assuming a possible future specification of the use of the reserved pins.

A shielded cable with twisted pair wires (cabe type LiYCY-TP) must be used. The CAN bus must be terminated with resistors on both ends of the cable structure.

TesiMod BT5N

2.5.7 Pin Assignment InterBus Optical Fibre

To integrate the unit into a network topology of the InterBus optical fibre device net it can be equipped with the special interfaces for InterBus Optical Fibre.
The optical fibre interface is stated as F-SMA type 905.

The connectors for the optical fibres are
DO1 and DI1 for Remotebus In and
DO2 and DI2 for Remotebus Out.

The connection must conform to „Technical Guideline For Optical Transmission“.

For the optical transmission a dielectrical fibre with refractive index profile, likely a polymer fibre with a diameter of 980 µm of the core and 1000 µm of the coating. The connector of the type F-SMA is according to the specifications of IEC 874-2 respectively DIN 47258.

The permitted distance between two subscribers of the optical fibre device bus is 1 through 5 m.



Infrared light can **damage the retina of the eye!** Never look into the open end of the optical fibre! Secure the open ends of the optical fibres and the plugs with caps!
Always wear safety glasses!



The transmitter and receiver units may get unusable by dirt. For transportation, storage and when a unit is not in use, place caps on the plug terminals.

TesiMod BT5N

2.5.8 Pin Assignment X3 SER2 RS232c

Interface for download, upload, logging printer and scanner.

Pin	Designation	Channel	Function
1	⊕	SER2	Low-noise Earth
2	TD	SER2	Transmit Data
3	RD	SER2	Receive Data
4	RTS	SER2	Request to Send
5	CTS	SER2	Clear To Send
7	SGND	SER2	Signal Ground
20	DTR	SER2	Data Terminal Ready

A shielded cable with stranding in layers (cable type LiYCY) and with a minimum cross-section of 0.25 mm² must be used. The maximum cable length is 15 m.



Connect the cable shield to the metal hoods of the connectors over as large a surface as possible! Please refer to appendix A.

2.6 Shielding

The shield must be connected to the metal hoods of the connector housings at both ends and over as large a surface as possible. It should be noted that a potential equalization line with a minimum cross-section equal to 10 times that of the shield may be necessary as a result of the grounding on both sides.

TesiMod BT5N

2.7 Display

The display in the **BT5N** operating terminal is a 4-line LCD Module with a width of 20 characters. The version with the VF Module is fitted with a 4-line display with a width of 20 characters too. The characters are displayed by a matrix of 5 x 7 dots. The LCD Module has a yellow-green LED backlighting. The VF Module is luminescent. The operating terminal has an optimum viewing angle of approximately 90°. The contrast of the display is kept constant over the entire temperature range. The default contrast can be set online by means of a system variable.

The displayable character set is shown by the display as the standard character set. Depending on type of LCD module the character set Cyrillic or Katakana is available, too. The VF module only supports loading the character set Katakana. Additionally you can use the character attribute *Flashing*.

Displays for the BT5N (LCD/VF) at a glance:

	<u>BT5N (LCD)</u>	<u>BT5N (VF)</u>
Type:	LCD Module	VF Module
Resolution:	4 x 20 Dots	4 x 20 Dots
Backlight:	LED backlit	Luminescent
Lifetime LCD/VF:	100000 h	50000 h
Lifetime Backlight:	100000 h	—
Lines:	4	4
Characters/Line:	20	20
Character Matrix:	5 x 7 Dots + Cursor	5 x 7 Dots + Cursor
Character Height:	4.3 mm	4.7 mm
Illumination Color:	—	Blue-green
Background Color:	Yellow-green	—
Visible Front Cutout:	23 mm x 74 mm (H x W)	23 mm x 74 mm (H x W)



If the display is damaged, do not swallow or breathe in the liquids or gases being emitted and avoid direct contact with skin.

Danger of Poisoning! Could Result in Burns!

TesiMod BT5N

2.7.1 Display Contrast Setting

The contrast for the display can be adjusted by means of the software. This requires the system variable **LCDContrast** to be set up in an I/O mask of the application. The value can then be modified using any editor that can handle integer numbers.

The limit values for the brightness must be set to

Lower level: -25
Upper level: +70

The values that apply for the VF Module brightness settings are as follows:

Input Value	Brightness Level	Brightness
<1	2	50%
1	1	25%
2	2	50%
3	3	75%
4	4	100%
>4	2	50%

If this variable is not defined in the menus or the value is out of the range of values, the default setting (value 25) will be loaded when the system is initialized.

The system variable can be stated in any I/O-mask of the application!

2.7.2 Default Contrast Setting

If the contrast of the display should be such that the masks are no longer legible, the default contrast setting can be restored using the user mode switch.

Position of the switch to restore the contrast:

S1 ON
S2 OFF
S3 OFF
S4 ON

This switch position coincides with “activating download by hardware”. The contrast will be reset before the warning is displayed. The warning will be displayed in a legible manner.

How to setup the default contrast:

- Switch off the operating terminal
- Set the DIP-switches to the above described switch positions
- Switch on the operating terminal
- Upon display of a warning, switch off the operating terminal
- Set the switch S4 to the OFF-position
- Switch on the terminal again.

The application description is not lost.

TesiMod BT5N

2.7.3 Character Attributes

By preselecting an attribute, all characters can be displayed as follows:

- normal
- flashing

2.7.4 Font Normal

```
öü\↑↓φ↑↓→←!"#$%&'()*
+,-./0123456789:;<=>
?@ABCDEFGHIJKLMNPOQR
STUVWXYZ[\]^_`abcdef
```

```
ghijklmnopqrstuvwxyz
<|>→←üäåöü。「」・ヲアイウ
エオヤヨツッアィウエオカキククコサシス
セソタチツテトナニヌネノヒフヘホマミム
```

```
×ε†13りリルL■7^°αββεμσ
ρqr' j* φφñöpqqθωΩÜ÷π° 4
〒万円÷■
```

2.7.5 Displayable Character Set

0	32	64	@	96	`	128	160	192	224
1	33	65	A	97	a	129	ü	161	225
2	34	66	B	98	b	130		162	226
3	35	67	C	99	c	131		163	227
4	36	68	D	100	d	132	ä	164	228
5	37	69	E	101	e	133		165	229
6	38	70	F	102	f	134		166	230
7	39	71	G	103	g	135		167	231
8	40	72	H	104	h	136		168	232
9	41	73	I	105	i	137		169	233
10	42	74	J	106	j	138		170	234
11	43	75	K	107	k	139		171	235
12	44	76	L	108	l	140		172	236
13	45	77	M	109	m	141		173	237
14	46	78	N	110	n	142	Ä	174	238
15	47	79	O	111	o	143		175	239
16	48	80	P	112	p	144		176	240
17	49	81	Q	113	q	145		177	241
18	50	82	R	114	r	146		178	242
19	51	83	S	115	s	147		179	243
20	52	84	T	116	t	148	ö	180	244
21	53	85	U	117	u	149		181	245
22	54	86	V	118	v	150		182	246
23	55	87	W	119	w	151		183	247
24	↑	56	X	120	x	152		184	248
25	↓	57	Y	121	y	153	Ö	185	249
26	→	58	Z	122	z	154	Ü	186	250
27	←	59	[123	{	155		187	251
28		60	<	124		156		188	252
29		61	=	125	}	157		189	253
30		62	>	126		158		190	254
31		63	?	127		159		191	255

/001-0158/
BT5NB_grau_eng_V10.30000AOKO



TesiMod BT5N

2.7.6 Loadable Font Katakana

032	048	064	080	096	112	160	176	192	208	224	240
	0	1	2	3	4	5	6	7	8	9	0
!	1	A	Q	a	9	u	7	+	4	e	o
"	2	B	R	b	r	T	I	Y	X	e	e
#	3	C	S	c	s	J	O	T	E	e	o
\$	4	D	T	d	t	L	I	T	P	u	o
%	5	E	U	e	u	.	o	+	1	e	U
&	6	F	V	f	v	9	o	2	3	o	+
'	7	G	W	g	w	7	+	2	7	o	π
(8	H	X	h	x	4	o	2	U	J	"
)	9	I	Y	i	y	9	7	J	U	"	U
*	:	J	Z	j	z	2	o	N	V	i	+
+	:	K	L	k	l	4	o	7	o	"	π
,	<	L	*	l	l	+	5	7	7	o	π
-	=	M	I	m	i	2	2	^	o	o	+
.	>	N	^	n	^	3	e	o	"	π	
/	?	O	_	o	e	u	U	7	"	o	■
047	063	079	095	111	127	175	191	207	223	239	255

TesiMod BT5N

2.7.7 Loadable Font Cyrillic

	032	048	064	080	096	112	160	176	192	208	224	240
	0	а	б	в	г	д	е	ё	з	и	й	к
!	л	а	б	в	г	д	е	ё	з	и	й	к
"	2	б	р	б	р	е	ё	з	и	й	к	л
#	3	с	с	с	к	к	н	н	н	н	н	н
\$	4	д	т	д	т	з	р	ь	ъ	ъ	ъ	ъ
%	5	е	у	е	у	н	ё	а	х	у	у	у
&	6	ф	у	ф	у	н	н	ъ	ъ	ъ	ъ	ъ
'	7	а	в	а	в	л	з	а	л	л	л	л
(8	х	х	х	х	л	н	л	л	л	л	л
)	9	т	у	т	у	в	а	л	л	л	л	л
*	#	т	з	т	з	ф	к	л	л	л	л	л
+	#	к	л	к	л	у	а	л	л	л	л	л
,	<	л	л	л	л	н	н	н	н	н	н	н
-	=	н	л	н	л	б	л	л	л	л	л	л
.	>	н	л	н	л	н	л	л	л	л	л	л
/	?	о	л	о	л	е	л	л	л	л	л	л

/001-0158/
BT5NB_grau_eng_V10.300000AOK0


TesiMod BT5N

2.8 User-Mode Switch

The user-mode switch is placed at the side of the unit.

User-Mode Switch

4 Switch Positions



S1	S2	S3	S4	Function
I	X	-	-	Standard-Mode with PLC (delivery state)
I	X	I	-	Standard-Mode without PLC
-	I	-	-	Transparent-Mode with start and stop code of the keys
-	-	-	I	Transparent-Mode without stop code of the keys
I	-	-	I	Activate download (deletes application memory) und default contrast setting

Legend of above table:

- I = Switch position ON
- = Switch position OFF
- X = Switch position irrelevant

TesiMod BT5N

2.9 Battery

A built-in lithium battery buffers the data in the CMOS-RAM and also supplies the real-time clock with power. The battery provides a minimum life of 5 years, even under unfavourable operating conditions. If the battery is drained the system message „change battery“ is generated.

We recommend to replace the battery every 4 years while performing the regular maintenance.

A new battery is supported by Sutron electronic or the sales representative of your country.

If the system message „change battery“ would not be recognized in due, eg the real time clock is interrupted or displays a wrong time, a loss of data in the CMOS-RAM can be expected. In this case you must check all alterable data like passwords, parameters in the system variables, data sets of recipes and the entries of the message system after replacing the battery.

Replacing the battery:

The battery can be replaced while the operating voltage is connected to ensure that the message data and time setting are not lost. Mind the safety instructions!

- Remove the mounting bolts of the connectors
- Remove the fastening screws of the enclosure and remove the enclosure
- Replace the cable fastener, which is used to hold the battery
- Plug off the connector of the battery cable and replace the battery
- Plug on the connector of the new battery
- Place the new battery onto the plastic carrier on the printed circuit board and fasten it with a new cable fastener
- Place the enclosure on the rear side of the unit
- At first fasten the bolts of the interface connectors and at last fasten the screws of the enclosure properly

Changing the battery may only be performed by qualified and authorized personnel!

Sewage and refuse disposal:

Dispose only drained batteries into the collection box of the community or of the local dealer. The battery is stated as drained when the message „change battery“ appears on the display of the appliance.

To prevent short circuitry in the collection boxes insulate the poles of each battery with insulation tape or put each single battery into a plastic bag.



Do not put lithium batteries in fire or heat them above 100° C and do not recharge them. **Danger of Explosion!**



Do not open lithium batteries. **Danger of Poisoning!**



Hazardous voltages can exist inside electrical installations that can pose a danger to humans. Coming in contact with live parts may result in **electric shock!**



Electrostatic discharges can damage electronic components! ESD protective measures must be observed!

TesiMod BT5N

2.10 Fuse

A semiconductor fuse is used to prevent damage to the operating terminal. Once the fuse has been activated, the device must be disconnected from the supply voltage to allow the semiconductor fuse to regenerate. With an ambient temperature of 20 °C, the regeneration takes about 20 seconds. The higher the ambient temperature, the longer the regeneration period.
The semiconductor fuse is not designed to be replaced.

2.11 Application Memory

The unit is equipped with a 256 KByte flash memory an application memory.
After switching on the unit the size of the application memory is displayed. This memory area is available to store the user application, the loadable protocol driver, the fonts and the recipe data.

3 Technical Data

Keyboard	a Total of 30 Keys, Membrane with Tactile Feedback, 2 Million Switch Cycles Divided into 6 Control Keys 6 Function Keys with LEDs and Slide-in Identification Strips 2 Special Keys with LED 3 Special Keys without LED 13 Editing Keys	
LCD Display	Backlit LCD Module / Luminescent VF Module, 4 Lines with 20 Characters Each, Display Area 23 x 74 mm (H x W) with Glare Suppression for Increased Contrast Lifetime LCD: 100000 h Lifetime Backlight: 100000 h Lifetime VF: 50000 h	
Interface X3	Variable Baud Rates and Data Formats SER2 RS232c	Download/Upload/Scanner/ Logging Printer
Interface X2	X2.1/X2.2 InterBus X2.1/X2.2 SUCOnet K X2 PROFIBUS-DP X2 MPI X2.1/X2.2 CAN-Bus DO1/DI1 DO2/DI2 InterBus Optical Fibre	Communication Communication Communication Communication Communication Communication

TesiMod BT5N

Protocols Standard	none
Protocols Field Bus	CAN/CANopen InterBus Moeller SUCOnet K PROFIBUS-DP Siemens S7 MPI
Central Unit	Z84-CPU, 10 MHz, Watchdog Timer, Real-Time Clock, Programmable Interface Parameters, Temperature Compensation of the Display, Adjustment of Brightness/Contrast, Battery Monitoring, User Mode Switch
Memory	256 KByte Flash Memory, Application Memory 256 KByte Flash Memory, Firmware 128 KByte stat. CMOS-RAM, Battery-Backed
Connection System	Plug-in Type, via SubminD Connector Strips
Supply Voltage	24 V Direct Voltage, Residual Ripple Max. 10%, SELV in accordance to DIN EN 61131 Minimum Voltage 19.2 V Maximum Voltage 30.2 V Typ. Power Consumption <0.3 A Peak Current (10 ms) <0.5 A
Connected Load	~10 W
Fuse	Semiconductor Fuse
Reverse Voltage Protection	Protection Diode
Noise Immunity	EC Electromagnetic Compatibility Directive 89/336/EEC EN 50082-2 EN 55011 Limit Class B EN 55022 EN 61000-4-2 EN 61000-4-3 EN 61000-4-4 EN 61000-4-5 EN 61000-4-6

TesiMod BT5N

Environmental Test	Operating Temperature	0°C to 50°C
	Storage Temperature	-20°C to 70°C
	Relative Humidity for:	
	Operation	max. 75% annual average
	Storage	max. 75% annual average
	Non-condensing	
Degrees of Protection	EN 60529 Mechanical Degrees of Protection	
	Front: IP65	
	Rear: IP20	
Front Panel	Aluminum, black anodized with affixed polyester cover, polyäthylen foam seal around rear of front panel	
	168.0 x 120.0 x 4.0 mm (H x W x D)	
Panel Cutout	160 x 112 mm (H x W)	
Mounting Depth	58 mm without Connector	
Enclosure	Zinc-Coated Steel Plate	
Total Weight	approx. 500 g	

TesiMod BT5N


4 Declaration of Conformity

EG - Konformitätserklärung

Seriennummer : BT5N/081100

Dokument - Nr./
Monat. Jahr : CE-BT5N.081_98/06.1999

Der Unterzeichner, der den nachstehenden Hersteller vertritt

Hersteller :		
Anschrift :	SÜTRON ELECTRONIC GMBH Kurze Straße 29 D-70794 Filderstadt (Bonlanden)	Telefon 0711/77098-0 Telefax 0711/77098-60

oder der den vom Hersteller nachstehend benannten Bevollmächtigten vertritt, der innerhalb der Gemeinschaft (oder des EWR) niedergelassen ist (falls zutreffend)

Bevollmächtigter:	Siegfried Buck	
Anschrift:	Kurze Straße 29	D-70794 Filderstadt

erklärt hiermit, daß das Produkt

Produktkennzeichnung :	Tesimod Bedienterminal BT5N/081100
------------------------	------------------------------------

in Übereinstimmung mit den Bestimmungen der nachstehenden EG-Richtlinie(n) (einschließlich aller zutreffenden Änderungen)


Referenz-Nr.	89 / 336 / EWG
Titel	Richtlinie des Rates zur Angleichung der Rechtsvorschriften der Mitgliedsstaaten über die elektromagnetische Verträglichkeit

und daß die Normen und/oder technischen Spezifikationen, die auf der Umseite in Bezug genommen sind, zur Anwendung gelangt sind.

Die letzten beiden Ziffern des Jahres in dem die CE-Kennzeichnung angebracht wurde: (nur einzutragen, wenn die Übereinstimmung mit den Bestimmungen der Niederspannungsrichtlinie 73/23/EWG erklärt wird)

Aussteller : 

Ort , Datum : Filderstadt , 01.06.99

Unterschrift: 
Siegfried Buck , Geschäftsführer
(Name und Funktion der vom Hersteller oder von seinem Bevollmächtigten zur Unterschrift berechtigten Person)

Die Sicherheitshinweise der mitgelieferten Produktdokumentation sind zu beachten .

EG-Konformitätserklärung

Seriennummer : BT5N/081100

Dokument - Nr./
Monat, Jahr : CE-BT5N.081_98/06.1999

Bezugnahme auf Normen und/oder technische Spezifikationen oder Teile von diesen die für diese Konformitätserklärung zur Anwendung gelangt sind :

- harmonisierte Normen :

Referenznummer	Ausgabedatum	Titel	Teile (1)
DIN EN 55011	12.98	Funkstörungen bei ISM-Geräten	
DIN EN 50082-2	02.96	EMV-Störfestigkeit Industriebereich	2
DIN EN 61000-4-2	1996	EMV-Störfestigkeit ESD	2
DIN EN 61000-4-3	08.97	EMV-Störf. Hf-elektromagn. Felder	3
DIN EN 61000-4-4	1996	EMV-Störfestigkeit Burst	4
DIN EN 61000-4-5	1996	EMV-Störfestigkeit Surge	5
DIN EN 61000-4-6	04.97	EMV-Störf. leitungsgef. Störgr.	6
DIN EN 55022	05.99	Funkstörungen bei ITE-Geräte	

- oder andere Normen und/oder technische Spezifikationen:

Referenznummer	Ausgabedatum	Titel	Teile (1)
----------------	--------------	-------	-----------

- andere Technische Lösungen, deren Details in den technischen Unterlagen oder in der technischen Dokumentation enthalten sind :

- Andere in Bezug genommene Dokumente oder Informationen, die von den anzuwendenden EG-Richtlinien gefordert werden :

Prüfbericht : 86137-1-BCD, PNR52

(1) Wo zutreffend, müssen die angewandten Teile oder Abschnitte der Norm oder der technischen Spezifikation in Bezug genommen werden.

SÜTRON ELECTRONIC GMBH Kurze Straße 29 D-70794 Filderstadt (Bonlanden)	Telefon 0711/77098-0 Telefax 0711/77098-60	Geschäftsführer: Siegfried Buck Frank Mohn	Amtsgericht Nürtingen HRB - Nr. 981
--	---	--	--

TesiMod BT5N

5 Index

A

Application Memory 38

B

Battery 37

C

Character Attributes 33

Control Keys 8

D

Declaration of Conformity 41

Default Contrast Setting 32

Degree of protection 18

Display 31

Display Contrast Setting 32

E

Editing Keys 7

Explanation of Symbols 5

F

Font

 Cyrillic 35

 Displayable 33

 Katakana 34

 Normal 33

Front Panel Dimensions 19

Front View 6

Function Key Arrangement 10

Function Keys 10

Fuse 38

K

Key

 Acknowledge 9

 Clear 9

 Cursor down 8

 Cursor home 9

 Cursor left 8

 Cursor right 8

 Cursor up 8

 Data Release 9

 Decimal Point 8

 Enter 9

 Help 9

 Minus 8

 Page 9

 Plus 8

 Print 9

Keyboard 7

M

Mounting Depth 20

Mounting the Terminal 18

P

Panel Cutout 21

Pin Assignment

 InterBus Optical Fibre 29

 X1 Supply Voltage 23

 X2 MPI 27

 X2 PROFIBUS-DP 26

 X2.1 / X2.2 CAN-Bus 28

 X2.1 / X2.2 InterBus 24

 X2.1 / X2.2 SUCOnet K 25

 X3 SER2 RS232c 30

R

Rear View

 CAN-Bus 16

 InterBus 12

 InterBus Optical Fibre 17

 MPI 15

 PROFIBUS-DP 14

 SUCOnet K 13

S

Shielding 30

Side View 20

Slide-in Identification Strips 11

Special Keys 9

T

Technical Data 39

U


User-Mode Switch 36

TesiMod BT5N

Appendix A

A Appendix A

A.1 Shielding of SubminD - Interconnections



- 1 SubminD Connector
- 2 Shield
- 3 Cord Grip
- 4 Cable

The shield must be pushed back tubularly.

By fastening the cable with the cord grip you have to ensure an electrical contact of the shield to the housing over an area as wide as possible and an appropriate strain relief.

