

Spark Curvy

A User's Guide

Content

1	Overview	3
1.1	<i>Introduction</i>	3
1.2	<i>Phone overview</i>	3
1.3	<i>Safety Notice</i>	4
1.4	<i>Maintainenance</i>	4
2	Getting Started	4
2.1	<i>SIM</i>	4
2.2	<i>Password Protection</i>	5
2.3	<i>SIM Lock</i>	5
3	Phone Menus	6
3.1	<i>Call logs</i>	6
3.2	<i>Contacts</i>	6
3.3	<i>Music</i>	7
3.4	<i>Camera</i>	8
3.5	<i>Messages</i>	8
3.6	<i>MultiMedia</i>	9
3.7	<i>File Manager</i>	11
3.8	<i>Fun & Games</i>	11
3.9	<i>Organizer</i>	11
3.10	<i>Tools</i>	11
3.11	<i>Settings</i>	12
3.12	<i>Internet Services</i>	17
4	SAR (Specific Absorption Rate) Information	18
5	E-waste Disposal Mechanism	18
5.1	<i>Do's and Don'ts for disposal e-waste</i>	18
5.2	<i>Consequences of improper handling & disposal of E-Waste</i>	19
6	Troubleshooting	19
7	Lava warranty certificate	21

1 Overview

1.1 Introduction

Thank you for choosing Spark Curvy mobile phone. You can read the manual for comprehensive understanding of using mobile phones and enjoy its functionality and simple method of operation.

Spark Curvy supports Dual SIM system. This phone provides you variety of features to facilitate your work and leisure activities. In addition to providing call facility, also provides you phone book, personalized ring tones, alarm, camera, image viewer, video recorder, video player, audio player, FM, facility to insert Memory Card, calculator, calendar, GPRS etc.

Lava mobiles reserve the right to alter the contents of this manual without any prior notice.

1.2 Phone overview



1 Receiver

2 Navigation Key

3 Left Soft Key

4 Dial/Answer Key

5 OK Key

6 Right Soft /Torch Key

7 End/Power Key

8 Keypad

9 Camera

10 Speaker

11 Flash Light/Torch

1.3 Safety Notice

If your phone is lost or stolen, immediately inform your telecomm service provider to de-activate the SIM. This will prevent you from unnecessary postpaid bills & prepaid balance loss. To make more secure use of mobile phones, please take precautionary measures, such as:

- Set up mobile phone password, PIN password & utilize privacy settings to prevent your phone & SIM from unauthorized usage.


1.4 Maintenance

Keep your mobile phone away from water & high humid areas. Use a soft, dry cloth to clean the phone, battery and charger. Regular clean your mobile to avoid dirt accumulate on open areas of phone or else may lead to poor keypad detection, power-down or down graded audio & camera quality.

2 Getting Started

2.1 SIM

Before start using your phone you must insert a valid SIM (Subscriber Identity Module) card.



Warning: Be sure to remove the battery before taking inserting SIM or memory card. There is absolutely prohibited in the case of an external power supply connected during insertion or removing the SIM, or SIM card and mobile phone may be damaged.

2.2 Password Protection

To prevent unauthorised usage, you can set the phone, password protected. To Use this function, you must enter the phone lock under security settings > phone security > Phone Lock to set password

Enter the phone lock password, press the LSK to confirm. By default, the phone lock password is set to 4321. It is recommended to change it.

2.3 SIM Lock

To prevent illegal use of your SIM Keep your SIM, PIN (Personal Identification Number) protected. To Use this, you have to set the PIN Lock on under security settings> PIN lock. You have to enter the PIN password at boot time, so that you can unlock the SIM card and use your SIM service. Enter the PIN password, press the LSK to confirm. By default, the PIN is set to 1234. If 3 consecutive incorrect attempts, your SIM will be network locked, the phone will ask for PUK password.

3 Phone Menus

3.1 Call logs

3.1.1 Missed calls

Display the missed calls list. Select contact & press the Options key:

- **View:** View the details.
- **Call:** Call the record number.
- **Send text message:** Send text message to record number.
- **Add to Blacklist:** Save the number to phonebook black list.
- **Delete:** Delete the number.

3.1.2 Dialed calls

Display the list of contacts of phone numbers to who call has been initiated. Please refer to missed calls for details.

3.1.3 Received calls

Display the list from who call has been received. Please refer to missed calls for details.

3.1.4 All calls

Display the all calls list (Missed, Dailed & Receieved). Please refer to missed calls for details.

3.1.5 Delete call logs

Press the LSK to select & "OK" to enter sub-menu to delete call records from respective call logs.

3.1.6 Call timers

Display the SIM 1 & SIM 2 Last, dialled, received & total call duration.

3.2 Contacts

You can use the phonebook to store records, can store the following: name and phone number. In the phonebook list, select a name, press the dial key to make call. Select a contact in the phonebook, you can do the following:

- **View:** View the contact details or edit record.
- **Send text message:** Send text message to this number.
- **Call:** Make a call to the number.
- **Edit:** Can edit and save record.
- **Delete:** Delete the record.
- **Copy:** Copy the current record to Phone/SIM.
- **Add to Blacklist:** Add the number to phonebook black list.
- **Add to Message Blacklist:** Add the number to message black list.
- **Mark several:** Mark some or all contacts to send message or delete.
- **Contact settings:**

Preferred storage: Can be in the SIM1, SIM2, Phone and All to which will store to SIM1 on no space, will store to SIM2 on no space, will store to phone.

Memory status: View the usage and free Phonebook capacity.

Copy contacts: To copy contacts to & fro between SIMs & phone memory.

Move contacts: To cut paste contacts to & from the SIMs to phone memory

Delete all contacts: To delete all contacts in SIMs & phone memory.

Backup contacts: Backup phonebook list.

Restore contacts: Restore the backed up contacts

3.3 Music

In the Audio player interface, you can press left and right keys to switch the music; Use Up & Down navigation key to adjust the play volume. Press the LSK to enter "list" menu and choose to play any songs in the list.

Press LSK to see options for highlighted song.

- **Play:** To play the selected song
- **Settings :**

List auto gen: Turning it on, you can perform Refresh Playlist operation.

Repeat: You can set particular or all songs to repeat mode.

Shuffle: Random order of play list.

Background play: Turning this on enables you to listen songs in other menu's too (background). Song play will pause while calling & will resume after call completion

3.4 Camera

The phone includes 1.3 MP camera which stores pics in memory card. State in the preview, press the LSK to enter "Options":

- **Switch to video recorder:** Switch to the video recorder.
- **Photos:** Photo album shows the current list of files.
- **Camera settings:** Including Anti-flicker, Scene mode, White balance and Delay timer, setting operation contents of the regulation. Use LSK > "OK" to save the current settings.
- **Image settings:** Include the Image size and image quality regulation.
- **Restore default:** Set all parameters to default settings.

3.5 Messages

It facilitates to send SMS, view receive SMS, save SMS etc. You can also create back of SMS & restore from Memory card

3.5.1 Write message

- **Send to :** After editing the information, select the operation, enter the number manually, or add records from the phonebook, you can do **send, Edit recipient, Remove recipient, Remove all recipients, Save** operations. Sent SMS to one or more persons, and storage to Drafts.
- **Input method:** ABC, Abc, abc or hindi etc
- **Advanced:**
 - Insert number:* Insert number into SMS from phonebook.
 - Insert name:* Insert the name of the record into SMS from phonebook.
- **Save:** Save to drafts.
- **Cancel:** To cancel the message written.

3.5.2 Inbox

Press LSK "Options" to enter the menu:

- **View:** To view the received message's details.
- **Reply:** Send SMS to the sender.
- **Call sender:** Make a call to the sender.
- **Forward:** Send the message to other people.
- **Delete:** Delete the message.

- **Delete all:** Delete all messages.
- **Save to phonebook :** To save number on SIM or phone memory

3.5.3 Drafts

SMS not sent but saved are stored. For options, please refer to "Inbox".

3.5.4 Outbox

SMS not sent successfully are stored here. For options refer to "Inbox".

3.5.5 Sent messages

List the SMS sent by you. For options, please refer to "Inbox".

3.5.6 SMS settings

- **SIM1\SIM2:** This menu can set SMS address, delivery report, reply path and voicemail server function.
- **Memory status:** View the SIM and Phone Occupied & free memory.
- **Save sent message:** If you turn off this feature, sent SMS will be unsaved.
- **Preferred storage:** Can set preferred storage as SIM or phone.
Note: This function needs the network operator support.
- **Message Blacklist:** To block the numbers for receiving any messages.

3.5.7 SMS Backup

Create a backup of SMS into Memory card.

3.5.8 SMS Restore

To restore SMS from Memory card.

3.6 MultiMedia

3.6.1 Image viewer

To view the images captured from mobile camera. Press the LSK to enter to "Options" to choose the pictures to do the View, Send, Use as, Rename, Delete,

change Storage and check Image information operations. Use navigation key to switch over pictures.

3.6.2 Video recorder

- **Switch to camera:** Switch to the camera.
- **Camcorder settings:** Recorder settings including Anti-flicker setting.
- **Video settings:** Include video quality.

3.6.3 Video player

Choose video player sub-menu, you can easily view the saved video player in the video list, press the LSK to enter "Options" to select the video files to do the play, send(send the video via Bluetooth or multimedia message if you want) ,rename, delete etc operations.

3.6.4 Sound recorder

The options consist of:

- **New record:** Start a new record. You can pause, start & stop recording. On stop you can choose to save the video.
- **List:** Display the sound you recorded and saved in the memory card.
- **Settings:** You can set the file format and audio quality of the record.

3.6.5 FM radio

FM interface, press the OK key to turn on / off FM play, press the up/down navigation key to automatic search, press left/right navigation key to adjust the FM playing volume. Press the left soft key "Options" can show FM options menu, the content were:

- **Channel list:** Shows FM channel list.
- **Manual input:** To manually enter the channel frequency, 87.5 ~ 108.0.
- **Auto search:** Auto search FM channels in the channel list.
- **Settings:** To Turn on/off the background and loudspeaker play. Also can set FM record audio quality.
- **Record:** Record your favorite FM audio.
- **File list:** To view get recorded FM audio

3.7 File Manager

Menu display **Memory card**. Select “**Memory Card**”, press the **LSK** to enter “**Options**”:

- **Open:** Displays the directories and files.
- **Format:** Format the memory card, this action will remove all available memory data.
- **Details:** More information you can view, such as Name, Total size, free size.
You can play the music or video files, view Photo, copy/move/delete files, rename files and so on. You can send the file through Bluetooth.

3.8 Fun & Games

This menu displays Lava zone, Fl & Eat N Run games

3.9 Organizer

3.9.1 Calendar

Enter calendar sub-menu, the screen will show a calendar month, and other background box with the current date marked. Press the up, down, left, and right navigation keys to change the date, calendar information on the screen will be updated accordingly. Press the left soft key “Options” option to display the calendar menu, and content as follows:

3.9.2 Alarm

Five alarm can be set. Select and edit an alarm clock: Can edit the setting of alarm on / off, Time, Snooze, Repeat, Alarm tone and Alert type. You can choose to set to repeat: Once, Everyday & Customize of days.

3.10 Tools

3.10.1 Calculator

Press the **LSK** to “Clear” & **RSK** (Back) to exit the calculator.

Note: This calculator has limited accuracy and rounding errors will be generated, especially while doing operation on out of range numbers which are beyond

capacity of phone to calculate. When the calculation is out of range, the display area will use the letter "E" to represent.

3.10.2 SIM tool kit

Enter SIM tool kit menu, display Operators's information.

3.10.3 Torch:

To turn on/off the torch.

3.10.4 Bluetooth

- **Power:** Activate Bluetooth on or off the Bluetooth function.
- **Connect:** You can connect the searched Bluetooth devices.
- **Visibility:** If set on, other devices can search this Bluetooth device; if set as off, can't.
- **My device:** Can search for nearby Bluetooth devices.
- **Search audio device:** Free devices to search for near-free Bluetooth enabled devices, such as Bluetooth headsets.
- **My name:** The Bluetooth device name can be modified.
- **Advanced Options :**

Audio path: It can be set to be in phone or forward to Bluetooth headset.

The file received will be automatically stored on memory card.

3.11 Settings

3.11.1 Profiles

Profiles include General, Silent, Meeting, Outdoor and Headset. Based on the different scenarios you can select the corresponding profile. You can activate, customize & reset.

- **Activate:** Enable the selected profile.
- **Customize:** It lets you alter the profile settings as per your needs.

Alert type: Can choose to Ring only, Vib. Only, Vib.and ring, Vib.

Ring type: You can choose repeat and beep once.

Ringtone: You can choose ringtones 1-3, or from the memory card.

Ringtone volume: To set the volume level from 1 to 7.

Message: You can choose ringtones 1-5 or from memory card

Message volume: To set the volume level from 1 to 7.

Keypad: You can set keypad as silent, click and tone

Keypad volume: To set the volume level from 1 to 7.

System alert: To turn on/off system alert.

- **Reset:** Reset profiles to defaults settings.

3.11.2 Phone settings

Into the phone settings sub-menu, you can change the following settings:

3.11.2.1 Time and Date

You can set the phone time and date. The menu consists:

- **Set home city:** Set the mobile phone home city.
- **Set time/date:** Time and date can be set to standard format. Phone allows you to set year from 2000 to 2030 between the dates. If daylight saving is set to open, then the phone time to add in the original time of one hour or one hour later.
- **Set format:** Set time and data's form.
- **Update with time zone:** On /off update with time zone.
- **Auto update time:** On /off auto update time.

3.11.2.2 Languages

Phone supports both English & Hindi language. Set the current language type, then menu and interface refresh for the corresponding language.

3.11.2.3 Preferred input method

The phone supports 5 types of input methods (ABC, abc & Hindi etc) for SMS & at other relevant menus. By default it is set to Abc.

3.11.2.4 Shortcuts

It facilitates to generate the list of items which will pop-up on pressing right navigation on home page. Press LSK (options) it displays add, edit, delete, delete all and change order.

3.11.2.5 *Dedicated keys*

Set up Navigation keys as a shortcut to particular menu item while on home screen. By default, Up: Camera, Down: Calendar, Left: write message & Right: Shortcuts.

3.11.2.6 *LCD backlight*

To set the LCD brightness level and turn off time (Backlight off time).

3.11.3 **Display**

- **Wallpaper:** To set the Wallpaper already stored in phone or choose from memory card.
- **Show date and time:** Whether to show date and time on home screen or not

3.11.4 **Call settings**

Sim1 & Sim2 settings will be activated only after inserting the sim's.

3.11.4.1 *Call waiting (SIM1 & SIM2)*

On enabling this feature, while already on call if new call comes, the network will notify you. This feature helps to answer new call without cutting the current call.

- **Activate:** Launch the function.
- **Deactivate:** Close the function.
- **Query status:** Query the function's status.

3.11.4.2 *Call divert (SIM1 & SIM2)*

It allows you to divert incoming call to other phone number you specify or store in voice mail. The features include: Divert all voice calls, Divert if unreachable, Divert if no answer, Divert if busy, divert all data calls.

3.11.4.3 *Call barring (SIM1 & SIM2)*

You can set the call barring on incoming & outgoing calls as per scenarios. Some network providers may not provide this service call. Please contact your network provider. Network provider will provide a four-ban password so that you

can enable call restrictions.

Change the password to enter the old call barring password, set new restrictions on the password. By default it's 4321

3.11.4.4 *Advanced settings*

- **Auto call record:** Turns on the automatic recording during a call.
- **Blacklist:** This feature allows you to block the numbers from which you do not want to receive the call.
- **Auto redial:** When turned on, your phone on failed attempt can automatically redial upto 10 times. This feature can save you the trouble of repeated calls.
- **Call time reminder:**It can prompt a certain length of time to set up the call, according to the menu function mode in order to select the following tips:

Off : Close the function.

Single: Enter any numbers between 1-3000 (sec) , which arrived at the selected time (seconds) of talk time when prompted.

Periodic: Enter any number between 30-60(sec), from the input time (in seconds), the intervals of 1 minute for talk time tips.

- **Vibration on Call Connection:** Phone will vibrate when call is connected
- **Answer mode:** When “Any key” option is enableed, on pressing any key other for incoming call other than power key will answer the call and on selecting option “Auto answer when headset mode” all incoming call will be received automatically.

3.11.5 **Network settings**

Press the left soft key to select automatic or manual mode. In Automatic, mobile phone SIM card information is automatically selected according to service provider. In manual you have to search the network services, mobile phone search to get the current list of service providers from which user can select the right service provider.

3.11.6 **Connectivity**

You can set Modem account as well as WAP account & use sim card services.

3.11.7 **Dual SIM settings**

Select to enable or disable the SIM cards services. Flight mode will disable the

SIM cards & other wireless connection

3.11.8 Security settings

Into the "Security Settings" menu, you can set the phone's security options for mobile phone and SIM card to avoid unauthorized use.

3.11.8.1 SIM security

- **PIN lock:** PIN password to lock your SIM card to prevent unauthorized use. If the current SIM card lock is off select On to lock. The next boot requires that you enter the correct PIN password to enter; if the current SIM card lock is on, select off to keep the PIN non password protected.
- **Change PIN:** If the current PIN password lock has been activated, you can re-set on the PIN password
- **Change PIN2:** PIN2 old to enter the correct password, you can set on the PIN2 password.

3.11.8.2 Phone security

- **Phone lock:** Phone lock password can prevent your mobile phone being used by the others.
Select on to enable the phone lock. Enter the correct password to enable phone lock; on next boot it requires the password to unlock the phone.
- **Change password:** Enter the current password and then enter a new password to change. New password will be set only after it is confirmed. Phone default password is 4321.

3.11.8.3 MobileTracker

- **Enable Mobile Tracker:** Input phone password into, the mobile tracking set to on or off.
- **MobileTrackerSetting:** Input phone number and remarks.
- **Change password:** Reset new password.

3.11.8.4 Screen auto lock

Set the screen auto lock time.

3.11.8.5 Privacy Protection

- **Settings:** Input phone password to set privacy for Call logs, Messages, Contacts & File Manager. Default Password is 4321.
- **Change password:** Change the privacy protection password.

3.11.9 Restore factory settings

In this menu, enter the password, the phone automatically reboot the phone to restore the default settings. The default password is 4321.

3.12 Internet Services

3.12.1 Internet

In the internet service interface, it has included the following items:

- **Internet :**
 - **Homepage:** Log on homepage, you will find it is a WAP website that you setted.user can set it by themselves.
 - **Bookmarks:** That default bookmarks, yahoo. You can go to relevant website conveniently. Users can add bookmarks by themselves.
 - **Search or input URL:** You can edit any website you want, but it is effective.
 - **Settings** it includes following items to users to set: data account, browser options and preferences settings.

Note: GPRS service requires network support & data enabled SIM card, must be after the opening and in a GPRS network coverage area, you can use GPRS services.

4 SAR (Specific Absorption Rate) Information

The highest SAR value for this mobile phone is <1.6 W/Kg, in accordance with the requirements of the ICNIRP, which recommended that the limit for exposure to radio waves is 1.6 watts/kilogram(W/kg) averaged over 1 gram of tissue. For more information, please visit our website (www.lavamobiles.com) to query.

Safety precautions:

- Use wireless hands-free system (Headphone, headset) with a low power

Bluetooth emitter

- Make sure the cell phone has a low SAR
- Keep your calls short or send a text message (SMS) instead. This advice applies especially to children, adolescents and pregnant women
- Use cell phone when the signal quality is good
- People having active medical implants should preferably keep the cell phone at least 15cm away from the implant

5 E-waste Disposal Mechanism

'E-waste' means waste electrical and electronic equipment (WEEE). In other words E-waste is a popular, informal name for electronic products nearing the end of their "useful life". For more details about e-waste please refer e-waste rules, 2011 www.moef.nic.in

5.1 Do's and Don'ts for disposal e-waste

5.1.1 Do's:

- Ensure that an Authorized Person repairs your Lava products
- Call Our Local Authorized Collection Centers to Dispose Lava products
- Always drop your used electronic products, batteries or any accessories thereof after the end of their life at nearest Authorized Collection Point or Collection Center.
- Separate the packaging material according to responsible waste disposal options and sorting for recycling.
- Always remove the battery from the product, when you do not intend to use the product anymore it in future.

5.1.2 Don'ts:

- Do not Dismantle your Lava Product on your own
- Do not give your e-waste to Kabbadi Wala / Scrap Dealer/ Rag Pickers.
- Do not dispose-off the e-waste in landfills
- Never dump E-waste in garbage bins.
- Do not dispose of your product at municipal waste bins or rooms.
- Do not throw used batteries into household waste.

5.2 Consequences of improper handling & disposal of E-Waste

- Improper disposal of waste prevents natural resources from being re-used.
- Some waste contains hazardous chemicals and if not disposed of properly may release toxins into the soil and water, and also releases greenhouse gases into the environment
- If e-waste is not properly disposed of, it can threaten the health and well-being of humans and animals and it also has adverse effect on the environment.
- Placing of batteries or devices on or in heating devices, such as microwave, ovens, stoves, or radiators and improper disposal of batteries may lead to explosion.
- If the battery terminals are in contact with metal objects, it may cause a fire.
- For more details on how to dispose of your Lava products at the end of life, Please refer the list of our Services Centers on Pan India basis on our website www.lavamobiles.com or please view this link for the details of Service Centers
<http://www.lavamobiles.com/support-services>.

6 Troubleshooting

Service Center number No.: 1860-200-7500

Kindly note please send area code of place through SMS to this No. and in return you will get address of service center nearest to you by SMS

Frequently Asked Questions (FAQ's and Troubleshooting)

FAQ	Cause and Solution
Fail to switch on	Press the power key for over 1 second. Check if the battery is properly connected. Please remove and install it again and retry; Check if battery is appropriately charged.
Fail to connect to network	In case of Weak signal, please try and move to a location with strong signal and try connecting to the network again; Please ensure that you are not beyond the network coverage of service providers; Please ensure you have a valid SIM card. Please contact your network provider for further information.

Display information while turning on	Check if the SIM card is installed correctly Handset lock password: If the handset lock is activated, you have to input handset password. Input PIN: if Inputting PIN while turning the phone on each time is activated, you have to input the PIN code. Input PUK code: When you've input wrong PIN code for 3 times will lock the SIM card. You need to input the PUK code provided by your network provider.
Poor quality of calling	Please check if the sound volume is tuned properly In an area with poor network conditions, example: basement, the signal might be weak. Try searching a location with stronger signal reception and call again. While using the mobile phone in the peak period of communication, like commute time, you may not be able to call because of line congestion.
Standby duration shortened	The standby duration is relative to the network systems. While the mobile phone is in an area with poor signal strength and cannot receive the signal, the handset will continuously search for a base station. This will significantly reduce battery charge. It is recommended that you turn off your mobile in area with no signal reception to save battery. Need replacing the battery: Please change to a new battery as battery performance may decrease after prolonged usage.
SIM Card Error	Dirt on the metal surface of an SIM card: Use clean cloth to wipe the metal touch point on an SIM card. The SIM card is not installed. The SIM card is damaged. Please contact your network service provider.
Fail to dial out	Please check if you press the dial key after typing the number. Please check if calling is forbidden because of default settings. Please check if the SIM is valid. Please check if the call barring is set. Please check if the fixed dial function is set.
Callers cannot contact you	Please check if the mobile phone is on and connected with the network. Please check if the Call barring or call divert is activated. Please check if the SIM card is valid.

Fail to charge	May be due to poor contact. Please check if the plug is connected well. Please confirm if the environment temperature is within the range of 0°C ~40°C while charging. If the battery or charger is damaged in that case you need to replace it.
----------------	--

7 Lava warranty certificate

Limited warranty: LAVA international Ltd. (LAVA) provides limited warranty for your mobile phone and original accessories delivered with your mobile phone (hereinafter referred to as “product”)

The warranty period for the transceiver is one (1) year and for battery, charger and headset is six (6) months from the date of purchase.

LAVA Warranty Subject to the conditions of this Limited Warranty, LAVA warrants a product to be free from defects in design, material and workmanship at the time of its original purchase by you, and for a subsequent period of one (1) year for transceiver and six (6) months for battery & charger. You shall have no coverage or benefits under this warranty in the event that any of the following conditions are applicable:

- The product has been subjected to abnormal use or conditions, improper storage, exposure to 1, excessive moisture or dampness, exposure to excessive temperature, unauthorized modification, unauthorized repair (including but not limited to use of unauthorized spare parts in repairs), abuse, accidents, Acts of God, spills of food or liquids, improper installation
- You have not notified Lava about defect during the applicable warranty period.
- The product serial no. code or the accessories date code has been removed, defaced or altered.
- The product has been used with or connected to an accessory (i) Not supplied by Lava or its affiliates, (ii) Not fit for use with the product or (iii) Used otherwise than in manner intended.
- The seals of the product’s battery enclosure have been broken or shown evidence of tempering or the product’s battery has been used in equipment other than that for which it has been specified usable by LAVA.
- All plastic surfaces and all other externally exposed part that is scratched or damaged due to normal use.

To get maximum of your new product, we recommend you to:

- Read the guidelines for safe and efficient use as mentioned in the manual.
- Read the terms and conditions of your Lava warranty in the manual.

- Keep your original receipt; you will need it for warranty services if asked to produce.
- Present this Lava Warranty Certificate along with original proof of purchase whenever you require any warranty services.

In case Lava product needs service, please visit the nearest Lava service centers given in the service guide. Please visit our Website www.lavamobiles.com for updated list of Authorized Service Centers near to your location. Important note: for your warranty to be valid, all information on the warranty certificate has to be completed including the stamp from the authorized distributor/retailer. All warranty information, product features and specifications are subject to change without notice.

IMEI No.
Dealers Stamp
Date of purchase
Model No.