

SZA-NA(FM) Operation Manual



Thank you for purchasing the **HOCHIKI** Very High Sensitivity Smoke Detection System SZA-NA(FM). This manual describes safety precautions and instructions to use the SZA-NA(FM) correctly. Read this manual carefully before using the SZA-NA(FM). Keep this manual near for quick reference. HOCHIKI shall not be liable for loss of profits or benefits, indirect, special, consequential or other similar damages arising out of improper use of this product, for any reason. The content of this manual is subject to change without any prior notice.





Table of Contents

1.	PARTS DESCRIPTION AND FUNCTIONS	1
1-1	Front Panel	1
1.2	Inside the SZA-NA(FM)	2
2.	BASIC WIRING	4
3.	INITIAL SYSTEM STATUS AND NORMAL SMOKE DETECTION STATUS	5
4.	INDICATIONS AND OPERATION WHEN SMOKE IS DETECTED	5
4.1	Indication When a Smoke Alarm Occurs	5
4.2	Resetting the Alarm	5
5.	INDICATIONS AND OPERATION WHEN AN AIR FLOW FAULT IS DETECTED	5
5.1	Indications When an Air Flow Fault Occurs (High Air Flow Fault or Low Air Flow Fault)	6
5.2	Resetting the Air Flow Fault	6
6.	INDICATIONS AND OPERATION WHEN FAULTS ARE DETECTED	6
6.1	Monitoring Items	6
6.2	Indications When a Fault Occurs	6
6.3	Resetting the Faults	7
7.	LASER UNIT OPERATION TESTS	7
7.1	Automatic Laser Unit Test	7
7.2	Manual Laser Unit Test	7
8.	SETTINGS	7
8.1	Setting Procedure	8
8.2	Data Setting	8
9.	CONTACT OUTPUT STATUS	14
9.1	Contact Output Status In Normal Monitoring	14
9.2	Contact Output Status When Power to the SZA-NA(FM) is Lost	14
10.	SPECIFICATION	15
11.	IF YOU HAVE ANY QUESTIONS, CONTACT	15














I. SAFETY PRECAUTION

SYMBOLS AND MARKS

This manual contains various symbols and marking to alert and inform the user to prevent personal injury and property damage. Read the notices and instructions below carefully before using the SZA-NA(FM).


 WARNING	<p>This safety reminder is given to items that are potentially dangerous to life and the system. If these items are performed improperly, you may be seriously injured and in extreme cases, loss of life may result. Operation of the system may be lost.</p>
 CAUTION	<p>This safety reminder is given to items that are potentially dangerous to you and the system. If these items are performed improperly, you may be injured and the system may malfunction.</p>
	<p>Prohibited items</p>
	<p>Required items</p>

Notices on installation and use of the product

 WARNING	 <p>This product is a Class 3B laser product.</p>  <p>Be sure to shut off power to the product before installing or cleaning the product.</p>  <p>Do not look into the sampling pipe from its opening. Exposure to a laser beam can cause damage to your eyes.</p>  <p>Do not touch the inside of the product with a wet hand. You may get a severe electrical shock and the product may be damaged.</p>
 CAUTION	 <p>Touch the head of a metallic screw to dissipate your static electricity before opening the panel (to protect the internal circuitry of the product from damage by static electricity).</p>  <p>Never disassemble or modify the product. Improper servicing may cause a failure or malfunction of the product.</p>  <p>Avoid installing the product in the following places to prevent damage to the product:</p> <ol style="list-style-type: none"> ① Areas in which blockage of the exhaust port or inlet ports of the sampling tube may occur. ② Areas of direct sunlight or exposure to high temperatures. ③ Areas in which high humidity, wet conditions, or significant dust buildup can occur. ④ Areas near a high voltage source or places being affected by electromagnetic induction. ⑤ Areas in which chemicals or gases are present.  <p>Do not place objects or cabling on the product or smoke sampling pipe.</p>  <p>This is a precision instrument. Do not hit or drop the product.</p>  <p>Firmly couple the sampling pipe with the pipe joint. Any gap, clearance, or hole on the joint will reduce the suction force.</p>  <p>Do not put your finger into the sampling pipe joint. The mesh guard in the sampling pipe joint has a sharp edge.</p>

1. PARTS DESCRIPTION AND FUNCTIONS

1-1 Front Panel



(1) Alarm Level Indicators

There are three alarm level indicators to indicate smoke density levels: Alarm 1, Alarm 2, and Alarm 3. When detecting smoke, the SZA-NA(FM) turns on or blinks the appropriate indicators Alarm 1, Alarm 2, or Alarm 3 according to the optical density of the smoke detected.

When the smoke density level is at Alarm level 2 or Alarm level 3, the alarm indicator lights together with the lower level alarm indicators.

Example: When the smoke density level is Alarm 3, the Alarm 3 indicator blinks and the Alarm 2 and Alarm 1 indicators turn on.

Alarm 3: Highest smoke density level. The Alarm 3 indicator blinks red.

Alarm 2: Medium smoke density level. The Alarm 2 indicator turns on red.

Alarm 1: Lowest smoke density level. The Alarm 1 indicator turns on orange.

(2) Air Flow Fault Indicator

This indicator turns on (or blinks) when the SZA-NA(FM) detects a high or low air fault trouble.

(3) System Fault Indicator

This indicator turns on (or blinks) when the SZA-NA(FM) detects a system failure.

(4) POWER Indicator

This indicator turns on (or blinks) when the SZA-NA(FM) is powered on normally. When this indicator is off, the SZA-NA(FM) is non-operational.


(5) RESET Switch

When pressed, this switch resets the smoke, air flow and fault conditions of the SZA-NA(FM). If the smoke density level is still over the preset alarm level after the RESET switch is pressed, the SZA-NA(FM) turns on or blinks the related indicators.


(6) Spanner Screws

These screws are used to mount the front panel on the SZA-NA(FM) body.

1.2 Inside The SZA-NA(FM)









- (1) Rotary Switches (SW8, SW9)
These switches are used for setting of the SZA-NA(FM).
- (2) 7-Segment Display
This display shows an error code representing a trouble when the SZA-NA(FM) detects a failure. This display is also used for setting of the SZA-NA(FM).
- (3) UP Switch
This switch is used to scroll up a list of error codes on the 7-segment display when the SZA-NA(FM) detects some failures. This switch is also used to select a value in setting of the SZA-NA(FM).
- (4) DOWN Switch
This switch is used to scroll down a list of error codes on the 7-segment display when the SZA-NA(FM) detects some failures. This switch is also used to select a value in setting of the SZA-NA(FM).
- (5) SET Switch
This switch is used for setting of the SZA-NA(FM).
- (6) TEST Switch
This switch is used to test the operation of the SZA-NA(FM) system.
- (7) DIP Switch
This switch is used to turn the indication of the 7-segment display upside down. When installing the SZA-NA(FM) with the suction hole down, set the first microswitch of the DIP switch to the OFF position. Always leave the second to fourth microswitches in the OFF position.



- (8) Laser Unit for Smoke Detection
This unit optically detects smoke.
- (9) Air Flow Sensor
This sensor senses a flow of air taken in from the air sampling tube.
- (10) Air Intake Fan for Air Sampling
This fan takes in air through the air sampling tube.
- (11) 24 VDC Fuse (F3)
This is a 24 VDC-1A fuse for circuit protection.
- (12) Jumper for Selecting Contact Logic (J1, J2, J3, J4)
These jumper pins are used to select dry contact output logic for Alarm 3, Alarm 2, Alarm 1, and System Fault: N/O ("a" contact, normally open) and N/C ("b" contact, normally closed)
Jumper for Alarm 3: J3
Jumper for Alarm 2: J2
Jumper for Alarm 1: J1
Jumper for System Fault: J4
- (13) Connector for Power Supply of Fan
This connector is for power of the fan, and it is usually inserted.
When starting up the SZA-NA(FM) in a low temperature environment, the SZA-NA(FM) may detect and annunciate "Air flow sensor trouble". In this case, start-up the SZA-NA(FM) with this connector unplugged, then plug back in later.

2. BASIC WIRING


 WARNING	 <p>Make sure to observe correct polarity. Use only approved and proper capacity cable when connecting the SZA-NA(FM).. Failure to follow these recommendations may cause damage to the SZA-NA(FM) or cause a fire.</p>
 CAUTION	 <p>If a fuse blows, investigate the wiring and remove the cause of the problem.. Replace fuse only with similar type size and rating..</p>  <p>The earth terminal must be connected. If the earth is not connected, improper operation may occur.</p>  <p>When making a inlet/outlet hole on the cable hole plate, remove the plate from SZA-NA(FM) before making the hole. Do not make any holes on main unit itself. After installation, ensure all debris is removed from and around the main unit. After performing the insulation test, it is imperative that the shorting bar in Jumper 7 (J7) and the FG line on the PCB should be removed. Failure to remove these components at this point may result in irreparable damage to the unit.</p>

Wiring Example

DC Input Voltage: 24V±10%

Relay Contact Rating: 24VDC, 0.5A

(The wiring example shows the state of the relay contacts before the power source is switched ON.)



3. INITIAL SYSTEM STATUS AND NORMAL SMOKE DETECTION STATUS

When turned on, the SZA-NA(FM) initially turns on the POWER indicator, the Air flow fault indicator, and the System fault indicator on the front panel, and shows the current sensitivity range on the 7-segment display behind the front panel.

About 20 seconds later, the SZA-NA(FM) becomes ready for detection, turns off the Air Flow Fault indicator, the System trouble indicator, and the 7-segment display. The SZA-NA(FM) starts normal monitoring during which, only the POWER indicator is on. **The following pages describe the default settings operation.**

4. INDICATIONS AND OPERATION WHEN SMOKE IS DETECTED

4.1 Indications When A Smoke Alarm Occurs

- (1) When detecting smoke, the SZA-NA(FM) turns on or blinks all or some of Alarm 1, Alarm 2, and Alarm 3 indicators according to the optical density of the detected smoke.

Alarm 3: The Alarm 1 indicator turns on orange. The Alarm 2 indicator turns on red. The Alarm 3 indicator blinks red.

Alarm 2: The Alarm 1 indicator turns on orange. The Alarm 2 indicator turns on red.

Alarm 1: The Alarm 1 indicator turns on orange.

- (2) The buzzer sounds differently in accordance with the optical density of the smoke detected.

Alarm 3: Quick beeps (at short intervals)



Alarm 2: Medium beeps

Alarm 1: Slow and short beeps (at long intervals)

* You can mute the buzzer by employing switch settings found on page 11 of this manual.

- (3) The SZA-NA(FM) operates the contact outputs according to the alarm level detected.

4.2 Resetting The Alarm

 CAUTION	 Find and remove the alarm cause before resetting the SZA-NA(FM), otherwise the alarm condition will not be reset.
--	---

After locating and extinguishing the source of smoke, press the RESET switch on the front panel. If the smoke density is still over the preset alarm level after the RESET switch is pressed, the SZA-NA(FM) turns on or blinks the related indicators again.

The SZA-NA(FM) can be set to latch the alarm status until the RESET switch is pressed or self-reset the alarm status (for automatic recovery) when the smoke optical density drops below the alarm levels.. By default, the SZA-NA(FM) is factory-set to latch all smoke alarms signals.

5. INDICATIONS AND OPERATION WHEN AN AIR FLOW FAULT IS DETECTED

5.1 Indications When An Air Flow Fault Occurs (High Air Flow or Low Air Flow Faults)

- (1) When detecting an air flow fault, the SZA-NA(FM) turns on the Air Flow Fault indicator. Default setting is set to disable detection of a high Air Flow Fault.)
- (2) The buzzer in the SZA-NA(FM) makes slow beeps to announce an Air Flow Fault.

- (3) The SZA-NA(FM) operates the System Fault contact outputs and alerts the related facilities.
- (4) The SZA-NA(FM) shows a related error code on the 7-segment display. When other troubles or faults exist, you can see their error codes by pressing the UP or DOWN switch.

Error code	Fault Name
11	High Air Flow Fault
13	Low Air Flow Fault

5.2 Resetting The Air Flow Fault

You can latch the air flow fault status until the RESET switch is pressed or self-reset the fault status (for automatic recovery) when the air flow fault is removed. The default setting for the SZA-NA(FM) is to latch Low Air Flow fault.

6. INDICATIONS AND OPERATION WHEN FAULTS ARE DETECTED

When the SZA-NA(FM) detects an fault, immediately troubleshoot and remove the cause to return the SZA-NA(FM) to normal monitoring status.

6.1 Monitoring Items

Item	Name of alarm	Description
Laser unit fault	Laser unit trouble	Checks the smoke detecting laser unit for a failure.
Air flow sensor trouble	Air flow sensor trouble	Checks the air flow sensor for a failure.
Power fault	Supply voltage failure	Detects a DC input voltage lower than 24 VDC.
Test-related error	Manual test error	Detects an error when the manual laser unit test fails.
	Automatic test error	Detects an error when the automatic laser unit test (once a week) fails.

6.2 Indications When A Fault Occurs

- (1) When detecting one of the above faults, the SZA-NA(FM) turns on the System Fault indicator.
- (2) The buzzer in the SZA-NA(FM) makes slow beeps to alert.
* You can mute the buzzer by setting.
- (3) The SZA-NA(FM) operates the System Fault contact outputs and alerts the related facilities.
- (4) The SZA-NA(FM) shows a related error code on the 7-segment display. When other faults exist, you can see their error codes by pressing the UP or DOWN switch.

Error code	Name of alarm
07	Laser unit fault
09	Air flow sensor fault
15	Supply voltage failure
21	Manual test error
25	Automatic test error

6.3 Resetting The Faults

When detecting a manual or automatic test error, press the RESET switch on the front panel of the SZA-NA(FM).

For other faults or errors, you can set either latching of status until the RESET switch is pressed or self-resetting of status (for automatic recovery) when the fault disappears. As default, the SZA-NA(FM) is factory-set to latch fault status.

7. LASER UNIT OPERATION TESTS



7.1 Automatic Laser Unit Test

The SZA-NA(FM) performs an automatic laser unit test periodically once a week (at a preset time on a preset day of the week). For setting of time and day, see section 7 "SETTINGS."

While the automatic laser unit test is in progress, the SZA-NA(FM) outputs no indication or beeping.

When the automatic laser unit test fails, the SZA-NA(FM) outputs an error code and beeps. For more information, see section 6. "INDICATIONS AND OPERATION FAULTS ARE DETECTED." After checking and repairing, press the RESET switch to return the SZA-NA(FM) to normal monitoring status.

7.2 Manual Laser Unit Test

 CAUTION	 In the manual laser unit test, the alarm contact output functions. Set the related facilities if necessary.
---	--



You can manually test the smoke detection laser unit of the SZA-NA(FM).

To start the manual test, keep on pressing the TEST switch on the printed circuit board for 5 seconds or longer or connect the TEST INPUT terminal to the COMMON terminal for 5 seconds or longer.

While this test is in progress, the SZA-NA(FM) turns on the indicators, activates alerting relays, and buzzing assuming that it detects a smoke alarm. (You can set to suppress indication and buzzing.)


When the manual laser unit test fails, the SZA-NA(FM) outputs an error code and beeps. For more information, see "5. INDICATIONS AND OPERATIONS WHEN THE OTHER ALARM IS DETECTED." After checking and repairing, press the RESET switch at the front side to return the SZA-NA(FM) to the normal monitoring status.

8. SETTINGS

 WARNING	 Call your local HOCHIKI distributor or vendor before changing the setting of the SZA-NA(FM). The SZA-NA(FM) has been factory-set to satisfy your environmental requirements. If improperly set, the SZA-NA(FM) may not work in case of emergency.
--	---

8.1 Setting Procedure

Follow the instructions below to set data for the SZA-NA(FM).



8.2 Data Setting

When you set an invalid value by the rotary switches, the 7-segment display shows "- -."

(1) Setting the current time

SW8	SW9	Value range	Initial value	Item name
1	0	02 to 89	02	Year
	1	01 to 12	01	Month
	2	01 to 31	01	Day
	3	00 to 23	00	Hours
	4	00 to 59	00	Minutes

Specify the current time here.

To specify a year of 2006, set "06" by the rotary switches.

(2) Setting a sensitivity range

SW8	SW9	Value range	Initial value	Item name
2	0	01 to 04	02	Sensitivity range

Specify a range of smoke detection sensitivity here. Smoke detection sensitivity ranges are assigned codes as shown below.

01: 0.005 to 0.1%/m (0.002 to 0.03%/ft)

02: 0.01 to 0.2%/m (0.003 to 0.06%/ft)

03: 0.025 to 0.5%/m (0.008 to 0.15%/ft)

04: 0.25 to 5.0%/m (0.08 to 1.55%/ft)

(3) Setting an alarm level

SW8	SW9	Value range	Initial value	Item name
2	1	01 to 20	20	Alarm 3 level
	2	01 to 20	16	Alarm 2 level
	3	01 to 20	10	Alarm 1 level

Select and specify a 3-step alarm level for smoke density monitoring.

(4) Setting an air flow fault level

SW8	SW9	Value range	Initial value	Item name
2	4	01 to 20	06	Low air flow fault level
	5	01 to 20	20	High air flow fault level

Select and specify an air flow fault level in air flow monitoring.

* This setting is invalid when the air flow monitoring function is disabled.

(5) Setting to enable or disable the air flow monitoring function

SW8	SW9	Value range	Initial value	Item name
2	6	00 to 01	01	Low Air Flow Fault monitoring function
	7	00 to 01	00	High Air Flow Fault monitoring function

Set the air flow monitoring function to enable or disable. The meaning of the setting is as follows: Initially, the high air flow fault monitoring function is disabled.

00: Disabled

01: Enabled

(6) Setting an alarm delay time

SW8	SW9	Value range	Initial value	Item name
3	0	00 to 60	00	Alarm 3 delay time
	1	00 to 60	00	Alarm 2 delay time
	2	00 to 60	00	Alarm 1 delay time

Specify a time period (in seconds) during which smoke detection alarm level is reached before the SZA-NA(FM) annunciates that an alarm has occurred. When "00" is set, the SZA-NA(FM) outputs an alarm immediately when detecting it.

(7) Setting an air flow fault delay time

SW8	SW9	Value range	Initial value	Item name
3	3	00 to 60	10	Low air flow fault delay time
	4	00 to 60	10	High air flow fault delay time

Specify a time period (in seconds) during which an air flow fault is reached before the SZA-NA(FM) annunciates that a fault has occurred. When "00" is set, the SZA-NA(FM) outputs a fault immediately when detecting it.

(8) Setting the delay time of Other faults

SW8	SW9	Value range	Initial value	Item name
3	5	00 to 60	10	Not Used
	6	00 to 60	10	Supply voltage alarm delay time

Specify a time period (in seconds) during which the above faults continue before the SZA-NA(FM) annunciates that a fault has occurred. When "00" is set, the SZA-NA(FM) outputs a fault immediately when detecting it.

(9) Setting to latch or self-reset the alarm status

SW8	SW9	Value range	Initial value	Item name
4	0	00 to 01	01	Latching or self-resetting Alarm 3
	1	00 to 01	01	Latching or self-resetting Alarm 2
	2	00 to 01	01	Latching or self-resetting Alarm 1

You can specify latching the alarm status until the RESET switch is pressed or self-resetting the alarm status (for automatic recovery) when the alarm level drops below the threshold. As the default, the SZA-NA(FM) is factory-set to latch all smoke alarms.

00: Self-resets the alarm status.

01: Latches the alarm status

(10) Setting to latch or self-reset the air flow and other faults

SW8	SW9	Value range	Initial value	Item name
4	3	00 to 01	00	Latching or self-resetting the low air flow fault
	4	00 to 01	00	Latching or self-resetting the high air flow fault
	5	00 to 01	00	Latching or self-resetting the other faults

You can specify latching of the alarm status until the RESET switch is pressed or self-resetting of the alarm status (for automatic recovery) when the fault disappears. As default, the SZA-NA(FM) is factory-set to non-latching.

00: Does not Latch the fault status.

01: Latches the fault status.

(11) Setting to turn on or off the alarm indication while an alarm or fault is delayed

SW8	SW9	Value range	Initial value	Item name
5	0	00 to 01	00	Turns on the Alarm 3 indicator while Alarm 3 is delayed.
	1	00 to 01	00	Turns on the Alarm 2 indicator while Alarm 2 is delayed.
	2	00 to 01	00	Turns on the Alarm 1 indicator while Alarm 1 is delayed.
	3	00 to 01	00	Turns on the Air Flow Fault indicator while the low air flow fault is delayed.
	4	00 to 01	00	Turns on the Air Flow Fault indicator while the high air flow fault is delayed.
	5	00 to 01	00	Turns on the Power Failure indicator while the AC power failure alarm is delayed.
	6	00 to 01	00	Turns on the System Failure indicator while the supply voltage alarm is delayed.

Specify the status of indicators on the front panel while smoke and faults are delayed. Specify ON or OFF for the indicators. As default, the SZA-NA(FM) is factory-set to turn off all of these indicators.

00: ON

01: OFF

* When the AC Power Failure indicator is set to OFF, and the power failure alarm is delayed, the POWER indicator remains ON.

(12) Buzzer setting

SW8	SW9	Value range	Initial value	Item name
6	0	00 to 01	01	Activates the buzzer when Alarm 3 occurs.
	1	00 to 01	01	Activates the buzzer when Alarm 2 occurs.
	2	00 to 01	01	Activates the buzzer when Alarm 1 occurs.
	3	00 to 01	01	Activates the buzzer when a low air flow fault occurs.
	4	00 to 01	01	Activates the buzzer when a high air flow fault occurs.
	5	00 to 01	01	Activates the buzzer when the other faults occur..

Specify turning on or off the built-in buzzer when smoke detection and other faults occur. Specify 00 (ON) or 01 (OFF) for each buzzer. As default, the SZA-NA(FM) is factory-set to turn on the buzzer for all smoke detection and other faults.

00: OFF (Deactivates the buzzer.)

01: ON (Activates the buzzer.)

(13) Setting to enable or disable the automatic laser unit test

SW8	SW9	Value range	Initial value	Item name
7	0	00 to 01	01	Enables the automatic laser unit test.

Specify enabling or disabling the automatic laser unit test. Specify 00 to disable the automatic laser unit test or 01 to enable the automatic laser unit test. As default, the SZA-NA(FM) is factory-set to enable the automatic laser unit test.

00: Disable the automatic test.

01: Enable the automatic test.

(14) Setting a day for automatically implementing the laser unit test

SW8	SW9	Value range	Initial value	Item name
7	1	01 to 07	01	Date of automatically implementing the laser unit test

Specify a day for automatically implementing the laser unit test. Days of the week are assigned unique codes as shown below. As default, the SZA-NA(FM) is factory-set to implement the automatic laser unit test on Monday.

- 01: Monday
- 02: Tuesday
- 03: Wednesday
- 04: Thursday
- 05: Friday
- 06: Saturday
- 07: Sunday

* This setting is invalid when the implementation of the automatic laser unit test is disabled.

(15) Setting the time of automatically implementing the laser unit test

SW8	SW9	Value range	Initial value	Item name
7	2	00 to 23	10	Time (hours) of automatically implementing the laser unit test
	3	00 to 59	00	Time (minutes) of automatically implementing the laser unit test

Specify the time of automatically implementing the laser unit test. As default, the SZA-NA(FM) is factory-set to implement the automatic laser unit test at 10:00 am.

* This setting is invalid when the implementation of the automatic laser unit test is disabled.

(16) Setting to enable or disable fault indications for the manual laser unit test

SW8	SW9	Value range	Initial value	Item name
7	4	00 to 01	01	Enables fault indications for the manual laser unit test.

Specify enabling or disabling fault indications (LED indication, beeping, etc.) in the manual laser unit test. Specify 00 not to implement fault indications (LED indication, beeping, etc.) in the manual laser unit test, or 01 to implement the fault indications. As default, the SZA-NA(FM) is factory-set to enable the fault indications.

- 00: Disable the fault indications for the manual test.
- 01: Enable the fault indications for the manual test.

(17) Setting to enable or disable output contacts

SW8	SW9	Value range	Initial value	Item name
8	0	00 to 01	00	Enable or disable output contacts.

Specify to enable or disable output contacts when a smoke alarm or system fault occurs during installation or maintenance of the SZA-NA(FM). This function controls the operation of the output relay contacts. The setting values are 00 and 01. As default, the SZA-NA(FM) is factory-set to enable alarm and fault output contacts.

- 00: Outputs enabled..
- 01: Outputs disabled.

(18) Setting to activate the buzzer when output contacts are disabled

SW8	SW9	Value range	Initial value	Item name
8	1	00 to 01	00	Activates the buzzer when output contacts are disabled.

Setting to activate the buzzer when output contacts are disabled. In this case, the buzzer beeps at short intervals for about 30 seconds. The setting values are 00 and 01. As default, the SZA-NA(FM) is factory-set to deactivate the buzzer.

00: OFF (Deactivates the buzzer.)

01: ON (Activates the buzzer.)

* This setting is invalid when the output contacts are enabled.

(19) Setting to enable or disable calculation of moving average deviations

SW8	SW9	Value range	Initial value	Item name
8	2	00 to 01	01	Calculates a moving average.

This function calculates a moving average of analog values for 2 seconds and monitors the deviation of the analog value from the moving average. This ensures that a transient analog value change does not significantly affect the monitoring of smoke detection or air flow. The setting values are 00 and 01. As default, the SZA-NA(FM) is factory-set to calculate a moving average of analog values.

00: Enable the calculation.

01: Disable the calculation.

*(20) Setting to clear the event history

SW8	SW9	Value range	Initial value	Item name
8	3	00 to 01	00	Self-resets the event history.

Specify to keep or self-reset the event history in the built-in memory. The setting values are 00 and 01.

00: Does not clear the event history.

01: Clears the event history.

*(21) Setting to clear the analog history

SW8	SW9	Value range	Initial value	Item name
8	4	00 to 01	00	Clears the analog history.

Specify to keep or self-reset the analog history in the built-in memory. The setting values are 00 and 01.

00: Does not clear the analog history.

01: Clears the analog history.

(22) Setting to initialize the system setting

SW8	SW9	Value range	Initial value	Item name
8	5	00 to 01	00	Initializes the system setting.

Specify whether you want to initialize the system settings stored in the built-in non-volatile memory (to the default setting). This function initializes parameter values to the default values. The setting values are 00 and 01.

00: Does not initialize the system setting.

01: Initialize the system setting.

* **Note:** Requires additional hardware and software to read event history.

(23) Setting for External Power Fault input monitoring

SW8	SW9	Value range	Initial value	Item name
8	6	00 to 01	00	External Trouble input logic (NO or NC).

If desired, the SZA-NA(FM) can monitor power faults on a power supply with battery backup using dry relay contacts. Specify the External Fault input contact logic NO or NC. The setting values are 00 and 01. As default, the SZA-NA(FM) is factory-set to "External Fault input logic = NO."

00: Monitors NO contacts.

01: Monitors NC contacts.

9. CONTACT OUTPUT STATUS

9.1 Contact Output Status In Normal Monitoring

Jumper connection for selection of contact logic	Alarm 3•2•1 output	System Fault output
NO	Closed for alarm and Normally-open	Closed for system alarm and Normally-open
NC	Open for alarm and Normally-closed	Open for system alarm and Normally-closed

9.2 Contact Output Status When Power to the SZA-NA(FM) is Lost

Jumper connection for selection of contact logic	Alarm 3•2•1 output	System Fault output
NO	Open	Closed
NC	Closed	Open

10. SPECIFICATION

Item	Specification
Model	SZA-NA(FM)
Power supply	24 VDC \pm 10% 0.5A or less
Working Voltage Range	19.4 VDC ~ 29.0 VDC
Sensitivity range	Selectable from four sensitivity ranges below Sensitivity 1: 0.005 to 0.1%/m (0.002 to 0.03%/ft) Sensitivity 2: 0.01 to 0.2%/m (0.003 to 0.06%/ft) Sensitivity 3: 0.025 to 0.5%/m (0.008 to 0.15%/ft) Sensitivity 4: 0.25 to 5.0%/m (0.08 to 1.55%/ft)
Current output	4-20mA DC output (Receiving resistance: 100 Ω or less)
Contact output	Alarm 1 output, Alarm 2 output, Alarm 3 output, and System Fault output
Contact capacity	24 VDC, 0.5A or less (each contact output)
Contact output logic	NO ("a" contact) or NC ("b" contact) selectable by a jumper
External power fault monitoring input	NO ("a" contact) or NC ("b" contact) selectable by system setting
Wires used	Heat-resistant shielded wires
Materials	Body and panel: Steel 22 Gage, baked painting Display operation panel: Steel 20 Gage
Colors	Body and panel: Munsell 2.5Y9/1 or equivalent Display panel: Munsell 5Y6/0.5 or equivalent
Weight	Approx. 8 lbs.
Dimensions	12 1/2" (W) \times 8 7/8" (H) \times 4" (D) (mm)
Operating temperature	-10°C to +50°C
Installation	Indoor (Non-condensing)
Accessory	Dedicated flexible pipe

11. IF YOU HAVE ANY QUESTIONS, CONTACT:

Hochiki America Corporation
 7051 Village Drive, Suite 100
 Buena Park, CA 90621-2268 USA
 Tel (714) 522-2246
 Fax (714) 522-2268
 Technical Support: (800) 845-6692