



| Manual Cube20 ProfiNET

- | Description
- | Installation
- | Characteristics
- | Startup
- | Diagnostics
- | Technical Data

Publisher's Note

Product Manual for Cube20 BN-PNIO DI8 (Article Number: 56006)

Version 1.0

Version 07_10 DE

Article Number 56006

Murrelektronik GmbH

Falkenstraße 3

D-71570 Oppenweiler

Fon +49 (0) 71 91 47-0

Fax +49 (0) 71 91 47-130

info@murrelektronik.de

Service and Support

Website:

www.murrelektronik.com

In addition, our Customer Service Center (CSC) will be glad to assist you:

The CSC supports customers over the entire course of the project, during planning and the conception of customer applications, configuration, installation, and startup. We also offer competent consulting or – in more complex cases – we even provide direct onsite support.

The CSC has a range of support tools. It performs measurements for fieldbus systems, such as PRO-FIBUS DP, DeviceNet, CANopen, and AS interface, as well as energy, heat, and EMC measurements.

Our coworkers at the Customer Service Center provide their competence, know-how, and have years of experience. They are familiar with how products made by various hardware and software manufacturers interact.

You can contact the Customer Service Center at

telephone number +49 (0) 71 91 47-424

or by email at csc@murrelektronik.de.

About the User Manual and its Structure

Bus Manual:

General explanations and functions for each bus.

On this subject, please click on the links to the next page.

System Manuals:

Describe the system in general and give an overview about the products, accessories and documentation.

Art. No.	Designation
----------	-------------

56030	Cube 20 System
56970	Cube 67 System
56974	Cube 67+ System

www.murrelektronik.com

Product Manuals:

Describe product-specific features.

Art. No.	Designation
----------	-------------

56001	Cube20 BN-P DI8
56005	Cube20 BN-E DI8
56006	Cube20 BN-PNIO DIO8
56035	Cube20 Erweiterungen

www.murrelektronik.com

Here are links to the bus user manuals:



>>> [PROFINET \(www.profinet.com\)](http://www.profinet.com)

Table of Contents

Publisher's Note	I
Service and Support.....	II
About the User Manual and its Structure	III
Table of Contents	V
Important Information	VII
1 Description of the Cube20 BN-PNIO DI8 Art. No. 56006.....	1
2 Installation	3
2.1 Terminal Overview of the Cube20 BN- PNIO DI8 Art. No. 56006	3
3 Characteristics of the Cube20 BN-PNIO	5
3.1 Cube20 BN-PNIO DI8 Art. No. 56006	5
3.1.1 Parameters.....	5
3.2 Identification and Maintenance	8
3.2.1 General Information	8
3.2.2 I&M 0 Module Description	8
3.2.3 I&M 1 – Functions and Installation Locations	9
3.2.4 I&M 2 – Installation Date	9
3.3 Acyclic Access Options.....	10
3.3.1 Index 10 Machine Options Management	10
3.3.2 Index 12 BusControl.....	11
3.3.3 Index 13 Status Request of the Cube20 BN-PNIO	12
3.4 I/O Data of Cube20 PNIO-DP DI8 Art. No. 56006.....	12
4 Startup of Cube20 BN-PNIO	13
4.1 GSDML File	13
4.2 Configuration with S7 Hardware Manager.....	13
4.2.1 General Information	13
4.2.2 Parameterization of Modular Station.....	14
4.2.3 Setting the Topology	14
4.2.4 Identifying Devices in the Network.....	16

4.2.5 Issuing Device Names and IP Addresses	17
5 Diagnostics	19
5.1 LED Indicators	19
5.1.1 Meaning of "Power" LED States	19
5.1.2 Meaning of "Bus Run" LED States.....	21
5.1.3 Meaning of "Cfg F" LED States.....	22
5.1.4 Power Supply Displays at Terminals	23
5.1.5 Signal-Logic Display and LED Behavior	24
5.2 Diagnostics with PROFINET.....	25
5.2.1 Diagnostic Concept.....	25
5.2.2 Predefined Diagnostics	25
5.2.3 Diagnostics of Cube20 BN-PNIO and I/O Modules	27
5.2.4 Diagnostic Message Parameters	28
5.3 Troubleshooting	28
6 Technical Data of 20 BN-PNIO DI8 Art. No. 56006	29
7 Accessories	31
Glossary	X
Legal Provisions	XIV

Important Information

Symbols and Icons

This manual contains information and instructions you must comply with in order to maintain safety and avoid personal injury or damage to property. They are identified as follows:



Notes indicate important information.



Warnings contain information that, if ignored, may cause damage to equipment or other assets or, if you fail to comply with safety precautions, may constitute a danger to the user's health and life.



➔ **Refer to our catalog or visit our inline shop at www.murrelektronik.com.**

Intended Purpose

Before starting the devices, read this manual carefully. Keep it in a location that is accessible to all users at all times.

The products that are described in this manual were developed, manufactured, tested, and documented in compliance with the relevant safety standards. In normal cases, these products do not constitute any danger to persons or objects, provided the handling specifications and safety instructions described in this manual are observed. They meet the specifications of the European EMC Directive (2004/108/EC).



DANGER!

The devices are not safety devices conforming to the relevant standards.

Do not use the OFF state of the outputs to implement safety-related requirements of the system/machine.

The products are designed for industrial use. An industrial environment is defined as one in which loads are not connected directly to the public low-voltage power grid. Additional measures must be taken if the products are used in private, business, or trade environments.

The safe, troublefree functioning of the products requires proper transportation, storage, mounting, and careful operation. Operation of the devices for their intended purposes is only guaranteed when the enclosures are fully mounted. If aggressive media are used, check their material resistance depending on the application.

Current safety and accident prevention laws valid for a specific application must be observed for the configuration, installation, setup, maintenance, and testing of the devices. The power supply must comply with SELV or PELV. Power sources in accordance with EN 61558-2-6 (transformer) or EN 60950-1 (switched-mode power supply) meet these requirements.

Only use cables that meet the requirements and regulations for safety, electromagnetic compatibility, and, if necessary, telecommunications terminal equipment specifications.



Information on the cables and accessories that are suitable for use with this product are contained in the Appendix to this manual.

Qualified Personnel

Only qualified, trained electricians knowledgeable in the safety standards of automation systems may configure, install, set up, maintain, and test the devices. The requirements concerning qualified personnel are dependent on the requirements profiles described in ZVEI and VDMA. For this reason, electricians must know the contents of the manual "Weiterbildung in der Automatisierung" (Further Training in Automation Systems) issued by ZVEI and VDMA and published by Maschinenbau-Verlag, Post Box 710864, 60498 Frankfurt, Germany) before installing and maintaining the devices. They are therefore electricians who are capable of assessing the work executed and any possible dangers arising from this due to their professional training, knowledge, experience, and their knowledge of the pertinent standards; or who have a level of knowledge equivalent to professional training due to their many years of activity in a comparable field.

Only Murrelektronik technical personnel are allowed to execute work on the hardware and software of our devices, if they are devices not described in this manual.



WARNING!

Unqualified tampering with the hardware or software, or failure to observe the warnings cited in this manual may result in severe personal injury or damage to property.

1 Description of the Cube20 BN-PNIO DI8 Art. No. 56006

The Cube20 System is an I/O system for use IP20 zones for the decentralized capture and control of digital and analog process parameters. It consists of a fieldbus-specific bus node and fieldbus-independent I/O modules that are linked to the bus node via an internal system connection. Please note the galvanic isolation between the input for the system power supply and the input for the sensor and actuator power supplies.

To maximize electromagnetic compatibility, we recommend implementing galvanic isolation.



Make sure you isolate the power supplies from different voltage sources for the system electronics (UB), sensors (UI), and actuators (UA). Otherwise, we cannot guarantee proper functionality.




Fig. 1: Typical system setup with galvanic isolation

Figure 1 shows a typical system setup of the Cube20 with digital inputs and outputs (DI / DO) and analog inputs and outputs (AI / AO).

This section explains that PROFINET, the I/O power supply, and the system electronics power supplies are galvanically isolated from each other. The internal electronics of the digital I/O modules are powered from the system cable, i.e. by the bus node. The internal electronics of the analog I/O modules are powered from the I/O power supply.



Information on the analog I/O modules:

Always connect the I/O power supply to guarantee communication for all analog modules via the internal system connection.

Features of the Cube20 BN-PNIO:

- Machine Options Management (see 3.3.1)
- Status request (see 3.3.3)
- Reset by acyclic access (see 3.3)
- IM 0 (see 3.3.2)
- IM 1 (see 3.2.3)
- IM 2 (see 3.2.4)

2 Installation

2.1 Terminal Overview of the Cube20 BN- PNIO DI8 Art. No. 56006




Fig. 2: Terminal overview of the Cube20 BN-PNIO DI8 Art. No. 56006



➔ ***For extensions, we recommend our voltage terminal block Art. No. 56109.***

For more details, please refer to the voltage terminal blocks in the Product Manual.

Refer to our catalog or visit our inline shop at www.murrelektronik.com

3 Characteristics of the Cube20 BN-PNIO

The section below lists the functions of the Cube20 BN-PNIO. They can be enabled or disabled by setting/not setting the parameters described.

3.1 Cube20 BN-PNIO DI8 Art. No. 56006

3.1.1 Parameters

Number of parameter bytes: 4

Bit assignment of parameter Byte 0




Fig. 3: Parameter Byte 0 of Cube20 PNIO-DP DI8 Art. No. 56006

Bit assignment of parameter Byte 1




Fig. 4: Parameter Byte 1 of Cube20 PNIO-DP DI8 Art. No. 56006

Bit assignment of parameter Byte 2




Fig. 5: Parameter Byte 2 of Cube20 PNIO-DP DI8 Art. No. 56006

Bit assignment of parameter Byte 3




Fig. 6: Parameter Byte 3 of Cube20 PNIO-DP DI8 Art. No. 56006



Refer to the appropriate product manual for how to parameterize Cube20 I/O modules. You will find an overview in the chapter "Manual Overview and Layout" on page III.

3.2 Identification and Maintenance

3.2.1 General Information

This section provides you with an overview of the scope of I&M (Identification & Maintenance) functions supported. The tables do not list any values and may change during the course of development (IM0), or may be written by later end-users (IM1).

Detailed lists and descriptions of parameters are contained in IEC 61158-6-10.

I&M data can be requested by acyclic access from the bus node. Addresses are slot-dependent. I&M data are addressable by their slot on the bus node or individual I/O modules.

I&M data are reserved for the bus node. For I/O modules without their own separate I&M data, the bus node must reply to requests with "Feature not supported". I/O modules with I&M data (e.g. IO link) have their requests forwarded and manage their I&M data themselves.

3.2.2 I&M 0 Module Description

I&M0 (required)		0xAFF0
Parameters	Description	Value
VendorID	Manufacturer ID of PNO	0x012F
OrderID	Bus node order number	56006
IM_Serial_Number	16-digit visual string (manufacturer-specific)	MAC ID
IM_Hardware_Revision	Hardware version (16-bit)	
IM_SW_Revision_Functional_Enhancement	Software version for major changes (8-bit)	
IM_SW_Revision_Bug_Fix	Software version for bug fixes (8-bit)	
IM_SW_Revision_Internal_Change	Software version for internal changes (8-bit)	
IM_Revision_Counter	I&M revision counter	0x0001
IM_Profile_ID	I&M profile ID (16-bit)	0x0000
IM_Profile_Specific_Type	I&M profile specification type(16-bit)	0x0000
IM_VERSION	I&M version ID	0x0101
IM_SUPPORTED	Describes which I&M functions are supported	0x0002

Tab. 1: I&M 0

3.2.3 I&M 1 – Functions and Installation Locations

I&M1	0xAFF1	
Parameters	Description	Value
IM_Tag_Function	32-digit visible string – module function	
IM_Tag_Location	22-digit visible string – installation location	

Tab. 2: I&M 1

3.2.4 I&M 2 – Installation Date

I&M1	0xAFF1	
Parameters	Description	Value
IM_Installation_Date	16-digit visible string – module installation date	
IM_Reserved	38 digits	

Tab. 3: I&M 2

3.3 Acyclic Access Options

3.3.1 Index 10 Machine Options Management

Slots 0 to 17 can be enabled or disabled in 8 bytes, provided "Machine Options Management" is parameterized.

Byte 0 Enable/disable Slots 1 to 8:




Fig. 7: Assignment of Byte 0

Corresponds to:

Byte 1: Enable/disable Slot 11 to 17; Slot 18 not available

Write or read accesses without "Machine Options Management" receive the negative reply "Access Denied".

Read accesses with "Machine Options Management" receive a positive reply.

If the configuration is invalid, Index 10 write accesses always receive a positive reply. If the configuration is valid after an Index 10 write access, every following Index 10 write access receives a negative reply with "Access Denied".

If no valid configuration is set in "Machine Options Management", the system does not exchange any relevant data with the controller.

3.3.2 Index 12 BusControl

Byte 0: „BusControl“:




Fig. 8: Index 12 BusControl byte DPV1

The bus node can be reset from the PLC using the BusControl access. This may reset a possibly present UA short-circuit or other fault without switching the power supply of the Cube67+ BN-P on or off manually.

3.3.3 Index 13 Status Request of the Cube20 BN-PNIO

Byte 0: Konfigurationsüberprüfung:




Fig. 9: Belegung Konfigurationsüberprüfung

Read access must be set with Index 13 to know whether a valid configuration was set in "Machine Options Management". Here, 1 is returned if the configuration is valid and the system is OPERATIONAL, otherwise 0.

If the bus node is parameterized with "Standard Configuration", the reply contains the present system state from **Fehler! Verweisquelle konnte nicht gefunden werden..**

Write accesses receive the negative reply "Access Denied".

3.4 I/O Data of Cube20 PNIO-DP DI8 Art. No. 56006

Bit Assignment of Input Data PAE I/O Data

Byte 0								
Bit	7	6	5	4	3	2	1	0
Terminal	X2 03	X2 02	X2 01	X2 00	X1 03	X1 02	X1 01	X1 00

Tab. 4: Input data of Cube20 BN-PNIO DP DI8 Art. No. 56006

4 Startup of Cube20 BN-PNIO

4.1 GSDML File

The GSDML file in XML format is required to operate the devices described in this manual.

GSDML-Vx.x-Murrelektronik- Cube20_BN_PNIO -JJJJMMTT.xml

Import the GSDML file to the appropriate configuration tool before starting up the device.



→ *The GSDML file is downloadable from the Murrelektronik website on the "Service >> Technical Data" page: www.murrelektronik.com*

4.2 Configuration with S7 Hardware Manager

This chapter describes how to configure and parameterize a Cube20 BN-PNIO using the example of the HW Config (hardware configuration software of the Simatic S7 Manager from Siemens).

4.2.1 General Information

Configuring a ProfiNet device is necessary to define the I/O data quantity and reserve the addresses in the controller.

First, add the head module to the virtual bus, just as in a construction kit. Head modules always have zero data length and their function acts as module identification and parameterization. They are in direct connection with the Article Number of each Cube20 BN-PNIO.

Each head module is followed in Slot 1 by a BN–PNIO DI8 as bus node together with its inputs.

Cube20 or Cube67 modules can then be installed in a row. A separate address can be assigned to each of the useful data modules in the PLC process image.

4.2.2 Parameterization of Modular Station

Double-click on any module to open a list box containing the parameter settings for this module.

Select the settings you require.




Fig. 10: Settings of Cube20 field devices in the Simatic Manager

4.2.3 Setting the Topology

ProfiNet offers a number of functions, diagnostic, and maintenance options based on the existing topology or utilizing knowledge of the topology. All Cube20 BN-PNIO devices support the topology setting and automatic topology recognition by the Engineering Tool.

This is followed by setting the topology for the Cube20 BN-PNIO.

Setup via connected adjacent devices is performed using Slots X1 P1 and X1 P2, which represent physical interfaces.

A list of possible ports of other devices in the project is contained in the Topology tab under the "Partner Port" option.




Fig. 11: List of possible partner ports

4.2.4 Identifying Devices in the Network

PNIO devices are identified by their MAC addresses and the appropriate device type. If you want to put several devices of the same type into operation, make sure you provide each with a definite unique identification.

Use your configuration tool to scan and select all the devices in the network. Use the path below to search the network for reachable users in the HW configuration: **Target system → Ethernet → Edit Ethernet Users → Search**

Identification takes place using the blink test. This test makes the LINK LED of the selected Cube20 BN-PNIO device blink at a rate of 2 Hz. Mark an available device and select the **Blink** option.

Fig. 12: Identifying devices in the network

Factory Settings of the Cube20 BN-PNIO

- MAC address 00-0F-9E-xx-xx-xx
- IP address 0.0.0.0
- Device type Cube20 PROFINET
- Device name:

The device name according to the factory settings is unassigned.

4.2.5 Issuing Device Names and IP Addresses

After you identify a device with a unique identification, assign a device name to it. The IP address is issued automatically by the PNIO controller via DCP.




Fig. 13: Issuing device names and IP addresses

The Simatic S7 Manager then shows you the data detected from the Cube20 BN-PNIO.

Further procedures:

- Enter a name for the device.
- Click on "**Assign Name**".
- If you do not want to fetch the address from a DHCP Server, set the required IP address and subnet mask.
- Click on "**Assign IP Configuration**".
- Or select the suboption to fetch the IP address from a DHCP Server.
-



With ProfiNet I/O, it is absolutely necessary to assign a unique name to each device. Address and name resolution is only controlled by the name that is stored permanently in the device.

Reset to Factory Settings

The "Reset to Factory Settings" function clears the previous settings and restores the defaults.

IP address: 0.0.0.0

Device name:

5 Diagnostics

5.1 LED Indicators

5.1.1 Meaning of "Power" LED States







The "Power" LED indicates the state of the Cube20 system voltage and internal communication.



Fig. 14: Power LED on Cube20 modules

Response of Power LED on Cube20 BN Modules

Color		Meaning for Power LED	Remedial Action
	green	System voltage (>12V) applied	
	flashes green	System link interrupted in the Cube20 System. Number of flash pulses corresponds to position of defective expansion module (e.g.: 1 to 15), with several modules, the nearest.	Exchange the affected module and power rest at terminal UB or perform Index 12 of Cube20 BN module via acyclic access
		Example: 	
	off	No system voltage (>12V)	Raise system voltage

Tab. 5: Response of Power LED on Cube20 BN Modules



The I/O data of unreachable modules is reset to zero. The input data of reachable modules is not updated. The output data is also reset to zero.



CAUTION

Devices from the Cube20 series are not safety devices conforming to the relevant standards. Do not use the OFF state of the outputs to implement safety-related requirements of the application.




5.1.2 Meaning of "Bus Run" LED States



The "Bus Run" LED indicates the state of PROFINET communication on the Cube20 PNIO DI8 Art. No. 56006.



Fig. 15: Run LED on the Cube20 PNIO DI8 Art. No. 56006

LED Display	Response	State
	lights up continuously (green)	Data transfer:
	flashing (green)	No data exchange
	off	- Voltage too low (<12 V) at Terminal UB

Tab. 6: Run LED on the Cube20 PNIO DI8 Art. No. 56006





5.1.3 Meaning of "Cfg F" LED States



The "Cfg F" LED indicates the state of a correct/incorrect configuration on the Cube20 PNIO DI8 Art. No. 56006.



Fig. 16: Cfg F LED on the Cube20 PNIO DI8 Art. No. 56006

LED Display	Response	State
	lights up continuously (green)	Configuration OK
	off	No configuration
	flashing (red)	Module flashed over PROFINET
	lights up continuously (red)	Real configuration does not match the projected configuration

Tab. 7: Cfg F LED on the Cube20 PNIO DI8 Art. No. 56006

5.1.4 Power Supply Displays at Terminals

Module Power Supply



No LED display at Terminal "UB". The system voltage state is indicated by the Power LED.



See section: Meaning of "Power" LED States



- The LEDs under "**UI**" indicate the status of the sensor power supply voltage.
- The LEDs under "**UB**" indicate the status of the module operating voltage.

LED display UI and UA	Response	State
	green	Power supply OK (≥ 18 V)
	red	Undervoltage (< 18 V)
	off	Voltage ≤ 12.5 V

Tab. 8: LED module power supply

Peripheral Power Supply

- The LEDs under "**US**" indicate the status of the sensor power supply voltage.
- The LEDs under "**UA**" indicate the status of the actuator power supply voltage.

LED Display US and UA	Response	State
	off	Power supply OK
	red	Overload or short-circuit of sensor or actuator power supply

Tab. 9: LED periphery power supply





The "US" LED is not designed individually for each terminal.

5.1.5 Signal-Logic Display and LED Behavior

Digital Input Modules

Each input and output is assigned a separate status display. It is labeled "00 to 03" or "00 to 07". The label indicates the channel number and bit position. It is arranged under the associated terminal and assigns the status of the peripheral components.

Relationship of signal-logic display and LED behavior at the input

LED Display	Logic Value	Voltage at Input	Signal
	off	0	Input with NO contact function
	yellow	1	
		0 V	
		24 V	

Tab. 10: LED at input of digital modules

5.2 Diagnostics with PROFINET

5.2.1 Diagnostic Concept

The diagnostic concept with PROFINET is divided into two steps.

Logging on the diagnostics:

Step 1: PROFINET saves all diagnostic information in the module.

Step 2: PROFINET sends an alarm telegram to the controller to report that diagnostic information is available. You can request this information as required.

Logging out the diagnostics:

Step 1: PROFINET clears the information in the module.

Step 2: PROFINET reports this to the controller.

5.2.2 Predefined Diagnostics

PROFINET receives predefined error codes that are used in alarm reports to inform the user which error has occurred.

Below is an extract from IEC 61158-6-10.

Code [HEX]	Meaning	Assigned text
0x0000	Reserved	Unknown error
0x0001	Short circuit	Sensor short-circuit
0x0002	Undervoltage	Sensor power supply undervoltage
0x0003	Overvoltage	
0x0004	Overload	
0x0005	Overtemperature	
0x0006	Line break	Line break
0x0007	Upper limit value exceeded	Upper limit exceeded
0x0008	Lower limit value exceeded	Lower limit exceeded
0x0009	ERROR	Fault

Code [HEX]	Meaning	Assigned text
0x000A	Simulation active	
0x000B	Unknown error	
0x000C	Unknown error	
0x000D	Unknown error	
0x000E	Unknown error	
0x000F	Parameter missing	
0x0010	Parameterization fault	
0x0011	Power supply fault	Actuator undervoltage
0x0012	Fuse blown / open	
0x0013	Communication fault	
0x0014	Ground fault	
0x0015	Reference point lost	Reference channel fault
0x0016	Process event lost / sampling error	
0x0017	Threshold warning	Actuator warning
0x0018	Output disabled	Deactivate actuator
0x0019	Safety event	
0x001A	External fault	Desina diagnostic
0x001B	Manufacturer specific	Actuator power supply not available
0x001C	Manufacturer specific	Sensor power supply not available
0x001D	Manufacturer specific	External actuator power supply not available
0x001E	Manufacturer specific	External actuator power supply undervoltage
0x001F	Temporary fault	
0x0609	Manufacturer specific	Machine Options Management not loaded
0x0610	Manufacturer specific	Configuration error

Tab. 11: Predefined error codes in PROFINET

5.2.3 Diagnostics of Cube20 BN-PNIO and I/O Modules

Module	Diagnostic	Error Code	Report to
Digital modules	Sensor short-circuit	0x0001	Module / channel
	Undervoltage (US/UI/UA)	0x0002	Module
	No voltage (UA)	0x0011	Module
	DESINA (only Cube67 modules)	0x001A	Module / channel
	Actuator short-circuit	0x0018	Module / channel
	Actuator warning (only Cube67 modules)	0x0017	Module / channel
Analog modules	Line break	0x0006	Module / channel
	Measuring range undershot	0x0008	Module / channel
	Measuring range overshoot	0x0007	Module / channel

Tab. 12: Allocation between predefined and Murrelektronik-typical diagnostics

5.2.4 Diagnostic Message Parameters

This section describes the parameters used for diagnostic logon and logout.

Slot	Receives information regarding the slot where the diagnostic is reported. The software must know what module is configured at which slot.		
ChannelNumber	The exact channel number can be sent here for channel diagnostics and is then displaced like this. Channel number 0x8000 is reserved for module diagnostics, e.g. undervoltage.		
ChannelProperties	This parameter describes the I/O functions of the affected channel/module with the diagnostic. The values for this are contained in IEC 61158-6-10.		
ChannelErrorType	This is where the error codes from Table 265.2.2 are saved.		
AlarmState	0	-	outgoing diagnostic
	1	-	incoming diagnostic

5.3 Troubleshooting

Diagnostic Message		Possible Cause	Action
Chan- nel	Short-circuit (sensor supply)	Overload or short-circuit of sensor power supply to 0V.	Change cable to sensor or check sensor for short-circuit.
	Line break	Defective line. Only for analog inputs and outputs.	Check connection to sensor or sensor itself.
	Upper limit overshoot	Analog input measuring range overshoot.	Check connection to sensor or sensor itself.
	Lower limit undershoot	Analog input measuring range undershoot.	Check connection to sensor or sensor itself.
	Deactivate actuator	Overload or short-circuit of output signal to 0V.	Check wiring or actuator.


Tab. 13: Troubleshooting

6 Technical Data of 20 BN-PNIO DI8 Art. No. 56006

PROFINET IO Device IP20 with 8 digital inputs

[Terminal X1] → 4 inputs

[Terminal X2] → 4 inputs



EMC

EN 61131-2 Product standard

EN 61000-4-2 ESD	Contact ± 4 kV, air ± 8 kV
EN 61000-4-3 RF-Field & GSM.....	10 V/m
EN 61000-4-4 Burst	± 2 kV DC inputs, ± 1 kV signal lines
EN 61000-4-5 Surge	Asym./symm. ± 500 V
.....	Asym. ± 1 kV
EN 61000-4-6 HF-asymmetric	10 V
EN 61000-4-8 Magnetic field 50 Hz	30 A/m
EN 55011 Emission	QP 40 dBµV/m (30 ... 230 MHz)
.....	QP 47 dBµV/m (230 ... 1000 MHz) Class A

Ambient Conditions

Operating temperature	0°C... +55°C
Storage temperature	-20°C to +85°C
Enclosure type according to EN 60529	IP 20

Mechanical Ambient Conditions

Oscillation according to EN 60068 Part 2-6	5 g
Shock according to EN 60068 Part 2-27	15 g / 11 ms

Miscellaneous

Dimensions (LxWxH) in mm	117 x 56 x 47 mm
Mounting dimension (L xW)in mm	117 x 56 mm
Weight	170 g

Bus Data

Transfer protocol	PROFINET I/O according to IEC 61158
Transfer rate	100 MBit/s
Addressing.....	automatically

System connection

Transfer protocol	Internal system
Addressing.....	Automatic

Connection Possibilities

Internal system connection Out.....	10-pin male connector
Sensor and actuator supply	Cage clamp 2.5 mm ²
Bus connection	RJ45
Sensor	2x4 terminal block connectors

Power Supply

Operating voltage range logic U_B	18 ... 30.2 V DC
Current consumption (only, U_B)	100 mA
Sensor supply U_I	18 ... 30.2 V DC
Reverse voltage protection module electronics	Yes
Reverse voltage protection sensor power supply	yes
Reverse voltage protection actuator power supply	yes
Overvoltage protection	yes (suppressor diode)

Inputs

Delay time for signal change	2 ms
Input characteristics	EN 61131-2, Type 2
Galvanic separation.....	500 V

Sensor power supply

Max. current.....	0.7 A
Short circuit protection for sensors with automatic restart .	Yes
Reverse polarity protection.....	Yes



This is a class A product. The product may cause broadcast interferences in a residential environment. In this case, the applicant may have to take appropriate measures.

7 Accessories

A list of Cube20 accessories is contained in the Cube20 System Manual.



* Refer to our catalog or visit our online shop at www.murrelektronik.com

Glossary

AI	Analog Input.
Deactivate actuator	Short-circuit or overload at an output results in output switchoff.
AO	Analog Output.
BN-PNIO	Bus Node-PROFINET.
Bus Run LED	LED to signal bus status.
Bus segment	Due to the electrical specification of the RS-485 interface, the number of users on the RS485 network is restricted to 32 users. If more than 32 Profibus users are connected, the network must be divided into segments by means of repeaters.
Byte	Equivalent to 8 bits.
Cfg F-LED	LED to signal a correct/incorrect configuration.
DESINA	DEcentralized and Standardized INstallation technology
DI	Digital Input
DIN	Deutsches Institut für Normung (German Standards Institute)
DIN TH35	Standardized DIN mounting rail (35x15 mm, 35x7.5 mm).
DO	Digital Output
DP	Decentral Periphery. Profibus protocol for the high-speed cyclic data exchange.
I/O	Input/Output
EC Directive 2004/108/EC	EMC Directive.
EMC	Electromagnetic Compatibility.
EN	European Standard
ESD	Electrostatic Discharge
FE	Function ground/earth.
GSDML	The Generic Station Description Markup Language file is the device master file in XML format containing the technical features of a PROFINET product. This file is required to configure a PROFINET system and is provided by the device manufacturer.

I	Current.
I/O	Input/Output
I/O link	Standardized communication system to link intelligent sensors and actuators to an automation system.
ID number	A 16-bit number that identifies a Profibus product uniquely. It represents a reference for the DDB file. Several devices may also have the same ID number, provided they are describable in a common DDB file. This number is issued by the Profibus Nutzerorganisation e.V. (German Profibus User Organization).
IEC	International Electrotechnical Commission
IEC 61158	Profibus DP and FMS standard valid worldwide. Successor of international standard EN 50170 Volume 2.
IP20	Ingress Protection, protection degree to DIN EN 60529 1st digit = protection against contact and foreign bodies 2nd digit = protection against water 2: Protection against the ingress of solid foreign bodies above a diameter of 12.5 mm, protection against access by finger 0: No protection against inclusion
ISO	International Standard Organization
LED	Light Emitting Diode
LSB	Least Significant Bit.
FO	Fiber optics, optical fiber.
MSB	Most Significant Bit.
OSI	Open Systems Interconnection
PAA	Process map of outputs
PAE	Process map of inputs
PELV	Protective Extra Low Voltage.
PNO	Profibus/PROFINET-Nutzerorganisation e.V. (German Profibus User Organization)
Power-LED	LED to signal operating status
ProfiNet	Process Field Network
Pt 100	Temperature sensor on platinum base (0°C equals 100Ω).
+R	High potential sensor connection

-R	Low potential sensor connection.
Repeater	Coupling element to process signals between Profibus segments.
RL	Sensor power supply in three-wire mode.
RTD	Resistance Temperature Device.
RTR	Remote Transmission Request. Request for data using the same identifier as used for data transmission.
S	Reference potential
SDO	Service Data Object, Objects for access and manipulation to data in the object directory
Segment	Left segment of the internal system connection (Sockets 0 and 2) and right segment of the system link (Sockets 1 and 3)
SELV	Safety Extra Low Voltage.
Simatic Manager	Programming software for program-logic controllers made by Siemens.
PLC	Program-logic controller
SYNC	Synchronization object
Line	System line connected to an appropriate socket with the associated modules (Socket 0 = Line 0, etc.)
TH	Thermoelement / thermocouple.
TH	Low potential sensor connection.
TH+	High potential sensor connection
Type E, Type J, Type K, Type N, Type R	Thermocouples as per DIN EN 60584.
U	Voltage.
U/I	Voltage / current
UA (brown terminal)	Actuator power supply
UA (red terminal)	Module power supply.
UB	Operating voltage.
UI (red terminal)	Module and sensor power supply.
US (brown terminal)	Sensor power supply.

VDMA	Verband Deutscher Maschinen- und Anlagenbau e.V. (Association of German Machinery and Industrial Equipment Manufacturers)
Virtual Modules	Modules in the GSD file, e.g. line modules or placeholders that do not correspond to any real physical module.
VZ	Sign (+ or -)
ZVEI	Zentralverband Elektrotechnik- und Elektronikindustrie e.V. (German Electrical and Electronic Manufacturers' Association).

Legal Provisions

Exclusion of Liability

Murrelektronik GmbH has checked the contents of this technical documentation for conformity with the hardware and software described therein. Deviations can not be excluded in individual cases. For this reason, Murrelektronik excludes the warranty for the correctness of its contents and any liability for errors, in particular full conformity. The limitation of liability shall not apply if the cause for damage is attributable to willful intent and/or gross negligence, or for all claims arising from the Product Liability Law. Should a major contractual obligation be violated by criminal negligence, the liability of Murrelektronik GmbH shall be limited to damages that typically arise.

Subject to technical changes and alternations in content. We advise that you check at regular intervals whether this documentation has been updated since corrections that may become necessary due to technical advances are included by Murrelektronik GmbH at regular intervals. We are gratefully for any suggestions for improvement.

Copyright

It is prohibited to transfer or photocopy the documentation either in paper or in digital form, reuse or divulge its contents unless otherwise expressly permitted by Murrelektronik GmbH or in conjunction with the production of documentation for third-party products that contain products made by Murrelektronik GmbH. Violations will result in liability for damages. All rights reserved, in particular in the event of the award of patents or granting of utility models.

Right of Use

Murrelektronik GmbH grants its customers a non-exclusive right revocable at any time and for an indefinite period of time to use this documentation to produce their own technical documentation. For this purpose, the documentation produced by Murrelektronik GmbH may be changed in parts, or amended, or copied, and transferred to the customer's users as part of the customer's own technical documentation on paper or on electronic media. The customer shall then bear sole responsibility for the correctness of the contents of the technical documentation produced by him.

If the technical documentation is integrated in part, or in full in the customer's technical documentation, the customer shall refer to the copyright of Murrelektronik GmbH. Furthermore, special attention shall be paid to compliance with the safety instructions.

Although the customer is obliged to make reference to the copyright of Murrelektronik GmbH, provided the technical documentation of Murrelektronik GmbH is used, the customer shall market and/or use the technical documentation on his sole responsibility. The reason is that Murrelektronik GmbH has no influence on changes or applications of the technical documentation and even minor changes to the starting product or deviations in the intended applications may render incorrect the specifications contained in the technical documentation. For this reason, the customer is obliged to identify the technical documentation originating from Murrelektronik GmbH if and inasmuch as the documentation is changed by the customer. The customer shall be obliged to release Murrelektronik from the damage claims of third parties if the latter are attributable to any deficits in the documentation. This shall not apply to damages to the rights of third parties caused by deliberate or criminal intent.

The customer shall be entitled to use the company brands of Murrelektronik GmbH exclusively for his product advertising, but only inasmuch as the products of Murrelektronik GmbH are integrated in the products marketed by the customer. The customer shall refer to the brands of Murrelektronik GmbH in an adequate manner if the brands of Murrelektronik GmbH were used.



stay connected

Murrelektronik GmbH | Falkenstraße 3, D-71570 Oppenweiler | P.O. Box 1165, D-71567 Oppenweiler
Phone +49 7191 47-0 | Fax +49 7191 47-130 | info@murrelektronik.com | www.murrelektronik.com



The information in this manual has been compiled with the utmost care. Liability for the correctness, completeness and topicality of the information is restricted to gross negligence.