

Digital Video Recorder

CADVR-1004C/08C/16C

CADVR-1004CK/08CK/16CK

CADVR-4004C/08C/16C

CADVR-4004D/08D/16D

USER MANUAL

VISTA
Honeywell



CAUTION

**RISK OF ELECTRIC SHOCK
DO NOT OPEN**



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER. NO USER SERVICABLE PARTS INSIDE.

REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the products' enclosure that may be of sufficient magnitude to constitute a risk of electric shock



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF THE PLUG TO THE WIDE SLOT AND FULLY INSERT.

Important Safeguards and Warnings

Thank you for choosing Honeywell VISTA DVRs, for a better understanding of the product, we recommend you read the instruction and safety information before use.

This user manual is an operation guide only. It has no implied or stated warranty, or guaranty of the product described herein. The copy right and all right reserved to the company. Please do not reprint and spread without authority. Please note the latest bulletin of the company for the updated version.

- Please keep in temperature between 0°C and 40°C, Keep away from harsh environment like humid
- Keep out of direct sunlight and devices generating heat
- Do not install it in Harsh environment including humid, dust and smoke
- Keep horizontal mounting
- Keep installing in stable location, prevent it from falling
- Do not place other devices onto it, Heavy stress, violent vibration or water splash are not allowed during transportation, storage and installation.
- Install in Well-ventilated locations. Do not block the vents.
- Only operated in the rated input and output range
- Do not dismantle the product as your wish
- All the examination and repair work should be done by the qualified service engineers. We are not liable for any problems caused by unauthorized modifications or attempted repair.
- Be sure to use all the accessories recommended by manufacturer.
- Before installation, please open the package and check all the components are included.
- Contact your local retailer ASAP if something is broken in your package.

Operation Environment

To display and manage multiple audio and video spontaneously the basic configuration of the server should be as follows:

CPU: Intel Core i3 550

Memory: 4G

Graphics: Discrete graphics 512M, HDD, client tailed

This product works with Windows XP/ WIN7/ WIN8/ VISTA/ MAC.

For best viewing, resolution should be 1024×768, DirectX should be at least ver. 8.1 or newer.

CONTENTS

1.	INTRODUCTION	6
1.1	Product Features	6
1.2	Specification – CADVR-1004C / 08C / 16C	6
1.3	Specification – CADVR-4004D / 08D / 16D	7
1.4	Specification – CADVR-4004C / 08C / 16C	8
2.	SYSTEM STARTUP	10
2.1	Wizard interface	10
2.2	Administrator Login Interface	10
2.3	Basic Setup	11
2.4	Network setup	11
2.5	Network testing	12
2.6	DDNS & Port Setup	12
2.7	Record Mode & Record Setup	13
2.8	HDD Setup	14
2.9	Use of Taskbar (For Mouse operation only)	14
3.	GUI MENU OPERATION	17
3.1	BASIC	18
3.1.1	System setup	18
3.1.2	DATE/TIME	19
3.1.3	DISPLAY	20
3.1.4	RECORD	21
3.1.5	USER	23
3.2	ADVANCE	25
3.2.1	ALARM	25
3.2.2	NETWORK	32
3.2.3	COMM	35
3.2.4	P.T.Z	37
3.3	SEARCH	37
3.4	DISK MANAGEMENT	39
3.4.1	HDD	39
3.4.2	USB Storage	39
3.5	SYSTEM INFORMATION	40
3.5.1	DEVICE INFORMATION	40
3.5.2	NETWORK	41
3.5.3	ONLINE	42
3.5.4	RECORD	42
3.6	DEVICE MAINTENANCE	42
3.6.1	BASIC	42
3.6.2	SETTINGS	44
3.7	LOGOUT	46
4.	NETWORK SETTING FOR REMOTE CONTROL	47

4.1	Obtaining Your Network Settings	47
4.2	Confirm your DVR Connection	48
4.3	Port Forwarding Your Router	49
4.4	Confirm your DVR Remote Connection.....	50
5.	CMS: CA-DVR-CS10	51
5.1	Brief introduction	51
5.2	CA-DVR-CS10 Function	52
5.3	System running environment and installation.....	52
5.4	Operation Guide.....	53
5.4.1	Firmware Login	53
5.4.2	Introduction of the window	53
5.4.3	Add a device	53
5.4.4	Live video	55
5.4.5	Snapshot.....	56
5.4.6	Channel Group	56
5.4.7	Patrol.....	56
5.5	ICON Function Explanation	57
5.6	System Setup	59
5.7	Remote Setup	60
5.8	Log.....	63
6.	DDNS REMOTE CONTROL.....	64
6.1	DVR COMM Setup.....	64
6.2	Domain REELINK.NET setup	64
6.2.1	Log in.....	64
6.2.2	Device Remote View	66
6.2.3	DEVICE MANAGEMENT	66
6.2.4	USER MANAGEMENT	67
6.2.5	LOG QUIRES	69
6.2.6	PERSONAL INFORMATION	70
6.2.7	EDIT PASSWORD.....	70
6.2.8	SYSTEM	70
6.2.9	EXIT	71
7.	CADVRView MOBILEPHONE REMOTE CONTROL	72
7.1	Function Description	72
7.2	Working Environment & Download	72
7.3	CADVRView Operation.....	72
7.3.1	Device Management.....	73
7.3.2	Live View.....	74
7.3.3	Playback.....	76
7.3.4	Settings	78
7.3.5	More	79
7.3.6	About	79

1. INTRODUCTION

1.1 Product Features

- H.264 compression
- Two USB interface, USB2.0 for data backup, USB1.1 for mouse operation
- 2 SATA HDD Slot
- Special file system for security.
- 16 bit color translucent user-friendly GUI, with notes for selected menu items
- Optimized four channel simultaneously playback
- Double level user management
- Support live view, parameter setting and copy playback video via network.
- Free DDNS Service

1.2 Specification – CADVR-1004C / 08C / 16C

Model Number		CADVR-1004C/CK	CADVR-1008C/CK	CADVR-1016C/CK
System	User Interface	Graphic User interface(OSD Menu)		
	Security	User password, administrator different authority		
Video	Video input	4 channels	8 channels	16 channels
	Video output	CVBS/VGA		
	Display	1/4 optional	1/4/9 optional	1/4 /9/16 optional
	VGA	1024*768,1280*720, 1280*1024, 1366*768, 1440*900		
	Video standard	PAL 25f/s CCIR625 NTSC 30 f/s CCIR525		
Audio	Audio compress	ADPCM		
	Audio in/out	1 in, 1out	1 in, 1 out	2 in, 1 out
Alarm	Alarm in/out	N/A		4 in, 2 out
Image & Storage	Video compress	H.264 VBR/CBR		
	Image quality	CIF/HD1/D1(optional)	CIF/HD1/D1(optional)	CIF
	Resolution	4D1 record& 4ch playback	8CIF record& 8ch playback, 8HD1 record&1CH playback, 2D1+6CIF record&1CH playback	16CIF record & 4CH playback
	Video Bit Rate	CIF: 384-768 Kbps(optional) HD1: 512-1024 Kbps(optional) D1: 896-1280Kbps(optional)		
	Audio Bit Rate	32Kbps		
	Storage	1 SATA HDD		
	Recording	Manual/alarm/motion detection/timing		
Setting	Network	RJ45 10MB/100MB Protocol: TCP/IP, PPPOE, SMTP,UPNP,DHCP and DDNS		
	Control Method	Remote control, USB mouse, panel control		
	Mobile live view	I phone /Blackberry/Android/Windows Mobile/Symbian OS		
	Backup	USB2.0, Network		
	Serial	RS485		
Com	Serial	RS485		

	LAN	1 RJ45,10M/100M	1 RJ45,1000M
HDMI & ESATA	--	--	HDMI & ESATA
Working Environment	Working temperature: -10°C~+55°C; Working humid:< 90%		
	Storage Temperature:-20°C~+70°C;Storage humid:< 95%		
Power Supply	A/C 110V -240V / DC 12V/2A		
Consumption	7W(without HDD)		15W(without HDD)
Device Dimension	315mm(L)x230mm(W)x45mm(H)		
Weight	1.5KG		

1.3 Specification – CADVR-4004D / 08D / 16D

Model	CADVR-4004D	CADVR-4008D	CADVR-4016D
[Video]			
Composite Input	4CH, 1.0Vp-p, 75Ω	8CH, 1.0Vp-p, 75Ω	16CH, 1.0Vp-p, 75Ω
Signal Format	NTSC/PAL and RGB(VGA)		
Main Monitor Output	CVBS/VGA/HDMI/ESATA		
VGA Output	1024*768,1280*720, 1280*1024, 1366*768, 1440*900		
Rotation Output	Support		
Image & storage Resolution	4CH D1 record & 4CH playback	8CH D1 record & 8CH D1 playback	16CH D1 record &16CH D1 playback
[Audio]			
Input & Output	4CH BNC Input / 1CH BNC Output	8CH BNC Input / 1CH BNC Output	16CH BNC Input / 1CH BNC Output
Voice Talk	Support		
[Recording]			
Compression Format	H.264 VBR / CBR		
Compression Resolution	D1 Real Time		
Bite Rate	Video Bite Rate: D1: 896-1280Kbps(optional), Audio Bite Rate: 32Kbps		
Recording Mode	Manual/alarm/motion detection/timing		
Motion Detection	Each Channel Area Selectable(Sensitivity Adjustable)		
[Display]			
Multiscreen Display	1 / 4 Windows	1 / 4 / 9 Windows	1 / 4 / 9 / 16 Windows
[Playback]			
Playback	4CH	8 CH	16 CH
Playback Mode	Normal Playback, Various playback speed (Forward, Backward, Step)		
Search Mode	Date/Time, Event (Alarm)		

[Alarm]			
Alarm input	4 Alarm inputs	8 Alarm inputs	4 Alarm inputs
Alarm Output	1 Alarm outputs	1 Alarm outputs	2 Alarm outputs
[Language]			
Multi-Language	English, Chinese, Korea		
[Storage & Back Up]			
Internal HDD	4 SATA HDD, Max. HDD Capacity: Support 2TB each (4X2TB=8TB)		
Data Backup	ESATA, Internet (Support network download and backup)		
	USB2.0 (Flash disk, portable disk, USB burner and etc.), support 3G		
[Serial Port]			
PTZ Camera Control	1 x RS-485, 1 x RS-232		
[Operation]			
Control Applications	Via Front Panel Control, USB Mouse, Remote Controller, TCP/IP (Network), Cell Phone Interface		
[Network]			
Remote Access Tool	ActiveX Base Web Live & Search / VISTA Honeywell CMS Access (Live, Setting, Search, Recoding, ETC.) / Cell phone Network		
Network Service	Protocol: TCP/IP, PPPOE, SMTP,UPNP,DHCP and DDNS		
Network Interface	10/100 base-T Ethernet (RJ-45)		
System Time Sync	Support Network Time Protocol		
[Other]			
Operating Temp.	-10℃~55℃		
Operating Humidity	10%~90% / Non-condensing		
Power	DC 12V, 5A (without HDD & other)		
Dimensions(WxHxD)	440mm(L)x390mm(W)x70mm(H)		
Weight	Approx. 4kg (Without HDD)		

1.4 Specification – CADVR-4004C / 08C / 16C

Model	CADVR-4004C	CADVR-4008C	CADVR-4016C
[Video]			
Composite Input	4CH, 1.0Vp-p, 75Ω	8CH, 1.0Vp-p, 75Ω	16CH, 1.0Vp-p, 75Ω
Signal Format	NTSC/PAL and RGB(VGA)		
Main Monitor Output	CVBS/VGA/HDMI/ESATA		
VGA Output	1024*768,1280*720, 1280*1024, 1366*768, 1440*900		
Rotation Output	Support		
Image & storage Resolution	2CH D1 & 2CH CIF record & 4CH playback	1CH D1 & 7CH CIF record & 8CH D1 playback	2CH D1 & 14CH CIF record &16CH D1 playback
[Audio]			

Input & Output	4CH BNC Input / 1CH BNC Output	8CH BNC Input / 1CH BNC Output	16CH BNC Input / 1CH BNC Output
Voice Talk	Support		
[Recording]			
Compression Format	H.264 VBR / CBR		
Resolution	D1 + CIF Real Time		
Bite Rate	Video Bite Rate: D1: 896-1280Kbps(optional), Audio Bite Rate: 32Kbps		
Recording Mode	Manual/alarm/motion detection/timing		
Motion Detection	Each Channel Area Selectable(Sensitivity Adjustable)		
[Display]			
Multiscreen Display	1 / 4 Windows	1 / 4 / 9 Windows	1 / 4 / 9 / 16 Windows
[Playback]			
Playback	4CH	8 CH	16 CH
Playback Mode	Normal Playback, Various playback speed (Forward, Backward, Step)		
Search Mode	Date/Time, Event (Alarm)		
[Alarm]			
Alarm input	4 Alarm inputs	8 Alarm inputs	4 Alarm inputs
Alarm Output	1 Alarm outputs	1 Alarm outputs	2 Alarm outputs
[Language]			
Multi-Language	English, Chinese, Korea		
[Storage & Back Up]			
Internal HDD	4 SATA HDD, Max. HDD Capacity: Support 2TB each (4X2TB=8TB)		
Data Backup	ESATA, Internet (Support network download and backup)		
	USB2.0 (Flash disk, portable disk, USB burner and etc.), support 3G		
[Serial Port]			
PTZ Camera Control	1 x RS-485, 1 x RS-232		
[Operation & Network]			
Control Applications	Via Front Panel Control, USB Mouse, Remote Controller, TCP/IP (Network), Cell Phone Interface		
Remote Access Tool	ActiveX Base Web Live & Search / VISTA Honeywell CMS Access (Live, Setting, Search, Recoding, ETC.) / Cell phone Network		
Network Service	Protocol: TCP/IP, PPPOE, SMTP,UPNP,DHCP and DDNS		
Network Interface	10/100 base-T Ethernet (RJ-45)		
System Time Sync	Support Network Time Protocol		
[Other]			
Operating Temp.	-10℃~55℃		
Operating Humidity	10%~90% / Non-condensing		
Power	DC 12V, 5A (without HDD & other)		
Dimensions(WxHxD)	440mm(L)x390mm(W)x70mm(H)		
Weight	Approx. 4kg (Without HDD)		

2. SYSTEM STARTUP

SYSTEM STARTUP

Power on/off


Connect the power plug to the power port on the back of the DVR. The system will automatically run a status check, and will start after few seconds. You will see a wizard interface after the system loading.

SETUP WIZARD

Setup Wizard is a quick-set to enter the whole CMS. You can finish the DVR basic settings according to your requirements. This setup wizard contains all the basic settings, like time setup, network setup, HDD format reminder, etc. The DVR will achieve basic functions after the setup wizard has finished. If personalized settings are desired, please login to the main menu and setup to complete this function.

2.1 Wizard interface


Wizard interface is shown below. We recommend the initial user finish the guide step by step for the basic settings. Place a check mark '√' in the box in the lower left corner and then click 'Next' to perform the basic settings.



2.2 Administrator Login Interface

Here we recommend you setup a password for administrator and then click "Next" for more settings; if you click "Cancel", you will enter directly into the "Main Menu"; if you click "Prev.", the system goes to the previous page.

Note: By default, the administrator user name is: admin. There is no password, but for better security, we strongly recommend that you setup a password here.



A screenshot of a login window. It contains a table with three rows: 'User name' with the value 'admin', 'Password', and 'Retype password'. Below the table is a checkbox labeled 'Don't display this window again'. At the bottom right are three buttons: 'prev.', 'next', and 'Cancel'.


User name	admin
Password	
Retype password	

☐ Don't display this window again

prev. next Cancel

2.3 Basic Setup

Date/Time, date format, time format, time zone, camera system, language, should be setup according to the user's needs, as below:



A screenshot of the 'Basic Setup' window. It has a tab labeled 'System'. Inside the tab, there are two labels: 'Video format' and 'Language', each followed by a dropdown menu. Below the dropdowns is a checkbox labeled 'Don't display this window again'. At the bottom right are three buttons: 'prev.', 'next', and 'Cancel'.

System

Video format Video format ▼

Language Language ▼

☐ Don't display this window again

prev. next Cancel

Date/Time Setup: Click calendar and choose the date; Click time, a digital keyboard will appear, and then set to local time.

Date Format: Three format types: MM/DD/YYYY, DD/MM/YYYY, and YYYY/MM/DD.

Time Format: 24-hour/ 12-hour.

Time Zone: Click the down arrow, time zone options will be displayed, please select your time zone.

Note: Once the DVR connects with the internet, it will automatically adjust the time to the time zone you have chosen. Please make sure the time zone you chosen is the desired local time zone.

Camera System: PAL/NTSC optional.

Language: Choose your local language or the language you want.

2.4 Network setup

There are 2 kinds of network setup: obtain an IP automatically or static IP, select the type according to your network requirements, as displayed below:

☐ Obtain an IP address automatically
☒ Use the following IP address

IP address: 000.000.000.000
Subnet mask: 000.000.000.000
Default gateway: 000.000.000.000

☐ Obtain DNS server address automatically
☒ Use the following DNS server addresses

Preferred DNS server: 000.000.000.000
Alternate DNS server: 000.000.000.000

☐ Don't display this window again
prev. next Cancel

2.5 Network testing

The system will test your network setup automatically. If a network connection is abnormal, please return to the previous page to correct the settings and then click “Next”. If no testing is required, just click “Skip” to go to the next page, as displayed below:

Network status	
DVR IP address (LOCAL)	
Subnet mask	
Router IP address	
Preferred DNS server	
Alternate DNS server	
Internet IP address (WAN)	

☐ Don't display this window again
prev. next Cancel

2.6 DDNS & Port Setup

DDNS: Enable/Disable, please enable the DDNS to use a domain name server.

Server: Choose your domain name server: REELINK, dyndns, no-ip, changip or dnsexit.

Host Name: Enter the host name you registered on the domain name server.

User Name: Enter the user name you registered on the domain name server.

Password: Enter the password you registered on the domain name server.

As displayed below:

PORT SETUP

Media Port: one private communication port that between DVR and PC, default: 9000. If this port was occupied by other server port, please change to an idle port.

Web Port: Http port, default: 85, if change the web port, like to: 8088, when need to access through browser, need to add the web port after the IP address.

E.g.: http://ip address: 8088

Note: port range: 1-65535, some local ISP's may block port "85". We recommend you change to something such as e.g. 86 See display below:

2.7 Record Mode & Record Setup

Setup recording and audio for each channel; please tick the mark '√' to enable recording and audio.

There are two record modes: Always/Schedule.

For ease, setup one channel and then copy to the others, as shown below:

RECORD	CH	Resolution	Frame rate	Quality
	1	D1 ▼	25 ▼	Good ▼
	2	D1 ▼	25 ▼	Good ▼
	3	D1 ▼	25 ▼	Good ▼
	4	D1 ▼	25 ▼	Good ▼
	5	D1 ▼	25 ▼	Good ▼
	6	D1 ▼	25 ▼	Good ▼
	7	D1 ▼	25 ▼	Good ▼
	8	D1 ▼	25 ▼	Good ▼
	Bit rate			

Copy CH To CH

2.8 HDD Setup

HDD Information: You can check the HDD capacity and HDD quantity in the HDD setup.

HDD Format: tick '√' under format, and then click "Format".

Note: The newly installed HDD must be formatted through our DVR before usage.

Overwrite: There are three options to choose from; "by days", "by capacity" and "never". Please select desired method.

After the setup of disk, save and confirm interface will be shown on screen and click "Save to log out".

After the completion of setup wizard, DVR can be worked properly. If personalized settings are needed, you can login to the menu to setup. As shown below:

LOGIN
✖



DEVICE ID

(0)

USER NAME

PASSWORD

2.9 Use of Taskbar (For Mouse operation only)

By mouse operation, multi system options can be obtained.

Open task bar: right click any place on the screen, and open the task bar.



Choose an option below:

i. **start** START: Enter into the menu interface.

ii. Zoom of single channel: click and pop-up tick to show the channel to be zoomed.

iii. Zoom of quad: click and pop-up choose any four channels to be zoomed.

iv. Recovery of 8 channels: click to recover to 8 channels.

v. Settings of color: Open color setup interface (As shown below).

CH

1

▼

BRI

26

CON

23

HUE

31

SAT

23

Default


Apply

Choose the channel to be setup and BRI, CON, HUE, SAT can be adjusted from "1-63". Click "default" to recover to default settings; Click "apply" to save the settings.

vi. PIP: Drag mouse to partially enlarge.



vii. Setup of PTZ: Open the control interface of PTZ (As shown below).



- Choose of relevant channel, "all" refer to all channels, control of the PTZ of relevant channel.
- User can control the PTZ up, up left, down, right down, left, left down, right, right up or stop turning; turning speed(ranging from "1-39"), zoom, focus, and iris of PTZ can be adjusted. Select the code of preset point.
- Setup of preset point: choose the channel to set the preset point.
- Cruise line, click cruise setup to add or delete cruise.

CH1	Settings
CH2	Settings
CH3	Settings
CH4	Settings
CH5	Settings
CH6	Settings
CH7	Settings
CH8	Settings

viii.  Volume adjusts: open volume adjust control bar.


ix.  Manual record settings: open/close manual record.

x.  Video query: open video query interface, and view the video.

Right click any position on the screen, and shut off the task bar, and operating system.


3. GUI MENU OPERATION

Click “START” to enter the login interface, insert the Device ID, the default Device ID is “0”. The initial user name is: admin with no password, but if you setup a password during the setup wizard, you now need to input your password here.



Operation of menu

Enter the menu: the icon will be highlighted when the cursor moves onto the icon, click to enter.



- I.  BASIC: Open the basic menu, and 5 functions show in interface: system setup, time/date setup, record setup, display setup and user configuration
- II.  ADVANCE: Open the advance menu, you can: setup the alarm, network settings, Internet application settings, and PTZ configuration.
- III.  SEARCH: Search the video recorded.


- IV.  **DISK:** Display the HDD state and format the HDD.
- V.  **INFORMATION:** Display of the current configuration parameter, you can check: system information, network information, user information and video settings information.
- VI.  **MAINTENANCE:** Firmware can be upgraded; the frequency and schedule of upgrading can be setup.
- VII.  **LOGOUT:** Locks the front panel button, and user name and password need to be input while re-login.

3.1 BASIC

After enter the menu, move the cursor to “BASIC”, and the icon will be highlighted, click to enter.

3.1.1 System setup

To setup of device name, device ID, video format, VGA resolution, language, logout time and startup wizard.




- **Device name:** It is for the change of the device name, click the input box and keyboard will pop-up, and click the keyboard to edit the device name.
- **Device ID:** It is for the change of device ID, click the input box and keyboard will be pop-up, and click the keyboard to edit the device name.
- Select “PAL” or “NTSC” from the drop-down box.
- **VGA resolution:** Adjust according to the VGA used. Select “1024×768” or “1280×1024” from the drop-down box.
- **Language:** Select the language from the drop-down box.
- **Logout time:** Select between 30 seconds, 1 minute, 3 minutes, 5 minutes, 10 minutes to Never.
- **Startup wizard:** Select “Off” or “On” from the drop-down box.

Note: After setup is completed, click “Apply” to save the setup, and click “Default” to

recover to default settings, and click “Exit” to the return.

3.1.2 DATE/TIME


Date/Time setup



- **Date/time:** Click the calendar beside the date setup box, and select the date; Click the time setup box and click to input.
- **Date format:** Select “MM/DD/YYYY”、 “YYYY-MM-DD”、 “DD/MM/YYYY” from the drop-down box.
- **Time format:** Select “24-Hour” or “12-Hour” from the drop-down box.
- **Time zone:** Select from the time zone from the drop-down box.
- **Synchronization:** Network proof function. Mark while connecting to the web and select the proof sever from the drop-down box.
- **Time sever:** Select the proof sever among multi sever address from the drop-down box.

Note: After setting is completed, click “Apply” to finish setting, and click “Default” to recover to default settings, and click “Exit” to the return.

DST setup




- **Enable:** Mark enables the use of the DST setup.
- **Mode:** Select “Week” or “Date” from the box.
- **Offset:** time period ahead or delayed, Select “One hour” or “Two hours” from the box.
- **Start time:** It can be set according to the DST


Note: Click “Apply” to save the new setting. Click “Default”, to cancel the new setting. Click “Exit” to go back to the previous menu.

3.1.3 DISPLAY

Display



- **CH:** Order of the DVR channel
- **CH Name:** Click to modify the CH name.
- **Mask:** Click “setting” and select one CH. Drag the mouse to locate the mark area. 4 Mask areas are Maximum. Double click to cancel the mark. Click “Apply” to save. Click “Default” to cancel.



- **Color:** Click “Setting” and select one CH. Brightness Contrast Hue Saturation can be modified. Click “Apply” to save.

CH 1 ▼

BRI 26

CON 23

HUE 31

SAT 23

Default
Apply

CH 1 ▼

Time overlay ☒

Name overlay ☒

Default
Apply

- **Overlay:** Click “Setting “and select one CH. Select “Time overlay “and “Name overlay”. Click “Default” to cancel.
- **Copy CH:** Copy one CH setting to another CH.

Auto Sequence

In auto sequence mode, the display automatically switches between stencil 1x1, stencil 2x2, stencil 3x3 to custom viewing mode every dwell time(0~300).

Basic

SYSTEM

DATE/TIME

DISPLAY

RECORD

USER

Display
Auto sequence

Auto sequence
Stencil 1 x 1

	Sequence	Mode	CH	Dwell
✕ +	1			
✕ +	2			
✕ +	3			
✕ +	4			
✕ +	5			
✕ +	6			

Copy
Stencil 1 x 1
To custom
Copy

Default
Apply
Exit

3.1.4 RECORD

Basic setting




- **CH:** Order of the DVR channel
- **Enable:** click to enable the basic setting
- **Audio:** click to enable audio recording
- **Mode:** Click “Always” or “Time recording” to make the DVR record when start up or recording according to the set schedule.
- **Copy CH:** Copy one CH setting to another CH.

Bit rate



- **CH:** Order of the DVR channel
- **Resolution:** Click “CIF” “HD1” “D1” to set the recording resolution.
- **Frame rate:** “1-25”fps is for option.
- **Quality:** “Best” “Better” “Good” “Normal” for option
- **Copy CH:** Copy one CH setting to another CH.

Schedule



- **CH:** Order of the DVR channel
- Set the mode of recording."Manual" "Normal" "Alarm"
- Double click the recording schedule; the "schedule" window will pop up. You can set the recording schedule here.


Mon.

Add
Delete
OK

	Start time	End time	Type
☐	00:00:00	23:59:59	Normal

- **Copy CH:** Copy one CH setting to another CH.

3.1.5 USER



- **Create User:** Create a new User and configure authority

Basic information: fill in the User name, Password, Retype password, User type, Binding Client MAC, MAC.

Basic

User name	
Password	
Retype password	
User type	Normal
Binding client MAC	☐
MAC	00:11:00:33:44:55

Apply

Exit

- **Authority:** Select the Authority for this user.

Authority

Basic ☒			
☒ System	☒ Date/Time	☒ Display	☒ Record
Advanced ☒			
☒ Alarm	☒ Network	☒ COMM	☒ P.T.Z
Playback ☒			
☒ CH1	☒ CH2	☒ CH3	☒ CH4

Clear

All

Apply

Exit


3.2 ADVANCE

Click “Advance setting” on the master menu


3.2.1 ALARM

Motion

Alarm will be in triggered when there is movement in the detecting area



- **CH:** Order of the DVR channel
- **Enable:** Click to enable the basic setting.
- **Sensitivity:** “1-8”for options.
- **Area:** Set the area for motion detection
Red: Area in red indicates there is moving object in the detecting area
Green: Area in green indicates there is no moving object in the detecting area
Grey: Area in grey indicates this is not the detecting area
- **Schedule:** click the alarm button to enable the alarm. Drag your mouse to set your alarm plan. Red area is the time with alarm. Gray is the time without alarm. Click “Apply” to save. Click “Default” to cancel. Click “Exit” back to the superior menu.




Record	☐ 1 ☐ 2 ☐ 3 ☐ 4 ☐ 5 ☐ 6 ☐ 7 ☐ 8
	☐ 9 ☐ 10 ☐ 11 ☐ 12 ☐ 13 ☐ 14 ☐ 15 ☐ 16
Snapshot	☐ 1 ☐ 2 ☐ 3 ☐ 4 ☐ 5 ☐ 6 ☐ 7 ☐ 8
	☐ 9 ☐ 10 ☐ 11 ☐ 12 ☐ 13 ☐ 14 ☐ 15 ☐ 16
Send E-MALL	☐
Alarm output	☐
Alarm output duration	10s
Buzzer	None
Pop-up screen	None


Copy: For ease, setup one channel and then copy to the others.

- **Trigger:** The processing for alarming, click “settings” display as below:
 - i. Trigger recording: Place a check mark '√' for the channel you need to trigger, when there is alarm on the setting channel, will trigger to other channels.
 - ii. Snapshot: Place a check mark '√' in front the channel, when the setting channel has alarm, will snap a picture.
 - iii. Send E-mail: Place a check mark '√', when there is alarm, will send the snapped picture to the mailbox you set.
 - iv. Alarm output: Place a check mark '√', will trigger the external alarm.
 - v. Alarm output duration: Click the inverted triangle, options: 10s/ 30s/ 1min/ 3 min/ 5min/ 10min/ 15min/ 30min.
 - vi. Buzzer: Click the inverted triangle, options: None/10s/ 30s/ 1min/ 3 min/ 5min/ 10min/ 15min/ 30min.
 - vii. Pop-out image: Click the inverted triangle, options: None/ CH1/ CH2...
 - viii. Post-record: Click the inverted triangle, options: 10s/ 30s/ 1min/ 3 min/ 5min/ 10min/ 15min/ 30min.
 - ix. Pre-record: Click the inverted triangle, options: None/ 5s/ 10s
 - x. Trigger PTZ: None/ Cruise line/ Preset point
 - xi. Attention: Click “Apply” after setup.

Sensor alarm: High/Low voltage abnormal alarm.



- **ID:** Sensor ID.
- **Enable:** Place a check mark '✓'
- **Type:** N.O (Normal open) & N.C (Normal close) 2 options.
- **Name:** Input your own name for the sensor.
- **Schedule:** From Monday to Sunday, 0:00 to 24:00, setup alarm for time periods (time period cannot cross a day), double click on the time to enter the time period setup.
None: black color (back ground color), **Alarm:** red color.
Copy: For ease, setup one channel and then copy to the others.




- **Trigger:** The processing for alarming, click "settings" display as below:

Record	☐ 1 ☐ 2 ☐ 3 ☐ 4 ☐ 5 ☐ 6 ☐ 7 ☐ 8
	☐ 9 ☐ 10 ☐ 11 ☐ 12 ☐ 13 ☐ 14 ☐ 15 ☐ 16
Snapshot	☐ 1 ☐ 2 ☐ 3 ☐ 4 ☐ 5 ☐ 6 ☐ 7 ☐ 8
	☐ 9 ☐ 10 ☐ 11 ☐ 12 ☐ 13 ☐ 14 ☐ 15 ☐ 16
Send E-MALL	☐
Alarm output	☐
Alarm output duration	10s
Buzzer	None
Pop-up screen	None

- i. Trigger recording: Place a check mark '√' for the channel you need to trigger, when there is alarm on the setting channel, will trigger to other channels.
- ii. Snapshot: Place a check mark '√' in front the channel, when the setting channel has alarm, will snap a picture.
- iii. Send E-mail: Place a check mark '√', when there is alarm, will send the snapped picture to the mailbox you set.
- iv. Alarm output: Place a check mark '√', will trigger the external alarm.
- v. Alarm output duration: Click the inverted triangle, options: 10s/ 30s/ 1min/ 3 min/ 5min/ 10min/ 15min/ 30min.
- vi. Buzzer: Click the inverted triangle, options: None/10s/ 30s/ 1min/ 3 min/ 5min/ 10min/ 15min/ 30min.
- vii. Pop-out image: Click the inverted triangle, options: None/ CH1/ CH2...
- viii. Post-record: Click the inverted triangle, options: 10s/ 30s/ 1min/ 3 min/ 5min/ 10min/ 15min/ 30min.
- ix. Pre-record: Click the inverted triangle, options: None/ 5s/ 10s
- x. Trigger PTZ: None/ Cruise line/ Preset point
- xi. Attention: Click "Apply" after setup.

Video Loss: Alarm when there is video loss.




- **CH:** DVR channels.
- **Trigger:** The processing for alarming, click “settings” display as below:

Record	☐ 1 ☐ 2 ☐ 3 ☐ 4 ☐ 5 ☐ 6 ☐ 7 ☐ 8
	☐ 9 ☐ 10 ☐ 11 ☐ 12 ☐ 13 ☐ 14 ☐ 15 ☐ 16
Snapshot	☐ 1 ☐ 2 ☐ 3 ☐ 4 ☐ 5 ☐ 6 ☐ 7 ☐ 8
	☐ 9 ☐ 10 ☐ 11 ☐ 12 ☐ 13 ☐ 14 ☐ 15 ☐ 16
Send E-MALL	☐
Alarm output	☐
Alarm output duration	10s
Buzzer	None
Pop-up screen	None


- Trigger recording: Place a check mark '√' for the channel you need to trigger, when there is alarm on the setting channel, will trigger to other channels.
- Snapshot: Place a check mark '√' in front the channel, when the setting channel has alarm, will snap a picture.
- Send E-mail: Place a check mark '√', when there is alarm, will send the snapped picture to the mailbox you set.
- Alarm output: Place a check mark '√', will trigger the external alarm.
- Alarm output duration: Click the inverted triangle, options: 10s/ 30s/ 1min/ 3 min/ 5min/ 10min/ 15min/ 30min.
- Buzzer: Click the inverted triangle, options: None/10s/ 30s/ 1min/ 3 min/ 5min/ 10min/ 15min/ 30min.
- Pop-out image: Click the inverted triangle, options: None/ CH1/ CH2...
- Post-record: Click the inverted triangle, options: 10s/ 30s/ 1min/ 3 min/ 5min/ 10min/ 15min/ 30min.

- ix. Pre-record: Click the inverted triangle, options: None/ 5s/ 10s
- x. Trigger PTZ: None/ Cruise line/ Preset point
- xi. Attention: Click “Apply” after setup.

Camera block: Alarm when the camera was covered.



- **CH:** DVR channels.
- **Enable:** Place a check mark '✓'
- **Sensitivity:** Click the inverted triangle, 3 different level sensitivity: 1,2,3.
- **Schedule:** From Monday to Sunday, 0:00 to 24:00, setup alarm for time periods (time period cannot cross a day), double click on the time to enter the time period setup.



None: black color (back ground color), **Alarm:** red color.

Copy: For ease, setup one channel and then copy to the others.

- **Trigger:** The processing for alarming, click “settings” display as below:

Record	☐ 1 ☐ 2 ☐ 3 ☐ 4 ☐ 5 ☐ 6 ☐ 7 ☐ 8
	☐ 9 ☐ 10 ☐ 11 ☐ 12 ☐ 13 ☐ 14 ☐ 15 ☐ 16
Snapshot	☐ 1 ☐ 2 ☐ 3 ☐ 4 ☐ 5 ☐ 6 ☐ 7 ☐ 8
	☐ 9 ☐ 10 ☐ 11 ☐ 12 ☐ 13 ☐ 14 ☐ 15 ☐ 16
Send E-MALL	☐
Alarm output	☐
Alarm output duration	10s
Buzzer	None
Pop-up screen	None

- i. Trigger recording: Place a check mark '√' for the channel you need to trigger, when there is alarm on the setting channel, will trigger to other channels.
- ii. Snapshot: Place a check mark '√' in front the channel, when the setting channel has alarm, will snap a picture.
- iii. Send E-mail: Place a check mark '√', when there is alarm, will send the snapped picture to the mailbox you set.
- iv. Alarm output: Place a check mark '√', will trigger the external alarm.
- v. Alarm output duration: Click the inverted triangle, options: 10s/ 30s/ 1min/ 3 min/ 5min/ 10min/ 15min/ 30min.
- vi. Buzzer: Click the inverted triangle, options: None/10s/ 30s/ 1min/ 3 min/ 5min/ 10min/ 15min/ 30min.
- vii. Pop-out image: Click the inverted triangle, options: None/ CH1/ CH2...
- viii. Post-record: Click the inverted triangle, options: 10s/ 30s/ 1min/ 3 min/ 5min/ 10min/ 15min/ 30min.
- ix. Pre-record: Click the inverted triangle, options: None/ 5s/ 10s
- x. Trigger PTZ: None/ Cruise line/ Preset point
- xi. Attention: Click "Apply" after setup.

Others: HDD Invalid/HDD full/ IP conflict alarm settings.

The screenshot shows the 'Advance' window with the 'Others' tab selected. The settings are as follows:

Setting	Status	Action
Disk error	Enable	Settings
Disk full	Enable	Settings
Trigger		Settings
IP address conflict	Disable	Settings
Trigger		Settings

Buttons at the bottom: Default, Apply, Exit.

- **HDD invalid:** “Enable/Disable” 2 options, setup according to the user needs.
- **HDD full:** “Enable/Disable” 2 options, setup according to the user needs.
- **Trigger:** Choose the channels need to be triggered
- **IP address conflict:** “Enable/Disable” 2 options, setup according to the user needs.
- **Trigger:** The processing for alarming, click “settings” display as below:

Record	☐ 1 ☐ 2 ☐ 3 ☐ 4 ☐ 5 ☐ 6 ☐ 7 ☐ 8
	☐ 9 ☐ 10 ☐ 11 ☐ 12 ☐ 13 ☐ 14 ☐ 15 ☐ 16
Snapshot	☐ 1 ☐ 2 ☐ 3 ☐ 4 ☐ 5 ☐ 6 ☐ 7 ☐ 8
	☐ 9 ☐ 10 ☐ 11 ☐ 12 ☐ 13 ☐ 14 ☐ 15 ☐ 16
Send E-MALL	☐
Alarm output	☐
Alarm output duration	10s
Buzzer	None
Pop-up screen	None


- Trigger record: Place a check mark '√' for the channel you need to trigger, when there is alarm on the setting channel, will trigger to other channels.
- Snapshot: Place a check mark '√' in front the channel, when the setting channel has alarm, will snap a picture.
- Send E-mail: Place a check mark '√', when there is alarm, will send the snapped picture to the mailbox you set.
- Alarm output: Place a check mark '√', will trigger the external alarm.
- Alarm output duration: Click the inverted triangle, options: 10s/ 30s/ 1min/ 3 min/ 5min/ 10min/ 15min/ 30min.
- Buzzer: Click the inverted triangle, options: None/10s/ 30s/ 1min/ 3 min/ 5min/ 10min/ 15min/ 30min.
- Pop-out image: Click the inverted triangle, options: None/ CH1/ CH2...
- Post-record: Click the inverted triangle, options: 10s/ 30s/ 1min/ 3 min/ 5min/ 10min/ 15min/ 30min.
- Pre-record: Click the inverted triangle, options: None/ 5s/ 10s
- Trigger PTZ: None/ Cruise line/ Preset point
- Attention: Click “Apply” after setup.

3.2.2 NETWORK

LAN


- Obtain an IP address automatically
- Use the following IP address:
IP address: Fill in the IP address according to your network settings.
Subnet mask: Fill in the subnet mask according to your network settings.
Default gateway: Fill in the default gateway according to your network settings.
If there is no router in your network, fill in the IP you get from your Internet Service Provider (ISP). If there is a router in your network, make sure you have set the subnet

mask correctly.



- Obtain DNS server address automatically
- Use the following DNS sever addresses:
Preferred DNS server: fill in the DNS you get from your Internet Service Provider (ISP).
Alternate DNS server: fill in the DNS you get from your Internet Service Provider (ISP).
Attention: Click “Apply” after setup.

PPPoE



- **PPPoE:** Enable the PPPoE
- Fill the user name and password of your PPPOE which is provided by your Internet Service Provider (ISP). The system will restart after clicking OK. If the user name and password are correct, the system will connect to the network via the PPPOE. And the IP address will be filled automatically. **Note: Click “Apply” after setup.**

3G

Advance

LAN PPPoE **3G** Port Sub-stream

3G switch Disable

APN

User name

Password

Access number

Default Apply Exit

Port

Advance

LAN PPPoE 3G **Port** Sub-stream

Media port

Web port

Default Apply Exit


- **Media Port:** one private communication port that is between the DVR and PC, the default is Port: 9000. If this port is occupied by another server port, please change to an idle port.
- **Web Port:** Http port, default is Port: 85, if a change of the web port is required, like to example Port: 8088, the user will need to add the new port after the IP address when accessing the DVR via the web.

E.g.: <http://192.168.x.x:8088>

Note: Port Range: 1-65535, some ISP's may block port "80", so we recommend changing to another, example Port: 8086.

Attention: Click "Apply" after setup.

Sub-stream




All the setup here is for network transfer.

- **CH:** All DVR channels.
 - **Enable:** Place a check mark '✓' which means use sub-stream for network transfer.
 - **Resolution:** QCIF/CIF
 - **Frame rate:** PAL system: 1 to 25; NTSC system: 1 to 30.
 - **Quality:** Normal/Good/Better/Best
- Copy:** For ease, setup one channel and then copy to the others.
Attention: Click “Apply” after setup.

3.2.3 COMM


DDNS



- **DDNS:** Enable/Disable, please enable the DDNS when you use domain name server.
- **Server:** Choose your domain name server: REELINK, dyndns, no-ip, changip or dnsexit.
- **Host name:** The host name you registered on the domain name server.
- **User name:** The user name you registered on the domain name server.
- **Password:** The password you registered on the domain name server.
- **Test:** After setup, click “Test” to check connected or not.

Attention: Click “Apply” after setup.

E-MAIL



- **E-MAIL:** Enable/ Disable
- **Sending interval:** Immediately/ 30s/ 1 min/ 3min/ 5 min/ 10 min.
- **Mail server (SMTP):** Put your email server address.
- **Port:** Default is 25, if not, contact with your email server provider.
- **Connection security:** None or SSL/TLS.
- **User name:** Input the sender’s email address.
- **Password:** Input the sender’s email password.
- **To:** Input the email address you want to receive the alarm snap pictures.
- **CC:** Input the email address you want to copy to, at most could cc to 4 email address.
- **Test:** Click “Test”, system will send a test email to the receiver.


Attention: Click “Apply” after setup.

UPnP


Enable/Disable UPnP

Enable the UPnP when you need the DVR connect to Internet.

Attention: Click “Apply” after setup.



3.2.4 P.T.Z



- **CH:** All DVR channels.
 - **Enable:** Place a check mark '√' when one channel connects to PTZ.
 - **Protocol:** Pelco-D/Pelco-P/ Panasonic/Sony/Samsung/ Philips...etc.
 - **Baud rate:** 1200/ 2400/ 4800/ 9600
 - **Address:** Input the address you get from PTZ parameters.
- Copy: For ease, setup one channel and then copy to the others.
Attention: Click “Apply” after setup.

3.3 SEARCH

In main menu, click “Search”, display as below.




The left side shows the calendar, the right side displays the playback time zone. Green color means normal recording, red color means alarm recording, and black color (back ground color) means no recording. On the time line, there is a time bar that you can drag to any time you want to playback.

After entering playback interface, DVR will automatically search current day's (today) recording files and show in the right window. If there is no recording, the right window would be empty.

- **Calendar:** green & red date background means there is recording that day, gray background means there is no recording that day, blue back ground shows the date you have selected.

Note: When you open the playback interface, the calendar displays the current month, and the blue background date is the current date (today).

- **Record Type:** All/Alarm/Normal
- **CH:** Choose the channel you want to playback.
- **First, Prev., Next, Last:** Check the recording page by page.
- **Lock/unlock:** Place a check mark '✓' for the recording you want to lock, then click lock, after locked, the recording cannot delete and overwrite.
If want to unlock, just click "Unlock".
- **Backup:** check '✓' the recording files that you want to backup on the right window, and then click backup. If the files capacity you select is larger than your USB capacity, the system will prompt you to change to a bigger capacity USB or reduce the quantity of selected recording files.
- **Search:** click "SEARCH", and the right window will display the recording files.
- **Playback:** click "PLAYBACK" to enter into playback interface.



Control buttons:


- Click “PLAY/STOP”, “STEP”, “FAST FORWARD”, “FAST BACKWARD” and “SLOW” to do corresponding operation.
- Drag the slider to adjust volume, if you don’t need audio, click the speaker to mute.
- Clicks “X” to exit playback interface.

3.4 DISK MANAGEMENT

Click “HDD” in the main menu.

3.4.1 HDD

Display HDD ID, Status, Capacity Total/Free and format information




- **Format:** Place a check mark '√' under format, and then click “Format”.
Note: The newly installed HDD must be formatted through our DVR before usage.
- **Overwrite:** There are three options to choose from; “by days”, “by capacity” and “never” .Please selects desired method.

Attention: Click “Apply” after setup.

Note: After the setting, click "Save". Click "Default" to the default setting.

3.4.2 USB Storage


Display USB storage status, Capacity Total/Free and format information



3.5 SYSTEM INFORMATION

After enter main menu, move cursor to INFORMATION and click it.

3.5.1 DEVICE INFORMATION



- **Device Name:** The name given to DVR
- **Device ID:** The ID of DVR
- **Serial NO:** Serial number of DVR
- **Firmware Version:** The firmware version of DVR
- **MAC:** MAC add of DVR

3.5.2 NETWORK

User can check all of information of LAN, PPPoE, 3G after connected DVR.

The screenshot shows the 'Information' window with the 'LAN' tab selected. The left sidebar contains 'DEVICE', 'NETWORK' (highlighted), 'ONLINE', and 'RECORD'. The main area displays a table of LAN configuration parameters.

LAN	
Network status	
IP address(LAN)	
Subnet mask	
Default gateway	
Preferred DNS server	
Alternate DNS server	
IP address conflict	
IP address(WAN)	
Media port	
Web port	

An 'Exit' button is located at the bottom right of the window.

The screenshot shows the 'Information' window with the 'pppoe' tab selected. The left sidebar is the same. The main area displays a table of PPPoE configuration parameters.

pppoe	
Network status	Disable
IP address	
Preferred DNS server	
Alternate DNS server	

An 'Exit' button is located at the bottom right of the window.


The screenshot shows the 'Information' window with the '3G' tab selected. The left sidebar is the same. The main area displays a table of 3G configuration parameters.

3G	
3G status	Unknown
Module status	Unknown
SIM card status	Unknown
Network status	Unknown
Signal	Unknown
IP address	Unknown

An 'Exit' button is located at the bottom right of the window.

3.5.3 ONLINE

Shows the online user name, IP add, log in time and connection statues



3.5.4 RECORD

Shows the Channel#, resolution, frame fate, quality and date per hour.



3.6 DEVICE MAINTENANCE


After enter main menu, move cursor to MAINTENANCE and click it.

3.6.1 BASIC


Upgrade the device firmware or Standby or Reboot the system; Set an auto maintenance time or frequency.

Auto Maintain: System auto maintenance


- Select "Never" in drop-down box, then the system won't start auto maintenance, but manually maintain is available.




- If choose “every month”, then the date will be shown in drop-box. Set the date and time to auto maintenance.



- If choose “Every week” in drop-down box, the seven days of a week shows behind it, then edit the time fix an auto maintenance time this week



- If you choose “Everyday” in drop-down box and fix the time, it will auto maintenance in that time every day.



FIRMWARE UPGRADE


- Copy the firmware to a blank USB drive.
- Insert USB drive to the USB port of DVR
- Enter DVR-MENU-ADVANCE-SYSTEM MAINTAINANCE
- Click SYSTEM UPGRADE. It will scan the USB Drive and start the upgrade. Don't pull out the USB drive during upgrading.

STANDBY: Click to standby

Reboot: Click to reboot.

Note: Click save to save the setting, click default back to default settings.

3.6.2 SETTINGS



Export settings: copy the device setting to a USB drive

Exporting

Export parameter successfully!

No

IMPORT settings: copy the system setting to this device

Exporting

Export parameter successfully!

No

Load factory default: contains system setting, display setting, device maintenance, alarm setting, network application, date and time, recording, User, network, and PTZ. Just click the one you want to load factory default and then apply it.


☒ System	☒ Date/Time
☒ Display	☒ Record
☒ Maintenance	☒ User
☒ Alarm	☒ Network
☒ App	☒ P.T.Z.

All Clear Apply Exit

NOTE: you can click the button ALL or CLEAR to select all the items above or clear it all.

3.7 LOGOUT

Enter main menu, move cursor to LOGOUT icon and then click it, the NOTE window pops out, if you are sure to logout just click YES, then the main menu locked, the password is needed if you want to enter it again.



4. NETWORK SETTING FOR REMOTE CONTROL

The following steps will guide you through the steps necessary to access your VISTA DVR remotely via internet. Before proceeding, please connect your DVR to your router and obtain a computer that is connected to the same router. And make sure that your computer can access internet. After properly port forwarding your router, you will be able to access your DVR through Internet Explorer and our client software.

4.1 Obtaining Your Network Settings

Open a command prompt on the computer


I. Windows Vista and 7 users

- Locate the Windows Icon in the bottom left corner of the task bar.
- In the Search box, type “cmd” or “command” to locate the command prompt.
- Following the available prompt, type “ipconfig” and press Enter.

II. Windows NT, 2000, and XP users

- Locate the Windows Icon in the bottom left corner of the task bar, click Run, type cmd or command and press enter.
- Following the available prompt, type “ipconfig” and press Enter.

This will bring up a display of your network settings. Make sure to write down the IP Address, Subnet Mask and Default Gateway. This will display the address of your router.



```
Administrator: C:\Windows\system32\CMD.exe

Wireless LAN adapter Wireless Network Connection 2:

    Media State . . . . . : Media disconnected
    Connection-specific DNS Suffix  . :

Ethernet adapter Local Area Connection:

    Connection-specific DNS Suffix  . : honeywell.com
    Link-local IPv6 Address . . . . . : fe80::31ba:c0bb:849d:e2bc%15
    IPv4 Address. . . . . : 199.63.134.33
    Subnet Mask . . . . . : 255.255.255.0
    Default Gateway . . . . . : 199.63.134.201

Wireless LAN adapter Wireless Network Connection:

    Media State . . . . . : Media disconnected
    Connection-specific DNS Suffix  . :

Tunnel adapter Local Area Connection* 9:

    Media State . . . . . : Media disconnected
    Connection-specific DNS Suffix  . :
```

III. Now check for an open address on the network, make sure to use an address that is in the same subnet.

(Example: if you're gateway is 199.63.134.33 you want to check for an address available like 199.63.134.34 or 199.63.134.35, and so forth.)

➤ Static IP Address:

You can check the address availability by performing the “Ping” operation. E.g., type “ping 199.63.134.62”.

- If there is a reply the address is already in use

```
C:\Users\se570243>ping 199.63.134.62

Pinging 199.63.134.62 with 32 bytes of data:
Reply from 199.63.134.62: bytes=32 time<1ms TTL=64
Reply from 199.63.134.62: bytes=32 time<1ms TTL=64
Reply from 199.63.134.62: bytes=32 time=1ms TTL=64
Reply from 199.63.134.62: bytes=32 time<1ms TTL=64

Ping statistics for 199.63.134.62:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 1ms, Average = 0ms
```

- If there is no reply (request timed out, destination host unreachable) the address is available for use.

```
C:\Users\se570243>ping 199.63.134.64

Pinging 199.63.134.64 with 32 bytes of data:
Reply from 199.63.134.33: Destination host unreachable.
Reply from 199.63.134.33: Destination host unreachable.
Reply from 199.63.134.33: Destination host unreachable.
Reply from 199.63.134.33: Destination host unreachable.

Ping statistics for 199.63.134.64:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
```

- You have found an available address in the same sub-net, you can assign this address (Static Address) to the DVR.
 - a) Enter the Network Configuration interface of the DVR.
 - b) Access Main Menu by right clicking on the monitor using a mouse and enter the password at the prompt.
 - c) Go to System Configuration >> Network Configuration.
 - Enter the available static address
 - Subnet Mask (255.255.255.0, etc.)
 - Enter Default Gateway address you made a note of earlier

➤ **Dynamic IP Address:**

You can enable the DHCP checkbox in the DVR Network Configuration interface.

- a) Enter the Network Configuration interface of the DVR.
- b) Access Main Menu by right clicking on the monitor using a mouse and enter the password at the prompt.
- c) Go to System Configuration >> Network Configuration.
 - Check the DHCP radio box, and click Save.
 - Reboot the system.
 - Return to the Network Configuration to check what the current IP address is. It will be listed under Current Configuration >> IP Address.


4.2 Confirm your DVR Connection

Open the Internet Explorer browser (Note that Internet Explorer (64-bit) is not currently supported), type the IP address of the DVR in the Internet Explorer address bar.


E.g.: IP: 199.63.134.62, Web port: 85

Users need to input `http://192.168.15.145:85` to access the DVR

- Internet Explorer will prompt you to install the ActiveX control.
- Click and install the ActiveX control.
- The user login interface will be displayed as shown:



User can select language, input correct user name and password to log in IE interface. After successful log in, the following interface will appear.



4.3 Port Forwarding Your Router

By default, web Port: 85, media port: 9000

- Enabling Ports to be forwarded to a device on your local network will give users remote access to the device from the internet. (Information for forwarding ports through many brands of routers can be found at <http://www.portforward.com> .

Although this site doesn't specifically show port forwarding for DVRs, it can still be useful.)

- Once you have accessed the router successfully, follow the steps to guide yourself to the port forwarding interface. Once in the interface forward the following ports: http port and client port.

By default, web port: 85, media port: 9000

- Every model of Router is different. A very helpful site is: <http://www.pcwintech.com/portforwarding-> guides or refers to your ISP providers and router manual.

***Helpful Tips:**


- If you are unable to access the default router address, use the "Default Gateway" address.
- A reboot and reset of the default router settings may be necessary.

4.4 Confirm your DVR Remote Connection

Open an Internet Explorer browser and proceed to the website:

<http://www.yougetsignal.com/tools/openports>, this tester will provide you your external IP address and a port's status.

- Enter '85' (or your web port) in the Port number field.
- Click on the Check button. If your port is forwarded successfully, your status will be shown as open.



- Repeat step 1 and 2 for port 8000 (or your client port).
- If both ports are forwarded properly, use the external IP address to connect remotely to your DVR from outside the network.
- To test this, have someone connect to the external IP address via Internet Explorer off site, your login information will be the same as the DVR once connected.

5. CMS: CA-DVR-CS10

5.1 Brief introduction

VISTA CA-DVR-CS10 features multiple functions like: monitor the devices management and remote control.

The system supports multiple sites, various devices. Users can watch the real time video, track the historic video, and operate the remote control and remote settings.

Typical application as follows





VISTA CA-DVR-CS10 armed with great expansibility and flexibility, it can manage DVR devices under a PC directly. And it can also complete the remote control and the surveillance of the large multi-sites, under the coordination with Management server, streaming media servers, and database. The user permissions and site settings are under the management of the server in a complex system and View client obtains the certificate from the server. When runs without server it gets the certificate from the local computer.

5.2 CA-DVR-CS10 Function

- Multi-level user permission management
- Multi-channel image simultaneous viewing, inspection, playback, capture
- Remote backup, parameters setup, recording control remotely, PTZ control remotely
- Sites management
- Image is clear and recording is stable

5.3 System running environment and installation


This system can run under WINXP/WIN7/VISTA, resolution requests 1024X768, DirectX need 8.1 higher. Double click “ViewClient.EXE” and then follow the instruction step by step.




5.4 Operation Guide

5.4.1 Firmware Login

After the installation of the firmware, enter the login interface. The initial user name is: admin, no password.



5.4.2 Introduction of the window




- 1- Area of listed device
- 2- Area of video
- 3- list of main function
- 4- Buttons of PTZ operation
- 5- Area of information

5.4.3 Add a device

Operation of groups

In order to facilitate the management of a large number of devices, you can put devices into different groups.

Add a group: Click the add button under the list of the devices, input the name of the device, and click OK. When a sub-group needs to be added, right-click the parent group to add a sub-group.



Delete a group: Select the group to be deleted, and click the delete button below the list area or right click the group to delete a group.

Edit a group: Select the group to be edited, and click the edit button below the list area or right click the group to edit a group.

Operation of device

After adding a group, device can be added. Add a device: right click the name of the group, select "Add a Device", and confirm.




5.4.4 Live video

Open video

Open the video by double clicking the device in the list or right click menu in the video window



Splitting windows, click different splitting windows buttons to split the windows into 3、4、6、9、10、16、36、64. Double click can maximum this window Splitting windows.



Splitting windows, click different splitting windows buttons to split the windows into 3、4、6、9、10、16、36、64. Double click can maximum this window Splitting windows.

Audio

Click the following buttons to switch on or off the audio



Switch on the Audio,




Switch off the Audio



5.4.5 Snapshot



Click to snapshot a picture. The picture will be saved in your PC and the following windows will be pop up




5.4.6 Channel Group




5.4.7 Patrol

After adding some channel groups and making your loop plan, select some of the added

channel groups and add it to the right table.




After selecting the loop plan in the list, click the  to start or stop the patrol.




5.5 ICON Function Explanation

Click the buttons on the right of the main interface for PTZ, playback, color adjustment.




Double click the device in the device list, search the video file, the date in red in the calendar shows there are video files of the day.



Double click the buttons in red in the calendar to playback the video of the day.




Introduction of the playback control buttons:




5.6 System Setup


Click the right side of the main interface button into the system setup window.




System: setup the login password and the path for captured images.



Record setup: Disk setup of local video record.



Permission Settings: Add a user and setup the permission.




Alarm Setting: Set alarm type

5.7 Remote Setup

Click the remote setup button on the right side of the main interface to enter the remote setup interface.

System setup: Show the device name, device ID, Serial No., firmware version and MAC information of the device.



Time settings: Setup the Date/Time, time zone choose synchronization sever and DST.

Time Settings

Date/Time: 05/07/2012 05:34:52

Modify System Time Sync. Time with PC

Date format: MM/DD/YYYY

Time format: 24-Hour

Time zone: (GMT) Dublin, Edinburgh, Lisbon, London

Synchronization: ☐

Time server: time.windows.com

Default Apply

Display settings: Setup the channel name, time/channel name overlay and Mask area.

Display Settings

CH: CH1

Time overlay: ☒

Channel name overlay: ☒

Name: CH1

Overlay: Settings

Mask: ☐

Mask setup: Settings

Copy CH: 1 To CH: All Copy

Default Apply

Record settings: Setup the channel resolution, frame rate, quality, record mode and record schedule.

Record Settings

CH: CH1

Enable: ☒

Audio: ☒

Resolution: CIF

Frame rate: 25

Quality: Good

Mode: Always

Schedule: Settings

Copy CH: 1 To CH: All Copy

Default Apply

User settings: Delete and add users

User

User name	User type	Binding Client MAC
admin	Normal	Unlimited

Online users

User name	IP address	Login time	Disconnect
-----------	------------	------------	------------

Alarm settings: Setup the alarm schedule and trigger.

Alarm Settings

☒ Motion
 ☐ Sensor
 ☐ Video loss
 ☐ Camera block
 ☐ Others

CH	CH1
Enable	☐
Sensitivity	6
Area	Settings
Schedule	Settings
Trigger	Settings
Copy CH 1	To CH All Copy

Alarm Settings

☒ Motion
 ☐ Sensor
 ☐ Video loss
 ☐ Camera block
 ☐ Others

CH	CH1
Enable	☐
Sensitivity	5
Area	Settings
Schedule	Settings
Trigger	Settings
Copy CH 1	To CH All Copy

Network setup: Setup Lan and ADSL, and port mapping

COMM: Choose the domain name server.

COMM

DDNS E-MAIL UPnP

DDNS ☒

Server REELINK

Default ☒

Test

Default Apply

System Manage: Disk management, P.T.Z settings and system maintenance.

System Manage

Disk management P.T.Z Maintenance

ID	Status	Capacity Total/Free	Format
1	Recording	320.0G / 218.0G	☐
2	No HDD	0G / 0G	☐

Overwrite by capacity

Format

Default Apply

5.8 Log

All types of operation show in log

Client

Log Type Operation Log Start Time 02-20-2012 00:00:00 Search

Operation Type All Operation End Time 02-20-2012 23:59:59 Export

Alarm Type	Info	User	Time
Login		Client	02-20-2012 14:54:49
Exit		Client	02-20-2012 14:51:18
Open Video	Channels: 4	58.60.231.218	02-20-2012 14:51:08
Open Video	Channels: 3	58.60.231.218	02-20-2012 14:51:07
Open Video	Channels: 2	58.60.231.218	02-20-2012 14:51:06
Open Video	Channels: 1	58.60.231.218	02-20-2012 14:51:06
Open Video	Channels: 4	192.168.1.234	02-20-2012 14:51:04
Open Video	Channels: 3	192.168.1.234	02-20-2012 14:51:03
Open Video	Channels: 2	192.168.1.234	02-20-2012 14:51:02
Open Video	Channels: 1	192.168.1.234	02-20-2012 14:51:01
Login		Client	02-20-2012 14:49:10
Exit		Client	02-20-2012 14:44:33
Open Video	Channels: 1	58.60.231.218	02-20-2012 14:44:11
Open Video	Channels: 4	58.60.231.218	02-20-2012 14:44:10
Open Video	Channels: 3	58.60.231.218	02-20-2012 14:44:09
Open Video	Channels: 2	58.60.231.218	02-20-2012 14:44:08
Open Video	Channels: 4	192.168.1.234	02-20-2012 14:44:05
Open Video	Channels: 3	192.168.1.234	02-20-2012 14:44:04
Open Video	Channels: 2	192.168.1.234	02-20-2012 14:44:04
Open Video	Channels: 1	192.168.1.234	02-20-2012 14:44:03
Login		Client	02-20-2012 14:43:57

6. DDNS REMOTE CONTROL

Honeywell VISTA provide www.reelink.net to our customer for free domain, Reelink is an Intelligent monitoring and management software that used for monitoring & management of the various device and remote images; it works as a server and solves the problems like network settings complicated and free domain instability.

Two parts are introduced here below: “DVR device-side” and “reelink.net”

6.1 DVR COMM Setup

Turn on the DVR, goes to MENU-> advance->network setting

- i. Set the DVR IP according to your local IP, turn on “UPNP” on both DVR and Router.
- ii. Enable REELINK in DDNS server.

The image shows two screenshots of the VISTA DVR's network configuration interface. The top screenshot is the 'COMM' (Communication) settings page, with the 'DDNS' tab selected. It shows options to enable DDNS, choose the server (set to REELINK), and enable the default DDNS service. The bottom screenshot is the 'APP' (Application) settings page, with the 'UPnP' tab selected, showing the UPnP service is enabled.


Please refer to Chapter 4 for connecting your DVR with internet, make sure your DVR access internet successfully before use log in DDNS server.

6.2 Domain REELINK.NET setup

6.2.1 Log in

Open web explore, input www.reelink.net enter the login window as below:

Single User and Advanced User




The image shows the Reelink login interface. It features a circular logo on the left and the title 'Reelink' at the top. Below the title, there are two login sections. The 'Single User' section has fields for 'Serial Num.' and 'Device Password', with a 'Login' button below. The 'Senior User' section has fields for 'User' (containing 'VISTA') and 'Password' (masked with dots), with a 'Login' button below. A 'Register' link is next to the 'User' field, and a 'Forget' link is next to the 'Password' field. At the bottom, it says 'This system support ie8 version above'.

Single user: Supports one DVR series No. Log in, insert DVR series No. and DVR password (with setup of password before)

Senior user: To manage more devices' users, insert user name and password to log in.


User Register: Please register before use log in first time. Follow the instruction and read the protocol carefully.

Note: Please fill the correct email address; this is the ONLY WAY to find your password.




The image shows the 'New User Registration' form. It has a title 'New User Registration' and a link 'Existing accounts, direct [login](#)'. The form contains several input fields: 'User', 'Password', 'Confirm Password', 'Name', 'Telephone', 'Email', and 'MSN'. Each of the first three fields has a red asterisk next to it. The 'Email' field has a red note next to it: '*(Forget the password will be back by mail)'. At the bottom, there is a 'Register' button and a checkbox labeled '88110.net User registration agreemen'.

Forget password: If you forgot the password, please click "forgot password" and enter your user name, then a link will be sent to your email address. Enter you email click this link and change your password.



6.2.2 Device Remote View

Here you can find GROUP and DEVICE, which all added in DEVICE MANAGEMENT. Double click the device to view remotely. Picture shows below:



CADVR-1008C Green: device on line, CADVR-1008C Gray: device off line

6.2.3 DEVICE MANAGEMENT

Group




- Adding group:** To add sub-group, select main-group, input the sub-group name and save.
- Modify group:** User can revise any sub-group except the center main-group. You can change the group which the sub-group belongs to and revise the name of sub-group

- iii. **Deleting sub-group:** User can delete any sub-group except the center main-group which cannot be deleted. If the group deleted has sub-groups, the sub-groups were deleted either.

Device


- i. Adding device in specific group, please refer to the following image



Select the group (the device belongs to), device name, serial Number of DVR, user name and password, clicks save. After saving, the information will be shown in the list

Change the value of device, the date information marked * is required to complete.

- ii. Delete, It contains the multiple data delete and single data delete
Multiple data delete: click the check box of the date, click delete
Single data delete: click to delete the single data.
- iii. Modification, Click to modify the statistics that you try to edit, device code, if leave blank means no modification.




6.2.4 USER MANAGEMENT ROLE

Role: It is so-called classification that means permission distribution; user under one specific role can only use the permission of this specific role. The roles here also mean inheritance, for example: A-> B, B-> C, thus, C can use B's permission, but cannot use all the permissions of A.


- Adding

Add role, then add page, confirm the name of role, and choose main role, tick the permission of this role(Group permission, means this role manages which groups 【the devices submit to the group】 ; Operation permission, means the permission of operation function), save to complete this role adding.




- **Modification**

Modify any roles, but the main role cannot be modified, modify permissions and role names, etc.



- **Delete**


Delete any roles, but main role cannot be deleted, if the main role is deleted, then the sub-role and the users under the sub-role will be deleted too.




USER

User: After the user login the system, authorities will be the authorities under the role.

- Add, Click add, and enter into the add page





Select the role, fill in the User and Password (the user and password is for the login the system), email is necessary and convenient for the pickup in case of password missing. Save and finish the adding of users. Red*: Indicate it is necessary.

- Delete, There are two types of delete, one is for the delete of multi data, the other is for the delete of single data.

Delete of multi data, select the box before the data, click delete, will delete multi data.

The screenshot shows the 'Device' tab selected. A red arrow points to the 'Delete' button in the top toolbar. Below the toolbar, a table lists devices. The first device is 'VISTA'. The second device is 'Operate' with serial number 'D18017C20018F50A9538' and device name 'CADVR-1008C'.

	Operate	Serial number	Device name
	Edit Delete	D18017C20018F50A9538	CADVR-1008C

Delete of single data, delete the bar of data.

The screenshot shows the VISTA interface. At the top, there are tabs: 'Video browsing', 'Device', 'User', 'Log queries', and 'Personal info.'. Below the tabs, there is a sidebar with a '+ Add', a green checkmark 'Edit', and a green square 'Delete'. The main area shows a table with columns: 'Operate', 'Serial number', and 'Device name'. A red arrow points to the 'Operate' column header. Below the header, there is a row with a checkbox, the text 'Edit Delete', the serial number 'D18017C20018F50A9538', and the device name 'CADVR-1008C'.

- Edit, revise the data through click Edit.



The screenshot shows the 'Operate' tab in the VISTA interface. A table lists devices with columns for 'Operate', 'Serial number', and 'Device name'. The first row contains the serial number 'D18017C20018F50A9538' and device name 'CADVR-1008C'. A red arrow points to the 'Edit Delete' link in the 'Operate' column of this row.

Operate	Serial number	Device name
Edit Delete	D18017C20018F50A9538	CADVR-1008C

6.2.5 LOG QUIRES

Search all the actions in the system that took by the user.

Select caste, User ect. Then click Search, a log will be listed in the below area.

6.2.6 PERSONAL INFORMATION

The name Telephone, Email address ect can be Modified. But caste, account and authority is not allowed to be modified. Click “Save” and a box will be pop up if modified successfully.

6.2.7 EDIT PASSWORD


Input the old password (the current password) and the new password. Input your new password again and make sure they are the same. Clicks “save”. If the old password is wrong, a error will be prompted

6.2.8 SYSTEM

The information of this app is shown here

Name	ViewClient
Size	7.87MB
Version	1.0.0.014
Date	2012-06-05 15:06:04
Download	

6.2.9 EXIT



7. CADVRView MOBILEPHONE REMOTE CONTROL

7.1 Function Description


CADVRView mobile phone remote surveillance firmware supports:

- Device live view, zoom image, flips the channel, switch of the screen anyway.
- PTZ control, zoom function.
- Local record, multi-screen capture, audio output.
- Add, edit and delete device information.
- Remote configuration of device parameter and account management.
- Wi-Fi or 3G network connection method.

7.2 Working Environment & Download

Apply to ios (iphone 4/ipad 4.3 or above version), Andriod and Blackberry system mobile phone. Clients use iPhone/iPad/Andriod/Blackberry mobile phone to access App Store, login App Store, and search CADVRView, click to install.

7.3 CADVRView Operation




After the installation of firmware, choose CADVRView to run the mobile surveillance firmware.




CADVRView interface provide 2 type login methods:

Normal



DDNS Server



Following description is introducing the operation of normal type access.

DDNS access, if user already registered and uploaded device in reelink.net, input same user name and password, device will automatically list in CADVRView. Please refer DVR user manual chapter 6: DDNS Remote Control for details.

7.3.1 Device Management


After Normal type login, the default device list is empty. The first operation is to add the device. After adding the device, operations of preview and configuration can be done. Edit and delete device is also allowed.

Add & Edit device



Click **Device**, Enter the interface of device management. Click the right upper corner "+" to add a device. Illustration of device adds up options:

Options	Illustration
Device name	Device name can be customized
IP address	The IP address of the device or device-binding domain.
Media port	The media port of the device, default is 9000
Web port	Data port code of the device, default is 80
User name	User name to login the device
Password	Password to login the device
Channels	Setup the number of channels
Sever IP	Temporarily not realized



After adding the device, return to device list interface. The newly add-up device will be shown in the list.

Click the device in the list and enter the preview interface, connect and open the device.

Click upper left "Edit", click the device name, enter the device information edit interface; Click "Delete" to delete the device.


Click upper left "Done" to return to device management interface.

7.3.2 Live View

After adding the device, live view of channels can be operated.




Click **LiveView**, Enter the live view interface(the default interface after login the firmware is the live view interface).



Descriptions of each button:

Button	Definition
	PTZ control button
	Record of all the channels
	Capture images of all the channels
	Stop live view of all the channels
	Audio of all the channels

After entering the live view interface, click upper right "Select", click and choose the device, live view the images. Click the liveview button to view all CHs of the device




Enlarge the live view CH:

- Double click the CH to full screen this CH. Double click again to go back to the 4 CH live view.
- Swipe 2 figures to full screen the CH or go back to 4CH live view
Right or left swipe jumps from one CH to the next CH when full screen

- PTZ



Click one CH and click  to enable the PTZ. Click the direction button to control the camera. Support swipe to zoom in or zoom out. (Before use this function, make sure your DVR connected with PTZ successfully.)





- Record, Capture, Switch on/off live view and audio

Click one CH and click  to enable the local record function. This button will be in green when recording. Click this button again to stop recording, button will change to gray.

Click one CH and click . The live view will be captured and a window will be popped up. Click "Save" to save this picture. Click "Cancel" to cancel this picture.


Click one CH and click  to switch on/off live view of this CH.

Click one CH and click  to switch on/off Audio of this CH.



7.3.3 Playback


This function can view and playback the saved recordings and snapshot pictures. Click Playback to go to the playback menu.



Description:

Item	Description
Remote Playback	Playback the recordings in the DVR remotely
Local Playback	Playback the recordings in the mobile phone
Picture Playback	View and playback the snapshot picture
Capture Playback	View and playback the capture picture

• Remote Playback




Click  to go to the Remote Playback menu. Click "Select" to select the remote device. Then the list of recordings will be created. Select the date then the list of recording of that date will be created. Double click the files in the list to playback.



• Local Playback



Click , enter local playback list. Drag the icon > to left to delete the files.




- **Event Playback**

If there is no event recording, then event playback list will be empty.

- **Capture Playback**




Click **Play image** to playback the image, Double click the image you want to enlarge, click the icon in left bottom corner to save image, click the icon in right corner delete image.



7.3.4 Settings




Click **Settings** enter setting interface, choose the device first, and then enter the settings like bellow.



7.3.5 More

More settings are lists here: System, about click  enter the interface.



7.3.6 About

Click About to check software version and published date.

MEMO: