

BLUSKY
Simple yet effective

USER MANUAL

BSC9000 SERIES
GSM/GPRS MODEMS

Energy Meters:
www.metermeter.net

Optical Probes:
www.opticalprobe.net

Converters and Modems:
www.convertermodem.net

Company Website:
www.bluskyelectronics.com

CONTENTS

1. About This Document.....	4	10. Notation LEDs.....	28
2. Safety Precautions	5	11. SMS	29
2.1. Usage of Modem in a Vehicle	5	12. Installation of Modem.....	30
2.2. Protection of Modem	6	12.1. Inserting SIM Card	30
3. Applied Terms and Abbreviations	7	12.2. Connecting External Antenna (Type SMA)	31
4. Usage of Device.....	8	12.3. Connecting Modem to An External Device	31
5. Principle of Operation.....	9	12.4. Connecting Power Supply	32
6. Structure of BSC9000 Series Modem.....	12	12.4.1. DC Power Supply.....	32
7. Software	14	12.4.2. AC Power Supply	32
7.1. Firmware.....	14	12.4.3. USB Power Supply - Configuration Mode.....	33
7.2. Management Software: Troll	14	12.5. Mounting the Modem	34
7.2.1. Troll Main Window and Functions	15	13. Troubleshooting.....	35
7.2.2. Troll: Connection with Modem.....	16	13.1. Power LED of Modem is not ON.....	35
7.2.3. Troll: Reading and Writing Configuration of Modem.....	18	13.2. GSM LED of Modem is not ON.....	35
7.2.4. Troll: Saving Configurations and Reading Saved Configurations.....	22	13.3. GPRS LED of Modem is not ON.....	35
7.2.5. Troll: Issues That Must be Considered Before Usage	22	13.4. Modem does not respond to Troll software	35
8. Communication Interfaces	24	14. Document Version	36
9. Digital Inputs/Outputs and Additional Power Output	26		



1. ABOUT THIS DOCU- MENT

This document includes details about installation and using of BLUSKY BSM9000 series GSM/GPRS modems. Aktif Enerji has rights to apply changes that are not described in this document to the system.

Our company indicates that performances of products and accessories depend on environmental conditions in usage area.

Complete or some of this document can not be used or publish without permission of Aktif Enerji.



- Modem propagates radio frequency (RF) signals. When modem is being used, Rules of usage and safety precautions about RF devices should be considered.

- Please, pay attention not to use this device in planes, hospitals, petrol stations or places that using of GSM devices is forbidden.

- Please be sure that modem does not do parasitic effects to nearby devices. For instance: cardiac pacemaker, medical equipments. Antenna of modem must be kept away from computers, office equipments, home applications etc.

- An external antenna should be connected to modem for proper operation. Please, use antenna which is approved to use with this modem, only. When you need to choose a new antenna, please contact with our company.

- Antenna must be far away from human body at least 26.6cm. Please do not put antenna in metal boxes.

2.1. Usage of Modem in a Vehicle

- In case of modem will be used in a vehicle, before finishing the installation, please control relevant laws and regulations of your country about usage GSM in vehicles.

- Please, get installation of modem done to qualified staff. Owing to possibility of occurring parasitic effects on your vehicle's electronics, please take authorized service of your vehicle advice.

2. SAFETY PRECAU- TIONS

- Modem should be connected to power supply system of your vehicle by using a fuse-protected terminal in your vehicle's fuse box.
- Please, be careful when modem gets power from battery of your vehicle. Battery may be discharged after a while.

2.2. Protection of Modem

- To be sure about correct usage, please install and switch on your modem carefully.
- Please do not use your modem in places which has high humidity and high temperature and do not expose your modem to hazardous chemicals, water or dust.
- Please do not try to modify or disassembly your modem. There is no any part that can be fixed by user. This process makes warranty void.
- Please do not drop, hit or shake your modem and do not use your modem in extremely shaky environments.
- Please do not pull cable of antenna or power, attach/remove connector by holding it.
- Please use your modem according to user's manual. Using modem unlike as described in this user manual will make warranty of your device void.



IP address	A special number that assigned to a device working on Internet
APN	“Access Point Name” – GPRS server name that provides data transmission
GSM	“Global System for Mobile Communications” – Voice, data and text message package transmission technology which is commonly used in cell phone
GPRS	“General Packet Radio Service”, technology which is applied for data package transmission in GSM networks
TCP	“Transmission Control Protocol” – A data transmission flow control which is applied between devices working in a network. Data is sent in packages. This protocol guarantees data transmission correctness.
Package Transmission	The transmission that data is not sent continuously, they are sent in pieces which are named as package.
SIM	“Subscriber Identity Module” – An Identity card, special for subscriber
SMS	“Short Message Service” – A service to send short text message.

3. APPLIED TERMS AND ABBRE- VIA- TIONS



4. USAGE OF DEVICE

BSC9000 series modems are multipurpose GSM/GPRS modems that make data transmission possible by using any network of an operator which works in 900/1800MHz or 850/900/1800/1900MHz bands. Modem is designed to work with any device that has RS-232 or RS-485 type serial interface.

Modem provides remote reading of electricity, water, gas meters and other measuring devices having serial port by GPRS.

On the side of GPRS network, connection is performed in TCP/IP protocols. On the side of device, connection is established with RS-232 and RS-485 type serial outputs.

BSC9000 series modems are also equipped with one digital input and one digital output. By using this features, BSC9000 series modems can get signals from a door detector, alarm unit or any device that has a digital output. Status of those signals can be reported as an SMS or they can be read remotely by using GSM/GPRS communication protocol or locally by using service connection.



BSC9000 series modems work as TCP server or client in GPRS Networks. IP address of modem is determined by used SIM card. Modem is started as a server or client device according to its configuration, automatically. When the modem is started, it controls SIM card, signal strength, and GSM network availability then it logs to APN by using previously configured login information. The relevant service is started by successful login to APN.

Modem has features to provide data flow diagnostics. If the signal strength is too low or the data cannot be transmitted for a certain period of time or there is a time period which is previously defined by the user to restart the modem, modem reinitiates the GPRS network connection and logs to APN again.

BSC9000 series modems work transparently. It makes communication possible independent from the connection's protocol with all transmission channels. Figure 1 shows all existing transmission channels.

The modem postpones the restart procedure if there is a data transmission and/or USB configuration cable is actively connected.

The data coming from GPRS network is buffered in internal memory and it is sent serially from a local transmission channel which is set previously by user. Similarly, data coming from serial channel is buffered in size of TCP packages in internal memory and sent to GPRS network.

5. PRIN- CIPLE OF OPE- RATION



NOTE





Figure 1.
Existing Transmission
Channels in BSC9000
series modems



The data coming from GPRS network is buffered in internal memory and it is sent serially from a local transmission channel which is set previously by user. Similarly, data coming from serial channel is buffered in size of TCP packages in internal memory and sent to GPRS network.

Since the BSC9000 series modems work transparently, it supports connections with IEC 62056-21, IEC1142, DLMS or other similar protocols.

Internal registers of BSC9000 series modems can be read by using free Troll software or BLUSKY ASCII AT command sets. It lets user to change GPRS connections and all other settings of modem. Please check item 7 for details on software.

It is obligatory to authenticate to the modem with a valid username and password in order to change or read settings. Also, five different IP address and Subnet Masks can be set as black list or white list filter to improve security. Terminal block of the modem can also be sealed and manipulations to terminal cover can be logged thus reliability of the modem is maximized.

BSC9000 series modems can also send information by using SMS beside using the serial interfaces. SMS messages can be sent according to any of events encountered below:

- Modem terminal cover is opened or closed
- Violation of white list or black list filter
- Authentication attempt by using wrong username or password
- A signal change is detected (ON or OFF) in digital input of modem
- GSM signal strength is below user defined threshold level

The digital input in BSC9000 series modems can be used to collect external alarm signals, to cumulate the pulses of other gas or water meters, to detect instantly door or cubicle openings or similar events. Also the digital output in modem lets user to control external alarms, motors or similar devices or to generate clock synchronization pulses. It is settable to give single pulse or continuous ON signal or continuous OFF signal.

6. STRUCTURE OF BSC9000 SERIES MODEM

BSC9000 series modems can be mounted on a 35mm DIN Rail directly or can be hung on a wall. All connections, SIM card slot and connection terminals are covered with a sealable terminal cover.

Design of modem provides easy connection, It is easy to reach all connection terminals and SIM card slot without demounting the modem by opening sealable terminal cover. Device has an SMA antenna connector for external antenna connection. Long antenna cables can be used where GSM signal strength is low to improve GSM signal strength.

Internal structure of BSC9000 series modems consists of the following blocks: power supply, transmission section that provides data transmission by using GSM/GPRS, RS-232 and RS-485 to communicate with a local device, inputs/outputs, USB input for local configuration and ARM Cortex-M3 processor unit that controls all processes in modem. Internal GSM/GPRS module works at 900/1800Mhz or 850/900/1800/1900Mhz.




Figure 2.
Front view of GSM/GPRS
Communication Module




Figure 3.
Back view of GSM/GPRS
Communication Module




Figure 4.
Connector Connection
view of GSM/GPRS
Communication Module

Power input of modem accepts voltages between 9-54 DC or 265V AC, 50-60Hz. It provides ease of use by working with different kind of power supplies according to user needs. Also, modem supplies 12 Volt DC Voltage output which is isolated from the system galvanically. This additional isolated voltage supply lets users to use digital inputs and outputs without need of any additional power supply to complete the input and/or output circuit.



7. SOFT- WARE

7.1. Firmware

There is special software in nonvolatile memory of Modem. This software is embedded on an army level stable operating system. Also the configuration information are saved in two different memory areas in modem for safety. This software executes all operational processes such as GSM/GPRS connections, data transmission with serial ports, showing operating status with LEDs and showing situations of inputs/outputs etc.

BSC9000 series modems executes all processes automatically once the power supply is connected without giving additional commands. Configuration status is controlled on every startup (disk check), if original configuration is defected, configuration is reconstructed from a backup and modem continues to work without any interruption. Device configuration is saved in a nonvolatile memory so that in case of restart or re-run of the device, all configurations remain unchanged.

7.2. Management Software: Troll

“Troll” software is used to display configuration and operation status of modem and to change all operational parameters of BSC9000 series modems. It runs on computers with Windows operating system and it is supplied with a modem free of charge. It provides executing service commands, monitoring operation status of device, reading and editing configurations, loading factory settings, restarting of device, updating firmware etc. Also, this program lets user to set all parameters of modem.

Troll can connect BSC9000 series modems by using USB service connection locally (Communication Parameters: 115200 Baud, 8N1(8 data bits, 1 stop bit, Parity None)) or remotely via GPRS connection by using TCP/IP protocol.

7.2.1. Troll Main Window and Functions

Install Troll software like any other Windows (it works on Win7, Win Vista, XP ... both in 64bit and 32bit systems) based software and run it. The window on Figure 5 will appear. Options on this screen is described below:

The screenshot shows the Troll software interface with several annotated parts:

- Serial, TCP selections:** Defines the connection channel that will be used to connect the modem. The interface shows radio buttons for 'Serial' and 'TCP'.
- Device manager:** Can be opened and devices with COM ports can be seen by using **See COM Ports**.
- COM Port:** Will be used for communication is chosen from **Connection COM Port**.
- Communication:** If Communication will be established over **TCP**, IP address and Port is entered here.
- Configuration Settings:** Group helps to set or read parameters of modem. It is possible to read or write settings on single page or all settings in software.
- Configurations:** Can be saved to a file or previously saved configurations can be opened by using this menu.
- Connect button:** Connection to modem is realized according to the given parameters by using **Connect** button.
- Settings tab pages:** Related settings are displayed in **Settings** tab pages. The interface shows tabs for System Information, Serial Port Settings, Network Settings, Security Settings, SMS Sending Settings, Input/Output Settings, and Process Log.
- Information Bar:** Gives information about current processes. The interface shows a status bar at the bottom indicating 'Connected to system'.

The main window displays the following information:

- System Information:**
 - Version: 2.0
 - Model: Blusky BSC9000 GPRS modem
 - Production Date: 12-05-09 20:13:42
 - IMEI: 861630001400230
 - Device Name: Z
 - Sim Pin Status: READY
 - Modem Status: SERVER LISTENING
 - Time remaining to start: 2m5s
- Signal Information:**
 - IP: 188.59.24.174
 - Port: 1111
 - Signal Strength: 70% (represented by a progress bar)
 - Buttons: Continuous Read


Figure 5

7.2.2. Troll: Connection with Modem

In Connection Details group, there are settings for starting a proper communication with the modem. Options of this menu are shown in Figure 6:



Figure 6



In order to start a communication with the modem, a few basic settings should be done in software.

- **Local Configuration with Serial Communication:** First of all, serial option should be checked. After USB cable is connected and modem usb driver is installed, proper COM port should be chosen. To choose proper COM port, please click on [See COM Ports](#) button and view loaded COM ports on your computer. Available COM ports can be seen under Ports (COM & LPT) title of Device Manager window as shown in Figure 7.

Please close the Device Manager window after being sure about COM port of the modem and select the related COM port from [Connection COM port](#) combo box.

- **Remote Configuration with TCP Communication:** First of all, TCP option should be checked. After that IP address and Port number of modem should be entered. IP address is determined by inserted SIM card and APN information thus before setting up the modem for the first usage, an IP address information cannot be achieved (IP info can also be get from GSM SIM card provider). Port number can be set independent from IP address in configuration. Default port number is 10001.




Figure 7

In order to be able to connect the modem remotely by using TCP/IP protocol, the modem must operate in server mode.

NOTE

7.2.3. Troll: Reading and Writing Configuration of Modem

Once the modem connection is established by using the relevant login information, configuration settings and identity information of modem can be read and settings that are permitted to change can be updated. In order to realize those operations buttons in Configuration Settings group can be used. Menu options are shown in figure 8:





Figure 8

With **Read** button all related information can be read. Read information are reported as tabs; **System Information Tab**



The basic information about the modem can be seen in this tab. Additionally, signal strength level can be monitored. Also the time of modem and name of modem can be set from this tab.

Serial Port Settings Tab

System Information | Serial Port Settings | Network Settings | Security Settings | SMS Sending Settings | Input/Output Settings | Process Log

RS232 Port Settings RS485 Port Settings

Baud Rate:

Data Bits:

Parity:

Stop Bits:

Flow Control:

Mode:

Baud Rate:

Data Bits:

Parity:

Stop Bits:

In this tab, active local port of the modem and communication parameters of this port can be set.

Network Settings Tab

System Information | Serial Port Settings | Network Settings | Security Settings | SMS Sending Settings | Input/Output Settings | Process Log

APN Name:

APN Username:

APN Password:

Sim Pin:

Operating Mode:

Server Port:

Reset Time Period:

Hours: Minutes:

PIN information of SIM card, APN settings, operation status of modem and restarting time of modem when there is no data transmission can be determined in this tab.


Security Settings Tab



The screenshot shows the 'Security Settings' tab of a modem configuration interface. At the top, there are several tabs: 'System Information', 'Serial Port Settings', 'Network Settings', 'Security Settings', 'SMS Sending Settings', 'Input/Output Settings', and 'Process Log'. The 'Security Settings' tab is active. It features three radio buttons: 'White List', 'Black List', and 'None'. The 'None' radio button is selected. Below the radio buttons, there are two columns of input fields. The left column is for the 'White List' and the right column is for the 'Black List'. Each column has two sub-columns: 'IP Address' and 'Network Mask'. Each sub-column has three rows of input fields.

White list or black list filter settings can be done in this tab. If black list is activated, devices that have IP address and Subnet Mask which is defined in blacklist are not allowed to establish connection with the modem. Also if white list is activated, only the devices having IP addresses and Subnet masks that are defined in While List are allowed to establish connection with the modem.


SMS Settings Tab



The screenshot shows the 'SMS Sending Settings' tab of a modem configuration interface. At the top, there are several tabs: 'System Information', 'Serial Port Settings', 'Network Settings', 'Security Settings', 'SMS Sending Settings', 'Input/Output Settings', and 'Process Log'. The 'SMS Sending Settings' tab is active. It contains two input fields: 'Tel Numbers' and 'Message center number:'. Below these are five checkboxes for different events: 'Send SMS when system restarted', 'Send SMS when white or black list is violated', 'Send SMS when wrong username or password is used to enter the system', 'Send SMS when input signal is detected or disappeared', and 'Send SMS when GSM signal strength is under threshold value'. A dropdown menu shows '-105dB'.

The modem can send reports to the predefined telephone number via SMS according to the predefined event occurrence during operation of the modem. User can get SMS from the modem when the selected event in this tab occurred during operation.

Input/Output Settings Tab



In this tab, digital inputs and outputs of modem can be controlled and related settings can be done.

Process Log Tab




In this tab, user can monitor the history of program usage and realized commands.

7.2.4. Troll: Saving Configurations and Reading Saved Configurations

Configurations can be saved into a file so that same configurations can be applied to multiple modems easier and faster and also used configurations can be archived. Current settings of modem can be saved in a file or previously saved configurations can be opened by options in Save/Open Configuration menu group. Menu options are shown in Figure 9:



Figure 9



7.2.5. Troll: Issues That Must be Considered Before Usage

- For the first connection, the user must use local serial connection method. If the network settings are done properly, the modem can get a valid IP and then it will be available to connect the modem remotely over GPRS by using the IP and port information that are also displayed in System Information tab. The modem cannot attach itself to GPRS channel and get a valid IP address unless valid APN login information is set in the modem. Please contact your SIM card supplier if you are not sure about your APN settings.

- APN name login info may be different according to SIM card operator that is used. User should know the APN name to provide proper connection. APN name can be learned from operator.

- There are two arrow under the Configuration Settings group buttons of Troll. User can reach extra functions for reading and writing configurations by clicking them.



Figure 10

- Modem can be restarted or factory settings can be restored by using the Admin Tools tab.
- SIM PIN code consists of maximum 4 digits. User should pay attention to enter code correctly. If the PIN is entered incorrectly, modem can detect it and blocks the initiation process until correct PIN entrance, thus also avoid blocking SIM card.
- Modem (restart) Reset Time Period should be between 5 and 240 (4 Hour) minutes. The modem reset procedure is postponed if USB local configuration is connected and active and/or there is data transmission.

8. COM- MUNI- CATION INTER- FACES


To use with external serial devices, BSC9000 series modems are equipped with RS-232 and RS-485 serial interfaces.

Modem enables connecting multiple devices. The number of devices to be connected is defined by standards of serial ports. RS-485 allows to connect up to 32 devices and RS-232 best connecting single device to the modem.

Single device or several addressable devices can be connected to BSC9000 series modems by using serial connections.


- RS-232 – asynchronous, bidirectional, five-wire (RTS and CTS are supported, they are not mandatory to connect if hardware flow control is not used) serial interface

DB9M Pin #	BSC9000 RS-232
1	NA
2	RXD (Data In)
3	TXD (Data Out)
4	NA
5	GND
6	NA
7	RTS (HW Flow Control Output)
8	CTS (HW Flow Control Input)
9	NA



- RS-485 – asynchronous, bidirectional, two-wire or four-wire interface in “half duplex” mode

BSC9000 RS485	Connection	Serial Device
RS-422 or 4-wire RS-485 Mode		
TX+	→ →	RX+
TX-	→ →	RX-
RX+	← ←	TX+
RX-	← ←	TX-
2-wire RS-485 Mode		
D+	← →	D+
D-	← →	D-



There are also LEDs which visualize the transmission of data over serial interfaces in front panel of modem. “TX” LED blinks when data is transmitted from the modem and “RX” LED blinks when the modem receives data.

9. DIGITAL INPUTS/ OUTPUTS AND ADDI- TIONAL POWER OUTPUT

BSC9000 series modems are equipped with digital input and outputs and additional power output to be used with those input and outputs. The digital input can be used to collect external alarm signals, to cumulate the pulses of other gas or water meters, to detect instantly door or cubicle openings or similar events. Also the digital output in modem lets user to control external alarms, motors or similar devices or to generate clock synchronization pulses.



Input: Optomofset: Works with 9 - 240 Volts AC/DC, 60mA

Output: Solid state relay: Works with 9 - 240 Volts AC/DC, 120mA


Power Output: 12VDC, max power 1W, galvanically isolated from the system

Both input and output do not have any polarity.

Sample input connections:



Sample output connections:



There are also LEDs which visualize the input and output contact states in front panel of modem. «Input» LED turns on when signal is detected in input circuit and «Output» LED turns on when output circuit is closed (set to ON (High) mode).



10. NOTA- TION LEDS

LEDs are located on front panel of modem and they give information about operation status. Following cases can be observed without connecting an external device to the modem;

- Power input is detected
- Correct login to SIM card (Modem is ready to use, GSM connection is ready)
- GPRS connection is established
- Data transmission to GPRS layer from serial input (data from modem)
- Data transmission to serial input from GPRS layer (data to modem)
- Input circuit is closed
- Output circuit is closed
- Signal strength of GSM (3 LEDs)

When the related state occurs, related LEDs turn on and when the state changes, related LEDs turn off. For signal strength, there are three LEDs;

- **1 led ON:** Signal strength $\leq -93\text{dbm}$ (%40)
- **2 led ON:** Signal strength $\leq -69\text{dbm}$ (%80)
- **3 led ON:** Signal strength $> -69\text{dbm}$ (%100)

Also there are 2 additional LEDs under the terminal cover in order to show:

- USB connection is ready to use
- USB connection is physically done



BSC9000 series modems lets user to get information from modem via SMS messages. User can get SMS messages about following events:

- Modem terminal cover is opened/closed
- Violation of white list or black list filter
- Authentication attempt by using wrong username or password
- A signal change is detected (ON or OFF) in digital input of modem
- GSM signal strength is below user defined threshold level

Settings such as message center number, in which event the message will be sent, telephone number which the message will be sent can be set by using Troll software or BLUSKY ASCII AT commands.

11. SMS



12. INSTAL- LATION OF MODEM

12.1. Inserting SIM Card

Please use a pencil or a paperclip to press eject button of SIM card holder. SIM cover will eject a little bit out. Then, pull out SIM cover completely.



NOTE

Do not try to pull up SIM card before pressing the eject button of SIM card holder. Do not forget to enter SIM PIN number into your modem, otherwise device cannot use the SIM card. (Modem is equipped with a safety system such that if the PIN number is not correct, modem blocks modem start routine and does not continue until new PIN is set).

Insert SIM card to its holder and be sure that it is inserted completely. Insert SIM connector to its slot again.

12.2. Connecting External Antenna (Type SMA)

Connect external antenna having SMA male connector to antenna input of your modem as shown in Figure 11. Please, make sure about connector is connected tightly and antenna has 50ohm impedance which is appropriate for GSM frequency.

Please use antennas designed for GSM devices. Inappropriate antennas will affect communication negatively and will damage your modem.




Figure 11

12.3. Connecting Modem to An External Device

Modem can be connected to any device that have RS-232 or RS-485 serial output.

In order to connect the modem to an RS-485 device via 2 or 4 wire connection setup, notations on modem terminal block must be used for physical connection and RS-485 output must be activated in modem with correct connection parameters.

In order to connect the modem to a RS-232 device, please use a standard DB9 Female connector with standard RS-232 connections and please set the active serial port of modem to RS-232 output with correct connection parameters.

The digital input and output connections and settings can also be done in same manner.


12.4. Connecting Power Supply

12.4.1. DC Power Supply

DC adapter should be connected to power connector as shown in Figure 12. Please, pay attention to specifications that are below about power supply.

Input Voltage Interval	9V – 56V
Max Current	2A

Modem will be switched on automatically and power LED will be turned on.



12.4.2. AC Power Supply

AC power cables should be connected to power connector as shown in Figure 13. Please, pay attention to specifications that are below about power supply.

Input Voltage Interval	85-265V AC, 50-60Hz
Max Current	2A

Modem will be switched on automatically and power LED will be turned on.




Figure 13

12.4.3. USB Power Supply - Configuration Mode

Modem can also be power by just connection the USB cable. In this case the GPRS connection layer will not be functional. This mode is supplied to make easy and fast configurations via just connecting USB cable.

Features related to GPRS module like reading signal strength, the IMEI number and the message center number will not be available in this mode.


NOTE

12.5. Mounting the Modem

To mount the modem, put it to DIN rail, lean the module with springs against the lower edge of DIN rail and lastly lift device up firmly and press towards to the rail. DIN rail apparatus is shown in Figure 14:



Figure 14





13.1. Power LED of Modem is not ON

Check if the modem is connected to power supply properly and output nominal values are covered.

13.2. GSM LED of Modem is not ON

Check if a valid SIM card is used and it is inserted properly.

Check if the SIM card is blocked or not.

Check if the SIM pin number is set properly or not.

13.3. GPRS LED of Modem is not ON

Check if the external antenna is connected properly.

Check if the GSM network signal is available enough where the modem is mounted.

Check if the APN parameters are entered correctly or not.

13.4. Modem does not respond to Troll software

Check if the USB cable is connected properly.

Check if the COM setting of software is done correctly and driver is installed.

Check if the USB cable is connected after the USB ready LEDs are ON.

13. TROU- BLE- SHOO- TING



14. DOCU- MENT VER- SION

Created: Mart 2012

Update: January 2013

Version: 2

Updates since last version

1. The changes with the new plastic mould and new PCB functionalities has been added



For Questions, comments and suggestions, please contact us.