

Welcome to use Our Injection Molding Machine Control System

Safety Cautions

(Please read it before installation)



Danger

1. In order to ensure the secure operation of the whole system in case of the abnormal external power and the control system's failing to function, please set up the external safe circuit for the control system.
2. Upon its failure to detect the abnormal conditions of input and output, the control system cannot control the output. Therefore, please design the external circuit and framework to ensure the safe operation of the system.



Cautions

1. Please read this User's Guidance carefully before installation.
2. Do not dismantle the host computer shell and keyboard without permission.
3. In case of any questions, please dial the after-service service hotline of PORCHESON.



Note

1. With the constant upgrading and improvement of the system, the changes in the relevant information and technical parameters will not be informed in advance.
2. If there is deficiency in this manual, please do not hesitate to give your comments and suggestions.

Statement

Please read the manual carefully before you use this system. PORCHESON Company will only be responsible for the maintenance of the problems exist in the system itself, and will not be responsible for the fault caused by improper operation, unauthorized maintenance, natural disasters, or the system damage or data loss caused by other abnormal situations. The changes in the manual will not be informed in advance. The contents in the manual are for reference, the company will not be responsible.

for the losses caused by the misunderstanding of the manual. There may be differences between the actual objects and the abstract image, but the functions are Consistent.

According to the Copyright Law, the Company owns and retains the exclusive ownership of all works, without the written approval of the Company, any deletion, revision, reproduction or imitation of the manual are not permitted.

PORCHESON TECHNOLOGY CO., LTD

TB118

Operator's Manual

**System Configuration &
Installation** 1

**Button Operation
specification** 5

**Explanation of the Param
eter/Function Setting** 12

Production management 35

**Explanation of the System
Debugging and Setting** 41

**Input/output State
Detection** 55

Reference & Appendices 63

2009.07 Version

All copyrights are reserved, any duplication without the prior authorization shall be forbidden.

Contents

Chapter 1 System Configuration & Installation

1. System Configuration & Remarks.....p6
2. Features of the PS860AM Control System..... p6
3. Installation and Debugging of Computer Control System.....p7

Chapter 2 Specifications of the Button-Pressed Operations

1. Figure of Keyboard of the Operation Panel (See the figure below).....p10
2. Explanation of the Functional Keys..... p11
3. Explanation of the Parameter Setting button.....p12
4. Cursor Key.....p12
- 5.Operation Mode Selection Key..... p13
6. Electrothermal ON/OFF key and Motor ON/OFF key..... p13
7. Manual Operation Keys.....p14
8. Setting Scope of Numeric Items..... p16

Chapter 3: Descriptions on setting parameters/functions

1. The main control panel shown while turning on.....p17
- 2 Setting for celerity information.....P21
- 3 Setting for mould close information.....p22
4. Set mould opening information.....p23
5. Set the plastic injecting information.....p24
6. Set the pressure retaining information.....p25
7. Set plastic melting/drawing/cooling information.....p26
8. Set the stuff auto-clearing up information.....p27
9. Set the table information.....p28
10. Set the mould adjusting information.....p29
11. Set the ejecting forward information.....p30
12. Set loose core information.....p31
13. Set the air blow information.....p32
14. Set time/count information.....p33
15. Set temperature information.....p34
16. Set warm-up and chart of observation information.....p35
17. Set Module information..... P36
18. Amend note information..... P37
19. special parameter adjustmetn SettingP38

Chapter 4 production management

1. Set production Information	p40
2. SPC Track Note Page.....	p41
3. Pressure/Speed curve Setting Page.....	p42
4. Temperature Track curve Page.....	p43
5. Alarm note	p44
6. USB Setting Page.....	p45

Chapter 5 Instructions for the System Commissioning Settings

1. Engineer Setting Page.....	p46
2. Delay Setting Page.....	p47
3. Pressure/Flow Slope Setting Page.....	p48
4. Pressure Pre-Adjustment Page.....	p49
5. Flow Pre-Adjustment Page.....	p50
6. Back Pressure Pre-Adjustment Page	p51
7. Electronic Ruler/ Pressure Setting Inspection Page	p52
8. Special Function Options Page	p53
9. Standby Function Setting Page.....	p56
10. Programmable Standby Function Page.....	p57
11. Temperature Parameter	p58
12. Machine No./ Production-Factory Value Setting Page	p59

Chapter 6 Input/Output Mode Inspection

1. Input Inspection Page.....	p60
2. Key inspection Page	p62
3. Output Inspection Page.....	p63

Reference & Appendices

1. Tb118 keyboard installation dimension Layout	p66
2. Tc118 keyboard installation dimension Layout	p67
3. external dimensions and installation hole positions drawings for power supply case and transformer.....	p68
4. Exterior dimensions and installation hole position drawings for main controller	p68
5. system wiring drawing.....	p69
6. Motor heating wiring drawing.....	p70
7.Common Interference Suppression Method	p71

Chapter 1 System Configuration & Installation

1. System Configuration & Remarks

No.	Code	Content	Q'ty	Remarks
1 Host Computer	PS660AM	24 / 24+9 + 3Electronic Ruler	1 Set	Optional
	PS860AM	27 / 28+10+3Electronic Ruler	1 Set	
2 Keyboard	TB118(colour)	" 800*480 16:9 7 inch/TFT	1 Set	Optional
	TC118(Colour)	" 800*480 16:9 7 inch/TFT	1 Set	
3.Power pack	PW600B	600W	1 Set	
4.Message cable	DB- 15F	1 To 8 meter optional	1 Set	


2. Characteristics of PS860AM Control System

- ▶ The whole computer may control all functions and temperatures.
- ▶ The system has bright LCD display and 800*480 7inch? concolorous/colorful (optional)
- ▶ The system adopts two CPU design with fast operating speed, precise control and high stability.
- ▶ The control host computer adopts the blocking design with time-saving installation and rapid maintenance.
- ▶ It has the real time function to display time and date in real time.
- ▶ With 999 groups of mode data storage, it may enter the model description and real-time operating help in Chinese and English.
- ▶ The cipher setting and data locking can prevent the operators from changing the established data arbitrarily to influence the quality of products.
- ▶ There are multiple languages for your choice that display dynamically in real time.
- ▶ Packing modulus setting function for 6-digit output may set the packing modulus.
- ▶ Various self-plugging and tein type programs are applicable for the self-plugging and tein control in different types.
- ▶ Ejector nozzle temperature can be controlled with open or enclosed loop.
- ▶ PID (Proportional Integral Derivative) with self temperature control has (6+1) sections of temperatures.
- ▶ Temperature may be preset a week in advance to enable more convenient operation.
- ▶ Various types of Glue Shot ways, 4 sections of Glue Shot and class-3 pressure preservation
- ▶ Failure Self-detection functions, alarm display and voice prompt
- ▶ Input and output are done by the optically coupled circuit to isolate the interference of the external circuitry.
- ▶ The output value of pressure, speed, current can have real-time dynamic observation, and it is not necessary to install another ammeter
- ▶ In the inspection window, you can inspect all input and output points and the moving states of key.
- ▶ 3-circuit standard D/A proportion output with max. current as 3A
- ▶ Presetting of the voltage and runoff values, proportional valve available for the products in all brands and better linear proportion.

3. Installation and Debugging of Computer Control System

3.1 Cautions upon Installing the Control System

The design of control system is simple and easy, only one 15-core shielding cable connecting the keyboard and host computer shell with flexible and handy installation and connection. The sketch map for installation is shown as follows:



control box equipment outfit (for reference only)

- (1) Upon installing the host control box, adopt the enclosed distribution cabinet at the first choice. It shall be fixed in the well-ventilated, greaseproof and dustproof conditions equipped with a fan and dustproof. The distribution box shall be stored under 50°.
- (2) Upon fixing the host computer and power pack, please keep the interconnecting parts such as all AC connectors and transformers as far away from each other as possible to prevent the electric wave interference from the electronic grid.
- (3) All electric wires and shielding wires shall not be cut off, lengthened or curtailed arbitrarily. You should use the electric wires and shielding wires provided by this company to prevent from influencing the reliability and normal operation of the control system.
- (4) The shell of flame couple shall adopt the shielding wire. When the outer shielding of all flame couples adopts the thermal couple reticles, the reticle and machines shall be well grounded and connected to the ground with the earthing resistance below 10Ω.
- (5) Upon wiring, separate the high and low pressure line from the computer control line as much as possible, do not bind all electrical wires together to prevent the interference from affecting the reliable operation of control system.
- (6) Upon fixing the keyboard and 15-core communication connections of the host computer, you shall press and tweak with force to prevent the poor connection from affecting the reliable operation of control system.
- (7) Pay special attention to the oil valve outlet public port YCOM, it shall be connected well to prevent the computer from inputting while having the phenomenon of oil valve having no motion.

3. 2 Inspection of the Control System

- (1) After installation completed, carry out an overall inspection if all connection lines are well fixed including the switching power supply, host computer shell, electrothermal output line and the thermal couple of keyboard, etc.
- (2) After the line inspection completed, carry out an electric connection inspection. First take out the 11-digital output line plug of the DC power supply outlet port, namely the power pack, and then power on to examine and measure if the voltage is the same as the nominal values and observe if the output indicator on the power pack is normal.
- (3) Power off after the measurement completed, insert the DC power supply to input to the plug of host computer shell. After power-on again for inspection, LCD on the keyboard will display the normal state of the main page. Revolve on the emergency stop switch to check if the RUN indicator on the host computer shell turns on. When it turns on, it indicates that the system can work soundly.

3. 3 Setting of the Control System

- (1) After the system having shown normal operating state, press  button on the monitor page to adjust color and comparison.


- (2) To conduct the parameter setting and memory testing, press  button to select a group of


module numbers and then set data in all screens. Press  button to save data. Disconnect

the power and connect it again after a few time, the system will automatically call the data of module numbers saved by you. In case of they are correct, it indicates that the memory is all right.

- (3) Afterwards, set the data in all relevant data (please see Chapter III Explanation of the Parameter Setting for the detailed operations). Upon setting in the first time, set the pressure and speed as little as possible and then after all movements come normally, gradually increase the values to normal parameters to prevent from damaging the mechanical performances.
- (4) After all parameter set, save them and carefully inspect if all input and output points are normal. Carry out an overall inspection of the alarm system, including the front and back safety doors. The wire of safety doors shall be connected as stated in the following figure.



Safety Door 1 (PS860AM)





Safety Door Wiring Diagram (for reference only)

Safety Door 2 (PS860AM)



Safety Door Wiring Diagram (for reference only)

★ Safety Doors * Special Explanation: (PS860AM)

When X00=ON/X15=OFF or X00=OFF/X15=ON closing/opening the doors, or in case of other abnormal conditions, the system will issue an alarm 2 seconds later for Safety Door Failure and simultaneously terminate all operating output. In the semi-automatic mode, the condition for opening/closing the safety doors is that the time from LS1, LS2, LS3, LS4 all turn [OFF] to all turn [ON] is more than 0.5 as valid in order to prevent the twitter of safety door switches from causing error operation.

Chapter 2 Explanation of the Key Operations

1. Figure of Keyboard on the Operation Panel (See the figure below)



2. Explanation of the Functional Keys

Keys	Usage
	Enter into the screen to set the mold opening & locking movement
	Enter into the screen to set the Glue Shot and pressure-preserving movement
	Enter into the screen to set the feeding, glue taking and automatic material removal movement
	Enter into the screen to set the nozzle and model adjustment
	Enter into the screen to set ejector, self-plugging and huff.
	Enter into the screen to set timing and counting.
	Enter into the screen to set temperature and pre-heating.
	Enter into the screen to set the changes to mold and production facilities.
	Enter into setting celerity one 、 two setting page
	Return to the monitor screen in any time.
	The on-line help screen upon entering into the current state.

Keys	Usage
 PC LINK	Enter into the screen to set USB
 DIAGNOSE	Enter into the screen to set alarm
 CURVE	Enter into the screen to Speed and Temperature Track curve
 FLOW CHART	Enter into the screen to Setting production Information and SPC Track Note

3. Explanation of the Parameter Setting



0-9 numeric keys are used for data input in the data setting screen. When the electric lock is in “OFF” state, these ten numbers are locked to ensure the data will not be changed arbitrarily. In the meanwhile, there are 26 English letters and special symbols respectively on 0-1 numeric keys used for the input of Chinese and English letters as well as the machine serial number. [DELETE] key is used to delete the error words during entering the parameters and serial numbers. [INPUT] key is used to select the functions during function selection and used to confirm during item confirmation.

4. Cursor Key

Keys	Usage
	Skip key, pressing it will skip the cursor to the upper line
	Escape key, pressing it will move the cursor to the left
	Escape key, pressing it will move the cursor to the right
	Skip key, pressing it will skip the cursor to the lower line

5.Operation Mode Selection Key

Keys	Usage	Remarks
	Pressing this key will enter the system into manual state.	There is an indicator on the left upper of all keys. Pressing any key will turn on this indicator, indicating the system is in this state. Every time the computer is started, the default state of system is manual operation. In case of the temperature has not reached the set value, the system is impossible to perform semi-automatic 、senr-automatic and time automatic operations. The indicator will not turn on when the semi-automatic 、senr-automatic and time automatic operation key pressed till the temperature reaches the set value.
	Pressing this key will enter the system into semi-automatic operation	
	Pressing this key will enter the system into senr-automatic operation	
	Pressing this key will enter the system into time-automatic operation	

6. Electrothermal ON/OFF key

and Motor ON/OFF key

In the manual mode, press the key once and the indicator at the left upper will turn on, indicating the function state has opened. Pressing the key again and this indicator will turn off, indicating the function state has shut off. Repeatedly pressing this key, the functions will turn on or off in turn. Upon the emergency switch stops, the motor will power off swiftly without affecting the electro thermal operation.

7. Manual Operation Keys

Keys	Usage	Operation Conditions
	Model-opening operations	1. The model has not opened to the termination position.
	Mold-locking operating	1. Normal safety door input; 2. Ejector retracts till bumping; 3. Mold has not locked to the termination position; 4. The signals (mold-locking) of robot hands have been connected when the robot hands are selected.
	Glue Shot Operation1	1. In case of time glue shot selected, the injection time has not completed; 2. In case of the position selected, it has not reached the glue-shot termination position; 3. Temperatures within all sections of material canister shall not exceed the leeway scope (without temperature alarm)
	Decompression	1. When the electronic ruler is off duty, the time for launching back is inadequate; 2. When the electronic ruler is on duty, the position for launching out is inadequate; 3. The actual temperature of the reel has to be in the setup scope (no temperature alarm) and the time for cold start of the screw is adequate;
	Ejection advance operation1	1. Mode opening has come to the terminate position; 2. The neutron withdrawal limit has been connected and the time for withdrawal of neutron is adequate; (when select neutron) 3. Mechanical hand signals (tray mode) has been connected (when select mechanical hand); 4. When the electronic ruler is on duty, the position of tray mode has not reached the terminal position; 5. When the electronic ruler is off duty, ① choose the trip: has not reached the stop position. ② choose the time: the time calculation of tray mode is not adequate;
	Liftoff operation	1. When the electronic ruler is on duty, the position of tray mode has not reached the terminal position; 2. When the electronic ruler is off duty, ① choose the trip: has not reached the stop position. ② choose the time: the time calculation of tray mode is not adequate;

Keys	Usage	Operation Conditions
	Feeding Operation	1. Feeding has not come to the termination position; 2. Temperatures within all sections of material canister shall not exceed the leeway scope (without temperature alarm)
	Automatic Material Removal Operation	1. Selection and use of automatic material removal; 2. Times of automatic material removal not completed; 3. Temperatures within all sections of material canister shall not exceed the leeway scope (without temperature alarm)
	Several Items Operation	1. The operating conditions are the same as those for ejection advance and liftoff; 2. The time of ejector setting has not completed.
	Lubricating Pump Work	1. Lubricate total time have no end
	Male Mold Huff Operation	1. Selection and usage of male mold huff; 2. The time of male mold huff has not completed.
	Female Mold Huff Operation	1. Selection and usage of female mold huff; 2. The time of female mold huff has not completed
	Nozzle advance operation	1. When the block limit selection is off duty, there is no conditions; 2. When the block limit selection is on duty, ① the lock mode stops ON. ② Has not reached the block stop position; b. the time calculation of the block is not enough;
	Nozzle backward operation	1. No condition;
	Mold-adjusting Selection	1. If transfers mode by hand, press this button in the manual state, the indication light will be on, that means you can transfer mode by hand; 2. If automatically transfers mode, press the button twice in the manual state, and the indication light will be on, that means you can conduct automatic transfer of mode;
	Mold-Adjusting Backward Operation	1. Enter the state of manual mode transfer; 2. The mold-adjusting retract has not come to the termination position.

Keys	Usage	Operation Conditions
	Mold-Adjusting Forward Operation	1.To select the mold-adjusting use state; 2.The mold-adjusting advance has not come to the termination position.
	Chip-insertion Operation A	1.Selection and usage of Self-plugging A; 2.Chip-insertion A has not come to the termination position or the time has not completed; 3.Liftoff has reaches its position or the liftoff time has come.
	Chip-Extraction Operation A	1.Selection and usage of Self-plugging A; 2.Chip-insertion A has not come to the termination position or the time has not completed; 3.Liftoff has reaches its position or the liftoff time has come.
	Chip-insertion Operation B	1.Selection and usage of Self-plugging B; 2.Chip-insertion B has not come to the termination position or the time has not completed; 3.Liftoff has reaches its position or the liftoff time has come.
	Chip-Extraction Operation B	1.Selection and usage of Self-plugging B; 2.Chip-insertion B has not come to the termination position or the time has not completed; 3.Liftoff has reaches its position or the liftoff time has come.

8. Setting Scope of Numeric Items

Number	Setting Items	Setting Scope	Unit
1	Time Setting	Digital ≤ 600.00	Second
2	Pressure Setting	Digital ≤ 160.0	Bar
3	Speed Setting	Digital ≤ 99.9	%
4	Back Pressure	Digital ≤ 160.0	Bar
5	Temperature Setting	Digital ≤ 999.9 (Measure) Digital ≤ 600.0 (set)	°C
6	Storage of Mold Data	Digital ≤ 999	Number
7	Predicted Turnout	Digital ≤ 99999999	PC

In case of the set values exceed the above-mentioned scopes, the system will not accept the numbers set and keep the original set values. For the habit of data input, the data input of this system is display from right to left.

Chapter 3: Descriptions on setting parameters/functions


1. The Main Control panel while turning on

Connect with power, turn the red urgent stop switches, the operation light of the computer-RUN -flickers, the following menu shown on the display, now the control system is running and it is ready to operate the machine.



Press  key at any time after re-turning on the computer, and then enter the menu of the monitor menu of the machine. This menu is for monitoring temperature and machine running condition. The names and numbers of the moulds will be set in mould information menu. The temperature scale and current oil temperature show the real value of each stage thus its information cannot be modified. Each function of the menus is described as follows:

The descriptions on mode:

Mode	Meanings
	Motor is running
	Electrical heating opened
	Lubricator is lubricating.
	The lubricator unsuccessful unchain

The descriptions on display:

Display	Meanings and descriptions
Manual	The running mode of the machine;
Injection Nozzle	This section is heating;
Mould number	The current mould number;
Movable mould	Shows the current position of the mould. The unit: mm;
Screw	Shows the current position of the screw. The unit: mm;
Thimble	Shows the current position of the thimble. The unit: mm;
Pressure	The set pressure value of the current movement;
Flux	The set flux value of the current movement;
Prepare mold number	The number of mold opening of the current mode of the predicted production;
Output	Record the numbers of mold opening for current mould number during the automatic operation of the system;
Set	The time value and counter data of the current movement;
Operation	When a time value set for current movement, only the operation time increase to the set time, the next movement starts. When it is the number was set, the acted numbers will be shown on the display till the numbers reach the set counter date.;
Whole process	The real operation cycle time of the system;
In low temperature	When the actual temperature is not in the scope of setup scope, it will display the abnormal state of the current temperature in each area;
The Luo pole turns soon	The number of rotation of the screw in one minute (unit: RPM);

Descriptions on alarm mode

Alarm	Source	Solution
Exits unclosed	The mode locking stops and “xits unclosed” showed if you operate mode locking while exits unclosed;	Check if the switches of the front and rear exits are correctly connected with input interface of X00、X01 and X15、X16 and check if they can be pressed normally.
Open Exits	In “Semi auto” mode, the exits remain unopened while a single cycle ended;	Open the exits, take out the products, close exits and then continue the processing.
Failure of sensor inspection	In automatic operation, when the inspecting sensor is not “ON” after thimble withdrawing in sensor cycling mode and the mid-time is over, it warns “Failure of sensor inspection” ;	Remove the failure of Ejecting forward and Ejecting backward and judge if there are any long cover. The connection lines and the sensor itself should be mainly inspected when the light of X04 input point always shines.
Mould opening not fixed	When eject forward manually, the mould opening not reach the position of stopping mould opening;	Re-operate unlocking, or check position of lock opening. ① When the electronic ruler is on duty, check the number at the position. ② When the electronic ruler is off duty, check whether X12 is connected.
Clamping and open mould not fixed on time	Clamping and open mould not completed within “ the time limitation of the mould opening or closing” ;	Check the clamping and open mould process, extend properly “the time limitation of the mould opening or clamping” if it is normal.
Low pressure mould protecting time is over	It will warn if it has not turned into high pressure when the low-pressure time is over.	Check the mould, extend properly the low pressure time” if there is not any redundant objects.
Failure of Exit	Alarm when there is only one press in X00、X01 and X15、X16;	Check if the switches of the front and rear exits are correctly connected with input interface of X00、X01 and X15、X16 and check if they can be pressed normally.
Plastic melting not completed on time	Plastic melting not completed within “ the time limitation of plastic melting” ;	Check the plastic melting process and find out if the plastic in plastic drum has been run out. Extend properly “the time limitation of plastic melting” if it is normal.
Failure of plastic injection	The plastic injection testing stroke switches X20 has not been pressed or the electronic ruler has not reached the plastic injection testing point during plastic injection.	Check plastic injection process and adjust the deviation value of plastic injection testing
Failure of motor	Alarm when signal inputs motor protection point X16.	Check if there is a protection on the oil hydraulic motor caused by relay against overload.
Cycle time is over	When Auto production cycle time is longer than set [cycle time]	Check the auto production process, extend properly the set [cycle time] if it is normal.

Alarm	Source	Solution
Knockout core A not completed. Knockout core B not completed.	Machine has chosen knockout core A and B. It requires that the knockout space of the knockout core must have been connected when eject forward or multi-eject forward;	Check if the stop switches of the knockout core A and B are connected correctly and if they can be pressed normally. Set a stop mode in function menu for knockout core A and B when you do not use the knockout core function.
The set output reached	The machine stops when the output stopping machine function started or the numbers of mould opening have reached the set output number.	Solution: If you need the machine continues running after the output reached, just set the [stop after alarm] in production menu as [out]; or reset the total mould opening of the current mould number .

Descriptions on operation/prompt mode

Alarm	Source
High temperature in 1,2,3, 4,5, stages Injection nuzzle.	The real temperature related to the stage of the machine hopper is higher than the set top limited value. (Maximum temperature values = the setup temperature value + the setup maximum value).
Low temperature in 1,2,3, 4,5, stages Injection nuzzle.	The real temperature related to the stage of the machine hopper is lower than the set down limited value. (the set down limited value = the setup temperature value - the setup maximum value).
Temperature short circuit n 1,2,3, 4,5, stages Injection nuzzle	The real temperature related to the stage of the machine hopper is higher than the set top limited value.
Auto stuff clearing up completed	After the set number movement completed and while auto stuff clearing up.
Auto mould adjusting completed	Auto mould adjusting completed when using mould auto adjusting.
Auto mould adjusting not completed	Auto mould adjusting not completed when using mould auto adjusting.
Enter manual mode first	When operate manual keys in auto mode.
Functions not selected	Certain function has not been selected when manual operate its keys.
Start motor	How to select motor: Prompt when the semi-auto/auto keys are pressed, as the motor has not been started.
Next cycle Prepared	In auto mode, the mid-time between completing a cycle and starting next cycle.
Sensor prepared	The mid-time has not been reached after withdrawing thimbles during auto sensor cycling.
Exit mould adjusting mode first	When operate non-[adjust forward, backward and auto mould adjusting] keys in mould adjusting mode.
Enter mould adjusting mode first	When operate [adjust forward, backward and auto mould adjusting] keys in non-mould- adjusting mode.

2. Setting for celerity information



Press **CELERITY SET** key, enter the menu for setting celerity one information, now the menu is as following:

2009-06-09 【Fast Set1】 16:39:14

	Pres	Flux	Place	
SlwMldC	20.0	20.0	508.8	Slow. C. T(s) *****
FastMldL	50.0	80.0	109.0	Low. P. T(s) 50.00
LPreMldL	20.0	30.0	2.0	LMT. Time(s) 50.00
HPreMldL	120.6	25.0	*****	
SlwMldO	20.7	20.0	50.5	Slow. O. T(s) *****
FastMldO	40.0	80.0	215.5	LMT. Time(s) 50.00
MSPdMldO	60.0	70.0	550.8	Mach. Hand isabled
LSPdMldO	45.0	20.0	600.0	
EFastAdv	60.0	80.5	*****	Delay Time :jecNumber
ESlowAdv	55.0	20.0	*****	0.5 0.8 2
EKeep	50.0	10.0	*****	****
ERet	45.0	45.0	*****	1.0
				0.6

Hint: Set Range: 0~999



Press **CELERITY SET** key twice, enter the menu for setting celerity two information, now as following:

2009-06-09 【Fast Set2】 16:39:20


	Pres	Flux	Time	Place	
InjSeg1	125.9	95.0	*****	0.00	Total. T
InjSeg2	110.0	90.5	*****	5.00	50.00 (s)
InjSeg3	30.0	20.0	*****	20.00	Inj. Mode
InjSeg4	110.8	80.0	*****	70.00	Place
InjSeg5	20.0	40.0	*****	120.00	
KpLev4	20.0	20.0	1.00		
KpLev3	35.0	25.0	1.10		
KpLev2	50.0	35.0	2.59		
KpLev1	55.0	20.0	1.25		
F. Tk	30.0	25.0	****	20.00	B. Pres
Me11	120.0	85.0	****	150.00	15.2
Me12	80.0	20.0		220.00	20.2
B. Tk	50.0	43.0	****	250.00	****
					CoolTime
					30.00 (s)
					MeltLmt
					80.00 (s)

Hint: Set Range: 0.00~600.00


Quick setting 1 and 2 menus are parameters cluster menus common used by jet moulding machines. These two menus can provide important parameters needed daily adjustment by machines, including: mould clamping, mould open, injection, hold pressure, plasticization, ejector forward.

3. Set mould close information

Press **開鎖模** **M.PLT** key, enter the menu for setting mould close, now the menu is as following:




Descriptions on setting parameters/ process/function mode




- (1). Process: while mould close, enter slow clamping first, and then enter fast clamping when the stroke arrives at [508.8], and then enter low pressure clamping when stroke runs another [109.0], and then enter high pressure clamping when stroke runs another [2.0] till clamping completed. It alarms [low pressure mould protection time is over] when the low pressure time is over but not enter the high pressure yet
- (2). Slow mode locking: when the dynamic mode electronic ruler is [off duty], the time for slow lock of the mode.
- (3). Low pressure protection: Set a smaller low-pressure time for mould close, it is best to be fitting, otherwise, the mould can not be protected.
- (4). Time limitation to mold open and close: time limitation to mold open and close, please set it longer, and it is better to be fitting, otherwise, the system alarms [mold open/close not completed on time].
- (5). Differential mould close: press input keys to select [on] or [off], output when select [on] for quick mould close Y52, not output when select [off] for quick mould close Y52,

4. Set mouId opening information

Press  key twice, enter the menu for setting mould opening, now the menu is as following:



Descriptions on setting parameters/ process/function mode




- (1). Process: while mould opening, enter slow mould opening first, and than switches to quick mould opening when stroke arrives at 50.5mm, and than switches to middle speed mould opening when arrives at 215.5mm, and than switches to low speed mould opening when arrives at 550.8mm, and than mould opening completed when arrives at 600mm
- (2). Slow mode opening: when the dynamic mode electronic ruler is [on duty], the time for slow opening of the mode.
- (3). Time limitation to mould opening and clamping: time limitation to mould opening and clamping, please set it longer, and it is better to be fitting, otherwise, the system alarms [mould opening/clamping not completed on time].
- (4). The function of manipulator: if a manipulator needed, please select [on] for it. After [on] selected, the machine will output manipulator signal while mould opening comp leted. Before mould close, the next cycle starts only after receiving the manipulator signal, and stop the output of it at the same time.


5. Set the plastic injecting information



Press INJECTION key once, enter the menu for setting plastic injection, now the menu is as following:



Descriptions on setting parameters/ process/function mode




- (1). Process: while plastic injecting, 1 stage injects plastic first, and then switches to 2 stage when arrives at 220.0mm, and then switches to 3 stage when arrives at 150.9mm, and then switches to 4 stage when arrives at 98.5mm, and then switch to pressure retaining when arrives at 10.0mm
- (2). The whole process of plastic injecting; monitor the normal plastic injecting process. Equal time arrives when start plastic injecting ---start timing and switch to pressure retaining whatever the arrives the distance or not. Thus the injecting time should be set longer than real time.
- (3). Ejection models: ① when the screw electronic ruler is on duty, you can choose [position] or [time]. a. If you select [position], the ejection will be pressure keeping through the position of the electronic ruler; b. If you select [time], the ejection will be pressure keeping through time. ② when the screw electronic ruler is off duty, you can select [trip] or [time]. a. If you select [trip], the ejection will be pressure keeping through trip; b. If you select [time], the ejection will be pressure keeping through time.


6. Set the pressure retaining information

射出

Press **INJECTION** key twice, enter the menu for setting pressure retaining, now the menu is as following:



Descriptions on setting parameters/ process/function mode



- (1). Process: when enter pressure retaining after injecting, enter the 1st grade pressure of pressure retaining and speed movement first, and then [the 1st grade time is over] enters the 2nd grade of pressure retaining, and then enter the 3rd grade pressure retaining through [the 2nd grade pressure retaining is over], and then switches to plastic melting delay after [the 3rd grade pressure retaining is over]
- (2). How to use: it will be controlled as following when only 1st pressure retaining control is needed for molding condition: key the 1st pressure retaining time in the box of 1st grade time, pressure retaining 2nd time [0.00, it is 0 when (out)], pressure retaining 3rd time [0.00, it is 0 when (out)].
- (3). The function of slope: Controlling on pressure is for retaining pressure or change of slope. Refer to the set menu, the real output pressure is as the picture above right.
- (4). Ejection test: you can select [on duty] or [off duty], when you select on duty, in the mode of half/full automation, computer will get the average value 20-100 mode ejection ends as the ejection test point. Users can set up the permitted error value scope on the pressure keeping page. If surpass the setup mode number, and if it is under the test scope or over the test, you will hear the alarm [the ejection is failed], at the same time, the production management will regard it as the defect.

7. Set plastic melting/drawing/cooling information

儲料

Press **FEEDING** key once, enter the menu for setting plastic melting/drawing/cooling, now the menu is as following:

2009-06-09 【Melt/Take/CoolSet】 16:35:33

0.00 mm

Pres 0.0
Flux 0.0
BackPres 0.0


	F. Tk	Mel1	Mel2	B. Tk
Pres (bar)	30.0	120.0	80.0	50.0
B. Pres (ba	****	15.2	20.2	****
Flux (%)	25.0	85.0	20.0	43.0
Place (mm)	20.00	150.00	220.00	250.00

CoolTime 30.00 (s)
MeltLmt 80.00 (s)
FeedDela 1.0 (s)

Hint: Set Range: 0.0~999.9

Machine Run Well Ready

Descriptions on setting parameters/ process/function mode




- (1). Process: After retaining pressure, front drawing first, switches to melting 1 when arrives at 20.0mm, and then switches to melting 2 when arrives at 150.0mm, and then switches to back drawing when arrives at 220.0mm, and then plastic melting completed when arrives at 350.0mm.
- (2). Time limitation to plastic melting: the time for monitoring no-stuff. The uncompleted plastic melting will be taken as no-stuff when time is over. So set the time limitation longer than real plastic melting time, otherwise it alarms [plastic melting not completed on time].
- (3). Cooling time: In auto mode, cooling time stars just after plastic injecting pressure retaining. The time for plastic melting and drawing is a part of cooling time. When the process time is longer than cooling time, the cooling time is over. Mould can be opened only after plastic melting/drawing completed. Otherwise mould will be opened as soon as the cooling time is over.

8. Set the stuff auto-clearing up information

Press  key twice, enter the menu for setting stuff auto-clearing up, now the menu is as following:



Descriptions on setting parameters/ process/function mode



- (1). Process: How to use the stuff auto-clearing up function. In manual mode, press the key of stuff auto-clearing up, the system starts the stuff auto-clearing up process, first is the process of with drawing, and than cycles automatically according with process shown in the diagram above.
- (2). Times of stuff clearing up: the times of repeating plastic melting and injecting.
- (3). Automatic cleaning of materials: Select On Duty, press the [automatic clearing of materials] button to clear the materials.
- (4). Material restoring time: when it automatically operates, and after the block finishes, start to operate the storage materials, the time accounted returns the ejection movements.

9. Set the table information

座臺/調模

Press **NOZZ/ADJ.** key once, enter the menu for setting table, now the menu is as following:



Descriptions on setting parameters/ process/function mode

- (1). Block's slow motion: ① when the electronic ruler is off duty, the block will encounter the block stop switch [X06] and then will be inserted into the block slow motion and die combination. The time accounting stops when come to the block. ② when the electronic ruler is on duty, the speed of the block is controlled by electronic ruler. (Function: to prevent crash and to protect the service life of die.)
- (2). Auto table:[off], [plastic melting completed] or [cooling completed] can be selected. If [plastic melting completed] is selected, withdrawing after plastic melting completed in auto mode.
- (3). Block termination methods: ① When the electronic ruler is off duty, you can select [trip] or [time], if you select trip, the automatic block withdrawal will retreat to the back of the block and stop at the location of [X07] switch control; if you select time, the withdrawal of automatic block will be controlled by the setup time. ② when the electronic ruler is on duty, select [position] or [time], if you select position, the withdrawal of automatic block will be controlled by the position of the electronic ruler; if you select time, the withdrawal of automatic block will be controlled by the setup time. (Note: in the state of manual state, press [block back] button, the movement of block withdrawal will not be limited)

10. Set the mould adjusting information

Press  key twice, enter the menu for setting mould adjusting, now the menu is as following:




Descriptions on setting parameters/ process/function mode

- (1). How to adjust mould: [Manual] or [Auto] can be selected, the pressure for mould adjusting is about 20-50 bar, the speed is 30-60%.
- (3). Fine adjusting mode: [Time] or [gear number] can be selected. Select [time] if the machine is not mounted with sensor; the initial value is controlled by [time]; select [gear number] if there is a sensor, the initial value is controlled by [gear number].
- (3). The time of mould closing: In auto mould adjusting, time limitation for mould closing.
- (4). How to use auto mould adjusting: Select [auto] for mould adjusting, press the key of [mould adjusting] and [auto mould adjusting], and then enter the mode of auto mould adjusting as soon as the exit shut. The movement pressure and flux of adjusting forward and backward in the process of auto mould adjusting is controlled by a set value in the fine adjusting box. The sound of can be heard and [mould adjusting completed] shown after the mould adjusting completed.
- (5). While adjust mould manually or automatically, the forward time of mould adjusting is controlled by stop limit.

11. Set the ejecting forward information

Press  key once, enter the menu for setting ejector forward, now the menu is as following:



	EjcRe.	E. A. F.	E. A. S.	Keep
Pres (bar)	45.0	60.0	55.0	50.0
Flux (%)	45.0	80.5	20.0	10.0
Place (mm)	*****	*****	*****	*****
Delay (s)	0.6	0.5	****	****
Time (s)	****	0.8	****	1.0


Hint: 0. Times 1. Vibrating 2. Retaining

Descriptions on setting parameters/ process/function mode

- (1). Times fixed : [Ejecting forward] → [Ejecting backward stop] as a cycle, move in according to times.
- (2) Vibrating: [ejecting forward stop] → [ejecting forward stop, off] as a cycle, the movements are set in according to the times of the ejecting forward. The ejecting backward movement ends when times finished.
- (3) forward retaining: Used in semi-auto. Stops while ejecting forward movement reach its limits, and not ejecting backward until before closing mould in next cycle.
- (4). backward delaying: after ejecting forward and backward completed, the ejecting backward movement occurs while the set time delayed.
- (5). forward delaying: after mould opening completed, the ejecting forward movement occurs while the set time delayed.
- (6). Retaining function: if the retaining time is set as 00, there is no retaining function. The retaining function is for retaining pressure, speed and starting retaining time for the output after ejecting forward completed. The retaining movement is completed as soon as the time is over.
- (7) [Note]: A. when do manual mode holding, the number will no be limited. (if do manual repeated mode holding, the number will be limited) B. If you set the number of mode holding at 0, the function of mode holding can not be on duty.

12. Set loose core information

Press  key twice, enter the menu for setting loose core, now the menu is as following:



	AIn	AOut	BIn	BOut
Pres (bar)	60.0	65.0	40.0	35.0
Flux (%)	35.0	50.0	25.0	15.0
Time (s)	****	****	3.0	3.0
Count	***	***	***	***
StartLoc	L. M. F	O. M. F	L. M. F	O. M. F
StaPlace	*****	*****	*****	*****

CoreA Disable
Amod Way
CoreB Disable
Bmod Time

Hint: 0. Time 1. Way 2. Count

Machine Run Well Ready

Descriptions on setting parameters/function mode

- (1) Core starting: there are [stroke] and [position] for options. Choosing [stroke], then it will be controlled by stroke setting values; choosing [position] then it will be controlled by position setting values
- (2) The function of loose core A: [On] or [Off] can be selected.
- (3) The function of loose core B: [On] or [Off] can be selected.
- (4) Mode A: [Time], [stroke] and [count] can be selected. If [time] selected, set the time till the movement of loose core A terminated; if [stroke] selected, the movement of loose core will not terminate until the stop signal [X25, X26] of input point shows ON; if [count] selected, pipe thread control can be taken, and the movement termination is decided by the number of pipe tread pulse inputted through [X25, X26].
- (5) Mode B: [Time], [stroke] and [count] can be selected. If [time] selected, set the time till the movement of loose core B terminated; if [stroke] selected, the movement of loose core will not terminate until the stop signal [X30, X30] of input point shows ON; if [count] selected, pipe thread control can be taken, and the movement termination is decided by the number of pipe tread pulse inputted through [X30, X31].
- (6) Time/gear number: Time or gear number can be set in this box, when [time] is selected for loose core A and B, the set value in the box is time. When [count] is selected for loose core A and B, the set value in the box is gear number.
- (7) Start the trip: the neutron start the position of movement (neutron in: [before lock the mode], [before the low pressure], [before the high pressure] and [the lock mode stops]; neutron out: [before the mode opening] [before the middle speed], [before the low speed] and [the mode opening stops]), that is, where the template is moving, setup the action of neutron A and B.
- (8) Start position: The position for starting the movement of core knock in or knock out where the mould stops-- is a set value for the movement of core loose A and B.



13. Set the air blow information

Press  key thrice, enter the menu for setting air blow information, now the menu is as following:



Descriptions on setting parameters/function mode

- (1) Why blowing air: This function can be used in the stamping mould that need air blow.
- (2) Time delay: Delay first when arrives automatically at the position of air blow, and than blow air when delay time starts.
- (3) Start the trip: you can select[before the mode opening] or [after the mode opening] to set the value of blowing.
- (4) Starting position: [Pre-mould opening] can be selected. [Pre-mould opening] is taken as a set value for the movement of air blow.
- (5). Function mode: [On] or [Off] can be selected, no movement of air blow if [Off] is selected.



14. Set time/count information

Press  key thrice, enter the menu for setting time/count, now the menu is as following:



2009-06-09 【Time/CountSet】 16:36:22


Lubr. M. N	0	Middle. T	1.00
LubrTo. T	0.00	Act Li. t	99.00
Lubric. T	0.00	Fau. Warn	10.00
Lubr. Int.	0.00	Cycle. t	120.00

PC. ON. Time	0	H	0	M
Mato. ON. Time	0	H	0	M
Mato. RUN. Tim	0	H	0	M

Hint: Set Range: 0.00~600.00


Description on setting parameters

- (1). Lubricating modulus: Count mould opening times. The oil pump starts when mould opening times reach the set value.
- (2). Total time for Lubrication: the total time spent in this lubrication.
- (3). the output of the repeated operation with the total time for lubricatin.
- (4). The interval of the repeated operation with the total time for lubricatin.
- (5). Wait Cycle time: During auto process, it is the time between completed thimble movement and starting a movement of moulds clamping of next cycle.
- (6). Cycle time: The time limitation to operation cycle in automatic process. The system alarms [cycle time is over] when the real operating time is longer than cycle time limitation.
- (7). Movement time limitation: the max time permitted when output movement.
- (8). Error alarm bell: The max time when error output occurs. To avoid long time alarming, the bell stops alarm when time is over
- (9).during the output time of lubrication, if it fails to detect any lubrication pressure signal, it would trigger an alarm, telling that the lubrication is failing. If “opping working” after the failing of lubrication is chosen, then it would stop lubricating and would change to work in manual mode and stop the engine after the cycle of the alarming.



15. Set temperature information

Press  key, enter the menu for setting temperature, now the menu is as following:



Description on setting parameters

The set temperature value is 0.1°C (Celsius). The temperature of the hopper of injection molding machine is close-loop controlled after it is fed back to controlling system by K style thermal electric couple.

The system provides total 6 stages of temperature control and 1 stage oil temperature testing. [Open-loop] / [close-loop] can be selected to control temperature for injection nozzle. The system monitors the temperature in every area to find out if the temperature overpasses the set top and bottom limitation. It cannot inject or melt plastic if the temperature is lower than the bottom limitation and than the cold preventing screw starts. It alarms when the temperature is higher than the top limitation.

The temperature of each stage is shown on the main menu

Half temperature functions: select use, at this time, the temperature setup value is half of the current showed setup value.


Cold boot: After the boot, the actual temperature in each area will be within the setup scope.

部分塑胶密度与料管加热温度参考资料

原料简名	密度	加热温度°C	原料简名	密度	加热温度°C
A.B.S	1.01-1.05	190-270	PMMA	1.17-1.20	180-260
PS	1.05	190-240	PPO	1.08-1.09	260-330
A.S	1.06-1.07	180-250	PA/NYLON	1.08-1.17	230-290
H.P.S	1.05-1.08	220-280	NYLON66	1.03-1.15	280-330
L.P.S	0.91-0.93	150-260	PVC/S	1.20-1.40	150-180
H.P.E	0.94-0.96	190-260	PVC/H	1.30-1.58	160-200
P.P	0.98-0.90	200-290	P.E.T	1.38-1.41	280-310
P.C	1.2-1.22	280-320	P.T	1.41-1.52	220-280
P.O.M	1.41-1.42	190-230			

16. Set warm-up information

Press  key twice, enter the menu for setting warm-up, now the menu is as following:



Press  key third, enter the menu for setting chart of observation, now the menu is as following:



Description on setting parameters

Warm-up function: Can set a time for seven days a week in advance. The system controls the heating system to heat through the set value of the intraday [on]/[off] time. The system heats automatically the hopper to working temperature before operator comes to the office. The operator's waiting time for heating hopper is decreased.

*[note]: The input value of time adopts the input value of 24 hours system. 00:00 is 12: 00 Midnight.

17. Set mould information

Press  key, enter the menu for setting mould, now the menu is as following:



2009-06-09 【Mold Info】 16:38:27

Mold No. 3 READ SAVE DELETE

MoldName 3alma Abc輸入

Mold View

No.	Mould Name	Save Date
0	abc	2009-6-10 14:38:52
1	Link1	2009-5-17 15:38:12
2	Link2	2009-4-26 15:17:52

Description on setting parameters

- (1). Mould number: this system can store 10 mould numbers. The system can provide automatically the information of the modified mould number after they have been modified.
- (2). How to store mould: Move cursor to the box of mould numbers, key in the mould number; and than move the cursor to the box of the name of the mould, key in the name of the mould; this system provides the input modes with English/Chinese phonetic alphabet; move the cursor to box of storage after the name has been keyed in and than press [enter] to store the name.
- (3). How to get mould: Move cursor to the box of mould numbers, key in the mould number that will be read out, move the cursor to the box of reading out, press [enter] to read out. The functions of getting mould is limited within manual mode to prevent accident occurs; in the semi-auto/ auto mode, the accident is caused by the influence of bad products, which comes from the sudden varying of the set parameters in the menu.
- (4). How to delete: Move cursor to box of mould number, key in the mould number that will be deleted, and than move the cursor the box of deleting, press the [enter] to delete. The current mould number can not be deleted.
- (5). How to check mould: Move cursor to the box of mould browsing, read it through the rolling menu by using up and down key.

18. Amend note information

Press  key twice, enter the menu for amend note information, now the menu is as following:


2009-06-09		【AmendHistory】		16:38:31	
		Times: 3		Show	Delete
Amend Time	Amend Page	Amend Item	Quondam Va	Amend Val.	
12:24:15	InjectionP4	Seg4Pres	38.0	55.0	
11:20:38	PreHeatingP15	OFF	OFF	ON	
10:14:08	mold openP3	SlowFlux	0.0	30.0	

Description on setting parameters

- (1). Page number: This screen can keep at most 999 items of records, press  or , press buttons to move up an down cursor to view the revised information.
- (2) Printing: start printing function.

19. Set special parameters


Press **1_{STU}** key in the home menu, enter the menu for setting special parameters,
now the menu is as following:



- (2) Mid / big pump start: when the setup executive action flow value is bigger than the setup mid/big pump flow output value, the mid/big pump output point will have output.
- (3) Move the cursor to select the [special parameters>>] button, press the input button, a new page will pop up. At this time, the screen displays as follows:



- (3a) Adjustment of LCD contrast: move the cursor to this place, input the data [adjustment range "1-31"]. Under appropriate brightness, the higher the contrast is, the richer the color will be (Note: when LCD is the STN screen, it can be valid).
- (3b) LCD brightness adjustment: move the cursor to this place, input the data [adjustment range "0-100%"], the screen will display the darkness & brightness degree according to the data entered.
- (3c) LCD color setup: the system can provide [normal/anti-color] two options, move your cursor to this place, press [input] button to select LCD color display.
- (3a) LCD backlight time: the system has the function of screen protection, the background light time is adjustable, the setup scope is 1 ~ 6 minutes. If the keyboard is not pressed in the setup time, the background light will be automatically turned OFF. (Note: if any button is pressed, background light will be on)
- (3e) Function of key sound: Select [use], you will hear a "tick" sound when the key is pressed, if do not select, no sound.
- (3f) Key sound scope: move your cursor to this place, input the data [scope "0-10"] to adjust voice volume.
- (3g) Correction of Touchscreen: click on the [Correction] button to enter the correction page (Note: only if keyboard has the touch function, the correction can be valid)
- (3h) Network connection status: the network connection status is indicated with colors.
- (3i) Current IP: show the IP address of the machine.
- (3j) Current connection state: show the network connection status: disconnect / connect.
- (4) Move the cursor to select [language conversion>>] button, press the input button, a new page will pop up. The screen displays as follows:



- (4a) Language options: the system provides [language 1 / Language 2 / Language 3 / language 4 / Language 5 / Language 6] the six language options, move the cursor to this place, press the [input] button, you can carry out the conversion. (Note: the language categories of the system can be set up by users)

Chapter 4 production management

1. Set production Information



Press **FLOW CHART** key, enter the menu for setting production information, now the menu is as following:

FLOW CHART 2009-06-09 【ProductManagement】 16:38:39

SetNumber	um. aMolc	Output	Good	Inferior
4000	3	12	33	3

WarnStop Disable Zero OFF Delete

Date	No.	Number	Good	Inferior
08-15 10:17	3	12	33	3

Hint:

Description on setting parameters

- (1) The quality products equal to the number of the opened mould times the amount of one mould minus rejects. The rejects are controlled through ejecting testing function. When ejecting testing function is on, just like in stroke. When too much or too less stuff occurs, the rejects will increase amount value of one mould, and [Failure of plastic] alarms.
- (2) Set mould numbers: In the mould numbers setting of pre-production, the system starts alarming when the number of mould opening arrives at the first 5 moulds till it reached The set output .
- (3) Stop after alarming: [On] or [Off] can be selected. It will continue producing even arrives at the set mould number if [Off] has been selected till an operator stops it.
- (4) How to check production records: Move cursor to the box of production records, read it through the rolling menu by using [↑ ↓] key.

2. SPC Tracing record

Press  key 3 times to enter the SPC Tracing record with production management, and the panel is as follows:




Description on setting parameters

- (1). Pages: the panel has up to 999 pages, containing the consecutive information of the 999 modules. The SPC Tracing record system can provide up to 9 important parameters of the latest 999 modules. The operator can scroll up and down between page 1 and page 10 to manage the production of the modules. By using the system, the operator will be able to have more insight of the actual variation of the important parameters and take specific and proper actions to adjust the system's operation and improve the quality of the product as a result.
- (2). Print the page: the function would let the operator to make use of the printing service of the system.
- (3). Intermittent cycle: record the data once every several cycles.
- (4). Recording cycle: After entering automatic state, it will calculate from the first product, when the product number is smaller than the data, the SPC tracking record will be valid.

3. Pressure / Speed curve

press the  key 5 times to enter the panel and it should be as follows:



Description on setting parameters

- (1). Display choice: the system can show you the selected curve, such as curve of injection, curve of pressure for injection, pressure for pressure retention, pressure for locking the modules. All the curves can be selected by the input key.

4: Temperature tracing curve panel.

Press  key for 4 times to enter the temperature tracing curve panel, and it is as follows:



Description on setting parameters

- (1). Display: That is to monitor the historic tracing curve of the temperature of a specific segment. For reference , it can provide historic parameters of each segment, which are up to the past 6 hours. This lets the operator more insight of the variation of the actual temperature and let compare and analyze how the change of the temperature affects the quality of the products.
- (2). Interval of the sample record: is the interval of the sampling process 5 minutes.

5. Alarm note page

Press  key one times to enter the alarm note page, and it is as follows:



The screenshot shows a software interface titled 'AlarmHistory'. At the top, it displays the date '2009-06-09' and the time '16:39:04'. Below the title, there is a 'Number:' field with the value '3', and two buttons labeled 'ShowAll' and 'Clear'. The main part of the interface is a table with three columns: 'Alarm Time', 'No.', and 'Alarm matter'. The table contains three rows of data.

Alarm Time	No.	Alarm matter
16 10:25	3	temp. higher
16 09:43	5	temp. higher
16 08:15	8	manual time over


Parameter setting introduction

- (1). Display: the system stores at most 999 pieces of alarm records for inspection, it will be helpful for the maintenance of the equipments.
- (2). Printing list: start the function of printing list of the printer.

6. USB setting page (for options)



Press  button for one time; enter USB setting page. At this time the page shows as following:




Parameter setting introduction

- (1) **Formula downloading**: download the mould data from control system of jet moulding machine to the USB of moveable disc.
- (2) **Formula uploading**: upload the mould data from the USB of moveable disc to control system of jet moulding machine; at the same time the data will overlay previous data correspondingly.
- (3) **System downloading**: download the mould data from control system of jet moulding machine to the USB of moveable disc.
- (4) **System uploading**: upload the mould data from the USB of moveable disc to control system of jet moulding machine; at the same time the data will overlay previous data correspondingly.
- (5). **Start/End D**: when you are downloading the material of [formula] and [system], please designate the scope of the downloading data ([formula]: 0~1999; [system]: 10000 ~ 10599).
- (6). **Mainframe replication**: means updating the host procedures. First, press the stop button on the keyboard, then move the cursor to [replication], press the enter button and move the cursor to select [. Pin] files and update it.
- (7). **Update OPWIN.PS6**: means updating the keyboard procedures. Move the cursor to [update], press the enter button and move the cursor to select [. PS6] files and update it.
- (8). **Update the boot background documents**: means updating the boot screen. Move the cursor to [update], press the enter button and move the cursor to select [. Bmp] files and update it.

Chapter 5 Instructions for the System Commissioning Settings

1. Engineer Setting Page

Press  Key on the Main Page to enter the Engineer Setting Page, and the following will be displayed:



Enter the password * * * *. If correct,  will be displayed. If incorrect,  will be displayed. If the password entered is correct, you can enter the system parameter setting page. It is not necessary for the equipment end-user to adjust the system parameters. Please consult the equipment manufacturer for any query. Any parameter adjustment disorder may result in damage to equipment capability, unstable performance or failure to operate.

After the correct password is entered, the cursor jumps automatically to the first item from the right. The cursor can be moved to different items and then Key   is pressed to enter the corresponding pages. Alternatively, you can press the following keys  to enter directly the corresponding pages:

Key	Entering Page	Key	Entering Page
 開鎖模 M.PLT	<Delay Setting>	 托模/中子 EJE/CORE	<Standby Function Setting>
 射 出 INJECTION	<Pressure/Flow Setting I> <Pressure/Flow Setting II>	 時 間 TIME	<Programmable Standby Points>
 儲 料 FEEDING	<Pressure Pre-Adjustment> <Flow Pre-Adjustment>	 溫 度 TEMP.	<Temperature Parameter/ Time Setting>
 座臺/調模 NOZZ/ADJ.	<Special Function Options>	 資 料 DATUM	<Machine No./Ex-Factory Value Setting>

3. Pressure/Flow Slope Setting Page

Entering **Engineer Setting Page**,, press Key  once to enter Pressure/Flow Slope Page I. The following is displayed:

NextPage

【Set Pres/Flux Slope1】

Re. Eng.

Act	P	F
SlowClos	16.0	16.0
FastClos	16.0	16.0
LowClos	16.0	16.0
HPreClose	16.0	16.0
SlowOpen	16.0	16.0
FastOpen	16.0	16.0
MediOpen	16.0	16.0
LowOpen	16.0	16.0
ADV. Quic	16.0	16.0
ADV. Slow	16.0	16.0

Act	P	F
EjecRet	16.0	16.0
CoreAIn	16.0	16.0
CoreAOut	16.0	16.0
CoreBIn	16.0	16.0
CoreBOut	16.0	16.0
1LevInjc	16.0	16.0
2LevInjc	16.0	16.0
3LevInjc	16.0	16.0
4LevInjc	16.0	16.0
5LevInjc	16.0	16.0

Hint: Set Range: 1.0~16.0

Entering **Engineer Setting Page**,, press Key  twice to enter Pressure/Flow Slope Page II. The following is displayed:

NextPage

【Set Pres/Flux Slope2】

Re. Eng.

ACT	P	F	ACT	P	F
1LevPres	16.0	16.0	MldThin	16.0	16.0
2LevPres	16.0	16.0	MldThic	16.0	16.0
3LevPres	16.0	16.0	Spare	1.0	1.0
4LevPres	16.0	16.0	Spare	1.0	1.0
FronDecp	16.0	16.0	Spare	1.0	1.0
1LevFeed	16.0	16.0	Spare	1.0	1.0
2LevFeed	16.0	16.0	Spare	1.0	1.0
BackDeco	16.0	16.0	Spare	1.0	1.0
NozzIADV	16.0	16.0	Spare	1.0	1.0
NozzIRET	16.0	16.0	Spare	1.0	1.0

Hint: Set Range: 1.0~16.0

Description on setting parameters

The Pressure/Flow Slope refers to the steep degree of rise or fall when the pressure/flow changes from one value to the next value. "1.0" stands for the slowest change and "16.0" stands for the fastest change. The setting range is [1.0-16.0].

4. Pressure Pre-Adjustment Page

Entering **Engineer Setting Page**, press **FEEDING** Key once to enter the Pressure Pre-Adjustment Page. The following is displayed:

PreA	Disable	
1	1	OFF
10	3000	OFF
20	5999	OFF
30	8998	OFF
40	11997	OFF
50	14996	OFF
60	17995	OFF
70	20994	OFF

80	23993	OFF
90	26992	OFF
100	29991	OFF
110	32990	OFF
120	35989	OFF
130	38988	OFF
140	41987	OFF
150	44986	OFF
160	48000	OFF

Hint: Set Range: 0~65535

Description on setting parameters

The pressure pre-adjustment is the linear adjustment of pressure output. In general, the standard pressure is 0-800mA and the standard output impedance is 10-20 Ω , unless the manufacturer has specific requirements since different manufacturers' overall oil piping designs and the capabilities of the pressure proportional valve being used are different.

Pressure Adjustment Method:

The parameters on this page have been set before ex-factory. If the capability of the proportional valves being used by the user is different, and the normal proportion and linear proportion cannot be achieved, the parameters on this page can be adjusted. First set the pre-adjustment to be [Activated], and then set the pre-adjustment item to be [ON]. For example, for the 50 bar pressure position of Item 50, if the reading on the pressure meter is 45 bar, the parameter of this item should be increased until the pressuremeter reading reaches 50 bar. Make adjustments on all parameters which need adjusting and make the 0-140 bar pressures being set correspond to the pressures being shown on the oil pressure meter respectively. After the adjustments are completed, the computer executes automatically linear processing and takes the processing results as the subsequent normal D/A proportional output values.

Initial data:

First, pre-adjust the needed maximum pressure data in 160bar, and then move the cursor to [initial data], press the enter key and select [open], the system will automatically distribute average data to 10bar--160bar.

5. Flow Pre-Adjustment Page



Entering **Engineer Setting Page**,, press Key **FEEDING** twice to enter the Flow Pre-Adjustment Page. The following is displayed:

NextPage **【FluxPreA】** Re. Eng.

CurrMin 1000	PreADisable	70	25194	OFF
PreAQdjP 80.0 bar	1 1 OFF	80	28793	OFF
Initial OFF	10 3600 OFF	90	32392	OFF
ScrewSpd: ***** RPM	20 7199 OFF	99	36000	OFF
current 0 mA	30 10798 OFF			
	40 14397 OFF			
	50 17996 OFF			
	60 21595 OFF			

Hint: 0. OFF 1. ON

Description on setting parameters

The flow pre-adjustment is the linear adjustment of flow output. In general, the standard value is 0-800mA and the output impedance is 40 Ω ,unless the manufacturer has specific requirements since different manufactures' overall oil piping designs and the capabilities of the pressure proportional valve being used are different.

Flow Adjustment Method:

The parameters on this page have been set before ex-factory. If the capability of the proportional valves being used by the user is different, and the normal proportion and linear proportion cannot be achieved, the parameters on this page can be adjusted. As for the speed adjustment, different manufacturers have different measuring methods. Some manufacturers use the melt tachometer to measure the rotation speed. First heat the barrel until the barrel temperature reaches normal melt temperature. Set the melt speed to be 1, 10, 20, 30, and more until 99 and check the actual values. Make adjustments on all parameters which need adjusting and make the 0-99% speeds being set correspond to the proportional coefficients being shown on the tachometer respectively. After the adjustments are completed, the computer executes automatically linear processing and takes the processing results as the subsequent normal D/A proportional output values.

Initial data:

First, pre-adjust the needed maximum flow data in 99%, and then move the cursor to [initial data], press the enter key and select [open], the system will automatically distribute average data to 10%---99%.

6. Back Pressure Pre-Adjustment Page

Entering **Engineer Setting Page**, press Key

儲料
FEEDING

three time to enter the Back Pressure

Pre-Adjustment Page. The following is displayed:

The screenshot shows the 'PreBackPres' screen with the following data:

Coil. RES		PreA Disable		Back Pressure Data			
12	Ω	1	1	OFF	80	97	OFF
Curr. Min		10	13	OFF	90	109	OFF
5		20	25	OFF	100	121	OFF
Curr. Max		30	37	OFF	110	133	OFF
800	mA	40	49	OFF	120	145	OFF
Initial		50	61	OFF	130	157	OFF
OFF		60	73	OFF	140	169	OFF
		70	85	OFF	150	181	OFF
					160	200	OFF

Hint: Set Range: 0~255

Description on setting parameters

The back pressure pre-adjustment is the linear adjustment of back pressure output. In general, the standard pressure is 0-800mA and the standard output impedance is 10-20 Ω, unless the manufacturer has specific requirements since different manufactures' overall oil piping designs and the capabilities of the pressure proportional valve being used are different.

Back Pressure Adjustment Method:

The parameters on this page have been set before ex-factory. If the capability of the proportional valves being used by the user is different, and the normal proportion and linear proportion cannot be achieved, the parameters on this page can be adjusted. First heat the barrel until the barrel temperature reaches normal melt temperature. Set the melt back pressure to be 1, 10, 20, 30, and more until 140 and check the actual values. Make adjustments on all parameters which need adjusting and make the 0-140 bar back pressures being set correspond to the back pressures being shown on the back pressure meter respectively. After the adjustments are completed, the computer executes automatically linear processing and takes the processing results as the subsequent normal D/A proportional output values.

Initial data:

First, pre-adjust the needed maximum pressure data in 160bar, and then move the cursor to [initial data], press the enter key and select [open], the system will automatically distribute average data to 10bar---160bar.

7. Electronic Ruler Setting Page

Entering **Engineer Setting Page**, press Key **座臺/調模** **NOZZ/ADJ.** one/twice times to enter the Electronic Ruler / Pressure Setting Page. The following is displayed:




Description on setting parameters

- (1) Electronic Ruler Function: If the equipment needs to use the electronic ruler, choose [Activated].
If the equipment adopts stroke switch control, choose [Deactivated].
- (2) Measurement Values: indicating the actual dynamic positions of the electronic rulers for the clamping unit, the injection unit and the ejector.
- (3) Total Length: referring to the actual lengths of the electronic rulers for the clamping unit, the injection unit and the ejector.
- (4) Limit Position: It refers to the maximum value set for the position. This parameter is subject to the maximum position setting. For example, if the parameter set is bigger than the limit position value, the system will not accept the parameter set and will retain the original setting.
- (5) Zeroing: When the equipment choose [Activated] for the Electronic Ruler Function and uses the electronic ruler, it may appear that the mechanic movement stroke is in place and yet the actual positions of the electronic rulers for the clamping unit, the injection unit and the ejector do not indicate "0". In such case, the corresponding ruler should be zeroed. Move the cursor to the zeroing button for [clamping unit ruler], [injection unit ruler] and [ejector ruler], and then press **輸入** **ENTER** Key to make zero clearing for the corresponding electronic ruler.
- (6) Functions of sensors: setting process same as electronic ruler.

8. Special Function Options Page

Entering **Engineer Setting Page**, press **托模/中子** **EJE/CORE** Key to enter the Special Function Options Page.

The following is displayed:



Descriptions on setting parameters function mode

- (1) Motor Idle Running & Automatic Stop: When [Activated] is chosen, time setting is effective and the setting range is 1-99 minutes. If the equipment has no operation within the set time period after the motor starts up, the motor is turned off automatically to protect the motor life and to save electricity charge.
- (2) Motor Y-ΔConversion: If [Activated] is chosen, the system converts from star output to delta output when the motor starts up. The conversion time period can be set and the setting range is 2.0-99.9 seconds.
- (3) Manual Base Advance Limit: If deactivated, the injection base advance is not subject to stroke control. If activated, the injection base advance position is subject to the control of the limit switch X06.
- (4) Mould Opening with Melt: If activated, the mould opening can be done as soon as the cooling time expires, even if the melt has not finished taking out.
- (5) Melt Key Locking: If activated, press the melt key once and then the melting continues and will stop when the melt position is reached or the time expires. Or press the melt key once more to stop the melting.
- (6) Neutron beginning methods: select [trip] or [position], select [position] to set the position value, and the movements when the dynamic mode arrives; select [trip], select the starting movements from the four options of dynamic mode trip.
- (7) Ejector Stop Type: [Stroke] or [Time] can be chosen. If [Stroke] is chosen, the stop is subject to the stroke. If [Time] is chosen, the stop is subject to the set time.
- (8) Mould Adjustment Activation: [Hydraulic] or [Electric] can be chosen. When [Hydraulic] is chosen, mould adjustment pressure and speed do not participate in the mould adjustment job.
- (9). Start to blow: select [position] or [trip], start the blowing work at the dynamic mode position or the trip conditions in automatic state.
- (10). Ejection total time: select [off duty] or [on duty], when you select off duty, it will eject the pressure transfer condition trip or eject time; when you select on duty, it will eject the pressure transfer condition trip or eject time or eject the total time.



Entering Engineer Setting Page, press **EJE/CORE** Key to enter the Special Function Options Page.

The following is displayed:



Function parameter setting introduction

- (1) Pressure/flux upper limit: the setting value in this page will lie on the upper limit range for setting values of mould parameter in every page.
- (2). Maximum temperature / percentage: the scope of maximum temperature setup value.

托模/中子
EJE/CORE

Entering **Engineer Setting Page**, press **托模/中子 EJE/CORE** Key three times to enter the Special Function Options Page. The following is displayed:

NextPage		【ChoseSpecFunc3】 ↑		Re. Eng.	
FeedSpd	Disable	CoolwaterDel	2.0		
FeedGearNumber	1	OilShort	Disable		
Lubrication self-locking		OilShortDe. Ala	2.0		
1stTimesLubr	Disable	MotorStartDela	0.0		
LubrMode	New	The proportion	Disable		
Lubr. M. N. U. Li.	2	Spare	0.0		
Lubric. T. L. Li.	2.00	Spare	0.0		
CoolWaterMod	Enable	Spare	0.0		


Hint: Set Range: 0.0~999.9

Function parameter setting introduction

- (1). Rotation speed of storage materials: when select [on duty], the screw rotation speed will be displayed on the monitoring page, conversely, it will not be displayed.
- (2). Gear number of single circle of storage materials: the gear number of one circle of gear screw.
- (3). Electric heat restriction: select [on duty], the electric heat can not be started in the course of motor starting.
- (4). Function of intermittent lubrication: you can select [on duty] or [off duty], if select [off duty], it will have continuous lubrication; if select [on duty], it will have intermittent lubrication.
- (5). Maximum number of lubrication mode: The maximum number of lubrication mode, it is used to control the lubrication cycle.
- (6). Minimum time of lubrication: the minimum lubrication time.
- (7). Output of insufficient oil restriction: select [on duty], when the X32 input time of insufficient oil alarm reaches the setup value, it will give an alarm.
- (8). Motor start delay: after the motor is started, you should delay the setup time, then you can conduct manual or automatic operation.

9. Standby Function Setting Page

After entering the correct password, press  Key to enter the Standby Function Setting Page. The following is displayed:



Descriptions on setting parameters function mode

- (1) Output Point Transfer Function: This function can be activated or deactivated. If activated, the output point executes immediately transfer operation. In case that mal-function or damage occurs to a certain point, the control can be transferred to another point by activating this function. For example, in case that failure occurs to the mould opening output point and the knockout core function is deactivated, the Y46 mould opening point can be transferred to Y66 and then the output wires should be exchanged. The system is equipped with the function of simultaneously transferring two output points. Once this function is activated, the system makes judgment on the two selected items. If the item is [ON], the transfer of the pre-set conditions of the item will be executed.
- (2) Input Point Transfer Function: This function can be activated or deactivated. If activated, the input point executes immediately transfer operation. In case that mal-function or damage occurs to a certain point, the control can be transferred to another point by activating this function. For example, in case that failure occurs to the front safety door input point and the knockout core function is deactivated, the X00 front safety door input point can be transferred to X25 and then the input wires should be exchanged. The system is equipped with the function of simultaneously transferring two input points. Once this function is activated, the system makes judgment on the two selected items. If the item is [ON], the transfer of the pre-set conditions of the item will be executed.

8. Programmable Standby Function Page

After entering the correct password, press Key

時間
TIME

 to enter the Programmable Page.

The following is displayed:



Descriptions on setting parameters function mode

In order to meet diversified application needs and provide an innovative product, we take the initiative to offer the programmable standby function page so that the users can define and revise by themselves the functions and the action sequence.

Example 1: For a certain mould injection machine, due to the different design of the oil piping, it is required that a point is output while clamping at high pressure and the power will not be interrupted until the melt finishes taking out. To achieve such a special function, choose an item and have it activated, and then specify an output point (i.e. this function is output through Y xx), and then set the action sequence [CD].

Notes: Regarding the output scope of Sequence D Clamping Stop, in automatic mode, the clamping switch is contacted during the process of mould close at high pressure, and this sequence output starts until the melting finishes; in manual mode, the clamping switch is contacted during the process of mould close at high pressure, and this sequence output starts until the mould opening key or the reset key is pressed.

Example 2: For a certain mould injection machine, due to the different design of the oil piping, it is required that a point is output while injecting and melting. To achieve such a special function, choose an item and have it activated, and then specify an output point (i.e. this function is output through Y xx), and then set the action sequence [FH].

11. Temperature Parameter/Time Setting Page

After entering the correct password, press Key



to enter the Temperature Parameter/Time Setting Page. The following is displayed:



function Description on setting parameters

- (1) Nozzle Function、Sequence I、Sequence Ii、Sequence III、Sequence Iv、Sequence Vfunction、[Activated] or [Deactivated] can be chosen. If deactivated, the system will not execute inspection and control on this sequence.
- (2) Oil Temperature Alarm: [Activated] or [Deactivated] can be chosen. If deactivated, once it is detected that the oil temperature is equal to or over the set upper limit, the alarm will be neglected. If activated, the alarm will be output, and the system will turn to manual mode and the motor will be turned off when the alarm cycle ends.
- (3) Pd Setting: Pd has been set before ex-factory. It is recommended that the user should not revise this parameter under normal circumstance.
- (4) Proportion control: proportion control is one of the simplest way for controlling, in which the input error signals are in proportion relation with output signals. There are steady-state errors when proportion control is the only way to be utilized.
- (5) Different coefficient control: in different coefficient control, output error signals of controller form direct proportion relationship with input error signals of controller. Fluctuation even destabilization may appear in automatic control system during the course of getting over and adjusting errors. The reason is: the existing heavier inert (links) or lagging assemblies can constrain errors, and its changing is always behind the changing of errors. The solution is to make the changing of errors constraint effect become advancing? i.e., the errors constraint effect should be zero when errors become close to zero. That is, it is not efficient enough to introduce proportion into controller merely. The function of proportion can only enlarge the amplitude value of errors. But at present time it is necessary to increase different coefficient, which can forecast the changing directions of the errors. The controller combined proportion with different coefficient can cause errors constraint effect to be zero, even to be negative, thereby severe over adjusting of proportion under controlling can be avoided. So for assemblies under controlling with heavier inertia or lagging, PD controller can improve dynamic behaviors of system during adjustment.

12. Machine No./Ex-Factory Value Setting Page

After entering the correct password, press Key **資料** (DATUM) to enter the Machine No./Ex-Factory Value Setting Page. The following is displayed:


Descriptions on setting parameters function mode

- (1) Mould Injection Machine No.: The system is equipped with the function of setting NO. for the mould injection machine so that the manufacturer can set the No. for easy sales management and after-sales service record.
- (2) Ex-Factory Value Restoration: During the modifying process of password pages, if normal operation cannot be achieved due to too much deviations of the modified parameters, press Key Enter and choose Confirm, and then all the contents and all the parameters will be restored to the standards values set before ex-factory.
- (3) System Backup value: standard values backup are provided for resetting when machines leave factory;
- (4). Time setup: to set up the time, after the setup, press the [input] key, and then press [OK], the update is successfully set up.


Chapter 6 Input/Output Mode Inspection

1. Input Inspection Page


- (3) Press **2_{VWX}** Key on the Main Page to enter Input Inspection Page I(PS660AM) and the following will be displayed:




- (4) Press **2_{VWX}** Key on the Main Page to enter Input Inspection Page I(PS860AM) and the following will be displayed:



- (7) Press **3_{YZ}** Key on the Main Page to enter Input Inspection Page II (PS660AM) and the following will be displayed:



- (8) Press **3_{YZ}** Key on the Main Page to enter Input Inspection Page II (PS860AM) and the following will be displayed:



- (6) The above input inspection pages are used for signal inspection and cannot accept information modification. The solid box on the display indicates that the signals are being input.

2. Key Inspection Page


- (1) Press **4_{JKL}** Key on the Main Page to enter Key Inspection Page I and the following will be displayed:



- (2) Press **5_{MNO}** Key on the Main Page to enter Key Inspection Page II and the following will be displayed:



- (3) Press **6_{PQR}** Key on the Main Page to enter A/D Inspection Page I and the following will be displayed:



3. Output Inspection Page

- (1) Press Key **7_{ABC}** on the Main Page to enter Output Inspection Page I and the following will be displayed:




- (2) Press Key **7_{ABC}** on the Main Page to enter Output Inspection Page II(PS660AM) and the following will be displayed:



- (3) Press Key **8_{DEF}** on the Main Page to enter Output Inspection Page II(PS860AM) and the following will be displayed:



- (4) Press Key **9_{GHI}** on the Main Page to enter Output Inspection Page I(PS660AM)and the following will be displayed:




- (5) Press Key **9_{GHI}** on the Main Page to enter Output Inspection Page III(PS860AM)and the following will be displayed:




- (4) Above delivery inspection pages are used for monitoring signals. If you want to inspect whether the delivery valve is ok or not manually without any actions, you can move the cursor to the delivery name which is waiting for your inspection, pressure 揺 nter 搦 utton, then the delivery valve will come to work. Meanwhile the solid block in the scene shows the delivery of the signals.

★ Special explanation


All the input and output point pages in this instruction manual are subject to changes without notice. The inspection pages displayed on the computer should be correct and final.




TB118 keyboard installation dimension Layout




Tc118 keyboard installation dimension Layout




External dimensions and installation hole positions drawings for power supply case and transformer




Exterior dimensions and installation hole position drawings for main controller



PS860AM system drawing



Motor Electric-Heating Wiring Diagram (for reference only)

**Common Interference Suppression Method (for reference only)**