

# **PXI8757**

## **User's Manual**



**Beijing ART Technology Development Co., Ltd.**

# Contents

<i>Contents</i> .....	2
<i>Chapter 1 Overview</i> .....	3
<i>Chapter 2 Components Layout Diagram and a Brief Description</i> .....	4
2.1 The Main Component Layout Diagram.....	4
2.2 The Function Description for the Main Component.....	4
2.2.1 Signal Input and Output Connectors .....	4
2.2.2 Potentiometer .....	4
2.2.3 Status Indicator.....	5
<i>Chapter 3 Signal Connectors</i> .....	6
<i>Chapter 4 Analog Signal Connection</i> .....	7
<i>Chapter 5 Methods of Realizing the Multi-card Synchronization</i> .....	8
<i>Chapter 6 The Instruction of the AD Trigger Function</i> .....	9
6.1 AD Internal Trigger Mode.....	9
6.2 AD External Trigger Mode.....	9
<i>Chapter 7 Notes, Calibration and Warranty Policy</i> .....	12
7.1 Notes .....	12
7.2 Analog Signal Input Calibration.....	12
7.3 Warranty Policy .....	12
<i>Products Rapid Installation and Self-check</i> .....	14
Rapid Installation .....	14
Self-check.....	14
Delete Wrong Installation.....	14

# ***Chapter 1 Overview***

In the fields of Real-time Signal Processing, Digital Image Processing and others, high-speed and high-precision data acquisition modules are demanded. ART PXI8757 data acquisition module, which brings in advantages of similar products that produced in china and other countries, is convenient for use, high cost and stable performance.

## **Unpacking Checklist**

Check the shipping carton for any damage. If the shipping carton and contents are damaged, notify the local dealer or sales for a replacement. Retain the shipping carton and packing material for inspection by the dealer.

Check for the following items in the package. If there are any missing items, contact your local dealer or sales.

- PXI8757 Data Acquisition Board
- ART Disk
  - a) user's manual (pdf)
  - b) drive
  - c) catalog
- Warranty Card


## **FEATURES**

### **Analog Input**

- Converter Type: AD7671ASTZ (4 chips)
- Input Range:  $\pm 10\text{V}$ ,  $\pm 5\text{V}$ ,  $\pm 2.5\text{V}$ ,  $0\sim 10\text{V}$ ,  $0\sim 5\text{V}$
- 16-bit resolution
- Sampling Rate:  $10\text{Hz}\sim 1\text{MS/s/ch}$
- Input Channels: 4
- Analog Input Mode: differential input
- Acquisition Mode: synchronous acquisition
- Data Read Mode: Software and DMA mode
- FIFO Size: 8K word
- Memory Signs: full, non-empty and half-full
- Programmable Gain: 1,2,4,8 times (AD8251) or 1,2,5,10 times (AD8250) or 1,10,100,1000 times (AD8253)
- Trigger Mode: software trigger, hardware trigger(external trigger)
- Trigger Source: ATR and DTR
- Trigger Type: level trigger, edge trigger
- Trigger Direction: negative, positive, positive and negative trigger
- AD Conversion Time:  $\leq 3\mu\text{S}$
- Analog Input Impedance:  $10\text{M}\Omega$
- Amplifier Set-up Time:  $785\text{nS}$  (0.001%) (max)
- System Measurement Accuracy: 0.01%
- Operating Temperature Range:  $0^{\circ}\text{C}\sim 55^{\circ}\text{C}$
- Storage Temperature Range:  $-20^{\circ}\text{C}\sim 70^{\circ}\text{C}$

## *Chapter 2 Components Layout Diagram and a Brief Description*

### **2.1 The Main Component Layout Diagram**



### **2.2 The Function Description for the Main Component**

#### **2.2.1 Signal Input and Output Connectors**

CN1: analog input connector

#### **2.2.2 Potentiometer**

RP1: analog input AI0 zero-point adjustment

RP2: Analog input AI1 zero-point adjustment

RP3: Analog input AI2 zero-point adjustment

RP4: Analog input AI3 zero-point adjustment

RP5: Analog input AI0 full-scale adjustment

RP6: Analog input AI1 full-scale adjustment

RP7: Analog input AI2 full-scale adjustment

RP8: Analog input AI3 full-scale adjustment

RP9: Analog trigger level adjustment

### **2.2.3 Status Indicator**

LED1: PWR


LED2: TRIG

LED3: PCI

LED4: ADC

# Chapter 3 Signal Connectors

CN1: 50-pin SCSI




Pin name	Type	Pin function definition
AI0+~AI3+	Input	Analog input (positive)
AI0-~AI3-	Input	Analog input (negative)
AGND	GND	Analog signal ground
DGND	GND	Digital signal ground
CLKIN	Input	Click input
CLKOUT	Output	Click output
ATR	Input	Analog trigger signal input
DTR	Input	Digital trigger signal input

## Chapter 4 Analog Signal Connection

Double-ended input mode, which was also called differential input mode, uses positive and negative channels to input a signal. This mode is mostly used when biggish interference happens and the channel numbers are few.


According to the diagram below, PXI8757 board can be connected as analog voltage double-ended input mode, which can effectively suppress common-mode interference signal to improve the accuracy of acquisition. Positive side of the 4-channel analog input signal is connected to AI0+~AI3+, the negative side of the analog input signal is connected to AI0-~AI3-, equipments in industrial sites share the AGND with PXI8757 board.



## Chapter 5 Methods of Realizing the Multi-card Synchronization


Three methods can realize the synchronization for the PXI8757, the first method is using the cascade master-slave card, the second one is using the common external trigger, and the last one is using the common external clock.

When using master-slave cascade card programs, the master card generally uses the internal clock source model, while the slave card uses the external clock source mode. After the master card and the slave card are initialized according to the corresponding clock source mode. At first, start all the slave cards, as the main card has not been activated and there is no output clock signal, so the slave card enters the wait state until the main card was activated. At this moment, the multi-card synchronization has been realized. When you need to sample more than channels of a card, you could consider using the multi-card cascaded model to expand the number of channels.




When using the common external trigger, please make sure all parameters of different PXI8757 are the same. At first, configure hardware parameters, and use analog or digital signal triggering (ATR or DTR), then connect the signal that will be sampled by PXI8757, input triggering signal from ART pin or DTR pin, then click “Start

Sampling” button, at this time, PXI8757 does not sample any signal but waits for external trigger signal. When each module is waiting for external trigger signal, use the common external trigger signal to startup modules, at last, we can realize synchronization data acquisition in this way. See the following figure:



**Note: when using the DTR, use the internal clock mode**

When using the common external clock trigger, please make sure all parameters of different PXI8757 are the same. At first, configure hardware parameters, and use external clock, then connect the signal that will be sampled by PXI8757, input trigger signal from ART pin or DTR pin, then click “Start Sampling” button, at this time, PXI8757 does not sample any signal, but wait for external clock signal. When each module is waiting for external clock signal, use the common external clock signal to startup modules, at last, we realize synchronization data acquisition in this way. See the following figure:





## Chapter 6 The Instruction of the AD Trigger Function

### 6.1 AD Internal Trigger Mode

When AD is in the initialization, if the AD hardware parameter `ADPara.TriggerMode = PXI8757_TRIGMODE_SOFT`, we can achieve the internal trigger acquisition. In this function, when calling the `StartDeviceProAD` function, it will generate AD start pulse, AD immediately access to the conversion process and not wait for the conditions of any other external hardware. It also can be interpreted as the software trigger.

As for the specific process, please see the figure below, the cycle of the AD work pulse is decided by the sampling frequency.




Figure 5.1 Internal Trigger Mode

### 6.2 AD External Trigger Mode

When AD is in the initialization, if the AD hardware parameter `ADPara.TriggerMode = PXI8757_TRIGMODE_POST`, we can achieve the external trigger acquisition. In this function, when calling the `StartDeviceProAD` function, AD will not immediately access to the conversion process but wait for the external trigger source signals accord with the condition, then start converting the data. It also can be interpreted as the hardware trigger. Trigger source is the DTR (Digital Trigger Source).

When the trigger signal is the digital signal (standard TTL-level), using the DTR trigger source. There are two trigger types: edge trigger and pulse level trigger.

#### (1) Edge trigger function

Edge trigger is to capture the characteristics of the changes between the trigger source signal and the trigger level signal to trigger AD conversion.

When `ADPara.TriggerDir = PXI8757_TRIGDIR_NEGATIVE`, choose the trigger mode as the falling edge trigger. That is, when the DTR trigger signal is on the falling edge, AD will immediately access to the conversion process, and its follow-up changes have no effect on AD acquisition.




Figure 5.2.1 Falling edge Trigger

When `ADPara.TriggerDir = PXI8757_TRIGDIR_POSITIVE`, choose the trigger mode as rising edge trigger. That is, when the DTR trigger signal is on the rising edge, AD will immediately access to the conversion process, and its follow-up changes have no effect on AD acquisition.


When `ADPara.TriggerDir = PXI8757_TRIGDIR_POSIT_NEGAT`, choose the trigger mode as rising or falling edge trigger. That is, when the DTR trigger signal is on the rising or falling edge, AD will immediately access to the conversion process, and its follow-up changes have no effect on AD acquisition. This function can be used in the case that the acquisition will occur if the exoteric signal changes.

## (2) Level trigger function

Level trigger is to capture the condition that trigger signal is higher or lower than the trigger level to trigger AD conversion.

When `ADPara.TriggerDir = PXI8757_TRIGDIR_NEGATIVE`, it means the trigger level is low. When DTR trigger signal is in low level, AD is in the conversion process, once the trigger signal is in the high level, AD conversion will automatically stop, when the trigger signal is in the low level again, AD will re-access to the conversion process, that is, only converting the data when the trigger signal is in the low level.

When `ADPara.TriggerDir = PXI8757_TRIGDIR_POSITIVE`, it means the trigger level is high. When DTR trigger signal is in high level, AD is in the conversion process, once the trigger signal is in the low level, AD conversion will automatically stop, when the trigger signal is in the high level again, AD will re-access to the conversion process, that is, only converting the data when the trigger signal is in the high level.

*Figure 5.2.2 High Level Trigger*

When `ADPara.TriggerDir = PXI8757_TRIGDIR_POSIT_NEGAT`, it means the trigger level is low or high. The effect is the same as the internal software trigger.

## ***Chapter 7 Notes, Calibration and Warranty Policy***

### **7.1 Notes**

In our products' packing, user can find a user manual, a PXI8757 module and a quality guarantee card. Users must keep quality guarantee card carefully, if the products have some problems and need repairing, please send products together with quality guarantee card to ART, we will provide good after-sale service and solve the problem as quickly as we can.

When using PXI8757, in order to prevent the IC (chip) from electrostatic harm, please do not touch IC (chip) in the front panel of PXI8757 module.

### **7.2 Analog Signal Input Calibration**

Every device has to be calibrated before sending from the factory. It is necessary to calibrate the module again if users want to after using for a period of time or changing the input range. PXI8757 default input range:  $\pm 10\text{V}$ , in the manual, we introduce how to calibrate PXI8757 in  $\pm 10\text{V}$ , calibrations of other input ranges are similar.

Prepare a digital voltage instrument which the resolution is more than 5.5 bit, install the PXI8757 module, and then power on, warm-up for fifteen minutes.

- 1) Zero-point adjustment: select one channel of analog inputs, take channel AI0+ for example, put 0V into AI0, and then run ART Data Acquisition Measurement Suite in the WINDOWS. Choose channel 0,  $\pm 10\text{V}$  input range and start sampling, adjust potentiometer RP1 in order to make voltage value is 0.000V or near 0.000V. Other channels zero adjustment is the same as this one.
- 2) Full-scale adjustment: select one channel of analog inputs, take channel AI0 for example, put 10V into AI0, and then run ART Data Acquisition Measurement Suite in the WINDOWS. Choose channel 0,  $\pm 10\text{V}$  input range and start sampling, adjust potentiometer RP7 in order to make voltage value is 9999.69mV or near 9999.69mV. Other channels full-scale adjustment is the same as this one.
- 3) Repeat steps heretofore, until meet the requirement.

### **7.3 Warranty Policy**

Thank you for choosing ART. To understand your rights and enjoy all the after-sales services we offer, please read the following carefully.

1. Before using ART's products please read the user manual and follow the instructions exactly. When sending in damaged products for repair, please attach an RMA application form which can be downloaded from: [www.art-control.com](http://www.art-control.com).
2. All ART products come with a limited two-year warranty:
  - The warranty period starts on the day the product is shipped from ART's factory
  - For products containing storage devices (hard drives, flash cards, etc.), please back up your data before sending them for repair. ART is not responsible for any loss of data.
  - Please ensure the use of properly licensed software with our systems. ART does not condone the use of pirated software and will not service systems using such software. ART will not be held legally responsible for products

shipped with unlicensed software installed by the user.

3. Our repair service is not covered by ART's guarantee in the following situations:

- Damage caused by not following instructions in the User's Manual.
- Damage caused by carelessness on the user's part during product transportation.
- Damage caused by unsuitable storage environments (i.e. high temperatures, high humidity, or volatile chemicals).
- Damage from improper repair by unauthorized ART technicians.
- Products with altered and/or damaged serial numbers are not entitled to our service.

4. Customers are responsible for shipping costs to transport damaged products to our company or sales office.

5. To ensure the speed and quality of product repair, please download an RMA application form from our company website.

# Products Rapid Installation and Self-check

## Rapid Installation

Product-driven procedure is the operating system adaptive installation mode. After inserting the disc, you can select the appropriate board type on the pop-up interface, click the button **【driver installation】** ; or select CD-ROM drive in Resource Explorer, locate the product catalog and enter into the APP folder, and implement Setup.exe file. After the installation, pop-up CD-ROM, shut off your computer, insert the PCI card. If it is a USB product, it can be directly inserted into the device. When the system prompts that it finds a new hardware, you do not specify a drive path, the operating system can automatically look up it from the system directory, and then you can complete the installation.

## Self-check

At this moment, there should be installation information of the installed device in the Device Manager (when the device does not work, you can check this item.). Open "Start -> Programs -> ART Demonstration Monitoring and Control System -> Corresponding Board -> Advanced Testing Presentation System", the program is a standard testing procedure. Based on the specification of Pin definition, connect the signal acquisition data and test whether AD is normal or not. Connect the input pins to the corresponding output pins and use the testing procedure to test whether the switch is normal or not.

## Delete Wrong Installation

When you select the wrong drive, or viruses lead to driver error, you can carry out the following operations: In Resource Explorer, open CD-ROM drive, run Others-> SUPPORT-> PCI.bat procedures, and delete the hardware information that relevant to our boards, and then carry out the process of section I all over again, we can complete the new installation.