

# TwinLock compact

## Manual



EN 1300  
M 106302 / M 106301  
G 106016 / G 106015  
Class 2 / C

Copyright © September 08 INSYS MICROELECTRONICS GmbH

Any duplication of this manual is prohibited. All rights on this documentation and the devices are with INSYS MICROELECTRONICS GmbH Regensburg.

### Restrictions of guarantee

This handbook contains a concise description. The compilation of the text has been made with the utmost care. Despite all efforts, there may be deviations to the actual functions. No guarantee can therefore be given for the accuracy of the contents. We can neither assume legal responsibility nor any liability for incorrect information and their consequences. Suggestions for improvements and comments are always welcome.

### Trademarks and logos

The use of a trademark or logo not shown below does not indicate that it is freely available for use.

INSYS ® is a registered trademark of INSYS MICROELECTRONICS GmbH.

Windows™ is a registered trademark of Microsoft Corporation.

### Publisher:

INSYS MICROELECTRONICS GmbH  
Waffnergasse 8  
93047 Regensburg, Germany

Phone: +49 (0) 941/58692-22  
Fax: +49 (0) 941/563471  
Internet: <http://www.insys-security.de>

Carl Wittkopp GmbH & Co. KG  
Sternbergstr. 5  
42551 Velbert, Germany

Phone: +49 (0) 2051/9566-0  
Fax: +49 (0) 2051/9566-66  
Internet: <http://www.cawi.com>

Subject to technical changes. Errors excepted.

Date: September 08

Version: 1.06

The manual contains detailed information for the operation and the programming of the high-safety lock **TwinLock compact** and is mainly intended for the system MASTER responsible for the system configuration and administration.

For users, we recommend the Quick Reference Guide. The concise document contains all important information required for normal system operation in short form.

The document ASSEMBLY INSTRUCTIONS has been created to assist with the installation of the system. This contains all information for the implementation of the TwinLock system.

## Table of contents

<b>1. SYSTEM DIAGRAM .....</b>	<b>6</b>
<b>2. SYSTEM DESCRIPTION.....</b>	<b>7</b>
2.1. INPUT UNIT : FLATCONTROL.....	7
2.2. LOCK : TWINLOCK COMPACT.....	7
2.3. BUS DISTRIBUTOR : TWINCONNECT.....	7
2.4. EXTENSION UNIT : TWINXT.....	8
2.5. CHIP CARDS (TWINCARD) .....	9
2.6. CONFIGURATION SET TWINCOMM .....	10
<b>3. FUNCTION DESCRIPTION.....</b>	<b>11</b>
3.1. CODE AND LOCKING FUNCTIONS .....	12
3.2. TIMER FUNCTIONS .....	15
3.3. SERVICE FUNCTIONS .....	16
3.4. OPERATIONAL SAFETY .....	17
3.5. SABOTAGE SAFETY.....	19
3.6. PC SUPPORT WITH CONFIGURATION SET TWINCOMM.....	19
<b>4. OPERATION .....</b>	<b>20</b>
4.1. DISPLAY AND CONTROL ELEMENTS OF THE INPUT EQUIPMENT .....	20
4.3. GENERAL OPERATING INSTRUCTIONS .....	22
<b>5. GENERAL OPERATION PROCESSES.....</b>	<b>24</b>
5.1. UNLOCKING A LOCK .....	24
5.2. CLOSING A LOCK .....	25
5.3. STATUS REQUEST OF A LOCK/ VERSION REQUEST .....	26
5.4. RESPONSES.....	27
<b>6. PROGRAMMING THE SYSTEM WITH THE CONTROL UNIT .....</b>	<b>29</b>
6.1. REPROGRAMMING A MASTER CODE.....	30
6.2. REPROGRAMMING THE MANAGER CODE .....	31
6.3. PROGRAMMING AND REPROGRAMMING OF A USER CODE.....	32
6.4. DELETE A USER CODE .....	33
6.5. DISPLAY THE PROGRAMMED USER CODES.....	34
6.6. SETTING THE DATE, TIME AND WEEKDAY .....	35
6.7. CODE LINKAGE PROGRAMMING (FOUR-EYE-CODE).....	36
6.8. PROGRAM UNLOCKING TIME DELAY .....	37
6.9. PROGRAM OPENING DURESS (FORCED SEQUENCE).....	38
6.10. PROGRAM SILENT ALARM.....	39
6.11. PROGRAMMING ACTIVATION OF TWINXT LOCK I/O.....	40
6.12. RESET THE INPUT UNIT .....	41
6.13. LOCK MOTOR SERVICE .....	43
6.14. REGISTER/REPLACE LOCKS IN THE SYSTEM.....	44
6.15. WRITE LOG AND CONFIGURATION TO CHIP CARD .....	45
6.16. WRITE LOG AND CONFIGURATION TO CHIP CARD .....	46
6.17. READ NEW SYSTEM LANGUAGE .....	47
6.18. IGNORE BOLT SYSTEM POSITION SWITCH .....	48
6.19. ACTIVATE PARALLEL CODE.....	49
6.20. AUTOMATIC LOCKING.....	50
<b>7. PROGRAMMING THE SYSTEM WITH THE PC SOFTWARE TWINCOMM.....</b>	<b>51</b>
7.1. GENERAL OPERATION .....	52
7.2. PROGRAMMING OF GENERAL SETTINGS.....	54
7.3. PROGRAMMING THE UNLOCKING DELAY.....	57

---


7.4. DISPLAY EVENT LOG .....	58
7.5. USER DATA MANAGEMENT .....	59
7.6. CUSTOMER DATA MANAGEMENT .....	60
<b>8. TECHNICAL DATA .....</b>	<b>61</b>

## Revision History


## Support / Hotline

## 1. System Diagram

**TwinLock compact – 1 lock with 12 VDC power supply / TwinXT optional**



**TwinLock compact – 2 locks with 12VDC power supply / TwinXT optional**



## 2. System Description

**TwinLock compact** is an electronic high safety lock system with integrated arming device for a burglary alarm system class 3/C. It is a modular system. The security-relevant system parts are designed fully redundant.

The system consists of the following components:

- 1-2 Control units = Terminals
- 1-2 locks
- 1 Bus distributor = Connector for the individual components (hub)
- 1 Extension units TwinXT

### 2.1. Input Unit : FlatControl

The input unit is mounted on the outside of the safe (see assembly of the input unit) and is used to control and operate the locking system (code input, programming, etc.), as well as to arm or disarm a burglary alarm system using a physical code (chip card).



### 2.2. Lock : TwinLock compact

The locks are mounted within the secured area of the safe (see assembly of locks). The mnemonic codes are stored and evaluated inside the locks.



### 2.3. Bus Distributor : TwinConnect

The bus distributor TwinConnect enables the connection of the individual system components.

In addition, TwinConnect has a power supply unit (12 VDC), which can supply the TwinLock compact system. (When the arming device is connected, however, the system must be supplied through the BAS).



## 2.4. Extension Unit : TwinXT


The TwinLock compact system can be extended by 2 inputs and 2 outputs by means of the extension unit **TwinXT** very easily. Basically, a TwinXT can be connected to each lock in the system. Consequently, each lock can be specifically locked or released, and each lock can have a bolt system contact.



- 2 switching inputs (release/bolt system contact) for lock 1
- 2 switching inputs (release/bolt system contact) for lock 2
- 2 relay outputs (status/silent alarm) (30V/1A)
- Power supply 12 VDC
- Antitamper loop with tamper switch




## 2.5. Chip Cards (TwinCard)



### **TwinCard code access**


Chip card as 'physical code' to disarm a BAS.

The code is changed continuously.



### **TwinCard configuration**

Chip card for the system configuration and the event log. In cooperation with the PC software TwinComm, the configuration can be imported or exported and the log can be read out.



### **TwinCard language**

Chip card for the configuration of the system language. (German, English, Czech, Portuguese...)




### **TwinCard TwinComm**

Lizenzchipkarte for the TwinComm configuration Software.

## 2.6. Configuration Set TwinComm

The TwinLock compact system can be configured fast and conveniently using the program TwinComm in connection with the chip card reader of the configuration set and the chip card **TwinCard configuration**. All settings and the event log can be displayed, printed and saved.



## 3. Function Description

### Code and Locking Functions

- 1 Master code per lock
- 1 System code
- 99 User codes per lock
- Status indicator for programmed user codes
- Code linking (Four-eye code )
- Silent alarm
- Code manipulation detection
- Quick unlocking code
- Opening duress (forced sequence)
- Parallel code
- Automatic lock with door switch

### Timer Functions

- Time delay
- Alarm/sabotage delays
- Automatic switching to daylight savings time

### Service Functions

- Event log 768 events
- Import/export of the configuration via chip card
- System language can be configured using the chip card
- Reset of the individual system components
- Query of the system component version
- System components login/logout
- Step-by-step operation for motor test
- System line free configurable
- System status indicator
- Voltage monitoring

## 3.1. Code and Locking Functions

### Master code

Each lock has a master code (ID = 00 + 6-digit master code).

The master code has the authorization to program lock-specific procedures (e.g. time delay, user codes, etc.) or to unlock, respectively.

The master code can not be deleted or deactivated.

### Attention:



The default code for the user 00 (= Master) of each lock is the pre-programmed code 1 2 3 4 5 6 . The user codes no. 01...99 of the individual locks have been deactivated by the manufacturer.

For safety reasons, the master codes of the individual codes must be changed **IMMEDIATELY!**

When programming the code you must see to the new unlocking code being checked repeatedly while the safe is open.

Do not use personal data when programming unlocking codes!

Loosing a master code can have very costly consequences!!!

### Manager code

There is one manager code (6-character code) per lock. The manager code is also called the **system code!**

The manager code has the authorization to program the settings and time functions. It does not have any opening authorization, though.

The manager code cannot be deleted or deactivated.

### ATTENTION:

**The code 1 1 1 1 1 1 is pre-programmed as the works code for the system code.**

### User codes, Benutzercodes

Each lock has 35 user codes (user ID + 6-digit user code).

The user codes are programmed or deleted by the according master code. A user can reprogram his/her user code autonomously. Otherwise, the user only has an unlocking authorization.

A user code can be assigned the possibility for "Quick unlocking" (= quick unlocking code) without time delay expiration (see timer programs 3.2.2).


### Status indicator for programmed user codes

For each lock, the programmed user codes can be displayed. The programming status, i.e. OK or NOK is displayed. The display can only be activated by the according lock master.

## Quick opening code

A user can be assigned the function of the quick opening code, which circumvents a programmed time delay. The user who has stored the code with number 09 has the quick opening code by default.

## Code distribution in the TwinLock 7220 system



## Unlocking & Locking

The unlocking is tied to at least one code entry. This always takes place via the menu keys (see sabotage safety). Unlocking can be prevented by several functions (timer programs...).

## Opening duress (forced sequence)

When a 'opening duress' is activated, the locks can only be opened in a certain order / sequence (lock 01, 02, ...). When locking the system, the sequence is reversed. The system is only unlocked and accessible for configuration and service after all locks have been opened.

## Automatic lock with door switch

The system can be locked automatically using a door switch or a bolt system contact, which is either connected to a TwinAlarm or TwinXT system, depending on the system variant.

This function can only be configured via the PC software TwinComm.

## Code linkage

For the entire system, the function 'Four-eye code' can be programmed. A lock can thus only be unlocked by entering 2 user codes respectively. Programming can only be performed by the system master. If a four-eye code has already been programmed, the system master can perform the programming only in connection with other users of lock 01.

## Parallel code

For a **2 lock system**, the function 'parallel code' can be programmed.

This function can only be configured via the PC software TwinComm.

In this case, the unlocking codes apply to 2 locks, e.g. the user does no longer need to select a lock, and he is not bound to a specific lock. In all locks, however, the same codes must be programmed for the according users, e.g.

User 08:                    Lock 1: Code : 080808  
                              Lock 2: Code : 080808

User 009:                Lock 1 :        Code : 090909  
                              Lock 2 :        Code : 090909

## Note on code linkage and parallel code:

**Attention: The code linkage and the parallel code can not be set simultaneously.**

## Silent alarm

During a threatening situation, a special alarm code may be entered when locks are opened and closed, to trigger a silent alarm.

The alarm code consists of the normal user access code where the last number is increased by **+1** (9 switches to 0!).

The system now acts exactly like for the normal opening procedure for the user (and the intimidator), but at the same time a silent alarm signal is sent to the BAS.

Furthermore, an individual opening time delay may be defined for the case of an alarm. The lock can only be opened after the set waiting period has expired (see also timer programs 3.2.2).

The defined release time of the "normal" time delay is used as release time.

Example:

Unlocking code: 1-2-3-4-5-6 >> Alarm code: 1-2-3-4-5-7

## Code Manipulation

When the code has been entered incorrectly for four times, a blocking time of 1 minute is activated. During this blocking time, no opening procedure may be performed. Each further incorrect code entry increases the blocking time by one minute. The maximum blocking time is 15 minutes.

At the beginning of the locking period, the incorrect code entries are classified as a manipulation attempt and stored in the event memory. The next time that a correct code is entered, the code error counter is reset and the locking period is deleted.

(see also timer programs 3.2.2, sabotage safety 3.2.5)

wrong code blocking time
-----------------------------

## 3.2. Timer Functions

### Time delay

Unlocking delay, individually configurable (00 - 99 min.). A release time (00 - 99 min.) can be programmed for each unlocking delay. After the time delay expiration an unlocking code must be re-entered.

The programming is performed by the system manager.

A user can be assigned a quick unlocking code function to bypass this program.

### Alarm/sabotage delays

When the unlocking code was entered incorrectly 4 times, a time delay of 1 minute starts. For each further attempt with a wrong code the waiting period is extended by 1 minute, up to a maximum of 15 minutes.

When a silent alarm is triggered, a waiting period with a set duration will start.

These special programs can not be bypassed or interrupted.

## 3.3. Service Functions

### Event Log

The latest 768 events (programming processes, hardware errors, and certain status messages, manipulation and sabotage attempts) are logged in chronological order, including date and time (perhaps the user number).

There is also the possibility to transfer the entire event memory to the TwinCard configuration. Display and printing of the event memory take place with the PC software TwinComm.

### Configuration import/export

An entire configuration profile can be swapped out to the chip card Twin Card Configuration. This profile can then be edited with the PC software TwinComm and reimported or saved. The above-described event log is also written to the card and can be displayed, printed and saved using TwinComm.

### System language

The system language can be transferred using the chip card TwinCard language. This card is available in several languages and must be requested separately.

### More functions

- Reset of the individual system components
- Query of the system component version
- System components login/logout
- Step-by-step operation for motor test
- Operation of several control units



## 3.4. Operational Safety

### Redundancy

A dual bus system and a dual electronic and mechanical locking system in the locks guarantee high system stability. The two identical system parts are completely independent from each other and can therefore function individually.

### Voltage monitoring

When the power supply is applied or when the system recovers from energy saving mode, the state of the battery (system voltage) is checked. When the system falls below a set warning threshold, an entry is made in the log and a message is displayed. Press F2 to display the system voltage from the system menu.

```
*** TwinLock ***  
battery: 9.0V
```

```
*** TwinLock ***  
!!! Low Batt !!!
```


Every time the system is restarted (battery replacement) or when the system is activated, the battery voltage is measured and checked. If the battery voltage falls below the set warning limit, the message

'!!! Low - Batt !!!' is displayed and also stored in the event memory.

## Power Failure

The FlatControl receives its power supply via each of the two bus cables. When a voltage failure occurs, an emergency current feed for the entire system is possible via a jack at the bottom of the keyboard.

For this, an adapter cable 7237-101-0 and a 9 volt block battery (alkaline type) is required. For the connection of the adapter cable, see figure.



## Real time clock

The date and the time are generated by a specially buffered real time clock and will survive even if the system receives no current for several days.

If a real time clock still happens to be deleted, the system will be in an undefined state.

It must therefore be possible to set the date and time even when the system is locked.

Key F2 in the system menu >> system voltage >> key F2 >> 1 >> 0 >> date/time

(system code required)

## Further functions

Protection against locking the locks while the bolt system is open.

(only in connection with TwinXT or TwinAlarm)

Constant self-diagnosis of the bus lines and system components.

Log entry of all warning and error messages.

Validity check of entered times and dates.

## 3.5. Sabotage safety

### Input unit TwinControl/FlatControl

The input unit in the unsecured area is secured by different measures.

Opening the case (battery compartment TwinControl) is immediately detected and displayed until an authorized user unlocks the system lock properly.

A person standing next to the authorized user cannot watch the entering of the code. A special film in the view window of the terminal prevents the reading of the display from a lateral position.

Besides that, the opening code is not entered via the keyboard, but via the arrow keys above a digit selection on the display. After each entry of a digit, the cursor will be displayed at a randomly selected new position.

### Further functions

All codes are saved and evaluated within the secured area.

Log entry of all safety-relevant events.

Blocking times when a wrong code is entered repeatedly.

(see code programs, timer programs)

Configuration only possibly for unlocked systems after entering the system codes.

## 3.6. PC Support with Configuration Set TwinComm

Basically, the TwinLock compact system also works without PC support, but using the software simplifies the configuration and enables easy reading of the event log.

The exchange of data with the lock system takes place with the chip card **TwinCard configuration** and the service function '**Import/Export**' at the control unit.

Read-out configuration profiles can be saved, printed, or modified and reimported.


All timer programs and system settings can be programmed.

When the system settings are read out, the event log is also written to the chip card.


The protocol can be displayed and printed with TwinComm.

## 4. Operation

### 4.1. Display and Control Elements of the Input Equipment



## 4.2. Menu Navigation



## 4.3. General Operating Instructions

### System Activation


When idle, the TwinLock System is activated by operating a menu key at the control unit. After the activation, a system check is performed and the individual states of the connected locks and of the TwinLock system are displayed.

system check  
lock opened 01

system check  
system locked


### Key Functions

#### Menu Keys:



- > Menu navigation to the right, i.e. next menu item
- < Menu navigation to the left, i.e. previous menu item
- enter Selection or confirmation
- clear Cancel, return to previous menu item  
(press 2 seconds = return to system menu)


#### Key Pad:



- 0...9 Numeric keys to enter timer programs, etc.
- F2 Display of the current battery voltage  
(only possible in the system menu)

### Code input

The code is only entered via the number keys. The menu keys are intended for menu navigation and extended entries.



Using the menu keys for  
Menu Navigation



Entering the code using the numeric keypad

## System Menu

The start page of the menu structure is called system menu . The system menu consists of one editable line (line 1 = system line, which can contain individual text), and the current date/time display (line 2).

```
*** TwinLock ***  
Mo 15.09.08 12:00
```


### *Programming the Code*

#### **Important notes regarding the programming of the code**

- \* **For security reasons, switch the system code or the master code of the individual codes immediately after Installation.**  
The default code 1 2 3 4 5 6 is pre-programmed for the user no. 00 (= system master) and for the system master is 1 1 1 1 1 1. The user codes no. 01...99 of the individual locks have been deactivated by the manufacturer.
- \* **When programming the code you must see to the new unlocking code being checked repeatedly while the safe is open!**
- \* **Do not use personal data when programming unlocking codes!**

## 5. General Operation Processes

### 5.1. Unlocking a Lock




Automatic return after 3 seconds



## 5.2. Closing a Lock


TwinLock compact  
close

Select the menu item "Close"  
(see menu plan, 4.2.)



close  
lock 01

Select a lock



close  
Please wait

Lock locks

close  
lock closed 01

With the lock closed,  
the system cannot be re-configured

close  
system locked

Automatic return after 3 seconds

## 5.3. Status Request of a Lock/ version request

TwinLock compact  
Status / Info



Status / Info  
Lock closed 01

Version query  
SW version : TS01

Lock  
SW version : S01

Select the menu item "Status"  
(see menu plan 4.2.)

The status of the selected  
component is displayed.



With 2 locks in the system, the version of the  
second lock also is on display.

Automatic return after 3 seconds

## 5.4. Responses

### Unlocking Messages

open time lock week	No unlocking possible, because the current time is not within the time window defined in the weekly program.
open time lock day	No unlocking possible, because the current date coincides with the date of a defined special day.
open locking period	No unlocking possible, because the blocking time program is active.
open part blocking	No unlocking possible, because the chosen lock is partly blocked.
Open cancel Blocking time	An active timer program is cancelled by activating the input TIMEOUT in the secured area.
open terminal switch	The control unit was switched or re-initialized.
open ! manipulation !	At the last code entry, a user entered a wrong code more than three times. ! Attention!
Restart or currentless	The system has either been restarted or the power supply has been interrupted.

### Status messages

system check failure Bus A	Lock can no longer be addressed at bus A. <b>Please call customer service !</b>
system check failure Bus B	Lock can no longer be addressed at bus B. <b>Please call customer service !</b>
system check failure motor A	Final bolt position of the lock at bus A is not accessible. <b>Please call customer service !</b>
system check failure motor B	Final bolt position of the lock at bus B is not accessible. <b>Please call customer service !</b>

System check failure motor AB	Final bolt position of the lock is not accessible at bus A or bus B. <b>Please call customer service !</b>
----------------------------------	---

Status DMS XX Error	General lock fault. <b>Please call customer service !</b>
------------------------	--

## General Error Messages

. . . . . invalid code	Code entry incorrect. Please enter correct code!
---------------------------	---

. . . . . invalid input	Incorrect or invalid entry. Check entry and retry!
----------------------------	---

. . . . . failure BUS A	Addressed component at bus A does not respond. <b>Please call customer service !</b>
----------------------------	---

. . . . . failure BUS B	Addressed component at bus B does not respond. <b>Please call customer service !</b>
----------------------------	---

. . . . . failure motor AB	Error when unlocking/locking a lock. <b>Please call customer service !</b>
-------------------------------	---

. . . . . COM - Error	Error during communication between control unit and lock. <b>Please call customer service !</b>
--------------------------	--

## 6. Programming the System with the Control Unit








The following functions and settings can be performed using the control unit:

- Reprogram master code
- Reprogram manager code
- Program user codes
- Delete a user code
- Display a programmed User code
- Activate/deactivate code linkage
- Date/Time
- Program unlocking delay
- Program silent alarm
- Program parallel code
- Activate lock I/O, TwinXT
- Write configuration and log to chip card
- Read configuration from chip card
- Import new system language
- Automatic locking with door switch

Some of these functions and all others can be implemented by means of the **Configuration Set TwinComm**.

## 6.1. Reprogramming a Master Code

configuration Mastercodes	Select the menu item "Master Code" (see menu plan, 4.2.)	
configuration lock 01	Select lock	
Mastercodes Code:*****	Enter the master code Schlosses eingeben	
Mastercodes Please wait	Evaluate the entry	
New M-Code Code:*****	Enter the new master code Of the selected lock	
Confirm Code Code:*****	Reconfirm the new master Code once more	
New M-Code Please wait	Save the new code	
New M-Code Saved	Action completed	

Automatic return after 3 seconds

Besides the normal unlocking authorization, the master code is also authorized to program the user codes.

When entering the code, the user = 00 is the master.

### ACHTUNG:









The default code **1 2 3 4 5 6** is pre-programmed for the master of each lock. For safety reasons, the master codes of the individual locks must be changed immediately.

When programming the code make sure that the new unlocking code is checked repeatedly while the safe is open.

**Do not use personal data when programming unlocking codes!**  
**Loosing a master code can have very costly consequences!!!**

## 6.2. Reprogramming the Manager Code

configuration Manager Code	Select the menu item ' <b>Managercode</b> ' (see menu plan, 4.2.)	
configuration lock 01	Select the lock	
Manager code Code:*****	Enter the Manager Code of the Selectec lock	
Manager Code Please wait	Evaluate the entry	
New Manager Code Code:*****	Enter the new manager code of the selected lock	
Confirm Code Code:*****	Confirm new manager code again	
New Manager Code Please wait	Save the new code	
New Manager Code Saved	Action completed	

Automatic return after 3 seconds

The manager code does not have any opening authorization. It does grant authorization to configure the system. When the code is entered, the user using this code is identified to be the system manager.

**ACHTUNG:**

The default code 1 1 1 1 1 1 is pre-programmed for the manager.







For safety reasons, the master codes of the individual locks should be changed immediately.

Do not use personal data!

**The master code of lock 01 is also called the system code!!!**

## 6.3. Programming and Reprogramming of a User Code

The programming of the user codes is just possible if the locks are open.

configuration usercodes	Select the menu item ' <b>User Codes</b> ' (see menu plan, 4.2.)	
usercodes programming	Select programming	
Usercodes lock 01	Select the lock	
old M/U code user: xx	Enter the user number.	
old M/U code code:*****	Enter the old unlocking code (user codes) or master code	
programming user no.: xx	Enter the user number of the user code to be programmed	
new usercodes code:*****	Enter the new unlocking code	
confirm code code:*****	Re-enter the new unlocking code	
usercodes please wait		
usercode xx saved	The new user code is saved	

Automatic return after 3 seconds

### User codes

A user can reprogram his/her user code autonomously. Otherwise, the user only has an unlocking authorization.

When a user code is programmed for the first time, the master code has to be entered first.

### Attention:

**When programming the code you must see to it that the new unlocking code is checked repeatedly while the safe is open.  
Do not use personal data when programming a code**



## 6.4. Delete a user code

```
usercodes
delete
```

Select menu item '**Delete user codes**' (see menu diagram, 4.2.)

```
delete
lock 01
```

Select lock

```
Code entry
user no.: 00
```

Enter the user number 00 for the master code

```
old M/U code
code:*****
```

Enter the master code of the selected lock

```
delete
user no.: xx
```





Select the user to be deleted

```
delete
please wait
```

The selected user is deleted

```
usercode xx
deleted
```

Action completed







Automatic return after 3 seconds

Only the according owner of the master code can delete user codes. This action is saved in the event log.

The function itself can only be performed at the control unit.

## 6.5. Display the Programmed User Codes

<p>Usercodes Anzeige Usercode</p>	<p>Select the menu item '<b>Display User Code</b>' ( see menu plan 4.2</p>	
<p>Usercodes Schloss 01</p>	<p>Select the lock</p>	
<p>Mastercodes Code:*****</p>	<p>Enter the master code of the selected lock</p>	
<p>Mastercodes Bitte warten</p>	<p>Evaluate the entry</p>	
<p>Prog.U-Codes 03 U-Code 01: OK</p>	<p>Navigate through the user numbers Use the arrow keys (&lt; &gt;) Terminate with ENTER/CLEAR</p>	

### Display the Programmed User Codes

For each lock, the users can be displayed, which were entered in it. This means that not the codes themselves are displayed, but the status (programmed, not programmed).


The display of a programmed user code can only take place by entering the according master code of the lock.

<p>Prog.U-Codes 03 Usercode 01: OK</p>	<p><i>Comment:</i>  <b>1. line:</b>      <i>Number of programmed user codes for this lock</i>   <i>e.g. progr. u codes 03: Three user codes are programmed all in all</i></p> <p><b>2. line:</b> <i>Displays which user code is programmed:</i>  <i>OK = programmed</i>  <i>NOK = not programmed</i>   <i>e.g. u code 01: OK</i>  <i>User code 01 is programmed</i></p>
--	---

## 6.6. Setting the Date, Time and Weekday


configuration  
date/time

Select the menu item '**Date/Time**'  
(see menu plan 4.2)



System Code  
Code:\*\*\*\*\*

Enter system code





System code  
Please wait

Evaluate the entry

time: 10:01 Mo  
date: 20.12.07

Select time-date/weekday  
Display current settings  
Activate the entry with enter  
Set the day of the week with menu keys



time: 12:00 Mo  
date: 18.08.07

Re-enter date,  
time or weekday

date/time  
saved

Action completed

### Date/Time


The date/time/weekday can only be changed by the owner of the system code. This action is saved in the event log.

#### Attention:



**The correct setting of the date/time/weekday is the basis for all timer programs in the system or the event log to run properly.**

## 6.7. Code Linkage Programming (Four-Eye-Code)



Automatic return after 3 seconds

### Code linkage


When code linkage was selected (four-eye code), the lock can only be unlocked or programmed by entering 2 codes. The arrangement of the 2 codes is random.

The function applies to the entire system, i.e. each lock must be unlocked with 2 codes, when code linkage is activated.

The programming of this function can only be performed by the owner of the system code and is saved in the event log!

After the 4-eyes principle has been activated, the system code also has to be entered in connection with a second code (user code) for programming.

## 6.8. Program Unlocking Time Delay



Automatic return after 3 seconds

### Time Delay for Unlocking:

This function delays the unlocking procedure when the code is entered correctly. The time is entered in minutes (00-99). A time delay can be entered for each lock.

### Release time:


The release time is used to safeguard the time delay. If a release time was programmed (e.g. >00), a correct unlocking code must be entered after the time delay has expired, to finally open the lock.

The release time is set in minutes (00-99) and specifies the period, during which the user can re-enter the unlocking code after the time delay has expired. If no release was programmed (00), the lock will open without re-entering the code after the time delay has expired.

The programming of this function can only be performed by the owner of the system code and is saved in the event log!

Factory setting:                      Time: 00 Rel.: 00 (deactivated)

## 6.9. Program Opening Duress (Forced Sequence)



Automatic return after 3 seconds

### Opening Duress (Forced Sequence)

Programming the function 'Opening Duress' determines the unlocking or locking sequence.

The system is in unlocked state only when all locks are open. It will be in a locked state if all locks are closed.

Opening sequence: lock 1, lock 2 (system unblocked)

Locking sequence: lock 2, lock 1 (system locked)

The programming of this function can only be performed by the owner of the system code and is saved in the event log!


Factory setting:

No opening duress, no forced sequence (= No).

#### Note:

**This function is only possible with a 2-lock system.**

## 6.10. Program silent alarm



Automatic return after 3 seconds

### Silent alarm

A silent alarm is indicated via the alarm output of the arming device (relay output).

When the function is activated, a silent alarm is triggered by entering a valid unlocking code (last code digit +1, see example) and stored in the event log.


A time delay can be set (00-99 min), which is only activated during the triggering of an alarm. The defined release time of the programmed „normal“ time delay is used as release time.

The function 'Silent alarm' can only be performed by the owner of the system code and is saved in the event log.

Example:

User code: 1-2-3-4-5-6 >> alarm code 1-2-3-4-5-7  
 (9 becomes 0!)

## 6.11. Programming activation of TwinXT lock I/O



Automatic return after 3 seconds

### Lock I/O

The inputs or outputs of the locks can be programmed by means of the system code  
The following functionality (**blocking element**) can be achieved:

Input functions:

- \* Locking feature (contact for external release/blocking of the lock)
- \* Locking after bolt contact query

Output functions:

- \* Silent alarm (relay contact for silent alarm messages)
- \* Display of the lock bolt position (relay contact)

This programming action is saved in the event log!

Factory setting:

TwinXT inactive


Release and bolt system contact = high active



## 6.12. Reset the Input Unit

System  
Reset

Select the menu item '**System Reset**'  
(see menu plan 4.2.)




System code  
Code:\*\*\*\*\*

Enter system code

System code  
Please wait

Evaluate the entry



Reset  
saved

Action completed

Automatic return after 3 seconds

### System reset:


Only the owner of the manager code can perform the system reset. The following settings are reset to factory defaults:

Unlocking delay	Inactive
System line	TwinLock compact
Battery warning limit	8,0V
Code linkage	1 User
Locks	0
Parallel code	Inactive
Forced Sequence	Inactive
/ Opening Duress	
Quick unlocking code	user 09

Only the control unit is reset. This means that all settings which are stored in the control unit are reset to factory defaults. The locks are not reset during this procedure and therefore maintain their allocations.

After a control unit has been reset, it is restarted. The system sends a prompt for re-registering.


```
System-Setup
New system
```



To re-integrate the existing locks into the system, the menu item "Terminal switch" must be activated using the arrow keys.


```
System setup
Terminal switch
```

Switch to "Terminal switch".  
Acknowledge with Enter




```
System-Setup
Terminal No.: 01<
```

Select the number of the control unit.  
Acknowledge with Enter.  
(Usually always: 01)



```
System Setup
No. DMS : 01<
```

Select the number of locks  
available in the system.  
Acknowledge with Enter.



```
System code
Code: *****
```

To assign a serial number, the system code of the lock or locks must be entered (e.g. 1 1 1 1 1 1).



```
Serial number
Please wait
```

The serial number is transmitted to the lock.

```
Serial number
saved
```

The serial number has been stored in the lock.


For the 2nd lock, the master code of lock 2 has to be entered.

After all data is entered, a system check is performed and the system is operational.

## 6.13. Lock Motor Service


Service  
Motor-Service

Select the menu item **'Motor service'**  
(see menu plan 4.2)




Motor service  
Lock 01

Select the lock




Master code  
Code:\*\*\*\*\*

Enter the master code of the  
selected lock



Master code  
Please wait

Evaluate the entry



Motor service  
<=Open Closed=>

Open and close gradually  
Cancel with ENTER/CLEAR

Automatic return after 150 seconds

### Gradual opening and closing:

With this function, the lock can be opened and closed gradually for service purposes. This function can only be activated or performed by the owner of the according master code of the according lock. The user has 150 seconds to the next motor step. If no key is pressed, the function is cancelled.

The gradual opening or closing of the lock bolt is only meant for service purposes and can only be performed in an unlocked system state.

After this function is completed, it is stored in the event log.


## 6.14. Register/Replace Locks in the System

Service  
Reg. lock

Select the menu item '**Reg. lock**'  
(see menu plan 4.2)

System code  
Code:\*\*\*\*\*

Enter system code



System code  
Please wait

Evaluate the entry


SReg. lock  
New lock

Reg. lock  
Replace lock

Selection: Re-register  
or replace a lock

Replace lock  
Lock 01

Select the lock to  
be replaced



!!Bus cable on!!

Connect both bus cables of the according  
lock to TwinConnect  
and acknowledge with ENTER

System code  
Code: \*\*\*\*\*

To allocate the serial number, the system code  
of the new lock must be entered.  
(1 1 1 1 1 1)

Serial number  
Please wait

The serial number is transferred to the lock

Reg. lock  
Lock 02 OK

Detect and initialize the lock  
Acknowledge the lock number









Automatic return after 3 seconds

### Re-registering/replacing of locks:

Only the owner of the system code can re-register or replace a lock. This action is stored in the event log.

A maximum of 2 locks can be registered!

## 6.15. Write Log and Configuration to Chip Card

<p>TwinLock compact Import / Export</p>	<p>Select the menu item 'Import / Export' (see menu plan 4.2)</p>	
<p>Systemcode Code:*****</p>	<p>Enter System Code</p>	
<p>System code Please wait</p>	<p>Evaluate the entry</p>	
<p>Import / Export Daten - Export</p>	<p>Select data export with the menu keys</p>	
<p>Data export Insert card</p>	<p>Insert the TwinCard configuration</p>	
<p>Data export Configuration</p>	<p>Select Export configuration</p>	
<p>Write data &gt;&gt;&gt;&gt;&gt;&gt;</p>	<p>Data is written to the chip card</p>	
<p>Daten - Export Remove card</p>	<p>Remove card</p>	

The data can be read by means of the **Configuration set TwinComm** and can be processed further.

The data export procedure is stored in the event log.

## 6.16. Write Log and Configuration to Chip Card

```
*** TwinLock ***
Import / Export
```

Select the menu item **'Import / Export'**  
(see menu plan 4.2/ see above)


```
System code
Code:*****
```

Enter system code



```
System code
Please wait
```

Evaluate the entry



```
Import / Export
Data - Export
```

Select data export with the menu keys


```
Data export
Insert card
```

Insert the TwinCard configuration



```
Data export
Configuration
```

Select Export configuration



```
Write data
>>>>>
```

Data is written to the chip card

```
Data export
Remove card
```

Remove card

The data can be read by means of the **Configuration set TwinComm** and can be processed further.

The data export procedure is stored in the event log.

## 6.17. Read New System Language


To switch the language of your system, you need an according **TwinCard language**. The language cards can be ordered on request.

```
*** TwinLock ***
Import / Export
```

Select the menu item **'Import / Export'**  
(see menu plan 4.2)


```
System code
Code:*****
```

Enter system code



```
System code
Please wait
```

Evaluate the entry



```
Import / Export
Data import
```

Select data import with the menu keys

Insert the TwinCard language




```
Data import
Insert card
```

Select Export configuration

```
Data import
Language
```

Data is read from the chip card into the system



```
Read data
>>>>>>
```

Remove card

```
Data import
Remove card
```

The data import procedure is stored in the event log.  
The new language is activated immediately after the card has been read

## 6.18. Ignore Bolt System Position Switch



System  
Central inactive

Central inactive  
\*= Yes \*=No

Central inactive  
Stored

Select "Yes"

The setting is stored



The bolt system position switch, which may be connected to TwinAlarm or TwinXT, is ignored for one locking procedure.


This means that the system can still be locked properly even if the switch is damaged.

### Note:

**In any case, the customer service should be informed!**



## 6.19. Activate Parallel Code



### Notes:

**Only possible, if there are 2 or 3 locks in the system**



Unlocking procedure:

During the unlocking procedure, the status of lock 01 is queried first. If lock 01 is closed, an unlocking code must be entered without selecting lock 01 beforehand. If lock 01 is open, the condition of lock 02 is automatically queried. When lock 02 is closed, an unlocking code must be entered without selecting lock 02 beforehand. Lock 02 unlocks.

### Programming of the codes

In all locks, the same codes must be programmed for the according users,

e.g.

User 08:                      Code: Lock 1: 080808  
                                     Code: Lock 2: 080808

### Notes:

1. For this functionality, the explicit four-eye code (code linkage) is deactivated.
2. This function is only approved for 2 lock operation.

## 6.20. Automatic Locking

The TwinLock system can be automatically locked using a door switch or a bolt system position switch. The switch is connected to a TwinXT or TwinAlarm system, depending on the system variant.

In idle state (display off), the door or bolt system switch is queried periodically. Pressing the key will automatically lock the system.

### Connection to TwinXT

***The following connections and settings must be performed:***

- Connect the switch at the terminals of the bolt system position switch (see assembly instructions). For a two lock system, the terminals of the bolt system position switch must be bridged for lock 1 and 2.
- Activate TwinXT (via the menu or the PC software)
- Set the forced sequence (via the menu or the PC software TwinComm)
- Setting the switching status for the locking (via PC software TwinComm)
  - Active low => when the contact is closed -> System locks
  - Active high => when the contact is open -> System locks
- Setting: Automatic locking with door switch (via PC software TwinComm)
- Optional: Combination with partial blocking time (via PC software TwinComm)

## 7. Programming the System with the PC Software TwinComm



The following functions can be performed with the configuration software TwinComm.

### **General settings**

- Silent alarm, alarm delay
- TwinXT active
- Automatic switching to daylight savings time
- Quick unlocking code
- Four-eye-principle
- Parallel code
- Lock after bolt system contact query
- Automatic locking with door switch
- Quick unlocking code
- System line
- Battery warning limit

### **Timer Programs**

- Alarm time delay
- Time delay, release time

### **Managing functions**

- Customer data
- User data
- Menu simulator and menu wizard

## 7.1. General Operation

### License chip card

To activate the PC software you will need a license chip card, which is a part of the scope of delivery of the configuration set. After TwinComm is started, this card must be inserted into the chip card reader.



After the license chip card has been read, the according locking system can be selected. (-> **TwinLock compact**)

### Start screen



Before the chip card reader is used, the serial interface to which the reader is connected must be activated.

The setting is done in the menu "**Chip card -> Configure**". Or the user is prompted to select the interface when the PC software starts for the first time.




To read the data from the chip card “**TwinCard configuration**“, it must be inserted into the chip card reader. Then push the button “**Read chip card**”.

To save the data to the chip card “**TwinCard configuration**“, it must be inserted into the chip card reader. Then push the button “**Write chip card**”.



## 7.2. Programming of General Settings



### Code linkage

Programming the four-eye code principle  
For unlocking and programming, 2 code entries each are required

### Activate TwinXT

Lock I/O. The inputs and outputs of the extension unit TwinXT are activated and queried. TwinXT must be activated for the function of automatic locking with door switch.

### Parallel code

Only possible, if there are 2 or 3 locks in the system

#### Unlocking procedure:

During the unlocking procedure, the status of lock 01 is queried first. When lock 01 is closed, an unlocking code must be entered without selecting lock 01 beforehand.

When lock 01 is open, the condition of lock 02 is queried automatically. When lock 02 is closed, an unlocking code must be entered without selecting lock 02 beforehand. Lock 02 unlocks.

## Programming of the codes

In all locks, the same codes must be programmed for the according users, e.g.

user 08:                   Code : lock 1 : 080808  
                                  Code : lock 2 : 080808

## Notes:

1. For this functionality, the explicit four-eye code (code linkage) is deactivated.
2. This function is only approved for 2 locks operation.

## Quick unlocking code

A user code that skips the unlocking delay can be defined as quick unlocking code.

## General

not with TwinLock compact  
except for forced sequence

## Forced sequence / Opening Duress

programmable, i.e. the unlocking and locking sequence.

Unlocking: Lock 01 -> Lock 02

Locking: Lock 02 -> Lock 01

## Battery warning limit:

With this function, the threshold of the battery warning can be set between 6.8 V and 9.3 V. Critical dropping of the supply voltage is automatically detected and the following message is displayed:

```
*** TwinLock ***  
!!! Low Batt !!!
```

## Switching to Daylight savings time:

The time is automatically switched at the last weekend in March and at the last weekend in October.

## Automatic locking a door switch

Automatic locking with  
bolt system or door switch.

For this action, the function **TwinXT active** must be programmed.

## Manual locking after bolt system query

Before the locking procedure, the position of the bolt system is queried using a switch. For this action, the functions **TwinXT active** must be programmed.

## TwinAlarm active

not with TwinLock compact

## Silent alarm

Activate silent alarm, time delay  
01-99 minutes

## BAS level

not with TwinLock compact

## Arming with code card


not with TwinLock compact

## System line:

The system line is displayed in the 1st. line of the main menu, on the display of the control unit. It can be changed and set as required anytime.




## 7.3. Programming the Unlocking Delay



For each lock, an unlocking delay of 01 – 99 minutes can be programmed. A release time of 01 – 15 minutes can be programmed as well, during which a code entry must take place after the unlocking delay has expired.

Unlocking delay = 00      No unlocking delay  
Release time = 00      No code entry after unlocking delay  
                                 The lock is immediately unlocked

## 7.4. Display Event Log




### The following events are logged:

All unlocking and locking procedures and all code entries are logged. Furthermore, all configuration procedures and manipulation attempts are logged.


The log list can be printed on a connected printer or saved and archived in a file.

Use the button "Update user" to display the according user names after the log is being read, if the users were entered.

## 7.5. User Data Management




Each user of the lock can be allocated a name which is also saved in the event log.



The user overview can be printed or saved for administrative purposes.

## 7.6. Customer Data Management



Customer data can be saved and archived for each programming. This means that an individual configuration file can be created for each customer. This file can be read also at a later date.

## 8. Technical Data

### Input Unit: FlatControl

Power supply:	9 VDC Alternatively, power supply unit 12 VDC via TwinConnect Alternatively emergency power supply via mini DC jack
Current consumption:	Stand-by condition: approx. 30 $\mu$ A Input condition (display active) approx. 55mA
Dimensions:	3.54 x 2.40 x 1.34 inches (L x W x H)
Environment:	32°F - 122°F, 75% RH Environment class II according to VdS
Protection class:	IP 30

### Schloss : TwinLock compact

Power supply:	9VDC
Current consumption:	Idle state: ca. 40 $\mu$ A Motor operation (without bolt load): approx. 110 mA
Dimensions:	90 x 61 x 34 mm (L x B x H)
Environment:	0-50°C, 75% r.F Umweltklasse II nach VdS
Protection class:	IP 30

### Bus distributor: TwinConnect

Power Supply	12 VDC (optional)
Current consumption	For power supply operation 12 VDC: Approx. 9 mA Only as distributor: 0 mA
Dimensions:	3.94 x 2.36 x 0.98 inches (L x W x H)
Environment:	32°F - 122°F, 75% RH Environment class II according to VdS
Protection class:	IP 30

### Extension Unit: TwinXT

Power Supply	12 VDC (optional) Only for output relay operation
Current consumption	For power supply operation 12 VDC: Approx. 20 mA Per relay Only when the inputs are used: 0 mA
Dimensions:	3.94 x 2.36 x 0.98 inches (L x W x H)
Environment:	32°F - 122°F, 75% RH Environment class II according to VdS
Protection class:	IP 30

## Revision History

Version	Date	Modification	Name
1.00		First edition	MB
1.01	04.07.05	Update	MB
1.02	08.05.06	New name TwinLock compact	MB
1.03	04.10.06	Update	ES/GH
1.04	30.10.06	update TwinCards	ES
1.05	07.12.06	Update	MB
1.06	15.09.08	Update user terminal and number of users	MR

!!! Subject to correction !!!

## Support / Hotline

### **Carl Wittkopp GmbH & Co. KG**

Sternbergstr. 5

D – 42551 Velbert

Tel.: +49(0)2051 – 9566-0

Fax.: +49(0)2051 – 9566-66

[www.cawi.com](http://www.cawi.com)

### **INSYS Microelectronics GmbH**

Waffnergasse 8

D – 93047 Regensburg

Tel.: +49(0)941 – 58692-22

Fax.: +49(0)941 – 563471

[www.insys-security.de](http://www.insys-security.de)