



# **RMU2**

## **Linux Logic Controller**

### **User Manual**

**Control & Information Technology Group  
134 W Rio Robles Drive  
San Jose, CA 95134**

**Main: 408.750.0300  
Fax: 408.750.2990**

**Manual Rev. 09  
03/2010**

## **Copyright**

This manual and the software described in it are copyrighted with all rights reserved. Under the copyright laws, this manual and software may not be copied, in whole or part, without the prior written consent of MKS Instruments. The same proprietary and copyright notices must be affixed to any permitted copies as were affixed to the original. This exception does not allow copies to be made for others whether or not sold, but all of the materials purchased may be sold, given, or loaned to another person. Under the law, copying includes translating into another language or format.

© MKS Instruments - CIT Products Group, 2010

## **Preface**

### **About this manual**

This manual is designed to serve as a guideline for the installation, setup, operation and basic maintenance of the RMU device. The information contained within this manual, including product specifications, is subject to change without notice. Please observe all safety precautions and use appropriate procedures when handling the RMU product and its related software.

## Table of Contents

<b>1</b>	<b>INTRODUCTION.....</b>	<b>6</b>
1.1	CONVENTIONS USED IN THIS USER MANUAL.....	6
<b>2</b>	<b>INSTALLATION AND SETUP .....</b>	<b>7</b>
2.1	SHIPPING BOX CONTENTS.....	7
2.2	RMU DESCRIPTION .....	7
2.3	MECHANICAL DESCRIPTION.....	8
2.4	INSTALLATION.....	8
2.5	WIRING AND HARDWARE CONFIGURATION .....	9
2.5.1	<i>Power Supply Wiring</i> .....	9
2.5.2	<i>Analog I/O Wiring</i> .....	10
2.5.3	<i>Digital I/O Wiring</i> .....	11
2.5.4	<i>Combo I/O Wiring</i> .....	12
2.6	DIGITAL INPUTS.....	13
2.7	DIGITAL INPUT INTERFACE EXAMPLE .....	14
2.8	DIGITAL OUTPUTS.....	14
2.9	DIGITAL OUTPUT INTERFACE EXAMPLE.....	14
2.10	ANALOG INPUTS.....	15
2.11	ANALOG OUTPUTS.....	15
2.12	SERIAL PORT CONNECTIONS.....	16
2.12.1	<i>COM1 and COM2</i> .....	16
2.12.2	<i>COM3 and COM4</i> .....	16
2.13	STANDARD RS232 SERIAL CABLE WITH HANDSHAKING CONNECTION.....	18
<b>3</b>	<b>QUICK-START.....</b>	<b>19</b>
3.1	TELNET.....	19
3.2	SERIAL CONNECTION.....	20
3.3	CONFIGURATION.....	20
3.4	BOOTING THE RMU.....	20
<b>4</b>	<b>RMU SOFTWARE USER'S GUIDE .....</b>	<b>21</b>
4.1	SYSTEM COMPONENTS.....	21
4.1.1	<i>Boot Loader</i> .....	21
4.1.2	<i>Kernel</i> .....	22
4.1.3	<i>The built-in Initrd File System</i> .....	22
4.1.4	<i>JFFS2</i> .....	23
4.1.5	<i>Compact Flash</i> .....	23
4.1.6	<i>Kernel's Modules</i> .....	23
4.1.7	<i>Cross Platform Development Tools</i> .....	24
4.1.8	<i>Creating my first application</i> .....	25
4.2	RUN-TIME PLATFORM.....	26
4.2.1	<i>Boot procedure</i> .....	26
4.2.2	<i>Configuration</i> .....	26
4.2.3	<i>Storage</i> .....	32
4.3	WEB SERVER.....	34
<b>5</b>	<b>DIO API.....</b>	<b>34</b>
5.1	DEVICE APIS.....	35
5.1.1	<i>Overview</i> .....	35
5.1.2	<i>Basic procedures</i> .....	36
5.1.3	<i>ASCII Interface</i> .....	37
5.1.4	<i>Binary Interface</i> .....	37
5.2	FUNCTION DEFINITIONS.....	37
5.2.1	<i>Open()</i> .....	37
5.2.2	<i>Close()</i> .....	38
5.2.3	<i>Read()</i> .....	38

5.2.4	<i>Write()</i> .....	40
5.2.5	<i>ioctl()</i> .....	42
<b>6</b>	<b>AIO API</b> .....	<b>43</b>
6.1	BASIC PROCEDURES .....	44
6.2	TRANSLATING READS & WRITES .....	45
6.3	FUNCTION DEFINITIONS .....	45
6.3.1	<i>Open()</i> .....	45
6.3.2	<i>Close()</i> .....	46
6.3.3	<i>Read()</i> .....	46
6.3.4	<i>Write()</i> .....	47
6.4	MKSAIO.H .....	48
6.5	SAMPLE CODE .....	50
<b>7</b>	<b>MMI API</b> .....	<b>51</b>
7.1	AT89 API .....	51
7.1.1	<i>Function Definitions</i> .....	52
7.2	AT89DISPLAY API .....	54
7.2.1	<i>Function Definitions</i> .....	54
7.3	AT89BUTTONS API .....	57
7.3.1	<i>Function Definitions</i> .....	57
<b>8</b>	<b>RS-485</b> .....	<b>60</b>
<b>APPENDIX A: POSIX FUNCTIONS DESCRIPTION</b> .....		<b>61</b>
1.	FUNCTION "OPEN" .....	61
2.	FUNCTION "CLOSE" .....	65
NAME	.....	65
SYNOPSIS	.....	65
DESCRIPTION	.....	65
RETURN VALUE	.....	65
ERRORS	.....	65
CONFORMING TO	.....	65
NOTES	.....	65
SEE ALSO	.....	65
3.	FUNCTION "READ" .....	66
NAME	.....	66
SYNOPSIS	.....	66
DESCRIPTION	.....	66
RETURN VALUE	.....	66
ERRORS	.....	66
CONFORMING TO	.....	66
RESTRICTIONS	.....	66
SEE ALSO	.....	66
4.	FUNCTION "WRITE" .....	67
NAME	.....	67
SYNOPSIS	.....	67
DESCRIPTION	.....	67
RETURN VALUE	.....	67
ERRORS	.....	67
CONFORMING TO	.....	67
NOTES	.....	67
SEE ALSO	.....	67
5.	FUNCTION "IOCTL" .....	68
NAME	.....	68
SYNOPSIS	.....	68
DESCRIPTION	.....	68

**RMU2 User Manual**

---

RETURN VALUE ..... 68  
ERRORS ..... 68  
NOTE ..... 68  
CONFORMING TO ..... 68  
SEE ALSO ..... 68  
**APPENDIX B: HOW TO CROSS-COMPILE TCPDUMP ..... 69**  
**APPENDIX C: HOW TO CROSS-COMPILE BOA WEB SERVER ..... 70**  
**SPECIFICATIONS ..... 71**  
**WARRANTY ..... 74**

# 1 Introduction

The RMU is an open control platform that allows customers to run MKS or customer specific applications in Linux environment. The platform consists of a PowerPC processor, local peripherals, and PCI IO and special function cards. All IO boards communicate using the PCI-104 bus. This manual provides details on the installation and use of this product.

The RMU supports at maximum, the following features:

- PowerPC running at 400 MHz, 760 MIPS with support of floating point instructions
- 16 MB of on board Flash using the Linux Journaling file system.
- On Board compact flash socket for CF type 2 devices for application and data storage.
- 128MB SDRAM
- Power Conditioning (18 – 30V)
- 4 RS232 interface. (1 port used for diagnostics port, software selectable 485 on 2 of ports)
- 2 independent 10/100 Ethernet ports
- USB V1.1
- Up to 96 DIO Points
- Up to 64 Analog input points and 32 Output point

## 1.1 Conventions used in this User Manual



**Warning**

The **WARNING** sign denotes a hazard to personnel. It calls attention to a procedure, practice, condition, or the like, which, if not correctly performed or adhered to, could result in injury to personnel.



**Caution**

The **CAUTION** sign highlights information that is important to the safe operation of the RMU, or to the integrity of your files. .



**Note**

**THE NOTE SIGN DENOTES IMPORTANT INFORMATION. IT CALLS ATTENTION TO A PROCEDURE, PRACTICE, CONDITION, OR THE LIKE, WHICH IS ESSENTIAL TO HIGHLIGHT.**

On screen buttons or menu items appear in bold and cursive.  
Example: Click ***OK*** to save the settings.

Keyboard keys appear in brackets.  
Example: [ENTER] and [CTRL]

Pages with additional information about a specific topic are cross-referenced within the text.

## 2 Installation and Setup

### 2.1 Shipping Box Contents

- RMU Module
- Power mating connector

### 2.2 RMU Description

The RMU is a compact, Linux controller with integrated I/O and peripherals. The CPU will have Linux kernel 2.4.x. All required kernel drivers are preloaded to support current hardware requirements.

There are 5 RMU packages, each to accommodate the number of I/O slots (0-4) Each I/O card to have a D-sub 37 connector, top and bottom. Each cards connectors to be in the same location, so enclosure cutouts are the same for a DIDO or AIAO card.

The front of the RMU provides all operators interface and status indicators. The figure below describes the features on the front panel. These items include I/O indicators, fuses, IP address switches, and diagnostic ports.

The following mechanical drawing is a typical 2 expansion slot model.




Figure 1 RMU Description

## 2.3 Mechanical Description

The following mechanical drawing describes a typical 2 slot configuration. Additional slots will cause the unit to be wider but will not change height or depth. Addition mechanical information for other configurations can be obtained through your local MKS representative




Figure 2 Mechanical Description



Note

ALL DIMENSIONS ARE METRIC

## 2.4 Installation

The RMU mounts on a standard 35mm DIN rail system. Make sure there is sufficient side clearance for ventilation, to maintain an ambient operating temperature of 0°C to 50°C.




Figure 3 RMU DIN Rail Mounting




## 2.5 Wiring and Hardware Configuration

Ethernet and I/O cables are available from a variety of industrial sources. See table below for orderable I/O mating connectors. Example mating connector for the RMU IO is provided in Table 1

Table 1 Mating IO Connector Information

Description	MFG	Part Number
37-pin D-SUB with Shell (Terminal Block Connections)	Phoenix	2300986




**Caution** In order to guarantee proper operation and prevent damage to the product insure that the chassis ground is properly attached for the application.



**Warning** Follow all applicable electrical codes when mounting and wiring any electrical device.

### 2.5.1 Power Supply Wiring

Connect an external 18-30 VDC power supply to the 3-terminal Power Connector. The connector should be wired according to the labeling on the RMU.



Pin	Signal
1	18-30 VDC
2	Chassis GND
3	GND

Figure 4 Power Terminal Block


The manufacturer and ordering part number for the RMU power terminal block connector is described in Table 3.

Table 2 Terminal Block Information

Description	MFG	Part Number
3-pin Terminal Block	Weidmuller	1625620000


## 2.5.2 Analog I/O Wiring

The RMU analog expansion board has two D-Sub 37 connectors used to access the I/O points. Each I/O card type has unique pin assignments; the assignments for the analog card are shown in the following figures.




### Analog Inputs – Differential Mode

#### Top Side Connector



### Analog Inputs – Single Ended Mode

#### Top Side Connector



### Analog Outputs

#### Bottom Side Connector




#### Note

**ALL ANALOG POWER COMES FROM AN INTERNAL POWER CONVERTER. EXTERNAL PINS FOR +/- 15 VOLTS SHOULD BE USED AS REFERENCE ONLY. SUPPLIES HAVE LIMITED POWER AND SHOULD NOT BE USED TO DRIVE EXTERNAL LOADS.**

### 2.5.3 Digital I/O Wiring


The RMU digital expansion board has two D-Sub 37 connectors used to access the I/O points. The +24V power must be supplied by an external source via these connectors. Each I/O card type has unique pin assignments; the assignments for the digital card are shown in the following figures. All the 24 GNDs are one net.



**Digital Top Side Connector**

**Source/Sink Select for Digital Top Connector**

Sink/Source Select	
Sourcing Input/Sinking Output	Short Pin 18 to 37
Sinking Input/Sourcing Output	Short Pin 19 to 37




**Digital Bottom Side Connector**

**Source/Sink Select for Digital Bottom Connector**

Sink/Source Select	
Sourcing Input/Sinking Output	Short Pin 18 to 37
Sinking Input/Sourcing Output	Short Pin 19 to 37

## 2.5.4 Combo I/O Wiring


The Combo I/O Expansion Card has two 37-pin D-Sub connectors used to access the I/O points. The +24V power must be supplied by an external source via these connectors. The +/- 15V power is supplied by an internal converter. The pin assignments are shown in the following tables. All the 24 GNDs are one net.



**Combo Top Side Connector**

### Source/Sink Select for Combo Top Connector


Sink/Source Select	
Sourcing Input/Sinking Output	Short Pin 18 to 37
Sinking Input/Sourcing Output	Short Pin 19 to 37



**Combo Bottom Side Connector**

### Source/Sink Select for Combo Bottom Connector

Sink/Source Select	
Sourcing Input/Sinking Output	Short Pin 18 to 37
Sinking Input/Sourcing Output	Short Pin 19 to 37



**Combo Bottom Side Connector (Differential)**

**Source/Sink Select for Combo Bottom Connector**

Sink/Source Select	
Sourcing Input/Sinking Output	Short Pin 18 to 37
Sinking Input/Sourcing Output	Short Pin 19 to 37




**Note**


**ALL ANALOG POWER COMES FROM AN INTERNAL POWER CONVERTER. EXTERNAL PINS FOR +/- 15 VOLTS SHOULD BE USED AS REFERENCE ONLY. SUPPLIES HAVE LIMITED POWER AND SHOULD NOT BE USED TO DRIVE EXTERNAL LOADS**

## 2.6 Digital Inputs

Digital I/O can be configured as either sinking or sourcing I/O. Each input circuit includes an indicator LED in series with the detection opto-coupler. The opto-coupler isolates the processor from the inputs. The inputs require 1.5mA in order to turn on.



**Figure 4 Sourcing Input**



**Figure 5 Sinking Input**

## 2.7 Digital Input Interface Example

Below is an example of how to use the digital input interface for both the sinking and sourcing hardware configurations. The digital I/O circuitry is powered from an external +24-volt power source via the I/O connector.




Figure 6 Sourcing Input




Figure 7 Sinking Input

## 2.8 Digital Outputs

The individual outputs will support up to a 200 mA load per channel. Each output is thermally protected against short-circuiting (500 mA typically) and includes under voltage protection. The output Fault State is accessible through software. External Schottky diodes are provided for output transient protection and each I/O point is protected with a self-resetting poly fuse rated for 500 mA. Outputs default to the OFF condition during power up and processor reset conditions. The figure below shows the output circuitry.






Figure 8 Digital Output

## 2.9 Digital Output Interface Example

Below is an example of how to interface with the digital outputs for both the sinking and sourcing hardware configurations. The digital I/O circuitry is again powered from an external +24-volt power source via the I/O connector.



Sinking Output



Sourcing Output

Figure 9

## 2.10 Analog Inputs

The analog inputs are coupled directly to the processor and are implemented using 14 bit A/D converters. The analog input range is  $-10V$  to  $+10V$ .

All analog circuitry is powered from an internal  $\pm 15V$ dc power source. The  $+15V$  and  $-15V$  power is protected with a self-resetting poly fuse rated at 100 mA.

**Table 3 Analog Voltage Conversion**

Conversion Table	
10 V	0x1FFF
5 V	0x0FFF
0.0012 V	0x0001
0 V	0x0000
-0.0012 V	0xFFFF
-5 V	0x2FFF
-10 V	0x2000

**Table 4 Analog Description**

Card Type	Number of Inputs	Type
Analog Expansion Card	16	Single ended inputs
Combo Expansion Card	8	Single ended inputs that can also be connected in pairs to create differential inputs. Particular pairs must be used (input 1-5, 2-6, 3-7, 4-8) if a differential input is required.

## 2.11 Analog Outputs

The analog outputs are implemented using 12 bit D/A's with a  $-10V$  to  $+10V$  output range. The output drivers are capable of driving 2 Kohm (5 mA) output loads. Analog outputs default to 0 volts during power up and processor reset conditions.

**Table 5 Analog Voltage Conversion**

Conversion Table	
10 V	0x0FFF
5 V	0x0BFF
0 V	0x07FF
-5 V	0x03FF
-10 V	0x0000

**Table 6 Analog Description**

Card Type	Number of Outputs	Type
Analog Expansion Card	8	Single ended outputs
Combo Expansion Card	2	Differential outputs

## 2.12 Serial Port Connections

The RMU2 contains 4 total serial communication ports. Connector is standard D-Sub 9 pin male. COM1 and COM2 are RS232 only. COM3 and COM4 are RS232/RS485 Software selectable.

### 2.12.1 COM1 and COM2

COM1 and COM2 only support simple RS232 protocol with no hardware flow control.

#### 2.12.1.1 Simple RS232 serial port connector's pin-out

Pin	RS232 Function	Description
2	RXD	Receive Data (a.k.a RD, Rx)
3	TXD	Transmit Data (a.k.a TD, Tx)
5	SGND	Ground
1, 4, 6-9	NC	No Connect

### 2.12.2 COM3 and COM4

COM3 and COM4 are RS232/RS485 Software Selectable. RS232 supports hardware flow control. RS485 supports both half and full-duplex mode.

**NOTES:** HW Flow Control for RS232 is only supported on COM 3 and COM4.

#### 2.12.2.1 RS232 serial port connector with HW flow control pin-out

(DTR/DSR signals are not supported and are shorted together internally)

Pin	RS232 Function	Description
1	DCD – No Connect	Data Carrier Detect ( <b>No Connect</b> )
2	RXD	Receive Data (a.k.a RD, Rx)
3	TXD	Transmit Data (a.k.a TD, Tx)
4	DTR	Data Terminal Ready (shorted to pin 6 internally)
5	SGND	Ground
6	DSR	Data Set Ready (shorted to pin 4 internally)
7	RTS	Request To Send
8	CTS	Clear To Send
9	RI – No Connect	Ring Indicator ( <b>No Connect</b> )



### 2.12.2.2 RS485 Half-Duplex port pin-outs

For RS485 half-duplex mode: pin2 and pin3 (TxD) need to be tied together. Pin7, pin8 (RxD) also need to be tied together.


Pin	RS485HD Function	Description
1	NC	No Connect
2	RS485-	Data Output (Need to short to pin 3 externally)
3	RS485-	Data Output (Need to short to pin 2 externally)
4	NC	Short to pin 6 internally
5	GND	Signal Ground
6	NC	Short to pin 4 internally
7	RS485+	Data Input (Need to short to pin 8 externally)
8	RS485+	Data Input (Need to short to pin 7 externally)
9	NC	No Connect

### 2.12.2.3 RS485 Full-Duplex port pin-outs

Pin	RS485FD Function	Description
1	NC	No Connect
2	RxD-	Data Input-
3	TxD-	Data Output-
4	NC	Short to pin 6 internally
5	GND	Signal Ground
6	NC	Short to pin 4 internally
7	TxD+	Data Output+
8	RxD+	Data Input+
9	NC	No Connect

### 2.13 Standard RS232 Serial Cable with handshaking connection

The figure below shows a female-female null modem with full handshaking connection. Only the ring indicator **RI** and carrier detect **CD** signal are not linked.



Connector 1	Connector 2	Function
2	3	Rx ← Tx
3	2	Tx → Rx
4	6	DTR → DSR
5	5	Signal ground
6	4	DSR ← DTR
7	8	RTS → CTS
8	7	CTS ← RTS

### 3 Quick-Start

This quick-start guide describes the basic requirements to connect the RMU to a PC, using Telnet and Serial interface.


Default network settings are:

Lan1 DHCP

Lan2 192.168.1.2

#### 3.1 Telnet


The unit can be accessed by “telnet” command to bring Linux console. From Windows Command Prompt, type “telnet <unit\_ip>”:



```
Command Prompt - cmd
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.
C:\>telnet 192.168.1.5_
```

Login: root

Password: root



```
Telnet 192.168.1.129
Linux 2.4.25-mks-rp-7.1 (RMU) (23:27 on Thursday, 01 February 2007)
RMU login: root
Password:
~ $ _
```

### 3.2 Serial Connection

Basic connections to the RMU consist of a null modem connection to COM 1 and power.

- Power up RMU by attaching power connector with 24VDC source, 1A.
- Attach a null modem cable to RMU COM1 port and your PC.

### 3.3 Configuration

The RMU's console is accessed through the PC RS232 serial Interface. Any terminal program will work; Hyperterminal is used in this documentation.

**Table 9 Serial Configuration**

Parameter	Value
Baudrate	115200
Data bits	8
Parity	None
Stop bits	1



### 3.4 Booting the RMU

Plug the power cable into the unit to start the boot process. Once the System has booted log in to Linux, the user is “root” and the password is “root”.

Users can use terminal program such as Microsoft® HyperTerminal or Tera Term Pro to communicate to the diagnostics port of the RMU (on Linux boxes minicom, c-kernel, cu, etc)



**Note**

**NOTE THAT SETTINGS CAN BE OVERWRITTEN BY CONFIGURATION FILES FROM APPLICATION PARTITION (SEE BELOW).**

## 4 RMU Software User's Guide

The RMU contains sixteen megabytes of FLASH memory. The first six megabytes contain:

1. Boot Loader (UBoot)
2. Linux Kernel (**version 2.4.25**) (compressed)
3. Initrd File System and data files image (compressed)

The next ten megabytes contain the Journaling Flash File System (JFFS2) that is used to store application programs and data.

### 4.1 System Components

#### 4.1.1 Boot Loader

The major functions of the boot loader are:

1. Initialize the basic board fundamentals peripherals.
2. Hold fundamental system parameters, such as MAC address and part number.
3. Interact with the console (RMU COM1) to start the boot process
4. Uncompress and copy the Linux Kernel to the RAM
5. Uncompress and copy the Initrd File system to the RAM to be used as the root file system ("/). The Initrd File system will be stored in RAM as a ram disk file system /dev/ram0.
6. Start the Kernel.

The user interface to U-Boot consists of a command line interrupter, much like a Linux shell prompt. When connected via a serial line you can interactively enter commands and see the results. After power on, the initial u-boot prompt looks similar to this:

```
U-Boot 1.1.3 (Aug 15 2005 - 15:08:45)
```

```
CPU: MPC5200 v2.1 at 396 MHz
```

```
Bus 132 MHz, IPB 66 MHz, PCI 33 MHz
```

```
Board: Motorola MPC5200 (IceCube)
```

```
I2C: 85 kHz, ready
```

```
DRAM: 128 MB
```

```
FLASH: 16 MB
```

```
PCI: Bus Dev VenId DevId Class Int
```

```
00 1d 1057 5809 0680 00
```

```
01 08 0458 0228 0e00 00
```

```
01 09 0458 0228 0e00 00
```

```
01 0a 0458 0228 0e00 00
```

```
01 0b 0458 0228 0e00 00
```

```
01 0c 10ec 8139 0200 00
```

```
00 1e 3388 0021 0604 ff
```

```
In: serial
```

```
Out: serial
```

```
Err: serial
```

```
Net: FEC ETHERNET, RTL8139#0
```

```
IDE: Bus 0: OK
```

```
Device 0: not available
```

```
Device 1: not available

Type "run flash_nfs" to mount root filesystem over NFS

Hit any key to stop autoboot: 0
=> <INTERRUPT>
=>
```

To access the U-boot prompt, stop Linux Kernel from booting by hitting any key before the timer prompt expires.

**help**, **printenv**, **setenv**, **saveenv** and **run** commands are available at U-boot shell.

Use **saveenv** command to save changed environment variables

```
=> saveenv
Saving Environment to Flash...
Un-Protected 1 sectors
Erasing Flash...
done
Erased 1 sectors
Writing to Flash... done
Protected 1 sectors
=>
```

Having a network connection on your boot loader is very convenient during development. All networked boards can download and boot the same kernel image from a centralized server, so user only needs to update a single copy of kernel on the server and not each board individually.

### 4.1.2 Kernel

The kernel is the core of the system; it controls all resources and processes. When the kernel starts, it determines which of the root file system is configured. The system can be brought up with one of two root file systems: initrd +JFFS2 or the Compact Flash. In both cases, the kernel will start the init process and read the inittab for more startup instructions.

### 4.1.3 The built-in Initrd File System

Initrd is a ram based file system that consists of the following folders:

bin	dev
lib	tmp
sbin	etc
mnt	proc
usr	var

The `initrd` is a volatile entity; therefore it's not the place for permanent settings. Any changes or additions to the file system will be lost when the system is rebooted. Permanent settings should use the Flash memory file system (JFFS2) which is mounted by the system startup to the `/mnt/ffs` VFS location. The `initrd` startup code creates "hooks" to the JFFS2 file system allowing permanent configuration.

#### 4.1.4 JFFS2

Journaling Flash File System (JFFS) version 2 is a standard file system for flash memory; it comes as a complementary sub file system to the `initrd`. JFFS basic directory hierarchy includes the `etc` and `lib` sub directories. Customization configuration files are under `etc` subdirectory. Additional kernel modules are under `lib` subdirectory. Unnecessary modules may be removed. The rest of the JFFS sub file system can be used as the user's application play ground.

Important files under `etc`:

- `network.conf`
- `rc.application`
- `rc.preconfig`

#### 4.1.5 Compact Flash

The RMU supplied a self contained unit, and as such include all the necessary tools and applications for development and maintenance. In addition, the RMU supports a compact flash that can be used for development or additional data storage.

An alternative way to run the system is to start the system from the removable Compact Flash. When the RMU boots-up it can be easily manipulated to continue the bootstrap sequence from the Compact Flash. In this case, the compact flash is used as the system root file system.

#### 4.1.6 Kernel's Modules

All supported devices are included in the monolithic part of the RMU kernel. Other drivers can be loaded into the kernel space by demand. These the kernel's modules are supplied as part of the bundle and can be located on the JFFS sub file system, under `/lib/modules/2.4.25-mks-rp-XX/`. It was intentionally placed on the JFFS to allow the removal of unneeded modules to allow additional storage space.

Modules can be loaded or removed with `insmod` and `rmmod` utilities, respectively. All current loaded modules and their dependencies are under `/proc/modules` file and can be seen with command "`cat /proc/modules`"

The following example illustrates how to access Windows 2000/XP/2003 file share. It is assumed that Windows computer has:

1. Shared directory called "RMU"
2. IP address: 192.168.1.3
3. Local user "rmu" with password "rmu" which has permissions to access the share

CIFS driver must be loaded to enable Windows file share connectivity.

CIFS can be loaded with the below command sets:

```
insmod cifs.o
mkdir /mnt/winxp
mount -t cifs cifs /mnt/winxp -o unc=//192.168.1.3/RMU,user=rmu,pass=rmu
```

Note that module needs to be loaded only once. If it is required to mount more Windows file shares, it is not necessary to run “insmod cifs.o” command.

To check if the module is loaded, use “lsmod” command:

```
lsmod

Module                Size  Used by  Tainted: GF
rt18150                8432    0 (unused)
cifs                   167256  0 (unused)
usb-storage            58992    0 (unused)
```

Use “rmmod” to remove a module:

```
rmmod cifs
```

### 4.1.7 Cross Platform Development Tools

To build applications to run on the RMU, acquire the DENX Software Engineering Embedded Linux Development Kit (ELDK) 3.1.1. The ELDK provides cross compilation tools to allow the user to develop RMU applications on ELDK supported host platforms. The ELDK 3.1.1 Tools can be obtained from DENX at <http://www.denx.de>. To correctly interface with the RMU kernel and the associated runtime libraries, it is imperative that the application code be build with ELDK 3.1.1 tools. The relevant architecture for the RMU is the **ppc\_82xx**. gcc version.

Pay attention to use the right set of tools. Make sure the ppc\_82xx binary directory is on the system PATH, and export the CROSS\_COMPILE environment variable to point to the **ppc\_82xx-** tools package.

Below is the link to obtain ELDK:

<http://www.denx.de/wiki/view/DULG/ELDKAvailability>

Alternative direct links to ISO image on different mirrors:

1. <ftp://mirror.switch.ch/mirror/eldk/eldk/3.1.1-2005-06-07/ppc-linux-x86/iso/ppc-2005-06-07.iso>
2. <http://mirror.switch.ch/ftp/mirror/eldk/eldk/3.1.1-2005-06-07/ppc-linux-x86/iso/ppc-2005-06-07.iso>



## 4.1.8 Creating my first application

Let's use the following example code *hello.c* as our first RMU's application, hello

```
#include <stdio.h>

int main( int argc, char* argv[])
{
    printf("Hello World!\n");
    return 0;
}
```

Target associated tools have to be used for cross compilation environment. Current RMU architecture under ELDK is the *ppc\_82xx*, make sure to set the system PATH and the CROSS\_COMPILE environment variables accordingly.

Assuming ELDK is installed to "/opt/eldk-3.1.1", here is what's needed to compile the application at the very minimum:

```
user@x86-pc$ export CROSS_COMPILE=ppc_82xx-
user@x86-pc$ /opt/eldk-3.1.1/usr/bin/ppc_82xx-gcc hello.c -o hello
```

if a static link is needed pass the *-static* flag to the linker. Now we can copy (FTP or NFS) the binary to the unit and execute it:

```
user@rmu# ./hello

Hello, world!
```

It is recommended to use special makefile to do cross-compilation. Here is an example of such a makefile ("Makefile.82xx"):

```
include Makefile

export CROSS_COMPILE=ppc_82xx-

PATH += /opt/eldk-3.1.1/usr/bin:/opt/eldk-3.1.1/bin
CC = ppc_82xx-g++
CXX = $(CC)
```

As you can see, this makefile includes the original makefile and overwrites the compiler definition.

Coming back to our first application, we need to create a makefile ("Makefile"):

```
hello: hello.o
clean:
    rm -f hello hello.o
```

Now we can compile the binary for x86 platform:

```
make clean; make
```

Or for RMU:

```
make clean; make -f Makefile.82xx
```

In order to get application to start when unit boots, its startup command needs to be added to “/mnt/ffs/etc/rc.application” file. Please, see section 4.2.2.3 for more details.

Please, see Appendix B and C for cross-compiling 3<sup>rd</sup> party packages with “configure” script.

## 4.2 Run-time platform

The run time platform refers to the system running from flash; it may use the compact flash but only as an external storage, and not as the system root file system. Usually it implies a stable and finalize product. This is the default factory setup. The components involved are the Linux kernel, the initialization ram-disk (InitRD), and the JFFS2 as a dynamic but non volatile file system. The kernel and InitRD are supplied as a solid binary. The JFFS2 comes with default content. User can choose to remove or change the JFFS' content, and what to do with the rest of the storage place.

### 4.2.1 Boot procedure

Default settings configure the bootloader to invoke the Linux OS automatically. The Linux OS will run with console on COM1 and default network configuration. The defaults are: console 115200bps, 8N1, no flow control, network LAN1(eth0) set by a DHCP, LAN2(eth1) 192.168.1.2.

Whether it is the console or a telnet session the login shell will be activated (the console login shell mask CTRL-C).

It is highly recommended to login first via the serial console to make sure that the system is configured as needed before switching to the network connection.

Use telnet to log into the system, and ftp or tftp to transfer files to/from the RMU.

The factory settings for the development platform's user and password are: **root** and **root**, respectively.

### 4.2.2 Configuration

#### 4.2.2.1 Serial Port Configuration

RMU supports standard “stty” (setserial) to view/configure the serial port parameters. Below are some common stty commands (all examples below are issued on COM3)



### 4.2.2.2 Initialization

The kernel starts the init process with configuration files from InitRD rootfs. "Hooks" were created with the system startup procedure, allowing the customization of the system initialization.

The described flow below is part of the solid initrd image, except for the hooks which will be emphasized.

The environment variable FFS will be used as the pointer to the location of the configuration files on the mounted JFFS sub file system.

- Init process starts and follows the inittab instructions.
- Default configuration is loaded e.g.; IP addresses, location of the JFFS ( $\{FFS\}$ ), services to run. (`/etc/rc.config`)
- The second MAC address is set. It's striped from the kernel command line. The first MAC address is set by the u-boot.
- Set the loopback interface
- Mount the sub-systems proc, usbfs and jffs
- [hook] if exist, invoke the script  $\{FFS\}/etc/rc.preconfig$
- [hook] if exist, load the configuration file  $\{FFS\}/etc/network.conf$
- [hook] if exist, invoke the script  $\{FFS\}/etc/rc.network$
- [hook] if exist, load the configuration file  $\{FFS\}/etc/services.conf$

**Table 10 system's Initialization hooks**

The hook	Purpose				
$\{FFS\}/etc/rc.preconfig$	<p>[script]            This should be the place to make all system adjustment before any action has been taken.            For instance create soft/hard links, manipulate initrd files such as the password file, loads modules etc.</p>				
$\{FFS\}/etc/network.conf$	<p>[configuration]            This should be the place to make the basic network configuration.</p> <table border="1" style="margin-left: 40px;"> <thead> <tr> <th>HOSTNAME</th> <th>Unit network host name</th> </tr> </thead> <tbody> <tr> <td>ETH0</td> <td>           Network configuration for eth0.            Possible values are (including quotes):           <ul style="list-style-type: none"> <li>• "dhcp"</li> <li>• "auto"</li> <li>• "&lt;ip_address&gt;"</li> <li>• "&lt;ip_address&gt; netmask &lt;mask&gt;"</li> </ul>           Some examples:           <ol style="list-style-type: none"> <li>1. ETH0="dhcp"</li> <li>2. ETH0="auto"</li> <li>3. ETH0="192.168.1.5"</li> <li>4. ETH0="10.10.2.12 netmask 255.255.0.0"</li> </ol> </td> </tr> </tbody> </table>	HOSTNAME	Unit network host name	ETH0	Network configuration for eth0. Possible values are (including quotes): <ul style="list-style-type: none"> <li>• "dhcp"</li> <li>• "auto"</li> <li>• "&lt;ip_address&gt;"</li> <li>• "&lt;ip_address&gt; netmask &lt;mask&gt;"</li> </ul> Some examples: <ol style="list-style-type: none"> <li>1. ETH0="dhcp"</li> <li>2. ETH0="auto"</li> <li>3. ETH0="192.168.1.5"</li> <li>4. ETH0="10.10.2.12 netmask 255.255.0.0"</li> </ol>
HOSTNAME	Unit network host name				
ETH0	Network configuration for eth0. Possible values are (including quotes): <ul style="list-style-type: none"> <li>• "dhcp"</li> <li>• "auto"</li> <li>• "&lt;ip_address&gt;"</li> <li>• "&lt;ip_address&gt; netmask &lt;mask&gt;"</li> </ul> Some examples: <ol style="list-style-type: none"> <li>1. ETH0="dhcp"</li> <li>2. ETH0="auto"</li> <li>3. ETH0="192.168.1.5"</li> <li>4. ETH0="10.10.2.12 netmask 255.255.0.0"</li> </ol>				

			Note: the values must be quoted.						
		ETH1	Network configuration for eth1. Format is the same as for ETH0						
		GATEWAY	Network default gateway. This setting is ignored if either one of eth0 or eth1 is set to "dhcp"						
		DNS	List of one or more DNS servers Example: DNS="192.168.1.1 10.10.1.1"						
`\${FFS}/etc/rc.network	<p>[script] This is the callback that gets executed at the end of main network configuration script. It could be used to do any network oriented actions, such as interface manipulation and/or setting up advanced routing, notifying needed applications etc.</p>								
`\${FFS}/etc/rc.ip_change	<p>[script] This script is a callback for IP address change. This could happen when e.g. DHCP server gives unit the new IP address. Such callback could be used to notify needed application(s) and/or to display the new IP address on 4-digit display. Interface name is supplied as the first parameter to this callback and this NIC identifies the one with changed IP.</p>								
`\${FFS}/etc/services.conf	<p>[configuration] The place to enable or disable any of the services.</p> <table border="1" data-bbox="737 1010 1365 1398"> <tr> <td>SYSLOGD</td> <td>Defines whether "syslogd" service needs to be started at boot up. Service is started only if this variable is set to lowercase "y".</td> </tr> <tr> <td>XINETD</td> <td>Defines whether "xinetd" service needs to be started at boot up. Service is started only if this variable is set to lowercase "y". <b>Warning:</b> if you disable this service, both telnet and ftp servers will no longer be accessible.</td> </tr> <tr> <td>PORTMAP</td> <td>Defines whether "portmap" service needs to be started at boot up. Service is started only if this variable is set to lowercase "y".</td> </tr> </table>			SYSLOGD	Defines whether "syslogd" service needs to be started at boot up. Service is started only if this variable is set to lowercase "y".	XINETD	Defines whether "xinetd" service needs to be started at boot up. Service is started only if this variable is set to lowercase "y". <b>Warning:</b> if you disable this service, both telnet and ftp servers will no longer be accessible.	PORTMAP	Defines whether "portmap" service needs to be started at boot up. Service is started only if this variable is set to lowercase "y".
SYSLOGD	Defines whether "syslogd" service needs to be started at boot up. Service is started only if this variable is set to lowercase "y".								
XINETD	Defines whether "xinetd" service needs to be started at boot up. Service is started only if this variable is set to lowercase "y". <b>Warning:</b> if you disable this service, both telnet and ftp servers will no longer be accessible.								
PORTMAP	Defines whether "portmap" service needs to be started at boot up. Service is started only if this variable is set to lowercase "y".								

### 4.2.2.3 Network

The system has a default network configuration, [see /etc/rc.config]. However the RMU supplied with a template `\${FFS}/etc/network.conf` which sets the following settings.

ETH0 (LAN 1) factory setting

Parameter	RMU Setting
IP-Address of eth0	DHCP

ETH1 (LAN2) factory setting

Parameter	RMU Setting
IP-Address of eth1	192.168.1.2
Subnet Mask	255.255.255.0
Default Gateway	N/A

IF configuration file is missing, the units revert to the below network settings:

ETH0 (LAN1) default setting

Parameter	RMU Setting
IP-Address of eth0	192.168.1.5
Subnet Mask	255.255.255.0
Default Gateway	None

ETH1 (LAN2) default setting

Parameter	RMU Setting
IP-Address of eth1	172.21.232.5
Subnet Mask	255.255.0.0
Default Gateway	172.21.100.1

#### 4.2.2.3.1 Interactive configuration

When unit is inaccessible from the network and/or user interface does not provide a functionality to change the IP address, special “net” command from serial console can be used to setup primary network interface – LAN1. LAN2 (eth1) is not supported.

User needs to login via serial console and execute the following command at prompt:

```
net <ip_address>
This will permanently set LAN1 to specified <ip_address>. The full syntax of net command is
the following:
net <ip_address> [ <netmask> [ <default gateway> ] ]
where:
<ip_address> is one of
    •dhcp
    •auto
    •fixed IP address
<netmask> - subnet mask
<default gateway> - default gateway for the current network.
```

Note that <netmask> and <gateway> parameters are optional. Network change is taken into effect immediately. No restart is required. If executed without arguments, *net* command shows the current configuration and current IP addresses.

Below are some examples of how net command can be used (note that “user@rmu#” represents command prompt and must not be typed in):

1. Just change the IP address and leave default gateway unchanged:

```
user@rmu# net 192.168.1.5
```

2. Provide subnet mask as well:

```
user@rmu# net 10.10.12.32 255.255.0.0
```

3. Specify default gateway:

```
user@rmu# net 192.168.1.5 255.255.255.0 192.168.1.1
```

4. Get IP address from DHCP server:

```
user@rmu# net dhcp
```

5. Get IP address automatically in unmanaged network:

```
user@rmu# net auto
```

6. Check current configuration and IP addresses:

```
user@rmu# net

eth0: dhcp
eth1: dhcp
Gateway: 10.112.3.2
DNS: 150.100.100.30 150.100.100.89
Current IP address(es):
inet addr:192.168.1.160 Bcast:192.168.1.255 Mask:255.255.255.0
inet addr:172.21.211.70 Bcast:172.21.255.255 Mask:255.255.0.0
inet addr:127.0.0.1 Mask:255.0.0.0
Usage:
...> net ip_address [netmask [gateway]]
```

#### 4.2.2.3.2 Temporary configuration

In order to set the IP manually use the following example. Note that IP address will be changed for the current session only. After reboot, the old IP configuration will be restored.

```
user@rmu# ifconfig eth1 192.168.1.3
```

#### 4.2.2.4 Auto run

To automate the system operation, the init process invokes the `$(FFS)/etc/rc.application` automatically whenever it sense it is not running. i.e.; the `$(FFS)/etc/rc.appliaction` is invoked on system startup. In case the `$(FFS)/etc/rc.appliaction` will crash or end unexpectedly the init process will invoke it again [respawn].

Lets take the *hello* example code introduced in section 5.2.3, and make it run automatically on system startup. Lets edit `$(FFS)/etc/rc.appliaction`

```
user@rmu# vi /mnt/ffs/etc/rc.application
```

Here is the content of /mnt/ffs/etc/rc.application

```
#!/bin/sh  
  
/mnt/ffs/hello
```

The result of this will be a constant printout of Hello World, because the hello will finish running and the `/${FFS}/etc/rc.application` will exhausted, and the init process will bring it up again and again. To run it once use the `hold` shell command in the script, this way the `rc.application` script will still run and will be respawn only if it crashes unwontedly.

```
#!/bin/sh  
/mnt/ffs/hello >/dev/null 2>&1 &  
hold
```

Save the file and reboot the system, by enter the command **reboot** or cycle the RMU power to reboot the RMU. You will observe the **Hello World** output on reboot, but only once. If you would kill the `rc.application`, you should observe the **Hello World** output again.

It is also recommended to start the application by `/bin/conti.sh` script. This script will restart the application in case it crashed:

```
#!/bin/sh  
conti.sh /mnt/ffs/hello >/dev/null 2>&1 &  
hold
```

## 4.2.3 Storage

### 4.2.3.1 JFFS

The JFFS file system is designed to manage Flash in the most efficient way, it's wearable oriented to keep the flash life cycle longer. It tolerates brutal and unexpected power cut. It's mounted over the `/dev/mtdblock3` MTD device.

The JFFS contains basic configuration templates and kernel's modules. User can choose to use those supplied modules or to remove them and free JFFS storage space. The JFFS file system is mounted automatically by the init process from the InitRD's configuration file instructions. The Factory associated configuration files are under the `/${FFS}/etc` sub-directory. The Factory associated kernel's external modules are under `/${FFS}/lib/modules` sub-directory. The rest of the JFFS available memory is for customer's application use.

### 4.2.3.2 Compact Flash

In the Runtime platform the compact flash is used for general storage. It is not mounted automatically, it should be mounted manually, or by adjusting the hooks to do it automatically.

Usually a new compact flash comes preformatted with a FAT file system.



#### 4.2.3.2.1 Accessing CompactFlash

From within the RMU, CompactFlash is accessible as “/dev/hda”.

This command mounts Compact flash (assuming a single partition) into file system:

```
user@rmu# mount /dev/hda1 /mnt/data
```

Example for expected console's messages for the ext3 file system

```
hda: hda1
hda: hda1
kjournald starting. Commit interval 5 seconds
EXT3 FS 2.4-0.9.19, 19 August 2002 on ide0(3,1), internal journal
EXT3-fs: mounted filesystem with ordered data mode.
user@rmu#
```

To check is the compact flash already mounted to /mnt/data:

```
user@rmu# if mountpoint -q /mnt/data; then echo "Yes"; else echo "No"; fi

Yes
```

#### 4.2.3.2.2 Formatting CompactFlash

As mentioned above, most of brand-new CompactFlash cards come pre-formatted as FAT. In order to format it to EXT3, simply unmount it (if mounted) and run mkfs.ext3:

```
user@rmu# umount /mnt/data
user@rmu# mkfs.ext3 /dev/hda1
user@rmu# tune2fs -i 0 -c -1 /dev/hda1
```

#### 4.2.3.3 USB

Basic USB support is included monolithically in the Linux kernel. But to support an USB as a storage device, a particular kernel module should be loaded. The kernel modules are supplied as an external package located on the JFFS sub file system. User has the flexibility to remove these modules for storage space if found not useful.

Preloading the usb storage driver

```
insmod usb-storage.o
```

Expected console messages

```
Initializing USB Mass Storage driver...
usb.c: registered new driver usb-storage
```

```
USB Mass Storage support registered.
```

Messages similar to below are observed when an USB device is inserted:

```
hub.c: new USB device 0-1, assigned address 6
hub.c: USB hub found
hub.c: 1 port detected
hub.c: new USB device 0-1.1, assigned address 7
scsi0 : SCSI emulation for USB Mass Storage devices
  Vendor: Corsair  Model: Flash Voyager  Rev: 1.00
  Type:   Direct-Access          ANSI SCSI revision: 02
Attached scsi removable disk sda at scsi0, channel 0, id 0, lun 0
SCSI device sda: 507904 512-byte hdwr sectors (260 MB)
sda: Write Protect is off
sda: sda1
```

The following message signifies that an USB storage was detected but the driver was not loaded into the kernel. Use *insmod* procedure to look for the usb-storage module from `/proc/modules`.

```
hub.c: USB hub found
hub.c: 1 port detected
hub.c: new USB device 0-1.1, assigned address 3
usb.c: USB device 3 (vend/prod 0x67b/0x2517) is not claimed by any active driver.
```

Example for loading a disk-on-key

```
user@rmu# mkdir /mnt/usb
user@rmu# mount /dev/sda1 /mnt/usb/
```

### 4.3 Web Server


RMU does not have a web server application in the files system as a default. However, any web server application, such as BOA, may be loaded onto internal or external flash. BOA web server documentation can be found at <http://www.boa.org/>. BOA web server needs to be configured and started. See Appendix C for the procedure of how to create a binary for RMU.

See section [TBD] for details about how to add applications to startup sequence.

## 5 DIO API

The Digital IO Expansion Module is a PCI104 compatible device. The PCI interface for the Digital IO board is PCI 2.1 compatible. The PCI Connector is PC104 Compliant. The slot addresses for the PCI bus are determined by jumper settings. The RMU Digital IO Module's Driver is included with the Linux distribution or is available upon request. The API for the Driver is standard POSIX format.

The I/O module is configurable; each of the modules has Digital IO points can be configured as inputs or outputs. Units can be configured for sink or source, a jumper is used to activate the I/O configuration on the connector pins. See section for DIDO connection.



## 5.1 Device APIs

### 5.1.1 Overview

The API utilizes the standard POSIX interface to provide the user access to the devices functionality. As a POSIX compliant API, the DIO driver supports the standard operations: `open()`, `close()`, `read()`, `write()` and `ioctl()`. The use of `open()`, `close()`, `read()` and `write()` doesn't rely on any explicit definitions, it relies only on the standard POSIX definition standard. In order to use the `ioctl()`, an explicit protocol definition needs to be declared; it's done in the form of include file, which describes and defines the type of commands available.

The DIO are accessed via the VFS character device node. Its major should be 240. The DIO supports two interfaces: ASCII and Binary. Both have the same basic functionalities. The later includes some enhancements, such as get the previous output IOs states when setting a new ones and getting a timestamp indication with the read response. More on these enhancements are shown below.

The RMU supports up to four DIO cards. The cards are accessed via the special files:

- `/dev/mksdio[0-3]` (non-blocking ASCII reads would be used to poll the IO)
- `/dev/mksbio[0-3]` (blocking ASCII reads is interrupt change of state based)
- `/dev/mksbiob[0-3]` (blocking and non-blocking binary reads is interrupt change of state based)

Two basic methods can be used to get input information from the DIO card, polling and interrupt. When polling method is used, the application will read the DIO card status periodically. This method uses non-blocking mechanism. If the interrupt approach is preferred, then the blocking mechanism should be used. The reader will be blocked from listening to the DIO inputs and is released only when a relevant event occurs. A relevant event may be an IO's rising or/and falling edge condition that the driver was preset to notify the application. The notification is done by releasing the blocking device.

When a channel is opened for listening, it's immediately sent a status message. If it's using a blocking mechanism then it waits for any event that may appear.

**NOTE:** Non-blocking reads will always report the current IO states, where the blocking reads may report a time drifted IO states in case the application delayed the interrupt reading sequence

### 5.1.2 Basic procedures

The basic procedures are configuration, read and write.

#### Configuration

The default configuration sets all DIO as input channels, and interrupts are disabled. If different configuration is desired, e.g., setting output channels or using blocking for waiting on rising edge events, user must send a configuration message before using the IOs. The configuration can be changed at any time, but be aware of change in behavior. The configuration commands are sent to the cards by *write()* or *ioctl()* API functions according to the chosen Interface, i.e., ASCII or Binary.

#### Reading

Reading operation can be done by polling or by waiting on an event, i.e., blocking. By configuring the DIOs channels properly, the read operation may selectively notify you on events of interest and ignore the rest, for example rising edge occurrences in DIO3 & DIO5 in addition to falling edge occurrences in DIO3 & DIO6.

The default driver behavior is to queue-up events until the application take action, the main reason is to prevent event lost. But when real-time comes into consideration, the use of the queuing characteristic may be suppressed. The suppression can be done only once per system run. The tool to control it, *mksdio\_config*, resides on the *initrd*.

A standard POSIX *select* function can be used for the blocking approach. *Select* function allows application to handle more than a single device, i.e. a card, at a time. More than one devices could be read in blocking mode and set to notify the application on interrupt events. The application will be notified for any of the events no matter what card causes it. The application can even use this function with a time out period.

#### Writing

A DIO must be set as output channels before a write can take place, otherwise the output command will be ignored. In Binary mode, the sent buffer should be writable i.e., not a constant variable or one containing a reusable information, since the content will be overwritten after the return from the system call. The system call will write the previous DIO state into that buffer.

### 5.1.3 ASCII Interface

The ASCII API is associated with two sets of minors, minors 0-3 for operating in none blocking manner and minors 4-7 for operating in blocking manner, /dev/mksdio[0-3], /dev/mksbio[0-3], respectively .

Messages written to/reading from the device are in pure text. The configuration commands passed to the driver are in-bound; changing IO output states is just one of the available commands. There is only one type of received message: one that reports the IO states.

### 5.1.4 Binary Interface

The binary API is associated with its minors 8-11. For example, in order to access the first DIO card via the binary API, the VFS should include an entry like /dev/mksdiob0 with major 240 and minor 8, the second will be with minor 9 etc.

Messages written to/reading from the device are in binary code. The configuration commands passed to the driver are out-of-bound. The only in-bound command is the command to change the IO output states. All out-of-bound commands are sent to the driver by using the *ioctl* POSIX API. There are three kinds of message types: configuration commands, write IO output states, and read IO input states.

Two methods are available to manipulate the output IOs: *Snapshot* or *Selective*. The *Snapshot* method sets all the 24 IOs at once, The *Selective* method only sets a selective group of IOs; the selection is done by an additional IOs mask.

The only user defined types are the IOCTL commands codes and are supplied as an include file *mksdio\_ioctl.h* and also in this document

## 5.2 Function Definitions

The following API functions are supported

- Open() - is used to open a node to a specific Digital expansion module
- Close() – is used to release the node resource of a specific Digital expansion module
- Write()- is used to write to the digital outputs of a card
- Read() is used to read the input channels of the card

### 5.2.1 Open()

open a connection to a physical Digital IO module. The open function for the dio opens a data channel to the DIO card, handing a file descriptor to the application allows the invocation of the read,write and ioctl commands.

```
int open( const char* pathname, int flags);
```

#### Parameters

Type	Name	Description
Char	Pathname	the path name to the DIO device file ( e.g. /dev/mksdiob0 )
int	flags	one of the O_RDONLY, O_WRONLY or O_RDWR options to open the file. Usually it would be O_RDWR , for reading and writing.

**Return Value**

Type	Values
<i>int</i>	<ul style="list-style-type: none"> <li>The file descriptor if successful</li> <li>-1 if an error occurred.</li> </ul>

**REMARK:** use to open both ASCII and Binary interface, the device name will associated the application handler with the ASCII or the Binary interface.

**5.2.2 Close()**

Close an open connection to a physical Digital IO module. The close function for the dio will close the connection to a DIO module. Release any unnecessary system resources.

```
int close ( int fd);
```

**Parameters**

Type	Name	Description
Char	fd	file descriptor to be closed

**Return Value**

Type	Values
<i>int</i>	<ul style="list-style-type: none"> <li>0 if successful</li> <li>-1 if an error occurred.</li> </ul>

**5.2.3 Read()**

Read status of the physical Digital IO.

```
size_t read (int fd, void* buf, size_t count);
```

**Parameters**

Type	Name	Description
Int	fd	file descriptor to read from.
void*	buf	pointer to buffer in memory that will contain the data + the time indication.[only in binary mode]
Size_t	Count	number of bytes to be read.

**Return Value**

Type	Values
<i>int</i>	8 - indicating the succesful load of 8 bytes into the buffer (Binary Driver) 26 - indicating the succesful load of 26 bytes into the buffer (ASCII Driver) -1 if an error occurred.(Binary Driver) -1 if an error occurred.(ASCII Driver)

**Using ASCII Interface**

The syntax of the messages is ASCII based and as such it can be manipulated both by a shell script and by an execution. See [Examples].

**Message syntax Table:**

Syntax	Description
1	Channel on value
0	Channel off value

The received message contains a 26<sup>th</sup> characters long, 24 character each per channel, and characters 25-26 are new line followed by a NULL character. The message dumps the IO state into a character string indicating the IO current status. It always dumps all of the 24 channels.

**Using Binary Interface**

Read status of the physical Digital IO as a 32-bit word, or 4 bytes. Each bit represents the DIO status. The DIO occupies the first 24 bits of the message for the 24 DIO channels. the second 32-bit word will be attached to the return data including the event's time indication, the time indication is the number of 10ms ticks occurred since system startup.

The *read()* operation could be invoked as a blocked or non-blocked operation. This behavior could be controlled by using the ioctl command (MKS\_IOCTL\_SET\_NONBLOCK).

**Example:**

Assuming the following LEDS output on the front panel.

2	24																						
1	23																						
1	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	
1	1	0	1	1	1	0	0	1	1	0	1	1	0	1	1	0	1	1	0	1	1	0	1
1	23																						

DIO channels 1-3, 6-7, ... , 23-24 are ON  
DIO channels 4-5,8, ..., 20-22 are OFF

ASCII : "111001101010000010100011\n\0"  
Binary: bytes order 1->4 [0x00][0xc5][0x05][0x67]

- NOTE: few clarifications for the use of blocking mode.
1. The first read will always be none blocked and the return buffer content will be a snapshot of the DIOs states.
  2. in order to get notified for any DIO change, the mask for Rising and Falling edges should be adjusted [see ioctl for binary mode and the write for the ASCII mode]

### 5.2.4 Write()

Write status of the physical Digital IO module

```
size_t write ( int fd, const void* buf, size_t len);
```

**Parameters**

Type	Name	Description
Int	Fd	file descriptor to be write to
Void*	buf	pointer to the send data: see how to use ASCII and Binary interfaces below for more details
Size_t	len	number of bytes to be write. For ASCII 1<=Len<=24, for Binary 4 or 8 Bytes, see how to use ASCII and Binary interfaces below for more details

**Return Value**

Type	Values
Int	<ul style="list-style-type: none"> <li>• Successful in Selective mode: 8 (Binary Driver)</li> <li>• Successful in Snapshot mode: 4 (Binary Driver)</li> <li>• 27 bytes if Successful (ASCII Driver)</li> <li>• 1 if an error occurred.(Binary Driver)</li> <li>• 1 if an error occurred.(ASCII Driver)</li> </ul>

**Using the ASCII Interface**

The syntax of the messages is ASCII's based and as such it can be manipulated both by a shell script and by an execution. See [Examples]. As mentioned above the ASCII interface send all commands in-bounds, an ASCII message is build out of a appended characters each represent an operation, the location of the character implies on which DIO its should be delivered. The first character will be relate to DIO1 the second to the DIO2 etc. therefore a message may be short as a single character or as long as 24 characters, any additional characters append on the end of the message are being ignored.

**Message syntax Table:**

Syntax	Description
m	Mask interrupt
U	unmask interrupt
I	Mark as an input
O	Mark as an output
X	A don't care sign
1	Channel on value
0	Channel off value
R	Filters only rise
f	Filters only fall

The message can be described as a vector of commands, up to the number of addressable DIOs, which is 24 (per card). Each offset in the vector address to a specific DIO with the



same index. Vector[1] addresses DIO1, vector[2] addresses DIO2 and so on.( the vector first element index is 1).

#### Basic Messages Examples:

- "oi" - the 'o' is being sent to DIO1 and the 'i' is being sent to DIO2, respectively. The commands are 'o' mark as an output channel, 'i' mark as an input channel. The result for that message will be marking DIO1 as an output channel and marking DIO2 as an input channel.
- "xixi" – the 'x' means an operation don't care, its propose is to be a place-holder saying the DIO[index] has a NOP command, a command to do nothing. It's needed to keep the order. The result leaves DIO1 and DIO2 unchanged and mark DIO3 as an input channel
- "xxxx1xx0" – set DIO5 to ON and DIO8 to OFF by ignoring any other change.
- "r1f" – enable notification on rising edge event for DIO1, sets DIO2 to ON, enable notification on falling edge event for DIO3.

### Using the Binary Interface

The syntax of the message is Binary, which means working with a base unit of 32 bits.

There are two kinds of messages in the binary interface: *snapshot* and *selective*. *Snapshot* sets all the 24 DIOs at once. *Selective* may set only a subset of the DIOs leaving the other untouched.

Each DIO represented as a bit in the 32-bits word. There are 24 DIOs, bits 0 to 23 will represent the state of DIO 1 to 24, respectively. This representation is used for both types of messages. For the *selective* message type, an extra mask is appended to the DIOs states, it marks the DIO that should be affected by the assignment. It's also constructed of a bit-set representing the DIO channels in the same manner the states field represents the DIOs states. In any of the methods, the *write()* function will copy the card's DIOs states into the supplied buffer just before the write execution.

#### Input

*Snapshot: 1 x 32bits word [4 bytes]*

*Selective: 2 x 32bits word [8 bytes]*

The length of the message indicates which type of message was sent, so no other indication is needed.

#### Example:

```
// assuming all DIOs configured to be outputs and there states is off.
```

```
U32 message[2];
```

```
message[0] = 0x00ffffff;
```

```
message[1] = 0x00000003;
```

```
// device configuration at this place.
```

```
// now lets use the Snapshot message, the length
```

```
// was set to 4, the message[1] will be ignored,
// and all the card's DIOs will be effected by the
// value in message[0]. All DIOs should be light up,
// the value will be 0x00ffffff
write (fd, message, 4);
// print the return of the previous states of all DIOs.
printf("previous states %x\n", message[0]);
// that will set back the DIOs to the initial states
// which is 0x00000000
write (fd, message, 4);
//message[0] and message[1] will be send.
// and DIOs states will be (0x00000003) =
// (message[0] (0x00ffffff) & message[1] (0x00000003))
write (fd, message, 8);
// message[0] contains the previous value.
```

**Message syntax Table:**

Syntax	Description
1	Channel on value
0	Channel off value

### 5.2.5 ioctl()

Control the behavior of the physical Digital IO + the driver behavior.

```
int ioctl (int fd, int request, ...);
```

#### Parameters

Type	Name	Description
Int	Fd	file descriptor to be write to
int	Request	One of the operations mentioned below. Basically there are two type of operations, a set command and a get command. The set command uses the associated parameters as input data to the driver. The get command uses the associated parameter as a place holder for the output information coming from the driver. Therefore usually the type of parameter associated with a set command will be of type value and the one associated with a get command will be pointer to a place holder that eventually should hold the output for the specific command.

...  
The associated parameters, goes with the ioctl command. Each command defines its own associated parameters type and behavior.

**List of Set/Get command pairs:**

Command	Description
MKS_IOCTL_GET_NONBLOCK MKS_IOCTL_SET_NONBLOCK	Set the blocking/non-blocking read behavior  Associated parameter: Type: unsigned long <ul style="list-style-type: none"> <li>▪ Value: 1– blocking</li> <li>▪ Value: 0 – Non-blocking</li> </ul>
MKS_IOCTL_GET_OUTPUT_MASK MKS_IOCTL_SET_OUTPUT_MASK	Set the output mask, defines the behavior of the particular DIOx when IO status will be send to the driver by the write command, prevent writing 1s on unwanted DIOs  Associated parameter: Type: unsigned long <ul style="list-style-type: none"> <li>▪ Value: 0x00000000 – 0x00ffffff (default 0x00000000)</li> </ul>
MKS_IOCTL_GET_RISE_MASK MKS_IOCTL_SET_RISE_MASK	Set a software/hardware interrupt mask, defines which DIO will trigger a interrupt on a rising edge.  Associated parameter: Type: unsigned long <ul style="list-style-type: none"> <li>▪ Value: 0x00000000 – 0x00ffffff (default 0x00000000)</li> </ul>
MKS_IOCTL_GET_FALL_MASK MKS_IOCTL_SET_FALL_MASK	Set a software/hardware interrupt mask, defines which DIO will trigger a interrupt on a falling edge.  Associated parameter: Type: unsigned long <ul style="list-style-type: none"> <li>▪ Value: 0x00000000 – 0x00ffffff (default 0x00000000)</li> </ul>

**Return Value**

Type	Values
Int	0 on Success -1 if an error occurred.

## 6 AIO API

The AIO (Analog IO Card) can be approached via the Linux VFS just as any regular file. The message commands structure and codes are supplied as an include file *mksaio.h* and also in this document.

The AIO input and output differ in their presentation. Input is represented by a 14 bits and output is represented by a 12 bits.

## 6.1 Basic procedures

The basic procedures are configuration, read and write. The configuration and write operation both use the same message structure in order to pass a command. Read uses a different message structure, it loads each read not only the AIO states but rather all the AIO status information.

### Configurations

The default configuration is 16 single-ended, watchdog interrupt disabled.

Mode – can be changed at any time, the options are single-ended (16 channels) and differential mode (8 channels).

Watchdog – Internal watchdog can be enabled or disabled. When enabled, it's up to the application to reset its ticks counter.

### Reading

Each read operation fetches all the information from the AIO card packed into a structure defined in a supplementary include file *mksdio.h*. It includes all 16 AIO channels' readings, Watchdog information, output readiness indicator flag and the mode flag i.e; whether it's a 16 single-ended or a 8 differential. The AIO channel's read is unprocessed i.e.; 14 bits samples in 2's compliments format (see ***translate\_input*** function from 5.2).

### Writing

Setting a new value to an AIO is done by creating a message that includes the channel number and the VDC value in [0..4095] range proportionally corresponding to [-10..10] range (see ***translate\_output*** function from 5.2).

The POSIX function to be used for the configuration and writing procedures is the function *write* with the *mksaio\_cmd* structure. The POSIX function to be used for the reading procedure is the function *read* with the *mksaio\_info* structure.

## 6.2 Translating reads & writes

Translating the reads to the range of +10-(-10)V is done by to following logic.

```
// the following code can be a one liner macro as well, it is not an optimal code, for matter, of
// readiness and clarity.
float translate_input(unsigned short orig_val )
{
    float fValue = (float)(orig_val & 0x1FFF) / 819.2 - 10.0;
    if ((orig_val & 0x2000) == 0) fValue += 10.0;

    return fValue;
}
```

Translating the writes to the 12bits 2's compliments

```
unsigned short Translate_output( float volts)
{
    // boundries check can be added
    return (unsigned short)((orig_val + 10.0) / 204.8);
}
```

## 6.3 Function Definitions

The following API functions are supported

- Open() - is used to open a node to a specific Analog expansion module
- Close() – is used to release the node resource of a specific Analog expansion module
- Write()- is used to write to the digital outputs of a card
- Read() is used to read the input channels of the card

### 6.3.1 Open()

open a connection to a physical Analog IO module

```
int open( const char* pathname, int flags);
```

#### Parameters

Type	Name	Description
Char	Pathname	the path name to the AIO device file ( e.g. /dev/mksai0 )
int	flags	one of the O_RDONLY, O_WRONLY or O_RDWR options to open the file. Usually it would be O_RDWR , for reading and writing.

**Return Value**

Type	Values
<i>int</i>	<ul style="list-style-type: none"> <li>The file descriptor if successful</li> <li>1 if an error occurred.</li> </ul>

**Discussion**

The open function for the AIO opens a data channel to the AIO card, handing a file descriptor to the application allows the invocation of the read and write.

**6.3.2 Close()**

close an open connection to a physical Analog IO module

```
int close ( int fd);
```

**Parameters**

Type	Name	Description
Char	Ed	file descriptor to be closed

**Return Value**

Type	Values
<i>int</i>	<ul style="list-style-type: none"> <li>0 if successful</li> <li>1 if an error occurred.</li> </ul>

**Discussion**

The close function for the dio will close the connection to a AIO module. Release any unnecessary system resources.

**6.3.3 Read()**

read status of the physical Analog IO and the companion card information.

```
ssize_t read (int fd, void* buf, size_t count);
```

**Parameters**

Type	Name	Description
<i>int</i>	fd	file descriptor to read from.
<i>Void*</i>	Buf	pointer to buffer in memory that will contain the data Of a <i>struct mksaio_info</i>
<i>Size_t</i>	Count	number of bytes to be read.(size of struct mksaio_info)

**Return Value**

Type	Values
<i>int</i>	<ul style="list-style-type: none"> <li>Sizeof(struct mksaio_info) if successful</li> <li>-1 if an error occurred.</li> </ul>

**Discussion**

The definition of the *mksaio* data structure can be found in the file *mksaio.h*. Getting Information from the AIO driver should be done by using the *mksaio\_info* structure. This structure contains 4 sections:

- The ADC – a vector of the AIO channel current values in 2's compliment values
- Watch\_dog – information regarding the watch dog, such as is it enabled or disabled, time for expiration and indication whether or not an interrupt occurred. The parameters names in the structure are *is\_int\_enabled* and *is\_int\_occured* respectively.
- DAC – an indicator field that indicates whether AIO card is ready to digest a new output channel update. The parameter's name is *is\_ready*. There is an additional remanded parameter *is\_int\_enabled* it's mapped to the same parameter describe under the watch\_dog structure.
- AI\_conf – mode of operation. i.e; shows the mode a differential mode or a single-ended mode. Its value also implies on the number of valid ADC channels, whether it 8 or 16.

**6.3.4 Write()**

write status of the physical Analog IO module

```
ssize_t write ( int fd, const void* buf, size_t len);
```

**Parameters**

Type	Name	Description
Int	fd	file descriptor to be write to
Void*	buf	pointer to buffer in memory that will contain the data Of <i>struct mksaio_cmd</i>
Size_t	Len	Sizeof(struct mksaio_cmd)

**Return Value**

Type	Values
<i>Int</i>	<ul style="list-style-type: none"> <li>• Sizeof(struct mksaio_cmd) if successful</li> <li>• -1 if an error occurred.</li> </ul>

**Discussion**

The definition of the *mksaio* data structure can be found in the file *mksaio.h*. As mentioned above the write function serves both for configuration and for AIO value settings. It's done by sending a command using the *mksaio\_cmd* structure.

Command	Description
MKSAIO_CMD_SET_MODE	Sets 16 single-ended mode or a 8 differential mode. Options are: <b>MKSAIO_MODE_8_DIFFERENTIAL</b> <b>MKSAIO_MODE_16_SINGLE_ENDED</b> via the structure <i>data.value</i> field.
MKSAIO_CMD_OUTPUT	Set output values per channel. Two associated parameters, the channel and the value. The channel is set to the structure's <i>data.output.channel</i> field. The value goes to the <i>data.output.val</i> field. NOTE: the value is a 12bits 2's compliment
MKSAIO_CMD_WD_INT_CTL	Enable/Disable the watch dog Options: <b>MKSAIO_ENABLE/MKSAIO_DISABLE</b> Via the structure's <i>data.value</i> field
MKSAIO_CMD_WD_RESET	Reset the watchdog, and load the the ticks counter to a new value. The new value is set to the structure's <i>data.value</i> field the value range from 1 to 127, each tick is a 10ms

## 6.4 MKSAIO.H

```

#ifndef _MKSAIO_H_
#define _MKSAIO_H_

#ifdef __cplusplus
extern "C" {
#endif

/*
 * List of available commands
 */
#define MKSAIO_CMD_SET_MODE          (1) /* sets single-ended and differential */
#define MKSAIO_CMD_OUTPUT            (2) /* Set Output values per channel*/
#define MKSAIO_CMD_WD_INT_CTL        (3) /*Enable/Disable watch dog */
#define MKSAIO_CMD_WD_RESET          (4) /* Reset the watch dog and enable */
                                        /* it with a selected value*/

/* Options for AI Configurations (MKSAIO_CMD_SET_MODE) */
#define MKSAIO_MODE_8_DIFFERENTIAL  (1)
#define MKSAIO_MODE_16_SINGLE_ENDED (0)

/* General Options (MKSAIO_CMD_WD_INT_CTL,etc.)*/
#define MKSAIO_ENABLE                 (1)
#define MKSAIO_DISABLE                (0)
    
```



```
/* output format to be used by the user's application */
struct mksaio_info{
    unsigned short ADC[16];
    struct {
        unsigned char ticks_left:7; // ticks in 10msec
        unsigned char is_int_enabled:1;
        unsigned char is_int_occured:1;
        unsigned char unused:7;
    }watch_dog;

    struct {
        unsigned char is_int_enabled:1;
        unsigned char is_ready:1;
        unsigned char unused:6;
    }DAC;

    unsigned char AI_conf;
};

union mksaio_cmd_data{
    struct{
        unsigned long val:12;
        unsigned long channel:3;
        unsigned long unused:17;
    }output;
    unsigned long value;
};

struct mksaio_cmd
{
    unsigned long code;
    union mksaio_cmd_data data;
};

#ifdef __cplusplus
}
#endif

#endif /* _MKSAIO_H_ */
```

## 6.5 Sample Code

Here is sample code to set analog output to a specific voltage:

```
/*
 *      nFD – descriptor of open device file (e.g. "/dev/mksaio1")
 *      nInput – input number to be changed
 *      fValue – voltage (-10..10)
 */
bool SetAnalogOut(int nFD, int nInput, double fValue)
{
    struct mksaio_cmd cmd;

    double fRange = (fValue + 10.0) * 204.8;

    cmd.code = MKSAIO_CMD_OUTPUT;
    cmd.data.output.val = (int)fRange;
    cmd.data.output.channel = nInput;

    return sizeof(cmd) == write(nFD, &cmd, sizeof(cmd));
}
```

Sample code to switch between single ended and differential mode:

```
/*
 *      nFD – descriptor of open device file (e.g. "/dev/mksaio1")
 *      bDiff – true: differential, false: single ended
 */
void SetDifferential(int nFD, bool bDiff)
{
    struct mksaio_cmd cmd;

    cmd.code = MKSAIO_CMD_SET_MODE;
    cmd.data.value = bDiff ? MKSAIO_MODE_8_DIFFERENTIAL :
    MKSAIO_MODE_16_SINGLE_ENDED;

    return sizeof(cmd) == write(nFD, &cmd, sizeof(cmd));
}
```

## 7 MMI API

The MMI driver supplies services to the RMU's 4-digits ASCII display, 2 push buttons and the 3 LEDs on the panel (NET,MOD and STAT). The driver communicates with a single peripheral, a PIC controller [AT89S8253], located on the power board along with the digits ASCII display and 2 push buttons.

Three device nodes should be set:

1. AT89 : /dev/at89
2. Display : /dev/at89display
3. Buttons: /dev/at89buttons

All 3 nodes interface the MMI driver with different minor number.

To monitor the AT89 configuration there is an entry in the proc subsystem /proc/mks/at89.

*mksmmi\_ioctl.h* is an associated file that contains the definitions of the various MMI commands – those commands that invoked by using the out-of-bound *ioctl* POSIX function.

### 7.1 AT89 API

This part of the driver supports the AT89 update mechanism and controls the LEDs colors. The AT89 FW can be uploaded and downloaded by using the *read* and *write* commands, the operation is transparent in a sense its detects the operation, stop the running of the AT89, reads it's content or in case of writing, it cleans up the internal E2PROM, then it writes its content; finally when the session is been closed the AT89 running mode return to it's previous state.

The LEDs color control done by using *ioctl* . each LED could be in one of the following 4 colors: no active(dark), green,red and amber. The setting is done by supplying the function with the LEDs index as the operation code and the color code as the accompany parameter's value. The codes are taken from the definition file *mksmmi\_ioctl.h*.

## 7.1.1 Function Definitions

The following API functions are supported

- open() - is used to open a node to the at89 module
- close() - is used to release the node resource of a specific to the at89 module
- write() - is used to write to the fw image to the AT89's E2PROM
- read() - is used to read the fw image from the AT89's E2PROM
- ioctl() – is used to manipulate the LEDS

### 7.1.1.1 Open()

open a connection to the AT89 device.

```
int open( const char* pathname, int flags);
```

#### Parameters

Type	Name	Description
Char	Pathname	the path name to the DIO device file ( in this case /dev/at89 )
int	flags	one of the O_RDONLY, O_WRONLY or O_RDWR options to open the file. Usually it would be O_RDWR , for reading and writing.

#### Return Value

Type	Values
Int	The file descriptor if successful -1 if an error occurred.

#### Discussion

The open function for the at89 opens a data channel to the AT89 controller.

### 7.1.1.2 Close()

close an open connection to the AT89

```
int close ( int fd);
```

#### Parameters

Type	Name	Description
Char	fd	file descriptor to be closed

#### Return Value

Type	Values
Int	0 if successful -1 if an error occurred.

**Discussion**

Close function for the AT89 module

**7.1.1.3 Write()**

Writes the incoming data to the AT89's E2PROM sequentially (lseek is not supported) , it transparently handle the erasing of blocks in the E2PROM. No recovery support in case of malfunction after the erase. In this case the session should be closed and repeat the attempt. Any length of data chunk can be used. For optimal operation use chunks of 64 bytes.

`ssize_t write ( int fd, const void* buf, size_t len);`

**Parameters**

Type	Name	Description
Char	Fd	file descriptor to be write to
Void*	Buf	pointer to buffer in memory that contains the data to be written to the E2PROM.
Size t	Len	Number of bytes to be write

**Return Value**

Type	Values
ssize_t	<ul style="list-style-type: none"> <li>• number of actual bytes written.</li> <li>• -1 if an error occurred.</li> </ul>

**7.1.1.4 Read()**

Read the AT89's E2PROM content sequentially (lseek is not supported)

`ssize_t read ( int fd, const void* buf, size_t len);`

**Parameters**

Type	Name	Description
Char	Fd	file descriptor to be write to
Void*	Buf	Pointer to buffer in memory that will contain the data from the E2PROM.
Size t	Len	Number of bytes to be

**Return Value**

Type	Values
ssize_t	<ul style="list-style-type: none"> <li>• number of actual bytes written.</li> <li>• -1 if an error occurred.</li> </ul>

### 7.1.1.5 ioctl()

The LEDs' behavior is controlled by this function.

```
int ioctl (int fd, int request, ...);
```

#### Parameters

Type	Name	Description
int	fd	file descriptor to be used.
Int*	Request	The options are IOCTL_MKS_SET_LED1, IOCTL_MKS_SET_LED2, IOCTL_MKS_SET_LED3, IOCTL_MKS_GET_LED1, IOCTL_MKS_GET_LED2, IOCTL_MKS_GET_LED3, Each one of them as its name points to a specific LED whether for fetching its state or to set its state. Its accompany to the value parameters that can be the value 1-4 , no light, green, red and amber respectively

...

#### Return Value

Type	Values
Int	<ul style="list-style-type: none"> <li>• 0 if successful</li> <li>• -1 if an error occurred.</li> </ul>

## 7.2 AT89Display API

4-digits ASCII display, it located on the power board.

Support:

1. scrolling
2. blinking
3. display text up to 40 characters (a support for up to 64 chars will be support shortly)

The default behavior is to scroll the text on the display whenever the sent text is longer than the physical 4 digits display. The scroll and blinking features are controlled via *ioctl* command. The *write* command is used to send text to the display. There is no *read* command for this device.

### 7.2.1 Function Definitions

The following API functions are supported

- Open() - is used to open a node to the at89 module
- close() - is used to release the node resource of a specific to the at89 module
- Write() - is used to write text string to the 4-digits display
- ioctl() – is used to manipulate the 4-digits display behavior

### 7.2.1.1 Open()

Open a connection to the display device.

```
int open( const char* pathname, int flags);
```

**Parameters**

Type	Name	Description
Char	Pathname	the path name to the DIO device file ( in this case /dev/at89display )
int	flags	one of the O_RDONLY, O_WRONLY or O_RDWR options to open the file. Usually it would be O_RDWR , for reading and writing.

**Return Value**

Type	Values
Int	The file descriptor if successful -1 if an error occurred.

**Discussion**

Open a data channel to the display controller.

### 7.2.1.2 Close()

Close an open connection to the display

```
int close ( int fd);
```

**Parameters**

Type	Name	Description
Char	fd	file descriptor to be closed

**Return Value**

Type	Values
Int	0 if successful -1 if an error occurred.

**Discussion**

Close function for the display.

### 7.2.1.3 Write()

Writes the text string contained in the buffer to the display

```
ssize_t write ( int fd, const void* buf, size_t len);
```

**Parameters**

Type	Name	Description
Char	Fd	file descriptor to be write to
Void*	Buf	pointer to buffer in memory that contains the text string to be display
Size_t	Len	number of bytes to be write

**Return Value**

Type	Values
ssize_t	<ul style="list-style-type: none"> <li>• number of actual bytes written.</li> <li>• -1 if an error occurred.</li> </ul>

**7.2.1.4 ioctl()**

Control the behavior of the display's scroll and blink.

```
int ioctl (int fd, int request, ...);
```

**Parameters**

Type	Name	Description
int	fd	file descriptor to be used.
Int*	Request	there are two control options fro the scroll, the scroll speed, and scroll step. The scroll speed is the time gap between each display scroll refresh (not internal display screen refresh). Scroll step is the number on character to shift per each refresh. Blink is the effect in which appearance and disappearance of the entire content on the display is toggled. Value 0 stop the blink any other positive value is the number of 10ms delay between each toggle

The associated parameters, goes with the ioctl command. Each command defines its own associated parameters type and behavior.

**List of Set/Get command pairs:**

Command	Description
MKS_IOCTL_GET_SCROLL_SPEED MKS_IOCTL_SET_SCROLL_SPEED	Set/get the display scroll refresh in units of milliseconds, zero value disables the scrolling.  Associated parameter:  Type: unsigned long <ul style="list-style-type: none"> <li>▪ Value: 0 – disable scrolling</li> <li>▪ any other value is legal.</li> </ul>
MKS_IOCTL_GET_SCROLL_STEP MKS_IOCTL_SET_SCROLL_STEP	Set/get the display scroll step size in characters, zero value disables the scrolling.  Associated parameter:  Type: unsigned char <ul style="list-style-type: none"> <li>▪ Value: 0 – disable scrolling</li> <li>▪ any other value is legal</li> </ul>
MKS_IOCTL_GET_BLINK MKS_IOCTL_SET_BLINK	Set/get the display blink delay , zero value disables the blinking.



	Associated parameter:  Type: unsigned char <ul style="list-style-type: none"> <li>▪ Value: 0 – disable blinking</li> <li>▪ any other value is legal</li> </ul>
--	----------------------------------------------------------------------------------------------------------------------------------------------------------------------

## Return Value

Type	Values
<i>Int</i>	<ul style="list-style-type: none"> <li>• 0 if successful</li> <li>• -1 if an error occurred.</li> </ul>

## 7.3 AT89Buttons API

There are two push buttons on the power board. Their status can be fetched by reading the `/dev/at89buttons` device. The read operation could be blocked or non-blocked. Both techniques trigger a communication message to the AT89 in order to retrieve the current buttons states. The caller will be informed whether the buttons were not pushed, were pushed or were pushed and released.

NOTE: An interrupt driven mechanism is in development; it will be combined with the operation of the block mode.

NOTE: Currently, the blocking mode is implemented without the support of an interrupt, but based on the driver being updated regarding the buttons states each time the driver communicates with the AT89. It's not recommended to use the blocking mode without the support of a hardware interrupt. Support for hardware interrupt is in development.

### 7.3.1 Function Definitions

The following API functions are supported

`Open()` - is used to open a node to the AT89 buttons module  
`close()` – is used to release the node resource of AT89 buttons module  
`Read()` is used to read the input channels of the card  
`ioctl()` - used for a blocking / nonblocking configuration

#### 7.3.1.1 Open()

Open a connection to the AT89 buttons module.

```
int open( const char* pathname, int flags);
```

#### Parameters

Type	Name	Description
Char	Pathname	the path name to the DIO device file ( e.g. <code>/dev/at89buttons</code> )

int	flags	one of the O_RDONLY, O_WRONLY or O_RDWR options to open the file. Usually it would be O_RDWR , for reading and writing.
-----	-------	-------------------------------------------------------------------------------------------------------------------------

**Return Value**

Type	Values
Int	The file descriptor if successful -1 if an error occurred.

**Discussion**

The open function for the AT89buttons opens a data channel.

### 7.3.1.2 Close()

Close an open connection to the AT89buttons

```
int close ( int fd);
```

**Parameters**

Type	Name	Description
Char	fd	file descriptor to be closed

**Return Value**

Type	Values
Int	0 if successful -1 if an error occurred.

**Discussion**

Close function closes the channel to the AT89buttons.

### 7.3.1.3 Read()

Reads the buttons status register, the size to be reading should be 1 byte.

```
ssize_t read ( int fd, const void* buf, size_t len);
```

**Parameters**

Type	Name	Description
Char	Fd	file descriptor to be write to
Void*	Buf	pointer to buffer in memory that will contain the data from the buttons register
Size t	Len	number of bytes to be

**Discussion**

For now the only working mechanism is polling, therefore the read will be a non-block by default. Each time the key status is read, the driver clears the status register for the next

read. The read register (1byte). Hold the information for both buttons. Each button state is represented by 2 bits. Bits 0-1 are the first button state, the following bits 2-3 are the second button state.

**Button's state values**

State	Value
not pressed	0
Pressed	1
Released	2
Pressed & Released	3

**7.3.1.4 ioctl()**

Control the behavior of the buttons blocking / non blocking working mode. At this point only a non block mode is enabled. When the blocking working mode will be handy this characteristic will be controlled be the *ioctl*'s IOCTL\_MKS\_SET\_NONBLOCK code.

```
int ioctl (int fd, int request, ...);
```

**Parameters**

Type	Name	Description
int	fd	file descriptor to be used.
Int*	Request	there are two control options fro the scroll, the scroll speed, and scroll step. The scroll speed is the time gap between each display scroll refresh (not internal display screen refresh). Scroll step is the number on character to shift per each refresh.

**Return Value**

Type	Values
ssize_t	<ul style="list-style-type: none"> <li>• number of actual bytes written.</li> <li>• 1 if an error occurred.</li> </ul>

**List of Set/Get command pairs:**

Type	Values
IOCTL_MKS_SET_NONBLOCK	0 - blocking mode 1- non blocking mode

## 8 RS-485

Two (2) optional COM ports (COM3 and COM4) can operate in both RS232 and RS485 modes. From application side, appropriate mode is chosen by accessing different device file from under '/dev/"/>.

```
~ $ ls -la /dev/ttyS2 /dev/ttyS3 /dev/ttyS2_485 /dev/ttyS3_485
```

```
crw----- 1 root    root      4,  66 Jun  7  2005 /dev/ttyS2
crw----- 1 root    root      4,  67 Jun  7  2005 /dev/ttyS3
crw----- 1 root    root     4, 202 Jun  7  2005 /dev/ttyS2_485
crw----- 1 root    root     4, 203 Jun  7  2005 /dev/ttyS3_485
```

By accessing /dev/ttyS2 or /dev/ttyS2\_485, COM3 will be running in RS-232 or RS-485 mode respectively. Please, note that once port is opened in a specific mode, the access to the other device file will be blocked for as long as the original device is open. For example, if an application opens /dev/ttyS2, attempts from other applications to open /dev/ttyS2\_485 will result in "device does not exist" error.

# Appendix A: POSIX Functions Description

For more details, please refer to Linux manual pages

## 1. Function “open”

### NAME

open, creat - open and possibly create a file or device

### SYNOPSIS

```
#include <sys/types.h>
#include <sys/stat.h>
#include <fcntl.h>

int open(const char *pathname, int flags);
int open(const char *pathname, int flags, mode_t mode);
int creat(const char *pathname, mode_t mode);
```

### DESCRIPTION

Given a *pathname* for a file, **open()** returns a file descriptor, a small, non-negative integer for use in subsequent system calls (**read(2)**, **write(2)**, **lseek(2)**, **fcntl(2)**, etc.). The file descriptor returned by a successful call will be the lowest-numbered file descriptor not currently open for the process.

The new file descriptor is set to remain open across an **execve(2)** (i.e., the **FD\_CLOEXEC** file descriptor flag described in **fcntl(2)** is initially disabled). The file offset is set to the beginning of the file (see **lseek(2)**).

A call to **open()** creates a new *open file description*, an entry in the system-wide table of open files. This entry records the file offset and the file status flags (modifiable via the **fcntl()** **F\_SETFL** operation). A file descriptor is a reference to one of these entries; this reference is unaffected if *pathname* is subsequently removed or modified to refer to a different file. The new open file description is initially not shared with any other process, but sharing may arise via **fork(2)**.

The parameter *flags* must include one of the following *access modes*: **O\_RDONLY**, **O\_WRONLY**, or **O\_RDWR**. These request opening the file read-only, write-only, or read/write, respectively.

In addition, zero or more file creation flags and file status flags can be bitwise-or'd in *flags*. The *file creation flags* are **O\_CREAT**, **O\_EXCL**, **O\_NOCTTY**, and **O\_TRUNC**. The *file status flags* are all of the remaining flags listed below. The distinction between these two groups of flags is that the file status flags can be retrieved and (in some cases) modified using **fcntl(2)**. The full list of file creation flags and file status flags is as follows:

#### **O\_APPEND**

The file is opened in append mode. Before each **write()**, the file offset is positioned at the end of the file, as if with **lseek()**. **O\_APPEND** may lead to corrupted files on NFS file systems if more than one process appends data to a file at once. This is because NFS does not support appending to a file, so the client kernel has to simulate it, which can't be done without a race condition.

#### **O\_ASYNC**

Enable signal-driven I/O: generate a signal (SIGIO by default, but this can be changed via **fcntl(2)**) when input or output becomes possible on this file descriptor. This feature is only available for terminals, pseudo-terminals, sockets, and (since Linux 2.6) pipes and FIFOs. See **fcntl(2)** for further details.

#### **O\_CREAT**

If the file does not exist it will be created. The owner (user ID) of the file is set to the effective user ID of the process. The group ownership (group ID) is set either to the effective group ID of the process or to the group ID of the parent directory (depending on filesystem type and mount options, and the mode of the parent directory, see, e.g., the mount options *bsdgroups* and *sysvgroups* of the ext2 filesystem, as described in **mount(8)**).

#### **O\_DIRECT**

Try to minimize cache effects of the I/O to and from this file. In general this will degrade performance, but it is useful in special situations, such as when applications do their own caching. File I/O is done directly to/from user space buffers. The I/O is synchronous, i.e., at the completion of a **read(2)** or **write(2)**, data is guaranteed to have been transferred. Under Linux 2.4 transfer sizes, and the alignment of user buffer and file offset must all be multiples of the logical block size of the file system. Under Linux 2.6 alignment to 512-byte boundaries suffices. A semantically similar (but deprecated) interface for block devices is described in **raw(8)**.

#### **O\_DIRECTORY**

If *pathname* is not a directory, cause the open to fail. This flag is Linux-specific, and was added in kernel version 2.1.126, to avoid denial-of-service problems if `opendir(3)` is called on a FIFO or tape device, but should not be used outside of the implementation of `opendir`.

**O\_EXCL**

When used with `O_CREAT`, if the file already exists it is an error and the `open()` will fail. In this context, a symbolic link exists, regardless of where it points to. `O_EXCL` is broken on NFS file systems; programs which rely on it for performing locking tasks will contain a race condition. The solution for performing atomic file locking using a lockfile is to create a unique file on the same file system (e.g., incorporating hostname and pid), use `link(2)` to make a link to the lockfile. If `link()` returns 0, the lock is successful. Otherwise, use `stat(2)` on the unique file to check if its link count has increased to 2, in which case the lock is also successful.

**O\_LARGEFILE**

(LFS) Allow files whose sizes cannot be represented in an *off\_t* (but can be represented in an *off64\_t*) to be opened.

**O\_NOATIME**

(Since Linux 2.6.8) Do not update the file last access time (*st\_atime* in the inode) when the file is `read(2)`. This flag is intended for use by indexing or backup programs, where its use can significantly reduce the amount of disk activity. This flag may not be effective on all filesystems. One example is NFS, where the server maintains the access time.

**O\_NOCTTY**

If *pathname* refers to a terminal device --- see `tty(4)` --- it will not become the process's controlling terminal even if the process does not have one.

**O\_NOFOLLOW**

If *pathname* is a symbolic link, then the open fails. This is a FreeBSD extension, which was added to Linux in version 2.1.126. Symbolic links in earlier components of the *pathname* will still be followed.

**O\_NONBLOCK** or **O\_NDELAY**

When possible, the file is opened in non-blocking mode. Neither the `open()` nor any subsequent operations on the file descriptor which is returned will cause the calling process to wait. For the handling of FIFOs (named pipes), see also `fifo(7)`. For a discussion of the effect of `O_NONBLOCK` in conjunction with mandatory file locks and with file leases, see `fcntl(2)`.

**O\_SYNC**

The file is opened for synchronous I/O. Any `write(s)` on the resulting file descriptor will block the calling process until the data has been physically written to the underlying hardware. *But see RESTRICTIONS below.*

**O\_TRUNC**

If the file already exists and is a regular file and the open mode allows writing (i.e., is `O_RDWR` or `O_WRONLY`) it will be truncated to length 0. If the file is a FIFO or terminal device file, the `O_TRUNC` flag is ignored. Otherwise the effect of `O_TRUNC` is unspecified.

Some of these optional flags can be altered using `fcntl()` after the file has been opened.

The argument *mode* specifies the permissions to use in case a new file is created. It is modified by the process's `umask` in the usual way: the permissions of the created file are **(mode & ~umask)**. Note that this mode only applies to future accesses of the newly created file; the `open()` call that creates a read-only file may well return a read/write file descriptor.

The following symbolic constants are provided for *mode*:

**S\_IRWXU**

00700 user (file owner) has read, write and execute permission

**S\_IRUSR**

00400 user has read permission

**S\_IWUSR**

00200 user has write permission

**S\_IXUSR**

00100 user has execute permission

**S\_IRWXG**

00070 group has read, write and execute permission

**S\_IRGRP**

00040 group has read permission

**S\_IWGRP**

00020 group has write permission

**S\_IXGRP**

00010 group has execute permission

**S\_IRWXO**

00007 others have read, write and execute permission

**S\_IROTH**

00004 others have read permission

**S\_IWOTH**

00002 others have write permission

**S\_IXOTH**

00001 others have execute permission

*mode* must be specified when `O_CREAT` is in the *flags*, and is ignored otherwise.

`creat()` is equivalent to `open()` with *flags* equal to `O_CREAT|O_WRONLY|O_TRUNC`.

RETURN VALUE

`open()` and `creat()` return the new file descriptor, or -1 if an error occurred (in which case, *errno* is set appropriately).

NOTES

Note that `open()` can open device special files, but `creat()` cannot create them; use `mknod(2)` instead.

## RMU2 User Manual

---

On NFS file systems with UID mapping enabled, **open()** may return a file descriptor but e.g. **read(2)** requests are denied with **EACCES**. This is because the client performs **open()** by checking the permissions, but UID mapping is performed by the server upon read and write requests.

If the file is newly created, its **st\_atime**, **st\_ctime**, **st\_mtime** fields (respectively, time of last access, time of last status change, and time of last modification; see **stat(2)**) are set to the current time, and so are the **st\_ctime** and **st\_mtime** fields of the parent directory. Otherwise, if the file is modified because of the **O\_TRUNC** flag, its **st\_ctime** and **st\_mtime** fields are set to the current time.

## ERRORS

### EACCES

The requested access to the file is not allowed, or search permission is denied for one of the directories in the path prefix of *pathname*, or the file did not exist yet and write access to the parent directory is not allowed. (See also **path\_resolution(2)**.)

### EEXIST

*pathname* already exists and **O\_CREAT** and **O\_EXCL** were used.

### EFAULT

*pathname* points outside your accessible address space.

### EISDIR

*pathname* refers to a directory and the access requested involved writing (that is, **O\_WRONLY** or **O\_RDWR** is set).

### ELOOP

Too many symbolic links were encountered in resolving *pathname*, or **O\_NOFOLLOW** was specified but *pathname* was a symbolic link.

### EMFILE

The process already has the maximum number of files open.

### ENAMETOOLONG

*pathname* was too long.

### ENFILE

The system limit on the total number of open files has been reached.

### ENODEV

*pathname* refers to a device special file and no corresponding device exists. (This is a Linux kernel bug; in this situation **ENXIO** must be returned.)

### ENOENT

**O\_CREAT** is not set and the named file does not exist. Or, a directory component in *pathname* does not exist or is a dangling symbolic link.

### ENOMEM

Insufficient kernel memory was available.

### ENOSPC

*pathname* was to be created but the device containing *pathname* has no room for the new file.

### ENOTDIR

A component used as a directory in *pathname* is not, in fact, a directory, or **O\_DIRECTORY** was specified and *pathname* was not a directory.

### ENXIO

**O\_NONBLOCK** | **O\_WRONLY** is set, the named file is a FIFO and no process has the file open for reading. Or, the file is a device special file and no corresponding device exists.

### EOVERFLOW

*pathname* refers to a regular file, too large to be opened; see **O\_LARGEFILE** above.

### EPERM

The **O\_NOATIME** flag was specified, but the effective user ID of the caller did not match the owner of the file and the caller was not privileged (**CAP\_FOWNER**).

### EROFS

*pathname* refers to a file on a read-only filesystem and write access was requested.

### ETXTBSY

*pathname* refers to an executable image which is currently being executed and write access was requested.

### EWOULDBLOCK

The **O\_NONBLOCK** flag was specified, and an incompatible lease was held on the file (see **fcntl(2)**).

## NOTE

Under Linux, the **O\_NONBLOCK** flag indicates that one wants to open but does not necessarily have the intention to read or write. This is typically used to open devices in order to get a file descriptor for use with **ioctl(2)**.

## CONFORMING TO

SVr4, 4.3BSD, POSIX.1-2001. The **O\_NOATIME**, **O\_NOFOLLOW**, and **O\_DIRECTORY** flags are Linux-specific. One may have to define the **\_GNU\_SOURCE** macro to get their definitions.

The (undefined) effect of **O\_RDONLY** | **O\_TRUNC** varies among implementations. On many systems the file is actually truncated.

The **O\_DIRECT** flag was introduced in SGI IRIX, where it has alignment restrictions similar to those of Linux 2.4. IRIX has also a **fcntl(2)** call to query appropriate alignments, and sizes. FreeBSD 4.x introduced a flag of same name, but without alignment restrictions. Support was added under Linux in kernel version 2.4.10. Older Linux kernels simply ignore this flag. One may have to define the **\_GNU\_SOURCE** macro to get its definition.

## BUGS

"The thing that has always disturbed me about O\_DIRECT is that the whole interface is just stupid, and was probably designed by a deranged monkey on some serious mind-controlling substances." --- Linus  
Currently, it is not possible to enable signal-driven I/O by specifying **O\_ASYNC** when calling **open()**; use **fcntl(2)** to enable this flag.

## RESTRICTIONS

There are many infelicities in the protocol underlying NFS, affecting amongst others **O\_SYNC** and **O\_NDELAY**. POSIX provides for three different variants of synchronised I/O, corresponding to the flags **O\_SYNC**, **O\_DSYNC** and **O\_RSYNC**. Currently (2.1.130) these are all synonymous under Linux.

## SEE ALSO

**close(2)**, **dup(2)**, **fcntl(2)**, **link(2)**, **lseek(2)**, **mknod(2)**, **mount(2)**, **mmap(2)**, **openat(2)**, **path\_resolution(2)**, **read(2)**, **socket(2)**, **stat(2)**, **umask(2)**, **unlink(2)**, **write(2)**, **fopen(3)**, **fifo(7)**, **feature\_test\_macros(7)**



## 2. Function “close”

### NAME

close - close a file descriptor

### SYNOPSIS

```
#include <unistd.h>

int close(int fd);
```

### DESCRIPTION

**close()** closes a file descriptor, so that it no longer refers to any file and may be reused. Any record locks (see **fcntl(2)**) held on the file it was associated with, and owned by the process, are removed (regardless of the file descriptor that was used to obtain the lock).

If *fd* is the last copy of a particular file descriptor the resources associated with it are freed; if the descriptor was the last reference to a file which has been removed using **unlink(2)** the file is deleted.

### RETURN VALUE

**close()** returns zero on success. On error, -1 is returned, and *errno* is set appropriately.

### ERRORS

#### EBADF

*fd* isn't a valid open file descriptor.

#### EINTR

The **close()** call was interrupted by a signal.

#### EIO

An I/O error occurred.

### CONFORMING TO

SVr4, 4.3BSD, POSIX.1-2001.

### NOTES

Not checking the return value of **close()** is a common but nevertheless serious programming error. It is quite possible that errors on a previous **write(2)** operation are first reported at the final **close()**. Not checking the return value when closing the file may lead to silent loss of data. This can especially be observed with NFS and with disk quota.

A successful close does not guarantee that the data has been successfully saved to disk, as the kernel defers writes. It is not common for a filesystem to flush the buffers when the stream is closed. If you need to be sure that the data is physically stored use **fsync(2)**. (It will depend on the disk hardware at this point.)

### SEE ALSO

**fcntl(2)**, **fsync(2)**, **open(2)**, **shutdown(2)**, **unlink(2)**, **fclose(3)**

## 3. Function “read”

### NAME

read - read from a file descriptor

### SYNOPSIS

```
#include <unistd.h>

ssize_t read(int fd, void *buf, size_t count);
```

### DESCRIPTION

`read()` attempts to read up to `count` bytes from file descriptor `fd` into the buffer starting at `buf`. If `count` is zero, `read()` returns zero and has no other results. If `count` is greater than `SSIZE_MAX`, the result is unspecified.

### RETURN VALUE

On success, the number of bytes read is returned (zero indicates end of file), and the file position is advanced by this number. It is not an error if this number is smaller than the number of bytes requested; this may happen for example because fewer bytes are actually available right now (maybe because we were close to end-of-file, or because we are reading from a pipe, or from a terminal), or because `read()` was interrupted by a signal. On error, -1 is returned, and `errno` is set appropriately. In this case it is left unspecified whether the file position (if any) changes.

### ERRORS

#### EAGAIN

Non-blocking I/O has been selected using `O_NONBLOCK` and no data was immediately available for reading.

#### EBADF

`fd` is not a valid file descriptor or is not open for reading.

#### EFAULT

`buf` is outside your accessible address space.

#### EINTR

The call was interrupted by a signal before any data was read.

#### EINVAL

`fd` is attached to an object which is unsuitable for reading; or the file was opened with the `O_DIRECT` flag, and either the address specified in `buf`, the value specified in `count`, or the current file offset is not suitably aligned.

#### EIO

I/O error. This will happen for example when the process is in a background process group, tries to read from its controlling tty, and either it is ignoring or blocking `SIGTTIN` or its process group is orphaned. It may also occur when there is a low-level I/O error while reading from a disk or tape.

#### EISDIR

`fd` refers to a directory.

Other errors may occur, depending on the object connected to `fd`. POSIX allows a `read()` that is interrupted after reading some data to return -1 (with `errno` set to `EINTR`) or to return the number of bytes already read.

### CONFORMING TO

SVr4, 4.3BSD, POSIX.1-2001.

### RESTRICTIONS

On NFS file systems, reading small amounts of data will only update the time stamp the first time, subsequent calls may not do so. This is caused by client side attribute caching, because most if not all NFS clients leave `st_atime` (last file access time) updates to the server and client side reads satisfied from the client's cache will not cause `st_atime` updates on the server as there are no server side reads. UNIX semantics can be obtained by disabling client side attribute caching, but in most situations this will substantially increase server load and decrease performance. Many filesystems and disks were considered to be fast enough that the implementation of `O_NONBLOCK` was deemed unnecessary. So, `O_NONBLOCK` may not be available on files and/or disks.

### SEE ALSO

`close(2)`, `fcntl(2)`, `ioctl(2)`, `lseek(2)`, `open(2)`, `pread(2)`, `readdir(2)`, `readlink(2)`, `readv(2)`, `select(2)`, `write(2)`, `fread(3)`

## 4. Function “write”

### NAME

write - write to a file descriptor

### SYNOPSIS

```
#include <unistd.h>

ssize_t write(int fd, void *buf, size_t count);
```

### DESCRIPTION

**write()** writes up to *count* bytes to the file referenced by the file descriptor *fd* from the buffer starting at *buf*. POSIX requires that a **read()** which can be proved to occur after a **write()** has returned returns the new data. Note that not all file systems are POSIX conforming.

### RETURN VALUE

On success, the number of bytes written are returned (zero indicates nothing was written). On error, -1 is returned, and *errno* is set appropriately. If *count* is zero and the file descriptor refers to a regular file, 0 may be returned, or an error could be detected. For a special file, the results are not portable.

### ERRORS

#### EAGAIN

Non-blocking I/O has been selected using **O\_NONBLOCK** and the write would block.

#### EBADF

*fd* is not a valid file descriptor or is not open for writing.

#### EFAULT

*buf* is outside your accessible address space.

#### EFBIG

An attempt was made to write a file that exceeds the implementation-defined maximum file size or the process' file size limit, or to write at a position past the maximum allowed offset.

#### EINTR

The call was interrupted by a signal before any data was written.

#### EINVAL

*fd* is attached to an object which is unsuitable for writing; or the file was opened with the **O\_DIRECT** flag, and either the address specified in *buf*, the value specified in *count*, or the current file offset is not suitably aligned.

#### EIO

A low-level I/O error occurred while modifying the inode.

#### ENOSPC

The device containing the file referred to by *fd* has no room for the data.

#### EPIPE

*fd* is connected to a pipe or socket whose reading end is closed. When this happens the writing process will also receive a **SIGPIPE** signal. (Thus, the write return value is seen only if the program catches, blocks or ignores this signal.)

Other errors may occur, depending on the object connected to *fd*.

### CONFORMING TO

SVr4, 4.3BSD, POSIX.1-2001.

Under SVr4 a write may be interrupted and return EINTR at any point, not just before any data is written.

### NOTES

A successful return from **write()** does not make any guarantee that data has been committed to disk. In fact, on some buggy implementations, it does not even guarantee that space has successfully been reserved for the data. The only way to be sure is to call **fsync(2)** after you are done writing all your data.

### SEE ALSO

**close(2)**, **fcntl(2)**, **fsync(2)**, **ioctl(2)**, **lseek(2)**, **open(2)**, **pwrite(2)**, **read(2)**, **select(2)**, **writev(3)**, **fwrite(3)**

## 5. Function “ioctl”

### NAME

ioctl - control device

### SYNOPSIS

```
#include <sys/ioctl.h>

ssize_t ioctl(int d, int request, ...);
```

### DESCRIPTION

The **ioctl()** function manipulates the underlying device parameters of special files. In particular, many operating characteristics of character special files (e.g. terminals) may be controlled with **ioctl()** requests. The argument *d* must be an open file descriptor.

The second argument is a device-dependent request code. The third argument is an untyped pointer to memory. It's traditionally **char \*argp** (from the days before **void \*** was valid C), and will be so named for this discussion.

An **ioctl()** *request* has encoded in it whether the argument is an *in* parameter or *out* parameter, and the size of the argument *argp* in bytes. Macros and defines used in specifying an **ioctl()** *request* are located in the file `<sys/ioctl.h>`.

### RETURN VALUE

Usually, on success zero is returned. A few **ioctl()** requests use the return value as an output parameter and return a nonnegative value on success. On error, -1 is returned, and *errno* is set appropriately.

### ERRORS

#### EBADF

*d* is not a valid descriptor.

#### EFAULT

*argp* references an inaccessible memory area.

#### EINVAL

*Request* or *argp* is not valid.

#### ENOTTY

*d* is not associated with a character special device.

#### ENOTTY

The specified request does not apply to the kind of object that the descriptor *d* references.

### NOTE

In order to use this call, one needs an open file descriptor. Often the **open(2)** call has unwanted side effects, that can be avoided under Linux by giving it the `O_NONBLOCK` flag.

### CONFORMING TO

No single standard. Arguments, returns, and semantics of **ioctl(2)** vary according to the device driver in question (the call is used as a catch-all for operations that don't cleanly fit the Unix stream I/O model). See **ioctl\_list(2)** for a list of many of the known **ioctl()** calls. The **ioctl()** function call appeared in Version 7 AT&T Unix.

### SEE ALSO

**execve(2)**, **fcntl(2)**, **ioctl\_list(2)**, **open(2)**, **mt(4)**, **sd(4)**, **tty(4)**

## Appendix B: How to Cross-Compile tcpdump

Note: you do not need super-user privileges in order to be able to build the utility.

Download and unpack libcap and tcpdump (in this example, to `/home/rmu/tcpdump/`):

```
cd /home/rmu; mkdir tcpdump; cd tcpdump
wget http://www.tcpdump.org/release/tcpdump-3.9.5.tar.gz
wget http://www.tcpdump.org/release/libpcap-0.9.5.tar.gz
```

The environment variables need to be set for the console where we are going to build both libpcap and tcpdump:

```
export PATH=$PATH:/opt/eldk-3.1.1/usr/bin:/opt/eldk-3.1.1/bin
export CROSS_COMPILE=ppc_82xx-
export CC=ppc_82xx-gcc
export ARCH=ppc
export ac_cv_func_setvbuf_reversed=no
export ac_cv_linux_vers=2
```

libcap:

```
cd /home/rmu/tcpdump
tar zxf libpcap-0.9.5.tar.gz
cd libpcap-0.9.5

./configure --target=powerpc-linux --host=i686-pc-linux-gnu
--build=powerpc-linux --prefix=`pwd`/_install --exec-
prefix=`pwd`/_install-bin --with-pcap=linux

make; make install
```

tcpdump:

```
cd /home/rmu/tcpdump
tar zxf tcpdump-3.9.5.tar.gz
cd tcpdump-3.9.5

./configure --target=powerpc-linux --host=i686-pc-linux-gnu
--build=powerpc-linux --prefix=`pwd`/_install --exec-
prefix=`pwd`/_install-bin LDFLAGS=-L/home/rmu/tcpdump/libpcap-
0.9.5-ppc/_install-bin/lib CFLAGS=-I/home/rmu/tcpdump/libpcap-
0.9.5-ppc/_install/include --without-crypto

make; make install
```

As a result of successful configuration and build you get ready-to-run binary:

```
~ $ ls -al /home/rmu/tcpdump/tcpdump-3.9.5/_install-bin/sbin
-rwxr-xr-x 1 mm users 730077 2007-01-15 12:31 tcpdump
```

To reduce some space, the binary could be stripped:

```
~ $ ppc_82xx-strip /home/rmu/tcpdump/tcpdump-3.9.5/_install-
bin/sbin/tcpdump
~ $ ls -al /home/rmu/tcpdump/tcpdump-3.9.5/_install-bin/sbin
-rwxr-xr-x 1 mm users 655036 2007-01-15 12:31 tcpdump
```

## Appendix C: How to Cross-Compile Boa Web Server

Note: you do not need super-user privileges in order to be able to build the utility.

Download and unpack sources (in this example, to `/home/rmu/boa/`):

```
cd /home/rmu; mkdir boa; cd boa
wget http://www.boa.org/boa-0.94.14rc21.tar.gz
```

The environment variables need to be set for the console:

```
export PATH=$PATH:/opt/eldk-3.1.1/usr/bin:/opt/eldk-3.1.1/bin
export CROSS_COMPILE=ppc_82xx-
export CC=ppc_82xx-gcc
export ARCH=ppc
export ac_cv_func_setvbuf_reversed=no
export ac_cv_linux_vers=2
```

boa:

```
cd /home/rmu/boa
tar xzf boa-0.94.14rc21.tar.gz
cd boa-0.94.14rc21

./configure --target=powerpc-linux --host=i686-pc-linux-gnu
--build=powerpc-linux --prefix=`pwd`/_install --exec-
prefix=`pwd`/_install-bin

make
```

As a result of successful configuration and build you get ready-to-run binary:

```
~ $ ls -al /home/rmu/boa/boa-0.94.14rc21/src/boa
-rwxr-xr-x 1 mm users 656910 2007-01-15 17:11 boa
```

To reduce some space, the binary could be stripped:

```
~ $ ppc_82xx-strip /home/rmu/boa/boa-0.94.14rc21/src/boa
~ $ ls -al /home/rmu/boa/boa-0.94.14rc21/src/boa
-rwxr-xr-x 1 mm users 77800 2007-01-15 17:12 boa
```

Please, note significant reduction of binary size.

# Specifications

## Physical Specifications

Criteria	Specifications
Dimensions	4" H x 4" W x 1.5"D plus 0.7" per I/O slot
I/O Connector	37-pin male D-sub
Ethernet Connector	100 BaseT, RJ45 with EMI filter, LED indicators
RS-232 Connector	DB9 male connector
Weight	600g (1.32 lb)

## Environmental Specifications

Criteria	Specifications
Operating Temperature	0 to +55°C
Storage	-40 to +85 °C
Humidity	5 to 95% non-condensing

## Functional Specifications

Criteria	Specifications
PowerPC	400 MHz, 760 MIPS with support of floating point instructions
On board Flash	16 MB
SDRAM	128 MB
CompactFlash Port	Type II, currently tested up to 4GB
RS232	4 RS232 interface. (1 port used for diagnostics port, software selectable 485 on 2 of ports)
BUS Interface	2 isolated Ethernet ports – Modbus/TCP or Ethernet/IP
USB	USB 1.1 port
Front Panel Indicators	Network Status, Module Status, LINK, 100MB
Rotary Switches	IP address, operating mode

## Power Specifications

Criteria	Specifications
Input	Powered from I/O connector +24VDC@120 mA min
Isolation	DC/DC Isolation, 2.5KVrms
Over Current Protection	
Each Channel	1.5A
Total	3.0A

## Input/Output Specifications per Card

Criteria	Specifications
<b>DIDO Card</b>	
Number of Digital I/O	24 points (input or output)
Response Time	50µsec
Digital Input	
Sink	
Current sinking	1.5 mA min, Max -2.18 mA at Vin=0V
Logic Low Voltage	Min 8.1V to Max 30V
Logic High Voltage	Min 0V to Max 7V
Source	
Current sourcing	1.5 mA min, Max 2.33 mA at Vin=24V
Input Low Voltage	Min 0V to Max 6V
Input High Voltage	Min 6.5V to Max 30V
Digital Output	

**RMU2 User Manual**


---

<b>Sink</b>	
Current sinking	200 mA max / channel
Output OFF Voltage	Min 23.8V @ 580uA @ $R_L=240\Omega$ Min 23.8V @ 1mA @ $R_L=120\Omega$
Output ON Voltage	Max 240mV @ 200mA @ $R_L=120\Omega$ Max 133mV @ 100mA @ $R_L=240\Omega$
<b>Source</b>	
Current sourcing	200 mA max / channel
Current max	750 mA per 6 DO
Output ON Voltage	Min 23.3V @ 100mA @ $R_L=240\Omega$ Min 23.1V @ 200mA @ $R_L=120\Omega$
Output OFF Voltage	Max 0V @ 0uA @ $R_L=120\Omega$ Max 0V @ 0mA @ $R_L=240\Omega$

---

**AIAO Card**


---

Analog Accuracy	0.1% Full scale (-10V to 10V)
Analog Response Time	200 $\mu$ sec
Analog Input	16 single-ended points or 8 differential points (s/w selectable) 14 bit 1Khz RC filter
Analog Output	8 single-ended points 12 bit Range (-10 to +10V) 5mA / channel into a 2 K $\Omega$ load

---

**COMBO Card**


---

Number of Digital I/O	16 points (input or output)
Response Time	50 $\mu$ sec
Digital Input	Current sinking 1.5 mA min, Current sourcing 1.5 mA min,
Digital Output	Current sinking 200 mA max / channel Current sourcing 200 mA max / channel Current max 750 mA per 6 DO
Analog Accuracy	0.1% Full scale (-10V to 10V)
Analog Response Time	200 $\mu$ sec
Analog Input	8 single-ended points or 4 differential points (s/w selectable) 14 bit 1khz RC filter
Analog Output	2 differential points 12 bit Range (-10 to +10V) 5mA / channel into a 2 K $\Omega$ load

---



## Model Code Description

The Model code of RMU defines the features of the Unit for Hardware, software and other options:

	BASE	OPTIONS	SLOT 1	SLOT 2	SLOT 3	SLOT 4
Format:	RMU2	- C D CF	- DIDO AIAO AI AH AC COMB	- DIDO AIAO AI AH AC COMB	- DIDO AIAO AI AH AC COMB	- DIDO AIAO AI AH AC COMB

### Options

- E With CAN and (2) additional RS232/485 ports
- D With Display and Function Keys
- CF CompactFlash, range 64MB to 4GB

### Slot Designations

- DIDO 24 Channel Digital I/O Card
- AIAO 16 Channel Analog In, 8 Channel Analog Out
- AI 16 Analog Inputs (Voltage Type Inputs)
- AH 16 Analog Inputs (High impedance, 1Mohm)
- AC 8 Analog Inputs (Current Type Inputs)
- COMB Combination: 16DIDO, 4AI-DIF, 2AO-DIF



## WARRANTY

MKS Instruments, Inc. (**MKS**) warrants that for one year from the date of shipment the equipment described above (the “equipment”) manufactured by **MKS** shall be free from defects in materials and workmanship and will correctly perform all date-related operations, including without limitation accepting data entry, sequencing, sorting, comparing, and reporting, regardless of the date the operation is performed or the date involved in the operation, provided that, if the equipment exchanges data or is otherwise used with equipment, software, or other products of others, such products of others themselves correctly perform all date-related operations and store and transmit dates and date-related data in a format compatible with **MKS** equipment. THIS WARRANTY IS **MKS**’ SOLE WARRANTY CONCERNING DATE-RELATED OPERATIONS.

For the period commencing with the date of shipment of this equipment and ending one year later, **MKS** will, at its option, either repair or replace any part which is defective in materials or workmanship or with respect to the date-related operations warranty without charge to the purchaser. The foregoing shall constitute the exclusive and sole remedy of the purchaser for any breach by **MKS** of this warranty.

The purchaser, before returning any equipment covered by this warranty, which is asserted to be defective by the purchaser, shall make specific written arrangements with respect to the responsibility for shipping the equipment and handling any other incidental charges with the **MKS** sales representative or distributor from which the equipment was purchased or, in the case of a direct purchase from **MKS**, with the **MKS-CIT** home office in San Jose, CA

This warranty does not apply to any equipment, which has not been installed and used in accordance with the specifications recommended by **MKS** for the proper and normal use of the equipment. **MKS** shall not be liable under any circumstances for indirect, special, consequential, or incidental damages in connection with, or arising out of, the sale, performance, or use of the equipment covered by this warranty.

THIS WARRANTY IS IN LIEU OF ALL OTHER RELEVANT WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY AND THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, AND ANY WARRANTY AGAINST INFRINGEMENT OF ANY PATENT.