


MB-3688

120A 12V/24V DC PROGRAMMABLE DUAL BATTERY ISOLATOR

User Manual



Warning and Precautions

MB-3688 is built with corrosion resistant material and the main electronic assembly is well sealed inside the die cast alloy. This unit is not designed for environments that would allow water to come in contact with the terminals on the housing which result a short circuit.

The unit can be installed in any position but make sure that there is sufficient ventilated space around the unit to allow dissipation heat at the surface, a minimum of 50mm surrounding space is required.


When use with lead acid battery, make sure there is sufficient ventilation for the battery which can emit harmful & explosive and away from any possible spark or naked fire such as cigarette.

Cable Sizes and Fuses

Cables used at each positive terminal must be of sufficient rating. Under sized cables would affect the performance of the unit and shortens the life span. Wires connected to control or signal ports ① ② ③ ④ carry less than 0.5 Amp.

Fuses or circuit breakers of appropriate rating must be installed at positive terminal of the house battery and main battery. These fuses are for the safety and protection of the vehicle's electrical system in case of a short to the negative ground.

Warning for using the Remote Over-ride to start the vehicle

Always check if the house battery bank has sufficiently higher voltage than the main battery to do the job by pressing the  buttons when the unit is at OFF mode.

If house battery voltage is lower than the main battery, it would not work and deplete the Main (starting) battery further.

Large current will generate high heat on the cable and terminals during the cranking so do not over crank.

Allow sufficient time after first Over-Ride has been done.

It pays to investigate the real cause for the failure of starting the car and the draining out of the starting battery.

1. General description

This dual battery isolator is designed to be customized to meet your vehicle's specific application. The DC power system of various types alternator, main battery, house battery and loading usage are numerous and also change with time. It features the fine tuning of key voltages, delay time set points and constant monitoring of each battery to provide the maximal charging and protection of your batteries.

The reliable and efficient Mosfet switching has minimal voltage loss resulting much less generated heat than diode based isolators. Microprocessor Controlled circuit provides accurate monitoring, finer tuning of voltage, delay timer set points and more fail safe protection with diagnostic display.

2. Advanced Features

- Alert Voltage:
The additional Alert Voltage setting is to monitor the main battery voltage even when the unit in isolated mode and when the main battery voltage drops below the set Alert Voltage, the Remote LED Module will out slow flashes to alert end user.
- Remote LED Module with Over-Ride
With the supplied Remote LED module w Over-Ride accessory, end user is constantly informed about the status of the Isolator whether it is in Connection Mode, Isolation Mode, Main Battery is above or at Alert low level and Isolator is in Protection Mode.
- Selectable 12V or 24V system
- Selectable Ignition Control
- Wide range of programmable threshold voltages (connect, isolate, alert) with high resolution and respective delay time.
- Monitoring of Main and House battery voltage in Isolation Mode.

3. Intended Applications:

Caravan, vehicle with second battery, solar / wind charging multiple battery banks.

This unit when using between two batteries, it functions as an isolator as following:

- It isolates the main (starting) battery from the house battery in normal operating condition.
- It allows charging (connect) of the house battery only when the main battery voltage is higher than the selected Connect Voltage setting and or when ignition is switched on (if this Ignition function is selected).

This way, it also diverts excess power from the alternator to run equipment that feeds from the house battery.

It does not allow the house battery to power the car electronics or feed into the starting of the car unless the manual Over-Ride Connection is activated.

It prevents excessively large charging current dumping into the depleted house battery from the main battery and rapid repeated on-off by appropriate setting of the threshold voltages and delay times.


- When it is used with one battery and a load, it acts as a low voltage cut off to keep the battery from over discharge according to the selected voltages setting.

- **N.O.** Normally Open uses Connect Voltage as threshold voltage. Main and House battery are normally disconnected until voltage at the main battery reaches Connect Voltage.

This Normally Open is the factory preset and good for the isolator dual battery application.

- **N.C.** Normally Close uses Isolate Voltage as the threshold voltage. Main and House battery are normally connected until voltage at the main battery reaches Isolate Voltage.

- This normally close setting is suitable for application with single load or connection is a priority in the first place until the DC source drops below the Isolate Voltage



- ① R = Remote Over-ride Port for manual connection of the main and house terminal
- ② A = Remote Alert Signal Port (System Voltage, 100mA max.)
- ③ Ign. = Ignition Control Port
- ④ Neg. = Negative (Ground) Port
- ⑤ Main battery positive
- ⑥ House battery positive
- ⑦ Control buttons
- ⑧ LED indicators (to indicate the setting status)
- ⑨ 3 digits LED display
 - to display batteries voltage
 - status (ON/OFF)
 - set voltage and delay time
 - set menu

4. Programming Operation of MB-3688

There are 3 types of Set Menu Mode:

Mode 1 is for selection of 12V or 24V when the unit is first activated.


Mode 2 is for adjusting the threshold values of voltages and the related delay time.



Mode 3 is to confirm change of system state such as normal open/ close, ignition control and return to default factory setting.

The product will automatically exit with the new settings or return to the last set values after 10 seconds for Mode 1 and 20 seconds for Mode 2 and 3.

First activate the unit by connecting Main Terminal ⑤ to Positive and Neg. ④ to Negative of a 12V battery for 12V system and 24V battery for 24V system.

4.1 Set Menu Mode 1 ----- Setting of 12V or 24 V system

Press the  /  button to toggle 12V or 24V shown on Display.

Confirm your selection by pressing the  button for 12V system to  button for 24V system for a few seconds.

Display will show the *software version* to confirm setting then the battery voltage.




If no selection is done within 10sec., unit will go back to last set system voltage.

Remark: You have about 10 seconds to confirm your setting otherwise the product will go to the last set system voltage or factory default setting.



4.2 Set Menu Mode 2 ----- Viewing the Connect Voltage/ Isolate Voltage/ Alert Voltage/ Delay Time

This is the most used Set Menu Mode.


You have to pair the top LED “VOLT”, “SEC” with the bottom LED “connect”, “isolate” & “alert” to interpret the reading on the Display as shown in the following diagrams.

To enter into this mode Press both  and  button simultaneously until display shows  then the factory default Connect Voltage.


You can review the last set values of Connect, Isolate, Alert Voltages, Delay Times and etc.

by toggle the  (forward) or  (back) buttons and take note the pair of lit up LEDs


Connect Voltage (Default 13.7V for 12V system)




Connect Delay Time (Default 5sec)




Isolate Voltage (Default 12.8V for 12V system)




Isolate Delay Time (Default 5sec)



Alert Voltage (Default 12.0V for 12V system)



Alert Delay Time (Default 10sec)







4.3 Set Menu Mode 2 ----- Setting the Connect Voltage / Isolate Voltage / Alert Voltage / Delay Time

The procedure is same for setting and adjusting all the above parameters.

Example: Setting Connect Voltage

During the Review stage as in 4.2, toggle the  or  button to get to Connect Voltage position.

To set the Connect Voltage press both  and  button simultaneously again so that the displayed connect voltage **flashes**.

Press  or  button to increase or decrease the connect voltage to your desired voltage level.


Press both buttons simultaneously until display becomes solid to confirm new setting.

Continue to do other setting in the same way.



The product will return to exit from Set Mode 2 automatically after 20 seconds with the new settings.

4.4 Set Mode 3 for change of system controls as indicated in the (yellow imprints)

N.O. / N.C. (Normally Open / Normally Close), IGNITION CONTROL, FACTORY DEFAULT








Get to the Set Mode 2 first then press  button until Display shows 

Press both  &  button simultaneously to get to SET MODE 3


Display shows  first, then  or , ,  as Up button is pressed.

Return to the Factory Default Example:

 Press both Up & Down button simultaneously


Flashing  /  toggle by  or  button to 

Confirm by Press both  &  button simultaneously

 become solid to confirm return to the factory default setting has been done.

Unit will return to exit from Set Mode 2 automatically after 20 seconds with the new settings.

N.O. / N.C. Application

 MODE (Normally Open) This is the factory default mode.

The two terminals are normally isolated, (disconnected, open) when the unit is powered up.

The two terminals will be connected when the voltage at the main battery terminal is detected to be at the programmed "Connect Voltage" level (LVR) and after the set programmed DELAY TIME.


 MODE (Normally Close) This mode is selectable.

The two terminals are normally connected, close when the unit is powered up.


The two terminals will be disconnected, isolated, opened when the voltage at the main and after the set programmed DELAY TIME.

This mode is commonly used for battery protector application. The load will be on until the voltage of battery or other dc source drops below the set isolated voltage level.

Ignition Control application 

When the ignition control is set to , the unit only can be operated with car ignition switched ON.

The factory default setting of Ignition Control is at OFF mode, that is the unit is in operation all the time even when car ignition is switched off.

When the ignition control is set to , the unit can only be operated with car ignition is switched on and when the car is switched off the unit is also off.

See wiring diagram in section 6 for connection from Ignition Control Port (3) to the car's electrical point which has current when the car is switched on.

Remark: over-ride switch will connect main and house terminal irrespective ignition control is on or off.

5. Operation of MB-3688

The LED display and Remote Alert signal port

Normally the display is turned off to conserve energy, press any one of the two buttons to operate:

When unit is in isolated (disconnect) mode, the display shows **OFF**.

Press  Button to view Main (battery) terminal voltage

Press  Button to view House (battery) terminal voltage.

When unit is in Connected mode, the display shows **ON**.

Only one voltage (shared by both terminals) is shown on the display.

Status of the unit such as Connect, Isolate, Protection can also be remotely indicated by the supplied accessory Remote LED Module connected to the Remote Alert signal port.

5.1 Protection Diagnosis Table


Display Icon	Protection	Causes	Suggested Solution	Self-Recoverable or Manual Reset
oVP	Over Voltage Protection	Main Terminal Ⓢ Voltage >16V	Check DC source voltage to main terminal Ⓢ. Check load at terminal Ⓢ	Unit is self-recoverable when main battery voltage lower than 15.5V
ocP	Over Current / Over Load Protection	Over Current >120Amp	Check house battery level. Look for possible intermittent short circuit in the wiring.	Unit is self-recoverable after 1 minute. In case of ocP occurs 3 times in a row, a final protection will lock up the unit until complete reset by disconnect and reconnect the battery.
otP	Over Temperature Protection	Unit Over Temperature 90°C	Check location of unit is well ventilated. Check cable size is sufficiently rated.	Unit is self-recoverable when internal temperature cool down to below 70°C
lVP	Low Voltage Protection	Main Terminal Ⓢ Voltage <8V	Check main battery status and alternator.	Unit is self-recoverable when the main battery voltage >10V.

Remark: The above voltage setting in the table is only for 12V system, the voltage setting is double for 24V system.


6. Installation notes:

- 6.1 The unit is factory default as Normal Open **NO**. In case you want to use the unit as Normal Close, please go to the set mode and set the unit to **NC**.
- 6.2 The Ignition Control feature is factory default as OFF. In case you want to control the unit by car ignition switch, please go to the set mode and set the Ignition control to **YES**.
- 6.3 The recommended cable size is AWG#5 with 1M in length and 3% acceptable loss.
- 6.4 Always double check the tightness of all connections by wiggling the connected terminals and etc. Connectors and fasteners are prone to vibration loosening in a moving vehicle.
Loosen connections cause sparks.
- 6.5 It is recommended to install a fuse with suitable rating connected to the battery positive terminal for safety.
!! CAUTION: Surface is hot during operation

7. Installation for a Two Battery System (Example for 12VDC system)



8. Installation for a One Battery System (Example for 12VDC system)



- 8.1 The selected Isolate Voltage is usually lower than the two battery system since the unit here is mainly used as a protection against over discharging the battery.
- 8.2 However, the selection of Isolate Voltage and Connect Voltage are very much affected by the type of load and relative battery capacity. Select a higher Isolate Voltage for relatively smaller load; for high initial draw load such as Motor, choose a lower Isolate Voltage.
- 8.3 It is advisable to use a higher value of Connect Voltage to ensure a more completed charging operation.
- 8.4 Check the battery's specifications for suitable Connect Voltage and Isolate Voltage and in cycling or standby applications.

9. MANUAL FOR WIRING AND OPERATION OF THE CONTROL TERMINALS

Functions of the 4 Control terminals

[Neg] **Negative terminal:** Connect this to the chassis ground of the negative grounded vehicle.

[Ign] **Ignition control:** To turn ON/OFF the isolator synchronized with car ignition switch.
Connect this to the spot which is powered up when the Ignition switch is on.

[A] **External Alert/ Alarm port:** An external signal voltage to indicate the operation status of the unit.
It synchronizes with the Alert Voltage and delay time setting.
It gives out warning signal when unit is under protection.

On: The unit is connected



Off: The unit is isolated

Slow flash: To alert you the main battery voltage lower than default 12.0V or your set alert voltage.


Fast flash: Protection signal, the unit is isolated

[R] **Remote Override terminal:** Use the supplied accessory Remote LED indicator with Override button which has a momentary contact switch.
To manually connect the Main and House terminal via a momentary contact switch or toggle switch. [see wiring diagram in section 7]
After one 'make' as in the case of momentary contact switch, the connection of Main and House battery will last for about 20 seconds.
Use normal switch for continuous on/ off operation.

During Remote Override On condition, display shows `r o n` to indicate connection

Remark: When use for emergency boosting up the starter battery (main) , make sure to check voltage of house and main battery by pressing the   buttons that the voltage of the house battery bank is higher than the starter battery.

9.1 Connection of the supplied accessory “Remote LED indicator with Override button” to the above control port [Neg.], [A], [R]



Black wire to [Neg.]

Red wire to Main terminal

Green wire to [R]

Yellow wire to [A]

Negative ground

Remote Override function

Remote Override function

LED indicator

Remark: In case the Remote Over-ride Connection is not in operation, please do not wire up Main terminal and [R] port.

10. SPECIFICATIONS

Battery Voltage System	12V System		24V System	
	Default	Range	Default	Range
Connect Voltage	13.7VDC	9.2 - 16VDC	27.4VDC	18.4 - 32VDC
Isolate Voltage	12.8VDC	9 - 15.8VDC	25.6VDC	18 - 31.6VDC
Alert Voltage	12.0VDC	9 - 15.9VDC	24.0VDC	18 - 31.8VDC
Connect Delay	5 seconds	1 - 250 seconds	5 seconds	1 - 250 seconds
Isolate Delay	5 seconds	1 - 250 seconds	5 seconds	1 - 250 seconds
Alert Delay	10 seconds	1 - 250 seconds	10 seconds	1 - 250 seconds
Isolator Setting Accuracy	±0.2V			
Resolution	0.1V 1 seconds			
Operating Voltage				
	9 - 17VDC Nominal		18 - 34VDC Nominal	
Continuous Contact Current				
	120Amp			
Current draw in Isolate Mode				
	Less than 30mA (add approx 20mA when LED display is active)			
Current draw in Combine Mode				
	Less than 50mA (add approx 20mA when LED display is active)			
Voltage drop with 120A (Main battery to Aux. battery)				
	130mV			
Protections				
System Under Voltage				
	Disconnect (Auto reconnect when condition returns to normal)			
System Over Voltage				
	Disconnect (Auto reconnect when condition returns to normal)			
System Overload and Short Circuit				
	Disconnect (complete reset by disconnect and reconnect the battery)			
Unit Over Temperature				
	Disconnect (Auto reconnect when condition returns to normal)			
Advance Feature				
Ignition Control				
	Yes (Default as OFF)			
Normal Open/ Close (N.O./ N.C.)				
	Yes (Default as normal open)			
Remote Alert Provision for LED Indication				
	Yes (System Voltage, 100mA Max.)			
Conditional Manual Over-ride (connect) Mode				
	Yes (Remote Input +12VDC)		Yes (Remote Input +24VDC)	
Main Battery and House Battery Voltage Display				
	When unit in Isolated Mode			
Operating Temperature Range				
	-20°C to +60°C			
Operating Humidity				
	10% to 90% RH non-condensing			
Environmental Protection (Internal Component only)				
	IP67			
Approval				
	CE EN 61000-6-1, EN 61000-6-3, EN 50498			
Supplied Accessory				
	Remote LED Module with Over-Ride and 2M Cable			
Dimensions (L x W x H)				
	90 x 90 x 85 mm (3.5 x 3.5 x 3.4 inch)			
Weight				
	0.6kg (1.3lbs)			