


# User Manual for Rack Monitoring System




## SAFE WORKING

Important passages which must be observed are highlighted with the following symbols:




### **Danger**

**Calls attention to safety measures to prevent personal injury**



### **Note**

*Recommends actions and provides tips for trouble-free operation*



### **Caution!**

Highlights what must be done or not done in order not to damage material assets.



### **Attention**

The Rms LITE will be delivered without LCD-display and front console

## VALIDITY OF THIS MANUAL

This user manual applies exclusively to the RMS Rack Monitoring System.  
Software version: 2.0

## RMS PERFORMANCE FEATURES



- Illuminated LCD display for plain text displays
  - 4 keys on the front of the device
  - Measurement and monitoring of temperature, humidity, door contact (access), vibration, movement (infrared room surveillance), smoke, mains voltage
  - Flexible filter structure for uncomplicated realisation of even complex signal conditions
  - Operation and display of alarms via LCD display,  serial interface or network (Telnet and SNMP)
- Different interfaces for sensors, data transmission, digital inputs and switching outputs

**LINDY-Elektronik GmbH • LINDY Electronics Ltd.  
LINDY Italia S.r.l. • LINDY France Sarl  
LINDY-Elektronik AG • LINDY Computer Connection  
LINDY Australia Pty Ltd • LINDY International Ltd.**

**E-MAIL: [info@lindy.com](mailto:info@lindy.com)  
Internet: <http://www.lindy.com>**

# CONTENTS

3

<b>1</b>	<b>Please note</b>	<b>1.1 General information</b>	<b>05</b>
		<b>1.2 Safe working</b>	<b>06</b>
		<b>1.3 Warranty</b>	<b>06</b>
		<b>1.4 Service</b>	<b>07</b>
		<b>1.5 Standards, regulations and licence</b>	<b>07</b>
<b>2</b>	<b>Technical description</b>	<b>2.1 Rack monitoring</b>	<b>08</b>
		<b>2.2 Sensors</b>	<b>09</b>
<b>3</b>	<b>Installation and commissioning</b>	<b>3.1 Preparations</b>	<b>11</b>
		<b>3.2 19" installation</b>	<b>12</b>
		<b>3.3 Electrical installation</b>	<b>13</b>
		<b>3.3.1 Connections and cabling</b>	<b>13</b>
		<b>3.3.2 Fuse</b>	<b>16</b>
		<b>3.4 Commissioning</b>	<b>16</b>
<b>4</b>	<b>Operation</b>	<b>4.1 Operator control elements</b>	<b>17</b>
		<b>4.2 Initial state</b>	<b>17</b>
		<b>4.3 Operation via keys on the front of the device</b>	<b>18</b>
		<b>4.4 Operation via Telnet or serial interface COM</b>	<b>20</b>
		<b>4.5 Network configuration</b>	<b>23</b>
		<b>4.5.1 SNMP configuration</b>	<b>24</b>
		<b>4.5.2 Log service</b>	<b>25</b>
		<b>4.6 System configuration and update</b>	<b>25</b>
		<b>4.6.1 Configuration via TFTP</b>	<b>26</b>
		<b>4.6.2 Update via TFTP</b>	<b>26</b>
		<b>4.7 User administration</b>	<b>27</b>
		<b>4.8 I/O configuration</b>	<b>28</b>
		<b>4.8.1 Digital outputs</b>	<b>29</b>
		<b>4.8.2 Digital inputs</b>	<b>30</b>
		<b>4.8.3 Temperature inputs</b>	<b>30</b>
		<b>4.8.4 Humidity inputs</b>	<b>31</b>
		<b>4.8.5 Mains monitoring</b>	<b>31</b>
		<b>4.8.6 Connect external devices via serial interface</b>	<b>32</b>
		<b>4.8.7 AUX device selection</b>	<b>33</b>
		<b>4.9 Filters</b>	<b>34</b>
		<b>4.10 Message log</b>	<b>39</b>
<b>5</b>	<b>Example configuration</b>		
<b>6</b>	<b>Malfunctions</b>		<b>40</b>
<b>7</b>	<b>Technical data</b>		<b>45</b>
<b>8</b>	<b>Glossary</b>		<b>46</b>
			<b>47</b>
	<b>Appendices</b>	<b>A1 Conformity, EMC, CE, FCC</b>	<b>48</b>
		<b>A2 Documentation of the system configuration</b>	<b>49</b>
		<b>A3 Explanation of the MIB for RMS</b>	<b>50</b>
		<b>A4 GNU General Public Licence</b>	<b>57</b>

## 1.1

### GENERAL INFORMATION

#### Normal use

The RMS is supplied in flawless condition in terms of safety.

LINDY can only guarantee the safety, reliability and performance of the device if:

- modifications, conversions or repairs are carried out only by persons authorised by the manufacturer,
- the electrical installation of the installation room conforms with the general requirements according to IEC,
- the device is operated in an office environment (class 3K2 according to EN 60721). More stringent requirements apply to rooms with a higher degree of pollution.
- the device is operated at a maximum ambient temperature of +35°C.

#### Copyright

All rights to this manual are held by LINDY. The reproduction and reprinting even of parts of this Manual are permitted only if the source is stated.

#### Technical status

Technical status 07/2004

LINDY reserves the right, without prior notice,

- to make changes to the design and components and, instead of the stated components, to use equivalent other components in the pursuit of technical progress,
- to change the performance features of the software,
- to change the information in this manual.

#### Liability

LINDY accepts no liability for the complete correctness of the information. In particular, no liability whatsoever is accepted for damage or injury caused as a result of the use of the device.

### SAFE WORKING

**Important passages which must be observed are highlighted as follows in these instructions:**

Danger



**Calls attention to safety measures to prevent personal injury.**

Caution



Highlights what must be done or not done in order not to damage material assets.

Note



*Recommends actions and provides tips for trouble-free operation.*

Attention



The RMS LITE will be delivered without display and front console.

## 1.2.2

**General Safety Information**

For safe operation of the RMS please ensure you read all of this user manual and that you observe the instructions and information contained in it. Please also observe other documentation by manufacturers of connected devices.

- Always keep the user manual within reach of the device.
- Ensure the rack monitoring is in perfect technical condition. Have damage and faults remedied immediately by authorised persons.
- Only use the supplied mains cable.
- When plugging in and unplugging the mains plug,
  - never pull the cable
  - never touch the plug with wet hands
- When connecting devices to the cable clamps, always observe the VDE regulations!
- Do not convert or repair the device yourself!
- Use only original accessories.
- If liquids are spilled on the device, immediately unplug the mains cable from the mains and contact your dealer.
- Protect from heat.

Heat can damage both parts of the outside of the device and internal circuits and components.

- To clean the device, use only cloths moistened with water or washing-up liquid. Alcohol, thinners or similar chemicals damage the surface of the enclosure.

The device contains a lithium battery on the circuit board and toxic substances in the LCD display.

- The device must be disposed of properly

## 1.2.3

**Disposal**

## 1.3

**WARRANTY**

LINDY offers a warranty of 2 years for this products.

For further details, please see the General Terms of Business of LINDY.

The warranty is void if improper modifications are made to the device.

**Lapse of warranty**

## 1.4

### SERVICE

In the event of malfunction, please first follow the instructions in the relevant section (> 5). For all other questions, please do not hesitate to contact LINDY technical support.

### HOTLINE

DE: 0621 / 47 005 - 0  
UK: 01642 754040  
IT: 031 48 40 11  
FR: 0 825 825 111  
CH: 061 335 97 00  
USA: (256) 771-0660  
Australia: 07 3262 9033

### E-MAIL

support@lindy.com

- To receive a speedy reply, please provide the following information:
  - Device type
  - Serial number
  - Software version
  - Configuration file
  - Description of problem
- Please also leave your telephone number.

You will receive a qualified reply by e-mail or telephone.

## 1.5

### STANDARDS, REGULATIONS AND LICENCE

The LINDY RMS has been built and tested in accordance with the relevant guidelines. In connection with installation in a terminal (for example, a rack), the additional requirements in accordance with IEC 950 must be observed and complied with.

The RMS conforms to the safety requirements of the EU Directive on electromagnetic compatibility (EMC) (89/33/EEC) and the low voltage Directive (73/23/EEC).

Below is a list of the standards and regulations on which the RMS is based:

EN 55 022/Class B  
EN 60 950 (IEC 950)  
EN 61 000-4-2  
EN 61 000-4-3

### LICENCE

All LINUX source codes which were used to produce the product and are subject to the GPL (see GNU Public Licence ä A4 ) can be obtained for a service charge. This does not include the source codes of the RMS software itself. However, the LINUX sources are freely available, for example at URL: "<http://metalab.unc.edu/pub/Linux>".

## 2.1


## RACK MONITORING

The RMS monitors, protects and controls all the installations in network, switch cabinet and server racks and their environment.

## RMS LITE



## RMS ADVANCED



## Sensors

Local ambient conditions (for example, temperature or humidity) or operational status (for example fluctuations in mains voltage) can be detected via various sensors and inputs (> 2.2).

## Display



Signals are transmitted and data displayed via an LCD display, serial interface or Ethernet (Telnet or SNMP).

## Inputs and outputs

Digital inputs and switching outputs make it possible to continuously monitor the operating status and ambient conditions in the rack, and to react to events.

## Operation and configuration



The RMS is operated locally via 4 keys on the front.

RMS inputs and settings can be made remotely via the serial interface or via Telnet and SNMP.

The entire configuration of the system is permanently saved. Settings are retained even after a power failure or transportation.

## Software

The operating software of the RMS is subject to continuous improvement and expansion. Updates can be loaded quickly and easily at any time. The latest version is available on the Internet (> 1.4).

## Connection options

The RMS has a wide variety of connection options (> 3.3.1):




- A Three mains monitoring connections (6-pole plug connector)
- B Four digital, potential-free switching outputs (8-pole plug connector)
- C Eight digital, potential-free inputs with 12 V auxiliary voltage (16-pole plug connector)
- D Four digital, potential-free alarm inputs for the connection of differential signal lines (8-pole plug connector)
- E Four modular jacks for temperature or humidity sensor (RJ11)
- F Two potential-free UPS switching inputs (4-pole plug connector)
- G Ethernet network connection (RJ45 – 10 base T)
- H AUX serial interface (SUB-D, 9-pole) to control and monitor external devices (for example, chipcard reader, UPS, ...)
- I COM serial interface (SUB-D, 9-pole) as terminal connection


## 2.2

### SENSORS

#### Temperature (digital)




- Temperature range: 0 °C to 60 °C
- Measuring accuracy: ±1 °C
- Recalibration not necessary
- Cable length: 4 m
- Maximum cable length: 20 m
- With mounting hardware




#### Humidity (digital)



- Humidity range: 10 % to 90 % relative humidity at 0 °C to 60 °C
- Measuring accuracy: ±3 % relative humidity
- Recalibration not necessary
- Cable length: 4 m
- Maximum cable length: 20 m
- With mounting hardware



#### Combined Humidity and Temperature sensor (digital)




Combination of temperature and humidity sensor, equipment as above.



#### Vibration



- Detects movements and vibrations of varying intensity.
- Adjustable sensitivity
- Cable length: 4 m
- Maximum cable length: 20m
- With mounting hardware



#### Smoke alarm




- Optical smoke alarm with German insurance accreditation (VdS) for early detection of fires (producing light smoke).
- Temperature range for deployment: -20 °C to 75 °C
- Cable length: 4 m
- Maximum cable length: 20 m
- With mounting hardware




# 2 TECHNICAL DESCRIPTION

## Door Contact



Monitors access using a magnetic bridge sensor which responds to any magnetic material (no contact required).

- Also for monitoring side panels or cover
- Cable length: 4 m
- Maximum cable length: 20 m
- With mounting hardware



## Chipcard reader



The chipcard reader is integrated in the door frame of the server cabinet.

- It reads chipcards.
- It controls an electrical door opener using DIGITAL OUT 4 if the card is valid.
- It is connected to the AUX serial interface.



## Infrared room surveillance



Detects movements in the surveillance area.

- Adjustable sensitivity
- Sabotage protection
- Cable length: 4 m
- Maximum cable length: 20 m
- With mounting hardware



## Extension cable

- RJ11 cable for temperature or humidity sensors
- Length: 5 m; 10 m; 15 m; 20 m
- 4-core sensor cable (for all other sensors)
- Length: 5 m; 10 m; 15 m; 20 m



## Water sensor



Watersensor to detect floods / water



## Mains Power Strips

Switchable mains power strips can be managed by the RMS

- by RS-232 (IP versions also available)
- 4 out / 1 in (19" 1U)
- 8 out / 2 in (redundant power supply support)



 **Note**

Other sensors can be connected to DIGITAL IN, ALERT IN or UPS IN according to the requirements in 3.3.1.

# 3 INSTALLATION AND COMMISSIONING

## 3.1

### PREPARATIONS

#### Check the supplied items

- RMS
- Power cable (for the country in question)
- User's Manual
- 6 plug connectors
- Serial communication cable (RJ11 connector to 9-pole sub-D socket)
- 10 cable links, stripped
- CD-ROM

#### Transport Damage

##### Danger

If the device has visible transport damage, it must not be taken into operation as its safety is no longer guaranteed.  
• Immediately report transport damage to the carrier and the manufacturer.

## 3.1.2

### Necessary Accessories

#### Note

- Only use original accessories.

*If other sensors are used, pay attention to the specification of the inouts and outputs (> 3.3.1) !*


## 3.1.3

### Necessary Tools



For 19" installation of the RMS (> 3.2):

- 3mm flat-blade screwdriver for fixing the cable
- 4 mounting screws (with washers and nuts) for the 19" rack
- A screwdriver suitable for the mounting screws



# 3 INSTALLATION AND COMMISSIONING

## 3.2 19" installation

When installing the RMS in a rack, the additional requirements in accordance with IEC 950 must be observed and complied with!

- Determine the position in which the RMS is to be located within the 19" rack. Observe the existing number of blanking plates for a uniform rack appearance.

**!** Caution!

**Danger of overheating!**  
Allow sufficient space from built-in fans or air-conditioners to ensure an unimpeded flow of air in the rack.

**X** Note

- Mount the RMS on sliding rails if possible. This makes handling the device easier and reduces wear on the rack.

*If the RMS is mounted freely suspended, hold the device horizontally when tightening the screws and start with the two bottom screws.*

- Mount the RMS in the desired position with 4 mounting screws, washers and nuts.



# 3 INSTALLATION AND COMMISSIONING

## 3.3 ELECTRICAL INSTALLATION

### 3.3.1 Connections and cabling

- 1 Fuse plug > 3.3.3
  - 2 Mains Connections > 3.3.2
  - 3 MAINS MONITORING
  - 4 DIGITAL OUT
  - 5 DIGITAL IN
  - 6 ALERT IN
  - 7 TEMPERATURE/HUMIDITY
  - 8 UPS IN
  - 9 10 BASE T
  - 10 AUX
  - 11 COM
- temperature or humidity sensor connections 1-4  
UPS connections 1 - 2  
RJ45 Ethernet network connection  
Serial interface for the control and monitoring of external devices  
Serial interface for terminal connection

#### RMS ADVANCED



#### RMS LITE

##### Connection

- Before connecting the RMS to the mains, properly connect all the components to the rear of the device. Observe VDE regulations!
- Only have mains voltages connected by authorised skilled persons.
- Use wire end ferrules when connecting litz cables!
- Observe the information on documentation (> A2)!

##### Cabling

- Avoid tensile loads, serious kinking and damage to the cables as a result of sharp edges or unsuitable tools (optional cable protection available).

##### Mains monitoring


- 3 terminal pairs L1, L2 and L3 for the connection of 3 mains voltages
- Potential-free, no common earth reference
- $U_{IN}$  50 ... 255 V AC
- Only have mains voltages connected by authorised skilled persons. Observe VDE regulations!

##### Digital Out

- 4 terminal pairs for the connection of 4 consumers
- Potential-free relay switch contacts
- Relay 108 cycles purely mechanically, 105 cycles at maximum loads-witched
- Maximum load switched 1.5 A at 230 V AC, 2 A at 30 V DC

# 3 INSTALLATION AND COMMISSIONING

## DIGITAL IN



06 12: Overload




**X Note**

- 8 terminal groups (of 4 terminals) for connecting 'break contact/make contact' type devices, or devices with switching output
- Potential-free, digital
- Left terminal pair "IN+" AND "IN-" digital input
- For the connection of a break contact/make contact, an auxiliary voltage of +12 V (top terminal) and an earth reference GND (bottom terminal) can be connected from the right terminal pair using the enclosed cable links (see connection examples below).
- $U_{IN} +5 V \dots +25 V$
- $I_{IN}$  maximum 5 mA
- With auxiliary +12 V supply, maximum current draw of 200 mA
- Auxiliary voltage interruption in connection with overload or short circuit in the sensor cable:

"Fault" LED lights up.

Confirm the "overload" message in the LCD display using the ENTER key, then switch back on in the menu "Aux.Volt." with the ENTER key (> 6 ).

*In the event of interruption of auxiliary voltage, all auxiliary voltages (and thus all sensors) are switched off!*



## ALERT IN



- 4 terminal pairs for the connection of 4 differential signal lines or break contact/make contact type devices (only connect passive components)
- Maximum drawable alarm current approximately 20 mA
- For differential signal lines, ensure that the closed-circuit current of the entire signal line does not exceed a total of 900  $\mu A$ .

## TEMPERATURE/HUMIDITY

- 4 RJ11 modular jacks for the connection only of the Infracplus sensors available in the delivery programme (temperature sensor, humidity sensor or combined temperature/humidity sensor)
- digital

## UPS IN



- 2 terminal pairs for the connection of UPS switching outputs
- Potential-free, digital
- $U_{IN} +5 V \dots +25 V$
- $I_{IN}$  maximum 5 mA

## 10BASET

- RJ45 modular jack for connection to a 10 Mbit Ethernet

# 3 INSTALLATION AND COMMISSIONING

COM



– Serial interface – directly connected to the COM connection on the front of the device.

*Never connect both COM interfaces at the same time!*

Pin	Signal
1	-
2	RXD
3	TXD
4	-
5	GND

Pin	Signal
6	-
7	-
8	-
9	-
-	-



AUX



– Serial interface for the connection of external devices (for example, UPS, fans, airconditioners, chipcard reader heating, ...)

– Specific protocols on request. Please contact your RMS dealer.

Pin	Signal
1	DCD
2	RXD
3	TXD
4	DTE
5	GND

Pin	Signal
6	DSR
7	RTS
8	CTS
9	-
-	-

15


## Cable protection (optional)

- Mount the cable clamp bracket



- Fix the cables with suitable aids (cable binders, etc.) to the sheet metal lugs (serves as a cable grip).

- Insert the cover in the slots on the device, close the cover and snap it into the embossed areas.



# 3 INSTALLATION AND COMMISSIONING

## 3.3.2 Fuses Double -pole fuse / fuse of the neutral wire

 **Caution!**

 **Danger!**

**Fire risk.**  
Only replace fuses with fuses of the same type (250 V, 1 A, slow-acting, high switching)


- Switch off the device and unplug the mains plug.
- Remove the fuse plug and replace the fuse.

**The device is supplied from several power sources.**

• **The device may only be opened by trained personnel. To disconnect the device from the voltage supply before opening:**

- **Disconnect the mains plug.**
- **Disconnect the MAINS MONITORING inputs.**

- Open the cover of the device.
- Replace the fuse and close the device again.



## Fuse for the auxiliary voltage supply

## 3.4

### COMMISSIONING

#### Mains Socket

RMS ready

Only replace fuse F1 on the +12 V auxiliary voltage supply (marked in the device) with a fuse of the same type (250 V, 400 mA, fast-acting, 5 x 20 mm, UL-listed).

- Check that the RMS and the connected components are correctly cabled (> 3.3.1).

The mains socket is on the rear of the device.

- Use only the supplied power cable.

After connection, wait for the message in the LCD display.

- Input the network parameters via Telnet, the COM interface (> 4.4) or by hand via the keys (> 4.3).

If function problems should arise: (> 5)


All functions and displays indicated in the manual depend on the version of the operating software. The latest version is available on the Internet (> 1.4).



# 4 OPERATION

## 4.1 OPERATOR CONTROL ELEMENTS

RMS  
ADVANCED



### RMS ADV. & RMS LITE

- 1** Reset  
Resets the RMS to a defined standard state (> 5).
- 2** LED  
"Fault" (red) lights, up in connection with reset, overload or a serious system fault. "Warning" (yellow) lights up if the conditions of an appropriately configured filter apply (> 4.9), when booting and in connection with Reset. "Power" (green) lights up when the device is supplied with voltage.
- 9** "COM" communication socket for connection to a PC or terminal (serial communication cable included).

### RMS ADVANCED

- 3** Illuminated LCD display. Plain text display of inputs, messages and alarms.
- 4** Contrast controller for the LCD display
- 5** Left key  
Page back in the menu, reduce values
- 6** Right key  
Page forward in the menu, increase values
- 7** MENU key  
Change to menu level
- 8** ENTER key  
Menu selection of confirm values

RMS LITE



### **X** Note

*Never connect both COM interfaces at the same time!*

## 4.2 INITIAL STATE

In the initial state, various status messages are displayed cyclically in the LCD display. Each message is displayed for approximately 2 seconds.

LINDY RMS	Device name
N: RMS	SNMP Information (> 4.5.1)
L: Rechenzentrum	– Name (N)
C: Fred Clever	– Location (L)
	– Contact (C)
1192.168.018.103	Network Information (> 4.5)
N255.255.255.000	– IP Address (I)
B192.168.018.255	– Netmask (N)
G192.168.018.200	– Broadcast Address (B)
	– Gateway Address (G)


# 4.3

## OPERATION VIA KEYS ON THE FRONT OF THE DEVICE



The functions accessible via the keys are mainly displays, i.e. current statuses are displayed without the possibility of entering data. Exception: menu items under "Network – Interface".

### Selecting a menu item



- Change from the initial state to the menu level using the MENU key.

- Change between the menu items using the arrow keys


- Confirm the menu selection with the ENTER key.



Confirmation of the menu item Exit leads to the previous menu level.



Change to the initial state using the MENU key.



### Filter messages




Filter messages are displayed on the LCD display as follows:

- <Message number> (2-digit)
- blank
- <Time> (2-digit)
- <Unit of time> (s; m = min; h; d)
- Blank
- <Filter-designation> (9-digit)

- Confirm filter messages with the ENTER key. In the "Message Log" (> 4.10) the message is marked accordingly in the "Ack" column with an "x". For the filter message to be displayed, it is necessary for the "Message Priority" other than "none" to be assigned in the "Filter Configuration" menu (> 4.9.2).



### Display in the "Confirm" menu



- <Filter-Number> („F"; 2-digit; ":")
- \* (only with confirmed filter)
- <Current filter result > (3-digit: "off" or "on")
- Blank
- <Filter-designation> (9-digit)

For the display, it is necessary for "Confirmation" "yes" to be assigned in the "Filter Configuration" menu (> 4.9.2). Otherwise, the message "no confirm" appears.

### Entering network parameters



If a connection via the COM interface is not possible, the following four network parameters must be entered via the keys before the device can be operated with Telnet:

- IP address
- Netmask
- Broadcast
- Gateway

If one of these menu items is selected in the LCD display, the first position flashes after confirmation.

- Select the desired parameter with the arrow keys (the position selected flashes) and confirm with the ENTER key.
- Change the value of the selected parameter using the arrow keys (the parameter flashes) and confirm with the ENTER key.

Leave the numerical input:

- Select "OK" with the arrow keys and confirm with the ENTER key.

## 4.4

### OPERATION VIA TELNET OR SERIAL INTERFACE COM


All the settings in the RMS can easily be made via Telnet or via the serial interface (COM).  
COM parameters: 9600 baud, 8 data bits, no parity, 1 stop bit, software handshake.

**X** Note

*Never connect both COM interfaces at the same time!*

Create a Telnet connection on the computer:

- Input:  
Example: #telnet 192.168.18.103 <Return>  
The Login screen appears




- Log in with an entered user name (> 4.7).  
On first startup: rms <Return>
- Enter password.  
On first startup: rms <Return>

After successfully logging in, the main menu appears (see over).


**X** Note

*Letters in square brackets designate keys with which individual menu items can be selected.*



**MAIN MENU**

From the main menu it is possible to switch to the various submenus. References to sub-menus are marked with ">"

**[N] NETWORK CONFIGURATION**

Network and SNMP settings (> 4.5).

**[S] SYSTEM CONFIGURATION AND UPDATE**

Load and save system configuration and update operating software via TFTP (> 4.6).

**[U] USER ADMINISTRATION**

User administration settings and their rights (> 4.7).

**[I] I/O CONFIGURATION**

Setting input/output parameters (> 4.8).

**[F] FILTER CONFIGURATION**

Setting filter parameters (> 4.9).

**[M] MESSAGE LOG**

Display and confirmation of system messages (> 4.10). Unlike the system log (> 4.5.2), only filter messages are logged here.

**[?] HELP**

Explanation of the menu items.


**[Q] QUIT SESSION**

Quit session.

## Block diagram

The signals applied at the physical input terminals (left) are combined in a complex filter structure (centre). The resulting filter result can then be supplied for switching and signalling purposes at physical output terminals (right) or be used to influence other filters (feedback).

Method of operation and configuration options of the filters. (> 4.9).



## 4.5

## Network Configuration

The Ethernet interface makes it possible to integrate the RMS into a local network (10 Mbit Ethernet), thus making the following functions available:

- SNMP support, thus integration into network management platforms
- Log book functional capabilities (syslog service)
- Loading and saving the system configuration (TFTP)
- Updating the system (TFTP)

• If the RMS is not operated in an Ethernet network, the settings described in this chapter can be ignored.

**X** Note

*If you are unclear about the conditions of the local network, please ask your network administrator for assistance.*

Incorrect settings can have the effect that the device is isolated from the network and/or is no longer capable of sending messages to the desired destination addresses (see also > 4.5.1).

Central input mask for settings for the Ethernet interface. References to sub-menus are marked with ">".

```

Tabnet - RMS
-----
Network Configuration

[I] IP Address : 192.168.18.183 ( 192.168.18.183)
[N] Netmask : 255.255.255.0 ( 255.255.255.0)
[B] Broadcast : 192.168.18.255 ( 192.168.18.255)
[G] Gateway : 192.168.18.254 ( 192.168.18.254)
[S] SNMP Configuration >
[L] Log Service >

[?] Help
[Q] Quit Without Saving
[Return] Quit With Saving
  
```

**[I] IP ADDRESS**

IP address of the Ethernet interface.

**[N] NETMASK**

Netmask of the Ethernet interface.

**[B] BROADCAST**

Broadcast address of the Ethernet interface.

**[G] GATEWAY**

Gateway to adjacent networks of the local network, which may be required.

**[S] SNMP CONFIGURATION**

All SNMP-specific settings of the device (> 4.5.1).

**[L] LOG SERVICE**

System log settings (> 4.5.2).

**[?] HELP**

Explanation of the menu items..

**[Q] QUIT WITHOUT SAVING**

Jump back to the main menu without saving changes.

**[RETURN] QUIT WITH SAVING**

Jump back to the main menu and save changes.

## 4.5.1

### (SNMP CONFIGURATION)


Complete control of the RMS via SNMP with alarm (trap function) and support of separate communities for read and write operations.

SNMP V1 in accordance with RFC 1213 is implemented. MIB-II including RMS private MIB is supported.

The complete MIB file of the RMS is on the supplied CD-ROM.

Explanation of the MIB variables

> **A3.**



Visualised integration in management platforms on request.

#### [N] NAME

Administrative name of the device.

For example: "RMS"

#### [L] LOCATION

Description of the location of the device.

#### [C] CONTACT

Name of the person responsible for this device and contact information. For example:

"LINDY support,  
Tel. +49 (0) 621 / 47 005 - 0"

#### [R] READ COMMUNITY

Name of the community with the right to read SNMP variables.

For example: "public"

#### [W] WRITE COMMUNITY

Name of the SNMP community with the right to write SNMP variables.

For example: "private"

#### [T] TRAP COMMUNITY

Name of the SNMP community with the right to receive traps from this device.

For example: "alarm"

#### [S] SEND AUTHTRAPS

Send trap with unauthorised access with invalid or incorrect Community String (authority trap)..

#### [M] SNMP ACCESS

Enable or disable access via SNMP.

#### - Trap Destinations -

List of a maximum of 8 IP addresses to which SNMP traps are sent.

#### [A] ADD NEW TRAP DESTINATION

Add an IP address to the list of trap receivers..

#### [D] DELETE TRAP DESTINATION

Delete IP address from the list of trap receivers.

#### [?] HELP

Explanation of the menu items.

#### [Q] QUIT WITHOUT SAVING

Jump back to the "Network Configuration" menu without saving changes..

#### [RETURN] QUIT WITH SAVING

Jump back to the "Network Configuration" menu and save changes


## 4.5.2

### LOG SERVICE

Specify receivers of log messages in the network which support the standardised syslog service (UNIXServer).

Two types of messages can be logged via the syslog service:

- Filter results similar to the displays under [M] Message Log in the main menu (> 4.10).
- Debug messages in the event of error analysis (please contact technical support).



#### [M] MESSAGE LOG

Switch on/off display of filter messages.

#### [A] ADD A NEW DESTINATION

Add the IP address of a computer to receive log data.

#### [D] DELETE A DESTINATION

Delete a computer from the list.

#### [?] HELP

Explanation of the menu items.

#### [Q] QUIT WITHOUT SAVING

Jump back to the "Network Configuration" menu without saving changes.


#### [RETURN] QUIT WITH SAVING

Jump back to the "Network Configuration" menu and save changes.

## 4.6

### SYSTEM CONFIGURATION UPDATE

Reference to sub-menus are marked with ">".



#### [C] CONFIGURATION VIA TFTP

Save and load device configuration on other computers via TFTP (>4.6.1)

#### [U] UPDATE VIA TFTP

Update system software via TFTP (>4.6.2).

#### [E] ERASE CONFIGURATION

Reset all settings to the standard settings.

#### [R] Reboot

Warm restart of the device, session is interrupted.

#### [?] Help

Explanation of the menu items.

#### [Q] QUIT WITHOUT SAVING

Jump back to the main menu without saving changes.

#### [RETURN] QUIT WITH SAVING


Jump back to the main menu and save changes.

## 4.6.1 CONFIGURATION VIA TFTP

Tool for saving the system configuration in the network and thus capturing it in a central data backup.

The loading allows rapid startup without reparameterisation, for example after a system failure. This requires that the TFTP service is running on the computer stated (TFTP server).

- Please contact your network administrator.



### [F] FILENAME

Complete file name related to the exported TFTP directory

### [T] TFTP-SERVER

IP address of the TFTP server.

### [S] SAVE CONFIG

Save the system configuration. The configuration can only be saved in an existing file! This prevents overflow on the server hard disk as a result of the uncontrolled saving of configurations.

### [L] LOAD CONFIG

Load the system configuration.

### Status:

Display of the current or last TFTP process.

### [?] HELP

Explanation of the menu items.

### [Q] QUIT

Jump back to the previous menu

## 4.6.2 UPDATE VIA TFTP

Tool for simple updating of the operating software via the network. This requires that the TFTP service is running on the computer stated (TFTP server)..



### [F] FILENAME

File name of the operating software.

### [T] TFTP-SERVER

IP address of the TFTP server.

### [U] UPDATE SYSTEM

Update system software.

### Status:

Display of the last or current TFTP update.

### [?] HELP

Explanation of the menu items.

### [Q] QUIT

Jump back to the previous menu.

## 4.7 User Administration

Input mask to set up users with access rights.

All users are displayed with their user names, passwords and rights as well as their chipcard code, if applicable.



### [A] ADD USER

Add new user.

### [D] DELETE USER

Delete selected user (-->)

### [-] PREVIOUS USER

Selection pointer to previous user.

### [+] NEXT USER

Selection pointer to next user.

### [L] LEARN CHIPCARD

Assign a chipcard to the selected user.

### [U] UNLEARN CHIPCARD

Withdraw the chipcard from the selected user.

### [?] HELP

Explanation of the menu items..

### [Q] QUIT WITHOUT SAVING

Jump back to the main menu without saving changes.

### [RETURN] QUIT WITH SAVING

Jump back to the main menu and save changes..

Note



*A maximum of 12 users (RMS Advanced 99) can be created.*


*Reading or writing/reading rights can be assigned to each user. Users with reading rights cannot save changes and do not have access to user administration.*

*The name and password are case-sensitive. If the chipcard reader has been activated (> 4.8.7), the DIGITAL OUT 4 output is assigned exclusively to the door opener, in other words it is not possible to influence this output with the filters.*

## 4.8

### I/O CONFIGURATION

Input mask for the digital input and output settings.  
References to sub-menus are marked with ">".



#### [O] DIGITAL OUTPUTS

Configure digital outputs.

#### [I] DIGITAL INPUTS

Configure digital inputs.

#### [T] TEMPERATURE INPUTS

Configure temperature (sensor) inputs.

#### [H] HUMIDITY INPUTS

Configure humidity (sensor) inputs.

#### [M] MAINS MONITORING

Configure mains monitoring input.

#### [A] AUX

Configure serial interface AUX.

#### [?] HELP

Explanation of the menu items.

#### [Q] QUIT WITHOUT SAVING


Jump back to the main menu without saving changes.

#### [RETURN] QUIT WITH SAVING

Jump back to the main menu and save changes.


## 4.8.1 DIGITAL OUTPUTS

Input mask for the DIGITAL OUT digital outputs settings. Digital outputs are displayed with the number, description, combined filters, logic operation and effect.



### FOR CONFIGURATION WITH THE CHIPCARD READER ONLY

If the chipcard reader has been activated (> 4.8.7), the DIGITAL OUT 4 output is assigned exclusively to the door opener, in other words it is not possible to influence this output with the filters.



### [D] DESCRIPTION

Description of the digital output.

### [F] FILTER

Specify the filter(s) (> 4.9) which act(s) on a digital output.

### [L] LOGIC

Specify the logic operation with which the filters are combined.

### [E] EFFECT

State how the logic result acts on the digital output.

*ON* permanently switched on (independent of settings in Filter and Logic)

*OFF* switched off (independent of settings in Filter and Logic)

*THRU* switched through

*INVERT* switched through in inverted fashion

### [-] PREVIOUS OUTPUT

Selection pointer to previous output.

### [+] NEXT OUTPUT

Selection pointer to next output.

### [?] HELP

Explanation of the menu items.

### [Q] QUIT



Jump back to the previous menu.



The menu points **[D]**, **[F]**, **[L]** and **[E]** are disabled for DIGITAL OUT 4 whilst, the current status of the output is displayed in the column headed "State".

## 4.8.2 DIGITAL INPUTS

Displays the DIGITAL IN, ALERT IN and UPS IN digital inputs with the number, description, status (on/off), number of status changes and time of the last change.



### [D] DESCRIPTION

Description of the digital input.

### [R] RESET ALERT IN

Reset the sensors connected to the ALERT IN inputs (deletes the alarm status in the sensor).

### [-] PREVIOUS INPUT

Selection pointer to the previous input.

### [+] NEXT INPUT

Selection pointer to the next input.

### [?] HELP

Explanation of the menu items.



### [Q] QUIT

Jump back to the previous menu..

## TEMPERATURE INPUTS

### 4.8.3

Displays the TEMPERATURE/HUMIDITY digital temperature inputs with the number, description and current value.



### [D] DESCRIPTION

Description of the temperature input.

### [-] PREVIOUS TEMPERATURE

Selection pointer to the previous input.

### [+] NEXT TEMPERATURE

Selection pointer to the next input.

### [?] HELP


Explanation of the menu items.

### [Q] Quit

Jump back to the previous menu.

## 4.8.4 HUMIDITY INPUTS

Displays the TEMPERATURE/HUMIDITY digital humidity inputs with the description and current value.



### [D] DESCRIPTION

Description of the humidity sensor.

### [-] PREVIOUS HUMIDITY

Selection pointer to the previous input.

### [+] NEXT HUMIDITY

Selection pointer to the next input

### [?] HELP


Explanation of the menu items.

### [Q] QUIT

Jump back to the previous menu.

## 4.8.5 MAINS MONITORING

Displays the MAINS MONITORING digital inputs with the number, description and current value.



### [D] DESCRIPTION

Description of the mains.

### [+] NEXT MAINS

Selection pointer to the next mains.

### [-] PREVIOUS MAINS

Selection pointer to the previous mains.

### [?] HELP

Explanation of the menu items.

### [Q] QUIT


Jump back to the previous menu.

## 4.8.6

### CONNECT EXTERNAL DEVICES VIA SERIAL INTERFACE (AUX)

Devices with a serial interface (for example chipcard reader, UPS, etc.) can be connected to the AUX port on the rear of the RMS.

Software version 1.4 can support a chipcard reader to implement an access control system.



#### [U] UPDATE SCREEN

Update the screen..

#### [D] AUX DEVICE SELECTION

Select a different device.

#### [L] LOGIC

Set the logic for the door opener contact.

*make* The contact is made if successful (default status open)

*break* The contact is broken if successful (default status closed)

#### [T] OPEN TIME

Set the open time.

#### [O] OPEN DOOR MANUALLY


Open the door.

#### [?] HELP

Explanation of the menu points.

#### [Q] QUIT

Return to the previous menu.



#### **[-] Previous Device**

Set the selection pointer to the previous device.

#### **[+] Next Device**

Set the selection pointer to the next device.

#### **[?] Help**

Explanation of the menu points.

#### **[Q] Quit**

Return to the previous menu.

#### **[Return] Quit With Saving**

Save the changes and return to the previous menu.

**X** Note

*These settings affect the display and function in the menus "User Configuration" (> 4.7), "Digital Outputs" (> 4.8.1) and "AUX Configuration" (> 4.8.6).*

## 4.9 FILTER

The filters are the central elements of the RMS. They make it possible to logically combine the results recorded at the inputs, and to supply the result to the digital outputs or to generate various signals.


It is possible to configure a total of 12 filters (RMS Advanced 40) with an identical structure. In this case, all inputs are available to each filter.

Depending on the type of input signal (measured value, status, filter feedback), in principle there are three different function blocks for processing the results.

The results of all the function blocks are combined via a common, logical OR element to form the filter result.

This filter result can then, depending on requirements, be used to generate alarm messages (SNMP Trap, LED Warning, Buzzer), to control digital outputs, or for feedback to other filters.


Mode of operation



## 4.9.1

### FILTER SELECTION

All filters are displayed with the number, description, status, result, reactivation time and confirmation status.



#### [D] DISABLE

Deactivate the selected filter without changing the filter settings.

#### [C] CONFIRM FILTER

Confirm selected filter. The confirmation deactivates the filter for the duration of the reactivation time (> 4.9.2).

#### [F] FILTER CONFIGURATION

Configure selected filter.

#### [-] PREVIOUS FILTER

Selection pointer to the previous filter.

#### [+] NEXT FILTER

Selection pointer to the next filter.

#### [?] HELP

Explanation of the menu items.

#### [Q] QUIT


Jump back to the main menu without saving changes.

## 4.9.2

### FILTER CONFIGURATION

References to sub-menus are marked with ">".

A "(\*)" before the ">" indicates that at least one of the inputs is applied to this filter.



#### [D] DESCRIPTION

Description of the filter.

#### [E] EFFECT


Effect of the filter result after the OR element.

thru switched through  
 off switched off  
 invert switched through in inverted fashion

#### [S] SNMP TRAP

In connection with an event, send traps to all entered trap receivers (> 4.5.1).

no No trap  
 once Trap if the filter event occurs repeat Repeated traps (every 60 seconds) until the filter event occurs



**[L] LED WARNING**

In connection with an event switch the LED on "Warning"

**[B] BUZZER WARNING**

In connection with an event, switch on the buzzer.

**[M] MESSAGE PRIORITY**

Characterises the priority of the filter event.

*none* no entry in the message  
*critical*  
*warning*

**[C] CONFIRMATION**

Enable or disable confirmation of a filter result.

**[R] REACTIVATION TIME**

Specify the time after which a confirmed filter is reactivated.

**[I] DIGITAL/ALERT/UPS INPUTS**

Configure general digital inputs..

**[T] TEMPERATURE INPUTS**

Configure temperature inputs.

**[H] HUMIDITY INPUTS**

Configure humidity inputs.

**[M] MAINS INPUTS**

Configure mains monitoring inputs

**[F] FEEDBACK INPUTS**

Configure feedback inputs.

**[?] HELP**

Explanation of the menu items.

**[Q] QUIT WITHOUT SAVING**

Jump back to the previous menu without saving changes.

**[RETURN] QUIT WITH SAVING**

Jump back to the previous menu and save changes.

4.9.3

**DIGITAL/ALERT/UPS INPUTS**

The inputs are displayed with the type, number, description and effect.



**[ - ] PREVIOUS DIGITAL/ALERT/UPS INPUT**

Input  
 Selection pointer to the previous input.

**[ + ] NEXT DIGITAL/ALERT/UPS INPUT**

Selection pointer to the next input.

**[E] EFFECT**

Effect of the input signal on the OR element.  
 thru switched through  
 off switched off  
 invert switched through in  
 inverted fashion

**[?] Help**

Explanation of the menu items.

**[Q] QUIT**

Jump back to the previous menu.

## 4.9.4




### TEMPERATURE/MAINS/HUMIDITY INPUTS

The filter inputs for measured values are displayed with the threshold, mode and effect. They have a flexible structure for the creation of larger/smaller comparisons or window comparisons.

Thus the following filter conditions can easily be realised:

1) Simple larger/smaller comparison (switch if the input variable is smaller/larger than the threshold). Example 1 – Switch if temperature 1 > 35 °C: mode A ">"; threshold A 35; mode B "off"; threshold B any value; effect "thru".

2) "Window comparison" (switch if the input variable is inside/outside a defined range) Example 2 – Switch if voltage 1 is between 210 V and 240 V: Mode A ">"; threshold A 210; Mode B "<"; threshold B 240; effect "thru"  
 Example 3 – Switch if humidity 1 is less than 30 % or greater than 80 %: Mode A ">"; threshold A 30; Mode B "<"; threshold B 80; effect "invert"



**[A] MODE-A [B] MODE-B**

Set comparison module..

**[1] THRES-A [2] THRES-B**

Set threshold.

**[E] EFFECT**

State how the input acts on the OR element.

- thru switched through
- off switched off
- invert switched through in inverted fashion

**[-] PREVIOUS INPUT**

Selection pointer to previous input.

**[+] NEXT INPUT**

Selection pointer to next input.

**[?] HELP**

Explanation of the menu items.

**[Q] QUIT**

Jump back to the previous menu..

## 4.9.5

### FEEDBACK INPUTS

To realise complex filter conditions, each filter has two feedback inputs where filter events can be further processed.

The special feature here is the possibility of delay (delay time), conditional evaluation (pass condition) and hold time.




$F_1$ : Filter 1

$F_2$ : Feedback input of filter 2.

$f_1$ :  $F_1$  output event, input event of  $F_2$

$f_2$ : Output of the feedback input of  $F_2$



With a pass condition = thru, the effective hold time of  $f_2$  can be extended by any time by subsequent events of  $f_1$  (retriggering).  $f_2$  in this case is not released until thold after the last falling edge of  $f_1$ .

Feedback Inputs Filter 1					
No.	From Filter	Delay Time	Pass Condition	Hold Time	Effect
→ 1	*no filter*	*no delay*	thru	*no hold*	off
2	*no filter*	*no delay*	thru	*no hold*	off

[F] Filter	[P] Pass Condition	[E] Effect
[D] Delay Time	[H] Hold Time	
[-] Previous Feedback Input		
[+] Next Feedback Input		
[?] Help		

#### [-] Previous Feedback Input

Selection pointer to previous input.

#### [+] NEXT FEEDBACK INPUT

Selection pointer to next input.

#### [F] FILTER

Origin of the feedback.

#### [D] DELAY TIME

Set the delay time after the operation of the input event  $f_1$  in s.

#### [H] HOLD TIME

Set the hold time of  $f_2$  after the release of  $f_1$  in s.

#### [P] PASS CONDITION

Set the pass mode.

thru                      pass  
conditional          pass if input condition is still met

#### [E] EFFECT

State how the input acts on the OR element.


thru            switched through  
off            switched off  
invert        switched through in inverted fashion

#### [?] HELP

Explanation of the menu items.

#### [Q] QUIT

Jump back to the previous menu.



## 4.10

### MESSAGE LOG

The messages are displayed with the number, priority, acknowledgement, spent time and filter description.

A maximum of the 15 last messages can be displayed.



#### [A] ACKNOWLEDGE

Select message acknowledged (mark with x).

#### [-] PREVIOUS MESSAGE

Selection pointer to previous message.

#### [+] NEXT MESSAGE

Selection pointer to next message.

#### [?] HELP

Explanation of the menu items.

#### [Q] QUIT

Jump back to the previous menu.

# 5 EXAMPLE CONFIGURATION

## Preconfigured filters with an example of terminal assignment.

- Connect sensors to the suggested terminals.

When the RMS is delivered, the most common applications (described in part in the following) have been preconfigured so that commissioning involves setting fewer parameters.

No	Description	State	Result	Reactive	Confirmed	Disabled
1	temperature	act	no	0 s		
2	humidity	off	off	0 s		
3	smoke	off	off	0 s		
4	smoke/vibration	off	off	0 s		
5	ups	act	off	0 s		
6	infrared	act	off	0 s		
7	door	act	off	0 s		
8	door left open	act	off	0 s		
9	moused	off	off	0 s		
10	maximum alarm duration	act	off	0 s		
11	upper threshold	off	off	0 s		
12	lower threshold	off	off	0 s		

## Example of filter configuration using filter 1 (temperature).

- Activate the filter by setting the respective effect to "thru" or "invert" (preset: "off").
- Make individual settings (effect, warnings, ...) for each filter required. See also > 4.9.2.

```

[0] Description      : temperature
[E] Effect          : thru
[S] SWMP Trap      : repeat          [P] Message Priority : none
[L] LED Warning    : yes             [C] Confirmation    : no
[B] Buzzer Warning : no              [R] Reactivation Time : 0 s

[1] Digital/Alert/OPS Inputs >
[1] temperature Inputs (*): >
[0] Humidity Inputs >
[0] Mains Inputs >
[F] Feedback Inputs >
    
```

## Examples of filter settings

TEMPERATURE/HUMIDITY input 1 with simple comparison:  
Alarm if temperature > 35 °C.  
TEMPERATURE/HUMIDITY input 2 with window comparison:  
Alarm if temperature < 5 °C or > 45 °C. See also > 4.9.4.

No	Node-B	Thres-B	Node-B	Thres-B	Effect
1	>	35	off	40	thru
2	>	5	<	45	invert
3	off	40	off	40	off
4	off	40	off	40	off

Description of No 1 : temperature 1

```

[0] Node-B          [0] Node-B          [E] Effect
[1] Thres-B        [2] Thres-B
    
```



# 5 EXAMPLE CONFIGURATION

DIGITAL IN input 1:  
Alarm if passive infrared sensor operates. See also > 4.9.3.

No	Description	Effect
Digital In 1	infrared	thru
Digital In 2	door	off
Digital In 3		off
Digital In 4		off
Digital In 5		off
Digital In 6		off
Digital In 7		off
Digital In 8		off
Alert In 1	smoke	off
Alert In 2	vibration	off
Alert In 3		off
Alert In 4		off
UPS In 1	ups 1	off
UPS In 2	ups 2	off

DIGITAL IN input 2:  
Alarm if door is open for longer than 60 s.  
In the Filter Configuration menu, set effect to "thru" for filter 7.  
In the Feedback Input menu, set effect to "thru" for filter 8.  
See also > 4.9.5.



No	Description	Effect
Digital In 1	infrared	off
Digital In 2	door	thru
Digital In 3		off
Digital In 4		off
Digital In 5		off
Digital In 6		off
Digital In 7		off
Digital In 8		off
Alert In 1	smoke	off
Alert In 2	vibration	off
Alert In 3		off
Alert In 4		off
UPS In 1	ups 1	off
UPS In 2	ups 2	off

No	From Filter	Delay Time	Pass Condition	Hold Time	Effect
1	7	60 s	conditional	*no hold*	thru
2	*no filter*	*no delay*	thru	*no hold*	off

[F] Filter                                      [P] Pass Condition                                      [E] Effect  
 [D] Delay Time                                      [H] Hold time  
 [-] Previous Feedback Input  
 [+] Next Feedback Input

# 5 EXAMPLE CONFIGURATION


Limited alarm duration for filter 4:  
Internal buzzer active for 5 seconds if filter 4 (smoke and shock sensor) is active  
Set input for filter 10 Effect to "thru" in the Feedback menu..



## Specimen output configuration


Additional fan on DIGITAL OUT 1:  
activated if filter 1 trips (temperature).

Signal horn on DIGITAL OUT 2:  
activated if filter 4 (smoke or shock) or filter 6 (passive infra red) trip. Second fan on DIGITAL OUT 3 with hysteresis for temperature 1: switch on fan if temperature 1 > 37 °C and do not switch off until temperature 1 < 25 °C.



# 5 EXAMPLE CONFIGURATION

Two filters are required for this (copy of an RS flip-flop using NOR gate array).



```

Filter: RMS
[Order] [Labels] [Install]

Feedback Inputs
Filter 11

No  From Filter  Delay Time  Pass Condition  Hold Time  Effect
--  -
-> 1  12             *no delay*     conditional    *no hold*     thru
    2  *no filters*  *no delay*     thru           *no hold*     off

Temperature Inputs
Filter 11

No  Node-B  Thres-B  Mode-B  Thres-B  Effect
--  -
-> 1  3        37 C    off     40 C     thru
    2  off     40 C    off     40 C     off
    3  off     40 C    off     40 C     off
    4  off     40 C    off     40 C     off

Description of No. 1 : temperature 1

Filter Configuration
Filter 11

[D] Description      : upper threshold
[E] Effect           : invert
[S] SNMP trap       : no
[L] LCD Warning     : no
[B] Buzzer Warning  : no
[P] Message Priority : none
[C] Confirmation    : disabled
[R] Reactivation Time : 0 s
    
```

```

Filter: RMS
[Order] [Labels] [Install]

Digital Outputs

No  Description  Filter(s)  Logic  Effect  State
--  -
1  fan           x          or     thru   open
2  alarm         x x       or     thru   open
-> 3  fan 2        x          and    thru   open
    4  Output 4    *none*     and    off    open

[D] Description
[F] Filter
[L] Logic      [-] Previous Output
[E] Effect     [*] Next Output
    
```

 Caution

In the event of malfunctions  
System no longer starts.

If, during operation, the "Power" LED goes out or smoke or an abnormal smell is ascertained,

- Unplug the power cable.
- Please contact your dealer.

• Check whether your system is properly set up (> **3**).

**Cause:** Current operating software faulty.

**Remedy:**

- Ensure that a correctly configured (> 4.1.2 ) terminal is connected to the COM interface on the front of the device or on the back.
- Press the Reset key on the front of the device with a pointed object. The device will reboot.

The following boot messages appear on the terminal screen:

```
RMS-BIOS version 1.0.03
(c) LINDY-Elektronik GmbH 1998
Memory Test : 00004096k Ok
Status of IDE : Ok
Drive 0 : MZX023157, (C/H/S) : 123/2/32
Drive 1 : Not detected.
Probing...[ NE*000]
NE*000 base 0x0300, addr 00:10:6C:00:04:41
LILO
-----
RMS - Rack Monitoring System
System is ready to boot. You may choose your old image
by pressing 'o'.
-----
boot: <TAB>
r      RMS-Boot o RMS-Old
boot: o <ENTER>
Loading o
Linux version 2.1.97 (root@PC14) (gcc version 2.7.2.1) #7
SMP Tue May 5 10:26:58
Calibrating delay loop... 3.70 BogoMIPS
```

The "Fault" LED lights up, the sensors do not work, "Overload" is displayed in the LCD display.

- If, during the boot: display, the keys o and Return on the terminal keyboard are pressed, the system boots with the last valid operating software (otherwise it boots again with the current version, which is faulty here).
- Load the current operating software from the Internet and update the system(> **4.4.3**).


**Cause:** Auxiliary voltage interruption in connection with overload or short circuit in the sensor cable.

**Remedy:**

- Confirm the "Overload" message in the LCD display with the ENTER key.
- Remove the overload or short circuit.
- Switch the auxiliary voltage back on in the "Aux.Volt."(>**4.3**) menu with the ENTER key.
- Please contact technical support (> **1.4**) or your dealer.

If the malfunction still occurs after performing the remedial measures

# 7 TECHNICAL DATA



## RMS dimensions

External (WxDxH): 483 x 223 x 43.6mm  
Mounting dimensions (WxDxH): 445 x 218 x 43.6mm

## Weight

3.5 kg

## Rated voltage

AC 110 – 230 V

## Rated frequency

50/60 Hz

## Rated current

200 mA

## Protection class

I

## Rated ambient temperature

5 . . . 35 °

<b>19" Construction</b>	19-inch construction is the common name for a standardised modular system for electronic devices and system parts. It specifies the width of the front panel of plug-in units and subracks.
<b>Broadcast</b>	General, network-wide information.
<b>EMC</b>	Abbreviation for Electromagnetic Compatibility.
<b>FAQ</b>	Abbreviation for Frequently Asked Questions. The most frequent questions and problems on a subject are listed under FAQ on the Internet.
<b>Gateway</b>	Junction between network segments or networks, also with different protocols.
<b>HE</b>	Height classification dimension of 44.45 mm = 1 HE (1 U). From 19" technology.
<b>IP</b>	Abbreviation for Internet Protocol. Standardised protocol for data transmission and on the Internet for addressing computers. An IP address consists of a combination of 4 Bytes written as follows: A.B.C.D (for example, 192.168.0.88). For more information, see RFC.
<b>MIB</b>	Abbreviation for Management Information Base. Data structure which contains information on the SNMP agent.
<b>Netmask</b>	Used to divide the IP address into network address and interface address.
<b>RFC</b>	Abbreviation for Request For Comment. RFCs are the official form of publication of Internet standards and other technical documents on the Internet. Rules for formatting and publishing RFCs themselves are laid down in RFC 1543.
<b>SNMP</b>	Abbreviation for Simple Network Management Protocol. Established protocol for the exchange of management information. Standard RFCs on SNMP are RFC 1155, RFC 1157 and RFC 1213.
<b>TFTP</b>	Trivial File Transfer Protocol Simple protocol in IP-based networks for sending and receiving files.
<b>Trap</b>	(Alarm) message from an SNMP agent to the management environment.
<b>URL</b>	Abbreviation for Universal Resource Locator. Full Internet address.
<b>VDE</b>	Abbreviation for Verband Deutscher Elektrotechniker (Association of German Electrotechnical Engineers).

**Manufacturer**

LINDY-Elektronik GmbH  
Markircher Str. 20  
D-68229 Mannheim, Germany

**Product designation  
Model**

Data Terminal Equipment  
Remote Management System

The product conforms to the regulations of the following EU Directive:  
73/23/EEC.

The conformity of the product to the requirements of Directive  
89/336/EEC was tested using the following standards: EN 55022/Kl. B;  
EN 55024; EN 61000-4-2; EN 61000-3; EN 61000-4; EN 61000-6.

## Tested to Comply With FCC Standards For Commercial Use Only

**FCC Compliance Statement (United States)**

This equipment generates, uses and can radiate radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio communication. It has been tested and found to comply with the limits for a class A computing device in accordance with the specifications in Part 15 of FCC rules, which are designed to provide reasonable protection against such interference when the equipment is operated in a commercial environment. Operation of this equipment in a residential area may cause interference, in which case the user at his own expense will be required to take whatever measures may be necessary to correct the interference. If this equipment causes interference, what can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- a) Reorient or relocate the receiving antenna.
- b) Increase the separation between the equipment and receiver.
- c) Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- d) Consult the dealer or an experienced radi/TV technician

**FCC WARNING**

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment under FCC Rules.

**Canadian Department of Communications RFI statement**

This equipment does not exceed the class A limits for radio noise emissions from digital apparatus set out in the radio interference regulations of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la classe A prescrites dans le règlement sur le brouillage radioélectriques publié par le ministère des Communications du Canada


## A 2

### DOCUMENTATION OF THE SYSTEM CONFIGURATION

- Mark the cables of your RMS at both ends clearly with meaningful markings.

Use cable binders with marking areas or labels with sealing film.

- The following block diagram (master) can be used for documentation of the filter configuration



### EXPLANATION OF THE MIB FOR RMS

Structure of the MIB

The RMS can be accessed under the OID 1.3.6.1.4.1.1909.10 (iso.org.dod.internet.private.enterprises.infratec.rms)

#### 10 rms

- 1 rmssystem
- 2 input
  - 1 digitalInTable
  - 2 alertInTable
  - 3 upsInTable
- 3 output
  - 1 outputTable
  - 2 outputLogicTable
- 4 temp
  - 1 tempTable
- 5 humid
  - 1 humidTable
- 6 mains
  - 1 mainsTable
- 7 filter
  - 1 filterTable
  - 2 filterDigitalInTable
  - 3 filterAlertInTable
  - 4 filterUPSINTable
  - 5 filterTempTable
  - 6 filterHumidityTable
  - 7 filterMainsTable
  - 8 filterFeedbackTable
- 8 message
  - 1 messageTable
- 9 user
  - 1 userTable
- 20 aux
- 21 icc

The complete MIB in ASN.1-Notation is on the enclosed CDROM as the file "RMS MIB"

Key to the following Tables:

- INT Integer
- CNT Counter
- DS Display String
- OS Octet String
- TT TimeTicks
- RO Read Only
- RW Read Write

#### Objects under RMS system

(1.3.6.1.4.1.1909.10.1)


for example

Reset RMS

1.3.6.1.4.1.1909.10.1.4.0 := 1

Variable	Type	Value	Access
1 systemVersion	DS		RO
2 systemSNMPsave	INT	{ default (1), save (2) }	RW
3 systemMsgToSyslog	INT	{ msglog-off (1) msglog-on (2) }	RO
4 systemReset	INT	{ default (1), reset (2) }	RW
5 systemSNMPaccess	INT	{ readonly (1), readwrite (2) }	RO


## Objects under digitalInTable (1.3.6.1.4.1.1909.10.2.1)



for example:  
number of changes of input 9:  
1.3.6.1.4.1.1909.10.2.1.1.5.9

Variable	Type	Value	Access
1 digitalInEntry			
1 digitalInIndex	INT		RO
2 digitalInDescr	DS		RW
3 digitalInState	INT	{ off (1), on (2)}	RO
4 digitalInLastChange	TT		RO
5 digitalInChanges	CNT		RO


## Objects under alertInTable (1.3.6.1.4.1.1909.10.2.2)



for example :  
Reset sensors on Alert In 2  
1.3.6.1.4.1.1909.10.2.2.1.3.2 := 1


Variable	Type	Value	Access
1 alertInEntry			
1 alertInIndex	INT		RO
2 alertInDescr	DS		RW
3 alertInState	INT	{off (1), on (2)}	RO
4 alertInLastChange	TT		RO
5 alertInChanges	CNT		RO
6 alertInReset	INT	{default (1) alertIn-reset (2)}	RW

## Object under ups INTABLE (1.3.6.1.4.1.1909.10.2.3)



Variable	Type	Value	Access
1 upsInEntry			
1 upsInIndex	INT		RO
2 upsInDescr	DS		RW
3 upsInState	INT	{off (1), on (2)}	RO
4 upsInLastChange	TT		RO
5 upsInChanges	CNT		RO

## Objects under outputTable (1.3.6.1.4.1.1909.10.3.1)




Variable	Type	Value	Access
1 outputEntry			
1 outputIndex	INT		RO
2 outputDescr	DS		RW
3 outputEffect	INT	{off (1), on (2), thru (3), invert (4)}	RW
4 outputLastChange	TT		RO
5 outputChanges	CNT		RO
6 outputLogic	INT	{and (1), or (2)}	RW
7 outputState	INT	{open (1), short(2)}	RO

for example:

Read put description DIGITAL OUT 4:  
1.3.6.1.4.1.1909.10.3.1.1.2.4

## Objects under outputLogicTable (1.3.6.1.4.1.1909.10.3.2)



Variable	Type	Value	Access
1 outputLogicEntry			
1 outputLogicOutputIndex	INT		RO
2 outputLogicFilterIndex	INT		RO
3 outputLogicFilter	INT	{off(1),on(2)}	RW

## Objects under tempTable (1.3.6.1.4.1.1909.10.4.1)

for example:

Read out current temperature of temperature sensor 1:  
1.3.6.1.4.1.1909.10.4.1.1.3.1


## Objects under humidTable (1.3.6.1.4.1.1909.10.5.1)

Variable	Type	Value	Access
1 tempEntry			
1 tempIndex	INT		RO
2 tempDescr	DS		RW
3 tempValue	INT	{no-sensor (665)}	RO
Variable	Type	Value	Access
1 humidEntry			
1 humidIndex	INT		RO
2 humidDescr	DS		RW
3 humidValue	INT	{ no-sensor (255) }	RO

## Objects under mainsTable (1.3.6.1.4.1.1909.10.6.1)


Variable	Type	Value	Access
1 mainsEntry			
1 mainsIndex	INT		RO
2 mainsDescr	DS		RW
3 mainsValue	INT		RO

## Objects under filterTable (1.3.6.1.4.1.1909.10.7.1)



Variable	Type	Value	Access
1 filterEntry			
1 filterIndex	INT		RO
2 filterDescr	DS		RW
3 filterResult	INT	{false (1), true (2)}	RO
4 filterEffect	INT	{off (1), thru (2), invert (3)}	RW
5 filterTrap	INT	{no (1), once (2), repeat (3)}	RW
6 filterLED	INT	{no (1), yes (2)}	RW
7 filterBuzzer	INT	{no (1), yes (2)}	RW
8 filterMessagePriority	INT	{no-message (1), priority-warning (2), priority-critical (3)}	RW
9 filterConfirmation	INT	{disabled (1), RW enabled (2)}	
10 filterReactivationTime	INT	{no-timeout (1)}	RW
11 filterConfirm	INT	{not-confirmed (1), confirmed (2)}	RW

for example:  
allow confirmation for filter 4  
1.3.6.1.4.1.1909.10.7.1.1.9.4 := 1



## Objects under filterDigitalInTable (1.3.6.1.4.1.1909.10.7.2)

Variable	Type	Value	Access
1 filterDigitalInEntry			
1 filterDigitalInIndex	INT		RO
2 filterDigitalInPort	INT		RO
3 filterDigitalInEffect	INT	{off (1), thru (2), invert (3)}	RW


for example :  
Make DIGITAL INPUT 2 act on filter 6:  
1.3.6.1.4.1.1909.10.7.2.1.3.6.2

**Objects under  
filterAlertInTable  
(1.3.6.1.4.1.1909.10.7.3)**

Variable	Type	Value	Access
1 filterAlertInEntry			
1 filterAlertInIndex	INT		RO
2 filterAlertInPort	INT		RO
3 filterAlertInEffect	INT	{off (1), thru (2), invert (3)}	RW

**Objects under  
filterUPSInTable  
(1.3.6.1.4.1.1909.10.7.4)**

Variable	Type	Value	Access
1 filterUPSInEntry			
1 filterUPSInIndex	INT		RO
2 filterUPSInPort	INT		RO
3 filterUPSInEffect	INT	{off (1), thru (2), invert (3)}	RW



**Objects under  
filterTempTable  
(1.3.6.1.4.1.1909.10.7.5)**

for example:  
Exclude TEMPERATURE/HUMIDITY  
input from Filter 1  
1.3.6.1.4.1.1909.10.7.5.1.3.1.2 := 0

Variable	Type	Value	Access
1 filterTempEntry			
1 filterTempIndex	INT		RO
2 filterTempSensor	INT		RO
3 filterTempEffect	INT	{off (1), thru (2), invert (3)}	RW
4 filterTempAThres	INT		RW
5 filterTempAMode	INT	{off (1), greater (2), less (3)}	RW
6 filterTempBThres	INT		RW
7 filterTempBMode	INT	{off (1), greater (2), less (3)}	RW


**Objects under  
filterHumidityTable  
(1.3.6.1.4.1.1909.10.7.6)**

Variable	Type	Value	Access
1 filterHumidityEntry			
1 filterHumidityIndex	INT		RO
2 filterHumiditySensor	INT		RO
3 filterHumidityEffect	INT	{off (1), thru (2), invert (3)}	RW
4 filterHumidityAThres	INT		RW
5 filterHumidityAMode	INT	{off (1), greater (2), less (3)}	RW
6 filterHumidityBThres	INT		RW
7 filterHumidityBMode	INT	{off (1), greater (2), less (3)}	RW

**Objects under  
filterMainsTable**  
(1.3.6.1.4.1.1909.10.7.7)

Variable	Type	Value	Access
1 filterMainsEntry			
1 filterMainsIndex	INT		RO
2 filterMainsSensor	INT		RO
3 filterMainsEffect	INT	{off (1), thru (2), RW invert (3) }	
4 filterMainsATHres	INT		RW
5 filterMainsAMode	INT	{off (1), greater (2), RW less (3) }	
6 filterMainsBThres	INT		RW
7 filterMainsBMode	INT	{off (1), greater (2), RW less (3) }	

**Objects under  
filterFeedbackTable**  
(1.3.6.1.4.1.1909.10.7.8)



Variable	Type	Value	Access
1 filterFeedbackEntry			
1 filterFeedbackIndex	INT		RO
2 filterFeedbackInput	INT		RO
3 filterFeedbackInFilter	INT		RW
4 filterFeedbackDelay	INT		RW
5 filterFeedbackPassCond	INT	{ thru (1), conditional (2) }	RW
6 filterFeedbackHold	INT		RW
7 filterFeedbackEffect	INT	{ off (1), on (2), invert (3) }	RW

For example:  
Feedback input 1 of filter 8 is only  
to operate if the event is still  
applied:  
1.3.6.1.4.1.1909.10.7.8.1.5.8.1 := 1

**Objects under  
messageTable**  
(1.3.6.1.4.1.1909.10.8.1)

For example:  
Read out filter description from  
message 5:  
1.3.6.1.4.1.1909.10.8.1.1.3.5

Variable	Type	Value	Access
1 messageEntry			
1 messageIndex	INT		RO
2 messageFilter	INT		RO
3 messageFilterDescr	DS		RO
4 messageTime	TT		RO
5 messagePriority	INT	{no-message (1), RO warning (2), critical (3) }	
6 messageAcknowledged	INT	{not-acknow- ledged (1), acknowledged (2) }	RW

## Objects under **userTable** (1.3.6.1.4.1.1909.10.9.1)

Variable	Type	Value	Access
1 userEntry			
1 userIndex	INT		RO
2 userName	DS		RO
3 userRight	INT	{ readonly (1), read-write (2)}	RO
4 userChipcardKey	DS		RO
5 userChipcardAccess	INT	{ denied (1), granted (2) }	RO

## Objects under **aux** (1.3.6.1.4.1.1909.10.20)

Variable	Type	Value	Access
1 auxDevice	INT	{ no-device (1), chipcardreader (2)}	RO
2 auxDeviceName	DS		RO

## Objects under **icc** (1.3.6.1.4.1.1909.10.21)

Variable	Type	Value	Access
1 readerConnected	INT	{ no (1), yes (2) }	RO
2 readerCardInside	INT	{ no (1), yes (2) }	RO
3 readerCardKey	DS		RO
4 readerLEDcolor	INT	{ red (1), green (2) yellow (3) }	RO
5 openerLogic	INT	{ break (1), make (2) }	RO
6 openerOpenTime	INT		RO
7 openerState	INT	{ closed (1), open (2) }	RO

## GNU GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

Version 2, June 1991, Copyright (C) 1989, 1991 Free Software Foundation, Inc., 59 Temple Place - Suite 330, Boston, MA 02111-1307, USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

### Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software—to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps:

- (1) copyright the software, and
- (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all. The precise terms and conditions for copying, distribution and modification follow.

**0** This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you". Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

**1** You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program. You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

**2** You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.) These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program. In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

**3** You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.) The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable. If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

**4** You may not copy, modify, sublicense, or distribute the Program except as expressly provided

under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

**5** You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

**6** Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

**7** If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royaltyfree redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program. If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice. This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

**8** If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

**9** The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

**10** If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### **NO WARRANTY**

**11** BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

**12** IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

# PRODUCT MATRIX

Type	RMS LITE	RMS ADVANCED
Feature		
Speed	25 mhz	33 mhz
Flash	8mb	32mb
Housing	19" IHE	19" IHE
Front LCD Display	no	yes
Front Keypad	no	yes
Status LED's	yes	yes
Buzzer	yes	yes
Power supply range	110/230 V AC	110/230 V AC
DC, optional	48 V DC	48 V DC
Internal voltage supply for all sensors	yes	yes
Ethernet-Port	10 Mbit	10 Mbit
DHCP	no	yes
Telnet	yes	yes
SSH	no	no
HTTP	yes	yes
HTTPS	no	no
SNMP (get , set, trap)	yes	yes
TFTP	yes	yes
Mains Voltage measurement	1	3
Digital Out	4	4
Digital In	8	8
Alert In	-	4
Temperature / humidity	4	4
UPS In / Digital In 9 & 10	-	2
Com port Front	1	1
Com port Rear	-	1
VT 100	yes	yes
AUX port	1	1
Free programmable filters	12	40
Number of users	12	99
Email function	no	yes
Time server function	no	yes
Syslog function	yes	yes
Chipcard function	yes	yes
Proximity reader	no	yes
USV support	no	yes
activation of external power socket outlets	yes	yes



#### **Deutschland**

---

LINDY-Elektronik GmbH  
Markircher Str. 20  
68229 Mannheim  
Tel: 0621.47 00 5-0  
Fax: 0621.47 00 5-0  
E-Mail: info@lindy.de



#### **Schweiz / Suisse / Svizzera**

---

LINDY-Elektronik AG  
Florenzstrasse 9  
CH-4023 Basel  
67451Mundolsheim Cedex  
Services clients  
Tel: 061 335 97 00  
Fax: 061 335 97 09  
E-Mail: info@lindy.ch



#### **Great Britain**

---

LINDY Electronics Ltd.  
Sadler Forster Way  
Teesside Industrial Estate, Thornaby  
Stockton-on-Tees TS17 9JY, England  
Tel: 01642 - 754000  
Sales Fax: 01642 - 765274  
General Fax: 01642 - 754027  
E-Mail: Postmaster@lindy.co.uk



#### **France**

---

LINDY France Sarl  
6 rue Rapp  
CS 31015  
67451Mundolsheim Cedex  
Services clients  
Tél: 0 825 825 111  
Fax: 03 88 20 57 74  
Services administratifs:  
Tél: 03 88 20 04 66  
E-Mail: france@lindy.fr



#### **Italia**

---

LINDY Italia S.r.l.  
Via Varesina, 126/B  
22079 - Villa Guardia (CO)  
Tel: 031 48 40 11  
Fax: 031 48 06 52  
E-Mail: italia@lindy.it  
Supporto Tecnico:  
supporto.tecnico@lindy.it



#### **USA**

---

LINDY Computer Connection  
Technology Inc.  
16214 Phillips Road  
Athens, AL 35613  
Tel: (256) 771-0660  
Fax: (256) 771-0460  
E-Mail: usa@lindy-usa.com



#### **Australia**

---

LINDY Australia Pty Ltd  
Unit 2, 43-49 Sandgate Road  
AU- 4010 Albion Qld  
Tel: 07 3262 9033  
Fax: 07 3262 9055  
E-Mail: info@lindy.com.au



#### **International & Eire**

---

LINDY International Ltd.  
Sadler Forster Way  
Teesside Industrial Estate, Thornaby  
Stockton-on-Tees TS17 9JY, England  
Tel: +44 1642 - 754020  
Fax: +44 1642 - 754029  
E-Mail: Postmaster@lindy.com