



MP3 Player

User Manual

Please Read Carefully before using the Player

Note: MUST convert all video's/movies using the included Conversion CD before adding to the player.

EM162VID
EM164VID



TABLE OF CONTENTS

Introduction	1
Regulatory Information: FCC Part 15	2
Main Features	5
Overview	6
Connecting to the Computer	7
System requirements	7
Installing the driver for windows 98 SE	7
Connecting the player to a computer	8
Copy Files from a computer	8
Disconnecting from the computer.....	8
Charging the battery	9
Basic operation	10
Turn on/off the Player	10
Adjusting the volume	10
Resetting the Player	10
Unlock All Buttons	11
Entering the main menu	11
Listening to Music	12
Playing music	12
Display.....	13

Using Music Function Menu	13
Lyric Displaying	15
Watching a Video	16
Playing a video	16
FM radio	17
Listening to FM radio	17
Display	18
Using FM radio function menu	18
Viewing Photos	20
Viewing a Photo	20
E-book Reading	21
Save and Load a bookmark	22
Voice Recording and Playing	23
Recording a Voice	23
Setup the recording quality	24
Using voice function menu	25
Managing Files	26
Browsing all files and deleting a file	26
Changing Player Setups	27
Setup items	28
Power setup	28

Adjust the brightness.....	29
System tools	29
Converting Video to MTV Format.....	30
Troubleshooting	32
Specifications	33

Introduction

Thank you for purchasing this MP3 Player.

This manual contains important safety information and operation instructions, so please read all these instructions carefully before using the player and keep it for future reference.

This manual will help you use all of the exciting features to make your player more enjoyable.

We have done our best to produce a complete and accurate manual; however, we cannot ensure there are no errors or omissions. We also have no responsibility for damages or loss of data caused by improper operation.

The instruction manual is subject to change for improvement without notice.

Trademarks and trade names used in this user's manual are owned by their respective companies or organizations.

Regulatory Information: FCC Part 15

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THE DEVICE. ANY SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

Important Safety Precautions


Always follow these basic safety precautions when using your player. This will reduce the risk of product damage and personal injury.

- Do not disassemble, repair or modify the player by yourself. Refer servicing to qualified personnel.
- Do not dispose of the player in fire to avoid explosion because the player has a built-in battery.
- Do not touch the player with bare hands if the built-in battery is leaking. In this case, contact the service center for help since the liquid may remain in the player. If your body or clothes has contact with the battery liquid, wash it off thoroughly with water. Also, if some of the liquid gets into your eyes, do not rub your eyes but immediately wash them with clean water, and consult a doctor.
- Keep the player away from direct sunlight and heat sources.
- To avoid any malfunction, do not expose the unit to rain or moisture.
- Do not use the player in dry environments to avoid static.
- Never apply a heavy impact to the player like dropping it or placing it on a magnet.
- Route the USB cable so that people and pets are not likely to trip over or accidentally pull it as they move around or walk through the area.
- Disconnect the USB cable from the computer when you are not using the player for a long time.

- Clean only with dry cloth. Make sure the player is turned off before cleaning. Do not use liquid cleanser.
- Be sure to back up your files. We will not be liable for the loss of data due to improper operation, repair or other causes.
- Prolonged listening at full volume can cause hearing damage .
- Maximum output voltage $\leq 150\text{mV}$

Precautions in using the headphone


- Do not use the headphone while driving an automobile or riding a bicycle. It is not only dangerous, but also against the law. To avoid an accident, do not turn the volume of the headphones up too high while walking.
- It's not recommended that you use the headphones at a high volume for an extended time as this may cause hearing damage.



Main Features

- 1.5" CSTN color display 128*128
- Built-in rechargeable lithium battery
- Player may be used while connected to a computer.
- Playback of MP3, WMA, WAV music files
- Multiple equalizers (EQ) and 3D sound effects
- Display titles, artists and albums of music files (ID3 tag)
- Lyrics synchronization while music is playing
- Supports JPEG and BMP photo formats
- Supports MTV video format (converter included)
- Reading e-books in TXT format
- FM and Voice recording
- Folder navigation
- USB 2.0 high speed transmission

Overview



1. Earphone jack
2. Mini USB connection
3. MIC Built-in microphone for voice recording
4. [⏻] Power on/off; Record save; Open music/movie/FM Radio/Voice menu; Return to previous menu
5. RESET hole
6. Display screen
7. [⏮] Next track/option. Fast forward search.
8. [▶/⏸] Open the main menu; Confirm the selection; Starts/Pause playback; Unlock buttons.
9. [+] Increases the volume/up
10. [⏪] Previous track/option. Fast backward search. Return to previous menu the list interface
11. [-] Decrease the volume/down

Connecting to the Computer

System requirements

Your computer system must meet the following requirements:

- Pentium 200MHz or above
- Microsoft Windows 98SE/2000/ME/XP/Vista/7
- 120MB of available hard disk space
- USB port supported
- CD-ROM drive

Installing the driver for windows 98 SE

If your computer is running Windows ME/2000/XP/Vista, no driver is required to install.

If your computer is running Windows 98 SE, you must install the driver provided on the CD before connecting the player to your computer.

1. Insert the CD into the CD-ROM drive.
2. Execute the “**USB Disk Win98 Driver Version xxx.exe**” file on the CD.
3. Follow the instructions from the pop-up windows to complete the installation.
4. Restart the computer.

Note: *Make sure the player is not connected to the computer while installing the driver.*

Connecting the player to a computer

Files can be transferred directly into the player by using the USB data cable.

1. Make sure that your computer has been started before you start.
2. Connect the mini plug of the USB cable to the mini USB port on the player, and push the other end into a free USB port on your computer.
3. When the MP3 player is connected to your computer, a “Removable Disk” will be created in “My computer”.

Copy Files from a computer


1. Open the Windows Explorer or My computer. “Removable Disk” is displayed.
2. Drag and drop the files on your computer to the “Removable Disk”.

Note:

- *Please do not disconnect the USB cable during file transferring. It may cause a malfunction of the player and the files.*

Disconnecting from the computer

After finishing transferring, please disconnect the player from the computer as follows:

- 1 Left click the  icon at the taskbar.
- 2 Click the pop-up mini-window with message of “Stop the USB Mass Storage Device –Driver (X)”.
- 3 When you are prompted to remove the device, you can unplug the player safely.

Charging the battery

- The battery of the player is charging automatically when the player is connected to the computer. Make sure the computer has been started.
- The battery of the player is 80-percent charged in about two hours and fully charged in about four hours. If you charge the player while downloading files to the player, it might take longer.
- Read the battery level indication of your player:



Full



Three-quarters full



Half full



Low



Empty



Important:

- *Recommended temperature for battery charging is 0 °C to 35 °C.*
- *Fully charge it before you use the player for the first time or when you haven't used it for a long time.*
- *Charge the player immediately when the "Low battery" message is displayed.*
- *Do not over charge or discharge the player. Over charging or discharging will shorten the battery life.*
- *The battery could be over discharged if the player is not used for a long time (over three months). To avoid over discharge, fully charge the player every three months and always keep the voltage of the battery above 50%.*
- *If the player is not used for a long time, keep it under the temperature of 23 ± 5 °C and the moisture of 65 ± 20 % RH to maintain the performance of the battery.*



Basic operation

Turn on/off the Player

Make sure the battery is sufficiently charged and the headphones are connected correctly.

- To turn on the player, press and hold the  button.
- To turn off the player, press and hold the  button.

Note:

- *If it is the first time for you to turn on the player or turn on the player after default settings or resetting, you have to select a display language by pressing [V+] or [V-] buttons and then press  button to confirm.*
- *While the player is connected to the computer, you can also press and hold the  button to turn on the player.*

Adjusting the volume

- To increase the volume, press the [V+] button while music is playing.
- To decrease the volume, press the [V-] button while music is playing.


Resetting the Player

If a malfunction of the player occurs, take a metal pin, e.g. the end of a paper clip, and press it into the RESET hole to re-initialize the system of your player.

Unlock All Buttons

All buttons of the player will be locked after you do not use it for a certain time (you can set the time in setup menu). This prevents you from accidentally pressing the buttons while using the MP3 player on the move. Press and hold the **[▶||/M]** button to unlock all buttons.

Entering the main menu



1. In standby or playing mode, press and hold the **[▶||/M]** button to enter the main menu.
1. Press the **[V+]** or **[V-]** button to select: Music, Video, FM radio, Photo, E-Book, Voice, File Browse, Setup.
2. Then press the **[▶||/M]** button to enter the desired setting.


Main menu items	Description	Main menu items	Description
MUSIC	Play music tracks.	E-BOOK	Reading E-books.
VIDEO	Play video files.	VOICE	Voice recording and playing.
FM RADIO	Listen to FM radio; FM recording.	FILE BROWSE	Browse all files in the player and delete a file or not.
PHOTO	View photos.	SETUP	Customize the settings of your player.

Listening to Music


Playing music

Make sure that the battery is charged enough and the headphone is connected correctly.

1. Access Main menu by holding **[▶/⏸]**




2. Select "MUSIC" with **[V+]/[V-]**, then **[▶/⏸]**



While music is playing, you can:

- **Pause/Resume Playing:** Press **[▶/⏸]** button to pause playing. To resume playing, press **[▶/⏸]** button again.
- **Skipping Tracks:** Press **[⏮]** or **[⏭]** button to skip to previous/next track.
- **Searching:** Press and hold **[⏮]** button to fast rewind within a track. Press and hold **[⏭]** button to fast forward within a track.
- **Adjust Volume:** Press **[V+]** or **[V-]** button to increase/decrease the volume.
- **Music function menu:** Press **[⏻]** button to enter the music function menu, and press it again to exit.

Display





Using Music Function Menu

While music is playing, press the [⏻] button, the music function menu appears for you to set the music repeat mode, equalizer, 3D, play rate, file browse and classification.

1. Press [V+] or [V-] button to select among **Repeat Mode, Equalizer, 3D, Play rate, File Browse and Classification**
 2. Press [▶/⏮] button to enter.
 3. Press [⏻] button to exit and return to music playing mode.
- **Repeat Mode:** set the music repeat mode. Use [V+] or [V-] button to select among: No repeat, Repeat One, Repeat All, Shuffle All, Folder Normal, Folder All Repeat and Folder Shuffle All. And then press [▶/⏮] button to confirm, or press [⏪] button to back to previous screen.
 - a) No Repeat: Play all songs in order once.

- b) Repeat One: Repeat the current or selected song.
 - c) Repeat All: Repeat all songs.
 - d) Shuffle All: Play all songs in the Player at random.
 - e) Folder Normal: Play all songs in the current folder in order once.
 - f) Folder All Repeat: Repeat all songs in the current folder.
 - g) Folder Shuffle All: Play all songs in the current folder at random.
- **Equalizer:** set the music playing equalizer. Use [V+] or [V-] button to select among: Normal, Pop, Rock, Classic, Jazz, Bass, and Custom EQ. And then press [▶||/M] button to confirm, or press [◀◀] button to go back to previous screen.
To customize EQ:
 - a) Select “Custom EQ”, and then press [▶||/M] button.
 - b) Press [◀◀] or [▶▶] button to navigate among value bars.
 - c) Press [V+] or [V-] button to adjust the value.
 - d) Press [▶||/M] button to confirm and exit.
 - **3D:** to open 3D effect or not. Use [V+] or [V-] button to select “Off” or “On”, and then press [▶||/M] button to confirm, or press [◀◀] button to go back to the previous screen.
 - **Play rate:** set the music-playing rate. Use [V+] or [V-] button to select among: 1.00X, 1.14X, 1.33X, 0.67X, 0.80X. Then press [▶||/M] button to confirm, or press [◀◀] button to go back to the previous screen.
 - **File Browse:** Press [V+] or [V-] button to select File Browse, press [▶||/M] to play it.
 - **Classification:** classify songs by their genre, artist, album and title. If it is the first time for you to classify your songs, choose “Classification” and select “Yes”, and then press [▶||/M] to refresh your classification. When the classification is

finished, use [V+] or [V-] to select among genre, artist, album or title, then press , press [V+] or [V-] to choose a song, and then press  to play it.

Note: *The play rate function is not available for WMA music format.*

Lyric Displaying


This player supports lyrics display while music is playing. Only the lyrics in LRC format can be displayed.

To add lyrics to the music, take “love music. Mp3” for example:

1. Download the corresponding lyrics with extension “.lrc” from the Internet.
2. Rename the lyrics file as “love music.lrc”. Make sure the lyrics filename is the same as the music file name.
3. Copy both files into the same folder on the player.
4. The lyrics will be displayed on the screen while the music is playing.

Watching a Video

Playing a video



1. Press and hold the [▶||/M] to access the main menu.
2. Use [V+] or [V-] to select **VIDEO** and press [▶||/M]. The video list appears on the screen.
3. Use [V+] or [V-] to select a folder or a video and press [▶||/M] to open the folder or play the selected video.
4. Press [◀◀] to return to previous screen.




While video is playing, you can:

- **Pause/Resume Playing:** Press the [▶||/M] button to pause playing. To resume playing, press the [▶||/M] button again.
- **Skipping videos:** Press the [◀◀] or [▶▶] button to skip to previous/next video.
- **Searching:** Press and hold the [◀◀] button to fast rewind within a video; Press and hold the [▶▶] button to fast forward within a video.
- **Adjust Volume:** Press the [V+] or [V-] button to increase/decrease the volume.
- **Exit:** Press and hold the [▶||/M] button to return to video list menu.
- **Power Off:** Press and hold the [⏻] button to turn off the player.

FM radio





Listening to FM radio

Important: Always connect your headphone to the headphone jack, since the headphone cable serves as the antenna for the internal radio.


1. Access Main menu by holding .
2. Select "FM RADIO" with  then .



While listening to FM radio, you can:


- **Adjust Volume:** Press the  or  button to increase/decrease the volume.
- **FM radio function menu:** Press the  button to enter the FM radio function menu, and press it again to exit.
- **Power off:** Press and hold the  button to power off the player.


Display




1. Current frequency
2. Normal or Preset
3. Frequency Indicator
4. FM band
5. Volume level
6. Battery status

Using FM radio function menu


While listening to FM radio, press  button to enter FM radio function menu.

1. Press **[V+]** or **[V-]** button to select among **Save Station**, **Auto Scan**, **Band** and **Record** for state Normal
2. Press **[V+]** or **[V-]** button to select among **Del Station**, **Auto Scan**, **Band** and **Record** for state Preset
3. Press  button to enter.

- **Save Station**

To save a manual searched station, use **[V+]** or **[V-]** button to select “Yes”, and then press the  button to save the station.

- **Auto Scan**

Use **[V+]** or **[V-]** button to select “Auto Scan” and press the  button to start searching. The MP3 player searches automatically for all radio stations with the strongest reception and

save them in the 20 memory locations (CH01-CH20).

The player will start from the first channel automatically after finishing searching. Use [◀◀] or [▶▶] to select a channel.

- **Band**

When you travel overseas, change the FM Band to search the local radio station. Use the [V+] or [V-] button to select a FM Band from **US** (87.5-108.0), **Europe** (87.5-108.0) and **Japan** (76.0-90.0), then press the [▶II/M] button to confirm.

***Note:** Once you return to the FM radio mode after changing the FM Band, the player will search automatically for all radio stations in the region and save them in the 20 memory locations.*

- **Del Station**

To delete a station, use the [V+] or [V-] button to select “Yes” or “No”, and then press the [▶II/M] button to confirm.

- **Record**


Use the [V+] or [V-] button to select “Record” and press the [▶II/M] button to start FM recording. To pause recording, press [▶II/M]. To resume recording, press [▶II/M] again. Press the [⏻] button to save the recording and return to FM radio mode.

Note:

- *The recorded files are saved in the FM folder of the MP3 player as WAV files (format: FM000001.WAV, FM000002.WAV) and can be listened to in the Voice mode.*
- *FM recording is automatically stopped when the memory of the player is full or the battery power is no longer sufficient. Date for recording is automatically saved.*
- *The volume adjustment is not available during recording.*

Viewing Photos

Viewing a Photo




1. Press and hold **[▶/⏪]** to access the main menu.
2. Use **[V+]** or **[V-]** to select **PHOTO** and press **[▶/⏪]**. The photo list appears on the screen.
3. Use **[V+]** or **[V-]** to select a folder or photo and press **[▶/⏪]** to open the folder or view the selected photo.
4. Press **[⏪]** to return to the previous screen.

While viewing photos, you can:

- Use **[V+]** or **[V-]** to select a folder or photo and press **[▶/⏪]** to open the folder or view photos.
- To select the previous or next photo, press **[V+]** or **[V-]**.
- To return to the photo list, press **[⏪]** or **[⏩]**
- To select “Slide show”, press the **[▶/⏪]** button. To select “Manual scan”, press **[V+]** or **[V-]**.
- **Power Off:** Press and hold the **[⏩]** button to turn off the player.

E-book Reading

This player only supports E-Book in TXT format. Other formats must be saved as TXT format before transfer.



1. Press and hold **[▶II/M]** to access the main menu.
2. Use **[V+]** or **[V-]** to select **E-BOOK** and press **[▶II/M]**. The E-Book list appears on the screen.
3. Use **[V+]** or **[V-]** to select a folder or file and press **[▶II/M]** to open the folder or view the selected file.
4. Press **[◀◀]** to return to the previous screen.

While reading an E-Book, you can:

- **Auto paging:** Press the **[▶II/M]** button to start auto paging for every 4 seconds.
- **Fast browse** Press and hold the **[V+]** or **[V-]** button to fast browse.
- **To move to the previous or next page, press [◀] or [▶].**
- To return to E-book list, Press hold the **[▶II/M]**
- **Power Off:** Press and hold the **[⏻]** button to turn off the player.

Save and Load a bookmark

This function helps you to save the page you have read and recall it to continue reading next time.

While reading an E-Book, press and hold the [U] button to enter “Bookmark List”.

- **Save a Bookmark:**

1. Press the [V+] or [V-] button to select “New Bookmark”, and then press [▶II/M]. “Save Bookmark” appears on the screen.
2. Press the [▶II/M] button to confirm. A window pops up for you to select “Yes” or “No”.
3. Use the [V+] or [V-] button to select “Yes” (Save bookmark) or “No” (back to previous screen).
4. Press the [U] button to exit.

- **Load a Bookmark:**

1. Press the [▶II/M] button in “Bookmark List” interface.
2. Use the [V+] or [V-] button to select “Load Bookmark”.
3. Press the [▶II/M] button to confirm. Then you can skip to the page you have saved.
4. Press the [U] button to exit.

- **Delete a Bookmark:**



1. Press the [▶II/M] button in “Bookmark List” interface.
2. Use the [V+] or [V-] button to select “Delete Bookmark”.
3. Press the [▶II/M] button to confirm. There pops up a window for you to select “Yes” or “No”.
4. Use the [V+] or [V-] button to select “Yes” (Delete bookmark) or “No” (back to previous screen).
5. Press the [U] button to exit.

Note: While in E-Book list mode, you also can press the [U] button to enter “Bookmark List”. However, you can only load or delete a bookmark here.

Voice Recording and Playing

Recording a Voice

1. Access Main menu by holding **[▶/⏸/M]**
2. Select "VOICE" with **[V+]/[V-]** then **[▶/⏸/M]**



While recording a voice, you can:

- To pause the playback, press **[▶/⏸/M]** button again. To resume the playback, press the **[▶/⏸/M]** button.
- To skip to the previous or next track, press the **[⏮]** or **[⏭]** button.
- To search backward or forward within a track, press and hold the **[⏮]** or **[⏭]** button.
- Press the **[⏻]** button to enter the voice Sub-menu and select "Record", To stop the recording, press the **[▶/⏸/M]** button.

- Press the [⏻] button to save the recording and return to voice recording interface.
- **Save the Recording:** Press the [⏻] button to save the recording and return to voice recording interface.

Note:

- *The recorded voice files are saved in the VOICE folder of the MP3 player as WAV files (format: MIC00001.WAV, MIC00002.WAV).*
- *Voice recording is automatically stopped when the memory of the player is full or the battery power is no longer sufficient. Date for recording is automatically saved.*

Setup the recording quality


Before starting the recording, you can set the recording quality.





1. Press and hold [▶||/M] to access the main menu.
2. Use [V+] or [V-] to select **SETUP** mode and press [▶||/M]. The SETUP menu appears.
3. Use [V+] or [V-] to select **Record Setting** and press [▶||/M]. The record options appear.

Item	Occupy memory	Quality
Long Time	Occupy least memory	Normal recorded quality
Normal Quality	Occupy less memory	Better recorded quality
High Quality	Occupy much memory	Best recorded quality

4. Use [V+] or [V-] to select Long Time, Normal Quality or High Quality.
5. Press [▶||/M] to confirm.

Using voice function menu


While in standby mode of voice mode, press the  button to enter the voice function menu.

1. Press the **[V+]** or **[V-]** button to select among **Repeat Mode, Equalizer, 3D, Play Rate, File Browse, Record**
 2. Press the  button to enter.
 3. Press the  button to exit.
- **Record:** start recording. Use **[V+]** or **[V-]** button to select “Record”, and then press the  button to start recording.
 - **File Browse:** select a voice and play it. Use **[V+]** or **[V-]** button to select a voice, and then press the  button to play it.

Note: *Repeat Mode, Equalizer, 3D and Play rate functions in the Voice mode are the same as the functions in the Music mode.*

Managing Files


Browsing all files and deleting a file



1. Press and hold [▶II/M] to access the main menu.
2. Use [V+] or [V-] to select **FILE BROWSE** and press [▶II/M]. The file list appears on the screen.
3. Press [V+] or [V-] to navigate between files or folders.
To open a folder, select the folder and press [▶II/M].
4. Use [V+] or [V-] to highlight a file, and then press the [⏻] button, there will DELETE option menu will pop up.
5. Press [V+] or [V-] to select "Yes" or "No", and then press [▶II/M] to confirm.
6. Press [⏪] to return to the previous screen.

Changing Player Setups

The system setups let you customize and configure your MP3 player.



1. In standby or playing mode, press and hold **[▶/⏸/M]** to access the main menu.
2. Use **[V+]** or **[V-]** to select **SETUP** and press **[▶/⏸/M]**. The setup menu appears on the screen.
3. Use **[V+]** or **[V-]** button to select a setup item.
4. Then press the **[▶/⏸/M]** button to enter the submenu.
5. Use the **[V+]** or **[V-]** button to select a value.
6. Press the **[▶/⏸/M]** button to confirm. Or press the **[◀◀]** button to exit and not confirm.

Setup items

Setup Items	Description
Power	Set how long it will power off automatically after it is not used for a certain time. The available options include: 15 Minutes,30 Minutes,60 Minutes,90 Minutes,120 Minutes, Close
Language	Set up the display language.
Display Setting	Set the brightness and backlight time. The available options of backlight time include: 15 Seconds, 30 Seconds,1 Minute and Close
Record Setting	Set the recording quality
Sys Tools	Delete a file on the player; format the player; reset the player; get to know the system information; refresh playlist and sort files.
Hold Time	Set how long the keys will be locked if no button is pressed. The available options include: 10 Seconds,30 Seconds,1 Minute,3 Minutes,5 Minutes, Off

Power setup

- **Auto off:** To set how long it will power off automatically after it is not used for a certain time. Press [V+] or [V-] to select a time, and then press **▶||M** to confirm.
- **Always on**
Press [V+] or [V-] to select “Yes” or “No”, and then press **▶||M** to confirm.
Yes: The player will be always on while playing. However, it will power off automatically in standby mode if no button is pressed after the set time.
No: The player will power off automatically if no button is pressed after the set time.

Adjust the brightness

1. Press [V+] or [V-] to select “Display setting” in the SETUP menu, and then press [▶/M] to confirm.
2. Use [V+] or [V-] to select “Brightness”, and then press [▶/M] to enter.
3. Press [V+] or [V-] to adjust the backlight, and then press [▶/M] to confirm or press [◀◀] to exit.

System tools


- **Delete:** To delete a file in the player.
- **Format:** To format the player quickly or completely. After formatting, all the data on the player will be erased.
- **Reset:** To restore all settings of the player to factory default settings.
- **System info:** To check the free memory and firmware version of the player.
- **Refresh:** To refresh all the playlist of the player.
- **File Sort:** To sort all files on the player.

Note: Back up important files in the player before formatting. The erased files cannot be restored.


Converting Video to MTV Format

This player supports the playback of videos in MTV format. Other formats (AVI, WMV, MPEG1, Quick Time, MPEG2, RealMedia, MPEG4, 3GP) must be converted to MTV format. The “MTV Video Converter” is supplied on the CD to enable you to convert the other formats to MTV format.

1. Insert the provided CD to the CD-ROM driver of your computer.
2. Double-click the file “VideoConvert.exe” in the folder “MTV Video Converter” of the CD. The **Video Converter** window appears.



Video Converter




Open dialog box

- Click **Input Video**, and then select the input source from the **Open** dialog box.

Note: To input MP4 files, select **All Files (*.*)** in the **File of type** box so that the MP4 files can be found in the **Open** dialog box.

- Click **Output Video** to select an output directory.
- Click **Advanced Settings**. Select **128x128** in the **Output Frame Size** box and select **MTV** in the **Output Format** box.
- Click **Start Conversion**.

For detailed operations, click **Help**.



Note:

- To make your video is playable on the player, you must select **128x128** or less in the **Output Frame Size** box (Advanced Setting). Otherwise, the message “Device Not Support” will appear on the screen when you play the video file.
- You have to install the relevant codec package before running “Video Converter.exe”. If not, the system will prompt “Load Video Failed!” when you attempt to convert the video files. Click “OK” and follow the prompt to download and install codec from the web sites.



Troubleshooting

If you have problems in operating your player, please check the points below before sending it to the service center.

Cannot power on

- The battery may be exhausted. Please recharge the battery.

Files cannot be downloaded

- Check if the driver is installed correctly on the computer.
- Check the connection between the player and PC.

No sound from the headphone

- Please ensure the volume is not 0, and there is no problem with the headphone connection.
- Check that the audio file format is supported by the player.


Recording cannot be done

- Check if there is enough memory and battery capacity.

The words on the LCD display abnormally

- Please ensure you have selected the correct language.

The buttons do not work

- The key may be locked. Press and hold  to deactivate the lock function.
- Press the reset hole with metal pin to re-initialize the system of the player.

Poor FM reception

- Check whether a headphone is connected correctly to the headphone jack. The headphone cord functions as an antenna.
- Adjust the position of the player and headphone.
- Turn off the power of the electric devices near the player. If it is effective, move and use the player away from those electric devices.

Specifications

Audio Format	MP3/WMA/WAV	Size	75.4*40*11.9mm
Photo Format	JPEG/BMP	weight	26.6g
Video Format	MTV	Frequency response	20Hz~20KHz
MP3 bit Rate	8Kbps ~320Kbps	Dynamic current	15mA
WMA bit rate	5Kbps ~320Kbps	Storage condition	Humidity <90%, Normal temperature
S/N rate	80db (30K filter)	Working condition	Humidity <85%,-10~40°C
Dynamic range	>80db(1KHz)	Recorded format	WAV
Distortion	<0.2%	EQ	Normal/Pop/Rock/Classic/Jazz/Bass/Custom EQ
Battery	170mAh, up to 15 hours of music playback and 3 hours of video playback		
Support video format to converter	AVI(*.avi), WMV(*.wmv, *.asf), MPEG1(*.mpg), QuickTime(*.mov, *.qt), MPEG2(*.vob), Real Media(*.rm, *.rmvb,...), MPEG4, 3GP(*.3gp)		