

# Contents

Main Screen

## **Windows**

Plot Screen

Signal Generator

Profile

Tuning

Failsafe

Miscellaneous

Pulse

Data Acquisition

Dacq View

Read/Write

## **Other Functions**

Password


Communication Handling

## **How to Tune**

Tuning Procedure

# Main Screen

Normally, the first screen displayed upon running the ER3000 software is the main screen (Note - If communication is not functioning another screen will display first. See Communication Handling.) The main screen consists solely of a menu for accessing various functions.



The "**File**" menu item contains three submenus: "Save Configuration", "Change Configuration" and "Quit". "Save Configuration" will save the tuning parameters from the controller to a file. "Change Configuration" will open a file containing previously saved tuning parameters and download them to the controller. "Quit" is used to exit the program and close any other windows which are open.

The "**Node**" item is used to change the node being communicated to. It has two submenus: "Node Select" and "List Nodes". "Node Select" allows the user to enter a new node number to communicate with. "List Nodes" produces a list box of all nodes which are connected to the network; the user can then select one. See Communication Handling for more information. Note that the node number with which the program is currently communicating is shown in the Main Screen's title bar. This corresponds to the data in all windows.

The "**Window**" item is used to open various other screens. See specific sections for each item:

- Plot
- Signal Generator
- Profile
- Tuning
- Failsafe
- Miscellaneous
- Pulse
- Data Acquisition
- Dacq View
- Read/Write

The "**Refresh**" item is used to read up all the parameters from the controller and refresh the screens which are open. It is usually not necessary to do this unless parameters may have changed locally.

The "**Password**" item will not be visible if the user does not have password authorization.


The "**Help**" item is used for accessing this online help system.

### ***Context Sensitive Help***


This help system is context sensitive. If the right mouse button is clicked on any open screen the help system will be called for the appropriate topic.

# Plot Screen

The plot screen is used to graphically display, in real-time, the current setpoint and feedback from the selected controller. These values are updated every 100 milliseconds.



The main menu items are:



The "**File**" item has two subitems: "Print" to print a hardcopy of the current plot (with tuning parameters) and "**Quit**" to close the plot screen.

The "**Axis**" item is used to set up the ranges for the horizontal and vertical axes. "**Time**" corresponds to the time along the horizontal axis. Selecting "Minimum Vertical/Maximum Vertical" allows for inputting the "Minimum" and "Maximum" ranges for the vertical axis. Also "Full Scale" resets the vertical axis to the full range of the controller.


An alternate method of *setting the vertical axis* is via the mouse cursor. Left-clicking at two points on the plot corresponding to the desired min and max of the plot will cause the vertical axis to be rescaled. Double-left-clicking in any area of the plot will cause the vertical axis to be reset to full scale. (Double-left-clicking a second time causes the plot to zoom out further).

The "**Labels**" menu item causes the border and labels around the plot to be removed.


The "**PlotStop**" menu item (toggles to PlotStart) stops and starts the plot.

# Signal Generator

The signal generator provides a means for creating a setpoint from the computer and downloading it periodically (every 100 ms.) to the controller. Typically this screen will appear as follows:



The setpoint source gives the user the ability to determine where the setpoint comes from. The four options are:



**Analog Input** - The setpoint is to be obtained from the controller's analog input (4 to 20 mA or 1 to 5 V analog signal).

**Serial Port** - The setpoint is to be sent via the serial port (RS485) to the controller.

**Profile** - The setpoint is to be generated internally by the controller using the previously defined profile.


**User Interface** - The computer should not send setpoints to the controller since they will be generated locally (i.e. - using the optional user interface).

There are five different **signal types** available: Toggle, Square, Sine, Triangle and Pulse. If Square, Sine or triangle are chosen then the screen appears as above and the user can enter the period of the wave and **Setpoint 1** and **Setpoint 2** (the peak values for the wave). In addition the Run/stop button allows for stopping the waveform at the current value.




If **Toggle** is chosen as the wave type then the screen will appear as follows. In this case no period parameter is available and the switch becomes **Setpoint1/Setpoint2** for toggling between the two setpoints. Note that if the "Signal Generator" screen is opened in toggle

mode (or switched to toggle mode) then setpoint 1 will be set to the current setpoint read up from the controller unless the current setpoint happens to match setpoint 2.




The following screen shows the configuration for **Pulse** signals. Pulsing allows for manually single pulsing the controller's solenoids. A pulse width of 100% corresponds to a 25 ms. pulse on the inlet solenoid and a pulse width of -100% to a 25 ms. pulse on the exhaust solenoid. Each time the "Pulse" button is pressed the controller will output a single pulse.



[Note however, that the controller will still attempt to perform it's normal PID algorithm even when the signal generator is in pulse mode (to overcome this set the Proportional and Integral min/max terms to zero to disable PID control).]

If the controller has been set up for profile mode the signal generator appears as follows, allowing the user to stop, start (from beginning of profile) or run (continue from current location in profile) the current profile. See Tuning and Profile for more information on configuring profiles.




# Profile

The profile screen allows the user to upload, generate, download, save (to a file) and read (from a file) profiles which can be run on the controller. The ER3000 has the ability to run profiles independently of the computer, although a computer can be used to generate profile sequences and command the controller to stop or start the running of a profile.

**IMPORTANT!!!** - THE PROFILE CREATED IS ONLY PRESENT ON THE COMPUTER UNTIL "DOWNLOAD" IS SELECTED. ONLY THEN IS THE PROFILE IN THE CONTROLLER AND CAN BE RUN.


A typical profile screen follows.




The **PRINT** outputs the profile to a printer. **UPLOAD** reads the profile from the controller and displays it on the screen (upload also takes place automatically when the window is opened). **DOWNLOAD** writes the newly created or modified profile into the controller. **OPEN** reads a profile from a file. **SAVE** writes a profile to a file. **QUIT** closes the profile window.

By highlighting a profile step (using the up/down arrows or the mouse) and then selecting insert/modify/delete the user can create a custom profile. (Note - double-left-clicking on a profile item also can be used for modifying an item).

Choosing insert or modify, the user is presented with a screen for creating a profile step.



The types of segments include the following:



An "**End**" segment is used to end the profile.

A "**Ramp**" segment creates a ramp starting at the current setpoint and ramping to a desired setpoint in a specified time period.

A "**Step**" segment changes the setpoint immediately to a desired setpoint.


A "**Dwell**" holds the current setpoint for a specified period of time.

A "**Digital Output**" is available on the optional user interface, UI3000, and on units equipped with the digital output electronics. Specifying output 1 or 2 selects a digital output on the UI3000 and output 3 or 4 selects a digital output on the ER3000. If available the specified output is set to the specified state.

A "**Digital Input**" is available on the optional user interface, UI3000, and on units equipped with digital/analog electronics. Specifying input 1 or 2 selects a digital input on the UI3000 and input 3 selects a digital input on the ER3000. If available the profile is halted until the specified input is set to the specified state.


A "**Loop**" causes the profile to loop to a specified profile step a specified number of times (if the number is specified as zero then the loop will continue indefinitely).

A "**Change Variable**" allows the user to set an embedded variable to a specified value. Some of the variables are shown in the following diagram. See the ER3000 user manual for the significance of each variable.




# Tuning

The tuning screen contains the main parameters which affect the controller's performance. See the Tuning Procedure section for more detail on the tuning process.



The first parameter is the control mode. When selected the following menu appears.



The four options for control mode are as follows:

**Internal Feedback** - Internal feedback (onboard sensor) used.


**External Feedback** - External feedback (user supplied sensor) used.

**Cascade Loop** - Both internal and external used.

**Manual** - Setpoint directly controls the valves.

If the controller goes into failsafe mode then "FAILSAFE" will be displayed for "Control Mode" and if the controller goes into emergency stop mode (possible only with the user interface option) then "ESTOP" will be displayed for Control Mode.

Note that, based on the control mode, parameters are shown for the Inner Loop and Outer Loop as appropriate. In the following screen the Control Mode is set to Cascade Loop, hence both Inner Loop and Outer Loop parameters are displayed (compare to screen above which is set up for Internal Feedback).



The menu item labelled **Simple** (toggles to **Advanced**) reduces the number of parameters displayed and is useful for inexperienced users.

The following parameters apply to both the Inner Loop and Outer Loop:

**Proportional Term** - This term multiplies the error.

**Integral Term** - This term multiplies the integral of the error.

**Derivative Term** - This term multiplies the derivative of the feedback.

**Integral Minimum** - This is a lower limit set on the integral (the integrator will integrate down to this value).

**Integral Maximum** - This is an upper limit set on the integral (the integrator will integrate up to this value).

**Integral Deadband** - This causes integration to stop when the error is within this band (in percent). If this value is set to zero then it has no effect.

*Note - By choosing the **Format** menu item the preceding items can be displayed either as gains or as Bands/Reset/Rate. Gains are simply multiplying factors whereas Bands/Reset/Rate is the more traditional way of specifying PID values. Thus the user should choose one or the other format to enter tuning parameters.*

The next value on the screen - **ExtFBSource** is the source for the external feedback signal. The choices are External Feedback and Extra Input 1. Extra Input 1 is only available on units equipped with the additional digital/analog inputs.

The next two values on the screen - **Minimum Pulse Width** for the inlet and exhaust solenoids are the minimum values which are written to the pulse width modulators. They can have a value between zero and 50 (50 corresponds to a duty cycle of 20%). Essentially, these values are used to define the deadband of the output and prevent noise or small fluctuations in the controlled pressure from causing the valves from opening. Small values can be used to keep the valves from constantly sputtering and large values to prevent the

output pressure from varying much before taking action.

The following parameters pertain to the Sensor:

*Minimum Range* - The value corresponding to the minimum for the sensor. In the case of an external 4 to 20 mA transducer, this is the value which corresponds to 4 mA.

*Maximum Range* - The value corresponding to the maximum for the sensor. In the case of an external 4 to 20 mA transducer, this is the value which corresponds to 20 mA.

*Units* - Up to four characters which the user wishes to use to refer to the reading. This string is applied to the plot screen and to the optional user interface.

Note - If the user wanted to set up a system in internal feedback mode to display bar, instead of PSI, he/she would set units = "BAR", minimum range = "0", maximum range - "6.8947" (since 100 psi = 6.8947 bar).

# Failsafe

Failsafe checking is not usually used, however, it provides the ability to shut the controller down if an out of range condition occurs. Any combination of the following five parameters can be checked:

**Analog Setpoint** (range : -12.12% to 111.97%)

**Internal Sensor** (range : -12.12% to 111.97%)

**External Sensor** (range : -12.12% to 111.97%)

**Inner Error** (range : -124.12% to 124.09%)

**Outer Error** (range : -124.12% to 124.09%)

When the minimum value is set to the minimum value above and the maximum value is set to the maximum value above then the failsafe checking is disabled.


|                 | Minimum  | Maximum  |
|-----------------|----------|----------|
| Analog Setpoint | DISABLED | DISABLED |
| Internal Sensor | DISABLED | DISABLED |
| External Sensor | DISABLED | DISABLED |
| Inner Error     | DISABLED | DISABLED |
| Outer Error     | DISABLED | DISABLED |

Failsafe Condition


Inlet Closed / Exhaust Open

Disable All

When any value is selected (via a mouse click) the following dialog box is displayed. The "Out of Range" message is displayed if a value entered is not allowed. Selecting the "Disable" button will set the value to it's extreme and thus disable failsafe checking for the corresponding limit.



The final item on the failsafe screen, **Failsafe Condition** allows selecting one of the following conditions to be established should the failsafe condition exist.




Normally, "Inlet Closed/Exhaust Open" should be selected so that the controller vents to atmosphere if a failsafe limit is exceeded.

The **Disable All** button can be used to completely shut off the failsafe feature (most users will not need to use this feature).

# Miscellaneous

The miscellaneous screen contains a collection of parameters which don't fall into the category of any other screen.



The screenshot shows a window titled "Miscellaneous" with a blue header bar. The window contains several input fields and dropdown menus. Under the "Calibration" section, there are two input fields: "Span (%)" with the value "99.98" and "Zero (%)" with the value "0.00". Below this is a "Node Number:" field with the value "250". There are two dropdown menus: "Feedback Filter" set to "ON" and "Solenoid" set to "NORMAL". At the bottom, there are two read-only fields: "Serial Number : 4170" and "Version Number : 620".

The **calibration** parameters allow for fine adjustment of the controller. From the factory the **span** is set to 100% and the **zero** to 0%. However, the user may find it useful to adjust these parameters to compensate for external transducers (for example - overstressed transducers which need recalibration).

The "**Node Number**" can be input to change the node number of the unit being communicated with. Note that this is different from changing node from the main screen. When changing node from the main screen, the program merely attempts to communicate with a different controller. When changing node from the Miscellaneous screen, the node number of the current controller is reprogrammed (the main screen node is also updated so that the windows program continues to communicate with the same controller).

The "**Feedback Filter**" is a switch which enables/disables filtering of the feedback signal internally in the controller. Note that the signal used by the control algorithm is not filtered. This is useful for cleaning up noisy transducer signals for display on the plot screen.


The "**Solenoid**" parameter can be set to either "NORMAL" or "REVERSE". Reverse corresponds to reversing the action so that instead of opening the inlet solenoid, the exhaust solenoid is opened and vice versa. An example use for this feature would be if an external temperature transducer is used as feedback and the controller is regulating cooling air for temperature control. Thus, it is necessary to increase the flow in order to reduce the temperature.

The "**Serial Number**" is a factory programmed parameter and should not be changed by the user.

The "**Version Number**" indicates the version of the software in the unit. It is not changeable by the user.

# Pulse

The pulse mode parameters allow for fine tuning the controller. The pulse mode allows for a means of reducing oscillations caused by systems which respond slowly to adjustments made by the controller. Pulse mode is only activated within the integral deadband region (see Tuning screen). Pulsing continues until within the pulse deadband (see value below). Pulse mode has no effect on the normal control algorithm.



The screenshot shows a window titled "Pulse Variables" with a blue header bar. Inside the window, there is a "Pulsing" checkbox which is checked, and a dropdown menu set to "Enabled". Below this, there are three input fields: "Period" with the value "12", "Width" with the value "8", and "Deadband" with the value "3". At the bottom, there is a note: "NOTE: 'Integral Deadband' must be greater than zero for pulsing to function." followed by "See: TUNING" with a button labeled "TUNING".

"Pulsing" can be either "Enabled" or "Disabled".


The "Period" is the rate of the pulse. This number represents the number of passes through the control algorithm task before pulsing. The control algorithm task executes every 25 milliseconds.

The "Width" determines how long to hold the solenoid valve open. Part of this number compensates for allowed noise in the control system. Therefore, too small a number will not open the valve.

The "Deadband" is the number of counts of error allowed in the system for the pulsing function. One count of error is .03%. This number is typically 0-3.

# Data Acquisition


The Data Acquisition screen provides a means of saving setpoint and feedback data to a disk file. The data can then be viewed using the Dacq View functions. The sample rate can be any multiple of .100 seconds. The user specifies the filename for the data (if it already exists a message is displayed warning the user). The number of samples can also be specified. Or by pressing the start button followed by later pressing the stop button (the single button toggles between the two) data can be collected under manual control.



An optional file header can be written to the start of the file which includes the date and time and a user specified comment. Delimiters between data (data includes the time, with a resolution of .001 seconds, the setpoint and the feedback) can be specified as spaces, tabs or commas.


# Dacq View

The Dacq View screen provides a means of viewing data which has been previously collected to a file using the Data Acquisition functions.



After loading the screen the user must choose "File/Open" to load in a data file. Up to 10,000 points will be plotted.

If the file includes a header then choosing the "Header" menu item will display it in a separate window as shown below.




Once a data file has been loaded, the zoom menu item can be chosen to enlarge a region of the plot. Alternatively the mouse can be used to choose two corners of a rectangle to zoom (clicking with the left mouse button).

## Read/Write

The Read/Write screen allows direct access to all of the controller's variables. See the ER3000 User Manual for a description of each of the programmable variables.

*Note - This function should be used with caution since it can cause inadvertent changes to the controller.*

The user can open up to four read/write screens.



Each screen is set up for either reading or writing via the parameter in the upper left hand corner of the screen.

The variable number to be read or written can be entered directly or the user can select the desired ID via the list box (the box showing "ID\_SETPOINT" above).

The **PSI** entry corresponds to the value read (reading occurs about once per second) or the value to be written. This box is visible only for the ID\_SETPOINT and ID\_FEEDBACK parameters. It scales the value read, as in "RAW ER3000 16-BIT DATA" to the Sensor Range (and Units) specified in the TUNING window. Note that the write occurs only once after the user has changed the value. Also, certain variables are read-only and writing to them will have no effect (see ER3000 User Manual for details).


The RAW ER3000 16-BIT DATA entries are the SIGNED, UNSIGNED, and HEX representations of the data read from or written to the controller.

The **Refresh!** button is used to read up all the parameters from the controller and refresh the screens which are open. This should be done after writing any variable using the Read/Write screen.

Note again that the read/write screen is an advanced feature and not normally needed by most users.

# Password

The windows tune program provides a means for password protecting each of the screens from unauthorized use. To enable password protection choose the password menu item from the main screen. *(Note- this menu item only appears if password protection was previously disabled or if the user has previously logged in with a password.)* After choosing the main menu password item the following screen will appear.



To enable the password the first item must be selected to "Enable".

To change the password press the "**Change Password**" button. The user will then be prompted to enter the old password (the software uses the word "tescom" as the initial password) and then enter the new password (with verification).

Next the user can select any of the screens which should be password protected. In the screen shown above the Signal Generator, Read/Write and Profile screens have been selected for password protection.


The password will not take effect until the next time that the program is run. At that point the user will be presented with the following screen:



If the correct password is entered then the program will run the same as if password protection was not enabled. Otherwise the following message will appear.




Selecting "Yes" will allow the user to attempt to enter the password again. Otherwise if "No" is selected then the program will be run with the selected screens disabled. For example, with the selections shown in the screen at the beginning of this help topic the main menu will appear as follows:



Notice that the Signal Generator, Profile and Read/Write menu items appear in grey. This means that these menu items cannot be selected.

# Communication Handling

If the program is unable to communicate with a controller the following window will appear:



This window will appear if the controller is not properly wired to the computer or if the wrong node number has been selected.

If the user believes that the node number is in error and knows the correct node number then he/she can select "**Change Node**" and manually enter a new node number.

If it is believed that the node number is in error but the user does not know the node number of the controller, "**Search Network**" can be selected and the software will search for the appropriate node number.

If it is believed that the communication port is in error, the user can select the alternate communication port. The program will then exit, and it is necessary to restart the program for the new port to take effect. (*Note - The port number is stored in a file called "tescom.ini" in the windows directory.*)

"**Quit Program**" should be selected if all else fails and the user wishes to exit the program.

The **Simulate** button can be used to run the software in simulation mode (i.e. - without actually communicating with a controller).

# Tuning Procedure

This section will cover an example tuning procedure.

To begin, it should be realized that the tuning of PID controllers is learned with experience. However, the following basic concepts should allow the inexperienced user to tune their loops sufficiently well for the majority of applications.

There are some features of the ER3000 which are unique compared to other PID controllers and allow the system to be optimized. In particular, the use of four different modes of operation, the setting of minimum values for inlet and exhaust valves (deadband adjust) and the setting of maximum and minimum values for the integral sum allow for greater flexibility.

To begin, three windows should be opened :

- . Tuning (Advanced!).
- . Signal Generator.
- . Plot.

Each system has unique requirements, and since tuning will always be a compromise between various tradeoffs, it is necessary to decide what are the most important parameters for the given application. Typical goals include the following:

- . Maximize speed of response.
- . Minimize peak overshoot.
- . Minimize DC offset.
- . Minimize settling time.

In addition, the region of operation will affect how the unit is tuned. This application will be operating primarily in the 0 to 2500 psi region. Thus tuning should be performed over this entire range. However, the final setup should be tested in intermediate pressure ranges as well, to verify maximum performance throughout the system's range.

In the Tuning Window, make sure the Control Mode is set to External Feedback and the Sensor Range Minimum and Maximum are 0 and 2500 respectively. The ER3000 is shipped with outer loop PID parameters that have been established at the factory to work well with the regulator in that system, however, in this example we will begin tuning by setting the parameters as follows:

- Proportional: 200.
- Integral : 0.
- Derivative : 0.
- Integral Minimum : 0.
- Integral Maximum : 0.

(Note - For cascade control it is best to set the Integral Minimum = 0 and Integral Maximum = 32767. This is because it is necessary to maintain a positive pressure on the dome of the regulator to maintain output pressure from the system.)

In the Signal Generator, set 'Setpoint 1' & 'Setpoint 2' to 625 and 1875, which is 25% and 75%. Make sure that the plot screen is set up to show the entire tuning range. For example, with the above setpoints, the display should be set up for 0 to 2500.

Since tuning is generally done using step changes, set up 'Wave Type' for option 'TOGGLE'.

Now click on the "Setpoint 1/Setpoint 2" in the Signal Generator to toggle between the two setpoints.

With the proportional term set to 200, the response will be relatively slow. The first step in tuning is to see how far the proportional term can be increased. In general, increasing the proportional term will decrease the response time (i.e. - make the response wave more square), however a point will be reached at which the effect becomes detrimental. That is, too much proportional term will result in overshoot and possibly ringing of the response. Also, it should be noted that the effect of the tuning parameters (PID) tend to be logarithmic. Thus a possible sequence of values to try for the proportional term might be 200, 400, 800, 1600, until ringing and/or overshoot occurs and then narrow down to an optimal value, one which gives just a slight amount of overshoot and ringing.


Next the derivative term should be increased so as to reduce the overshoot and ringing in the system. However, too much derivative term may result in a noisy output.

Once the optimal proportional and derivative terms are found, the integral term should be adjusted. The integral term has the effect of eliminating DC offsets, however too much integral will lead to instability (overshoot and ringing). Again the effect is logarithmic so values such as 10, 20, 50, 100, 200, 500, 1000 ... can be tried until an optimal value is obtained.


At this point it should be noted that the ER3000 provides a unique integral limiting feature ('Minimum Outer Integral' and 'Maximum Outer Integral'). This allows for using large integral terms without creating excessive overshoot. It should be realized that the integral sum is what holds the valves open even when there is zero error. For closed-ended systems the minimum and maximum integrals can be very small. However, for systems requiring flow it is necessary to keep these values higher. To determine how small they can be made (remember - smaller is better as long as proper flow is maintained) the setpoint should be set to the maximum level and the minimum and maximum reduced until flow is no longer maintained, then slightly increase these values. Often, for closed ended systems a value of one or two is sufficient.

After performing the steps mentioned above, tuning can often be improved by iterating between the various parameters. Although performing basic tuning can be simple, learning to fully optimize the tuning requires experience, so experiment!


The following is an example sequence of tuning steps. First a very undertuned response is shown (note size of proportional term).




Next the proportional term is increased, however, overshoot and ringing results:



Now, some Derivative is introduced. Note the decrease in overshoot.



However, if we zoom in on the horizontal axis between 1750 and 2000 psi, we notice that a small offset remains.



What can be done to eliminate the offset is the addition of integral term. The resulting response follows:

**Tuning** File Format Simple 1

Control Mode: External Feedback

Sensor Range: Minimum 0.00, Maximum 2500.00, Units: PSI

Outer Loop

Proportional Term: 1000

Integral Term: 200

Derivative Term: 50

Integral Minimum: -12

Integral Maximum: 64

Integral Deadband: 0.00

ExtFBSource: External Feedback

Minimum Pulse Width: Inlet 10, Exhaust 10

