

Advanced Bubble Control ABC USER MANUAL

Fully Automatic IBC and Calibrator Cage Control For Blown Film Production Lines



Manual Number: ABC203

P.O.B. 1122 Afula Illit 18550, Israel Phone: +972-4-6405857, Fax: +972-4-6405911 info@sysmetric-ltd.com www.sysmetric-ltd.com October 25, 2013

Table of Contents

1.	Ge	neral	Description	. 4
	1.1.	Princi	ple of Operation	.4
	1.2.	Width	Control – Radius Sensors	5
	1.3.	Calibr	rator Cage Control – Cage Sensors	6
	1.4.	Blowe	ers and Balancing Valve Control	7
	1.5.	Width	Calibration	8
	1.6.	Model	ling Control	9
	1.7.	Opera	tor Display	10
	1.7	.1.	Main Screen	11
	1.7	.2.	Width Graph	12
	1.7	.3.	Service Screen	13
	1.7	.4.	Sensor Service Screen	14
	1.7	.5.	IBC Service Screen	15
	1.7	.6.	General Service Screen	16
2.	Ins	stallati	on	17
	2.1.	Radiu	s Sensors Installation	17
	2.2.	Comp	ensation Sensor Installation	18
	2.3.	Cage	Sensors Installation	19
	2.4.	DBC	Installation and Sensor Wiring	21
	2.5.	Contr	ol Cabinet Installation	22
	2.6.	Electr	ical Wiring	23
	2.6	.1.	Sensors and DBC Wiring	23
	2.6	5.2.	Balancing Valve Wiring	23
	2.6	5.3.	Power Wiring	23
	2.6	.4.	Control Signals Wiring	23
	2.7.	Install	lation Parameters	25
	2.7	.1.	Sensors Installation Parameters	25
	2.7	.2.	IBC Blowers and Balancing Valve Installation Parameters	26
	2.7	.3.	General Parameters	27
3.	Ch	ecking	g the System	28
	3.1.	Line (On and Line Speed Signals	28
	3.2.	Extruc	der On Signal	29
	3.3.	Intake	and Exhaust Blowers	29
	3.4.	Balan	cing Valve	30
	3.5.	Calibi	rator Cage Control	31
	3.6.	Senso	rs	31
4.	Tu	ning		32
	4.1.	Cage	Factor – Coarse Tuning	33
	4.2.	Blowe	rrs Ratio and Intake Blower Capacity	34
	4.3.	Balan	cing Valve Control Value	35
	4.4.		Factor – Fine Luning	50 26
-	4.3.	Finish	ung the Tuning Procedure	30
5.	Sy	stem C	Jperation	57
	3.1.	Startin	пд Ртоаиспоп	5/

	5.2.	Control Mode and Control Stages	38
	5.3.	Changing Product (Changing Width)	39
	5.4.	Width Calibration	40
	5.5.	Automatic Width Calibration	41
6.	Sei	rvice and Maintenance	42
	6.1.	Alarms	42
	6.1	.1. Alarm Log	42
	6.1	.2. Alarms Messages	.43
	6.2.	Ultrasonic Sensors	47
	6.3.	Calibrator Cage	49
	6.4.	Troubleshooting	50
Ар	pendix	x A – NS10 Screens	52
Ap	- pendix	x B – Parameters Synopsis and Common Values	53
Ap	- pendix	x C – Assembly Example	55

1. General Description

1.1. Principle of Operation

The basic IBC (Internal Bubble Cooling) operation is to synchronize the volume of cold air, pumped into the bubble, with the volume of hot air being drawn out of the bubble. To increase the bubble width, the exhaust rate should be reduced correctly (or intake increased) causing the bubble to inflate by the extra air intake to the right size. The opposite action is carried out in order to reduce web width. To improve the accuracy, by enabling fast reaction, a balancing valve is added and located (usually) on the exhaust pass.

Since the width accuracy and stability highly depends on the calibrator cage position it should be fixed to an optimum diameter. There are two basic cage–bubble relationships (*Cage Gap*). The first and most widely used is whereby the cage acts as a calibrator, meaning that the bubble is "blown into" the cage and freezes in it. The second is when the cage is larger than the bubble and only supports the bubble. While the first Cage *Gap* produces better accuracy, it may also lead to some scratches and marks on the web.

Sysmetric's ABC system controls all these variables. It uses eight ultrasonic sensors that measure the "frozen" bubble size, the calibrator cage diameter, the cage-bubble distance (*Gap*) and compensate for atmospheric changes.

The ABC system uses "modeling" technique. This technique is the most advanced control method available on the market today. It can forecast changes that will affect the web and take the required actions in time. The system controls the calibrator cage motor, the blowers speed and the balancing valve, allowing continuous changes of any parameter during line operation.

1.2. Width Control – Radius Sensors

Four long range ultrasonic sensors (*Radius Sensors*) are statically mounted above the cage where the bubble is almost frosted. Sensors 1, 2 and 3 measure the distance to the bubble and by knowing their exact position, three radiuses of the bubble are calculated. The fourth sensor is used to calculate a barometric compensation parameter which is used for eliminating barometric effects on the width accuracy.

The four sensors are synchronized (the sonic pulses are sequenced) to eliminate any possible interference and to allow fast and stable distance reading.



Figure 1.2-1 – Radius Sensors

Note: barometric compensation covers temperature change as well as pressure, humidity and other effects that produce sonic errors but although accurate bubble size is measured here, the accurate web width cannot be calculated directly. The bubble at this point is very hot and is about to shrink as its temperature reduces to the ambient temperature. This shrinkage is also compensated by the ABC system as explained in the width calibration chapter.

1.3. Calibrator Cage Control – Cage Sensors

Four short range sensors (*Cage Sensors*), sensors 5, 6, 7 and 8, are mounted on the calibrator cage arms. They measure the gap between the cage and the bubble.

Sensors 5 and 6 are used for positioning the calibrator cage at the correct diameter. Using the readings from the radius sensors and adding to it the average top distance (CP5 and CP6), the system "knows" the exact actual cage diameter. It calculates the required diameter according to the expected radius (taking into account the bubble shrinkage), and the desired gap (either positive or negative). The required and the actual values are used for controlling the cage position and bringing it to the correct position automatically.

Sensors 7 and 8 measure the gap between the cage and the bubble at the bottom of the cage. This gap is compared to a required gap and the error is used to control the position of the balancing valve.



Figure 1.3-1 – Cage Sensors

Note: the four cage sensors (sensors 5, 6, 7 and 8) are optional. With production lines that either do not have a calibrator cage when the cage acts only as a support, the cage sensors can be omitted.

1.4. Blowers and Balancing Valve Control

Intake blower pushes ambient air through a heat exchanger and into the bubble, while an exhaust blower pulls the hot air out. The speed of the intake blower is set according to the desired cooling power and the exhaust blower speed is controlled by the system so that the speeds of the two IBC blowers are fully synchronized. The blowers follow parabolic curve that perform linear cooling behavior so that the cooling power can be changed from 10% to 100% during production with minor (if any) effect on the bubble width.

To overcome the limited respond of the blowers' drivers, because of the blower's inertia, a servo operated throttle (*Balancing Valve*) is mounted into the exhaust pipe and allows fast air flow changes. This balancing valve is operated by a servo actuator that does not allow any backlash, friction or air flow drag to reduce its accuracy.

The control scheme positions the balancing valve at a constant steady position until it slowly adjusts the exhaust blower's speed.



Figure 1.4-1 – Blower and Balancing Valve

Notes:

The throttle is mounted at the exhaust pipe so that the extra heat produced due to its existence will not affect the cooling power and will not change the frost level (with positive gap value). Unlike throttle actuators that use spring and pneumatic pistons, the servo actuator always has pin point accuracy and maintains a stable position.

1.5. Width Calibration

Though physics state a clear relationship between the radius of the bubble and the width of the lay-flat, this is not true in a blown film line. The radius should be controlled to a slightly larger size so that the shrinking effect, caused by the temperature change, will bring the lay-flat to the exact required lay-flat width. This is done either automatically or manually:

- 1. Automatic calibration when a web guiding system is installed its reading can be directed to the ABC system for automatic calibration. This allows the system to automatically update the shrinkage parameter of the product and maintain accurate lay-flat width.
- 2. Manual calibration in manual mode the operator enters a manually measured width and the system calculates the shrinkage parameter accordingly.



Figure 1.5-1 – Width Calibration

Note: the shrinkage parameter changes slightly as capacities, cooling power or ambient temperature vary, so it is best to have automatic feedback.

1.6. Modeling Control

Several types of control formulas are usually used. The most common is the PID control and its derivatives. A better and newer control type is the Fuzzy-Logic. These two control formulas calculate the error between the set and the actual width and adjust the control accordingly. A third control formula, modeling, takes into consideration the "whole picture" with the actual process dimensions:

- T- the tower height
- *C* the collapsing frame height
- F the feedback distance (either manual or automatic)

The modeling control follows the reading taken from the bubble all along the production line. This enables very accurate control according to the actual effecting parameters.

For example, when a temporary width error occurs, it usually "copies" itself as it gets to the take-off nip. This effect extends the stability time. Modeling "waits" until the interference reaches the nip and at the right time it changes the air flow in the opposite direction. Thus, if any interference occurs, the bubble will stabilize immediately.

Modeling even takes into consideration the fact that the bubble "flows" into the nip via the collapsing frame that gradually folds the web.

The same technique is used to synchronize the exhaust blower to the intake blower speed. It enables vast changes in blower speed with minor effect on the lay-flat width. It is so stable that for many processes the balancing valve can be eliminated.



Figure 1.6-1 – Modeling Control

1.7. Operator Display



The system display is Omron's standard industrial color touch-screen panel. Every operation on the display is carried out by gently pressing on the display. Activating a button is carried out by gently pressing on the display where the button appears. Changing numeric values is carried out by gently pressing on the display where the value is written.

Different sizes of display are available: 5, 8, 10 and 12 inch. The commonly used display is the 5 inch. The 10 inch display is used where the ABC is part of a full line control system. The advantage of the 10 inch display is the ability to contain a great deal of data in one screen. This is useful mainly during the installation of the system and for monitoring the system when trying to identify a source of a control error. For normal operation the 5 inch display is as good as the 10 inch.

For convenience only, this manual uses pictures of the 5 inch screens in the explanations and examples. The 10 inch display holds the same data although it is arranged differently in the screens. General views of the 10 inch screens are shown in the appendix.

Several screens have one or more editable numeric items (e.g. the required lay-flat width). To modify the value of an item, take the following steps:

- 1. Select the item that you want to edit by pressing gently on the display where that item is written. A numeric keypad will appear on the display.
- 2. Enter the new value using the numeric keypad.
- 3. Press the Enter key to confirm the change.

The keypad screen will close and the item will receive the new value.

Cancel editing by pressing the *X* button in the keypad screen.

0.0%								
7	8	9	X					
4	5	6	+/-					
1	2	3	+					
0		Enter						

Figure 1.7-2 – Numeric Keypad

Note: in cases where the ABC is part of a line control system, it can be equipped with a communication unit (Omron CLK, Devicenet, Modbus, Profibus etc.) so that the local display can be omitted and the operation will be from the line's operation panel. This enables "tailored" adaptation by any manufacturer's line control system.

The following is a brief description of the screens of the ABC system. More detailed descriptions appear further on in this manual in the relevant chapters.

1.7.1. Main Screen

The main screen is used in the regular operation of the ABC system. This screen enables setting the required lay-flat width and the bubble-cage gap, calibrating the width and it indicates the system's status.

	1	Width			Gap		
Set	10	300m	IM		Ømm		
Act	10	300 m	IM		Ømm		
Widt	h Calibr	ation	Line	Speed	35.Øm/min		
	Ømm			ke	65.0%		
1				aust	68.2%		
MAIN GRAPH SERVICE ALARMS							

Figure 1.7-3 – Main Screen

- *Set/Act Width* the set and the actual lay-flat width.
- Set/Act Gap the set and the actual gap between the bubble and the calibrator cage.
- *Width Calibration* manual calibration of the shrinkage parameter.
- *I*, *II*, *III* indication flags showing the current system's control stage.
- *Line Speed* the current line speed.

- *Intake* the intake blower's speed.
- *Exhaust* the exhaust blower's speed.

Pressing *Graph* shows graphs of the width error and calibrator cage movement. This screen is useful for tracking the system's performance. *Service* includes several screens for setting the system's parameters. The Service screens are used during installation, tuning and maintenance of the system. Pressing *Alarms* opens the alarm log of the system.

1.7.2. Width Graph

The Width Graph screen shows the width error and the movements of the calibrator cage (opening and closing). This graph is useful for verifying the accuracy of the width. The graph can show the last 5 minutes or the last 60 minutes.



Figure 1.7-4 – Width Graph

- 5min shows a graph of the last 5 minutes.
- 60min shows a graph of the last 60 minutes.
- *EXIT* closes the graph screen.
- *Maximum* the maximum value on the error axis. Press it to change the value.
- *Minimum* the minimum value on the error axis. This value updates automatically according to the maximum value.

1.7.3. Service Screen

The Service Screen enables changing the display's data: date and time, brightness and contrast and selecting the interface language. A set of service screens are available from this screen: *SENSOR*, *IBC* and *GENERAL*.

HIGH MIDDLE LOW	Sys metric		
MIDDLE LOW	Sys metric bar		
LOW	1000		
	10.75		
Contrast	Phone: +972-4-6405857		
HIGH	Fax: +972-4-6405911		
LOW	www.sysmetric-ltd.com		
BC	GENERAL ALARMS		
	Contrast HIGH LOW		

Figure 1.7-5 – Service Screen

- *Date & Time* set the current date and time (used in the alarm log).
- *Brightness* select high, middle or low display brightness.
- *Contrast* select high or low display contrast.
- *Language* select the interface language (contact Sysmetric for additional languages).
- *SENSOR* switch to the Sensor Service screen.
- *IBC* switch to the blowers, balancing valve and cage service screen.
- *GENERAL* switch to a service screen with general control data.

The Sensor Service screen shows the current reading of each sensor. Pressing *Radius Sensors* and *Cage Sensors* buttons opens detailed service screens for the sensors. It is used during installation and for maintenance. See the relevant chapters for further details.

Radius S	ensors	Cage Sensors			
Radius 1	318.0mm	Cage	5	0.1mm	
Radius 2	Cage	6	-0.2mm		
Radius 3	Gap Sensors				
Reference 4	251.2mm	Gap 7		0.2mm	
Barometri	c Factor	Gap 8		0.5mm	
1.004	8				
MAIN SI	ENSOR	IBC	GENERAL	MODEL	

Figure 1.7-6 – Sensor Service Screen

- *Radius 1, 2, 3* three radiuses of the bubble measured by sensors 1, 2 and 3.
- *Reference* 4 the distance measured by the compensation sensor 4.
- *Cage 5 and 6* the gap between the rolls and the bubble at the top of the cage.
- *Gap 7 and 8* the gap between the rolls and the bubble at the bottom of the cage.
- *Barometric Factor* a calculated factor for compensating barometric effects on the measured bubble's radius.

1.7.5. IBC Service Screen

The IBC Service Screen is used for controlling the IBC blowers, the balancing valve and the calibrator cage. Pressing *Balancing Valve*, *Cage Control* or *IBC Blowers* opens detailed service screens for the balancing valve, the cage and the blowers accordingly. These screens are used during installation and for maintenance. See the relevant chapters for further details.

Balancing	Valve	IBC Blowers						
Control Value	5.0%	Blowers Ratio	1.000					
Open 51. Ø	6 Close	Control Range	0.200					
Cage Col	ntrol	Control Ratio	1.050					
Cage Factor	750z	Actual Ratio	1.050					
Set Radius	318mm	Intake Speed	65.0%					
Actual Radius	318mm	Exhaust Speed	68.2%					
MAIN SENS	OR IBC	GENERAL	ALARMS					

Figure 1.7-7 – IBC Service Screen

- *Control Value* determines the balancing valve's response level.
- *Open Close –* shows the current position of the balancing valve. 0% the valve is completely open, 100% the valve is completely closed.
- *Cage Factor* this factor represents the time to movement ratio of the calibrator cage.
- *Set and Actual Radius* the set and the actual radius of the calibrator cage.
- *Blowers Ratio* the ratio between the intake blower and the exhaust blower.
- *Control Range* the allowed range for the *Control Ratio*.
- *Control Ratio* the calculated ratio between the intake and the exhaust blowers.
- Actual Ratio the current actual ratio between the intake and the exhaust blowers.
- *Intake Speed* the current speed of the intake blower.
- *Exhaust Speed* the current speed of the exhaust blower.

1.7.6. General Service Screen

The General Service screen is used for entering some general control parameters and selecting the control mode of the system. For convenience it also enables changing the set width and gap as in the Main screen. This screen is used mainly during installation and for maintenance. See the relevant chapters for further details.



Figure 1.7-8 – General Service Screen

- *Tower Height* the height of the production tower.
- *Collapsing Frame* the height of the collapsing frames.
- *Feedback* the distance to the feedback point.
- *Width Error Threshold* a threshold for width error alarm.
- *Maximum and Actual Line Speed* the maximum and the current line speed.
- Manual, Auto and Continue control modes of the ABC system.
- *I*, *II*, *III* indication flags showing the current control stage of the system.
- *Set and Actual Width and Gap* the set and the actual width and gap.
- *Cal* width calibration value.

2. Installation

2.1. Radius Sensors Installation

The three radius sensors (sensors 1, 2 and 3) are 30mm cylindrical ultrasonic gages. They should be mounted on top of the calibrator cage with the following points taken into consideration:

- The sensors should be pointing at the bubble's center and placed at about 120° from each other.
- They should be mounted 250–400mm above the top bubble supporting arm.
- The minimum distance between the gage and bubble surface should be 250mm (when producing the maximum lay-flat width).
- The maximum reading distance is 1500mm (different gages can be used for larger/smaller bubbles).
- The exact distance from the gages to the center of the die should be measured and entered as the installed distance parameter at the radius sensors service screen.
- The system is supplied with standard brackets for the radius sensors. Some cages might require different brackets.



Figure 2.1-1 – Radius Sensors Installation



Figure 2.1-2 – Radius Sensor

2.2. Compensation Sensor Installation

The compensation sensor (sensor 4) used for compensating barometric effects reads a fixed known distance. It should be installed close to the radius sensors (on top of the cage) with the following points taken into consideration:

- It should be mounted in front of a static 100x100mm rectangular target.
- The path to the target should be clear from any objects.
- The distance to the target should be 200-300mm.
- The exact distance should be measured and entered in the *Reference Target* parameter in the Service screen.
- The system is supplied with a bracket for the compensation sensor.



Figure 2.2-1 – Compensation Sensor Installation



Figure 2.2-2 – Compensation Sensor

2.3. Cage Sensors Installation

The four cage sensors (sensors 5, 6, 7 and 8) should be mounted on the arms of the calibration cage so that they move with the cage as it opens and closes. They can be

mounted on the cage either vertically or horizontally with the following points taken into consideration:

- The sensors should be installed vertically above (vertically below for sensors 7 and 8) the center of the "roller area".
- The sensors must point to the center of the bubble.
- The top gages (sensors 5 and 6) should be 100-200mm above the top arm at a distance of 80mm from the bubble surface.
- The bottom sensors (sensors 7 and 8) should be at about the same height of the bottom rolls at the same (80mm) distance (usually they will be mounted on the second row of rolls).
- Make sure that the sensors do not collide with any part of the cage mechanism when opening the cage to its maximum diameter and when closing the cage to its minimum diameter.
- The sensors are supplied with standard brackets but depending on the arm mechanism some cages might need special brackets.



Figure 2.3-1 – Cage Sensors Installation



Figure 2.3-2 – Standard Bracket for Cage Sensors



Figure 2.3-3 – Cage Sensor

2.4. DBC Installation and Sensor Wiring

The Digital Bubble Controller (DBC) is Sysmetric's special electronic controller for operating the ultrasonic sensors. The DBC is installed in a protective box (*Junction Box*) that should be mounted on the cage. After mounting the junction box on the cage, wire the 8 sensors (3 radius sensors, the compensation sensor and the 4 cage sensors) to the DBC and wire the DBC to the PLC. See electrical drawings for details.



Figure 2.4-1 – Digital Bubble Controller (DBC)

2.5. Control Cabinet Installation

The control cabinet contains the PLC, the operation display and terminals for wiring the ABC system. The wiring includes the:

- Digital Bubble Controller (DBC)
- Balancing valve
- Intake blower speed input signal from the blower's driver 0-10V
- Exhaust blower speed output signal to the blower's driver 0-10V
- Take-off nip speed (line speed) input signal from the nip's driver 0-10V
- Calibrator cage position motor output signals for opening and closing the cage

See electrical drawings for details.

Two types of layout are possible:

- Integrated version when the ABC is part of a full line control the cabinet can be mounted close to the calibrator cage and wired via communication to the line control system (Modbus, Profibus, Devicenet or CLK). Some or all of the control signals can be sent to the ABC system through the communication instead of being wired to the ABC cabinet. In this layout operation is carried out via the operation panel of the line control system.
- Standalone version when the ABC is a standalone system the operation display is on the ABC cabinet and should be mounted in a position where it will be easy and convenient for the operator to reach the display. In this layout all the signals will be wired directly to the cabinet. Note: the operation display can still be mounted remotely (integrated in the main operation panel of the production line). Contact Sysmetric regarding this option.



Note: wire entry is possible via the bottom and/or top cover.

2.6. Electrical Wiring

Electrical wiring of the ABC system includes the following:

- 1. Wiring the sensors to the DBC in the junction box and wiring the DBC to the PLC.
- 2. Wiring the balancing valve to the PLC.
- 3. Wiring power to the PLC.
- 4. Wiring control signals between the PLC and the production line:
 - a. Line speed (take-off nip speed).
 - b. Intake blower speed.
 - c. Exhaust blower speed.
 - d. Opening and closing the calibrator cage.
 - e. Line on (take-off nip on) and extruder on signals.

The following is a short description of the electrical wiring and signals. Refer to the electrical wiring for details.

2.6.1. Sensors and DBC Wiring

Each sensor is wired with a 4 lead cable to the DBC. 8 cables for wiring the sensors are supplied with the system.

The DBC is wired to the PLC with a shielded pair 3x2 cable. The system is supplied with a 15m cable for that purpose.

2.6.2. Balancing Valve Wiring

The balancing value is wired with a shielded pair 3x2 cable. The system is supplied with a 15m cable for that purpose.

2.6.3. Power Wiring

The PLC cabinet should be wired to the power supply. The power supply to the ABC system should be 110-230Volt, 50/60Hz, 6Amp.

2.6.4. Control Signals Wiring

- a. Line speed an analog signal 0-10VDC from the take-off nip motor driver to the PLC. This signal indicates the current speed of the line (the speed of the take-off nip) where 0VDC is when the line is at zero speed and 10VDC is when the line is at maximum speed.
- b. Intake blower speed an analog signal 0-10VDC from the intake blower motor driver to the PLC. This signal indicates the current speed of the intake blower where 0VDC is when the blower is at zero speed and 10VDC is when the blower is at its maximum speed.
- c. Exhaust blower speed an analog signal 0-10VDC from the PLC to the exhaust blower motor driver. This signal controls the speed of the exhaust blower where 0VDC is zero speed and 10VDC is maximum speed.
- d. Opening and closing the calibrator cage the manual opening and closing signals from the buttons (or joystick) on the operator panel should be wired to the PLC and the PLC should be wired to the contactors that open and close the cage. In this

way, during manual operation (when the line is off) the PLC opens and closes the cage according to the commands of the operator and during automatic operation (when the line is working) manual commands are ignored and only the PLC controls the cage.

e. Line On and Extruder On signals – these two on/off signals indicate when the take-off nip is working and when the extruder is working.

2.7. Installation Parameters

Several control parameters should be entered during the installation of the system via the Service screens. These parameters include sensor installation parameters, production line dimensions and more.

2.7.1. Sensors Installation Parameters

Press *SERVICE* on the main screen (enter the password "4321") and press *SENSOR* to switch to the Sensor Service screen.



Figure 2.7-1 – Sensor screens

- 1. Press *Radius Sensors* and enter the installation distance of each sensor. For the radius sensors (*Radius 1, 2* and 3) it is the distance from the face of the sensor to the center of the die. For the compensation sensors (*Ref 4*) it is the distance from the face of the sensor to the reference target.
- 2. Press *Cage Sensors* and enter the installation distance of the cage sensors (*Cage 5*, 6 and *Gap 7*, 8). This is the distance from the face of the sensor's housing to the face of the cage's rolls (the distance to the bubble).

Note: although each sensor can have a different installation distance it is important that each group of sensors will have the same installation distance (the groups are: radius sensors 1, 2, 3 the cage sensors 5, 6 and the gap sensors 7, 8). Use a different installation distance only if there are mechanical limitations in the installation.

2.7.2. IBC Blowers and Balancing Valve Installation Parameters

Initial values should be set for the IBC blowers and the balancing valve. These initial values are for starting the ABC control and they should be adjusted later as explained in the Tuning chapter.

Press *IBC* to switch to the IBC service screen (from the main screen first press *SERVICE* and enter the password "4321").



Figure 2.7-2 – IBC screen

Press Balancing Valve and enter the following parameters:

- Zero Position 50.0%. This will set the balancing valve to its center position.
- *Valve Type* normally open or normally closed according to the valve's type. The type of the valve indicates its position when the control signal is zero. To change the type, press the *Normally Open* button.

Note: Sysmetric's balancing valve is a normally open valve.

Press IBC Blowers and enter the following parameters:

- *Blowers Ratio* 1.000. This will make the exhaust blower speed the same as the intake blower speed.
- In blower -2.000 M³/s. This is the intake blower capacity (the exact capacity will be adjusted later).
- *Ramp Time* the time of accelerating the blowers from zero to full speed and decelerating from full to zero. The ramp time is a parameter of the blowers' motors drivers. The ramp time must be equal for accelerating and decelerating and it must be

equal in the intake blower and the exhaust blower. For best performance of the ABC system the ramp time should be as low as possible, recommended values are 5-10 seconds. Note: the blowers need braking resistors to enable short ramp time.

• *Max speed* – is the resolution of the blowers' speed (usually the resolution of the analog input and output of the PLC). In the standalone version of the ABC system the resolution is 2047.

2.7.3. General Parameters

Press *General* to switch to the General Service screen (from the main screen first press *SERVICE* and enter the password "4321") and enter the following parameters:

- *Tower Height* the distance from the radius sensors (the top of the calibrator cage) to the take-off nip.
- *Collapsing Frame* the height of the collapsing frames.
- *Feedback* the distance from the radius sensors (the top of the calibrator cage) to the calibration point (whereby the width is measured for calibrating the shrinkage parameter).
- *Maximum Line Speed* the maximum speed of the take-off nip.

Tower Hei	8.	50M			Contro	bl		
Coll. Fram	2.	50M		Manua	Auto	Conti		
Feedback	25.	00M						
Width Err	1	.Ømm			Width	Gap		
Line Speed					Set	Ømm	Ømm	
Maximum	Maximum 50.0m/min				Act	Ømm	Ømm	
Actual	0M/	min		Cal		Ømm		
MAIN SENSOR IE					GEN	ERAL	ALARMS	

Figure 2.7-3 – General screen

After completing the installation of the ABC system, follow these steps to verify correct installation and operation of the system:

3.1. Line On and Line Speed Signals

- 1. In the main screen press SERVICE and then press GENERAL.
- 2. Turn on the take-off nip.
- 3. Increase the take-off speed and verify that the *Actual Line Speed* in the display is correct (matches the real speed of the nip). If not, check the electrical wiring (the line on signal and the line speed signal) and the value of *Maximum Line Speed*.
- 4. Turn off the take-off nip.

Note: it is recommended to measure at this time the real line speed with a tachometer directly on the take-off nip. Errors in the line speed will reduce the performance of the system and will be hard to detect afterwards.

Tower Hei	8	. 50M		Control				
Coll. Fran	2	.50M		Manua		Auto	Conti	
Feedback	25.	. 00M		I I		П		
Width Err		10mm			V	Vidth	Gap	
Line Speed					Set		Ømm	Ømm
Maximum	Maximum 50.0m/min				Act		Ømm	Ømm
Actual	Actual 35.0M/min				Cal			Ømm
MAIN	SENS	DR	IBO	C	GEN	ER	AL	ALARMS

Figure 3.1-1 – Checking the Line Speed

3.2. Extruder On Signal

- 1. Press Main in the control display to switch to the main screen.
- 2. Turn on the take-off nip and the extruder.
- 3. Set the take-off speed above 5 Meter/min.
- 4. Make sure that stage I flag starts blinking. If not, check the electrical wiring and that the line speed is above 5Meter/min.
- 5. Turn off the take-off nip and the extruder and make sure that the stage I flag turns off.



Figure 3.2-1 – Checking Extruder On

3.3. Intake and Exhaust Blowers

- 1. Make sure that the take-off nip is off.
- 2. In the main screen press *SERVICE* (enter the password "4321") and then press *IBC*.
- 3. Make sure that *Blowers Ratio* is 1.000, *In Blower* is 2.000M³/s and that *Ramp Time* and *Max Speed* are set correctly as explained in the installation chapter.
- 4. Turn on the intake blower and look at the *Intake Speed* value in the *IBC* service screen. Change the intake blower speed from zero to full speed and verify that the *Intake Speed* value changes from 0 to 100% accordingly. If not, check the electrical wiring.
- 5. While changing the speed of the intake blower check the speed of the exhaust blower at *Exhaust Speed*. The speed of the exhaust blower should follow 1:1 the speed of the intake blower. Verify that the exhaust blower is actually running at the correct speed corresponding to the value at *Exhaust Speed*. If not, check the electrical wiring.
- 6. Make a rapid change in the intake blower's speed from zero to full and verify that both blowers (the intake and the exhaust) ramp up to the full speed by the time defined in *Ramp Time*. Make a rapid change in the intake blower's speed from full to zero and verify that both blowers (the intake and the exhaust) ramp down to the zero speed by the time defined in *Ramp Time*. If the blowers do not ramp up or down by the *Ramp Time* check the ramp time parameters in the blowers' motors drivers or adjust the *Ramp Time* value.

Note: the Model control technique of the ABC system makes fast maneuvers in the exhaust blower speed so the ramp time must be as low as possible (5-10 seconds). Both

blowers, the intake and the exhaust, must have braking resistors to enable a short ramp time. Ramp time longer than 10 seconds will reduce the system's performance and will extend the time for reaching a correct lay-flat width.

Balancing	Valve	IBC Blow		
Control Value	0.0%	Blowers Ratio	1.000	
Open <mark>50</mark> . Ø	6 Close	Control Range	0.000	
Cage Co	ntrol	Control Ratio	1.000	
Cage Factor	Øz	Actual Ratio	1.000	
Set Radius	Ømm	Intake Speed	50.0%	
Actual Radius	Ømm	Exhaust Speed	50.0%	

Blowers Ratio	1.000	In Blower 2.	000M³/s					
Control Range	0.000	Ramp Time	5.Øs					
Control Ratio	1.000	Max Speed	2047z					
Actual Ratio	1.000							

Figure 3.3-1 – Checking the IBC Blowers

3.4. Balancing Valve

- 1. Make sure the intake blower is off.
- 2. In the main screen press *SERVICE* (enter the password "4321") select the *IBC* screen and press the *Balancing Valve* button.
- 3. Change the value of *Zero Position* and check that the balancing valve changes its position as follows:
 - At 0% the valve should be completely open (air will flow freely in the pipe).
 - At 100% the valve should be closed (the valve is blocking the air flow).

If the valve does not move check the electrical wiring. If the valve moves to the opposite position change the *Valve Type*.

4. Set the Zero Position back to 50.0%.

			Bala	Balancing Valve Blowers			iers	
	•	∀		Control	Value	0.0%	Blowers Ratio	1.000
Zero Position	50 Ø%	Control Value	0 0%	Open	50.0%	Close	Control Range	0.000
Zero Range	0.0%	Max Travel	0.0%	Ca	ge Contro	ol	Control Ratio	1.000
Zero Integral	0.0л Ит	Open 50 0	% Close	Cage Fa	actor	Øz	Actual Ratio	1.000
Actual Zero	50 0%	Valve Type	N Open	Set Rad	ius	Ømm	Intake Speed	0.0%
r iordar zoro	00.0/			Actual F	Radius	Ømm	Exhaust Speed	0.0%
Set Act								
	Bap	Ømm Ømm		MAIN	SENSOR	IBC	GENERAL	ALARMS

Figure 3.4-1 – Checking the Balancing Valve

3.5. Calibrator Cage Control

- 1. Make sure that the take-off nip is off.
- 2. In the main screen press *SERVICE* (enter the password "4321") select the *IBC* screen and press the *Cage Control* button.
- 3. Press and hold the *Open Cage* for more than 2 seconds and check that the cage opens. Press and hold the *Close Cage* for more than 2 seconds and check that the cage closes. If the cage does not change position or moves in the wrong direction check the electrical wiring.



Figure 3.5-1 – Checking the Calibrator Cage Control

3.6. Sensors

- 1. In the main screen press *SERVICE* (enter the password "4321") and select the *SENSORS* screen.
- 2. If possible, assemble the IBC pipe on the die and lower the calibrator cage so that the radius sensors will "see" the IBC pipe. If not, place some other cylinder object, with a known radius, in the center of the calibrator cage so that it will simulate the bubble.
- 3. Check the readings of the radius sensors 1, 2 and 3. The three sensors should have similar readings (allow +/-2mm difference) and the average radius that they read should be equal to the radius of the IBC pipe. If the readings are not equal check that all the three sensors are installed at the same distance from the center of the calibrator cage. If the sensors read a wrong radius check the *Install Distance* parameters of the sensors. If they don't show any reading check the electrical wiring.
- 4. Check that the compensation sensor reads a correct distance. *Reference* 4 should show the real distance to the reference target (allow 5% error). If not, check the installation distance parameter. Verify that *Barometric Factor* is 0.9500-1.0500. Note: only check the barometric factor if the compensation sensor is installed and works for more than an hour. If not, wait and check it later.
- 5. Close the calibrator cage so that the cage sensors 5, 6, 7 and 8 will be less than 200mm from the IBC pipe.

6. Check the readings of the cage sensors. The four sensors should have similar readings (allow +/-2mm difference). Their reading should be the distance between the cage's rolls and the IBC pipe. If the readings are wrong, or not equal, check installation distance parameters. If there are no readings, check the electrical wiring.

Radius S	ensors	Cage Sensors				
Radius 1	318.0mm	Cage	5	0.1mm		
Radius 2	318.0mm	Cage	6	-0.2mm		
Radius 3	318.0mm	(Gap Sensors			
Reference 4	251.2mm	Gap 7		0.2mm		
Barometri	c Factor	Gap 8		0.5mm		
1.004	8					
MAIN	INSOR	IBC	GENERAL	MODEL		

Figure 3.6-1 – Checking the Sensors

4. Tuning

After installing and checking the ABC system it is now ready for first time operation. During the first operation some of the system's parameters need to be tuned in order for the system to control correctly. Tuning the parameters requires the following steps:

- 1. Finding the *Cage Factor* for the calibrator cage.
- 2. Calibrating the *Exhaust Ratio* and the *Intake Blower Capacity* parameters.
- 3. Tuning the balancing valve control parameters.
- 4. Adjusting the *Cage Factor* parameter.

The following explanations describe how to tune the system. In some cases the explanations give some common initial values for some of the parameter. Note that different lines might need different values. It also assumes that all the installation parameters are set as explained in the installation chapter.

4.1. Cage Factor – Coarse Tuning

When controlling the calibrator cage position the actual cage position feedback has a long delay. For this reason the system uses a pulse technique to operate the cage motor according to a fixed ratio between the cage position error and the motor operation time. This ratio is called *Cage Factor* and it can be found using the Cage Factor screen.

In the *IBC* screen press the *Cage Factor* button and follow this procedure to find the cage factor:

- 1. Place a target in front of the gap sensors 7 and 8. The best method is to assemble the IBC pipe on the die.
- 2. Press and hold *Close Cage* to close the calibrator cage until both sensors 7 and 8 show readings.
- 3. Press and hold *Close Cage* for about 7 second and release. The system will show a value at *Calculated Factor*.
- 4. Press and hold *Open Cage* for about 7 seconds. The system will update the *Calculated Factor*.
- 5. Repeat opening and closing the cage several times and check the *Calculated Value*. It is recommended to test the factor at longer and shorter movements of the cage and at different positions of the cage.

Balancing Valve Blowers Control Value 0.0% 1.000 Blowers Ratio 50.0% Close 0.000 Dpen Control Range 1.000 Cage Control ontrol Ratio Øz Actual Ratio 1.000 Cage Factor **Ømm** 0.0% Set Radius ntake Speed 720z Cade Factor 0.0% Actual Radius Ømm Exhaust Speed 721z Calculated Factor 230.1mm Gap 7 SENSOR GENERAL 231.5mm MAIN IBC ALARMS Gap 8 TO CR TC FL WM. Open Close Cage Cage

The Calculated Factor will later be used as the Cage Factor.

Figure 4.1-1 – Cage Factor Tuning

- 6. Open the calibrator cage to its maximum position.
- 7. Select MANUAL mode in the General Service screen.
- 8. In the Balancing Valve screen set Maximum Travel to 0%.
- 9. In the *IBC Blowers* screen set *Control Range* to 0 and set *Intake Blower* capacity to 2.000M³/s.
- 10. Start the line with a safe bubble width (a medium size width). For stability, use only about 20% intake blower speed and the line speed should be about 10-15 M/Min. Wait until the width stabilizes. This might take several minutes and the actual width will not necessarily be equal to the set width. If the bubble does not stabilize increase the *Intake Blower* capacity parameter.
- 11. While monitoring the bubble, increase the intake blower speed to some average normal operating speed (about 40-50%). The width will change and stabilize after some minutes.
- 12. When the width is stable, copy the *Actual Ratio* parameter into the *Blowers Ratio* parameter. This should bring the actual width close to the set width. If needed wait several minutes and repeat this step. The expected width accuracy at this phase is ± 20 mm or better.
- 13. While the line is running enter a new *Set Width* and monitor the width change. The system should react to the new width within 5 seconds and the change should be fast. The bubble should be as close as ± 40 mm before the initial width gets to the nip.
- 14. If the change is too big (the width overshoots) then the *Intake Blower* capacity should be increased and vice versa. Repeat this step 3 to 4 times until fast stability is achieved. The test can be performed in both directions. Make sure that during the change the exhaust blower will not run below 20% or above 80%. If it does then longer stability time is normal and expected.

Note: if at this stage the width varies a lot and it takes a very long time for the width to stabilize, check the *Tower Height* and *Collapsing Frame Height* parameters in the *General* screen.

Balancing	Valve	IBC Blow	/ers	l			
Control Value	0.0%	Blowers Ratio	1.000		*		
Open <mark>50</mark> .09	% Close	Control Range	0.000	Blowers Ratio	1 000	In Blower 2	ΛΛΛΜ³/s]
Cage Co	ntrol	Control Ratio	1.000	Control Range	0.000	Ramp Time	5 Øs
Cage Factor	Øz	Actual Ratio	1.050	Control Ratio	1 000	Max Speed	20477
Set Radius	Ømm	Intake Speed	50.0%	Actual Ratio	1.000		20112
Actual Radius	Ømm	Exhaust Speed	52.5%	r lot dur Hutto	1.000		
MAIN SENS	OR IBC	GENERAL	ALARMS				

Figure 4.2-1 –Blower Ratio and Intake Blower Capacity Tuning

4.3. Balancing Valve Control Value

During the first control stages (I and II) the balancing valve control is minor. During the last control stage of the system (III) the balancing valve control action goes into full operation. The error between the set and actual gap is multiplied with the *Control Value* and the result is delivered to the valve. Its activity can be seen on the display on *Open/Close Valve* value.

- 15. After calibrating the *Blowers Ratio* and the *Intake Blower* capacity, close the calibrator cage up to the point where the rolls just start touching the bubble, that is, a zero gap between the cage and the bubble.
- 16. Verify that the *Actual Gap* in the screen is zero. If not, check the installation (and the installation distance parameter) of the gap sensors 7 and 8.
- 17. In the IBC screen, verify that the *Actual Radius* is equal to the *Set Radius* (allow up to 5mm error at this stage). If not, check the installation (and the installation distance parameter) of the cage sensors 5 and 6.
- 18. In the *Balancing Valve* screen set the *Control Value* to 2.0% and the *Maximum Travel* to 20.0%.
- 19. Enter 0 in the Set Gap.
- 20. In the *General Service* screen change the control mode to *Automatic*. The system should move to the third control stage (I and II flags are lit green and III is blinking).
- 21. In the *Balancing Valve* screen slowly increase the *Control Value*. A high value will increase the valve activity reducing the width small changes. This is true until the control over reacts and the width starts to shift and jump. The maximum value found should be reduced by about 40% and stored into *Control Value*. If for example a value of 14.0% produced maximum stability and beyond that the system is not stable, then a value of 10.0% should be used.
- 22. Change the *Set Gap* to +5mm and check that the *Actual Gap* reaches +5mm in a few seconds. Change the *Set Gap* back to zero and then to -5mm and check that the *Actual Gap* reaches -5mm in a few seconds. If the reaction is too slow increase the *Control Value* of the *Balancing Valve* (remember that a too high value will reduce the width stability). If the *Actual Gap* responds quickly to one direction but slowly to the other direction change the *Zero Position* accordingly. For example if the *Actual Gap* reacts quickly to a positive change in *Set Gap* (changing the *Set Gap* to -5mm) increase the *Zero Position* and vice versa. In any case don't use *Zero Position* larger than 70% or lower than 30%.

Note: changing the *Zero Position* of the balancing valve affects the *Blowers Ratio* parameter. If you want to change the *Zero Position* first set the system back to *Manual* control mode. Then change the *Zero Position*, wait for the bubble to stable and copy the new ratio from *Actual Ratio* to *Blowers Ratio* in the *IBC Blowers* screen.

23. Set Zero Range to 10% and Zero Integral to 10z.

				- [Balar	ncing \	/alve	IBC Blow	rers
	•			С	ontrol V	/alue	5.0%	Blowers Ratio	1.050
Zero Position	50 Ø%	Control Value	5.0%	0	pen	<mark>. 50</mark> . 0%	Close	Control Range	0.000
Zero Range	10 0%	Max Travel	20.0%		Cag	je Cor	itrol	Control Ratio	1.050
Zero Integral	10.0%	Open 50 0	% Close	С	age Fa	otor	Øz	Actual Ratio	1.050
Actual Zero	50.0%	Valve Type	N Onen	S	et Radi	us	Ømm	Intake Speed	50.0%
r lotdur 2010	00.0/		ni open	A	ctual R	adius	Ømm	Exhaust Speed	52.5%
	S	et Act							
	∋ap _	omm -5mm			MAIN	SENSO	R IBC	GENERAL	ALARMS

Figure 4.3-1 – Control Value and Zero Position Tuning

4.4. Cage Factor – Fine Tuning

During normal operation the bubble is pressed to the calibrator cage and this affects the motion of the cage. Thus, examination and fine tuning of the *Cage Factor* is required.

- 24. In the Cage Control screen set the value of Calculated Factor into the Cage Factor.
- 25. Enter a new *Set Width* and monitor the cage correction steps. When the *Cage Factor* is proper the first correction cycle will bring the cage to \pm 4mm from target. If the value is too low the control will need more correction cycles to reach the *Set Radius*. If the value is too high the system will overshoot and will make a correction step in the opposite direction. If necessary, adjust the *Cage Factor* value and repeat this action until good cage control is achieved.

Easy monitoring of the cage's correction steps can be carried out using the width graph. This graph shows, along with the width error, the cage's movements. Press the *Graph* button in the *Main* screen or the *Width* button in the *General* Service screen to reach this graph.

4.5. Finishing the Tuning Procedure

- 26. In the IBC screen set *Control Range* 0.200. This will start the automatic blower control process.
- 27. In the *General* screen turn on the *Continue* control mode to enable continuous control on the calibrator cage.
- 28. Bring the production line to normal operation and test the system in various widths to verify proper operation. The mentioned parameters may require minor adjustments in order to reach the best performance.

5. System Operation

The ABC system was designed for ease of operation and requires minimum operator supervision and intervention. During normal operation only the main screen is used. All other screens are for service and maintenance only.

5.1. Starting Production

When starting production carry out the following:

- 1. Enter the required lay-flat width
- 2. Enter the required gap.
- 3. Start the production.
- 4. After the width has stabilized measure the produced lay-flay. If it is not equal to the actual width showed on the ABC screen perform a width calibration.



Figure 5.1-1 – Main screen

Note: the gap can be changed during production with a small temporary effect on the layflat width. A larger gap will keep the rolls away from the bubble. This is useful to prevent the rolls from scratching the bubble in delicate products. A smaller or negative gap will cause the cage to hold the bubble tightly and will improve the width's accuracy and stability. 5.2.

The ABC system has 3 control modes:

- 1. *Manual* calibrator cage control is disabled. The system brings the bubble to the required width only by controlling the speed of the exhaust blower.
- 2. *Auto and Continue* the system brings the bubble to the required width by controlling the speed of the exhaust blower and by positioning the calibrator cage in the correct diameter.
- 3. *Auto* (*Continue* is off) same as *Auto and Continue* mode but 10 minutes after reaching the required width the cage control is disabled.

The normal operation of the ABC system is *Auto and Continue* control mode. *Manual* mode can be used if there is a problem with the calibrator cage and the cage cannot be moved. In some cases, mechanical backlash in the calibrator cage or instability in the production process can cause the system to continuously move the cage in and out as it tries to find the correct position that yields the correct width. In such cases the *Auto* mode (*Continue* is off) can be used and it might improve the system performance. In this mode, after the cage has been locked, the ability of the system to keep the required width is limited so set a value in the Width *Error Threshold* parameter to trigger an alarm in case there is a large width error.

Tower He	Tower Height 8.50M			Control					
Coll. Fran	Coll. Frame			N	Manual Aut		Auto	Conti	
Feedback	(25.	00M		1		11	111	
Width Err	Width Error TH		10mm	-	Wid		Vidth	Gap	
Lin	Line Speed				Set	1000mm		-5mm	
Maximum	50.	Øm/	′min	-	Act	10	300mm	-5mm	
Actual	35.	ØM/	′min		Cal			Ømm	
	148- 			33		ł			
MAIN	SENS	OR	IBC	;	GEN	IER	AL	ALARMS	

Figure 5.2-1 –Control Mode Selection

ABC

Depending on the control mode, the ABC system has up to 4 control stages. The three control stage flags I, II, III indicate the current control of the system. The following table details the different control stages of each control mode and describes the system function at each stage:

Mode	Stage	Flag I	Flag II	Flag III	Function
Manual	0	Off	Off	Off	Control is off
Manuai	1	Blink	Off	Off	Bringing bubble to the correct width ±50mm
	0	Off	Off	Off	Control is off
	1 Plink Off Off		Off	Bringing bubble to the correct width ±50mm	
Auto	1	DIIIK	OII	OII	Bringing cage to its set radius ±5mm
and	2	On	Blink	Off	Adjusting cage position for correct width
Continue	ontinue ² On		DIIIK	OII	Bringing gap to its set value ±5mm
	3	3 On	On	Blink	Adjusting cage position for correct width
	5		Oli	DIIIK	Keeping gap in its set value
	0	Off	Off	Off	The control is off
	1	Blink	Off	Off	Bringing bubble to the correct width ±50mm
Auto	1	DIIIK	OII	OII	Bringing cage to its set radius ±5mm
	2	On	Blink	Off	Adjusting cage position for correct width
(Continue	2	Oli	DIIIK	OII	Bringing gap to its set value ±5mm
is off)	is off) 2 On On		Blink	Adjusting cage position for correct width	
	5				Keeping gap in its set value
	4	On	On	On	Keeping gap in its set value (cage is locked)

5.3. Changing Product (Changing Width)

Changing the set width does not require any significant change in the production. While the line is still running carry out the following:

- 1. Enter the new width.
- 2. If necessary, change the gap.
- 3. After the width has stabilized measure the produced lay-flat. If it is not equal to the actual width showed on the ABC screen perform a width calibration.

Note: changing the width while the line is running might require lowering the line speed and/or the intake blower speed until the system stabilizes the new width. This depends on the initial speeds and other production parameters and varies from one production line to another. In most cases the width can be changed without changing any other parameters.

5.4. Width Calibration

As the bubble moves away from the die and towards the reception unit the plastic cools down and causes the width to shrink. The ABC system features a simply calibration procedure to compensate for this shrinkage effect and to ensure correct width production.

After the width stabilizes carry out the following to calibrate the width:

- 1. Measure the lay-flat width at the feedback point.
- 2. Enter the measured width in the *Width Calibration* in the display. A *Value Accepted* flag will indicate that the calibration succeeded and the calibration value will reset back to zero.



Figure 5.4-1 – Width Calibration

Note: some production parameters, such as line speed and production capacity, affect the shrinkage factor. After changing any production parameter verify the product width and calibrate if necessary. Once the production is stable the shrinkage is stable and the system will maintain the correct width.

5.5. Automatic Width Calibration

When a web guiding system is installed its reading can be directed to the ABC system for automatic calibration. This allows the system to automatically update the shrinkage parameter of the product and maintain accurate lay-flat width.

If the automatic calibration is installed it can be operated by switching its control switch in the calibration control screen. Press the *Cal* button in the *General Service* screen to reach the automatic calibration control switch.



Figure 5.5-1 – Automatic Width Calibration Control

When the automatic width calibration is enabled and the system reaches a stable width it will start the automatic calibrations. An *Automatic* flag will indicate that the automatic mode is on, the manual calibration will lock and a small flag (EL in the example below) will indicate that the actual width is now received from the web guiding system.

	Width			Gap			
Set	1000mm				-5mm		
Act	10	1000mm®			-5mm		
Widtł	n Calibra	ation	Line	Speed	35.Øm/min		
AU	TOMATI	с	Inta	ke	65.Ø%		
- I	Ш	Ш	Exh	aust	68.2%		
MAIN	GRAPH	I SERV	ICE		ALARMS		

Figure 5.5-2 – Automatic Width Calibration

Note: the automatic width calibration option is not included in the standard ABC system. Contact Sysmetric regarding the addition of this option to the system.

6. Service and Maintenance

6.1. Alarms

An alarm condition exists whenever the system recognizes that a fault has occurred. When an alarm condition occurs the system does the following:

- A corresponding alarm message appears on the display.
- The alarm is written in the alarm log.
- The alarm button on the operator display turns red.
- The system tries to maintain the correct width.
- The alarm output in the PLC turns on. This output can be wired to an external alarm device (light, siren or any central alarm system in the factory).
- Pressing the *ALARM* button deletes the alarm message. Further pressing the *ALARM* button toggles messages of all active alarms.

		W	/idth		Gap	
	Set	100	30mm		Ømm	
Alarm	Act	100	30mm		Ømm	
Message	Width Calibration			Line Speed 35. Øm/r		
		Ømm	In	take	65.Ø%	
	I	н		khaust	68.2%	
	F	RADIUS	SENSO	R 1 ER	ROR	
	MAIN	GRAPH	SERVICE		ALARMS	

Figure 6.1-1 – Alarm Message

6.1.1. Alarm Log

The system creates an alarm log. Press and hold the *ALARM* button for more than 1 second to switch to the alarm log screen.



Figure 6.1-2 – Alarm Log

The alarm log shows the following details:

- The alarm that was activated.
- The time at which the alarm was activated.
- The status of the alarm red if the alarm is still active or blue if the alarm was cancelled.

The log can be cleared by marking some or all the alarms and pressing the delete button.

6.1.2. Alarms Messages

The following is a list of alarm messages that can appear on the display according to the active alarm, the possible causes for the alarm and the actions to take. When trying to solve an error follow and execute the recommended actions in the order they appear in this manual i.e. only try the second action if the first did not solve the problem.

SENSOR # ERROR (For all sensors 1-8)

This alarm indicates an error in the specified sensor. See the Ultrasonic Sensors maintenance section for more details.

Action:

Switch to the sensors screen, check which error flag is on and act accordingly:

- For NS error, check the electrical wiring. If they are intact replace the sensor. If the electrical wiring is intact and the error remains after replacing the sensor, replace the DBC card.
- For NT, BR and CE errors, clean the sensor and check that it is perpendicular and facing directly to the center of the bubble. If this does not solve the error, replace the sensor.

Note: use a dry rag for cleaning the sensors. Do not use any chemical substance, it can damage the sensors.

BUBBLE WIDTH ALARM

When the continuous control mode is off, the system stops moving the calibrator cage 10 minutes after entering control stage III. If during production in this mode the width error is greater than defined in the *Width Error Threshold* the system triggers the bubble width alarm.

Action:

- Try to identify the source of the width error. Usually it happens if one of the production conditions changes such as temperatures, line speed, production capacity etc.
- Check the value of the Width Error Threshold and increase it if necessary.
- If the production is not stable enough either increase the value of *Width Error Threshold* or turn on the continuous control mode so that the system can keep adjusting the calibrator cage position and maintain the required width.

BUBBLE BREAK

If during production the radius sensors stop detecting the bubble the system triggers the bubble break alarm.

Action:

• Restore the bubble.

EXHAUST BLOWER TOO FAST

This alarm indicates that the exhaust blower is running at more than 95% of its maximum speed.

Action:

- Decrease the intake blower speed and the system will decrease the exhaust blower speed accordingly.
- Verify that the balancing valve is not blocked.
- Clean the exhaust blower and all the exhaust pipes from production remains such as plastic pieces and wax.

PLC BATTERY LOW

The PLC has a backup battery to maintain data while the power supply is off. This alarm indicates that the power in the backup battery is running low. **Action:**

• Replace the backup battery in the PLC. Note: use only Omron's original battery (3G2A9-BAT08).

EXCEPTIONAL BLOWERS RATIO

The system determines the required exhaust blower speed according to the *Blowers Ratio* parameter but since this ratio depends on various production parameters and varies with time, the system automatically adjusts this parameter in order to find the correct value. In order to do this the system first copies the *Blowers Ratio* into the *Control Ratio* parameter when the operation starts and then during the production it adjusts the *Control Ratio* within a range defined by the *Control Range* parameter. For example if the preset *Blowers Ratio* is 1.000 and the *Control Range* is 0.200 then the system can adjust the *Control Ratio* parameter reached the limit defined by the *Control Range* parameter. With respect to the last example it means that the value of *Control Ratio* reached either 0.800 or 1.200.

By principal the ratio between the intake and the exhaust blower cannot change. It is determined by their physical structure. Actually the ratio depends on some production parameters such as temperature and the blowers' speeds and it varies during production especially when the exhaust pipes start containing production remains such as wax and plastic pieces. Assuming that the *Blowers Ratio* parameter was set correctly during the installation and tuning of the system, if the *Control Ratio* has reached the limit of the *Control Range* it must be a consequence of some mechanical change in the production

line. For example if a plastic piece accidently enters the exhaust pipe and is now blocking some of the air flow the exhaust blower will need to run faster in order to drive the same amount of air. In such a case the system automatically increases the *Control Ratio* to compensate for that air blockage.

Action:

- Search for the origin of the problem and try to identify the cause of the change in the blower ratio. Common problems are:
 - Air leaks in the exhaust pipes.
 - Something clogs the exhaust pipes such as wax, plastic pieces, a bent pipe etc.
 - Something clogs the balancing valve.
 - Significant change in the temperature of the air in the IBC.
 - Significant change in the raw material or the production capacity.
- If the exhaust blower runs at a relatively high speed (above 80%) try to decrease its speed (decrease the intake blower speed and the system will decrease the exhaust's speed accordingly). In some blowers the capacity is not linear and it drops down at high speeds. This can cause a high *Control Ratio* when the blowers run at high speeds.
- To fix the error during production, take the half way value between the *Blowers Ratio* and the *Control Ratio* and set it as the new value of the *Blowers Ratio*. For example if the *Blowers Ratio* is 1.000 and the *Control Ratio* is 1.200 change the *Blowers Ratio* to 1.100. Remember the original value of *Blowers Ratio* and once production is stopped re-enter the original value and search for the origin of the problem as explained in the previous note.

BUBBLE WAVES

This alarm indicates that the surface of the bubble below the cage (in front of the gap sensors 7 and 8) is waving. This can reduce the width stability. When such an error occurs the system automatically reduces the balancing valve reaction level until the bubble re-stabilizes.

Action:

- Check the calibrator cage height. The gap sensors 7 and 8 should be at about the height of the frost line. If the calibrator cage is too high it will cause the bubble to wave.
- Decrease the *Control Value* of the balancing valve.
- Check the balancing valve. Make sure nothing disturb its movements.

DBC CONTROLLER ERROR

This alarm indicates an error in the Digital Bubble Controller (DBC). Action:

- If the alarm is persistent replace the DBC card.
- If the alarm was temporary read the DBC error code in the cage sensors screen and press *Clear*. If the error returns replace the DBC card.

DBC COMMUNICATION ERROR

This alarm indicates that the PLC fails to communicate with the Digital Bubble Controller (DBC).

Action:

- In the DBC check that the green LED marked 24V is on. If it is off check the 24VDC power supply from the main cabinet to the DBC.
- Check the electrical wiring between the PLC and the DBC.
- In the DBC check that that green LED marked COM1 is on. If not replace the DBC card.
- Check the 5VDC supply from the PLC to the DBC (see electrical wiring). If there is no 5VDC supply, replace the PLC.

BALANCING VALVE ERROR

When the actual position of the balancing valve is equal to its set position the valve controller sends an OK signal to the PLC. If this signal is missing for more than 1 second the system triggers the balancing valve error alarms.

Action:

- Clean the balancing valve pipe, butterfly and shaft and make sure nothing disturbs the valve from turning freely in the pipe.
- Press and hold the TEST button on the balancing valve for 5 seconds. The valve should run a test cycle in which it first goes to its center point (45°), opens all the way, closes all the way and then goes back to the position defined in the *Zero Position* parameter in the balancing valve screen.
- Check the electrical wiring between the PLC and the balancing valve.
- Open the cover of the valve's controller. Check that the power green LED on the bottom electronic card is on. If not check the 24VDC power supply from the main cabinet.
- Check that the 5V power green LED on the top electronic card is on. If not replace the electronic card.
- Check that the yellow LED marked ON is lit. Change the *Zero Position* parameter in the balancing valve screen. The yellow LED should turn off while the valve moves to the new position and then turn on again. Test the valve at different positions by setting different values between 0% and 100% in the *Zero Position* parameter. If there is a position in which the yellow LED does not turn on replace the actuator motor of the valve.

AUTOMATIC CALIBRATION ERROR*

This alarm indicates an error in the automatic width calibration. Action:

- Check that the automatic width source is working properly (the web centering unit).
- Check the electrical wiring and communication units between the PLC and the automatic width source (the web centering unit).

* This alarm is relevant only if the automatic width calibration option is installed and activated.

6.2. Ultrasonic Sensors

The ultrasonic censors are operated and controlled by the Digital Bubble Controller unit (DBC). As part of the control process, the DBC monitors each read cycle of the digital ultrasonic sensors. Thus, in addition to measuring the distance to the target, it indicates each sensor's status and gives specific alarms for different error conditions in the sensors. For each error condition in the sensor the system will raise a corresponding error flag in the *Radius Sensors* and *Cage Sensors* screens. In addition the system monitors the percentage of faulty read cycles and alarms for a sensor error if the error percentage goes above 50% (20% for the radius sensor during control stage I). This means that more than 50% of the sensor's read cycles are faulty. The alarm goes off if the error percentage goes below 30%.

The error conditions and its corresponding error flags are:

- NS No Sensor. The DBC does not detect any sensor wired to it.
- NT No Target. The sensor does not "see" any target (no echo is returned)
- BR Bad Reading. The sensor receives bad echo signal.
- CE Cov Error. The DBC receives bad signal from the sensor.

The error flags might flash on and off during normal operation but as long as the errors are minor and the error percentage remains zero, no action is needed. If the error percentage is not zero it is recommended to check the sensors even if the error percentage is below 50% and the system did not alarm yet. Although the system is expected to work well under such conditions, fixing the error will ensure the width's accuracy.

In order to ensure best performance of the system it is recommended to monitor the *Radius Sensors* and *Cage Sensors* screens as part of scheduled routine maintenance. If an error percentage is above zero or if the system alarms for a sensor error act as follows:

• For NS error, check the electrical wiring. If they are intact replace the sensor. If the electrical wiring is intact and the error remains after replacing the sensor, replace the DBC card.

• For NT, BR and CE errors, clean the sensor and check that it is perpendicular and facing directly to the center of the bubble. If this does not solve the error, replace the sensor. Note that the gap sensors 7 and 8 might need to be tilted slightly so that they will be perpendicular to the bubble's surface.

Note: use a dry rag for cleaning the sensors. Do not use any chemical substance, it can damage the sensors.

The following example shows an NT alarm in sensor number 1 and a minor BR error in sensor number 7.

Radius 3	Sensors		Cage Ser	sors
Radius 1	124.5m	nm Cage	e 5	0.1mm
Radius 2	318.0m	m Cage	6	-0.2mn
Radius 3	318.0m	ım	Gap Sens	sors
Reference 4	251.2m	im Gap	7	-0.3mm
Barometri	c Factor	Gap	8	-0.7mm
1.004	48			
RA	DIUS SE	NSOR 1	ERROR	
MAIN	ENSOR	IBC	GENERAL	MODEL

Radius Sensors		Install		Errors			
Radius 1	124.5	800.0	NS	NT	BR	CE	68%
Radius 2	318.0	800.0	NS	NT	BR	CE	0%
Radius 3	318.2	800.0	NS	NT	BR	CE	0%
Reference	Install	Errors					
Ref 4	251.2	250.0	NS	NT	BR	CE	0%

Cage Se	ensors	Install			Erro	ors	
Cage 5	0.1	80.0	NS	NT	BR	СE	0%
Cage 6	-1.2	80.0	NS	NT	BR	CE	0%
Gap 7	-0.3	80.0	NS	NT	BR	CE	2%
Gap 8	-0.7	80.0	NS	NT	BR	CE	0%
DBC Erro	or Code	0 0	ear				Help

Figure 6.2-1 – Sensor Errors

6.3. Calibrator Cage

The system sometimes bypasses the normal cage control and forces the cage to close or open or it disables the cage's movements. This is done when the system detects hazardous situations whereby the cage might collide with the bubble or when the cage's position disturbs the normal cage control. These situations are more common during control stage I when the system tries to stabilize a new width. When the system bypasses the normal cage control it lights a corresponding indication flag in the *Cage Control* screen.

If the cage seems to "freeze" in its place or it opens/closes unexpectedly, switch to the *Cage Control* screen to check if it is a control bypass. The bypass indication flags are:

- *TO* Too Open. The cage is too open and the cage sensors do not "see" the bubble. The system will force the cage to close until getting readings from the cage sensors.
- CR Collision Recover. When the system detects that the cage collides with the bubble it forces the cage to open. After such event it does not allow the cage to close until a full bubble height has run through the cage.
- *TC* Too Close. The system detects that the cage is too close and it disables further closing until the bubble draws away.
- *FL* Frost Line. When the frost line is too high (relatively to the cage position) it can create a situation in which at the top side of the cage the bubble radius is large and the bubble is close to the cage while on the bottom side of the cage the bubble radius is small and the bubble is far away from the cage. In such case the system does not allow the cage to close until the frost line is taken back down and the bubble's radius is similar along the cage.
- *WM* Wait for Model. When decreasing the required width the system does not allow the cage to close to its new radius before the model control has decreased the bubble's width (using the blowers) and it is less than 100mm from the required new width.



Figure 6.3-1 – Cage Control Bypass Flags (Example of CR shown)

6.4. Troubleshooting

The following table lists some error conditions in which the system does not work well without alarming for any errors.

Problem	Symptoms	Possible Cause	Action
		Take-off nip signal is off	Check the electrical wiring
System does not respond	Control stage I flag is off	Extruder signal is off	Check the electrical wiring
		Line speed is zero	Check the electrical wiring
		Wrong Blowers Ratio	Tune the Blowers Ratio parameter
		Wrong Intake Blower capacity	Tune the <i>Intake Blower</i> capacity parameter
	The width is jumping up and down	Wrong line speed	Calibrate the line speed
System hangs in control stage I and it takes a long		Wrong Tower Height	Fix the Tower Height parameter
time to reach the correct width		Wrong Collapsing Frame	Fix the Collapsing Frame parameter
	The width is stuck on wrong	Wrong Blowers Ratio	Tune the Blowers Ratio parameter
	value	The cage is stuck or the Cage	Check the cage and increase the
		Factor is too low	Cage Factor parameter
	Cage's actual radius is not equal to its set radius	<i>Cage Factor</i> is too high or too low	Fix the <i>Cage Factor</i> parameter
	Cage's actual radius is not equal	<i>Cage Factor</i> is too high or too	Fix the Cage Factor parameter
System hangs in control stage II	The estual gap is not equal to	The belonging volve regranded	Check the value and its perometers
	the set gap	too low	Check the valve and its parameters

Problem	Symptoms	Possible Cause	Action
	The cage is closing too much and opening too much	The <i>Cage Factor</i> is too high	Decrease the Cage Factor parameter
Width is not stable	The cage makes a lot of movements before fixing the width	The Cage Factor is too low	Increase the Cage Factor parameter
width is not stable	The gap is not stable	The cage is too high or too low	Adjust cage's height so that the gap sensors will be at the frost line height
	The gap is not stable	The valve response is too low	Increase the Control Value parameter
After some time the system locks on wrong width	Control stage flags I, II, III are all on	The system is in discontinue mode	Change the control mode to <i>Continue</i>
The width in the ABC screen is not equal to the actual width measured on the lay-flat		The width is not calibrated	Perform Width Calibration
Pubble grapher on the ease during startur		Wrong Blowers Ratio	Tune the Blowers Ratio parameter
Buoole crashes on the cage during startup		Wrong Intake Blower capacity	Tune the Intake Blower capacity parameter

Appendix A – NS10 Screens

Intake Blower	1.200M³/s
Blowers Ratio	1.000
Correction Range	0.200
Control Ratio	1.050
Actual Ratio	1.050
Exhaust E	lower
Ramp Time	5.Øs
Maximum Speed	4000z

Balancing Valve 50.0% ero Range 10.0% ero integral 10z 0.0% ctual Zero 20.0% faximum Travel 5.0% ontrol Value Valve Position 51.0% Open Valve Type Normally Open Balancing Valve

Open Cage	Close Cage
Gap 8	80. Ømm
Gap 7	80. Ømm
Teached Factor	720z
Cage Factor	750z

Cage Control

A	BC Cor	itrol	IBC Blov	vers	Balancing Valve				
Ope	eration 1	Mode	Blowers Ratio	1.000	Control Value 5.		. Ø%		
Manual	Auto	Continue	Correction Range	0.200	Valve Position				
Co	ontrol St	age	Control Ratio	1.050	Open 51, Ø%		Close		
Î	11	111	Actual Ratio	1.050	Cage Control				
	Canaar		Intake Speed	65.0%	Cage Factor 75		50z		
Dealline 4	Sensor	5 010 Bmm	Exhaust Speed	68.2%	Set Radius 318		L8mm		
Radius 1		010. UIIIII 010. Ømm			Actual Radius 318m		L8mm		
Radius 2		318. Ømm	General I	Data	TO CR TC FL		WM		
Reference 4	1	250. 0mm	Tower Height	8.50M	Web				
Cage 5		80. Omm	Coll. Frame Height	2.50M		Width			Gap
Cage 6		80. Omm	Feedback Distance	25.00M	Set	Set 1000m		n	Ømm
Gap 7		80. Ømm	Width Error Alarm	10mm	Actua	Actual 1000mr		n	Ømm
Gap 8		80. Ømm	Line Speed	35.0M/min	Calibra	ate		Ømm	1
			M : c						

Main Screen



Radius 2	210 Bmm						
D	010.6000	800. Umm	NS	NT	BR	CE	Ø%
Radius 3	318. Ømm	800. Omm	NS	NT	BR	CE	Ø%
Reference S	Install	Errors					
Reference 4	251.2mm	250. Ømm	NS	NT	BR	CE	Ø%
Barometric Factor	1.0048						02 - 2
Cage Sen	sors	Install		1	Erro	ors	
Cage 5	80. Ømm	80. Ømm	NS	NT		CE	4%
Cage 6	80. Ømm	80. Ømm	NS	NT	BR	CE	Ø%
Gap 7	80. Ømm	80. Ømm	NS		BR	CE	34%
Gan 8	80. Ømm	80. Ømm	NS	NT	BR	CE	ØX

Width Graph

ABC

Appendix B – Parameters Synopsis and Common Values

The following table lists all the parameters of the ABC system with a short description and common value of each parameter. It also specifies whether the parameter is controlled by the user or by the system. Some values such as set width or installation distance are completely dependent on the specific production line and were therefore left blank.

Note: for best performance each system must be tuned for its specific production line and the values of the parameters may vary from the values given in the following table.

Donomotor	Controlled	Common	Function		
Parameter	By		Function		
	Main Screen				
Set width	User		The required lay-flat width		
Act width	System		The actual produced width		
Set gap	User	-10 to +10mm	The required gap		
Act gap	System		The actual gap		
Calibration Width	User		Width shrinkage calibration		
Control I	System	Off/Blink/On	System Off/control stage I/finish stage I		
Control II	System	Off/Blink/On	Control stage I/control stage II/finish stage II		
Control III	System	Off/Blink/On	Control stage II/control stage III/finish stage III		
Line Speed	User		The line speed		
Intake	User	0-100%	The intake blower speed		
Exhaust	System	0-100%	The exhaust blower speed		
		Sensor Sci	een		
Radius 1, 2, 3	System		Radius at sensors 1, 2, 3		
Reference 4	System		Distance to target at sensor 4		
Cage 5, 6	System		Cage-bubble gap at sensors 5, 6		
Gap 7, 8	System		Cage-bubble gap at sensors 7, 8		
Barometric Factor	System	0.9800-1.02000	Calculated barometric factor		
Radius Sensors Screen					
Radius 1, 2, 3	System		Radius at sensors 1, 2, 3		
Install 1, 2, 3	User		Distance from sensors 1, 2, 3 to die center		
Ref 4	System		Measured distance to reference target		
Install 4	User		Distance to reference target		
Errors 1, 2, 3, 4	System	0-100%	Percentage of fault sensors readings		
		Cage Sensors	Screen		
Cage 5, 6	System		Cage-bubble gap at sensors 5, 6		
Gap 7, 8	System		Cage-bubble gap at sensors 7, 8		
Errors 5, 6, 7, 8	System	0-100%	Percentage of fault sensors readings		
DBC Error Code	System	0-9	Current or last DBC error code		
		IBC Scre	en		
Control Value	User	5-10%	Valve's response level		
Open – Close	System	30-70%	Current valve's position		
Cage Factor	User	500-1500	Cage's time to movement ratio		
Set Radius	System		Cage's set radius (according to set width)		
Actual Radius	System		Cage's actual radius		
Blowers Ratio	User	0.900-1.100	Intake to exhaust blowers ratio		
Control Range	User	0.100-0.200	Allowed range for the control ratio		
Control Ratio	System	0.800-1.200	Calculated intake to exhaust ratio		
Actual Ratio	System		Current actual blowers ratio		

D	Controlled	Common	Energy of any			
Parameter	By	Values	Function			
Intake Speed	User	0-100%	The intake blower speed			
Exhaust Speed	System	0-100%	The exhaust blower speed			
Balancing Valve Screen						
Zero Position	User	40-60%	Start point for the valve			
Zero Range	User	10%	Allowed range for actual zero position			
Zero Integral	User	10	Zero position adjustment factor			
Actual Zero	System	45-55%	The adjusted zero position			
Control Value	User	5-10%	Valve's response level			
Max Travel	User	20%	Allowed range for the valve's position			
Open – Close	System	30-70%	The current position of the valve			
Valve Type	User	N.CN.O.	Normally open or normally closed valve			
Cage Control Screen						
Cage Factor	User	500-1500	Cage's time to movement ratio			
Calculated Factor	System	500-1500	Calculated cage factor			
Gap 7, 8	System		Cage-bubble gap at sensors 7, 8			
IBC Blowers Screen						
Blowers Ratio	User	0.900-1.100	Intake to exhaust blowers ratio			
Control Range	User	0.100-0.200	Allowed range for the control ratio			
Control Ratio	System	0.800-1.200	Calculated intake to exhaust ratio			
Actual Ratio	System		Current actual blowers ratio			
In Blower	User	1.000-2.000	Intake blower capacity			
Ramp Time	User	5-10sec	Ramp time of the blowers			
Max Speed	User	2047/4000	Blower's speed range (AD and DA range)			
General Screen						
Tower Height	User	8.00-12.00m	Height from top of cage to take-off nip			
Collapsing Frame	User	2.00-4.00	Collapsing frames length			
Feedback	User	20.00-30.00	Distance to width feedback point			
Width Error TH	User	10-20mm	Width error alarm threshold (discontinue mode)			
Line Speed Maximum	User	100-150m/sec	The line speed when analog input is 10V			
Line Speed Actual	System		The current line speed			
Control Manual	User	On/Off	Disable cage control			
Control Auto	User	On/Off	Enable cage control			
Control Continue	User	On/Off	Continuous or discontinuous cage control			
Control I	System	Off/Blink/On	System Off/control stage I/finish stage I			
Control II	System	Off/Blink/On	Control stage I/control stage II/finish stage II			
Control III	System	Off/Blink/On	Control stage II/control stage III/finish stage III			
Set Width	User		The required lay-flat width			
Actual Width	System		The actual produced width			
Set Gap	User	-10 to +10mm	The required gap			
Actual Gap	System		The actual gap			
Calibrate	User		Width shrinkage calibration			
		Width Limits	Screen			
Set Width	User		The required lay-flat width			
Minimum Width	User	500-1000mm	Minimum allowed set width			
Maximum Width	System		Maximum set width			

Appendix C – Assembly Example

The following drawings show an example of the ABC system assembly on a blown film production line. Note that different lines may require different assembly.





Radius Sensors (1, 2, 3) and Compensation Sensor (4) Assembly



Cage Sensors (5, 6) and Gap Sensors (7, 8) Assembly

If you have any further questions please do not hesitate to contact us: info@sysmetric.com www.sysmetric.com Phone: +972-4-6405857 Fax: +972-4-6405911