

Energy Measuring Module

User's Manual (Details)

MODEL QE83WH4W

Thank you for purchasing the Mitsubishi MELSEC-Q series programmable controllers.

Before using this product, please read this manual carefully and pay full attention to safety to handle the product correctly.

Mitsubishi Programmable Controller	MODEL	QE83WH4W-U-SY-E	
MELSEG-Q	MODEL	19H866	
	CODE		
		IB63722	
C 2012 MITSUBISHI ELECTRIC CORPORATION			





(Read these precautions before using this product.)

This manual contains important instructions for MELSEC-Q series QE83WH4W.

Before using this product, please read this manual and the relevant manuals carefully and pay full attention to safety to handle the product correctly.

The precautions given in this manual are concerned with this product only. For the safety precautions of the programmable controller system, refer to the user's manual of the CPU module used.

In this manual, the safety precautions are classified into two levels: "DANGER" and "CAUTION".



Under some circumstances, failure to observe the precautions given under " (CAUTION" may lead to serious consequences.

Observe the precautions of both levels because they are important for personal and system safety.

Keep this manual in an accessible place for future reference whenever needed, and make sure it is delivered to the end user.

[Precautions for Operating Environment and Conditions]

- Do not use this product in the places listed below. Failure to follow the instruction may cause malfunctions or decrease of product-life.
 - Places the Ambient temperature exceeds the range 0 55°C.
 - Places the Relative humidity exceeds the range 5 95% or condensation is observed.
 - Altitude exceeds 2000 m.
 - Places exposed to rain or water drop.
 - Dust, corrosive gas, saline and oil smoke exist.
 - Vibration and impact exceed the specifications.
 - Installation on excluding the control board

[Design Precautions]

 Do not write data into "System Area" in the buffer memory of the intelligent function module. Also, do not output (turn ON) the "use prohibited" signal in the output signal sent from the sequencer CPU to the intelligent function module.

Doing so may cause a malfunction to the sequencer system.

•	• Do not install the input signal wire together with the main circuit lines or power cables. Keep a				
	distance as below. (Except for the terminal input part) Failure to do so may result in malfunction				
	due to noise.				
		Conditions	Distance		
		Below 600V, or 600A power lines	300mm or more		
	Other power lines 600mm or more				

[Installation Precautions]

•	Any person who is involved in the installation and the wiring of this Sequencer should be fully
	competent to do the work.
•	Use the programmable controller in an environment that meets the general specifications in the
	User's manual of the CPU module used.
	Failure to do so may result in electric shock, fire, malfunction, or damage to or deterioration of the
	product.
٠	To mount the module, while pressing the module-mounting lever located in the lower part of the
	module, fully insert the module fixing projection(s) into the hole(s) in the base unit and press the
	module until it snaps into place.
	Incorrect mounting may cause a malfunction, failure or a fall of the module.
	When using the Sequencer in an environment of frequent vibrations, fix the module with a screw.
٠	Tighten the screws within the specified torque range.
	Fixing-Module screw (arranged by user): M3 x 12mm
	Tightening torque of the fixing-module screws 0.36 - 0.48 N•m
	When the screw tightening is loose, it causes a fall, short-circuit, and a malfunction.
	Over-tightening can damage the screws and the module, and it may cause a fall, short-circuit, or a
	malfunction.
•	Shut off the external power supply for the system in all phases before mounting or removing the
	module. Failure to do so may result in damage to the product.
•	Do not touch directly any conductive parts and electronic parts of the module.

Doing so can cause a malfunction or failure of the module.

[Wiring Precautions]

- For installation and wiring works, make sure that the power source is shut off for all outside phases. If all phases are not turned off, it may cause an electric shock or product damages.
- When the input voltage of voltage transform unit is 55V or less, voltage display will be 0V by cut-off. The voltage maybe still applied even if the display is 0V. Touching the active wire is strictly prohibited. Make sure shut off the switch, and check the voltage was not been applied.

- When using this product, make sure to use it in combination with current sensor (EMU-CT === series or EMU2-CT5-4W) and Voltage transform unit (QE8WH4VT). Please not to exceed the ratings of this product for input of current sensor. For further details, please refer to current sensor manual to maintain the functionality and the accuracy of this product. The available range of the voltage transform unit is from 63.5/110 to 277/480V AC. When used in a circuit more than 227/480V AC, voltage transformer is required.
- Current sensor (EMU-CT50, EMU-CT100, EMU-CT250, EMU-CT400, EMU-CT600) is used only for low voltage circuit. It cannot be used with a high voltage circuit. Also, EMU2-CT5-4W should be used with the secondary side (5 A) of transformer transfixed. If it is connected with a high-voltage circuit by mistake, it may cause a burnout of the device and a fire. It is critically dangerous. For the Allowable maximum voltage, refer to Appendix 2 "Option devices".
- Current sensor has a polarity (directionality). Be careful about it when installing the module.
- Do not open the secondary side of current sensor.
- Take care not entering any foreign objects such as chips and wire pieces into the module. It may cause a fire, failure or a malfunction.
- In order to prevent the module from incoming foreign objects such as wire pieces during wiring work, a foreign-object preventive label is placed on the module. While a wiring work is performed, keep the label on the module. Before operating the system, peel off the label for heat release. If the foreign-object preventive label is not peeled and the system is in use, residual heat inside the module may reduce the product life.
- The wires to be connected to the module shall be put in a duct or fixed together by clamp. If not, the loosing and unstable wire or careless stretching results in poor contact of electric wires. That may cause a breakage of the module or wire or a malfunction.
- After wiring, confirm whether there is a wiring forgetting or a faulty wiring. They may cause a device malfunction, a fire, or an electric shock.
- When removing the wires connected to the module, do not pull wires as holding on their electric wire portions. Push the buttons on the terminal, and then remove the wire.
- If the wires connected to the module are strongly pulled off, it may cause a malfunction or a breakage to the module or the wire. (Tensile load: 22N or less)
- Ensure the wiring to the module properly, checking the rated voltage and current of the product and the terminal pin assignment. If the input voltage exceed the rated voltage or the wiring is improper, it may cause a fire or a breakage.
- Do not exceed the specified voltage when doing an insulation resistance test and a commercial frequency withstand voltage test.
- To protect persons who do not have adequate knowledge of electric equipment from elevtric shocks, any of the following measures should be taken for the panel.

(a) To lock the panel so that only trained persons having adequate knowledge of electric equipment can open it.

(b) To design the structure so that the power is automatically interrupted upon opening of the panel. The protection class of the panel should be IP2X or higher.

- Terminal screws must be tightened to the specified torque. (**P**8-1) Loose terminal screws may cause a short circuit or malfunction. If terminal screws are over-tightened, the screws or the module may be damaged, causing a short circuit or malfunction.
- Use an applicable solderless terminal for the current input line and tighten it to the specified torque.
 (●P8-8) If a spade terminal is used, it may fall, causing a breakage of the module when the terminal screw is loosened.
- In case using stranded wire, take measures so that the filament should not vary by processing the point twisted.

[Start-up Precautions]

- Use the product within the ratings specified in this manual. When using it outside the ratings, it not only causes a malfunction or failure but also there is a fear of igniting and damaging by a fire.
- Before operating the product, check that active bare wire and so on does not exist around the product. If any bare wire exists, stop the operation immediately, and take an appropriate action such as isolation protection.
- Do not disassemble or modify the module. It may cause failure, a malfunction, an injury or a fire.
- Attaching and detaching the module must be performed after the power source is shut off for all outside phases. If not all phases are shut off, it may cause failure or a malfunction of the module.
- Do not touch the live terminal. It may cause a malfunction.

[Maintenance Precautions]

- Cleaning and additional tightening of screws must be performed after the input power source is shut off for all outside phases. If not all phases are shut off, it may cause failure or a malfunction of the module.
- Use a soft dry cloth to clean off dirt of the module surface.
- Do not let a chemical cloth remain on the surface for an extended period nor wipe the surface with thinner or benzene.

Check for the following items for using this product properly for long time.

<Daily maintenance>

(1) No damage on this product (2) No abnormality with LED indicators (3) No abnormal noise, smell or heat.

<Periodical maintenance> (Once every 6 months to 1 year)

(4) Confirm there is loosing in installation, wire connection to terminal blocks, and the connection of the connectors. (Check these items under the power failure condition.)

[Storage Precautions]

- To store this product, turn off the power and remove wires, and put it in a plastic bag.
 For long-time storage, avoid the following places. Failure to follow the instruction may cause a failure and reduced life of the product.
 - Places the Ambient temperature exceeds the range -25 to +75°C.
 - Places the Relative humidity exceeds the range 5 95% or condensation is observed.
 - Dust, corrosive gas, saline and oil smoke exist, and vibration and frequent physical impact occur.
 - Places exposed to rain or water drop.

[Disposal Precautions]

• Dispose of the product as an industrial waste.

Revision history

* Instruction Manual Number is provided at the bottom of the cover page.

Printed date	*Instruction Manual #	* Instruction Manual Number is provided at the bottom of the cover page Description of revisions
July, 2012	IB-63722	First edition
l		

This manual does not guarantee to protect or does not give permission to any industrial property and any related rights. Also, our company shall not be held any responsible for any issues related to industrial properties due to product usage described in this manual.

© 2012 MITSUBISHI ELECTRIC CORPORATION

Table of Content	
Safety precautions	
Revision history	A-5
Table of content	
Compliance with the EMC and Low Voltage Directives	A-8
Product configuration	A-8
Chapter 1: Overview	1-1
1.1 Features ······	1-1
Chapter 2: System Configuration	2-1 - 2-4
2.1 Applicable system	2-1
2.2 How to check the function version, serial number, and module version	2-3
Chapter 3: Specifications	3-1 - 3-3
	0.4
3.1 General specifications	
3.2 Electrical and mechanical specifications	
Chapter 4: Functions	4-1 - 4-15
4.1 List of functions	1 1
4.1 Elsi ol functions 4.2 Functions in detail	
	4-2
Chapter 5: I/O signal to CPU module	5-1 - 5-7
	F 4
5.1 List of I/O signals	
5.2 Details of I/O signals	
Chapter 6: Buffer memory	6-1 - 6-29
6.1 Buffer memory assignment	6-1
6.2 Configurable sections (Un\G0 to Un\G99)	6-6
6.3 Measurement sections (Un\G100 to Un\G2999)	
6.4 Common sections (Un\4500 to Un\G4999)	
Chapter 7: Current measuring mode	7-1 - 7-6
7.1 Measuring functions in the current measuring mode	7-1
7.2 Activating the current measuring mode	7-1
7.3 List of I/O signals	
7.4 Buffer memory	
7.5 Names and functions of LEDs	
7.6 Names of signals of terminal block	
7.7 Wiring	7-6

Table of Content

Chapter 8: Setting and procedure for operation	8-1 - 8-20
8.1 Precautions for handling	
8.2 Procedure for operation	
8.3 Name and function of each part	
8.4 Attaching and removing the module	
8.5 Wiring ·····	
8.6 Setting from GX Developer	
Chapter 9: Programming	9-1 - 9-16
9.1 Programming procedure	
9.2 System configuration and usage conditions for sample program	
9.3 System configuration and usage conditions for current measuring mode	9-9
Chapter 10: Troubleshooting	10-1 - 10-9
10.1 List of error codes	
10.2 Troubleshooting ·····	
10.3 Q&A	
Appendix	Appendix 1 - 6
Appendix 1: External dimensions	
Appendix 2: Optional devices	Appendix-2
Index	Index 1

Compliance with the EMC and Low Voltage Directives

(1) For programmable controller system

To configure a system meeting the requirements of the EMC and Low Voltage Directives when incorporating the Mitsubishi programmable controller (EMC and Low Voltage Directives compliant) into other machinery or equipment, refer to Chapter 9 "EMC AND LOW VOLTAGE DIRECTIVES" of the QCPU User's Manual (Hardware Design, Maintenance and Inspection).

The CE mark, indicating compliance with the EMC and Low Voltage Directives, is printed on the rating plate of the programmable controller.

(2) For the product

For the compliance of this product with the EMC and Low Voltage Directives, refer to Section 8.5 Wiring.

(3) CE marking conformity combination module

This module conforms to CE marking standard in a condition to make combination use with following current censor and cable.

(a)Current input

current censor	EMU-CT50, EMU-CT100, EMU-CT250, EMU-CT400, EMU-CT600	EMU2-CT5-4W
cable or current censor cable	CE marking cable (twisted pair cable) Stranded wire: 1.3 mm ² (0.5 - 1.3 mm ²) Solderless terminal: R1.25-3	EMU2-CB-Q5B-4W EMU2-T1M, EMU2-T5M EMU2-T10M, EMU2-T1MS EMU2-T5MS, EMU2-T10MS
Max. cable length	50m	11m

(b)Voltage input

cable	CE marking cable (twisted pair cable)	
	Single wire: φ1.2 mm (φ0.5 - 1.2 mm)	
	Stranded wire: 1.3 mm ² (0.5 - 1.3 mm ²)	
Max. cable length	50m	

Product configuration

The following describes the product configuration.

Model name	Product name	Quantity
	Energy Measuring Module	1
QE83WH4W	Voltage input terminals	1

Note

Chapter 1: Overview

This manual explains specifications, handling methods, and programming of Energy Measuring Module QE83WH4W (hereinafter, abbreviated as QE83WH4W) supporting MELSEC-Q series.

1.1 Features

- This Energy Measuring Module can measure three channels of various types of electric quantity.
 It can measure three channels of electric energy, reactive energy, current, voltage, electric power, reactive power, power factor, and frequency.
 Both consumption and regeneration of the electric energy can be measured.
- (2) Extensive monitoring functions In addition to memorizing the maximum and minimum values, two types of alarm monitoring for upper and lower limit can be performed for each channel.
- (3) It also can measure the electric energy for a certain period.
 It can measure the electric energy for the duration of time for which the output device is on.
 This feature enables to acquire the electric energy needed during device operation or energy per tact.
- (4) Equipped with the current measuring mode where eight channels of current can be measured.

By selecting the current measuring mode using the intelligent function module switch, you can measure only the current through eight channels.

Note that the input/output signals and buffer memory to be used in the current measuring mode are different from those used in the regular operation mode. For details, refer to Chapter 7.

Chapter 2: System Configuration

2.1 Applicable system

The following describes applicable systems.

(1) Applicable module and the quantity of attachable pieces

(a)When mounted with CPU module

CPU module to which QE83WH4W can be attached and the number of attachable pieces are shown below.

Depending on the combination of the attached module and the number of attached pieces, lack of power capacity may occur.

When attaching the module, please consider the power capacity.

If the power capacity is insufficient, reconsider the combination of modules to be attached.

Since the number of attachable modules are limited by the power module which used, please refer to the notes on the 2.2 precautions for system configuration.

	plicable CPU Mc		Number of	Remarks
CPL	Ј Туре	CPU Model	modules	
		Q00JCPU	8	
	Basic model QCPU	Q00CPU	24	
	QCFU	Q01CPU	24	
		Q02CPU		
	l l'als a sufsuisses a	Q02HCPU		
	High performance model QCPU	Q06HCPU	64	
		Q12HCPU		
		Q25HCPU		
		Q02PHCPU		
	Process CPU	Q06PHCPU	64	
	Process CPU	Q12PHCPU	64	
		Q25PHCPU		
	Redundant CPU	Q12PRHCPU	53	
	Redundant CPU	Q25PRHCPU	53	
	Universal model QCPU	Q00UJCPU	8	
Programmable		Q00UCPU	24	
controller		Q01UCPU	24	
CPU		Q02UCPU	36	
		Q03UDCPU		
		Q04UDHCPU		
		Q06UDHCPU		
		Q10UDHCPU		
		Q13UDHCPU		
		Q20UDHCPU		
		Q26UDHCPU		
		Q03UDECPU	64	
		Q04UDEHCPU		
		Q06UDEHCPU		
		Q10UDEHCPU	4	
		Q13UDEHCPU	4	
		Q20UDEHCPU		
		Q26UDEHCPU	4	
		Q50UDEHCPU	4	
		Q100UDEHCPU		

Applicable CPU Mo	odule	Number of	Remarks
СРИ Туре	CPU Model	modules	
	Q06CCPU-V		
C Controller module	Q06CCPU-V-B	64	
	Q12DCCPU-V		

(b) When mounted with MELSECNET/H remote I/O station

The table below shows the network modules applicable to the QE83WH4W and the number of network modules to be mounted.

Depending on the combination with other modules or the number of mounted modules, power supply capacity may be insufficient.

Pay attention to the power supply capacity before mounting modules, and if the power supply capacity is insufficient, change the combination of the modules.

Applicable Network Module	Number of modules	Remarks
QJ72LP25-25		
QJ72LP25G	64	
QJ72BR15		

(c) The base unit can be mounted

QE83WH4W can be installed to any I/O slot of main base unit and extension base unit.

*1 In case of redundant CPU, can be mounted to the extension base unit only. Mounted to the main base unit is not allowed.

*2 Limited within the range of I/O points for the CPU module.

(2) Attachable base unit

QE83WH4W can be attached to any I/O slot of the basic base unit and expansion base unit (*1) (*2).

*1 In the case of dual CPU, it can be attached only to an expansion base unit. It cannot be attached to the base unit.

*2 It has to be within the range of I/O slots of the CPU module.

(3) Applicable software package

QE83WH4W supported software packages are as follows: (a) Software package for sequencer

Product name	Model name	Remarks
GX Works2	SW1DNC-GXW2	Sequencer engineering software
GX Developer	SWnD5C-GPPW	MELSEC sequencer programming software "n" in the model name is 4 or larger.

2.2 How to check the function version, serial number, and module version

 How to check the module version It can be checked with the serial number label (placed on the right side of QE83WH4W).



(2) How to check the function version and serial number(a) Checking on the front of the module

The serial number and function version on the rating plate is shown on the front (at the bottom) of the module.



- (b) Checking on the System monitor dialog box (Product Information List)
- To display the system monitor, select [Diagnostics] \rightarrow [System monitor] and click the Product Information List button of GX Developer.

Slot	Type	Series	Model name	Points	I/0 No.	Master PLC	Serial No	Ver.	Product No.		
PLC	PLC	Q	QOOUJCPU	-	-	-	131020000000000	В	140115140218032-B		
0-0	Intelli.	Q	QE83WH4W	32pt	0000	-	140410000000000	В	-		
0-1	-	-	None	-	-	-	-	-	-		
0-2	-	-	None	-	-	-	-	-	-		
0-3	-	-	None	-	-	-	-	-	-		
0-4	-	-	None	-	-	-	-	-	-		
										_	
										_	
										_	
										_	
										_	
										_	
										_	
										_	
										-	
										-	

Point	
The serial num	nber displayed on the Product Information List dialog box of GX
Developer may	differ from that on the rating plate and on the front of the module.
 The set 	rial number on the rating plate and front part of the module indicates
the mar	nagement information of the product.
 The set 	ial number displayed on the Product Information List dialog box of GX
Develo	per indicates the function information of the product.
The function info	prmation of the product is updated when a new function is added.

Chapter 3: Specifications

3.1 General specifications

	Item	Specifications
	Phase wire system	three-phase 4-wire
Rating	Voltage circuit * ¹	63.5/110 - 277/480V AC (Selected from: 63.5/110V, 100/173V, 105/182V, 110/190V, 115/199V, 120/208V, 127/220V, 200/346V, 220/380V, 230/400V, 240/415V, 242/420V, 250/430V, 254/440V, 265/460V, 277/480V AC. Each value refers to the primary voltage of voltage transform unit (QE8WH4VT).)
	Current circuit	 50 A, 100 A, 250 A, 400 A, 600 A AC (Current sensor is used. Each value refers to the current at the primary side of current sensor.) 5 AAC (Current sensor is used together with current transformer (CT), and the primary-side current is configurable up to 6000 A.) *²
	Frequency	50-60 Hz
(excluding	tolerance of main module g current sensor) * ³	Current, current demand $*^4$: ±1.0% (100% of the rating)Voltage: ±1.0% (100% of the rating)Electric power, electric power demand : ±1.0% (100% of the rating)Reactive power: ±1.0% (100% of the rating)Apparent power: ±1.0% (100% of the rating)Frequency: ±1.0% (45 - 65 Hz range of the rating)Power factor: ±3.0% (against the electric angle 90°)Electric energy: ±2.0% (5 - 100% range of the rating, power factor = 1)Reactive energy: ±2.5% (10 - 100% range of the rating, power factor = 0)
Measurab	ble circuit count	3 circuits (3 channels) under the same voltage system, or 8 circuits (8 channels) in the current measuring mode
Data upda	ate cycle	500 ms ^{*5} (100 ms in the current measuring mode)
Response	e time	2 seconds or less
Backup fo	or electric blackout	Backup is made using nonvolatile memory. (Stored items: settings, the max./min. values and time of occurrence, electric energy (consumption, regenerated), reactive energy (consumption lag), and periodic electric energy)
I/O occup	ation	32 points (I/O assignment: intelligence 32 points)

- * 1 : Voltage input is required a voltage transform unit (QE8WH4VT). Above 277/480V AC voltage transformer outside (VT) is required (Primary side of VT can be set up to 6600V (phase voltage) in any setting).
- * 2 : 5 A primary current can be set when using the current sensor is as follows.

5A, 6A, 7.5A, 8A, 10A, 12A, 15A, 20A, 25A, 30A, 40A, 50A, 60A, 75A, 80A, 100A, 120A, 150A, 200A, 250A, 300A, 400A, 500A, 600A, 750A, 800A, 1000A, 1200A, 1500A, 1600A, 2000A, 2500A, 3000A, 4000A, 5000A, 6000A (Primary current of CT can be set up to 6000A in any . However, secondary current of CT can not be set to other than 5A).

- * 3 :The ratio error of the current sensor : ±1.0% (5 100% range of the rating), and the ratio error of voltage transform unit : ±1.0% (primary voltage of the rating)
- * 4 : Demand shows the moving average of a set period.

* 5 : Always accumulating the integrated values of Wh and varh. It can capture short-cycled load fluctuation(500 ms or shorter).

3.2 Electrical and mechanical specifications

lte	em	Specifications								
Consumed V	A Voltage circuit	P1-P0: 2VA, unit)	P2-F	P0: 0.3VA	A, P3-P0: 0.	.3V/	A (primary side	e of volta	ge transforn	
	Current circuit	Each phase	0.1 V	'A (secor	ndary side o	of cu	urrent sensor)			
Internal curre	0.39 A									
consumption						050				
Operating ten	nperature	0-55°C (Av				35°	C or below)			
Operating hu		5 – 95% RH		condensa	ation)					
Storage temp		-25° – +75°C								
Storage humi		5 – 95% RH		condensa	ation)					
Operating alti		2000m or be		-						
Installation ar		Inside a cont		anel						
Operating env		No corrosive	gas		-					
Vibration resi	stance	Conforms to JIS B			Frequency		Constant acceleration	Half amplitude	Sweep	
		3502, IEC	Inter	mittent	5 – 8.4 Hz		-	3.5 mm	XYZ	
				tion	8.4 – 150 H	Z	9.8 m/s ²	-	each directio times	
			Cont	inuous	5 – 8.4 Hz		-	1.75 mm	-	
		vi		tion	8.4 – 150 Hi	Z	4.9 m/s ²	-		
Impact resista	ance	Conforms to JIS B 3502, IEC 61131-2 (147m/s ² , XYZ each direction 3 times) II or less 2 or less Class I								
Over voltage	category *1									
Pollution deg	ee *2									
Equipment ca										
Applicable wire	Voltage input terminal	Single wire Stranded wir	• * ⁴	AWG24 AWG20		Tię	ghtening torqu	ue : 0.4 – 0.5 N • m		
(Usable	Current input	Stranded wir	e ***			٨٣	nliachla colda	rloop torr	minolo :	
electric wire) * ⁶	terminal *3	Stranded wire *4		AWG20-18		Applicable solderless terminals : R1.25-3 (No solderless terminal with insulation sleeve can be used) Tightening torque : 0.42 – 0.58 N • m				
Tightening to	que	Current input terminal block fixing 0				0.0	0.66 - 0.89 N∙m			
			screws (M3.5) Module-fixing screws (M3 screw) * ⁵				0.36 – 0.48 N•m			
Commercial f withstand volt		Between voltage/current input terminals - SLD terminal					2210 V AC 5 sec			
Willound Voltago		Between voltage/current input terminals - sequencer power source and GND terminals					ower	2210 V AC 5 sec		
Insulation res	istance	5 MΩ or mor				s ab	ove		•	
Standard		EMC: EN61 LVD: EN611	131-2	:2007, É	N61326-1:2	200	6			
Dimensions							excluding prot	ruding po	ortions	
Mass		0.19kg				. ,				
	xpectancy	10 years (used under the average daily temperature 35°C or less)								

*1. This indicates the assumed area of electric distribution to which the device is connected, the area ranging from public distribution to factory machinery. The category II applies to the device power-supplied from fixed facility. The surge voltage of this product is 2500 V up to the rated voltage of 300 V.

*2. The index indicates the level of conductive substance at the device's operating environment. Contamination level 2 means only non-conductive substance. However, occasional condensation may lead to temporary conduction.

*3. At the connection between the secondary terminal of current sensor (k, l) and the main module terminal (1k, 1l, 2k, 2l, 3k, 3l), use twisted pair cable.

- *4. When using stranded wires for the voltage input terminals, use solderless terminals or strand the wire edges to prevent thin wires from loosening.
- *5. When using stranded wires for the current input terminals, use applicable solderless terminals. If any spade solderless terminal is used, it may be disconnected when the terminal screw comes loose, resulting in failure. In addition, no solderless terminal with insulation sleeve can be used.
- *6. The module can be fixed easily to the base unit, using the hook on top of the module. However, if it is used under a vibrating environment, we strongly recommend that the module be fixed with screws.
- *7. To comply with UL/c-UL standards, use the wires meeting the following requirements. The rated temperature of the copper conductor should be 60°C/75°C.

Chapter 4: Functions

4.1 List of functions

Functions of QE83WH4W are provided in Table 4.1.

The "n" that is used in this and later chapters (for example: Xn0, Yn0, Un\G0, etc.) refers to the number that appears at the beginning of QE83WH4W.

No.	Function	Descriptions	Reference section
1	Measurement	It measures current, current demand, voltage (L-L), voltage (L-N), electric power, reactive power, apparent power, electric power demand, power factor, frequency, effective energy (consumption, regeneration), reactive energy (consumption lag), and sequentially stores the records into a buffer memory.	Section 4.2.1
2	Periodic electric energy	The electric energy only for a period of time when a certain output signal is ON will be stored in the buffer memory. Periodic energy 1 and 2 can be measured independently.	Section 4.2.2
3	Hold max./min. values	For current demand, line voltage, phase voltage, electric power demand, and power factor, each maximum /minimum values and date/time of occurrence are stored.	Section 4.2.3
4	Upper/lower limit alarm monitoring	Of current demand, line voltage, phase voltage, electric power demand, and power factor, you can select two items for which their upper/lower limit can be monitored. If it exceeds the upper limit or goes below the lower limit, the specified input signal is turned on.	Section 4.2.4
5		Selecting the test mode using the intelligent function module switch enables pseudo-storage of the specified value into the buffer memory, even with non-existence of input from voltage and current (sensor). Using this module, you can create a sequence, etc.	Section
6	Integrated value setting	Setting integrated value (electric energy (consumption, regeneration) and reactive energy (consumption lag)) to any value.	Section 4.2.6
7	Current measuring mode function	By selecting the current measuring mode using the intelligent function module switch, you can measure eight channels of current and sequentially store the records into the buffer memory.	Chapter 7

Table 4.1 List of Functions

4.2 Functions in detail

4.2.1 Measuring functions

(1) Measured items

Measured items of each channel are described as follows: Each measured item is stored in the buffer memory every 500 ms.

Measured items				
	Details			
Current	1 - phase current			
Guneni	2 - phase current			
	3 - phase current			
	Neutral current			
	Average value current			
Current demand	1 - phase current demand			
* The average of fluctuation for the	2 - phase current demand			
set period of current demand time	3 - phase current demand			
is indicated.	Neutral current demand			
	Max. value			
	Min. value			
	Date of max. value occurrence			
	Date of min. value occurrence			
Voltage	Voltage V12			
Vollage	Voltage V23			
	Voltage V31			
	average value voltage (L-L)			
	Max. value of the voltage (L-L)			
	Min. value of the voltage (L-L)			
	Date/time of max. voltage value occurrence (L-L)			
	Date/time of min. voltage value occurrence (L-L)			
	Voltage V1N			
	Voltage V2N			
	Voltage V3N			
	average value voltage (L-N)			
	Max. value of the voltage (L-N)			
	Min. value of the voltage (L-N)			
	Date/time of max. voltage value occurrence (L-N)			
	Date/time of min. voltage value occurrence (L-N)			
Electric power	Present value			
Electric power demand	Present value			
* The average of fluctuation for the	Max. value			
set period of electric power	Min. value			
demand time is indicated.	Date/time of max. value occurrence			
	Date/time of min. value occurrence			
Reactive power	Reactive power			
Apparent power	Apparent power			

Power factor	Present value
	Max. value
	Min. value
	Date/time of max. value occurrence
	Date/time of min. value occurrence
Frequency	Present value
Electric energy	Electric energy (consumption)
	Electric energy (regeneration)
	Reactive energy (consumption lag)
Periodic electric energy *2	Periodic electric energy 1
	Periodic electric energy 2

*2: When the output device is ON, the active power (consumption) is measured.

(2) Total, maximum, and minimum values

The following describes how to calculate the maximum, minimum, and total values.

Item	Formula
Average value current	Average value current
	= (1-phase current + 2-phase current + 3-phase current) / 3
Average value voltage	Average value voltage (L-L)
(L-L)	= (voltage V12 + voltage V23 + voltage V31) / 3
Average value voltage	Average value voltage (L-N)
(L-N)	= (voltage V1N + voltage V2N + voltage V3N) / 3
Maximum current	Highest value among 1-phase current demand, 2-phase current demand,
demand	3-phase current demand, or N-phase current demand
	(The highest value after the max./min. value was reset.)
Minimum current	Lowest value among 1-phase current demand, 2-phase current demand, or
demand	3-phase current demand
	(The lowest value after the max./min. value was reset.)
Maximum value	Highest value among the voltage V12, the voltage V23, or the voltage V31
voltage (L-L)	(The highest value after the max./min. value was reset.)
Minimum value voltage	Lowest value among the voltage V12, the voltage V23, or the voltage V31
(L-L)	(The lowest value after the max./min. value was reset.)
Maximum value	Highest value among the voltage V1N, the voltage V2N, or the voltage V1N
voltage (L-N)	(The highest value after the max./min. value was reset.)
Minimum value voltage (L-N)	Lowest value among the voltage V1N, the voltage V2N, or the voltage V1N (The highest value after the max./min. value was reset.)

(3) Resolution of measured data

Resolution of measured data according to the rating (phase wire system, primary voltage, and primary current) is described as follows.

1) Current, current demand

Rated primary current setting	Multiplier	Resolution*		
5 A to 30 A	-3	2 digits after the decimal point	0.01 A	
40 A to 300 A	-3	1 digit after the decimal point	0.1 A	
400 A to 3000 A	-3	Integer	1 A	
4000 A to 6000 A	-3	×10	10 A	

* Digits lower than the resolution are fixed to 0.

2) Voltage

a. When not use voltage transformer

Input voltage setting	Multiplier Resolution*		
63.5 / 110 V to 277 / 480 V	-3	1 digit after the decimal point	0.1 V

b. When use voltage transformer

Rated primary voltage setting	Multiplier	Resolution	*			
1 V to 329 V	-3	1 digit after the decimal point	0.1 V			
330 V to 2299 V	-3	Integer	1 V			
3300 V to 6600 V	-3	×10	10 V			

* Digits lower than the resolution are fixed to 0.

3) Electric power, electric power demand, reactive power, apparent power

Full load power W ^{*1*3}	Multiplier	Resolution	
I . W <12 kW	-3	3 digits after the decimal point	0.001 kW
II . 12 kW ≤ W < 120 kW	-3	2 digits after the decimal point	0.01 kW
III. 120 kW ≤ W < 1200 kW	-3	1 digit after the decimal point	0.1 kW
IV. 1200 kW ≤ W < 12000 kW	-3	Integer	1 kW
V.12000 kW ≤ W < 120000 kW	-3	×10	10 kW

^{*1} Full load power W can be calculated by the following equation:

In addition, for calculating full load power W, refer to Table 4.2.

Full load power W [kW] = $3 \times (VT \text{ primary voltage}) \times (CT \text{ primary current}) / 1000$ Primary voltage = voltage (L-N) of input voltage (when not use voltage transformer)

= primary voltage of voltage transformer (when use voltage transformer)

^{*2} Digits lower than the resolution are fixed to 0.

^{*3} In the case of reactive power, the unit will be kvar.

In the case of apparent power, the unit will be kVA

4) Power factor

Power factor	Multiplier	Resolutio	n*
All setting ranges	-3	1 digit after the decimal point	0.1%

* Digits lower than the resolution are fixed to 0.

5) Frequency

Frequency	Multiplier	Resolution*	
All setting ranges	-3	1 digit after the decimal point	0.1 Hz

Digits lower than the resolution are fixed to 0.

6) Electric energy, periodic electric energy

Full load power W ^{*1}	Multiplier	Resolution*2*3	Range [kWh,kvarh]
I. W < 12 kW	-5	5 digits after the decimal point	0.00001 - 9999.99999
II. 12kW ≤ W < 120 kW	-4	4 digits after the decimal point	0.0001 - 99999.9999
Ⅲ. 120kW ≤ W < 1200 kW	-3	3 digits after the decimal point	0.001 – 999999.999
IV. 1200kW ≤ W < 12000 kW	-2	2 digits after the decimal point	0.01 – 9999999.99
V.12000kW ≤ W < 120000 kW	-1	1 digit after the decimal point	0.1 – 999999999.9

^{*1} For calculating full load power W, refer to Table 4.2.

 *2 Digits lower than the resolution are fixed to 0.

^{*3} Because the higher resolution than a typical watt-hour meter, the minimum digit values will change more than 2 at once update. According to setting value of input voltage, primary current, primary voltage of VT and the condition of load.



Table 4.2 How to calculate full load power

- (4) Restrictions for measuring data
 - Measurement cannot be performed immediately after the power loading to the sequencer system (Module ready signal is under the OFF condition).
 - After checking that Module ready (Xn0) is ON, obtain measuring data.
 - Measurement cannot be performed immediately after operating conditions are set up to the module. After checking that Operating condition setting completion flag (Xn9) becomes ON, obtain measuring data.
 - Behaviors during operation are as follows:

Measuring item	Behavior of the module				
Current	When the input current is less than 0.4% of the rating current, it becomes 0A.				
Current demand	Current demand is obtained by current moving average. Therefore, even if current is 0A, current demand may not be 0A.				
Voltage (L-N)	When the input voltage (L-N) is less than 55V, it becomes 0V. If there is no input at voltage V1N, all measurement cannot be done.				
Voltage (L-L)	When the input voltage (L-L) is less than 95V, it becomes 0V.				
Electric power	When current is 0A (at all phases are 0A) or when voltage is 0V (all phases are 0V), it becomes 0kW.				
Electric power demand	Electric power demand is obtained by electric power moving average. Therefore, even if electric power is 0kW, electric power demand may not be 0kW.				
Power factor	When current is 0A (at all phases are 0A) or when voltage is 0V (all phases are 0V), it becomes 100%.				
Frequency	Voltage condition When the input voltage (L-N) is less than 55V, it becomes 0H Frequency condition When it is less than 44.5Hz, it is fixed to 44.5Hz.				

4.2.2 Measuring function for periodic electric energy

This function is to measure electric energy for a certain period, and stores it into the buffer memory. It can be used to measure electric energy for a certain tact or energy (standby power) when the facility or equipment is not in operation.

(1) Overview

Note

- 1) It can measure two periodic electric energy (periodic electric energy 1 and periodic electric energy 2) of each channel. Each of these can be measured independently.
- 2) During the time when Periodic electric energy 1 measurement flag / Periodic electric energy 2 measurement flag is ON, periodic electric energy can be measured.
- 3) Periodic electric energy is stored in the nonvolatile memory, so that it can be retained even at a power source reset.
- 4) I/O signals and buffer memory corresponding to each periodic electric energy 1 and 2 are provided below.

		Buffer memory (Double words)	Periodic electric energy measuremen t flag	Periodic electric energy data completion flag	Periodic electric energy reset request	Periodic electric energy reset completion flag
011	Periodic electric energy 1	Un\G114, 115	Yn5	Xn5	Yn7	Xn7
СПІ	CH1 Periodic electric energy 2 Un\G116		Yn6	Xn6	Yn8	Xn8
0112	Periodic electric energy 1	Un\G1114, 1115	YnB	XnB	YnD	XnD
CH2 Periodic electric energy 2 Un\C		Un\G1116, 1117	YnC	XnC	YnE	XnE
СН3 —	Periodic electric energy 1	Un\G2114, 2115	Yn11	Xn11	Yn13	Xn13
	Periodic electric energy 2	Un\G2116, 2117	Yn12	Xn12	Yn14	Xn14

Measurement of periodic electric energy is performed every measuring cycle (500 ms). Therefore, if the time to turn ON the periodic electric energy measurement flag is set to 500 ms or less, measurement may not be taken.

(2) Basic procedure

1) Measuring periodic electric energy

- (a) Check that CH1 periodic electric energy 1 measurement flag (Yn5) is OFF.
- (b) Check CH1 periodic electric energy 1 (Un\G114, 115).
- (c) When starting measurement, set CH1 periodic electric energy 1 measurement flag (Yn5) to ON.

This module starts measuring the specified periodic electric energy, and CH1 periodic electric energy 1 data completion flag (Xn5) will be turned OFF

(d) When stopping measurement, set CH1 periodic electric energy 1 measurement flag (Yn5) to OFF.

This module stops measuring the specified periodic electric energy, and CH1 periodic electric energy 1 data completion flag (Xn5) will be turned ON.

(e) Check that CH1 periodic electric energy 1 data completion flag (Xn5) becomes ON, and obtain the value of periodic electric energy.



Figure 4.1 Basic procedure of measuring the periodic electric energy

- 2) Resetting periodic electric power
 - (a) Check that CH1 periodic electric energy 1 measurement flag (Yn5) is OFF and CH1 periodic electric energy 1 reset request (Yn7) is OFF.
 - (b) Set CH1 periodic electric energy 1 reset request (Yn7) to ON. The specified periodic electric energy is reset to 0 kWh, and CH1 periodic electric energy 1 reset completion flag (Xn7) will be turned ON.
 - (c) Check that CH1 periodic electric energy 1 reset completion flag (Xn7) has become ON, and then set CH1 periodic electric energy 1 reset request (Yn7) to OFF.

CH1 periodic electric energy 1 reset completion flag (Xn7) will be turned OFF.



Figure 4.2 How to reset the periodic electric energy

(3) Sample use case

1) Procedure for continuously measuring periodic electric energy

If you turn CH1 periodic electric energy 1 measurement flag to ON only for the extent of time you want to measure, this module accumulates the power starting at the previously measured amount. Usage procedure is the same as 1) in (2). An example is provided below.





Figure 4.3 Example of continuous measurement of periodic electric energy

2) Procedure for measuring periodic electric energy after every reset

If you turn Periodic electric energy measurement flag (Yn1/Yn2) to ON only for the extent of time you want to measure, this module accumulates the power starting at the previously measured amount. The following describes the usage procedure.

- (a) Check that CH1 periodic electric energy 1 measurement flag (Yn5) is OFF and CH1 periodic electric energy 1 reset request (Yn7) is OFF.
- (b) Set CH1 periodic electric energy 1 reset request (Yn7) to ON. The specified periodic electric energy is reset to 0 kWh, and CH1 periodic electric energy 1 reset completion flag (Xn7) will be turned ON.
- (c) Check that CH1 periodic electric energy 1 reset completion flag (Xn7) has become ON, and then set CH1 periodic electric energy 1 reset request (Yn7) to OFF.

CH1 periodic electric energy 1 reset completion flag (Xn7) will be turned OFF.

(d) When starting measurement, set CH1 periodic electric energy 1 measurement flag (Yn5) to ON.

This module starts measuring the specified periodic electric energy, and CH1 periodic electric energy 1 data completion flag (Xn5) will be turned OFF.

(e) When stopping measurement, set CH1 periodic electric energy 1 measurement flag (Yn5) to OFF.

This module stops measuring the specified periodic electric energy, and CH1 periodic electric energy 1 data completion flag (Xn5) will be turned ON.

(f) Check that CH1 periodic electric energy 1 data completion flag (Xn5) becomes ON, and obtain the value of periodic electric energy.



Figure 4.4 Example of measurement of periodic electric energy after every reset

4.2.3 Max./min. value hold function

It memorizes the max./min. value for each measured item, and retains it until the max./min. value clear is performed.

- (1) Max./min. value memory
 - 1) It memorizes the max. and min. values of the following measured items of each channel.
 - Current demand
 - Voltage

Max./

- Electric power demand
- Power factor
- 2) It memorizes the date and time of occurrence (year/month/day/hour/minute/second/day of the week) together with the max. and min. values.
- 3) The max. and min. values and the date of occurrence are stored in the nonvolatile memory, so that these values can be retained even at a power source reset.
- (2) How to clear the max. and min. values
 - 1) You can use the I/O signal to clear the max. and min. values.
 - 2) The max. and min. values immediately after the clear will be the present values and the date of occurrence will be the present date and time.
 - 3) The following describes how to clear the max. and min. values.
 - (a) Check that Max./min. values clear request (Yn4) is OFF.
 - (b) In the max./min. value clear target (Un\G56), set the measured items of the channel you want to clear.
 - (c) Set Max./min. values clear request (Yn4) to ON.

This module clears the max./min. values of the measured items of the channel you selected in step (b) above and their date of occurrence and turns Max./min. values clear completion flag (Xn4) to ON.

(d) Check that Max./min. values clear completion flag (Xn4) is ON, and then set Max./min. values clear request (Yn4) to OFF. Max./min. values clear completion flag (Xn4) will be turned OFF.

Max./min. values clear request (Yn4)	
min. values clear completion flag (Xn4)	OFF OFF

Figure 4.5 Procedure for clearing max./min. value

4.2.4 Upper/lower limit alarm monitoring function

You can set an upper and lower limit alarm for maximum two points for each channel and implement a monitoring function for them. During the alarm monitoring, it can monitor the input signal to check for the occurrence.

(1) Setting the upper/lower limit alarm monitoring

1)	Setting items	and setting rang	e for the alarm	monitoring are	described below.

Items set in the buffer memory	Setting range	Description
Alarm item	0: No monitoring 1: Current demand upper limit 2: Current demand lower limit 3: Voltage (L-L)upper limit 4: Voltage (L-L)lower limit 5: Power demand upper limit 6: Power demand lower limit 7: Power factor upper limit 8: Power factor lower limit 9: Voltage (L-N) upper limit 10: Voltage (L-N)lower limit	For respective alarm 1 and alarm 2, set the measuring item and either upper or lower limit for monitoring target.
Alarm value	-2147483648 – 2147483647 [Unit] Current:×10 ⁻³ A Voltage:×10 ⁻³ V Power:×10 ⁻³ kW PF:×10 ⁻³ %	The value to be monitored for the alarm. Set the value according to the unit of the measuring item that is set as an alarm monitoring item. (Double words)
Alarm reset method	0: Self-retention 1: Auto reset	Set whether or not the alarm-occurrence condition should be retained if the value goes below the upper limit alarm value or goes over the lower limit alarm value after the upper/lower limit alarm occurred.
Alarm delay time	0 – 300 [Unit] second	If it exceeds the upper limit alarm value or if it goes below the lower limit alarm value, and the situation continues for the period of the alarm delay time, then it is considered as an alarm occurrence.

The table below shows I/O signals and buffer memory for alarm 1 and alarm 2.

\sim		Alarm reset	Alarm flag	Buffer memory (Double words)			
		request		Alarm item	Alarm value	Alarm reset	Alarm delay
						method	time
CH1	Alarm 1	Yn9	Xn9	Un\G11	Un\G12, 13	Un\G14	Un\G15
	Alarm 2	YnA	XnA	Un\G21	Un\G22, 23	Un\G24	Un\G25
CH2	Alarm 1	YnF	XnF	Un\G1011	Un\G1012, 1013	Un\G1014	Un\G1015
	Alarm 2	Yn10	Xn10	Un\G1021	Un\G1022, 1023	Un\G1024	Un\G1025
CH3	Alarm 1	Yn15	Xn15	Un\G2011	Un\G2012, 2013	Un\G2014	Un\G2015
	Alarm 2	Yn16	Xn16	Un\G2021	Un\G2022, 2023	Un\G2024	Un\G2025

- 2) Setting procedures are as follows:
 - (a) Check that Operating condition setting request (Yn2) is OFF.
 - (b) Set the alarm item, alarm value, alarm reset method, and alarm delay time in the buffer memory. For the address of buffer memory for alarm 1 and alarm 2, refer to Chapter 6.
 - (c) Set Operating condition setting request (Yn2) to ON. Operation starts at each set value, and then Operating condition setting completion flag (Xn2) is turned ON.
 - (d) Check that Operating condition setting completion flag (Xn2) becomes ON, and then set Operating condition setting request (Yn2) to OFF. Operating condition setting completion flag (Xn2) will be turned OFF.

Operating condition setting request (Yn2)

Operating condition setting completion flag (Xn2)



Figure 4.6 Time chart of alarm monitoring setting

- 3) Each item of the alarm monitoring is stored in the nonvolatile memory, so that values can be retained even at a power source reset.
- (2) Behavior of the upper/lower limit alarm
 - 1) When the alarm reset method is set to "0: self-retention" (example of the upper limit monitoring with CH1 alarm 1)
 - (a) If the measured value that was set with the alarm 1 item exceeds the upper limit and the situation continues and remains for the alarm 1 delay time, CH1 alarm 1 flag (Xn9) will turn ON. At the same time, ALM1 LED flashes.
 - (b) Even if the measured value goes below the upper limit, CH1 alarm 1 flag (Xn9) remains in the ON status (self-retention). During the self-retention, ALM1 LED is lit.
 - (c) By turning CH1 alarm 1 reset request (Yn9) to ON, CH1 alarm 1 flag (Xn9) will turn OFF. At this time, ALM1 LED is turned off.
 - (d) Check that CH1 alarm 1 flag (Xn9) becomes OFF, and then set CH1 alarm 1 reset request (Yn9) to OFF.



Figure 4.7 Time chart of the upper/lower limit alarm (alarm reset method = "self-retention")

- When the alarm reset method is set to "1: auto reset" (example of the upper limit monitoring with CH1 alarm 1)
 - (a) If the measured value that was set with the alarm 1 item exceeds the upper limit and the situation continues and remains for the alarm 1 delay time, CH1 alarm 1 flag (Xn9) will turn ON. At the same time, ALM1 LED flashes.
 - (b) If the measured value goes below the upper limit, CH1 alarm 1 flag (Xn9) will turn OFF. At this time, ALM1 LED is turned off.
 - (c) If the measured value that was set with the alarm 1 item exceeds the upper limit but goes below the upper limit within the alarm 1 delay time, then CH1 alarm 1 flag (Xn9) will remain in the OFF status.



Figure 4.8 Time chart of the upper/lower limit alarm (alarm reset method = "auto-reset")

3) An example of the alarm 1 was indicated in 1) and 2) above. The alarm 2 will be in accordance with the same behavior.

For the setting items for the buffer memory that corresponds to the alarm 2 and the I/O signals, refer to Chapters 5 and 6. The following describes a case with the alarm 2.

[When the alarm reset method is set to "1: auto reset" (example of the lower limit monitoring with CH1 alarm 2)]

- (a) If the measured value that was set with the alarm 2 item goes below the lower limit and the situation continues and remains for the alarm 2 delay time, CH1 alarm 2 flag (XnA) will turn ON. At the same time, ALM2 LED flashes.
- (b) If the measured value exceeds the lower limit, CH1 alarm 2 flag (XnA) will turn OFF. At this time, ALM2 LED is turned off.
- (c) If the measured value that was set with the alarm 2 item goes below the lower limit but exceeds the lower limit within the alarm 2 delay time, then CH1 alarm 2 flag (XnA) will remain in the OFF status.



Figure 4.9 Time chart of the upper/lower limit alarm (alarm reset method = "auto-reset")

- (3) How to reset Alarm flag
 - 1)When Alarm flag is ON during the alarm occurrence or the self-retention (in the case of the alarm reset method = "self-retention"), Alarm flag can be reset (turned OFF) using Alarm reset request.
 - 2) How to reset Alarm flag during alarm occurrence (example of the upper limit alarm monitoring with CH1 alarm 1)
 - (a) If the measured value that was set with the alarm 1 item exceeds the upper limit, CH1 alarm 1 flag (Xn9) will turn ON. At the same time, ALM1 LED flashes.
 - (b) By turning CH1 alarm 1 reset request (Yn9) to ON, CH1 alarm 1 flag (Xn9) will turn OFF. At this time, ALM1 LED will remain flashing (because ALM1 LED is synchronized with the alarm status, it will not turn off).
 - (c) Check that CH1 alarm 1 flag (Xn9) becomes OFF, and then set CH1 alarm 1 reset request (Yn9) to OFF.
 - (d) If the measured value goes below the upper limit, ALM1 LED will turn off.
 - (e) After that, if the measured value exceeds the upper limit, CH1 alarm 1 flag (Xn9) will turn ON again. At the same time, ALM1 LED flashes.





3) How to reset Alarm flag during self-retention (in the case the alarm reset method = "self-retention" only)

Refer to the procedure described in (2) 1).

- (4) Precautions during the alarm monitoring
 - 1) When current demand time and electric power demand time are set to anytime except 0 second, current demand and electric power demand become lower than the actual values (closer to 0) immediately after the power source ON and the CPU reset. When current demand and electric power demand are being monitored for their lower limit, the alarm occurrence flag may turn ON. Thus, to avoid this from happening, follow the procedure below.
 - (a) Set the alarm monitoring target to "no monitoring" immediately after the power source ON and the CPU reset.
 - (b) After passing for a 3-times longer period than the demand time, set the alarm monitoring target again, and start the alarm monitoring.

4.2.5 Test function

This function is to output pseudo-fixed value to a buffer memory for debugging sequence program. The value can be output to the buffer memory without input of voltage and current.

- (1) How to use the test function
 - 1) Using the intelligent function module switch setting, you can start the test mode to output the fixed value.
 - 2) For procedure for the intelligent function module switch setting, refer to 8.6.2.
 - 3) To finish the test mode, the set value is returned by the intelligent function module switch setting, and after that, it enters to a normal operation by resetting it.
 - (It resumes with the previous set value, electric energy and periodic electric energy.)
- (2) Content of fixed-output

For the value to be output to the buffer memory, refer to Table 6.1 to 6.3 in 6.1 Buffer memory assignment.

- (3) LED display when using the test function All LED lights.
- (4) I/O signals when using the test functionUnit READY (Xn0) only ON. Other input and output signals are all OFF.
- (5) Precautions for using the test function

Because fixed-output is output to the buffer memory, isolate the actual device to avoid unexpected operation before running the sequence program.

4.2.6 Setting function for integrated value

This function is to set integrated value (electric energy (consumption, regeneration) and reactive energy (consumption lag)) to any value.

If you want to clear integrated value, set it to 0.

(1) Setting procedure

(a) Set CH1 integrated value setting target (Un\G51) in the buffer memory. Setting range is as follows:

Setting value				Description
CH1	CH2	CH3	All CHs	
0	0	0	0	No set
11	21	31	91	Electric energy (consumption)
12	22	32	92	Electric energy (regeneration)
13	23	33	93	Reactive energy (consumption lag)
19	29	39	99	Total integrated value

(b) Set CH1 integrated value setting value (Un\G52, 53) in the buffer memory.

- Configurable range: 0 to 999999999

- The unit used for the setting value is the same as that used for the electric energy and reactive energy that are output to the buffer memory.

For details, refer to section 6.3.1.

- (c) When Integrated value setting request (Yn3) is turned ON and preset of each integrated value such as electric energy (consumption), electric energy (regeneration), and reactive energy (consumption delay) is completed, Integrated value setting completion flag (Xn3) turns ON.
- (d) When Integrated setting request (Yn3) is turned OFF, Integrated value setting completion flag (Xn3) turns OFF.



Figure 4.11 Procedure for setting integrated value

(2) Default value

CH1 integrated value setting target (Un\G51) is set to 0 (No set). CH1 integrated value setting value (Un\G52, Un\G53) is set to 0.

Chapter 5: I/O signals for the CPU module

5.1 List of I/O signals

I/O signals of QE83WH4W are listed in Table 5.1.

Table 5.1 List of I/O signals			
Input signal (signal direction from QE83WH4W to CPU module)		Output signal (signal direction from CPU module to QE83WH4W)	
Device #	Signal name	Device #	Signal name
Xn0	Module ready	Yn0	Use prohibited ^{*1}
Xn1	Data acquisition clock	Yn1	Use prohibited ^{*1}
Xn2	Operating condition setting completion flag	Yn2	Operating condition setting request
Xn3	Integrated value set completion flag	Yn3	Integrated value set request
Xn4	Max./min. values clear completion flag	Yn4	Max./min. values clear request
Xn5	CH1 periodic electric energy 1 data completion flag	Yn5	CH1 periodic electric energy 1 measurement flag
Xn6	CH1 periodic electric energy 2 data completion flag	Yn6	CH1 periodic electric energy 2 measurement flag
Xn7	CH1 periodic electric energy 1 reset completion flag	Yn7	CH1 periodic electric energy 1 reset request
Xn8	CH1 periodic electric energy 2 reset completion flag	Yn8	CH1 periodic electric energy 2 reset request
Xn9	CH1 alarm 1 flag	Yn9	CH1 alarm 1 reset request
XnA	CH1 alarm 2 flag	YnA	CH1 alarm 2 reset request
XnB	CH2 periodic electric energy 1 data completion flag	YnB	CH2 periodic electric energy 1 measurement flag
XnC	CH2 periodic electric energy 2 data completion flag	YnC	CH2 periodic electric energy 2 measurement flag
XnD	CH2 periodic electric energy 1 reset completion flag	YnD	CH2 periodic electric energy 1 reset request
XnE	CH2 periodic electric energy 2 reset completion flag	YnE	CH2 periodic electric energy 2 reset request
XnF	CH2 alarm 1 flag	YnF	CH2 alarm 1 reset request
Xn10	CH2 alarm 2 flag	Yn10	CH2 alarm 2 reset request
Xn11	CH3 periodic electric energy 1 data completion flag	Yn11	CH3 periodic electric energy 1 measurement flag
Xn12	CH3 periodic electric energy 2 data completion flag	Yn12	CH3 periodic electric energy 2 measurement flag
Xn13	CH3 periodic electric energy 1 reset completion flag	Yn13	CH3 periodic electric energy 1 reset request
Xn14	CH3 periodic electric energy 2 reset completion flag	Yn14	CH3 periodic electric energy 2 reset request
Xn15	CH3 alarm 1 flag	Yn15	CH3 alarm 1 reset request
Xn16	CH3 alarm 2 flag	Yn16	CH3 alarm 2 reset request
Xn17	Use prohibited ^{*1}	Yn17	Use prohibited ^{*1}
Xn18	Use prohibited ^{*1}	Yn18	Use prohibited ^{*1}
Xn19	Use prohibited ^{*1}	Yn19	Use prohibited ^{*1}
Xn1A	Use prohibited ^{*1}	Yn1A	Use prohibited ^{*1}
Xn1B	Use prohibited ^{*1}	Yn1B	Use prohibited ^{*1}
Xn1C	Use prohibited ^{*1}	Yn1C	Use prohibited ^{*1}
Xn1D	Use prohibited ^{*1}	Yn1D	Use prohibited ^{*1}
Xn1E	Use prohibited ^{*1}	Yn1E	Use prohibited ^{*1}
Xn1F	Error flag	Yn1F	Error clear request

Table 5.1 List of I/O signals

Point

*1 These signals cannot be used by the user since they are for system use only. If these are set to on or off by the sequence program, the performance of the QE83WH4W cannot be guaranteed.

5.2 Details of I/O signals

Detailed explanation about I/O signals of QE81WH4W is provided as follows:

5.2.1 Input signals

- (1) Module ready (Xn0)
 - (a) When the power of CPU module is turned on or the CPU module reset is performed, it will turn ON as soon as the measurement is ready.
 - (b)This signal (Xn0) is turned OFF when energy measuring module displays a hardware error, and RUN LED is turned off.
- (2) Data acquisition clock (Xn1)
 - (a) When the power is supplied to the CPU module and immediately after the initial computation is performed, this signal (Xn1) is turned ON and count of the output period of data acquisition clock is started. After that, this signal turns ON at the timing when the measurement data is completely written into the buffer memory after the elapse of the output period of data acquisition clock.

If the settings of the primary voltage, primary current, and output period of data acquisition clock are changed, this signal turns ON immediately after the change of the settings and count of the output period of data acquisition clock is started.

- (b) This signal (Xn1) turns OFF 150 ms after it turns ON.
- (3) Operating condition setting completion flag (Xn2)
 - (a) When Operating condition setting request (Yn2) is turned ON, the following settings are changed and this signal (Xn2) turns ON.
 - Phase wire system (Un\G0)
 - Input voltage (Un\G1)
 - Primary current (Un\G2/1002/2002)
 - Current demand time (Un\G3/1003/2003)
 - Electric power demand time (Un\G4/1004/2004)
 - Primary voltage of VT (Un\G5)
 - Secondary voltage of VT (Un\G6)
 - Primary current of CT (Un\G7/1007/2007)
 - Alarm 1 item (Un\G11/1011/2011)
 - Alarm 1 value (Un\G12, 13/1012, 1013/2012, 2013)
 - Alarm 1 reset method (Un\G14/1014/2014)
 - Alarm 1 delay time (Un\G15/1015/2015)
 - Alarm 2 item (Un\G21/1021/2021)
 - Alarm 2 value (Un\G22, 23/1022, 1023/2022, 2023)
 - Alarm 2 reset method (Un\G24/1024/2024)
 - Alarm 2 delay time (Un\G25/1025/2025)
 - Output period of data acquisition clock (Un\G60, 61)
 - (b) When Operating condition setting request (Yn2) is turned OFF, this signal (Xn2) turns OFF.
- (4) Integrated value setting completion flag (Xn3)
 - (a) When Integrated value setting request (Yn3) is turned ON and set of each integrated value such as electric energy (consumption), electric energy (regeneration), and reactive energy (consumption delay) is completed, this signal (Xn3) turns ON.
 - (b) When Integrated value setting request (Yn3) is turned OFF, this signal (Xn3) turns OFF.
- (5) Max./min. values clear completion flag (Xn4)
 - (a) When Max./min. values clear request (Yn4) is turned ON and the data of max./min. value (maximum value, minimum value, and their date and time of occurrence) are cleared, this signal (Xn4) turns ON.
 - (b) When Max./min. values clear request (Yn4) is turned OFF, this signal (Xn4) turns OFF.
- (6) CH1 periodic electric energy 1 data completion flag (Xn5)
 - (a) When CH1 periodic electric energy 1 measurement flag (Yn5) is turned OFF and calculation of CH1 periodic electric energy 1 is stopped, this signal (Xn5) turns ON.
 - (b) When CH1 periodic electric energy 1 measurement flag (Yn5) is turned ON and calculation of CH1 periodic electric energy 1 is started, this signal (Xn5) turns OFF.
 - (c) In order to acquire the data under the condition where CH1 periodic electric energy 1 is checked after the accumulation of the periodic electric energy is stopped, obtain the data while this signal (Xn5) is ON.

*For specific usage procedures, refer to Section 4.2.2.

(7) CH1 periodic electric energy 2 data completion flag (Xn6)

The usage procedure is the same as that of CH1 periodic electric energy 1 data completion flag (Xn5). Refer to (6).

- (8) CH1 periodic electric energy 1 reset completion flag (Xn7)
 - (a) When CH1 periodic electric energy 1 reset request (Yn7) is turned ON and CH1 periodic electric energy 1 that is stored in the buffer memory is reset, this signal (Xn7) turns ON.
 - (b) When CH1 periodic electric energy 1 reset request (Yn7) is turned OFF, this signal (Xn7) turns OFF.

*For specific usage procedures, refer to Section 4.2.2.

- (9) CH1 periodic electric energy 2 reset completion flag (Xn8)
- The usage procedure is the same as that of CH1 periodic electric energy 1 reset completion flag (Xn7). Refer to (8).

(10)CH1 alarm 1 flag (Xn9)

- (a) If the measured value of CH1 alarm 1 item (Un\G11) exceeds the upper limit (or if it goes below the lower limit in the case of the lower alarm), after the elapse of CH1 alarm 1 delay time (Un\G15), this signal (Xn9) turns ON.
- (b) Operations after this signal (Xn9) is turned ON vary depending on the setting of CH1 alarm 1 reset method (Un\G14).
- [When CH1 alarm 1 reset method (Un\G14) is "0: self-retention"]

Even if the measured value of CH1 alarm 1 monitoring target goes below the upper limit (or if it exceeds the lower limit in the case of lower limit alarm), this signal (Xn9) remains ON. When CH1 alarm 1 reset request (Yn9) is turned ON, this signal (Xn9) turns OFF.

- [When CH1 alarm 1 reset method (Un\G14) is "1: auto reset"]
 - If the measured value of CH1 alarm 1 monitoring target goes below the upper limit (or it exceeds the lower limit in the case of lower limit alarm), this signal (Xn9) turns OFF.
- (c) When the measured value of the alarm 1 monitoring target is set to "not monitoring", this signal (Xn9) always turns OFF.

*For the actual behavior of alarm monitoring, refer to Section 4.2.4.

(11)CH1 alarm 2 flag (XnA)

The usage procedure is the same as that of CH1 alarm 1 flag (Xn9). Refer to (10).

- (12) Error flag (Xn1F)
 - (a) If an outside-set-value error occurs or a hardware error occurs, this signal (Xn1F) turns ON.
 - (b) The description of the error can be checked with latest error code (Un\G4500).

*For description of error codes, refer to Section 9.1.

(c) If an outside-set-value error occurs, this signal (Xn1F) is turned OFF by setting a value within the range again.

5.2.2 Output signals

- (1) Operating condition setting request (Yn2)
 - (a) When switching this request (Yn2) from the OFF status to the ON status, the following operating conditions will be set.
 - Phase wire system (Un\G0)
 - Input voltage (Un\G1)
 - Primary current (Un\G2/1002/2002)
 - Current demand time (Un\G3/1003/2003)
 - Electric power demand time (Un\G4/1004/2004)
 - Primary voltage of VT (Un\G5)
 - Secondary voltage of VT (Un\G6)
 - Primary current of CT (Un\G7/1007/2007)
 - Alarm 1 item (Un\G11/1011/2011)
 - Alarm 1 value (Un\G12, 13/1012, 1013/2012, 2013)
 - Alarm 1 reset method (Un\G14/1014/2014)
 - Alarm 1 delay time (Un\G15/1015/2015)
 - Alarm 2 item (Un\G21/1021/2021)
 - Alarm 2 value (Un\G22, 23/1022, 1023/2022, 2023)
 - Alarm 2 reset method (Un\G24/1024/2024)
 - Alarm 2 delay time (Un\G25/1025/2025)
 - Output period of data acquisition clock (Un\G60, 61)
 - (b) When the operating condition setting is completed, Operating condition setting completion flag (Xn2) turns ON.
 - (c) When this request (Yn2) is turned OFF, Operating condition setting completion flag (Xn2) turns OFF.
- (2) Integrated value setting request (Yn3)
 - (a) If you want to set the electric energy (consumption and regeneration) and the reactive energy to an arbitrary value, write Integrated value setting target (Un\G51) and Integrated value setting value (Un\G52, 53) into it, and after that, turn this request (Yn3) to ON.
 - (b) When switching this request (Yn3) from the OFF status to the ON status, the integrated value setting value will be set. When the integrated value setting is completed, Integrated value setting completion flag (Xn3) turns ON.
 - (c) When this request (Yn3) is set to OFF, Integrated value setting completion flag (Xn3) turns OFF.
- (3) Max./min. values clear request (Yn4)
 - (a) When the max./min. value data (max./min. value and their date/time of occurrence) is reset, this request (Yn4) turns ON.
 - (b) After writing max./min. values clear item (Un\G56), switching this request (Yn4) from the OFF status to the ON status will clear the max./min. values. When clearing the max./min. data is completed, Max./min. values clear completion flag (Xn4) turns ON.
 - (c) When this request (Xn4) is set to OFF, Max./min. values clear completion flag (Xn4) turns OFF.

- (4) CH1 periodic electric energy 1 measurement flag (Yn5)
 - (a) When switching this signal (Yn5) from the ON status to the OFF status, CH1 periodic electric energy 1 is measured and stored in the buffer memory.
 - (b) When this signal (Yn5) is turned OFF, CH1 periodic electric energy 1 data completion flag (Xn5) turns ON at the time that CH1 periodic electric energy 1 is checked for that period, and then CH1 periodic electric energy 1 is retained.
 - (c) In order to read the checked data of CH1 periodic electric energy 1 using the sequence program, use CH1 periodic electric energy 1 data completion flag (Xn5) as the interlock condition.

*For specific usage procedures, refer to Section 4.2.2.

(5) CH1 periodic electric energy 2 measurement flag (Yn6)

The usage procedure is the same as that of CH1 periodic electric energy 1 measurement flag (Yn5). Refer to (4).

- (6) CH1 periodic electric energy 1 reset request (Yn7)
 - (a) When this request (Yn7) is turned ON from the OFF status, CH1 periodic electric energy 1 reset completion flag (Xn7) turns ON, and CH1 periodic electric energy 1 that has been stored in the buffer memory is reset.
 - (b) Regardless of the status of CH1 periodic electric energy 1 measurement flag (Yn5), either OFF or ON, the periodic electric energy 1 can be reset using this request (Yn7). When CH1 periodic electric energy 1 measurement flag (Yn5) is ON, and the measurement is taking place, the measurement will resume immediately after the reset.
 - (c) When this request (Yn7) is set to OFF, CH1 periodic electric energy 1 reset completion flag (Xn7) turns OFF.

*For specific usage procedures, refer to Section 4.2.2.

(7) CH1 periodic electric energy 2 reset request (Yn8)

The usage procedure is the same as that of CH1 periodic electric energy 1 reset request (Yn7). Refer to (6).

- (8) CH1 alarm 1 reset request (Yn9)
 - (a) When CH1 alarm 1 flag (Xn9) is reset, this request (Yn9) turns ON. (b) When this request (Yn9) is switched from the OFF status to the ON status, CH1 alarm 1 flag (Xn9) will forcibly be turned OFF regardless of the present alarm occurrence status.
 - (b) Check that CH1 alarm 1 flag (Xn9) becomes OFF, and then set this request (Yn9) to OFF.
- (9) CH1 alarm 2 reset request (YnA)

The usage procedure is the same as that of CH1 periodic electric energy 1 reset request (Yn9). Refer to (8).

- (10) Error clear request (Yn1F)
 - (a) When switching this request (Yn1F) from the OFF status to the ON status while an outside-set-value error is present, Error flag (Xn1F) turns OFF, and the latest error code in the buffer memory (Un\G4500) will be cleared.
 - (b) At the same time as clearing the error above, the values that were set in the buffer memory below will be replaced with the previously set values, and integrated value setting target (Un\G51) and integrated value setting value (Un\G52, 53) will be reset to 0. [Set values to be replaced with the previously set values]
 - Phase wire system (Un\G0)
 - Input voltage (Un\G1)
 - Primary current (Un\G2/1002/2002)
 - Current demand time (Un\G3/1003/2003)
 - Electric power demand time (Un\G4/1004/2004)
 - Primary voltage of VT (Un\G5)
 - Secondary voltage of VT (Un\G6)
 - Primary current of CT (Un\G7/1007/2007)
 - Alarm 1 item (Un\G11/1011/2011)
 - Alarm 1 value (Un\G12, 13/1012, 1013/2012, 2013)
 - Alarm 1 reset method (Un\G14/1014/2014)
 - Alarm 1 delay time (Un\G15/1015/2015)
 - Alarm 2 item (Un\G21/1021/2021)
 - Alarm 2 value (Un\G22, 23/1022, 1023/2022, 2023)
 - Alarm 2 reset method (Un\G24/1024/2024)
 - Alarm 2 delay time (Un\G25/1025/2025)
 - Output period of data acquisition clock (Un\G60, 61)
 - (c) While a hardware error is present (error code: 0000h to 0FFFh), it will not be cleared even if this signal (Yn1F) turns ON.

Chapter 6: Buffer memory

6.1 Buffer memory assignment

The following describes buffer memory assignment.

Point

In the buffer memory, do not write data to the "system area" or area where data writing data from sequence programs is disabled. Doing so may cause malfunction.

(1) Configurable sections (CH1: Un\G0 to Un\G99, CH2: Un\G1000 to Un\G1099,

CH3: Un\G2000 to Un\G2099)

	Table 6.1 Configurable sections										
	Address		Data		Default	R/W		Output value during the			
ltem	([)ecima		Type	Description	Description value		Back up*1	test mode*2		
	CH1	CH2	CH3	Type		varue	varue		CH1	CH2	CH3
Setting		1000	2000					1			
value	—	S	S	—	System area			_		_	
		1001	2001		-						
		0		Pr	Phase wire system	4	R/W	0		4	
		1		Pr	Input voltage	101	R/W	0		101	
	2	1002	2002	Pr	Primary current	2	R/W	0	2	3	4
	3		2003	Pr	Current demand time	120	R/W	Ō	100	200	300
	4		2004	Pr	Electric power demand time	120	R/W	Ŏ	150	250	350
		5		Pr	Primary voltage of VT	0	R/W	Ŏ		0	
		6		Pr	Secondary voltage of VT	0	R/W	Õ		0	
	7	1007	2007	Pr	Primary current of CT	0	R/W	ŏ	0	0	0
	8		2008			v		<u> </u>	Ŭ	Ŭ	
	š	5	5	_	System area	_	_	l —		_	
	10		2010		- ,						
	11		2010	Pr	Alarm 1 item	0	R/W	0	1	3	5
	12		2012					T			
	13		2012	Pr	Alarm 1 value	0	R/W	0	1100	2100	3100
	14		2013	Pr	Alarm 1 reset method	0	R/W	0	0	1	0
	15		2014	Pr	Alarm 1 delay time	0	R/W	0	110	120	130
				FI		0	r///	0	110	120	130
	16 ≶		1016 2016 \$ \$		Sustam area						
		-			System area	_	_	-		_	
	20 1020 2020 21 1021 2021 Pr				0 R/W						
	21			Pr	Alarm 2 item	0	R/W	0	2	4	6
	22	1022	2022	Pr	Alarm 2 value	0	R/W	0	510	520	530
	23		2023							-	
	24		2024	Pr	Alarm 2 reset method	0	R/W	0	1	0	1
	25		2025	Pr	Alarm 2 delay time	0	R/W	0	210	220	230
	26		2026		_						
	S	S	S	—	System area	—	—	-		—	
	50		2053								
		51		Pr	Integrated value setting target	0	W			0	
		52		Dr		0	14/			0	
		53		Pr	Integrated value setting value	0	W	-		0	
	54		2054								
	54	1054	2004 \$		System area	l _		I _		_	
	, 55				Cystom area					_	
		Pr	Max (min values algoritan	0	W			0			
			PI	Max./min values clear item	0	٧V	<u> </u>		U		
	57 1057 2057 \$ \$ \$ 59 1061 2061			Suptom orga							
				System area	—	_	-		_		
	59		2061		output period of data			 			
		60		Pr		0	R/W	0		0	
	00	61	0000		acquisition clock			-			
	62		2062								
	S	S	S	—	System area	—	-	-		—	
	99 1099 2099		,								

Table 6.1 Configurable sections

*1 Even if the power failure is restored, data is held because data is backed up by the nonvolatile memory.

*2 For the procedure for using the test mode, refer to section 4.2.5.

(2) Measurement sections(CH1: Un\G100 to Un\G999, CH2: Un\G1100 to Un\G1999, CH3: Un\G2100 to Un\G2999)

	Addr	ess(De	cimal)	Data	Table 6.2 Measurement se	Default	R/		Output value during the		
Item	CH1	Type		value	Ŵ	Back up*	test mode*2 CH1 CH2 CH3				
Electric	100	1100	2100	Md	Multiplier of electric energy, reactive energy	-4	R		-4	-3	-2
energy	101	1101	2101		System area	_	_	_			
	102 103	1102 1103	2102 2103	Md	Electric energy (consumption)	0	R	0	1101000	1201000	1301000
	104 105	1104 1105	2104 2105	Md	Electric energy (regeneration)	0	R	0	1102000	1202000	1302000
	106 107	1106 1107	2106 2107	Md	Electric energy (consumption lag)	0	R	0	1103000	1203000	1303000
	108 \$ 113	1108 5 1113	2108 5 2113	_	System area			_		_	
	114 115	1114 1115	2114 2115	Md	Periodic electric energy1	0	R	0	1104000	1204000	1304000
	116 117	1116 1117	2116 2117	Md	Periodic electric energy2	0	R	0	1105000	1205000	1305000
	118 5 199	1118 5 1199	2118 5 2199		System area	_	_	_		—	
Current	200	1200	2200	Md	Multiplier of current	-3	R	_	-3	-3	-3
	201	1201	2201	—	System area	_					
	202 203	1202 1203	2202 2203	Md	1-phase current	0	R	—	210100	220100	230100
	204 205	1204 1205	2204 2205	Md	2-phase current	0	R	_	210200	220200	230200
	206 207	1206 1207	2206 2207	Md	3-phase current	0	R	_	210300	220300	230300
	208 209	1208 1209	2208 2209	Md	0-phase current	0	R	_	210400	220400	230400
	210 211	1210 1211	2210 2211	Md	1-phase current demand	0	R	_	210500	220500	230500
	212 213	1212 1213	2212 2213	Md	2-phase current demand	0	R	_	210600	220600	230600
	214 215	1214 1215	2214 2215	Md	3-phase current demand	0	R	-	210700	220700	230700
	216 217	1216 1217	2216 2217	Md	0-phase current demand	0	R	_	210800	220800	230800
	218 219	1218 1219	2218 2219	Md	Average current	0	R		210900	220900	230900
	220 221	1220 1221	2220 2221	Md	Maximum current demand	0	R	0	211000	221000	231000
	222	1222	2222	Md	Year of time of max.current	0	R	0	2001h	2002h	2003h
	223	1223	2223	Md	month and day of time of max. current demand	0	R	0	0101h	0102h	0103h
	224	1224	2224	Md	Hour and minute of time of max.current demand	0	R	0	1331h	1332h	1333h
	225	1225	2225	Md	Second and day of the week of time of max. current demand	0	R	0	3000h	3001h	3002h
	226 227	1226 1227	2226 2227	Md	Minimum current demand	0	R	0	211100	221100	231100
	228	1228		Md	Year of time of min.current	0	R	0	2006h	2007h	2008h
	229	1229	2229	Md	month and day of time of min. current demand	0	R	0	0206h	0207h	0208h
	230	1230	2230	Md	Hour and minute of time of min.current demand	0	R	0	1436h	1437h	1438h
	231	1231	2231	Md	Second and day of the week of time of min. current demand	0	R	0	3503h	3504h	3505h
	232 \$ 299	1232 5 1299	2232 \$ 2299		System area	_		_		_	

*1 Even if the power failure is restored, data is held because data is backed up by the nonvolatile memory.

*2 For the procedure for using the test mode, refer to section 4.2.5.

*3 The data becomes value at power on.

Table 6.2 Measurement sections	s (Un\G100 to Un\G2999) 2/3
--------------------------------	-----------------------------

Address(Decimal)		cimal)) Data		Default	R/	Back		value du	U	
Item I 1 1		Туре	Description	value	W	up*1		est mode*			
Voltage	300	1300	2300	Md	Multiplier of voltage	-3	R	-	CH1 -3	CH2 -3	CH3 -3
vollage	300	1300	2300		System area	-3			-3	-3	-3
	302	1302	2301								
	303	1303	2303	Md	1-2 line voltage	0	R	_	310100	320100	330100
	304	1304	2304	Md	2-3 line voltage	0	R	_	310200	320200	330200
	305	1305	2305	IVIU	2-3 lille voltage	0	Г		310200	320200	330200
	306	1306	2306	Md	3-1 line voltage	0	R	-	310300	320300	330300
	307	1307	2307	ina		Ŭ			010000	020000	000000
	308 309	1308 1309	2308 2309	Md	1-0 phase voltage	0	R	_	310400	320400	330400
	310	1310	2309				_				
	311	1311	2311	Md	2-0 phase voltage	0	R	—	310500	320500	330500
	312	1312	2312	Md	3-0 phase voltage	0	R	_	310600	320600	330600
	313			With	5-0 phase voltage	0			510000	320000	330000
	314	1314	2314	Md	Average value voltage (L-L)	0	R	_	310700	320700	330700
	315 316	1315 1316	2315 2316								
	317	1317	2310	Md	Average value voltage (L-N)	0	R	—	310800	320800	330800
	318	1318	2318								
	S	S	S	—	System area	—	—	—		_	
	319	1319	2319								-
	320	1320	2320	Md	Maximum value voltage (L-L)	0	R	0	310900	320900	330900
	321 322	1321	2321 2322	Md	Year of time of max.value voltage (L-L)	0	R	0	2011h	2012h	2013h
	322	1322 1323	2322	Md Md	Month and day of time of max. value voltage (L-L)	0	R	0	0311h	0312h	2013h 0313h
	324	1323	2323	Md	Hour and minute of time of max. value voltage (L-L)	0	R	0	1541h	1542h	1543h
	325	1325	2325	Md	Second and day of the week of time of max. value voltage	0	R	ŏ	4000h	4001h	4002h
	326	1326	2326	Md		0	R	0	311000	321000	331000
	327	1327	2327	IVIG	Minimum value voltage (L-L)						
	328	1328	2328	Md	Year of time of min.value voltage (L-L)	0	R	0	2016h	2017h	2018h
	329	1329	2329	Md	Month and day of time of min. value voltage (L-L)	0	R	0	0416h	417h	418h
	330	1330	2330	Md	Hour and minute of time of min. value voltage (L-L)	0	R	0	1646h	1647h	1648h
	331	1331	2331	Md	Second and day of the week of time of min. value voltage	0	R	0	4503h	4504h	4505h
	332	1332	2332	Md	Maximum value voltage (L-N)	0	R	0	311110	321110	331110
	333 334	1333 1334	2333 2334	Md Md	Year of time of max.value voltage (L-N)	0	R	0	2121h	2122h	2123h
	335	1335	2335	Md	Month and day of time of max. value voltage (L-N)	0	R	ŏ	0521h	0522h	0523h
	336	1336	2336	Md	Hour and minute of time of max. value voltage (L-N)	0	R	ŏ	1751h	1752h	1753h
	337	1337	2337	Md	Second and day of the week of time of max. value voltage	0	R	ŏ	5000h	5001h	5002h
	338	1338	2338	Md	Minimum value voltage (L-N)	0	R	0	311200	321200	331200
	339	1339	2339	Md	U ()			-			
	340	1340	2340	Md	Year of time of min.value voltage (L-N)	0	R	0	2026h	2027h	2028h
	341	1341	2341	Md	Month and day of time of min. value voltage (L-N)	0	R	0	0626h	0627h	0628h
	342	1342	2342	Md	Hour and minute of time of min. value voltage (L-N)	0	R	0	1856h	1857h	1858h
	343 344	1343 1332	2343 2332	Md	Second and day of the week of time of min. value voltage	0	R	0	5503h	5504h	5505h
	544	5	2332 \$		System area	_	_	_		_	
	399	1399	2399								
Electric	400	1400	2400	Md	Multiplier of electric power	-3	R	_	-3	-3	-3
power	401	1401	2401	_	System area	_	—	_		_	
	402			Md	Electric power	0	R	_	410100	420100	430100
	403	1403			· ·	-					
	404 405	1404 1405	2404 2405	Md	Electric power demand	0	R	—	410200	420200	430200
	405	1405	2405				<u> </u>				
	5	5	5	_	System area	_	—	_		_	
	419	1419	2419								
	420	1420	2420	Md	Maximum value of electric power demand	0	R	0	410300	420300	430300
	421	1421	2421		·	-					
	422	1422	2422	Md	Year of time of max.electric power demand	0	R	0	2031h	2032h	2033h
		423 1423 2423 Md Month and day of time of max. electric power demand			R	0	0701h	0702h	0703h		
	423								10016		1903h
	423 424	1424	2424	Md	Hour and minute of time of max. electric power demand	0	R	0	1901h	1902h	
	423				Hour and minute of time of max. electric power demand Second and day of the week of time of max. electric power				1901h 0000h	0001h	0002h
	423 424 425	1424 1425	2424 2425	Md Md	Hour and minute of time of max. electric power demand Second and day of the week of time of max. electric power demand	0	R R	0	0000h	0001h	
	423 424	1424	2424	Md	Hour and minute of time of max. electric power demand Second and day of the week of time of max. electric power	0	R	0			
	423 424 425 426	1424 1425 1426	2424 2425 2426 2427	Md Md	Hour and minute of time of max. electric power demand Second and day of the week of time of max. electric power demand	0 0 0	R R R R	0 0 0	0000h	0001h	
	423 424 425 426 427 428 429	1424 1425 1426 1427 1428 1429	2424 2425 2426 2427 2428 2429	Md Md Md Md Md	Hour and minute of time of max. electric power demand Second and day of the week of time of max. electric power demand Minimum value of electric power demand Year of time of min.electric power demand Month and day of time of min. electric power demand	0 0 0 0 0	R R R R	0 0 0 0 0	0000h 410400 2036h 0806h	0001h 420400 2037h 0807h	430400 2038h 0808h
	423 424 425 426 427 428	1424 1425 1426 1427 1428	2424 2425 2426 2427 2428 2429	Md Md Md Md	Hour and minute of time of max. electric power demand Second and day of the week of time of max. electric power demand Minimum value of electric power demand Year of time of min.electric power demand Month and day of time of min. electric power demand Hour and minute of time of min. electric power demand	0 0 0	R R R R	0 0 0	0000h 410400 2036h	0001h 420400 2037h	430400 2038h
	423 424 425 426 427 428 429	1424 1425 1426 1427 1428 1429 1430	2424 2425 2426 2427 2428 2429 2430	Md Md Md Md Md	Hour and minute of time of max. electric power demand Second and day of the week of time of max. electric power demand Minimum value of electric power demand Year of time of min.electric power demand Month and day of time of min. electric power demand Hour and minute of time of min. electric power demand Second and day of the week of time of min. electric power	0 0 0 0 0	R R R R		0000h 410400 2036h 0806h 2106h	0001h 420400 2037h 0807h 2107h	430400 2038h 0808h 2108h
	423 424 425 426 427 428 429 430 431	1424 1425 1426 1427 1428 1429 1430	2424 2425 2426 2427 2428 2429 2430 2431	Md Md Md Md Md Md	Hour and minute of time of max. electric power demand Second and day of the week of time of max. electric power demand Minimum value of electric power demand Year of time of min.electric power demand Month and day of time of min. electric power demand Hour and minute of time of min. electric power demand	0 0 0 0 0 0	R R R R R R	0 0 0 0 0	0000h 410400 2036h 0806h	0001h 420400 2037h 0807h	430400 2038h 0808h
	423 424 425 426 427 428 429 430 431 432	1424 1425 1426 1427 1428 1429 1430 1431 1431	2424 2425 2426 2427 2428 2429 2430 2431 2431	Md Md Md Md Md Md	Hour and minute of time of max. electric power demand Second and day of the week of time of max. electric power demand Minimum value of electric power demand Year of time of min.electric power demand Month and day of time of min. electric power demand Hour and minute of time of min. electric power demand Second and day of the week of time of min. electric power demand	0 0 0 0 0 0	R R R R R R		0000h 410400 2036h 0806h 2106h	0001h 420400 2037h 0807h 2107h	430400 2038h 0808h 2108h
	423 424 425 426 427 428 429 430 431	1424 1425 1426 1427 1428 1429 1430 1431 1432 \$	2424 2425 2426 2427 2428 2429 2430 2431	Md Md Md Md Md Md	Hour and minute of time of max. electric power demand Second and day of the week of time of max. electric power demand Minimum value of electric power demand Year of time of min.electric power demand Month and day of time of min. electric power demand Hour and minute of time of min. electric power demand Second and day of the week of time of min. electric power	0 0 0 0 0 0	R R R R R R		0000h 410400 2036h 0806h 2106h	0001h 420400 2037h 0807h 2107h	430400 2038h 0808h 2108h

*1 Even if the power failure is restored, data is held because data is backed up by the nonvolatile memory.

 *2 For the procedure for using the test mode, refer to section 4.2.5.

*3 The data becomes value at power on.

	Addre		cimal)	Data		Default	t R/	Back	Output value during the		
Item		•			Description	Description value	W	up*1	test mode*2 CH1 CH2 CH3		
Depetive	CH1 500	CH2	2500	Md	Multiplier of reactive power	-3	R	-F -	-3	CH2	CH3
Reactive	500		2500		System area	-3	ĸ		-3	-3	-3
power	502				Cystem area						
	503		2502	Md	Reactive power	0	R	—	510100	520100	530100
	504		2504								
	S	S	S	—	System area	—		—		_	
	599	1599	2599								
Apparent	600		2600	Md	Multiplier of apparent power	-3	R		-3	-3	-3
power	601			—	System area	—		—			
	602		2602	Md	Apparent power	0	R	_	610100	620100	630100
Power	603 700	1603	2603 2700	Md	Multiplier of power factor	-3	R		-3	-3	-3
factor	700	1700	2700		System area	-3	<u>к</u>		-3	-3	-3
Tactor	702	1702	2701								
	703	1703	2703	Md	Power factor	0	R	—	710100	720100	730100
		1704									
	S	S	S	—	System area	—	—	—		—	
		1719									
	720		2720	Md	Maximum power factor	0	R	0	710200	720200	730200
	721		2721		•			_			
	722	1722	2722	Md	Year of time of max. power factor	0	R	0	2041h	2042h	2043h
	723	1723	2723	Md	Month and day of time of max. power	0	R	0	0911h	0912h	0913h
					factor Hour and minute of time of max.						
	724	1724	2724	Md	power factor	0	R	0	2211h	2212h	2213h
					Second and day of the week of time			-			
	725	1725	2725	Md	of max. power factor	0	R	0	1000h	1001h	1002h
	726	1726	2726	N.4L		0	-		740000	700000	700000
	727	1727	2727	Md	Minimum power factor	0	R	0	710300	720300	730300
	728	1728	2728	Md	Year of time of min. power factor	0	R	0	2046h	2047h	2048h
	729	1720	2729	Md	Month and day of time of min. power	0	R	0	1016h	1017h	1018h
	123	1723	2123	IVIC	factor	0	IX.	0	101011	101711	101011
	730	1730	2730	Md	Hour and minute of time of min.	0	R	0	2316h	2317h	2318h
	100		2100	ina	power factor	Ű		0	201011	201111	201011
	731	1731	2731	Md	Second and day of the week of time	0	R	0	1503h	1504h	1505h
	732	1732	2732		of min. power factor			-			
	132	1732	2132		System area			_		_	
	, 799		, 2799								
Frequenc	800		2800	Md	Multiplier of frequency	-3	R	_	-3	-3	-3
	801		2801		System area						
	802	1802	2802	Md	Frequency	0	R	_	810100	820100	830100
	803	1803	2803	With		5	1		510100	520100	555100
	804		2804		Culatera energi						
	\$	\$ 1000	\$ 2000	—	System area	—	-	—		_	
999 1999 2999							l				

Table 6.2 Measurement sections	(Un\G100 to Un\G2999)) 3/3
--------------------------------	-----------------------	-------

*1 Even if the power failure is restored, data is held because data is backed up by the nonvolatile memory.

*2 For the procedure for using the test mode, refer to section 4.2.5.

*3 The data becomes value at power on.

(3) Common sections (Un\G4500 to Un\G4999)

Item	Address (Decimal) CH1 CH2 CH3	Data Type	Description	Default value	R/W	Back up*1	Output value during the test mode*2 CH1 CH2 CH3
Error	4500		Latest error code		R		
2/10/	4501		Year of time of error		R		2051h
	4502		Month and day of time of error	_	R	_	1130h
	4503		Hour and minute of time of error	_	R	_	0059h
	4504		Second and day of the week of time of error	—	R		5906h
	4505~4999	_	System area	_			_

Table 6.3 Common sections (Un\G4500 to Un\G4999)

*1 Even if the power failure is restored, data is held because data is backed up by the nonvolatile memory.

*2 For the procedure for using the test mode, refer to section 4.2.5.

6.2 Configurable sections (CH1: Un\G0 to Un\G99, CH2: Un\G1000 to Un\G1099,

CH3: Un\G2000 to Un\G2099)

6.2.1 Phase wire system (Un\G0)

Phase wire system for target electric circuits is configured. This setting is common to all channels. Do not change the set value from the default value of 4. Because this product is a three-phase four-wire dedicated product.

6.2.2 Input voltage (Un\G1), Primary voltage of VT (Un\G5), Secondary voltage of VT (Un\G6)

Input voltage (Un\G1): set the Input voltage to the voltage transform unit. This setting is common to all channels.

Primary voltage of VT (Un\G5): when use for primary voltage of voltage transformer that is not in the input voltage (Un\G1) setting, set the voltage of the primary side of voltage transformer.

Secondary voltage of VT (Un\G6): when use for primary voltage of voltage transformer that is not in the input voltage (Un\G1) setting, set the voltage of the secondary side of voltage transformer.

(1) Setting procedure

(a) Set the Input voltage in the buffer memory. Setting range is as follows:

When set other than "101 to 116" the value of this setting, set to "0:any set" this setting, and set primary / secondary voltage of VT (Un\G5 / Un\G6).

When the value of this setup is set as "101 to 116", primary/ secondary voltage of VT are disabled.

··· -				
	Input voltag	ge (Un\G1)	Primary voltage of	Secondary voltage
	Setting value	Description	VT (Un\G5)	of VT (Un\G6)
	0	Any setting	1 - 6600	1 - 220
	101	63.5/110 V		
	102	100/173 V		
	103	105/182 V		
	104	110/190 V		
	105	115/199 V		
	106	120/208 V		
	107	127/220 V	0 0000	0 000
	108	200/346 V	0 – 6600 (However, this	0 – 220 (However, this
	109	220/380 V	setting is disabled)	setting is disabled)
	110	230/400 V	setting is disabled)	setting is disabled)
	111	240/415 V		
	112	242/420 V		
	113	250/430 V		
	114	254/440 V		
	115	265/460 V		
	116	277/480 V		

- (b) Turn Operating condition setting request (Yn2) from OFF to ON to enable the setting. (Refer to 5.2.2 (1).)
- (2) Default value

It is set to 63.5/110 V (101).

- 6.2.3 CH1 primary current (Un\G2), CH1 primary current of CT (Un\G7)
 - •CH1 primary current (Un\G2): set the primary current of the target electric circuit.
 - •CH1 primary current of CT (Un\G7): when use for primary current of current transformer that is not in the CH1 primary current (Un\G2) setting, set the current of the primary side of current transformer.
 - (1) Setting procedure
 - (a) Set the primary current in the buffer memory. Setting range is as follows: Please choose the settings to match the current sensor to be used.

When set other than "1 to 5, 501 to 536" the value of this setting, set to "0: any set" this setting, and set primary current of CT (Un\G7).

When the value of this setup is set as "1 to 5, 501 to 536", primary current of CT is disabled.

CH1 primary cu	rrent	CT1 primary current of CT	Current sensor	
Setting value	Description		Current Sensor	
0	Any setting	1 - 6600	EMU2-CT5	
1	50A		EMU-CT50	
2	100A		EMU-CT100	
3	250A		EMU-CT250	
4	400A		EMU-CT400	
5	600A		EMU-CT600	
501	5/5A			
502	6/5A			
503	7.5/5A			
504	8/5A			
505	10/5A			
506	12/5A			
507	15/5A			
508	20/5A	1 – 6600		
509	25/5A	(However, this setting is		
510	30/5A	disabled)		
511	40/5A		EMU2-CT5	
512	50/5A		EMO2-CT5	
513	60/5A			
514	75/5A			
515	80/5A			
516	100/5A			
517	120/5A			
518	150/5A			
519	200/5A			
520	250/5A			
521	300/5A			
522	400/5A			

6 Buffer memory

QE83WH4W

CH1 primary cu	rrent	CT1 primory ourrest of CT	Current concor
Setting value	Description	CT1 primary current of CT	Current sensor
523	500/5A		
524	600/5A		
525	750/5A		
526	800/5A		
527	1000/5A		
528	1200/5A		
529	1500/5A	1 – 6600	EMU2-CT5
530	1600/5A	(However, this setting is disabled)	EWI02-C15
531	2000/5A		
532	2500/5A		
533	3000/5A		
534	4000/5A		
535	5000/5A		
536	6000/5A		

(b) Turn Operating condition setting request (Yn2) from OFF to ON to enable the setting. (Refer to 5.2.2 (1).)

(2) Default value It is set to 100 A (2). 6.2.4 CH1 current demand time (Un\G3)

Set a time duration for which the average fluctuation of current demand is measured from the measured current value.

If current demand time is set short, the response to change of current will be quick; however, the fluctuation range may be too large. Adjust the duration according to the load and purposes.

- (1) Setting procedure
 - (a) Set current demand time in the buffer memory.
 - Configurable range: 0 to 1800 (seconds)
 - Set the value in seconds.
 - (b) Turn Operating condition setting request (Yn2) from OFF to ON to enable the setting. (Refer to 5.2.2 (1).)
- (2) Default value It is set to 120 seconds.
- 6.2.5 CH1 electric power demand time (Un\G4)

Set a time duration for which the average fluctuation of electric power demand is measured from the measured power value.

If electric power demand time is set short, the response to change of power will be quick; however, the fluctuation range may be too large. Adjust the duration according to the load and purposes.

- (1) Setting procedure
 - (a) Set electric power demand time in the buffer memory.
 - Configurable range: 0 to 1800 (seconds)
 - Set the value in seconds.
 - (b) Turn Operating condition setting request (Yn2) from OFF to ON to enable the setting. (Refer to 5.2.2 (1).)
- (2) Default value

It is set to 120 seconds.

6.2.6 CH1 alarm 1 item (Un\G11), CH1 alarm 2 item (Un\G21)

Set which measuring item will be monitored for the upper/lower limit alarm. Alarm 1 and 2 operate independen

- (1) Setting procedure
 - (a) Set the item for alarm 1 and 2 in the buffer memory. Setting range is as follows:

Setting value	Description
0	No monitoring
1	Current demand upper limit
2	Current demand lower limit
3	Voltage (L-L) upper limit
4	Voltage (L-L) lower limit
5	Electric power demand upper limit
6	Electric power demand lower limit
7	Power factor upper limit
8	Power factor lower limit
9	Voltage (L-N)upper limit
10	Voltage (L-N)lower limit

(b) Measuring items for the monitoring target are as follows:

Description	Measuring item of monitoring target
Current demand upper limit	1-phase current demand 2-phase current demand 3-phase current demand Neutral current demand *1
Current demand lower limit	1-phase current demand 2-phase current demand 3-phase current demand *1
Voltage (L-L) upper limit Voltage (L-L) lower limit	Voltage V12 Voltage V23 Voltage V31 *1
Electric power demand upper limit Electric power demand lower limit	Electric power demand
Power factor upper limit Power factor lower limit	Power factor *2
Voltage (L-N) upper limit Voltage (L-N) lower limit	Voltage V1N Voltage V2N Voltage V3N *1

*1 When multiple number of measuring items are targeted for monitoring, the alarm judgment condition will be as following.

	Alarm judgment conditions				
Upper/lower limits	Condition for occurrence	Condition for			
	Condition for occurrence	non-occurrence			
Current demand upper limit Line voltage upper limit Voltage (L-N) upper limit	Any one of alarm item exceeds the alarm value.	All alarm item go below the alarm value.			
Current demand lower limit Line voltage lower limit Voltage (L-N) lower limit	Any one of alarm item go below the alarm value	All alarm item exceeds the alarm value			

*2 The idea of upper and lower for PF upper /lower limit judgment is shown below.



- (c) Turn Operating condition setting request (Yn2) from OFF to ON to enable the setting. (Refer to 5.2.2 (1).)
- (2) Default value

It is set to not monitoring (0).

6.2.7 CH1 alarm 1 value (Un\G12, 13), CH1 alarm 2 value (Un\G22, 23)

Set the upper/lower limit monitoring value for the target that was set in alarm 1 item and alarm 2 item.

- (1) Setting procedure
 - (a) Set the monitoring values for alarm 1 and 2 in the buffer memory.
 - Configurable range: -2147483648 to 2147483647
 - The unit of the setting value is the same as below which was used for the measuring value of the monitored target configured in alarm 1 item and alarm 2 item.

Alarm 1 item Alarm 2 item	Unit of alarm 1 value and alarm 2 value
Current demand upper limit Current demand lower limit	×10 ⁻³ A
Voltage (L-L) upper limit Voltage (L-L) lower limit	×10 ⁻³ V
Electric power demand upper limit Electric power demand lower limit	W (×10 ⁻³ kW)
Power factor upper limit Power factor lower limit	×10 ⁻³ %
Voltage (L-N) upper limit Voltage (L-N) lower limit	×10 ⁻³ V

- (b) Turn Operating condition setting request (Yn2) from OFF to ON to enable the setting.
- (2) Default value

It is set to 0.

6.2.8 CH1 alarm 1 reset method (Un\G14), CH1 alarm 2 reset method (Un\G24)

Set the reset method of the alarm1 and alarm 2.

For differences in behavior of alarm monitoring for different reset methods, refer to 4.2.4 (2).

- (1) Setting procedure
 - (a) Set the reset method for alarm 1 and 2 in the buffer memory. Setting range is as follows:

Setting value	Description
0	Self-retention
1	Auto reset

- (b) Turn Operating condition setting request (Yn2) from OFF to ON to enable the setting.
- (2) Default value

It is set to self retention (0).

6.2.9 CH1 alarm 1 delay time (Un\G15), CH1 alarm 2 delay time (Un\G25)

Set the alarm delay time for the alarm 1 and alarm 2.

Alarm delay time means a grace period that takes from the moment when it exceeds the upper limit or goes under the lower limit of the alarm 1 value or alarm 2 value until the alarm flag is turned ON. For detailed behavior, refer to 4.2.4 (2).

- (1) Setting procedure
 - (a) Set the delay time for alarm 1 and alarm 2 in the buffer memory.
 - Configurable range: 0 to 300 (seconds)
 - Set the value in seconds.
 - (b) Turn Operating condition setting request (Yn2) from OFF to ON to and enable the setting.
- (2) Default value

It is set to 0 seconds.

6.2.10 Integrated value setting target (Un\G51), Integrated value setting value (Un\G52, 53)

- (1) Setting procedure
 - (a) Set the integrated value setting target in the buffer memory. Setting range is as follows:

Setting	Setting value			
CH1	CH2	CH3	All	Description
			CHs	
0	0	0	0	No set
11	21	31	91	Electric energy (consumption)
12	22	32	92	Electric energy (regeneration)
13	23	33	93	Reactive energy (consumption lag)
19	29	39	99	Total integrated value

- (b) Set the integrated value setting value in the buffer memory.
 - Configurable range: 0 to 999999999
 - The unit used for the setting value is the same as that used for the electric energy and reactive energy that are output to the buffer memory.

For details, refer to section 6.3.1.

- (c) Turn Integrated value setting request (Yn3) from OFF to ON to enable* the setting.
- (2) Default value

It is set to 0.

6.2.11 Max./min. values clear item (Un\G56)

Select the max./min. values you want to clear.

- (1) Setting procedure
 - (a) Set max./min values clear item (Un\G56) in the buffer memory.
 - Setting range is as follows:

Setting	Setting value					
CH1	CH2	СНЗ	All	Description		
			CHs			
0	0	0	0	No clear		
11	21	31	91	Current demand		
12	22	32	92	Voltage		
13	23	33	93	Electric power demand		
14	24	34	94	Power factor		
19	29	39	99	All items		

- (b) Turn Max./min. values clear request (Yn4) from OFF to ON to enable the setting.
- (2) Default value

It is set to 0 (No clear).

- 6.2.12 Output period of data acquisition clock (Un\G60, 61)
 - Set the output period of Data acquisition clock (Xn1). This setting is common to all channels.
 - (1) Setting procedure
 - (a) Set output period of data acquisition clock (Un\G60, 61) in the buffer memory.
 - Configurable range: 0 to 86400000 (ms)
 - *When the output period of data acquisition clock is set to 0, Data acquisition clock (Xn1) is always OFF.
 - (b) Because the data update interval is 500 ms, Data acquisition clock (Xn1) runs every 500 ms. Note that the output period of data acquisition clock is not a multiple of 500 ms, Data acquisition clock turns ON at the time of the first data update after the elapse of the output period of data acquisition clock.

<Example> When the output period of data acquisition clock is 1600 ms:

Measurement data update count = 1600 ms/500 ms = quotient 3 + remainder 100

ms

Thus, the input device (Xn1) turns ON once in every four times the measurement data is updated.

As a result, it is same as the case where the output period of data acquisition clock is 2000 ms.

- (c) Turn Operating condition setting request (Yn2) from OFF to ON to enable the setting.
- (2) Default value

It is set to 0 (ms).

6.3 Measurement sections(CH1: Un\G100 to Un\G999, CH2: Un\G1100 to Un\G1999, CH3: Un\G2100 to Un\G2999)

6.3.1 Multiplier of CH1 electric energy (Un\G100)

Multiplier of electric energy are stored. As to how the multiplier is determinate, refer to section 4.2.1 (3).

- (1) Details of stored data
 - (a) Storage format

Data are stored as 16-bit signed binary in the buffer memory.

- Data range: -5 to -1
- (b) Update timing

It will be updated when input voltage (Un\G1), primary current (Un\G2), and primary voltage of VT (Un\G5) are set.

6.3.2 CH1 electric energy (consumption) (Un\G102, 103), CH1 electric energy (regeneration) (Un\G104,105)

Stores the electric energy of the consumption side and the regeneration side will be stored.

- (1) Details of stored data
 - (a) Storage format
 - Data are stored as double-word 32-bit signed binary in the buffer memory.

- Data range: 0 to 999999999

*For restrictions for measured data including resolution and measuring range, refer to section 4.2.1.

(b) Unit

Unit can be determined by multiplier of CH1 electric energy (Un\G100), as shown below.

Multiplier of CH1 electric energy (Un\G100)	Unit
-5	×10 ⁻⁵ kWh
-4	×10 ⁻⁴ kWh
-3	×10 ⁻³ kWh
-2	×10 ⁻² kWh
-1	×10 ⁻¹ kWh

(c) Update timing

6.3.3 CH1 reactive energy (consumption lag) (Un\G106, 107)

Delayed consumption of the reactive energy is stored.

- (1) Details of stored data
 - (a) Storage format

Data are stored as double-word 32-bit signed binary in the buffer memory.

- Data range: 0 to 999999999

*For restrictions for measured data including resolution and measuring range, refer to section 4.2.1.

(b) Unit

Unit can be determined by the electric energy and the multiplier of the reactive energy (Un\G100), as shown below.

Electric energy, multiplier of the reactive energy (Un\G100)	Unit
-5	×10 ⁻⁵ kvarh
-4	×10 ⁻⁴ kvarh
-3	×10 ⁻³ kvarh
-2	×10 ⁻² kvarh
-1	×10 ⁻¹ kvarh

(c) Update timing

It will be updated every measuring cycle (500 ms).

6.3.4 CH1 periodic electric energy 1 (Un\G114, 115), CH1 periodic electric energy 2 (Un\G116, 117)

Stores the periodic electric energy 1 and periodic electric energy 2. The periodic electric energy of the consumption side is measured.

For specific usage procedures for the periodic electric energy, refer to section 4.2.2.

- (1) Details of stored data
 - (a) Storage format

Data are stored as double-word 32-bit signed binary in the buffer memory.

- Data range: 0 to 999999999

*For restrictions for measured data including resolution and measuring range, refer to section 4.2.1.

(b) Unit

Unit can be determined by the electric energy and the multiplier of the reactive energy (Un\G100), as shown below.

Electric energy, multiplier of the reactive energy (Un\G100)	Unit
-5	×10 ⁻⁵ kWh
-4	$\times 10^{-4}$ kWh
-3	×10 ⁻³ kWh
-2	×10 ⁻² kWh
-1	×10 ⁻¹ kWh

(c) Update timing

6.3.5 Multiplier of CH1 electric current (Un\G200)

The multiplier of the electric current is stored.

- (1) Details of stored data
 - (a) Storage format
 Data are stored as 16-bit signed binary in the buffer memory.
 Data range: -3 (fixed)
 - (b) Update timing Because it is fixed at -3, there is no update.
- 6.3.6 CH1 1-phase current (Un\G202, 203), CH1 2-phase current (Un\G204, 205), CH1 3-phase current (Un\G206, 207), CH1 0-phase current (Un\G208, 209)

The electric current (effective value) of each phase is stored.

(1) Details of stored data

(a) Storage format

Data are stored as double-word 32-bit signed binary in the buffer memory.

- Data range: 0 to 99999999 (0 to 99999.999 A)

*For restrictions for measured data including resolution and measuring range, refer to section 4.2.1.

(b) Unit

 $\times 10^{-3}$ A *Unit is fixed.

(c) Update timing

It will be updated every measuring cycle (500 ms).

6.3.7 CH1 1-phase current demand (Un\G210, 211), CH1 2-phase current demand (Un\G212, 213), CH1 3-phase current demand (Un\G214, 215), CH1 0-phase current demand (Un\G216, 217)

Stores the electric current (effective value) at each phase that is measured based on the moving average for the duration of time configured in the electric current demand time (Un\G3).

(1) Details of stored data

(a) Storage format

Data are stored as double-word 32-bit signed binary in the buffer memory.

- Data range: 0 to 99999999 (0 to 99999.999 A)

*For restrictions for measured data including resolution and measuring range, refer to section 4.2.1.

(b) Unit

 $\times 10^{-3}$ A *Unit is fixed.

(c) Update timing

6.3.8 CH1 average current (Un\G218, 219)

Stores the average current.

For procedure for storing the average current, refer to section 4.2.1 (2).

- (1) Details of stored data
 - (a) Storage format

Data are stored as double-word 32-bit signed binary in the buffer memory.

- Data range: 0 to 99999999 (0 to 99999.999 A)

*For restrictions for measured data including resolution and measuring range, refer to section 4.2.1.

(b) Unit

 $\times 10^{-3}$ A *Unit is fixed.

(c) Update timing

It will be updated every measuring cycle (500 ms).

6.3.9 CH1 maximum current demand (Un\G220, 221), CH1 minimum current demand (Un\G226,227)

Stores the max./min. values of the electric current demand among phases. For procedure for storing the max./min. the electric current demand, refer to section 4.2.1 (2).

(1) Details of stored data

(a) Storage format

Data are stored as double-word 32-bit signed binary in the buffer memory.

- Data range: 0 to 99999999 (0 to 99999.999 A)

*For restrictions for measured data including resolution and measuring range, refer to section 4.2.1.

(b) Unit

 $\times 10^{-3}$ A *Unit is fixed.

(c) Update timing

It will be updated every measuring cycle (500 ms) if it exceeds the current max. value or goes under the current min. value.

6.3.10 Year of time of CH1 max. current demand (Un\G222),

month and day of time of CH1 max. current demand (Un\G223), hour and minute of time of CH1 max. current demand (Un\G224), second and day of the week of time of CH1 max. current demand (Un\G225), year of time of CH1 min. current demand (Un\G228), month and day of time of CH1 min. current demand (Un\G229), hour and minute of time of CH1 min. current demand (Un\G230), second and day of the week of time of CH1 min. current demand (Un\G231)

Stores year, month, day, hour, minute, second, and day of the week of time when CH1 max. current demand (Un\G220, 221) and CH1 min. current demand (Un\G226, 227) were updated.

- (1) Details of stored data
 - (a) Storage format

As indicated below, data are stored as BCD code in the buffer memory.



(b) Update timing

It will be updated every measuring cycle (500 ms) if it exceeds the current max. value or goes under the current min. value.

6.3.11 Multiplier of CH1 electric voltage (Un\G300)

The multiplier of the electric voltage is stored.

- (1) Details of stored data
 - (a) Storage format
 Data are stored as 16-bit signed binary in the buffer memory.
 Data range: -3 (fixed)
 - (b) Update timing Because it is fixed at -3, there is no update.
- 6.3.12 CH1 voltage between 1 and 2 wires (Un\G302, 303), CH1 voltage between 2 and 3 wires (Un\G304, 305), CH1 voltage between 3 and 1 wires (Un\G306, 307)

The electric voltage between every combination of wires (effective value) is stored.

- (1) Details of stored data
 - (a) Storage format
 - Data are stored as double-word 32-bit signed binary in the buffer memory.
 - Data range: 0 to 99999999 (0 to 99,999.999 V)

*For restrictions for measured data including resolution and measuring range, refer to section 4.2.1.

(b) Unit

 $\times 10^{-3}$ V *Unit is fixed.

(c) Update timing

It will be updated every measuring cycle (500 ms).

6.3.13 CH1 voltage V1N (Un\G308, 309), CH1 voltage V2N (Un\G310, 311),

CH1 voltage V3N (Un\G312, 313)

Stores the phase voltage.

- (1) Details of stored data
 - (a) Storage format

Data are stored as double-word 32-bit signed binary in the buffer memory.

- Data range: 0 to 99999999 (0 to 99,999.999 V)

*For restrictions for measured data including resolution and measuring range, refer to section 4.2.1.

(b) Unit

 $\times 10^{-3}$ V *Unit is fixed.

(c) Update timing

6.3.14 CH1 average value voltage (L-L) (Un\G314, 315), CH1 average value voltage (L-N) (Un\G316, 317)

Stores the average line voltage and the average phase voltage.

For procedure for storing the average voltage using phase wire system, refer to 4.2.1 (2).

- (1) Details of stored data
 - (a) Storage format

Data are stored as double-word 32-bit signed binary in the buffer memory.

- Data range: 0 to 99999999 (0 to 99,999.999 V)

*For restrictions for measured data including resolution and measuring range, refer to section 4.2.1.

(b) Unit

 $\times 10^{-3}$ V *Unit is fixed.

(c) Update timing

It will be updated every measuring cycle (500 ms).

6.3.15 CH1 maximum value voltage (L-L) (Un\G320, 321), CH1 minimum value voltage (L-L) (Un\G326, 327) CH1 maximum value voltage (L-N) (Un\G332, 333), CH1 minimum value voltage (L-N) (Un\G338, 339)

Stores the max./min. values of the voltage among in-between wires and phases. For procedure for storing the max./min. voltage, refer to section 4.2.1 (2).

- (1) Details of stored data
 - (a) Storage format

Data are stored as double-word 32-bit signed binary in the buffer memory.

- Data range: 0 to 99999999 (0 to 99,999.999 V)

*For restrictions for measured data including resolution and measuring range, refer to section 4.2.1.

(b) Unit

 $\times 10^{-3}$ V *Unit is fixed.

(c) Update timing

It will be updated every measuring cycle (500 ms) if it exceeds the current max. value or goes under the current min. value.

6.3.16 Year of time of CH1 max. voltage (L-L) (Un\G322), month and day of time of CH1 max. voltage (L-L) (Un\G323), hour and minute of time of CH1 max. voltage (L-L) (Un\G324), second and day of the week of time of CH1 max. voltage (L-L) (Un\G325), year of time of CH1 min. voltage (L-L) (Un\G328), month and day of time of CH1 min. voltage (L-L) (Un\G329), hour and minute of time of CH1 min. voltage (L-L) (Un\G330), second and day of the week of time of CH1 min. voltage (L-L) (Un\G331)Year of time of CH1 max. voltage (L-N) (Un\G334), month and day of time of CH1 max. voltage (L-N) (Un\G335), hour and minute of time of CH1 max. voltage (L-N) (Un\G336), second and day of the week of time of CH1 max. voltage (L-N) (Un\G337), year of time of CH1 min. voltage (L-N) (Un\G340), month and day of time of CH1 min. voltage (L-N) (Un\G341), hour and minute of time of CH1 min. voltage (L-N) (Un\G342), second and day of the week of time of CH1 min. voltage (L-N) (Un\G343)

Stores year, month, day, hour, minute, second, and day of the week of time when CH1 maximum voltage (L-L) (Un\G320, 321), CH1 minimum voltage (L-L) (Un\G326, 327), CH1 maximum voltage (L-N) (Un\G332, 333), and CH1 minimum voltage (L-N) (Un\G338, 339) were updated.

- (1) Details of stored data
 - (a) Storage format

As indicated below, data are stored as BCD code in the buffer memory. Buffer memory address Storage format h8 h7 Un\G322 e.g.) Year 2010 /Un\G328 2010h /Un\G334 /Un\G340 Year b12 b1 Un\G323 e.g.) July 30 /Un\G329 0730h /Un\G335 /Un\G341 Month Day h12 h11 h8 h7 h4 h3 Un\G324 e.g.) 10:35 /Un\G330 1035h /Un\G336 /Un\G342 Hour Minute b12 b11 b8 b7 e.g.) 48sec Firday 4805h Un\G325 0 fixed Second Day of the week /Un\G331 0 Sunday Monday /Un\G337 2 Tuesday /Un\G343 Wednesday 3 4 Thursday Friday Saturday

(b) Update timing

It will be updated every measuring cycle (500 ms) and if it exceeds the max. value or goes under the min. value.

6.3.17 Multiplier of CH1 power (Un\G400)

The multiplier of power is stored.

- (1) Details of stored data
 - (a) Storage format
 Data are stored as 16-bit signed binary in the buffer memory.
 Data range: -3 (fixed)
 - (b) Update timing Because it is fixed at -3, there is no update.

6.3.18 CH1 electric power (Un\G402,403)

The electric power (effective value) is stored.

- (1) Details of stored data
 - (a) Storage format

Data are stored as double-word 32-bit signed binary in the buffer memory.

- If the power is negative, represents the regenerative power.
- Data range:-999999999 to 999999999 (-9999999.999 to 999999.999 kW)

*For restrictions for measured data including resolution and measuring range, refer to section 4.2.1.

(b) Unit

 $\times 10^{-3}$ kW *Unit is fixed.

(c) Update timing

It will be updated every measuring cycle (500 ms).

6.3.19 CH1 electric power demand (Un\G404,405)

Stores the electric power that is measured based on the moving average for the duration of time configured in CH1 electric power demand time (Un\G4).

- (1) Details of stored data
 - (a) Storage format

Data are stored as double-word 32-bit signed binary in the buffer memory.

- If the power is negative, represents the regenerative power.
- Data range: -999999999 to 999999999 (-9999999.999 to 999999.999 kW)

*For restrictions for measured data including resolution and measuring range, refer to section 4.2.1.

(b) Unit

 $\times 10^{-3}$ kW *Unit is fixed.

(c) Update timing

6.3.20 CH1 maximum electric power demand (Un\G420, 421),

CH1 minimum electric power demand (Un\G426, 427)

Stores the max./min. values of the electric power demand.

- (1) Details of stored data
 - (a) Storage format

Data are stored as double-word 32-bit signed binary in the buffer memory.

If the power is negative, represents the regenerative power.

- Data range: -999999999 to 999999999 (-9999999.999 to 999999.999 kW)

*For restrictions for measured data including resolution and measuring range, refer to section 4.2.1.

(b) unit

 $\times 10^{-3}$ kW *Unit is fixed.

(c) Update timing

It will be updated every measuring cycle (500 ms) if it exceeds the current max. value or goes under the current min. value.

6.3.21 Year of time of CH1 max. electric power demand (Un\G422),

month and day of time of CH1 max. electric power demand (Un\G423), hour and minute of time of CH1 max. electric power demand (Un\G424), second and day of the week of time of CH1 max. electric power demand (Un\G425), year of time of CH1 min. electric power demand (Un\G428), month and day of time of CH1 min. electric power demand (Un\G429), hour and minute of time of CH1 min. electric power demand (Un\G430), second and day of the week of time of CH1 min. electric power demand (Un\G431)

Stores year, month, day, hour, minute, second, and day of the week of time when CH1 max. electric power demand (Un\G420, 421) and CH1 min. electric power demand (Un\G426, 427) were updated.

- (1) Details of stored data
 - (a) Storage format

As indicated below, data are stored as BCD code in the buffer memory.



(b) Update timing

It will be updated every measuring cycle (500 ms) if it exceeds the current max. value or goes under the current min. value.

6.3.22 Multiplier of CH1 reactive power (Un\G500), multiplier of CH1 apparent power (Un\G600)

The number of decimal places the reactive power and the apparent power are stored.

- (1) Details of stored data
 - (a) Storage format
 Data are stored as 16-bit signed binary in the buffer memory.
 Data range: -3 (fixed)
 - (b) Update timing Because it is fixed at -3, there is no update.

6.3.23 CH1 reactive power(Un\G502, 503)

Stores the total reactive power.

- (1) Details of stored data
 - (a) Storage format
 - Data are stored as double-word 32-bit signed binary in the buffer memory.
 - If the power is negative, represents the leading reactive power regenerative or consumption.
 - Data range: -9999999999 to 999999999 (-9999999.999 to 999999.999 kvar)

*For restrictions for measured data including resolution and measuring range, refer to section 4.2.1.

*The symbols prefixed to the data have the following meaning:

Minus (-) : Lead reactive power

Plus (+): Delayed reactive power

(b) Unit

 $\times 10^{-3}$ kvar *Unit is fixed.

(c) Update timing

It will be updated every measuring cycle (500 ms).

6.3.24 CH1 apparent power(Un\G602, 603)

Stores the total apparent power.

- (1) Details of stored data
 - (a) Storage format

Data are stored as double-word 32-bit signed binary in the buffer memory.

- Data range: 0 to 999999999 (0.000 to 999999.999 kVA)

*For restrictions for measured data including resolution and measuring range, refer to section 4.2.1.

- (b) Unit ×10⁻³kVA *Unit is fixed.
- (c) Update timing It will be updated every measuring cycle (500 ms).

6.3.25 Multiplier of CH1 power factor (Un\G700)

The multiplier of the power factor is stored.

- (1) Details of stored data
 - (a) Storage format
 Data are stored as 16-bit signed binary in the buffer memory.
 Data range: -3 (fixed)
 - (b) Update timing Because it is fixed at -3, there is no update.

6.3.26 CH1 power factor (Un\G702, 703)

Stores the power factor.

- (1) Details of stored data
 - (a) Storage format
 - Data are stored as double-word 32-bit signed binary in the buffer memory.
 - Data range:-99900 to 100000 (-99.900 to 100.000%)
 - *For restrictions for measured data including resolution and measuring range, refer to section 4.2.1.
 - (b) Unit

 $\times 10^{-3}$ % *Unit is fixed.

(c) Update timing It will be updated every measuring cycle (500 ms).

6.3.27 CH1 maximum power factor (Un\G720, 721), CH1 minimum power factor (Un\G726, 727)

The max./min. power factors are stored.

- (1) Details of stored data
 - (a) Storage format
 - Data are stored as double-word 32-bit signed binary in the buffer memory.
 - Data range: -100000 to 100000 (-100.000 to 100.000%)
 - *For the resolution, refer to Section 4.2.1.
 - (b) Unit

 $x10^{-3}$ % *Unit is fixed.

(c) Update timing

6.3.28 Year of time of CH1 max. power factor (Un\G722),

month and day of time of CH1 max. power factor (Un\G723), hour and minute of time of CH1 max. power factor (Un\G724), second and day of the week of time of CH1 max. power factor (Un\G725), year of time of CH1 min. power factor (Un\G728), month and day of time of CH1 min. power factor (Un\G729), hour and minute of time of CH1 min. power factor (Un\G730), second and day of the week of time of CH1 min. power factor (Un\G731)

Stores year, month, day, hour, minute, second, and day of the week of time when CH1 max. power factor (Un\G720, 721) and CH1 min. power factor (Un\G726, 727) were updated.

(1) Details of stored data

(a) Storage format

As indicated below, data are stored as BCD code in the buffer memory.



(b) Update timing

It will be updated every measuring cycle (500 ms) if it exceeds the current max. value or goes under the current min. value.

6.3.28 Multiplier of CH1 frequency (Un\G800)

The multiplier of the frequency is stored.

- (1) Details of stored data
 - (a) Storage formatData are stored as 16-bit signed binary in the buffer memory.Data range: -3 (fixed)
 - (b) Update timing Because it is fixed at -3, there is no update.

6.3.29 CH1 frequency (Un\G802, 803)

Stores the frequency.

- (1) Details of stored data
 - (a) Storage format
 - Data are stored as double-word 32-bit signed binary in the buffer memory.
 - Data range: 0 to 999999 (-0 to 999.999 Hz)
 - *For restrictions for measured data including resolution and measuring range, refer to section 4.2.1.
 - (b) Unit

 $\times 10^{-3}$ % *Unit is fixed.

(c) Update timing

- 6.4 Common sections (Un\G4500 to Un\G4999)
 - 6.4.1 Latest error code (Un\G4500)

The latest error code that is detected with this module will be stored. *For the list of error codes, refer to section 9.1.

- (1) Details of stored data
 - (a) Storage format

Data are stored as 16-bit signed binary in the buffer memory. - Data range: 0000h (normal), 0001h to FFFFh (error code)

- (b) Update timingIt will be updated at the time of error occurrence and error recovery.
- 6.4.2 Year of time of the error (Un\G4501), month and day of time of the error (Un\G4502), hour and minute the error (Un\G4503), second and day of the week of time of the error (Un\G4504)

The year, month, day, hour, minute, and day of the week of time of the error will be stored.

- (1) Details of stored data
 - (a) Storage format



(b) Update timing

It will be updated at the time of error occurrence and error recovery.

Chapter 7: Current measuring mode

- 7.1 Measuring functions in the current measuring mode
 - (1) Measured items

By activating the current measuring mode, you can measure only the current data shown below of up to eight circuits.

Each measured item is stored in the buffer memory every 100 ms.

	Measured items
	Details
Current	Current
Current demand	Current demand
	Maximum current demand
	Minimum current demand
	Date/time of the maximum current demand
	Date/time of the minimum current demand

- (2) Maximum/minimum current demand The maximum and minimum current demands are obtained as follows: Maximum current demand: Maximum value obtained since the reset of the maximum and minimum values until now. Minimum current demand: Minimum value obtained since the reset of the maximum and minimum
 - Minimum current demand: Minimum value obtained since the reset of the maximum and minimum values until now.
- (3) Resolution of measured data The resolution of the current value is same as those listed in 4.2.1 (3).
- (4) Restrictions on measured data The restrictions on the current value are same as those described in 4.2.1 (4).
- 7.2 Activating the current measuring mode
 - To use the current measuring mode, set Switch 4 of the intelligent function module switch to "1". (The intelligent function module switch setting dialog box appears when you click the Switch setting button on the I/O assignment tab shown in Section 8.6.1.)

witc	h settine	s for I∕O and ir	telligent function	module							
					Inpu	t format	DEC	•	◀	— Select "D	EC."
	Slot	Туре	Model name	Switch 1	Switch 2	Switch 3	Switch 4	Switch 5	•		
0	PLC	PLC									
	0(*·0)	Intelli.	QE83WH4W				1	0			
	1(*-1)										
	2(*-2)										
	3(*-3)										
	4(*-4)										
	5(*-5)										
	6(*-6)										
	7(*-7)										
	8(*-8)										
	9(*-9)										
	10(*-10) 11(*-11)										
	12(*-12) 13(*-13)										
	14(*-14)								-		
4	(17)	1	·					Þ	-		
End Cancel											

Figure 7.2 Intelligent function module switch setting dialog box

- 2) When the setting is completed, click the Complete setting button.
- 3) From the "Online" menu, select "Write to PC" to display the dialog box of Write to PLC, and then execute the writing of parameter to PLC. After resetting the CPU module, the value will become effective.

7.3 List of I/O signals

I/O signals used in the current measuring mode are listed in Table 7.3.

	al (signal direction from QE83WH4W to CPU	Output sig					
module)	l	QE83WH4W)					
Device #	Signal name	Device #	Signal name				
Xn0	Module ready	Yn0	Use prohibited ^{*1}				
Xn1	Data acquisition clock	Yn1	Use prohibited ^{*1}				
Xn2	Operating condition setting completion flag	Yn2	Operating condition setting request				
Xn3	Use prohibited ^{*1}	Yn3	Use prohibited ^{*1}				
Xn4	Max./min. values clear completion flag	Yn4	Max./min. values clear request				
Xn5	Use prohibited ^{*1}	Yn5	Use prohibited ^{*1}				
Xn6	Use prohibited ^{*1}	Yn6	Use prohibited ^{*1}				
Xn7	Use prohibited ^{*1}	Yn7	Use prohibited ^{*1}				
Xn8	Use prohibited ^{*1}	Yn8	Use prohibited ^{*1}				
Xn9	CH1 alarm 1 flag	Yn9	CH1 alarm 1 reset request				
XnA	CH1 alarm 2 flag	YnA	CH1 alarm 2 reset request				
XnB	CH2 alarm 1 flag	YnB	CH2 alarm 1 reset request				
XnC	CH2 alarm 2 flag	YnC	CH2 alarm 2 reset request				
XnD	CH3 alarm 1 flag	YnD	CH3 alarm 1 reset request				
XnE	CH3 alarm 2 flag	YnE	CH3 alarm 2 reset request				
XnF	CH4 alarm 1 flag	YnF	CH4 alarm 1 reset request				
Xn10	CH4 alarm 2 flag	Yn10	CH4 alarm 2 reset request				
Xn11	CH5 alarm 1 flag	Yn11	CH5 alarm 1 reset request				
Xn12	CH5 alarm 2 flag	Yn12	CH5 alarm 2 reset request				
Xn13	CH6 alarm 1 flag	Yn13	CH6 alarm 1 reset request				
Xn14	CH6 alarm 2 flag	Yn14	CH6 alarm 2 reset request				
Xn15	CH7 alarm 1 flag	Yn15	CH7 alarm 1 reset request				
Xn16	CH7 alarm 2 flag	Yn16	CH7 alarm 2 reset request				
Xn17	CH8 alarm 1 flag	Yn17	CH8 alarm 1 reset request				
Xn18	CH8 alarm 2 flag	Yn18	CH8 alarm 2 reset request				
Xn19	Use prohibited ^{*1}	Yn19	Use prohibited ^{*1}				
Xn1A	Use prohibited ^{*1}	Yn1A	Use prohibited ^{*1}				
Xn1B	Use prohibited ^{*1}	Yn1B	Use prohibited ^{*1}				
Xn1C	Use prohibited ^{*1}	Yn1C	Use prohibited ^{*1}				
Xn1D	Use prohibited ^{*1}	Yn1D	Use prohibited ^{*1}				
Xn1E	Use prohibited ^{*1}	Yn1E	Use prohibited ^{*1}				
Xn1F	Error flag	Yn1F	Error clear request				

Table 7.3 List of I/O signals

Point

*1 These signals cannot be used by the user since they are for system use only.

For details about each I/O signal, refer to Section 5.2.
7.4 Buffer memory

The following describes buffer memory assignment in the current measuring mode.

	Table 7.4 Buffer memory																				
Item			Ac	dress	Decim	ial)			Data	Description	t	R/	Back		Out	iput vali	ue durir	ng the te	est moc	e*2	
	CH1				CH5			CH8	Туре	Description	value	W	up*2	CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8
Setting value	_	S	S	4150 \$ 4152	4200 \$ 4202	4250 \$ 4252	4300 5 4302	4350 5 4352	—	System area	_	_	_				-	-			
		4002	4102		4 <u>202</u>	4202	4302	4302	Pr	Output period of data acquisition	0	R/	0				(
				40)01)02				Pr	clock Max./min. value clear target	0	W	0				(
		10.50		1	<u> </u>			10.50	Pr	Max./min. value clear target	0		_)			
	4003 ※	4053 ※	4103 ※	4153 ※	4203 ※	4253 ※	4303 ※	4353 ※	Pr	Primary current	2	R/ W	0	521	522	523	524	525	526	527	528
	4004	4054	4104		4204	4254	4304	4354	Pr	Current demand time	120	R/	0	1010	1020	1030	1040	1050	1060	1070	1080
	4005	4055 4054	4105 4104		4205 4204	4255 4254	4305 4304	4355 4354	Pr	Primary current of CT	0	R/	0	0	0	0	0	0	0	0	0
	4004 \$ 4010	4054 \$ 4060	\$ 4110	4160	4210	4260	4304 5 4310	4360	—	System area	—	-	—				-	-			
	4011	4061	4111	4161	4211	4261	4311	4361	Pr	Alarm 1 item	0	R/	0	1	2	1	2	1	2	1	2
	4012 4013	4062 4063	4112 4113	4162 4163	4212 4213	4262 4263	4312 4313	4362 4363	Pr	Alarm 1 value	0	R/ W	0	2010	2020	2030	2040	2050	2060	2070	2080
	4014			4164		4264	4314	4364	Pr	Alarm 1 reset method	0	R/	0	0	1	0	1	0	1	0	1
	4015 4016		4115	4165 4166		4265	4315	4365	Pr	Alarm 1 delay time	0	R/	0	101	102	103	104	105	106	107	108
	4016 \$ 4020	S	S	S	S	4266 \$ 4270	4316 \$ 4320	4366 5 4370	—	System area	—	_	—				-	_			
	4021		4121	4171	4221	4271	4321	4371	Pr	Alarm 2 item	0	R/	0	2	1	2	1	2	1	2	1
	4022	4072				4272	4322	4372	Pr	Alarm 2 value	0	R/	0	3010	3020	3030	3040	3050	3060	3070	3080
	4023 4024	4073	4123			4273 4274	4323 4324	4373 4374	Pr	Alarm 2 reset method	0	W R/	0	1	0	1	0	1	0	1	0
	4024			4175		4275	4325	4375	Pr	Alarm 2 delay time	0	R/	ŏ	201	202	203	204	205	206	207	208
	4026 \$ 4029	4076 لا	4126 \$ 4129	4176 لا		4276 \$ 4279	4326 5 4329	4376 5 4379	_	System area	_	_	-					_			
	4030			4180		4280	4330	4380	Md	Multiplier of current	-3	R	_	-3	-3	-3	-3	-3	-3	-3	-3
	4031			4181		4281	4331	4381	—	System area	-	—					_	_			
	4032 4033	4082 4083	4132	4182 4183	4232 4233	4282 4283	4332 4333	4382 4383	Md	Current	0	R	_	91100	91200	91300	91400	91500	91600	91700	91800
	4033			4184		4263	4333	4384		• · · · ·	-	_									
	4035	4085	4135		4235	4285	4335	4385	Md	Current demand	0	R	—	92100	92200	92300	92400	92500	92600	92700	92800
	4036			4186		4286	4336	4386	Md	Maximum current demand	0	R	_	93100	93200	93300	93400	93500	93600	93700	93800
	4037		4137		4237	4287	4337	4387 4388	Md	Year of time of max. current	0	R	_			2053h		2055h			
	4038		4138			4288	4338			Month and day of time of max.											
	4039	4089	4139	4189	4239	4289	4339	4389	Md	current demand	0	R	—	1121h	1122h	1123h	1124h	1125h	1126h	1127h	1128h
	4040	4090	4140	4190	4240	4290	4340	4390	Md	Hour and minute of time of max. current demand	0	R	-	2041h	2042h	2043h	2044h	2045h	2046h	2047h	2048h
	4041	4091	4141	4191	4241	4291	4341	4391	Md	Second and day of the week of time of max. current demand	0	R	—	2100h	2201h	2302h	2403h	2504h	2605h	2706h	2800h
	4042	4092				4292	4342	4392 4393	Md	Minimum current demand	0	R	_	94100	94200	94300	94400	94500	94600	94700	94800
	4043 4044	4093 4094	4143 4144		4243 4244	4293 4294	4343 4344	4393	Md	Year of time of min. current	0	R		2061h	2062h	2063h	2064h	2065h	2066h	2067h	2068h
										Month and day of time of min.			_								
	4045	4095	4145	4195	4245	4295	4345	4395	Md	current demand	0	R	-	1201h	1202h	1203h	1204h	1205h	1206h	1207h	1208h
	4046	4096	4146	4196	4246	4296	4346	4396	Md	Hour and minute of time of min. current demand	0	R		2151h	2152h	2153h	2154h	2155h	2156h	2157h	2158h
	4047	4097	4147	4197	4247	4297	4347	4397	Md	Second and day of the week of time of min. current demand	0	R	_	3101h	3202h	3303h	3404h	3505h	3606h	3700h	3801h
	4048 \$	S	4148 \$	S	4248 5 4249	4298 \$	4348 5 4349	4398 5 4399	_	System area	_	_	_				-	_			
	4049	4039	4149	+198	4249	4299	4349	4099													

* Set the primary current to the same value between CH1 and CH2, between CH3 and CH4, between CH5 and CH6, and between CH7 and CH8. If you set the CH2 (or CH4, CH6, or CH8) address to any value that is inconsistent with the value of CH1 (or CH3, CH5, or CH7), the value you set becomes invalid and is replaced with the value of CH1 (or CH3, CH5, or CH7) after the operating conditions are set.

7.5 Names and functions of LEDs

The following describes names and functions of LEDs in the current measuring mode.

Name	Color	Role	ON/OFF condition
0 LED	Green	Displays the operation	ON: Normal operation
		status of this module.	OFF: Internal power shut-off, hardware error ^{*1}
1 LED	Green	Displays CH1 current	ON: CH1 current > 0 A
		measurement status.	OFF: CH1 current = 0 A
2 LED	Green	Displays CH2 current	ON: CH2 current > 0 A
		measurement status.	OFF: CH2 current = 0 A
3 LED	Green	Displays CH3 current	ON: CH3 current > 0 A
		measurement status.	OFF: CH3 current = 0 A
4 LED	Green	Displays CH4 current	ON: CH4 current > 0 A
		measurement status.	OFF: CH4 current = 0 A
5 LED	Green	Displays CH5 current	ON: CH5 current > 0 A
		measurement status.	OFF: CH5 current = 0 A
6 LED	Green	Displays CH6 current	ON: CH6 current > 0 A
		measurement status.	OFF: CH6 current = 0 A
7 LED	-	-	Always OFF.
8 LED	Red	Displays errors and conditions of this module.	Flashing: Out-of-range error ^{*1} ON: Hardware error ^{*1} OFF: Normal operation
9 LED	Green	Displays CH7 current measurement status.	ON: CH7 current > 0 A OFF: CH7 current = 0 A
A LED	Green	Displays CH8 current	ON: CH8 current > 0 A
		measurement status.	OFF: CH8 current = 0 A
B LED	-	-	Always OFF.
C LED	-	-	Always OFF.
D LED	-	-	Always OFF.
E LED	-	-	Always OFF.
F LED	-	-	Always OFF.

Table 7.5 Names and functions of	f I EDs (in the	current measuring mode)
Table 7.5 Names and functions 0	n rens (in the	current measuring mode)

*1 For details, check with the list of error codes. (Refer to Section 7.8.)

7.6 Names of signals of terminal block

The following describes names of signals of terminal block in the current measuring mode.







Termina	al symbol	Name of terminal
CH1	1k 1I	CH1 current input terminal (power source side) CH1 current input terminal (load side)
	2k 2l	CH2 current input terminal (power source side) CH2 current input terminal (load side)
	3k 3l	CH3 current input terminal (power source side) CH3 current input terminal (load side)
CH2	1k 1I	CH4 current input terminal (power source side) CH4 current input terminal (load side)
	2k 2l	CH5 current input terminal (power source side) CH5 current input terminal (load side)
	3k 3l	CH6 current input terminal (power source side) CH6 current input terminal (load side)
СНЗ	1k 1I	CH7 current input terminal (power source side) CH7 current input terminal (load side)
	2k 2l	CH8 current input terminal (power source side) CH8 current input terminal (load side)
	3k 3l	-
F	PA	-
F	РВ	-
F	PC	-
F	PD	-
S	LD	-

Table 7.6 Names of signals of terminal block

7.7 Wiring

Follow the wiring diagram for external connection in the current measuring mode.









Chapter 8: Setting and procedure for operation

8.1 Precautions for handling

- (1) Do not drop or apply strong shock to the module case.
- (2) Do not remove the printed-circuit board of the module from the case. Doing so may cause failure.
- (3) Prevent foreign matter such as dust or wire chips from entering the module. Such foreign matter can cause a fire, failure, or malfunction.
- (4) A protective film is attached to the top of the module to prevent foreign matter, such as wire chips, from entering the module during wiring.
 Do not remove the film during wiring.
 Remove it for heat dissipation before system operation.
- (5) Module fixing screws must be tightened within the specified range as described below. Loose screws may cause short-circuit, failure, or malfunction.
 - *1 The module can be fixed easily to the base unit, using the hook on top of the module. However, if it is used under a vibrating environment, we strongly recommend that the module be fixed with screws.

Locations of screws	Torque range
Module fixing screws (M3 x 12 mm)	0.36 - 0.48 N∙m
Terminal screws on the current input terminal block (M3)	0.42 - 0.58 N∙m
Current input terminal block fixing screws (M3.5)	0.66 - 0.89 N∙m
Terminal screws on the voltage input terminal block	0.4 - 0.5 N∙m

(6) To attach the module to the base unit, firmly insert the protruding portions for fixing the module into the holes on the base unit, and make sure the module is securely attached to the module holes as fulcrum points.

Insecure attachment of the module may case malfunction, failure, and a falling.

(7) Before touching the module, make sure that you need to discharge static electricity on your body by touching a metal that is grounded.
 Otherwise, it may cause failure or molfunction to the module.

Otherwise, it may cause failure or malfunction to the module.

8.2 Procedure for operation



Figure 8.1 Procedure for operation

8.3 Name and function of each part

Names and functions of parts of QE83WH4W are provided below.



Figure 8.2 Appearance of the module

(1) Names and functions of LEDs

The following describes names and functions of LEDs.

Name	Color	Role	ON/OFF condition
0 LED	Green	Displays the operation status of this	ON: Normal operation
		module.	OFF: Internal power shut-off, hardware error *1
1 LED	Green	Displays CH1 measurement status	ON: Measuring electric energy (consumption)
		of this module.	Flashing: electric energy (regeneration)
			OFF: Not measuring (No measurement)
2 LED	Green	Displays CH2 measurement status	ON: Measuring electric energy (consumption)
		of this module.	Flashing: electric energy (regeneration)
			OFF: Not measuring (No measurement)
3 LED	Green	Displays CH3 measurement status	ON: Measuring electric energy (consumption)
		of this module.	Flashing: electric energy (regeneration)
			OFF: Not measuring (No measurement)
4 LED	Green	Displays CH1 1-side measurement	ON: Measuring electric energy (regeneration) on side 1
		status (regeneration) of this module.	OFF: Other than the above
5 LED	Green	Displays CH2 1-side measurement	ON: Measuring electric energy (regeneration) on side 1
		status (regeneration) of this module.	OFF: Other than the above
6 LED	Green	Displays CH3 1-side measurement	ON: Measuring electric energy (regeneration) on side 1
		status (regeneration) of this module.	OFF: Other than the above
7 LED	-	-	Always OFF.
7 LED 8 LED	- Red	- Displays errors and conditions of this	Always OFF. Flashing: Out-of-range error ^{*1}
		- Displays errors and conditions of this module.	
			Flashing: Out-of-range error ^{*1}
			Flashing: Out-of-range error ^{*1} ON: Hardware error ^{*1}
8 LED	Red	module.	Flashing: Out-of-range error ^{*1} ON: Hardware error ^{*1} OFF: Normal operation
8 LED 9 LED	Red Green	module. Displays CH1 2-side measurement status (regeneration) of this module.	Flashing: Out-of-range error ^{*1} ON: Hardware error ^{*1} OFF: Normal operation ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above
8 LED	Red	module. Displays CH1 2-side measurement status (regeneration) of this module. Displays CH2 2-side measurement	Flashing: Out-of-range error ^{*1} ON: Hardware error ^{*1} OFF: Normal operation ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2
8 LED 9 LED A LED	Red Green Green	 module. Displays CH1 2-side measurement status (regeneration) of this module. Displays CH2 2-side measurement status (regeneration) of this module. 	Flashing: Out-of-range error ^{*1} ON: Hardware error ^{*1} OFF: Normal operation ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above
8 LED 9 LED	Red Green	 module. Displays CH1 2-side measurement status (regeneration) of this module. Displays CH2 2-side measurement status (regeneration) of this module. Displays CH3 2-side measurement 	Flashing: Out-of-range error ^{*1} ON: Hardware error ^{*1} OFF: Normal operation ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2
8 LED 9 LED A LED	Red Green Green	 module. Displays CH1 2-side measurement status (regeneration) of this module. Displays CH2 2-side measurement status (regeneration) of this module. 	Flashing: Out-of-range error ^{*1} ON: Hardware error ^{*1} OFF: Normal operation ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above
8 LED 9 LED A LED	Red Green Green	 module. Displays CH1 2-side measurement status (regeneration) of this module. Displays CH2 2-side measurement status (regeneration) of this module. Displays CH3 2-side measurement 	Flashing: Out-of-range error ^{*1} ON: Hardware error ^{*1} OFF: Normal operation ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2
8 LED 9 LED A LED B LED	Red Green Green Green	 module. Displays CH1 2-side measurement status (regeneration) of this module. Displays CH2 2-side measurement status (regeneration) of this module. Displays CH3 2-side measurement status (regeneration) of this module. 	Flashing: Out-of-range error ^{*1} ON: Hardware error ^{*1} OFF: Normal operation ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above
8 LED 9 LED A LED B LED	Red Green Green Green	 module. Displays CH1 2-side measurement status (regeneration) of this module. Displays CH2 2-side measurement status (regeneration) of this module. Displays CH3 2-side measurement status (regeneration) of this module. Displays CH1 3-side measurement status (regeneration) of this module. 	Flashing: Out-of-range error ^{*1} ON: Hardware error ^{*1} OFF: Normal operation ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above
8 LED 9 LED A LED B LED C LED	Red Green Green Green Green	 module. Displays CH1 2-side measurement status (regeneration) of this module. Displays CH2 2-side measurement status (regeneration) of this module. Displays CH3 2-side measurement status (regeneration) of this module. Displays CH1 3-side measurement 	Flashing: Out-of-range error ^{*1} ON: Hardware error ^{*1} OFF: Normal operation ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above
8 LED 9 LED A LED C LED D LED	Red Green Green Green Green Green	 module. Displays CH1 2-side measurement status (regeneration) of this module. Displays CH2 2-side measurement status (regeneration) of this module. Displays CH3 2-side measurement status (regeneration) of this module. Displays CH1 3-side measurement status (regeneration) of this module. Displays CH2 3-side measurement status (regeneration) of this module. 	Flashing: Out-of-range error ^{*1} ON: Hardware error ^{*1} OFF: Normal operation ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 3 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 3 OFF: Other than the above
8 LED 9 LED A LED B LED C LED	Red Green Green Green Green	 module. Displays CH1 2-side measurement status (regeneration) of this module. Displays CH2 2-side measurement status (regeneration) of this module. Displays CH3 2-side measurement status (regeneration) of this module. Displays CH1 3-side measurement status (regeneration) of this module. Displays CH2 3-side measurement status (regeneration) of this module. Displays CH2 3-side measurement status (regeneration) of this module. Displays CH2 3-side measurement status (regeneration) of this module. 	Flashing: Out-of-range error *1 ON: Hardware error *1 OFF: Normal operation ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 3 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 3 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 3 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 3 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 3 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 3 OFF: Other than the above
8 LED 9 LED A LED C LED D LED	Red Green Green Green Green Green	 module. Displays CH1 2-side measurement status (regeneration) of this module. Displays CH2 2-side measurement status (regeneration) of this module. Displays CH3 2-side measurement status (regeneration) of this module. Displays CH1 3-side measurement status (regeneration) of this module. Displays CH2 3-side measurement status (regeneration) of this module. 	Flashing: Out-of-range error ^{*1} ON: Hardware error ^{*1} OFF: Normal operation ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 2 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 3 OFF: Other than the above ON: Measuring electric energy (regeneration) on side 3 OFF: Other than the above

Table 8.2 Names and functions of LEDs

*1 For details, check with the list of error codes. (Refer to section 10.1)

(2) Names of signals of terminal block

The following describes names of signals of terminal block.







Termir	nal symbol	Name of terminal
CH1	1k	1-phase current input terminal (power source side)
	11	1-phase current input terminal (load side)
	2k	2-phase current input terminal (power source side)
	21	2-phase current input terminal (load side)
	3k	3-phase current input terminal (power source side)
	31	3-phase current input terminal (load side)
CH2	1k	1-phase current input terminal (power source side)
	11	1-phase current input terminal (load side)
	2k	2-phase current input terminal (power source side)
	21	2-phase current input terminal (load side)
	3k	3-phase current input terminal (power source side)
	31	3-phase current input terminal (load side)
CH3	1k	1-phase current input terminal (power source side)
	11	1-phase current input terminal (load side)
	2k	2-phase current input terminal (power source side)
	21	2-phase current input terminal (load side)
	3k	3-phase current input terminal (power source side)
	31	3-phase current input terminal (load side)
	PA	
	PB	Terminal for connecting the secondary terminal
	PC	block of the voltage transform unit
	PD	
	SLD	Shield connection terminal

Table 8.3 Names of signals of terminal block

8.4 Attaching and removing the module





- Attach to the base of MELSEC-Q series.
- When attaching the module, make sure to insert the protruding portions for fixing the module into the holes on the base unit. In doing so, insert it securely so that the protruding portion of the module does not come off of the holes. Do not force to attach the module; otherwise the module may break.
- When installing the module at a vibrating area with strong impact, tighten the module to the base unit using screws. Module-fixing screws: M3 x 12mm (Prepare them yourself.)
- Attaching and detaching the module and the base unit should be performed 50 times or less (to conform to JIS B3502). If the count exceeds 50 times, it may cause a malfunction.



8.4.2 How to detach it from the base unit (Q6_WRB)

• When module-fixing screws are used, make sure to remove the screws for detaching the module first, and then remove the protruding portion for fixing the module from the holes. Do no force to remove the module; it may break the protruding portions for fixing the module.

7.5 Wiring

- 7.5.1 Precautions for wiring
 - (1) The voltage transform unit (QE8WH4VT) is required for voltage input. (Refer to section 8.5.3)
 - (2) For the current circuit input, Mitsubishi's current sensor is required. (Refer to section 8.5.3)
 - (3) Connect cables. For connecting voltage transformer, voltage transform unit and current transformer, refer to the corresponding wiring diagram.
 - (4) Do not install the input signal wire together with the main circuit lines or power cables. Keep a distance as below. (Except for the terminal input part) Failure to do so may result in malfunction due to noise.

Conditions	Distance
Power line of 600V or less and 600A or less	300mm or more
Other power line	600mm or more

- (5) For input wiring of the measurement circuit, use separate cables from other external signals in order to prevent from AC surge and induction.
- (6) Keep any object off the cables.
- (7) Protect cable coating from scratch.
- (8) Cable length should be routed in length with a margin, please take care to avoid causing stress to pull the terminal block. (Tensile load: less than 22N)
- (9) In actual use, please connect the SLD terminal to a shield.

8.5.2 How to connect wires

- (1) Follow the wiring diagram for external connection to QE83WH4W.
- $(2) \ Use \ appropriate \ electric \ wires \ as \ described \ below.$
 - <Voltage input terminals>
 - 1) Stripping length of the used wire in use has to be 7mm. Check the stripping length please use the strip gauge at the bottom of QE83WH4W main body.



Applicable wire	Single wire: φ1.2mm (φ0.5mm to φ1.2mm)
(Usable electric wire)	Stranded wire: 1.3mm ² (0.5 mm ² to 1.3 mm ²)

2) When using a stranded wire, strand the wire edges to prevent thin wires from loosening.

<Current input terminals>

1) For the connection between the secondary terminal of current sensor (EMU-CT50 /100 /250 /400 /600) and current input terminals, use twisted pair cable.

Applicable wire	Stranded wire: $0.75 \text{ mm}^2 (0.5 - 0.75 \text{ mm}^2)$
(Usable electric wire)	Stranded wife. $0.75 \text{ min} (0.5 - 0.75 \text{ min})$

2) Use a solderless terminal to prevent thin wires from loosening. No solderless terminal with insulation sleeve can be used

Applicable solderless terminal	R1.25-3
--------------------------------	---------

3) It is recommended to cover the solderless terminals connecting electric cables with a mark tube or insulating tube.

8.5.3 How to wire

Follow the wiring diagram (Figure 8.3) for external connection of QE83WH4W.



Figure 8.3-2 When a high voltage circuit (with a voltage transformer for gauge / current transformer)





Figure 8.3-3 When connecting several module (QE83WH4W) to Voltage transform unit (QE8WH4VT)

*1 Measurement module can be connected to a voltage transform unit (QE8WH4VT) is up to five. Transition wiring can be up to 2 to the voltage terminal block of the energy measuring module. 8.5.3.1 Current circuit connection

- For the current circuit connection, there are two ways as follows:
- 1) You can connect current sensor to the circuit, or
- 2) You can attach the 5 A current sensor to the secondary of the existing current transformer.
- (1) To attach current sensor (for low voltage circuit) to the circuit
 - Select an appropriate current sensor according to the current capacity of the circuit to be measured.

Item	Specifications							
Model name	EMU-CT50	EMU-CT100	EMU-CT250	EMU-CT400	EMU-CT600			
Primary current	50 A	100 A	250 A	400 A	600 A			

V Supplementary -----

- Make sure that before connecting the cable, the orientation of the current sensor is correct for attachment. K to L is the correct direction. K: power source side, L: load side.
- The length of the cable to be used for wiring is 50 m max for the following device: EMU-CT50, EMU-CT100, EMU-CT250, EMU-CT400, EMU-CT600.
- How to attach EMU-CT50/CT100/CT250

Follow the procedure below to attach to the cable of the target circuit.

- Open the movable core, as shown in the figure on the right. Lift slowly the hooks located on both sides of the movable core, and detach them from the stopper. Do not force to open it. You may break the hook.
- 2) Do not let the cable touch on the core-spilt surface. Thus, carefully pass the cable from underneath. Before passing the cable, check the direction symbols of K and L, in order to attach the sensor in the correct orientation. (Direction from power source side (K) to load side (L) is indicated with the direction the sensor in the correct orientation.

side (K) to load side (L) is indicated with the arrow.)

 Make sure no dust or foreign object is attached on the split-core surface, and after that, close the movable core. Lift the movable core until the

stoppers are firmly locked. (When the hooks on both side of movable core are locked to the stoppers, you will hear click sound twice.)

- 4) Put a binding cable through a hole for fixing the current sensor, and then tie it with the cable. Do not tie it too tightly. (Holes for fixing the current sensor are located on both side of the current sensor.)
- 5) Cut off the extra portion of binding cable, using a nipper, etc, to avoid interference of the cable.
- 6) Lift a protective cover of the secondary terminal, by holding the center portion of the protective cover, and remove it. And then, connect the given sensor cable. Check the terminal symbols printed on the secondary terminal surface, so that connection is performed correctly.





EMU-CT600

✓ Supplementary

• When opening the movable core on current sensor, **do not widen the hook for fixing the movable core too widely.** It may break the hook.

•	Refer to the table below for appropriate size of electric wires.									
			EMU-CT50	EMU-CT100	EMU-CT250	EMU-CT400				

 Usable wires size (reference)
 IV cable
 60 mm² or less
 60 mm² or less
 150 mm² or less
 500 mm² or less
 500 mm² or less

 Size (reference)
 CV cable
 38 mm² or less
 38 mm² or less
 150 mm² or less
 500 mm² or less
 500 mm² or less

 Size of electric wires conforms to what is described in the catalog of general PVC insulated

wires. Thickness of external PVC insulation is different for different wire. Check with the external dimension diagram of this product and make sure the wire can go through the given space.



■ How to attach EMU-CT400/CT600

Follow the procedure below to attach the cable to the target circuit.

- 1) Release the band 1) to the arrow direction (top), and detach the core cover.
- 2) Remove the terminal cover, and shift the secondary short switch into "short".
- Loosen the screw 2), and open the core band to remove the core. Make sure that no dust, etc attaches on the core.
- 4) Loosen the screw 3). Put this module onto the cable, and fix the module by tightening the screw 3) using the metal bracket that is directly attached to the cable. Tighten the screw as tightly as the metal bracket will not bend.
- Align the symbol of "K" on the removed core and the "K" on the module to return the core as in the original location. And then, tighten the core band using the screw 2).
- 6) Attach the core cover and fix it with the band 1).
- 7) Connect the secondary terminal with multiple-circuit power measuring module, turn the secondary short switch into "open", and then attach the terminal cover.
- (2) To attach 5 A current sensor to the secondary side of current transformer (/5A rating)
 - Transfix EMU2-CT5-4W current sensor to the secondary-side wire of current transformer (/5A rated). Make sure to use it in a correct combination with 5 A current sensor conversion cable: EMU2-CB-Q5B-4W
 - EMU2-CT5-4W has polarities. Make sure to connect to the right symbol on the terminal. Power source side: (k side), load side: (l side).



■ How to attach EMU2-CT5-4W

Follow the procedure below to attach the cable to the target circuit.

- 1) Slide the lock pin to the arrow direction.
- 2) Put the electric wire through the clamp, and close the clamp again.
- Use your finger to hold the clamp in the full close position, and push the lock pin until it locks.





Caution The lock pin is made of metal. If you let it touch electrically charged portions, it may cause electric shock or device failure or fire. Be careful handling the lock pin. Physical impact to the core may cause breakage. It may directly influence the performance. Be careful ٠ handling the core. The mating surface on the core is very sensitive. Even a small foreign object on the surface may affect the ٠ measurement performance. Excessive force to the core during open clamp may cause breakage. • Incorrect direction may cause inaccurate measurement. ٠ For both the transfixing wire and the binding band for fixing the sensor, use the size of W=2.6 mm or less. To fix them together Put a binding band through a hole for fixing the current sensor, and tie it with the cable. Do not tie it too tightly. (Total four holes for fixing the current sensor exist on both sides of the current sensor).

8 - 13

Extending the cable of 5 A current sensor

If the cable from current sensor is too short, you can extend it by using an extension cable as shown below. Extension cable (standard)

Model name	EMU2-CB-T1M	EMU2-CB-T5M	EMU2-CB-T10M
Cable length	1 m	5 m	10 m

Extension cable (separate)

Model name	EMU2-CB-T1MS	EMU2-CB-T5MS	EMU2-CB-T10MS
Cable length	1 m	5 m	10 m

Connecting 5 A current sensor and the cable

Connecting 5 A current sensor and extension cable (standard)



Connecting 5 A current sensor and extension cable (separate)



• Cable extension for EMU2-CT5-4W is 10 m max. (Total cable length is 11m max.)

• Use extension cable (separate) when 1-phase, 2-phase and 3-phase are set apart.

8.5.3.2 Voltage circuit connection

For the voltage circuit connection, there are two ways as follows:

- 1) Connect the voltage transform unit direct to the circuit.
- 2) Connect the voltage transform unit to voltage transformer secondary side.
- In any case, circuit voltage can't directly connect to voltage input terminal of QE83WH4W. Please connect to voltage output terminal of voltage transform unit (QE8WH4VT).
- If used at a circuit higher than 277/480V AC, make sure use a voltage transformer.
- The maximum value of the transformer primary voltage is 6,600V. Please connect the transformer secondary voltage to P1, P2, P3, and P0 terminals of QE8WH4VT. Make sure that terminal symbols are correct.
- In order to perform maintenance work such as changing the wire layout and replacing equipment, we recommend that you connect protective device (breaker or fuse) for the voltage input circuit of the voltage transform unit (P1, P2, P3, and P0 terminals).



 Voltage output terminal of voltage transform unit connect to QE83WH4W using a voltage input terminal block.

Fix the module by turning the lever until the clicks after inserting the voltage input terminal block.

• When removing a voltage input terminal block from the module, turn the lever in the opposite direction, hold the voltage input terminal part.



8.6 Setting from GX Developer

This section explains setting from GX Developer necessary to use QE83WH4W. Before performing this setting, install GX Developer and connect the Management CPU with the PC using a USB cable. For details, refer to the manual of CPU module.

- 8.6.1 I/O assignment setting
 - (1) Double-click the dialog box of "PLC Parameter" in the GX Developer Project.
 - (2) Click "I/O assignment".
 - (3) Set the following item to the slot*1 to which QE83WH4W has been attached.

LC r	name PLC	system [PLC file [PLC	RAS(1) [PLC RAS(2)	Device P	rog	am SFC	D I/O assign	nme	nt Serial	
1/0	Assignmen				_			_		
	Slot	Туре	Model name	Points		StartXY		-		
0	PLC	PLC 🗸			-					Switch setti
1	0(*-0)	Intelli. 🗸 🗸	QE83WH4W	32points	-	0000	Select			B 1 1 1 1
2	1(*-1)	-			-					Detailed set
3	2(*-2)	-			•					
4	3(*-3)				•					
5	4(*-4)				-					
6	5(*-5)				-					
7	6(*-6)				*			-		

Assigning the L/O address is not necessary as the CPU does it automati Leaving this setting blank will not cause an error to occur.

Figure 8.10 Dialog box of "I/O assignment"

Table 8.6 Setting	items on the "I/	O assignment" tab

Item	Descriptions
Туре	Select "Intelli.".
Model name	Enter the model name of the module.
Points	Select 32 points.
Start XY	Enter the initial I/O number of QE83WH4W.

*1 is a case where QE83WH4W is attached to the slot 0.

- 8.6.2 Setting the intelligent function of the module switch
 - (1) In the "I/O assignment" of 8.6.1, click the Switch setting button to display the dialog box of "I/O module, intelligent function module switch setting".
 - (2) The intelligent function module switch setting displays switches 1 to 5; however, only the switches 4 and 5 is used for this purpose. Switch setting is configured using 16-bit data. Settings are as shown in Table 8.8.



Figure 8.13 Dialog box to set the intelligent function of the module switch

Swith No.	Switch name	Description
1	Not used	-
2	Not used	-
3	Not used	-
4	Measuring mode selection	0: Regular oparating mode 1: Current measuring mode *When switch 5 is set to "1", the test mode is selected.
5	Test mode transition	 0: Measuring mode (Even when this switch is not set, the module runs in the measuring mode.) 1: Test mode For details of test mode, refer to 4.2.5.

-			
Table 8.8 Se	ettina the intellic	gent function of th	e module switch

- (3) When the setting is completed, click the Complete setting button.
- (4) From the "Online" menu, select "Write to PLC" to display the dialog box of Write to PLC, and then execute the writing to PLC parameter. After resetting the CPU module, the value will become effective.

8.6.3 Initial setting

This section explains the setting of the operating condition for input voltage, primary current, current demand time, voltage demand time, primary voltage of VT, secondary voltage of VT, and primary current of CT that are required for measurement. Once each value is set, these values will be stored in the nonvolatile memory of the module, so that reconfiguration is not needed. You can also perform the setting using sequence program. In this case, you need to create a program, as referring to Chapter 9.

Follow the procedure below for each setting.

- (1) Check the current setting
- (2) Set the Buffer memory
- (1) Check the current setting
 - From the "Online" menu, select "Monitor" "Buffer memory batch ...". The dialog box to monitor all buffer memories. After setting the address as shown below, click the Start monitoring button to check the current buffer memory status.
 - Module initial address: Set the initial address of this module. Buffer memory address: 0
 - (Display: 16-bit integer, numerical value: check the number in decimal)
 - 2) Check each item. The following shows items for operating condition settings. For specific setting value, see the provided references.

Bu	ffer memory add	ress	Item	Reference
CH1	CH2	CH3		
Un\G	0 (Common to al	l CHs)	Phase wire system	Section 6.2.1
Un\G	1 (Common to a	l CHs)	Input voltage	Section 6.2.2
Un\G2	Un\G1002 Un\G2002		Primary current	Section 6.2.3
Un\G3	Un\G1003	Un\G2003	Current demand time	Section 6.2.4
Un\G4	Un\G1004	Un\G2004	Electric power demand	Section 6.2.5
			time	
Un\G	5 (Common to al	l CHs)	Primary voltage of VT	Section 6.2.2
Un\G	6 (Common to a	l CHs)	Secondary voltage of VT	Section 6.2.2
Un\G7	Un\G1007	Un\G2007	Primary current of CT	Section 6.2.3

Table 8.9 List of setting items

Module start addr	ess:	0	(Hex)						
Buffer memory ac	ldress:	0	C DEC	HEX					
Monitor format:	● Bit &	Word	Display:	16bit integer		Value:	⊙ DEC		Start monito
	C Bit			C 32bit integer			C HEX		
	C Word								Stop monito
	U word			C Real number (
				C Real number (double precision)				
				C ASCII charact	er				Option setu
Address	+F E	EDC +BA	98 +7 6 5 -	4 +3 2 1 0				-	
0000			00 0000				4	-	
0001	0	000 00	00 0110	0101			1 01 -		Device tes
0002			00 0000				2		
0003			00 0111				120		
0004			00 0111				120		
0005			00 0000				0		Close
0006			00 0000				0		Ouse
0007			00 0000				0		
0008			00 0000				0		
0009			00 0000				0		
000A			00 0000				0		
000B			00 0000				0		
0000			00 0000				0		
000D 000E			00 0000				0		
000E			00 0000				0		
000P			00 0000				0		
0010			00 0000				0		
			00 0000				0		
0012									

Figure 8.14 Dialog box to monitor all buffer memories (a case where the module is attached to the slot 0)

- (2) Set the Buffer memory
 - 1) In the dialog box to monitor all buffer memories, click the <u>Device test</u> button to display the Device test dialog box.
 - 2) In the Word device / buffer memory, specify the module initial address and buffer address, and click the Set button to apply the setting.

	Device test	
	 Bit device Device Close 	`
4), 6)→	Y2	
	FORCE ON FORCE OFF Toggle force Hide history	
	Y-Word device/buffer memory	
2)→	C Device	
	In Provide the image of the	
	Address 0 V HEX V	
	Setting value	
	Program	ĺ
	Label reference program	
	- Execution history	
	Device Setting condition Find Module start:0 Address:E(H) 0 Find Module start:0 Address:C(H) 0 Find next	
	Module start:0 Address:B(H) 0 Module start:0 Address:7(H) 0 Module start:0 Address:7(H) 0	
	Module startf) Address 6(H) 0 Clear	

Figure 8.15 Device test dialog box (a case where this module is attached to the slot 0)

- 3) Change the setting in 2).
- In the section of bit device setting in the device test dialog box, select "Y2"* and click the FORCE ON button.
- 5) When the setting is completed without any problem, the Device "X2"* changes to ON. Check this using the procedure as follows:
 - (a) From the "Online" menu, select "Monitor" "Device batch ...". The dialog box to monitor all devices is displayed.
 - (b) Set "X0"* to the device, and click "Start monitor"
 - (c) Check that Device "X2"* is in the ON status.

Device bat	ch monitor-1		
Device: X0 Monitor forma		 I 16bit integer Value: DEC 32bit integer HEX Real number (single precision) Real number (double precision) ASCII character 	T/C set value Reference program MAIN Start monitor Stop monitor
Device	+FEDC +BA98 +7	654 + <mark>8</mark> 2 N 0	Onting actua
X0	0000 0000 0	000 p 10/1 5	Option setup
X10	0000 0000 0	000 000 0	

Figure 8.16 Checking the device "X2"* in the dialog box to monitor all devices

- 6) After checking that the device "X2"* is in the ON status, select "Device: "Y2"* in the dialog box of device test, and then click the FORCE OFF button. Setting is completes.
- 7) If the Device "X2"* is not in the ON status, this means an error because the set value is out of range (ERR.LED is flashing). Modify the setting, and change the device "Y2" to the OFF status, then change it back to the ON status.
- * Indicates a number in the case where the initial I/O number (initial XY) is set to 0.

8.6.4 Debugging program

QE83WH4W provides a test function so that you can debug a program with no input of voltage or current. Pseudo-value can be stored into the buffer memory. For detailed explanation for the test function, refer to 4.2.5.

Test function stores pseudo-values for setting value and error information as well as measured value. If you use these data to control the sequence program that controls external devices, there is a chance that erroneous control may occur. For safety of external devices, use this function after disconnecting the device.

- (1) Setting intelligent function of the module switch
 - 1) In the "I/O assignment setting" of 7.6.1, click the Switch setting button to display the dialog box of "I/O module, intelligent function module switch setting".
 - 2) The intelligent function module switch setting displays switches 1 to 5; however, use switch 5 when using the test function. Switch setting is configured using 16-bit data. Setting is as follows: Switch 5: "1"
 - 3) When the setting is completed, click the End button.
 - 4) From the "Online" menu, select "Write to PLC" to display the dialog box of Write to PLC, and then execute the writing to PLC parameter. After resetting the CPU module, the value will become effective.
- (2) Starting the test function
 - 1) Reset the CPU module.
 - 2) QE81WH4W starts in the test function mode. All LEDs are turned on. Pseudo-values are set effective in the buffer memory.
- (3) Finishing the test function (Move back to the normal operation)
 - 1) Following 1) and 2) in step (1), configure the intelligent function switch setting as shown below.
 - Switch 5: "0"
 - 2) Following 3) and 4) in step (1), complete the setting and write the data into PLC.
 - 3) Reset the CPU module, then the operation goes back to the normal operation.

Chapter 9: Programming

This chapter explains about programming for QE83WH4W. When you apply sample programs introduced in this chapter into the actual system, make sure to verify in advance that there is no problem with the target system control.

Follow the procedure in Figure 9.1 to create a sample program using QE83WH4W.

The default setting allows you to use either GX Developer (see Section 8.6 for the regular measuring mode and Section 7.2 for the current measuring mode) or the sequence program to make settings; however, if the setting is made for the first time by using GX Developer, the program for initial setting can be eliminated, which will reduce time for scanning.

9.1 Programming procedure

Follow the procedure in Figure 9.1 to create a program for acquiring the measured data, alarm monitoring, calculating periodical electricity amount using QE83WH4W.



Figure 9.1 Programming chart

9.2 System configuration and usage conditions for sample program

A sample program under the following system and the usage condition is shown below.

(1) System configuration



Figure 9.2 Sample system configuration using a sample program

(2) Setting conditions for the intelligent function of the module switch

Setting is as follows:

Table 9.1 Setting the intelligent function of the module switch

Switch No.	Switch name	Description
1	Not used	-
2	Not used	-
3	Not used	-
4	Measuring mode selection	0 (Regular operating mode)
5	Test mode transition	0 (Normal operation)

(3) Programming conditions

(a) Setting the operating conditions

- Phase wire : Three-phase 4-wire
- Input voltage : 220 / 380 V
- Primary current : 250 A
- Current demand time : 30 sec
- Electric power demand time : 30 sec
- Primary voltage of VT : 0
- Secondary voltage of VT : 0
- Primary current of CT : 0

(b) Alarm monitoring setting

- Alarm 1 item : Current demand upper limit
- Alarm 1 value : 100000 (100 A)
- Alarm 1 reset method : Auto reset
- Alarm 1 delay time
- Alarm 2 item
- Alarm 2 value : 120000 (120 A)
- Alarm 2 reset method : Self-retention
- Alarm 2 delay time : 5 sec

: Current demand upper limit

: 5 sec

9 Programing

(c) Data acquisition clock settingOutput period of data acquisition clock : 1000 (1sec)

(4) Before creating a program

Before creating a program, attach QE83WH4W to the base unit, and connect it to external devices.

Eurrent sensor: EMU-CT250 Voltage transform unit: QE8WH4VT



Figure 9.3 Example of wiring using a sample program

(5) Sample programming

(a) List of devices

(a) List of devices	Table 9.2 List of devices			
Device	Function			
D0	Device that stores Multiplier of electric energy			
D2, D3	Device that stores electric energy (consumption)			
D4, D5	Periodic electric energy 1			
D6, D7	Periodic electric energy 2			
D8, D9	Device that stores average current			
D10, D11	Device that stores average voltage			
D12, D13	Device that stores electric power			
D14, D15	Device that stores reactive power			
D16, D17	Device that stores power factor			
D18, D19	Device that stores frequency			
D28	Device that stores latest error code			
X0	Module ready			
X1	Output period of data acquisition			
	clock	4		
X2	Operating condition setting			
	completion flag	4		
X9	Alarm 1 flag	QE83WH4W		
XA	Alarm 2 flag	(X/Y0 to X/Y1F)		
X1F	Error flag	-		
Y5	Periodic electric energy 1			
	measurement flag	-		
Y6	Periodic electric energy 2			
	measurement flag	4		
Y2	Operating condition setting request			
	Device that the user will turn ON in			
X21	order to cancel error after CH1 alarm			
	2 occur	4		
	Device that the user will turn ON in	QX40		
X2E	order to support measurement of	(X20 to X2F)		
	CH1 periodic electric energy	4		
VOF	Device that the user will turn ON in			
X2F	order to reset integrated value of			
	CH1 Device that turns ON to send an			
Y30				
130	output to the external device when the CH1 alarm 1 occurs			
	Device that turns ON to send an	4		
Y31	output to the external device when	QY40		
131	the CH1 alarm 2 occurs	(Y30 to Y3F)		
	Device that turns ON to send an	1		
Y32	output to the external device in the			
	case of an error			

(b) List of buffer memories to be used

Device	Description	Setting value	Remarks
U0\G0	Phase wire method	4	Three-phase 4-wire
U0\G1	Input voltage	109	220 / 380 V
U0\G2	Primary current	3	250 A
U0\G3	Current demand time	30	30 sec
U0\G4	Electric power demand time	30	30 sec
U0\G5	Primary voltage of VT	0	When Primary voltage(U0\G1) is axpect 0
U0\G6	Secondary voltage of VT	0	When Primary voltage(U0\G1) is axpect 0
U0\G7	Primary current of CT	0	When Primary current (U0\G2) is axpect 0
U0\G11	Alarm 1 item	1	Current demand upper limit
U0\G12, 13	Alarm 1 value	100000	100 A
U0\G14	Alarm 1 reset method	1	Auto reset
U0\G15	Alarm 1 delay time	5	5 sec
U0\G21	Alarm 2 item	1	Current demand upper limit
U0\G22, 23	Alarm 2 value	120000	120 A
U0\G24	Alarm 2 reset method	0	Self-retention
U0\G25	Alarm 2 delay time	5	5 sec
U0\G51	Electric energy preset item	19	CH1 Total integrated value
U0\G52,53	Electric energy preset value	0	0kWh(kvarh)
U0\G60, 61	Output period of data acquisition clock	1000	1 sec
U0\G100	Multiplier of electric energy	-	Stores multiplier of electric energy
U0\G102, 103	Electric energy (consumption)	-	Stores electric energy
U0\G114,115	Periodic electric energy 1	-	Stores Periodic electric energy 1
U0\G116,117	Periodic electric energy 2	-	Stores Periodic electric energy 2
U0\G218, 219	Average current	-	Stores average current
U0\G314, 315	Average value voltage (L-L)	-	Stores average value voltage (L-L)
U0\G316, 317	Average value voltage (L-N)	-	Stores average value voltage (L-N)
U0\G402, 403	Active energy	-	Stores active energy
U0\G502, 503	Reactive power	-	Stores reactive power
U0\G602, 603	Apparent power	-	Stores apparent power
U0\G702, 703	Power factor	-	Stores power factor
U0\G802, 803	Frequency	-	Stores frequency
U0\G4500	Latest error code	-	Stores latest error code

Table 8.3 List of buffer memories to b	he used
	Je useu





QE83WH4W



Figure 9.4 Example of a sample program (continued)

QE83WH4W



Figure 9.4 Example of a sample program (continued)

9 Programing

9.3 System configuration and usage conditions for the current measuring mode

A sample program is shown below based on the following system and the usage condition.

(1) System configuration



Figure 9.5 Sample system configuration using a sample program

(2) Setting conditions for the intelligent function of the module switch

Setting is as follows:

Table 9.4 Intelligent function module switch setting

Switch No.	Switch name	Description
1	Not used	-
2	Not used	-
3	Not used	-
4	Measuring mode selection	1 (Current measuring mode)
5	Test mode transition	0 (Normal operation)

: 250 A

(3) Programming conditions

(a) Operating condition setting

- Channel to be used : CH1, CH2, CH3
- Primary current
- CH1, CH2, and CH3 current demand time: 30 sec.
- Primary current of CT : 0 (when CH1, 2, and 3 primary current is other than 0)

(b) Alarm monitoring setting

- CH1, CH2, and CH3 alarm 1 item : Maximum current demand
- CH1, CH2, and CH3 alarm 1 value : 100000 (100 A)
- CH1, CH2, and CH3 alarm 1 reset method : Auto reset
- CH1, CH2, and CH3 alarm 1 delay time : 5 sec.
- CH1, CH2, and CH3 alarm 2 item : Maximum current demand
- CH1, CH2, and CH3 alarm 2 value : 120000 (120 A)

- CH1, CH2, and CH3 alarm 2 reset method : Self-retention

- CH1, CH2, and CH3 alarm 2 delay time : 5 sec.

(c) Data acquisition clock setting

- Output period of data acquisition clock : 500 (0.5 sec.)

(4) Before creating a program

Before creating a program, attach QE83WH4W to the base unit, and connect it to external devices.

Electric current sensor: EMU-CT250 (Split type)





(5) Sample program using parameters of the intelligent function module

A sample program is shown below based on the following system and the usage condition.

(a) List of devices

	Table 9.5 List of devices		
Device	Function		
D0, D1	Device that stores CH1 current		
D4, D5	Device that stores CH2 current		
D6, D7	Device that stores CH3 current		
D10	Device that stores latest error code	T	
X0	Module ready		
X2	Operating condition setting		
Λ <u>Σ</u>	completion flag	_	
Х9	CH1 alarm 1 flag	_	
ХА	CH1 alarm 2 flag	QE84WH	
ХВ	CH2 alarm 1 flag		
XC	CH2 alarm 2 flag	(X/Y0 to X/Y1F)	
XD	CH3 alarm 1 flag		
XE	CH3 alarm 2 flag		
X1F	Error flag		
Y2	Operating condition setting request		
Voi	Device that the user will turn ON in order to cancel		
X21	error after CH1 alarm 2 occur		
Voo	Device that the user will turn ON in order to cancel	QX40	
X23	error after CH2 alarm 2 occur	(X20 to X2F)	
X25	Device that the user will turn ON in order to cancel		
720	error after CH3 alarm 2 occur		
V20	Device that turns ON to send an output to the external		
Y30	device when the CH1 alarm 1 occurs		
V24	Device that turns ON to send an output to the external		
Y31	device when the CH1 alarm 2 occurs		
Voo	Device that turns ON to send an output to the external		
Y32	device when the CH2 alarm 1 occurs		
Y33	Device that turns ON to send an output to the external	QY40	
155	device when the CH2 alarm 2 occurs	(Y30 to Y3F)	
Y34	Device that turns ON to send an output to the external		
104	device when the CH3 alarm 1 occurs		
Y35	Device that turns ON to send an output to the external		
100	device when the CH3 alarm 2 occurs		
Y3F	Device that turns ON to send an output to the external		
	device in the case of an error.		

(2) List of buffer memories to be used

Table 9.8 List of buffer memories to be used

Device	Description		Setting value	Remarks
U0\G4003	All CHs	Primary current	3	250 A
U0\G4005		Primary current of CT	0	When CH1, 2, 3 primary current (Un\4003) is other than 0
U0\G4004	CH1	Current demand time	30	30 sec.
U0\G4054	CH2	Current demand time	30	30 sec.
U0\G4011	CH1	Alarm 1 item	1	Maximum current demand
U0\G4012, 4013		Alarm 1 value	100000	100 A
U0\G4014		Alarm 1 reset method	1	Auto reset
U0\G4015		Alarm 1 delay time	5	5 sec.
U0\G4021		Alarm 2 item	1	Maximum current demand
U0\G4022, 4023		Alarm 2 value	120000	120 A
U0\G4024		Alarm 2 reset method	0	Self-retention
U0\G4025		Alarm 2 delay time	5	5 sec.
U0\G4061	CH2	Alarm 1 item	1	Maximum current demand
U0\G4062, 4063		Alarm 1 value	1000000	100 A
U0\G4064		Alarm 1 reset method	0	Auto reset
U0\G4065		Alarm 1 delay time	5	5 sec.
U0\G4071		Alarm 2 item	1	Maximum current demand
U0\G4072, 4073		Alarm 2 value	120000	120 A
U0\G4074		Alarm 2 reset method	0	Self-retention
U0\G4075		Alarm 2 delay time	5	5 sec.
U0\G4111	CH3	Alarm 1 item	1	Maximum current demand
U0\G4112, 4113		Alarm 1 value	1000000	100 A
U0\G4114		Alarm 1 reset method	0	Auto reset
U0\G4115		Alarm 1 delay time	5	5 sec.
U0\G4121		Alarm 2 item	1	Maximum current demand
U0\G4122, 4123		Alarm 2 value	120000	120 A
U0\G4124		Alarm 2 reset method	0	Self-retention
U0\G4125		Alarm 2 delay time	5	5 sec.
U0\G4000	All CHs	Output period of data acquisition clock	500	0.5 sec.
U0\G4032, 4033	CH1	Current	-	Stores the current measurement.
U0\G4082, 4083	CH2	Current	-	Stores the current measurement.
U0\G4132, 4133	СНЗ	Current	-	Stores the current measurement.
U0\G4500	Latest error code	÷	-	Stores the latest error code.

1. Initial setting program for QE83WH4W 0 X0 X2 0 1 Module Flag for	{MOV	K3	U0\ G4003 and 2 primary)	
READY complete operating condition		curre	ent		
setting	(MOV	K3 Prima CT	U0\ G4005 ary current of	ł	
	{MOV	K30	U0\ G4004 CH1 Current demand time		Basic operating condition setting
	{mov	K30	U0\ G4054 CH2 Current demand time	ŀ	
	 [MOV	K30	U0\ G4104 CH3 Current	ŀ	
	{mov	K1	U0\ G4011 Alarm 1 item		
	 {DMOV	K 100000	U0\ G4012	ŀ	
	 {mov	K1	U0\ G4014		CH1 Alarm 1 ► operating condition setting
			Alarm 1 reset method		
	[MOV	К5	U0\ G4015 Alarm 1 delay time		
	[MOV	K1	U0\ ^{G4021} Alarm 2 item		
	(DMOV	K120000	U0\ G4022 T Alarm 2 value	ł	CH1 Alarm 2
	(MOV		U0\ G4024 Alarm 2 reset		► operating condition setting
	[MOV	К5	U0\ G4025 Alarm 2 delay	ŀ	
			time		

Figure 9.7 Example of a sample program



Figure 9.7 Example of a sample program (continued)



Figure 9.7 Example of a sample program (continued)



Chapter 10: Troubleshooting

10.1 List of error codes

When the data are written to the CPU module from this module or when a reading error occurs, error codes will be stored into the following buffer memory.

Table 10.1 Latest error code	storage destination upon error occurrence

	rage destination upon enor occurrence
Latest error code	Time of error occurrence
Un¥G4500	Un¥G4501 to Un¥G4504

Table below shows error codes.

Table 10.2 List of error codes

Error code	Error	Measuring	Descriptions	Action	Reference
(HEX)	level	mode	 	Turn the power OFF/ON. If the error recurs, the module may	
0002h 0003h	Mid	All modes	Hardware error with the module.	have a failure. Consult with a nearest sales agent or our company branch for the symptom of the failure.	-
1001h	Low	Regular operating	Phase wire method is set out of range.	Check phase wire method, and set it within 1-3.	Section 6.2.1
1002h	Low	Regular operating	Input voltage is set out of range.	Set it within 1 to 9 according to the input voltage.	Section 6.2.2
1003h (CH1), 1013h (CH2) 1023h (CH3)	Low	Regular operating	Primary current is set out of range.	Set it within the range* of 1 to 5, 501 to 536 according to the primary current.	Section 6.2.3
1004h (CH1), 1014h (CH2) 1024h (CH3)	Low	Regular operating	Current demand time is set out of range.	Set current demand time within the range* of 0 to 1800 (seconds).	Section 6.2.4
1005h (CH1), 1015h (CH2) 1025h (CH3)	Low	Regular operating	Electric power demand time is set out of range.	Set electric power demand time within the range* of 0 to 1800 (seconds).	Section 6.2.5
100Dh	Low	Regular operating	Primary voltage of VT is set out of range.	Set primary voltage of VT within the range* of 0 to 6600 (V).	Section 6.2.2
100Eh	Low	Regular operating	Secondary voltage of VT is set out of range.	Set secondary voltage of VT within the range* of 0 to 220 (V).	Section 6.2.2
100Fh (CH1), 101Fh (CH2) 102Fh (CH3)	Low	Regular operating	Primary current of CT is set out of range.	Set primary current of CT within the range* of 0 to 6000 (A).	Section 6.2.3
1006h (CH1), 1016h (CH2) 1026h (CH3)	Low	Regular operating	Alarm 1 item is set out of range.	Set alarm 1 item within 1 to 8.	Section 6.2.9
1007h (CH1), 1017h (CH2) 1027h (CH3)	Low	Regular operating	Alarm 2 item is set out of range.	Set alarm 2 item within 1 to 8.	Section 6.2.9
1008h (CH1), 1018h (CH2) 1028h (CH3)	Low	Regular operating	Alarm 1 reset method is set out of range.	Set alarm 1 reset method within 0 to 1.	Section 6.2.11
1009h (CH1), 1019h (CH2) 1029h (CH3)	Low	Regular operating	Alarm 2 reset method is set out of range.	Set alarm 2 reset method within 0 to 1.	Section 6.2.11
100Ah(CH1), 101Ah(CH2) 102Ah(CH3)	Low	Regular operating	Alarm 1 delay time is set out of range.	Set alarm 1 delay time within the range* of 0 to 300 (seconds).	Section 6.2.12
100Bh(CH1), 101Bh(CH2) 102Bh(CH3))	Low	Regular operating	Alarm 2 delay time is set out of range.	Set alarm 2 delay time within the range* of 0 to 300 (seconds).	Section 6.2.12
100Ch	Low	Regular operating	Electric energy preset value is set out of range.	Set electric energy preset value within the range* of 0 to 9999999999 in the double word format (32-bit integer).	Section 6.2.13
1041h	Low	Current measuring	Output period of data acquisition clock is set out of range.	Set the output period of data acquisition clock within the range* of 0 to 86400000 in the double word format (32-bit integer).	Section 6.2.12
2000h	Low	Current measuring	Output period of data acquisition clock is set out of range.	Set the output period of data acquisition clock within the range* of 0 to 86400000 in the double word format (32-bit integer).	Section 6.2.12
2001h(CH1), 2021h(CH3) 2041h(CH5), 2061h(CH7)	Low	Current measuring	Primary current is set out of range.	Set it within the range* of 1 to 5 or 501 to 536 according to the primary current.	Section 6.2.3
2002h(CH1), 2012h(CH2) 2022h(CH3), 2032h(CH4) 2042h(CH5), 2052h(CH6) 2062h(CH7), 2072h(CH8)	Low	Current measuring	Current demand time is set out of range.	Set the current demand time within the range* of 0 to 1800 (seconds).	Section 6.2.4
2003h(CH1), 2013h(CH2)	Low	Current	Alarm 1 item is set out of range.	Set the alarm 1 item within the range	Section

Error code	Error	Measuring	Descriptions	Action	Reference
(HEX)	level	mode	•		
2023h(CH3), 2033h(CH4)		measuring		of 0 to 8.	6.2.9
2043h(CH5), 2053h(CH6)					
2063h(CH7), 2073h(CH8)					
2004h(CH1), 2014h(CH2)	Low				
2024h(CH3), 2034h(CH4)		Current		Set the alarm 2 item within the range	Section
2044h(CH5), 2054h(CH6)		measuring	Alarm 2 item is set out of range.	of 0 to 8.	6.2.9
2064h(CH7), 2074h(CH8)					
2005h(CH1), 2015h(CH2)	Low				
2025h(CH3), 2035h(CH4)		Current	Alarm 1 reset method is set out	Set the alarm 1 reset method within	Section
2045h(CH5), 2055h(CH6)		measuring	of range.	the range of 0 to 1.	6.2.11
2065h(CH7), 2075h(CH8)			orrange.		
2006h(CH1), 2016h(CH2)	Low				
2026h(CH3), 2036h(CH4)		Current	Alarm 2 reset method is set out	Set the alarm 2 reset method within	Section
2046h(CH5), 2056h(CH6)		measuring	of range.	the range of 0 to 1.	6.2.11
2066h(CH7), 2076h(CH8)			or range.		
2007h(CH1), 2017h(CH2)	Low				
2027h(CH3), 2037h(CH4)		Current	Alarm 1 delay time is set out of	Set the alarm 1 delay time within the	Section
2047h(CH5), 2057h(CH6)		measuring	range.	range* of 0 to 300 (seconds).	6.2.12
2067h(CH7), 2077h(CH8)			range.	Tange of 0 to 500 (seconds).	
2008h(CH1), 2018h(CH2)	Low				
2028h(CH3), 2038h(CH4)		Current	Alarm 2 delay time is set out of	Set the alarm 2 delay time within the	Section
2048h(CH5), 2058h(CH6)		measuring	range.	range* of 0 to 300 (seconds).	6.2.12
2068h(CH7), 2078h(CH8)			range.		
2009h(CH1), 2029h(CH3),	Low	Current	Primary current of CT is set out	Set primary current of CT within the	Section
2049h(CH5), 2069h(CH7),		measuring	of range.	range* of 1 to 6000 (A).	6.2.8
0000h	-	All mode	Normal	-	-

* Also check that it is set in decimal.

10.2 Troubleshooting

10.2.1 When "0" LED (RUN) is turned off

Table 10.3 When "0" LED is turned off

Check item	Action	Reference
Is power source is supplied?	Check that supply voltage of the power source is within the rating.	Section 3.1
Is capacity of the power source module sufficient?	Calculate the consumption current of CPU module, I/O module, and intelligent function module attached to the base unit, and check that the power capacity is sufficient.	-
Is the watchdog time an error?	Reset CPU module, and check whether it is turned on. If RUN LED is not turned on even after doing the above, the module may have a failure. Consult with a nearest sales agent or our company branch for the symptom of the failure.	-
Is the module properly attached to the base unit?	Check the module attachment status.	-
Is the slot type set to "empty" in the I/O assignment setting of the PC parameter at GX Developer?	Set the slot type to "Intelligent".	Section 8.5.1

10.2.2 When "8" LED (ERR) is turned on or flashing

(1) If it is ON

Table 10.4 When "8" LED is turned on

Check item	Action	Reference
	Check latest error code (Un\G4500), and take a corrective	
	action as described in section 10.1. After that, reset CPU	
Did any array appur?	module, and check whether it is turned on.	Section 10.1
Did any error occur?	If "8" LED is turned on even after doing the above, the	Section 10.1
	module may have a failure. Consult with a nearest sales	
	agent or our company branch for the symptom of the failure.	

(2) If it is flashing

Table 10.5 When "8" LED is flashing

Check item	Action	Reference
	The set value may be out of range. Check that the operating	
	condition settings and the integrated value are correct.	
	Correct configuration or turning Error clear request (Y1F*) ON	Section 8.6.3
Did any error occur?	will clear the error. When the error is cleared by Error clear	Section 6
	request (Y1F*), the operation continues according to the	Section 5.2.2
	previous settings.	
	* In the case where the initial I/O number of this module is 0	

Note that electric energy is not measured in the current measuring mode.

		Table 1	0.6 If electr	ic energy c	annot be measured	
Check	item		-	-	Solution	Reference
CH1	"1" LED is OFF.	"4" LED is OFF.	"9" LED is OFF.	"C" LED is OFF.	 The type of current sensor may be incorrect. In addition, if the rating of the sensor in use is different from the primary current, measurement cannot be taken correctly. Wiring is not done or wrong. Refer to Section 7.5 to check the wiring. Voltage wiring may be incorrect. Check connection of P1, P2, and P3. 	Section 8.5
CH2	"2" LED is OFF.	"5" LED is OFF.	"A" LED is OFF.	"D" LED is OFF.		
CH3	"3" LED is OFF.	"6" LED is OFF.	"B" LED is OFF.	"E" LED is OFF.		
CH1	"1" LED is flashing.	"4" LED is ON.	"9" LED is ON.	"C" LED is ON.	1) Current sensors on side 1 and side 3 may be installed in the reverse order or	
CH2	"2" LED is flashing.	"5" LED is ON.	"A" LED is ON.	"D" LED is ON.	current sensors on side 1 and side 3 may be swapped. Check the connection.	
СНЗ	"3" LED is flashing.	"6" LED is ON.	"B" LED is ON.	"E" LED is ON.	2) Voltage wiring may be incorrect. Check connection of P1, P2, and P3.	
CH1	"1" LED is ON, flashing, or OFF.	"4" LED is ON.	"9" LED is OFF.	"C" LED is OFF.	1) Current sensor on side 1 may be installed in the reverse order. Check the	
CH2	"2" LED is ON, flashing, or OFF.	"5" LED is ON.	"A" LED is OFF.	"D" LED is OFF.	connection. 2) Voltage wiring may be incorrect. Check	
CH3	"3" LED is ON, flashing, or OFF.	"6" LED is ON.	"B" LED is OFF.	"E" LED is OFF.	connection of P1, P2, and P3.	
CH1	"1" LED is ON, flashing, or OFF.	"4" LED is OFF.	"9" LED is ON.	"C" LED is OFF.	1) Current sensor on side 2 may be installed in the reverse order. Check the	
CH2	"2" LED is ON, flashing, or OFF.	"5" LED is OFF.	"A" LED is ON.	"D" LED is OFF.	connection. 2) Voltage wiring may be incorrect. Check	
CH3	"3" LED is ON, flashing, or OFF.	"6" LED is OFF.	"B" LED is ON.	"E" LED is OFF.	connection of P1, P2, and P3.	
CH1	"1" LED is ON, flashing, or OFF.	"4" LED is OFF.	"9" LED is OFF.	"C" LED is ON.	1) Current sensor on side 3 may be installed in the reverse order. Check the	
CH2	"2" LED is ON, flashing, or OFF.	"5" LED is OFF.	"A" LED is OFF.	"D" LED is ON.	connection. 2) Voltage wiring may be incorrect. Check	
СНЗ	"3" LED is ON, flashing, or OFF.	"6" LED is OFF.	"B" LED is OFF.	"E" LED is ON.	connection of P1, P2, and P3.	
CH1	"1" LED is ON.	"4" LED is OFF.	"9" LED is OFF.	"C" LED is OFF.	1) Measurement is taken normally. Check for the correct buffer memory address and	Chapter 6
CH2	"2" LED is ON.	"5" LED is OFF.	"A" LED is OFF.	"D" LED is OFF.	data format (double word: 32-bit integer).	
СНЗ	"3" LED is ON.	"6" LED is OFF.	"B" LED is OFF.	"E" LED is OFF.		

Table 10.6 If electric energy cannot be measured

10.2.4 If the electric current and voltage that are measured using this module do not match with the ones measured with other gauge

Table 10.7 If current and voltage that are measured using this module do not match with the ones measured with other gauge

	neasured with other gauge	
Check item	Action	Reference
Are primary current, and input voltage correct?	Check the value in the buffer memory for checking input current and primary voltage. When the value in the buffer memory is changed, you need to turn the request for operating condition setting into ON. Otherwise, it will not be applied to the measurement.	Section 6.1
Does the compared gauge measure the effective value correctly?	This module stores the effective value into the buffer memory. If the compared device uses the average value instead of the effective value, the resulted value may largely differ when there is current distortion in the measurement circuit.	-
Is the secondary of CT short-circuited?	Make sure that the secondary of CT is not short-circuited. If it is connected to Mitsubishi's current transformer CW-5S(L), check that the secondary switch is not short-circuited.	-
Are you using other current sensor than recommended ones?	Only the dedicated current sensors can be connected to this module. Check that other company's sensor is not being used.	-
Are you using the voltage transform unit?	Circuit voltage can not be entered directly into this module. Enter the output voltage of the voltage transform unit (QE8WH4VT).	-
Do you connect the voltage transform unit has been done correctly?	Please check whether wiring of the is voltage transform unit performed correctly.	-

10.3 Q&A

10.3.1	General
Q	To what degree is the module durable against overvoltage and overcurrent? Is external
Q	protective circuit required?
	Momentary*: Up to 2 times as high as rated voltage and 20 times as high as rated current.
A	Continuous : Up to 1.1 times as high as rated voltage and rated current.
	* Momentary means: Energizing 9 times for 0.5 seconds at 1-minute intervals, and then 1 time
	for 5 seconds.
Q	Can the module be used as an electric energy meter?
	This module can be used to measure the electric energy and to manage the use of electric
A	energy.
^	However, it cannot be used for deal and proof of electric energy measurement stipulated in the
	measurement law.
Q	Are errors in wiring verifiable easily?
	They are verifiable by the illuminating condition of "MEA.," "1," "2," and "3" LEDs on the front of
Α	the module.
	Refer to Section 9.2.3 for details.
Q	Is it OK to open the secondary terminals of the current sensor?
	The secondary side of the models EMU2-CT5-4W, EMU-CT50, EMU-CT100, and EMU-CT250
	is equipped with the protective circuit against opening of secondary terminals. Opening them
	during the wiring work causes no problems. However, for safety, please do not continuously
	energize the module with the terminals open.
Α	The secondary side of the models EMU-CT400 and EMU-CT600 is equipped with the protective
	circuit against opening of secondary terminals. However, during the wiring work, be sure to turn
	the secondary side short-circuit switch to short. After completion of work, be sure to turn the
	secondary short-circuit switch to open. Note that failing to turn the switch open results in an
	inaccurate measurement.
0	
Q	Is measurement of inverter circuit possible?
	Measuring the secondary side of the inverter is impossible due to the large fluctuation of
	frequency.
A	Make measurement on the primary side of the inverter. However, since a current waveform on
	the primary side of the inverter has a distortion containing the harmonic components, a slight
	error occurs.

	If a load such as welding equipment exists, a current flows only for a short period (e.g.
Q	2-cycle waveform of commercial frequency (50 Hz: 40 ms, 60 Hz: 33 ms)). Is accurate
	measurement possible?
	This module makes measurement with a sampling period of 4340 Hz (for both 50 Hz and
	60 Hz). However, measuring part of buffer memory data (Un¥G100 to Un¥G2999) is updated
	every 500 ms. The electrical amount such as current, voltage, electric power, power factor, and
Α	frequency is measured in a cycle of 500 ms period.
	The amount of electricity and reactive power amount are measured separately from the
	momentary data described above, using a sampling period of 4340 Hz continuously without
	intermittence. Therefore, measuring the load for a short period is possible.
Q	Obtained values may be different from other measuring instruments. Why is it so?
	There are various possible causes. Check the following first, please:
	[1] Check for wiring errors (polarity of current sensors, connections of current circuits, and
	connections of voltage circuits, in particular).
	[2] On the split-type current sensor, check for the poor engagement or separation of fitting
	surfaces.
	[3] On the split-type current sensor, check for pinching of foreign object between fitting surfaces.
Α	[4] Check that the measuring instrument used for comparison indicates a correct RMS value.
	[5] If the measuring instrument used for comparison measures an average value instead of rms
	value, distortion in the current of the circuit to be measured causes a significant difference of
	values. This module measures an rms value.
	[6] Check for the short-circuit on the secondary side of the current transformer (CT).
	[7] Current sensor connectable to the module is the dedicated current sensor only. Check that
	the proper current sensor is connected or not.

10.3.2 Q&A about Specifications

Q	What accuracy does "measuring accuracy" mean?
A	In terms of the amount of electricity, it means a range of tolerances in reading values. For example, when the reading value is "10 kWh," a tolerance is ± 0.2 kWh. In terms of measuring elements other than the amount of electricity, it means tolerance for the rated input. For a current, when a rated current is set to 250 A, $\pm 1\%$ of 250 A is a tolerance.
Q	Is accuracy of a current sensor and the voltage transform unit included?
A	Accuracy of a current sensor and the voltage transform unit are not included in accuracy of the module. A maximum value of tolerance is obtained by summing tolerance of the module and that of a current sensor and the voltage transform unit.
Q	To what degree an area of microcurrent is measured?
A	A current value is measured from the area exceeding 0.4% of the rated current. In an area below 0.4%, measurement result is indicated as "0" (zero). However, in that case, still, the amount of electricity is being measured. Even if the indicated value is "0," measurement value will increase in continuing measurement for a long time. The amount of electricity is measured with a load that is about 0.4% or more of all load power.



10.3.3 Q&A about Installing

Q	What is wire diameter that allows installing a current sensor?
A	 The following lists the nominal cross-sectional areas of the conductor of 600-V vinyl coated wires that can penetrate (values for reference). IV wire (600-V vinyl insulated wire) 60 mm² (EMU-CT50/CT100), 150 mm² (EMU-CT250) 500 mm² x 1 wire, 325 mm² x 2 wires (EMU-CT400/CT600) CV wire (600-V vinyl insulated wire) 38 mm² (EMU-CT50/CT100), 150 mm² (EMU-CT250,100 mm² is recommended) 500 mm² x 1 wire, 325 mm² x 2 wires (EMU-CT400/CT600) The above shows the standard nominal cross-sectional areas. Due to the outer difference of finished vinyl insulation and deformation (bending) depending on manufacturers, a wire may not penetrate. Make verification on site.
Q	What are the points when installing a current sensor?
A	Models EMU2-CT5-4W, EMU-CT50, EMU-CT100, EMU-CT250, EMU-CT400 and EMU-CT600 are split-type. If split surfaces are not engaged sufficiently or a foreign object exists between the split surfaces, adequate performances are not obtained. Pay attention in installation.

10.3.4 Q&A about Connection

Q	Does polarity exist in connection between a current sensor and the module?
A	Yes, it does. Make connections so that secondary terminals of current sensor (k, l) and terminal symbols of module agree with each other. If polarity is incorrect, the current value is measurable, but the electric power and the electrical energy can not be measured correctly.
Q	Does polarity exist in connection between a voltage transform unit and the module?
A	Yes, it does. Make connections so that output terminals of voltage transform unit (PA, PB, PC, PD) and terminal symbols of module agree with each other. If polarity is incorrect, the voltage value, the electric power and the electrical energy can not be measured correctly.
_	
Q	Are there any key points in avoiding errors in wiring?
A	 Check polarity of current sensor on the primary current side. Power supply side of the circuit is indicated as "K," and the load is indicated as "L." An arrow indicates the direction from K to L. Check the current sensor and the module are connected correctly for the 1-side circuit, 2-side circuit, and 3-side circuit.
	Besides, check that voltage inputs for voltage transform unit are connected correctly among P1, P2, P3, and P0.
Q	How do wires extend between a current sensor and the module?
	Model EMU2-CT5-4W is extendable up to 11 m, using together with a cable supplied with the sensor. To

Q Is the setting required? A At least, settings of, primary current and input voltage are required. Specify settings in accordance with a circuit to be connected. Q If a primary current setting value is different from that of rated current on a connected current setting value is different from that of rated current on a connected current

 sensor, does it cause a breakdown?

 A
 It does not cause breakdown or burning. However, measurement values will be totally incorrect.

Appendix

Appendix 1: External dimensions



Unit [mm]

Appendix 2: Optional devices

EMU-CT*** model split current sensor

Item			Specifications	5	
Model	EMU-CT50	EMU-CT100	EMU-CT250	EMU-CT400	EMU-CT600
Rated primary current	50A AC	100A AC	250A AC	400A AC	600A AC
Rated secondary current	16.66mA	33.33mA	66.66mA	66.66mA	66.66mA
Rated burden			0.1VA		
Maximum voltage (voltage to ground ∕ line voltage)	266V/460V AC				
Ratio error	$\pm 1\%(5\%$ to 100% of rating, RL $\leq 10\Omega$)				
Phase displacement	±0.9 c rad(5% to 100% of rating, $RL \leq 10\Omega$)				
Measurement(installation)category	III				
Pollution degree					
Working temperature range	-5°C to +55°C (daily mean temperature: 35°C or less)				
Working humidity range	5% to 95%RH (no condensation)				
CE marking conformity standard	EN61010-2-32				
CE marking conformity standard Maximum voltage (voltage to ground ∕ line voltage)	127V/220V +10% AC				
Weight (per one)		0.1kg		0.7	kg

■ 5A current sensor

Item	Specifications
Model	EMU2-CT5-4W
Rated primary current	5A AC
Rated secondary current	1.66mA
Rated burden	0.1VA
Maximum voltage (voltage to ground ∕ line voltage)	150V/260V AC
Ratio error	$\pm 1\%$ (5% to 100% of rating, R _L $\leq 10\Omega$)
Phase displacement	±0.9 c rad(5% to 100% of rating, $R_L \leq 10\Omega$)
Measurement(installation)category	
Pollution degree	ll
Working temperature range	−5°C to +55°C (daily mean temperature: 35°C or less)
Working humidity range	5% to 95%RH (no condensation)
CE marking conformity standard	EN61010-2-32
CE marking conformity standard Maximum voltage	127V/220V +10% AC
Weight (per one)	0.1kg

Voltage transform unit

ltem		Specification				
Model		QE8WH4VT				
Phase wire s	system	Three-phase 4-wire				
Input voltage range		63.5/110 to 277/480 V AC (The product does not operate on the voltage below 55/95 V AC.)				
Frequency		50 Hz/60 Hz				
Voltage output tolerance		±1.0% (against the rated primary voltage)				
Measurement category						
Pollution deg	gree					
Maximum connections	number of	5 modules				
	Operating temperature	0°C to +55°C (Average daily temperature 35°C or below)				
Operating condition	Operating humidity	5% to 95% RH (without condensation)				
condition	Storage temperature	-25°C to +75°C				
	Altitude	2000 m or lower				
Commercial withstand vo		Between voltage input terminals (P1, P2, P3, P0) and FG terminal: 2210 V AC 5 sec Between voltage input terminals (P1, P2, P3, P0) and secondary output terminals (PA, PB, PC, PD) (except for SLD terminal) 2210 V AC 5 sec				
Insulation re	sistance	10 M Ω or more (500 V DC) at the same locations as above				
Consumption	n VA	P1-P0: 2 VA, P2-P0: 0.3 VA, P3-P0: 0.3 VA (when inputting 277/480 V AC)				
Installation lo	ocation	Inside the control panel				
Secondary wire length		5 m or less				
Installation method		Installation on IEC rails, installation with screws				
Weight		0.3kg				
Product life expectancy		10 years (used under the operating conditions above.)				
CE marking compliance		EN 61131-2, EN 61010-1, EN 61326-1				
Combined d	evice for CE	Compliant with CE when combined with the energy measuring module of				
marking com		Mitsubishi general-purpose sequencer MELSEC-Q series.				
Combined d UL/c-UL con		Compliant with UL/c-UL when combined with the energy measuring module of Mitsubishi general-purpose sequencer MELSEC-Q series.				

Current sensor

♦ EMU-CT50, EMU-CT100, EMU-CT250



Model	Α	В	С	D	E	F
EMU-CT50/CT100	31.5	39.6	55.2	25.7	15.2	18.8
EMU-CT250	36.5	44.8	66	32.5	22	24

♦ EMU-CT400, EMU-CT600



Unit [mm]

♦EMU2-CT5-4W





Unit [mm]

Dedicated cable

♦5A current sensor cable EMU2-CB-Q5B-4W



Dedicated voltage transform unit
 QE8WH4VT



Unit [mm]

Index

[5]
5A current sensor 8-14
5A current sensor cable8-14
[A]
Alarm 1 flag (XnA) 5-4
Alarm 1 reset request (YnA) 5-6
Alarm 2 flag (XnB) 5-4
Alarm 2 reset request (YnB) 5-6
Alarm delay time 4-11
Alarm flag
Alarm reset method 4-11
Applicable wire 8-8
Average value current 4-3
Average value voltage 4-3
[C]
Current demand time
(E)
Electric energy (consumption) 4-1
Electric energy (regeneration) 4-1
Electric power demand time
EMU2-CT5-4W
EMU-CT50/100/250/400/600
Error clear request5-7
Error flag
External dimensions A-1
(F)
Flag for periodic electric energy 4-7
Full load power
(H)
Max./min. value hold function
[]
Integrated value setting completion flag 5-3
Integrated value setting request
(L)
List of functions
List of I/O signals
[M]
Max./min. values clear completion flag ·· 4-10,5-3
Max./min. values clear request
Module ready
[N]
Name of each part8-3

[0]

Operating condition setting completion flag5-2
Operating condition setting request5-5
Output signal5-5
(P)
Periodic electric energy 4-1, 4-7
Periodic electric energy 1 data completion flag
5-3
Periodic electric energy 1 measurement flag5-6
Periodic electric energy 1 reset completion flag
5-3
Periodic electric energy 1 reset request5-6
Periodic electric energy 2 data completion flag
5-3
Periodic electric energy 2 measurement flag5-6
Periodic electric energy 2 reset completion flag
5-3
Periodic electric energy 2 reset request5-6
Periodic electric energy reset4-8
Primary current4-4
Primary voltage4-4
Programming9-1
[S]
Solderless terminal8-8
[T]
Test 4-1, 4-15
Test function 4-15
Troubleshooting 10-1
[U]
Upper/lower limit alarm monitoring 4-1, 4-11
[W]
Wiring diagram8-9

Warranty

For using this product, please thoroughly read the following product warranty descriptions.

1. Gratis Warranty Period and Gratis Warranty Coverage

If any failure or defect (hereinafter collectively called "failures") for which our company is held responsible occurs on the product during the gratis warranty period, our company shall replace the product for free through the distributor at which you purchased the product or our service company.

However, if an international travel is required for replacement, or a travel to an isolated island or remote location equivalent is required for replacement, the actual cost incurred to send an engineer(s) shall be charged. [Gratis Warranty Period]

The gratis warranty term of the product shall be for one year after the date of purchase or delivery to a designated place.

Note that after manufacture and shipment from Mitsubishi, the maximum distribution period shall be six (6) months, and the longest gratis warranty term after manufacturing shall be eighteen (18) months. The gratis warranty term of repair parts shall not exceed the gratis warranty term before repairs.

- [Gratis Warranty Coverage]
 - (1) The gratis warranty shall apply only if the product is being used properly in the conditions, with the methods and under the environments in accordance with the terms and precautions described in the instruction manual, user's manual, caution label on the product, etc.
 - (2) Replacement shall be charged for the following cases even during the gratis warranty period.
 - 1) Failures occurring due to your improper storage or handling, carelessness or fault, and failures arising from the design contents of hardware or software you use.
 - 2) Failures arising from modification you performed on the product without prior consent of our company.
 - 3) Failures occurring in the event that the product is assembled into the device you use and that are acknowledged as avoidable if the device is equipped with a safety mechanism that comply with the legal regulations applicable to the device or with functions/architecture which are considered as necessary to be equipped under conventions of the industry.
 - 4) Failures due to accidental force such as a fire, abnormal voltage, etc. and force majeure such as an earthquake, thunderstorm, wind, flood, etc.
 - 5) Failures due to matters unpredictable based on the level of science technology at the time of product
 - 6) Other failures which are beyond responsibility of our company or which you admit that our company is not held responsible for.

2. Fare-Paying Repair Period after Production Discontinued

- (1) The period our company may accept product replacement with charge shall be seven (7) years after production of the product is discontinued.
 - Production stoppage shall be announced in the technical news, etc. of our company.
- (2) The product (including spare) cannot be supplied after production is discontinued.

3. Exemption of Compensation Liability for Opportunity Loss, Secondary Loss, etc.

Our company shall not be liable to compensate for any loss arising from events not attributable to our company, opportunity loss and lost earning of the customer due to failure of the product, and loss, secondary loss, accident compensation, damage to other products besides our products and other operations caused by a special reason regardless of our company's predictability in both within and beyond the gratis warranty period.

4. Change of Product Specifications

Please be advised in advance that the specifications described in catalogs, manuals or technical materials are subject to change without notice.

5. Application of Products

- (1) For use of our general-purpose sequencer MELSEC-Q series and Energy Measuring Module QE83WH4W, they shall be used for a purpose which shall not lead to a material accident even when a failure or malfunction of the sequencer occurs, and a backup or fail-safe function shall be implemented systematically at external of the device in the event of a failure or malfunction.
- (2) Our general-purpose sequencers are designed and manufactured as general-purpose products which are targeted for general industry applications. Therefore, use of the sequencer for purposes in nuclear power plants and other power plants of each electric power company which greatly affect public, or for purposes in each JR company and the Defense Agency requiring a special quality assurance system shall be excluded from its applications.

However, the sequencer may be used for such purposes if the customer acknowledges that it should be used for limited purpose only and agrees not to require special quality.

Also, if you are considering to use this device for purposes that are expected to greatly affect human life or property and require high reliability especially in safety or control system such as aviation, medical care, railroad, combustion/fuel device, manned carrier device, entertainment machine, safety equipment, please consult with our service representative to exchange necessary specifications.

Customer Service

Please contact us at the following locations.

1 - 8 Midori-cho, Fukuyama-shi, Hiroshima, 720 - 8647, Japan

Phone (084) 926 - 8142

When exported from Japan, this manual dose noto require application to the Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.

MITSUBISHI ELECTRIC CORPORATION July, 2012 (LY303Z743G91)



HEADQUARTERS	
MITSUBISHI ELECTRIC EUROPE B.V. German Branch	EUROPE
Gothaer Straße 8 D-40880 Ratingen Phone: +49 (0)2102 / 486-0	
Fax: +49 (0)2102 / 486-1120 MITSUBISHI ELECTRIC EUROPE B.Vorg.sl. CZ	FCH REP
Avenir Business Park, Radlická 714/113a (Z-158 00 Praha 5 Phone: +420 - 251 551 470 Fax: +420 - 251-551 -471	
MITSUBISHI ELECTRIC EUROPE B.V. French Branch 25, Boulevard des Bouvets F-92741 Nanterre Cedex Phone: +33 (0) 1 / 55 68 55 68 Fax: +33 (0) 1 / 55 68 57 57	FRANCE
MITSUBISHI ELECTRIC EUROPE B.V. Irish Branch Westgate Business Park, Ballymount IRL-Dublin 24 Phone: +353 (0)1 4198800 Fax: +353 (0)1 4198890	IRELAND
MITSUBISHI ELECTRIC EUROPE B.V. Italian Branch Viale Colleoni 7 I-20041 Agrate Brianza (MB) Phone: +39 039 / 60 53 1 Fax: +39 039 / 60 53 312	ITALY
MITSUBISHI ELECTRIC EUROPE B.V. Poland Branch Krakowska 50 PL-32-083 Balice Phone: +48 (0)12 / 630 47 00 Fax: +48 (0)12 / 630 47 01	POLAND
MITSUBISHI ELECTRIC EUROPE B.V. 52, bld. 3 Kosmodamianskaya nab 8 floor RU-115054 Moscow Phone: +7 495 721-2070 Fax: +7 495 721-2071	RUSSIA
MITSUBISHI ELECTRIC EUROPE B.V. Spanish Branch	SPAIN
Carretera de Rubí 76-80 E-08190 Sant Cugat del Vallés (Barcel Phone: 902 131121 // +34 935653131 Fax: +34 935891579	ona)
MITSUBISHI ELECTRIC EUROPE B.V. UK Branch Travellers Lane UK-Hatfield, Herts. AL10 8XB Phone: +44 (0)1707 / 27 61 00	UK
Fax: +44 (0)1707 / 27 86 95	
MITSUBISHI ELECTRIC CORPORATION Office Tower "Z" 14 F 8-12,1 chome, Harumi Chuo-Ku Tokyo 104-6212 Phone: +81 3 622 160 60 Fax: +81 3 622 160 75	JAPAN
MITSUBISHI ELECTRIC AUTOMATION, Inc. 500 Corporate Woods Parkway Vernon Hills, IL 60061 Phone: +1 847 478 21 00 Fax: +1 847 478 22 53	USA

EUROPEAN REPRESENTATIVES GEVA AUSTRIA Wiener Straße 89 AT-2500 Baden Phone: +43 (0)2252 / 85 55 20 Fax: +43 (0)2252 / 488 60 TECHNIKON BELARUS Oktyabrskaya 19, Off. 705 **BY-220030 Minsk** Phone: +375 (0)17 / 210 46 26 Fax: +375 (0)17 / 210 46 26 ESCO DRIVES & AUTOMATION BELGIUM Culliganlaan 3 BE-1831 Diegem Phone: +32 (0)2 / 717 64 30 Fax: +32 (0)2 / 717 64 31 Koning & Hartman b.v. BELGIUM Woluwelaan 31 BE-1800 Vilvoorde Phone: +32 (0)2 / 257 02 40 Fax: +32 (0)2 / 257 02 49 INEA RBT d.o.o. **BOSNIA AND HERZEGOVINA** Aleia Lipa 56 BA-71000 Sarajevo Phone: +387 (0)33 / 921 164 Fax: +387 (0)33 / 524 539 AKHNATON BULGARIA 4, Andrei Ljapchev Blvd., PO Box 21 **BG-1756 Sofia** Phone: +359 (0)2 / 817 6000 Fax: +359 (0)2 / 97 44 06 1 INEA RBT d.o.o. CROATIA Losiniska 4 a HR-10000 Zagreb Phone: +385 (0)1/36940-01/-02/-03 Fax: +385 (0)1 / 36 940 - 03 AutoCont C.S. s.r.o. CZECH REPUBLIC Technologická 374/6 **CZ-708 00 Ostrava-Pustkovec** Phone: +420 595 691 150 Fax: +420 595 691 199 **Beijer Electronics A/S** DENMARK Lykkegårdsvej 17 DK-4000 Roskilde Phone: +45 (0)46/757666 Fax: +45 (0)46 / 75 56 26 Beijer Electronics Eesti OÜ ESTONIA Pärnu mnt.160i EE-11317 Tallinn Phone: +372 (0)6 / 51 81 40 Fax: +372 (0)6 / 51 81 49 **Beijer Electronics OY** FINLAND Peltoie 37 FIN-28400 Ulvila Phone: +358 (0)207 / 463 540 Fax: +358 (0)207 / 463 541 UTECO GREECE 5, Mavrogenous Str. GR-18542 Piraeus Phone: +30 211 / 1206 900 Fax: +30 211 / 1206 999 MELTRADE Kft. HUNGARY Fertő utca 14. HU-1107 Budapest Phone: +36 (0)1 / 431-9726 Fax: +36 (0)1 / 431-9727 Beijer Electronics SIA LATVIA Ritausmas iela 23 **LV-1058 Riga** Phone: +371 (0)784 / 2280 Fax: +371 (0)784 / 2281 **Beijer Electronics UAB** LITHUANIA Savanoriu Pr. 187 LT-02300 Vilnius Phone: +370 (0)5 / 232 3101 Fax: +370 (0)5 / 232 2980

EUROPEAN REPRESENTATIVES ALFATRADE Ltd. MALTA 99. Paola Hill Malta- Paola PLA 1702 Phone: +356 (0)21 / 697 816 Fax: +356 (0)21 / 697 817 INTEHSIS srl MOLDOVA bld. Traian 23/1 MD-2060 Kishinev Phone: +373 (0)22 / 66 4242 Fax: +373 (0)22 / 66 4280 HIFLEX AUTOM.TECHNIEK B.V. NETHERLANDS Wolweverstraat 22 NL-2984 CD Ridderkerk Phone: +31 (0)180 - 46 60 04 Fax: +31 (0)180 - 44 23 55 Koning & Hartman b.v. NETHERLANDS Haarlerbergweg 21-23 NL-1101 CH Amsterdam Phone: +31 (0)20 / 587 76 00 Fax: +31 (0)20 / 587 76 05 Beijer Electronics AS NORWAY Postboks 487 NO-3002 Drammen Phone: +47 (0)32 / 24 30 00 Fax: +47 (0)32 / 84 85 77 Fonseca S.A. PORTUGAL R. João Francisco do Casal 87/89 **PT - 3801-997 Aveiro, Esgueira** Phone: +351 (0)234 / 303 900 Fax: +351 (0)234 / 303 910 Sirius Trading & Services srl Aleea Lacul Morii Nr. 3 ROMANIA RO-060841 Bucuresti, Sector 6 Phone: +40 (0)21 / 430 40 06 Fax: +40 (0)21 / 430 40 02 INEA RBT d.o.o. SERBIA Izletnicka 10 SER-113000 Smederevo Phone: +381 (0)26 / 615 401 Fax: +381 (0)26 / 615 401 SIMAP s.r.o. **SLOVAKIA** lána Derku 1671 SK-911 01 Trencín Phone: +421 (0)32 743 04 72 Fax: +421 (0)32 743 75 20 PROCONT, spol. s r.o. Prešov SLOVAKIA Kúpelná 1/A SK-080 01 Prešov Phone: +421 (0)51 7580 611 Fax: +421 (0)51 7580 650 INEA RBT d.o.o. SLOVENIA Stegne 11 SI-1000 Ljubljana Phone: +386 (0)1 / 513 8116 Fax: +386 (0)1 / 513 8170 Beijer Electronics AB SWEDEN Box 426 **SE-20124 Malmö** Phone: +46 (0)40 / 35 86 00 Fax: +46 (0)40 / 93 23 01 Omni Ray AG SWITZERLAND Im Schörli 5 CH-8600 Dübendorf Phone: +41 (0)44 / 802 28 80 Fax: +41 (0)44 / 802 28 28 GTS TURKEY Bayraktar Bulvari Nutuk Sok. No:5 TR-34775 Yukarı Dudullu-Ümraniye-İSTANBUL Phone: +90 (0)216 526 39 90 Fax: +90 (0)216 526 3995 CSC Automation Ltd. UKRAINE 4-B, M. Raskovoyi St. UA-02660 Kiev Phone: +380 (0)44 / 494 33 55 Fax: +380 (0)44 / 494-33-66

EURASIAN REPRESENTATIVES TOO Kazpromavtomatika KAZAKHSTAN UI. Zhambyla 28 KAZ-100017 Karaganda Phone: +7 7212 / 50 10 00 Fax: +7 7212 / 50 11 50 MIDDLE EAST REPRESENTATIVES I.C. SYSTEMS LTD. EGYPT 23 Al-Saad-Al-Alee St EG-Sarayat, Maadi, Cairo Phone: +20 (0) 2 / 235 98 548 Fax: +20 (0) 2 / 235 96 625 ILAN & GAVISH Ltd. ISRAEL 24 Shenkar St., Kiryat Arie **IL-49001 Petah-Tiqva** Phone: +972 (0)3 / 922 18 24 Fax: +972 (0)3 / 924 0761 GIRIT CELADON LTD ISRAEL 12 H'aomanut Street IL-42505 Netanya Phone: +972 (0)9 / 863 39 80 Fax: +972 (0)9 / 885 24 30 **CEG INTERNATIONAL** LEBANON Cebaco Center/Block A Autostrade DORA Lebanon - Beirut Phone: +961 (0)1 / 240 430 Fax: +961 (0)1 / 240 438

AFRICAN REPRESENTATIVE CBI Ltd. SOUTH AFRICA Private Bag 2016 ZA-1600 Isando Phone: + 27 (0)11 / 977 0770 Fax: + 27 (0)11 / 977 0761

MITSUBISHI ELECTRIC FACTORY AUTOMATION