

USER MANUAL




connect

**Universal Dual Headphone
Bluetooth® Wireless Audio Transmitter**

Model: AF-T1




PACKAGE CONTENTS

connect**Universal Dual Headphone
Bluetooth® Wireless Audio Transmitter****connect**
Bluetooth
TransmitterMicro-USB
charging
cable3.5mm
audio cable3.5mm to
RCA adapterTOSLINK
digital optical
S/PDIF audio
cableQuick
start
guide

connect

Universal Dual Headphone
Bluetooth® Wireless Audio Transmitter



- 1 Pairing button "B"
- 2 Indicator light "B"
- 3 Indicator light "A"
- 4 Pairing button "A"
- 5 On/Off switch

- 6 Analog audio input (3.5mm)
- 7 Digital audio input (TOSLINK optical S/PDIF)
- 8 Power/charging indicator light
- 9 Micro-USB power/charging port

COMPATIBILITY

The **Connect** is compatible with any device that has one of the following audio outputs:




1. 3.5mm (1/8")
headphone
jack



2. RCA audio
jacks (red
and white
connectors)



3. TOSLINK
digital optical
(S/PDIF)
connector



The **Connect** can stream music to any Bluetooth audio receiver that supports the A2DP Bluetooth profile, such as a Bluetooth headphone, Bluetooth speaker, or dedicated A2DP receiver.



The **Connect** also supports aptX® and aptX Low Latency, more efficient Bluetooth audio codecs capable of transmitting CD-quality audio that also provide lower and much lower latency (smaller delay), respectively, compared to regular Bluetooth audio (SBC). Using the **Connect** with a headphone that supports aptX or aptX Low Latency will provide the best possible audio quality and minimize audio lag/latency.

The **Connect** will always default to the best codec that is also supported by the headphones connected to it. If two headphones are connected, the best codec supported by both will be used.


CHARGING

To charge the **Connect**, plug the included Micro-USB charging cable into any powered USB port** and the charging port on the rear of the unit.

Charge time is approximately 90 minutes. The green charging indicator light will pulse slowly while the **Connect** is charging.

Note: If you use the **Connect** while plugged in to USB power, it is not necessary to charge the unit before using it, or to turn it off after each use.

When used while plugged in, the **Connect** will use USB power and the internal battery will be charged. When unplugged from USB power, the **Connect** will use the internal battery. When battery is low, the green power LED will blink once every second and a short alert tone will sound at 10 minute intervals.



The USB outputs of some TVs do not provide a stable current. It is recommended to use a computer or USB wall charger to charge the **Connect.

To turn on, slide the on/off switch on the right side of the **Connect** unit to the "On" position.



To turn off, slide the switch to the "off" position.


SETUP: CONNECTING TO TV OR OTHER AUDIO DEVICE

The **Connect** includes three connection options. Consult the user manual for your television or other device to find the appropriate connector to use for audio output (Audio Out).


Option 1: Digital optical audio out (TOSLINK)

Newer TVs are usually outfitted with a TOSLINK digital optical (SPDIF) connector.

- A. Remove the protective caps from the included fiber optic TOSLINK cable



- B. Plug the cable firmly into the optical audio output on the TV and the optical input of the **Connect**.



The volume of optical output is typically fixed and TV speakers can be controlled independently as necessary.

continue to next page


SETUP (Continued): CONNECTING TO TV OR OTHER AUDIO DEVICE

Note: If something is plugged into both the optical and 3.5mm input jacks of the *Connect*, the analog (3.5mm) input will have priority and the optical input will be muted. To use the optical input, unplug the 3.5mm connector from the transmitter.

Note: If you have successfully connected the TOSLINK cable and you are still not receiving any sound, please make sure that your audio output settings on your TV, DVR, or other relevant device are set to PCM.

Option 2: RCA audio out (red and white connectors)

Older TVs usually have analog audio output with RCA (red and white) connectors. To use the RCA output, attach the included RCA adapter to the 3.5mm stereo audio cable. Plug the connectors of the RCA adapter into the matching-color RCA jacks on the TVs and plug the attached 3.5mm cable into the 3.5mm input on the rear of the *Connect*.




The volume of RCA audio output is typically fixed and TV speakers can be controlled independently of the *Connect*.

SETUP (Continued): CONNECTING TO TV OR OTHER AUDIO DEVICE

Option 3: 3.5mm (1/8") headphone jack

Some TVs and most standalone receivers have a headphone jack on the front or side. To use the **Connect** with the headphone jack, plug the included 3.5mm stereo audio cable into the headphone jack on the TV and the 3.5mm input on the rear of the transmitter. A 1/4" adapter (not included) may be used with receivers that have a 1/4" jack.



TV speakers will typically be muted automatically when the headphone jack is used. The volume of the headphone jack can be controlled using the TV or receiver and will affect the volume of the **Connect**.

continue to next page


SETUP: PAIRING WITH BLUETOOTH HEADPHONES

Before use, the **Connect** must be paired with at least one Bluetooth headphone or other Bluetooth audio receiver.

Make sure your Bluetooth headphone or other device is turned off and within 1 meter (3 feet) of **Connect** and put it in pairing mode. With most headphones this is done by pressing and holding the Power/Multifunction button until the status indicator lights (typically red and blue) flash in an alternating pattern. If you are unsure of how to activate pairing mode, consult the user manual of your headphone/device.

Once the headphone is in pairing mode, press pairing button "A" located on the right side of the **Connect**. A blue light will blink rapidly on the top of the unit to indicate that the **Connect** is ready to pair. It will pair automatically with any headphone or other Bluetooth receiver that is also in pairing mode and located within 1 meter (3 feet). The **Connect** and headphone have to be in pairing mode simultaneously in order to pair.

The **Connect** will remain in pairing mode for 30 seconds or until successfully paired. Once paired, the blue light will blink several times and turn solid Blue.




Note: The above procedure creates a pairing in slot A. To pair a single headphone in slot B, simply use pairing button "B" instead. To pair two headphones simultaneously, follow the instructions in the next section.

continue to next page

SETUP (Continued): PAIRING WITH BLUETOOTH HEADPHONES

Optional: Pairing a 2nd Headphone

The **Connect** can stream audio to two Bluetooth headphones simultaneously. A second headphone can be paired after one headphone is already connected (as indicated by a solid blue light on top of the unit). To pair the second headphone, put it in pairing mode and then press pairing button "B" on the **Connect**. A blue light will flash to indicate that the **Connect** is in pairing mode and the second headphone will be paired.



Note: During the pairing process the sound may have a brief intermittent period.

Note: When streaming to two headphones, the **Connect** will always default to the best available codec that is supported by both of the connected headphones. For example, if one of the headphones supports aptX and the other does not, regular Bluetooth audio streaming will be used with both headphones.

continue to next page

SETUP (Continued): PAIRING WITH BLUETOOTH HEADPHONES

Optional: Replace Paired Headphone

Once the maximum of two connected headphones has been reached (as indicated by two solid blue lights on top of the **Connect**), additional headphones or other Bluetooth receivers can be paired in place of either of the connected headphones.

Follow the instructions found in the "Pairing a 2nd Headphone" section to replace one of the currently-paired headphones with a new device. Use pairing button "A" to replace the headphone paired in slot A and pairing button "B" to replace the headphone paired in slot B.

SUBSEQUENT USE – RECONNECTING HEADPHONES

The **Connect** will stay connected until either the unit or headphones are turned off or taken out of range. It is not necessary to turn off the **Connect** or headphones after each use except to conserve battery (note: when the **Connect** is plugged into USB power, it does not use the battery).

Previously paired Bluetooth headphones will reconnect to **Connect** automatically once turned back on. The **Connect** will not initiate reconnection. If the **Connect** itself is turned off, it is recommended to turn it back on first before turning on the paired headphones so that it can accept the incoming Bluetooth connection from the headphones. If the headphones are already on, turn them off and then on again.


Note: It may take up to 60 seconds for audio transmission to start after headphones re-connect.

ADJUSTING THE VOLUME


Volume can be individually adjusted on each set of headphones paired with the **Connect** using the built-in volume controls on the headphones.

With some TVs and connection options, TV volume may be further raised or lowered to change the volume of all headphones paired with the **Connect**. In this case, volume should be maximized on the TV and then adjusted via headphones for best audio quality.

STEP 1. MAXIMIZE TV VOLUME



STEP 2. ADJUST HEADPHONE VOLUME



FACTORY RESET / CLEAR MEMORY

The **Connect** can be reset by holding pairing button "A" on the right side of the unit for approximately 5 seconds until the blue indicator light begins to blink. The unit will enter pairing mode and previously paired devices will be cleared from memory.

LED INDICATOR LIGHTS

The **Connect** has a green power/charging indicator light on the rear of the unit and two blue indicator lights on the top. They indicate the status of the headphones as follows:

Indicator Light(s)	Connect Status
Green power indicator light on (USB Power plugged in)	Battery full
Green power indicator light pulsing slowly	Charging
Green power indicator light on (USB Power not plugged in)	On
Green power indicator light blinking rapidly	Low battery
Blue light blinking	Pairing mode active
One solid blue light	One headphone is connected
Two solid blue lights	Two headphones are connected

TROUBLESHOOTING

Issue: *Connect* will not turn on; Green power light doesn't turn on or turns on and then off

Make sure the *Connect* transmitter is plugged into a powered USB port or the internal battery has been charged. The green power indicator light on the rear of the unit will light up when the unit is turned on.

Issue: Not charging

If using a wall charger, make sure it is plugged in to a powered outlet. If using a computer, make sure the computer is on and the USB port has power.

Issue: Unable to pair Bluetooth headphones

Make sure both the *Connect* and the Bluetooth headphone are in pairing mode at the same time as indicated by the appropriate tones and/or light pattern and are with 1 meter (3 feet) of each other. Make sure the headphones or other Bluetooth device you are attempting to pair with the *Connect* support the A2DP Bluetooth profile and can act as a receiver. The *Connect* is a transmitter and cannot be paired with another Bluetooth transmitter such as a phone or tablet.

Issue: Headphones are connected (blue light solid) but audio is not heard

Ensure that either the analog (3.5mm) or digital (TOSLINK) audio cable is plugged in to both the *Connect* and your TV or other audio device. Ensure that audio is playing on the TV/device, the output you have selected is active, and volume is set to "high" on the TV/device. Ensure that volume is sufficiently high on your Bluetooth headphones.

If you are using an optical connection, make sure nothing is connected to the 3.5mm input of the *Connect*.

Issue: There is a delay (latency) in audio

Bluetooth is a digital wireless signal and there is some latency expected due to the coding/decoding and compression/decompression steps that must occur. The aptX and aptX Low Latency audio codecs supported by the *Connect* are notable for having lower and much lower latency (smaller delay), respectively, compared to regular Bluetooth audio. Using the *Connect* with a headphone that supports aptX or aptX Low Latency will minimize audio lag.

Some modern TVs and receivers also have an audio delay option. Please make sure that audio delay is set to 0 to minimize lag.

continue to next page

TROUBLESHOOTING (Continued)

Issue: I cannot connect to my phone, tablet, or other device via Bluetooth

The **Connect** is a Bluetooth transmitter. It cannot be connected with another transmitter such as a phone or tablet. It can only be connected with a Bluetooth receiver such as a Bluetooth headphone, speaker, sound bar, etc.

Issue: Previously paired headphones will not connect

Make sure that the **Connect** has not been reset since the headphones were last paired. Make sure the headphones are turned on and within range and that the **Connect** is not already connected with two other headphones/devices (at most 1 blue light should be on). Make sure the headphones are not connected to another device.

If the headphones are still unable to connect, power them off and then turn them back on. If problems persist, create a new pairing between the **Connect** and your headphones.

Issue: Low volume

Adjust the volume both on your Bluetooth headphones and on the TV or other connected device as both may control the volume.

Issue: Crackling noise, static, interference

For the most noise-free audio, maximize the volume on your TV or other device and adjust via the headphones.

Make sure you are within range of your Bluetooth-enabled device. Bluetooth devices are susceptible to interference from other Bluetooth devices, microwave ovens, power stations and transmission lines, Direct Satellite Service (DSS), and wireless devices operating on the 2.4 GHz band. Eliminate as many potential sources of interference as possible while using your Bluetooth headphones.

SAFETY AND CARE

Taking care of your device in accordance with the following recommendations will ensure optimal performance and a long lifespan.

- a) Battery performance will be severely decreased when stored in extreme temperatures: below -10°C/14°F or above 45°C/113°F including direct sunlight.
- b) Clean with a soft, slightly damp cloth. Do not use chemical cleaners.
- c) There are no user replaceable/repairable parts in the transmitter. Disassembling it will void your warranty.
- d) Do not expose to liquids. If the device comes in contact with liquids, quickly wipe away. If submerged in water, do not turn the device on until completely dried. Note: liquid submersion voids the warranty.
- e) Do not use around flammable gasses as fire or explosion may occur.
- f) Replacement parts and accessories are available online at www.MEEaudio.com

WARNING

Using headphones at high to moderate volumes for extended periods of time will result in permanent hearing damage. It is advised to adjust the volume to a comfortable listening level before putting on your headphones.

SPECIFICATIONS

See the *Connect* product page at www.MEEaudio.com for product specifications.

WARRANTY

MEE audio products purchased from authorized retailers are covered by a 1-year manufacturer's warranty. Visit the warranty information page at www.MEEaudio.com for warranty information.

connect

MEE audio

MEE audio and its logo are registered trademarks of S2E, Inc. All rights reserved.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by MEE audio is under license. Other trademarks and trade names are those of their respective owners.

aptX® software is copyright CSR plc or its group companies. All rights reserved. The aptX® mark and the aptX logo are trademarks of CSR plc or one of its group companies and may be registered in one or more jurisdictions.



www.MEEaudio.com
support@meelec.com