



Contents

This document contains the following sections:

Overview	1
eFlash	1
Integrated Configuration Tool	3
FlashTool	18
Troubleshooting	22

Overview

This chapter describes three different firmware tools. To determine which tool would be best for your setup, refer to the chart below:

Table 1. Controller firmware tools available

Controller	Tool available
M5PXNplus M3000PXNplus M2000PXNplus	<ul style="list-style-type: none"> eFlash: flash capability only Integrated Configuration Tool
Micro/5-PXN Micro/5-PX Micro/PXN-2000 Micro/PX-2000	<ul style="list-style-type: none"> eFlash FlashTool

Throughout this manual, reference to Facility Commander™ Wnx is represented as “FCWnx” in text content to avoid repetition.

eFlash


eFlash is a flash method accessed within the FCWnx application. The procedure to flash has been integrated so that the controller stays online and continues to process badge and alarm activity while in the process of being flashed.

The FCWnx **Controller Monitor** allows you to monitor communications and control each controller in the system. (Refer to the *Facility Commander Wnx User Manual* or Online Help for additional information.)

To flash controllers that already have SP3.x or later firmware:

1. Verify that the FCWnx services are running (refer to the *Facility Commander Wnx Installation Manual*).
2. Log on to the FCWnx program. The login ID and password must belong to a member of the spadmin local user group on the Server computer and the user group on any client computer.)
3. Verify that the controller is online in the FCWnx program. From the Application Group pane, select the **Monitors & Controls**, then **Controller Monitor**. Check that the **State** column reads Online. If not, set the controller online before continuing.


Figure 1. Sample Controller Monitor



4. Select the controller or multiple controllers that you want to flash. If flashing a line of controllers, we recommend starting with the end-of-line controller, and work toward the head-of-line controller. This requires a working knowledge of your FCWnx system. The firmware version column on the **Controller Monitor** displays the current firmware on the controller.
 - If the LED is green, the controller firmware matches the latest firmware on the Server computer.


- If the LED is yellow, the controller firmware **does not** match with the latest firmware on the Server computer.
5. Click the right-mouse button and select **Flash Controller(s)** from popup menu.

Figure 2. Flash Controller (s) option



The **Controller Flash & Controller Preference Configuration** window displays. This window is only available if the controller is online. There are three options. Refer to the appropriate section below.

Figure 3. Controller Flash & Controller Preference Configuration



View/Edit Parameter Info

This option is available for selection of a single controller. When this option is selected, the **Controller Preference Configuration** window displays and the configuration for the controller is retrieved.

Controller Preference - Direct/Dialup:

(This option not supported for the PXNplus controller.) allows you to change the connection type of the controller and its **Address**, **Idle Time**, and **DI res tolerance**.

Controller Preference - Credential Format:

displays the custom credential formats that are currently in the controller. If there are no custom formats, the fields are empty. If a format in the database does not match what is available in the controller, the window list displays the message 'Unrecognized Format.' to change the credential format:

- **Magnetic stripe:** Select the type of magnetic stripe format from the drop-down list.
- **Wiegand:** Click Assign formats to display a list of available Wiegand credential formats from which to choose and assign to this controller.
- **Clear formats in Controller:** Click to clear all custom credential formats from the controller. Credentials associated with those formats no longer work.
If you change the credential format, any format that existed in the controller previously is replaced.

Controller Preference - Networking:

(This option not supported for the PXNplus controller.) displays only if the system identified your controller as a network controller and allows you to change the network preferences for the controller.

1. Make the changes needed and click **OK**. A dialog box displays asking you to verify your request.
2. Click **OK** to re-configure the controller. The controller resets after the configuration changes have been made.

Start Flashing Controller(s)

This option starts flashing the selected controller(s) with the latest firmware. A dialog box displays, asking you to verify your request. The flashing process takes approximately two to three minutes; it varies with the amount of data that needs to be transmitted to the controller.

1. Click **Start Flashing Controller(s)** to immediately download the appropriate firmware to the controller. A dialog box displays asking you to verify your request.
2. Click **OK** to begin the flash and reset process. After a successful flash, the controller resets and a database download takes place.

View/Edit Flash Files

Use this option **ONLY** when it is necessary to selectively flash an older version of firmware on a controller. This application automatically selects the latest version by default. The flashing process takes approximately two to three minutes; it varies with the amount of data that needs to be transmitted to the controller.

1. Select the firmware file by using
 - the drop-down list
 - the **Browse** button to navigate another media source or directory where the firmware files reside.
2. Click **OK** to begin the flash and reset process. After a successful flash, the controller resets and a database download takes place.

Integrated Configuration Tool

The Integrated Configuration Tool is a browser-based utility used to configure the PXNplus CPU board, update the firmware, and view the application log file.

Requirements**Software requirements**

One of the following:

- Microsoft Internet Explorer 6.0 or later
- Netscape 7.0 or later
- Mozilla 5.0 or later

Hardware requirements

- Cat5 crossover cable for direct connection to a controller
- Cat 5 standard cable with network hub

PXNplus controller connection configurations

Figure 4. Connecting directly using crossover cable





Figure 5. Connecting through network hub



Before you continue

Answer these questions before continuing:

Is there a firewall on the computer you are using to access the Integrated Configuration Tool?

If yes, you need to disable it in order to use the Integrated Configuration Tool.

Is your network using a proxy?

If yes, you need to disable the proxy or bypass it.

Complete the [Configuration checklist for Integrated Configuration Tool](#) on page 18 for each controller that you are setting up.

Connecting and starting the tool

If this is a new controller, there are special first-time configuration instructions. Refer to [First-time configuration](#) on page 5.

Starting the tool

1. Connect the PC to the controller using one of the connection configurations shown in [Figure 4](#) and [Figure 5](#).
2. In the browser Address field, enter the IP address of the controller.
3. At the password screen, enter your username and password. The default is `install, install`. We recommend that you change this default. See [Change Username/Password](#) on page 14.

If you need to flash the controller, see [Flash controller menu/Flash controller](#) on page 17.

First-time configuration

1. By default, the controller's IP address is `192.168.6.6`. To have your laptop/computer communicate with the controller, you must set your laptop/computer IP address to `192.168.6.5`, or similar valid IP address (`192.168.6.x` where x is any number between 1 and 254 except 6). The setup is different between Windows 2000 and Windows XP. Refer to the appropriate section.

For Windows 2000:

- a. Click **Start, Settings**, then **Network and Dial-up Connections**.
- b. Right-click on **Local Area Connection**. If the first option in the drop-down list box is:
 - **Disable**, then the connection is enabled. Go to [step c](#).
 - **Enable**, then select it to enable the connection. Return to [step a](#).
- c. Select **Properties** from the drop-down list box.
- d. In the section **Components checked are used in this connection**, select **Internet Protocol TCP/IP**.
- e. Click **Properties**.
- f. If this laptop/computer is set for:
 - DHCP, then the field **Obtain an IP address automatically** is already selected. Select **Use the following IP address**.
 - Static, write down the IP address and Subnet number. You need to reset your computer back to these numbers once the controller configuration is complete.
- g. Enter the IP address `192.168.6.5`, or a similar valid IP address (`192.168.6.x` where x is any number between 1 and 254 except 6).
- h. Change the subnet mask to `255.255.255.0`.
- i. You do not need to change the gateway.
- j. Click **OK** until all open windows are closed.
- k. Go to [step 2](#).

For Windows XP:

- a. Click **Start**, then **Control Panel**.
- b. From the **Control Panel** window, select **Network Connections**.
- c. Right-click on **Local Area Connection**. If the first option in the drop-down list box is:
 - **Disable**, then the connection is enabled. Go to [step d](#).
 - **Enable**, then select it to enable the connection. Return to [step a](#).
- d. Select **Properties** from the drop-down list.
- e. In the section **This connection uses the following items:**, select **Internet Protocol TCP/IP**.
- f. Select **Properties**.
- g. If this laptop/computer is set for:
 - DHCP, then the field **Obtain an IP address automatically** is already selected. Select **Use the following IP address**.
 - Static, write down the IP address and Subnet number. You need to reset your computer back to these numbers once the controller configuration is complete.

- h. Enter the IP address 192 . 168 . 6 . 5, or a similar valid IP address (192 . 168 . 6 . x where x is any number between 1 and 254 except 6).
 - i. Change the subnet to 255 . 255 . 255 . 0.
 - j. You do not need to change the gateway.
 - k. Click **OK** until all open windows are closed.
2. Connect the Cat-5 crossover cable from the Ethernet port on your laptop or computer directly to the controller Ethernet port (no hub or switch).
3. If your controller is not yet powered up, do so now.
4. Open an Internet browser window on your laptop/computer.
5. In the browser's Address field, enter the default static IP address of the controller: 192 . 168 . 6 . 6
6. The Integrated Configuration Tool starts. At the password screen, enter your username and password. The default is `install`, `install`. We recommend that you change this default. See [Change Username/Password](#) on page 14.

Controller setup overview

To set up a network controller

In order to set up a network controller, you must complete these screens:

- **Controller Configuration menu->Host/Connection type:** Select the software package and network. See [Controller Configuration menu->Host/Connection type](#) on page 7.
- **Controller Information menu->Controller information:** Set the controller address. See [Controller Information menu->Controller Information](#) on page 8.
- **Controller Parameters menu->Network configuration:** The setup depends on whether the IP address is static or dynamic. See [Network configuration](#) on page 9.
- **Controller Parameters menu->Dial configuration:** If using the optional dial fallback feature, you must complete the Dialup tab also. See [Dial configuration](#) on page 10.

After completing all the screens, click **Apply Changes** under the Administration menu and then click **Restart Application** for the changes to take effect.

To set up a dialup controller

In order to set up a dialup controller, you must complete these screens:

- **Controller Configuration menu->Host/Connection type:** Select the software package and network. See [Controller Configuration menu->Host/Connection type](#) on page 7.
- **Controller Information menu->Controller information:** Set the controller address. See [Controller Information menu->Controller Information](#) on page 8.
- **Controller Parameters menu->Dial configuration:** If using the optional dial-up (fallback) feature, you must complete the Dialup tab also. See [Dial configuration](#) on page 10.

After completing all the screens, click **Apply Changes** under the Administration menu and then click **Restart Application** for the changes to take effect.

To set up a direct controller


In order to set up a direct controller, you must complete these screens:

- **Controller Configuration menu->Host/Connection type:** Select the software package and network. See [Controller Configuration menu->Host/Connection type](#) on page 7.
- **Controller Information menu->Controller information:** Set the controller address. See [Controller Information menu->Controller Information](#) on page 8.

Controller Configuration menu->Host/Connection type

Use this form to select the software package and connection type.

Figure 6. Host/Configuration type screen




1. If you have not already done so, log on to the Integrated Configuration Tool. See [Starting the tool](#) on page 5.
2. From the **Controller Configuration** menu, select **Host/Connection Type**.
3. In the **Host/Server Type** field, select **Facility Commander Wnx**.
4. In the **Primary Connection Type** field, for:
 - network controllers, select **Ethernet**.
 - dialup controllers, select **Dialup**.
 - direct controllers, select **Direct**.
5. Click **Save**.
6. If this completes your controller configuration, click **Apply Changes** then **Restart Application** now.

Controller Information menu->Controller Information

Use this form to set the controller’s address. This form also provides the controller online/offline status, build and application versions, and modem baud rate.

Figure 7. Controller Information screen



1. From the **Controller Information** menu, select **Controller Information**.
2. To set the controller address, enter the number in the **Controller Address** field.
3. To use the status reports in the **Other Info** field, see [Using the Other Info field](#) on page 8.
4. Click **Save**.
5. If this completes your controller configuration, click **Apply Changes** then **Restart Application** now.

Using the Other Info field

There are several status reports based on uClinux commands which are available for checking and monitoring the PXNplus board. Call GE Customer Support for assistance with these reports.

1. In the **Other Info** field, click the down arrow for a list of available reports.
2. Select the report you want. See [Table 2](#) below for a brief explanation of each report.

Table 2. Controller Info reports

Report	Description
Memory Usage	displays amount of memory available, both used and free
Process State	lists which processes are running
Board Info	displays hardware related information, such as boot and board version
OS Info	displays information related to the linux operating system on the controller
Uptime	time since the last reboot
DB File Info	lists persistence-related database files

Table 2. Controller Info reports (continued)

Report	Description
Message Info	lists data on the controller's message queues
Ping Host	pings the host from the controller (based on the current host IP or name) Successful ping result: 2 packets transmitted, 2 packets received, 0% packet loss Unsuccessful ping result: 2 packets transmitted, 0 packets received, 100% packet loss
Check Route	checks route information from the controller
Thread Status	lists the application firmware components and whether they are currently running
DMA Info	status of the DMA IO interface

Controller Parameters menu

The menu contains the following options:

- **Network configuration:** configure the network settings.
- **Dial configuration:** configure dial-up settings. See [page 10](#).
- **3DES Keys:** set data encryption. See [page 11](#).
- **Badge formats:** not used with Facility Commander Wnx.
- **Other Parameters:** set parameters such as setting badge history and alarm history memory allocation and changing username and password. See [page 12](#).

Network configuration

Use this form to configure the network settings for the controller. A static or dynamic IP address can be used.

Figure 8. Controller Parameters/Network configuration screen

The screenshot shows the 'Integrated Configuration Tool' web interface in a Microsoft Internet Explorer browser window. The address bar shows 'http://192.168.0.4/main_ie.html'. The page features the GE Security logo and a navigation menu on the left. The main content area is titled 'Controller Parameters' and includes a 'Network configuration' section. In this section, the 'Controller Information' tab is active, showing options for 'Use DHCP' (checked) and 'Use MAC address' (unchecked). The 'Controller name' is set to 'micro1.getest.ge.com' and the 'Controller MAC' is '00 : B0 : 19 : 2A : 06 : 1F'. Below this, the 'Host Information' section is also active, with 'Use DNS (Host information optional for Secure Perfect)' checked. Fields for 'Host name', 'Back up host name' (optional), and 'Domain' are present, along with a 'DNS IP' field set to '192 . 168 . 0 . 10'. A 'Save' button is located at the bottom of the configuration area.

1. From the **Controller Parameters** menu, select **Network configuration**.
2. In the **Controller Information** area, set the controller name or address. Perform one of the following:

DHCP:

 - For a dynamic controller IP address, select **Use DHCP**.

To name the controller, perform one of the following:

 - Enter a fully qualified, unique domain name in the Controller Name field. For example: `micro.getest.ge.com`
 - Select the checkbox **Use MAC** and the controller name is generated from the Controller MAC address. A MAC address (media access control address) is a unique identifier attached to most forms of networking equipment. The MAC address for your PXNplus CPU board can be found in the **Controller MAC** field. This option disables the **Controller Name** field.

Note: Give this name or MAC address to your Network Administrator so that it can be added to the DNS database.


Static:

 - For a static controller IP address, enter the IP address of the controller given to you by your Network Administrator in the field **Controller IP**.
 - If using a gateway, you may accept the gateway IP generated based on the controller IP or you may enter a gateway IP address in the **Gateway** field.
 - If using a subnet mask, you may accept the subnet mask generated based on the controller IP or you may enter a subnet mask in the **Subnet** field.
3. If using DNS, select the **Use DNS** checkbox in the **Host Information** area. Then, enter the DNS IP address in the **DNS IP** field.
4. Click **Save**.
5. If this completes your controller configuration, click **Apply Changes** then **Restart Application** now.

Dial configuration

Use this screen to set up the dial-up or dial fallback feature. Either the on-board modem or an external modem can be used.

Figure 9. Controller Parameters/Dial configuration screen



1. From the **Controller Parameters** menu, select **Dial configuration**.
2. In the **Host Phone # 1** field, enter the phone number for the host computer. Use the format: `aaa-xxx-xxxx` (For example, `561-555-5555`)
3. If there is an additional phone number to reach the host, enter it into the field **Host Phone # 2**, otherwise, leave the field blank.

4. The fields **Modem Init String** and **Modem Deinit String** require values only if you are experiencing difficulties with the optional modem board.
5. Click **Save**.
6. If this completes your controller configuration, click **Apply Changes** then **Restart Application** now.


DES encryption configuration

In order to secure transmissions between the controller and the host, the data is encrypted using triple DES (Data Encryption Standard) encryption. Use this screen to enter keys which creates an encryption pattern for transmission.



CAUTION: The host DES keys and the controller DES keys **MUST** match!

Figure 10. Controller Parameters/3DES keys screen



1. If you have not already done so, log on to the Integrated Configuration Tool. See *Starting the tool* on page 5.
2. Click **Controller Parameters**, then **3DES keys**.

Keep the following in mind:

- DES keys must be exactly 16 characters.
- DES keys must be valid hexadecimal characters (0 through 9, upper or lower case letters A through F).
- No two or more DES keys can have the same value.



CAUTION: You cannot modify only one key! All must be changed or you can not save.

3. Click **Save**.
4. If this completes your controller configuration, click **Apply Changes** then **Restart Application** now.

Badge format

Note: This feature of the tool is for Picture Perfect users only! FCWnx users should use the Credential Format form located in the FCWnx application.


Other Parameters

The form contains the following fields:

- **Set Badge History vs Alarm History Memory Allocation:** allocate percentage of history memory to badge history. See [page 12](#).
- **Set Resistor Tolerances:** tighten the range the voltage changes before detecting a 4 state DI state change. See [page 13](#).
- **Change Username/Password:** change either the username and/or the password used to log on to the Integrated Configuration Tool. See [page 14](#).
- **Disable (Enable) Integrated Configuration Tool:** select this toggle field to block or allow access to the Integrated Configuration Tool. See [page 14](#).

Set Badge History vs Alarm History Memory Allocation


Figure 11. Parameters/Other Parameters - Set Badge History vs Alarm History Memory Allocation screen



1. If you have not already done so, log on to the Integrated Configuration Tool. See [Starting the tool](#) on page 5.
2. Click **Controller Parameters**, then **Other Parameters**.
3. Select the checkbox next to the **Set Badge History vs Alarm History Memory Allocation** field. The field **Percent of history buffer to use for Badge History (0 - 100)** displays.
4. Enter the percentage of history you would like to use for badge history. The remaining percentage of history is used for alarm history.
5. Click **Save**.
6. If this completes your controller configuration, click **Apply Changes** then **Restart Application** now.

Set Resistor Tolerances

Figure 12. Controller Parameters/Other Parameters - Set Resistor Tolerances screen




1. If you have not already done so, log on to the Integrated Configuration Tool. See [Starting the tool](#) on page 5.
2. Click **Controller Parameters**, then **Other Parameters**.
3. Select the checkbox next to the **Set Resistor Tolerances** field. The following fields display:
 - **Res Tol # 1:** Tightens the range the voltage changes before detecting a 4-state DI state change
 - **Res Tol # 2:** Reserved
 - **Res Tol # 3:** Reserved
4. Enter the resistor tolerance needed in the appropriate field.
5. Click **Save**.
6. If this completes your controller configuration, click **Apply Changes** then **Restart Application** now.

Change Username/Password

For increased security, we recommend that you change the default username and password.

Figure 13. Controller Parameters/Other Parameters - Change Username/Password screen




1. If you have not already done so, log on to the Integrated Configuration Tool. See [Starting the tool](#) on page 5.
2. Click **Controller Parameters**, then **Other Parameters**.
3. Select the checkbox next to the **Change Username/Password** field. The fields **New Username** and **New Password** display.
4. Enter a new username and password.
5. Click **Save**.
6. If this completes your controller configuration, click **Apply Changes** then **Restart Application** now.

Disable or Enable Integrated Configuration Tool

Disabling the Tool

1. Successfully log on to the Integrated Configuration Tool.
2. From the **Controller Parameters** menu, select **Other Parameters**.
3. Select the option *Disable Integrated Configuration Tool*.
4. Selecting this option generates a dialog prompt verifying your selection. You must select **OK** on the prompt to disable the Integrated Configuration Tool.

Figure 14. Controller Parameters/Other Parameters - Disable Integrated Configuration Tool



5. To make this selection permanent, click **Save, Apply Changes**, then **Restart Controller**.
6. After the controller performs a successful reboot, the Integrated Configuration Tool is permanently disabled.

Enabling the Tool

There are two options to enable the Integrated Configuration Tool: temporary and permanent. The Temporary option allows access to the Tool until the micro resets. The Permanent option allows access until you manually disable the Tool again.

Before you begin, you **MUST** have physical access to the controller.

Temporary enabling

1. Verify that the controller has completed the power-up boot cycle by checking that D20 is no longer in the constant ON state.
2. On the PXNplus CPU board, jumper JP2. Verify that DS6 turns ON. Allow up to five seconds for DS6 to be turned ON. Once DS6 is ON, remove the jumper and DS6 turns OFF.
3. The Integrated Configuration Tool is now enabled until the controller reboots.

Permanent enabling

1. Complete the steps in the section *Temporary enabling* above then return to this section.
2. Successfully log on to the Integrated Configuration Tool.
3. Select **Controller Parameters**, then **Other Parameters**.
4. Select the option *Enable Integrated Configuration Tool*.
5. Selecting this option generates a dialog prompt verifying your selection. You must select **OK** on the prompt to enable the Integrated Configuration Tool.
6. To make this selection permanent, click **Save, Apply Changes**, then **Restart Controller**.
7. The controller performs a system reboot automatically.
8. After the controller performs a successful reboot, the Integrated Configuration Tool is permanently enabled.

Administration menu

The menu contains the following options:

- **Apply Changes:** applies new changes.
- **Restart Application:** makes changes permanent.
- **Restart Controller:** reboots the controller.
- **Restore Factory Defaults:** restores factory defaults.

Apply Changes

Click this menu item to apply any new changes made to the controller’s configuration.

Restart Application

Click this menu item to make the changes to the controller permanent.

Restart Controller

Click this menu item to shut down and restart the controller.

Restore Factory Defaults

The PXNplus board is shipped with the following default settings:

- **Primary Connection Type:** Ethernet
- **IP Address:** 192.168.6.6
- **Mask:** 255.255.255.0
- **Gateway:** 192.168.6.1


There are two methods to restoring the factory default settings: through the Integrated Configuration Tool and by the CPU board. The table below explains when to use each method.

Restore the factory defaults by ...	Result
clicking the Defaults button in the Integrated Configuration tool	Settings are restored to factory defaults except for the network configuration.
shorting JP4 until DS3 turns on (See Integrated Configuration Tool on page 22.)	All settings are restored to the factory defaults.

Flash controller menu/Flash controller

The PXNplus CPU board uses a single image capable of supporting both Picture Perfect, Secure Perfect, and Facility Commander hosts. The file is in the format (where *vvvv* is the four digit version number of the firmware): *PXNPvvvv.efl*

Figure 15. Flash Controller screen



1. If you have not already done so, log on to the Integrated Configuration Tool. See [Starting the tool](#) on page 5.
2. From the Flash Controller menu, select **Flash Controller**.
3. Click **Browse** and locate the new flash file.
4. Click **Save**. The controller reboots automatically.

Note: The controller may reboot several times based on the update:

 - 1 time = application update only
 - 2 times = application and web server or kernel update
 - 3 times = application, web server and kernel update
5. If you wish to continue configuration changes, you need to log back in.

Logging menu

The menu contains the following options:

- **Log Control Parameters:** select the items to track and send to the log file.
- **View Log File:** displays the log file.
- **Save Log File:** saves the log to a file.
- **Print Log File:** prints the log.
- **Clear Log File:** clears the contents of the log file.

Log Control Parameters

The system logger provides verification of controller operation independently from the host. Other filtering can be applied to troubleshoot problems; **contact GE Security Customer Support and Engineering for assistance.**

View Log File

Click this menu item to view the logfile.

Save Log File

Click this menu item to save the log file.

Print Log File

Click this menu item to print the log file.

Clear Log File

Click this menu item to clear the contents of the log file.

Configuration checklist for Integrated Configuration Tool

In order to complete controller configuration using the Integrated Configuration Tool, you need the following information:

Communication type		Information needed	Write your answer here	
Direct		Controller address:		
Dial-up		Controller address:		
		Phone number to reach host:		
		Secondary phone number to reach host:		
Ethernet	Use DHCP: NO Use DNS: NO	Controller IP:		
		Gateway:		
		Subnet:		
		Host IP: (Optional)		
	Use DHCP: YES Use DNS: YES	Controller Name or Controller MAC which is provided for you:		
		Host Name: (Optional)		
	Use DHCP: NO Use DNS: YES	Controller IP:		
		Gateway:		
		Subnet:		
		Host Name: (Optional)		
		Domain: (Optional)		
		DNS IP: (Optional)		
	Use DHCP: YES Use DNS: NO	Controller Name or Controller MAC which is provided for you:		
		Host IP: (Optional)		

FlashTool

FlashTool is a flash method for downloading firmware to controllers in maintenance mode or controllers with firmware earlier than SP3.x. To upgrade controllers with firmware earlier than SP3.x, you **MUST** use the FlashTool method of flashing.

Before flashing (downloading application code to) your controllers in maintenance mode or controllers with firmware earlier than SP3.X, you need to install the Micro Installation Tool - FlashTool.

Installing FlashTool

To install the FlashTool application:

1. Log on as local administrator.
2. In Windows® **Explorer**, navigate to the FCWnx\Firmware folder on the Server computer.
3. Double-click the FlashTool . EXE file. The **Micro Installation Tool - FlashTool Installation Welcome** window displays.
4. Click **Next**. The **Select Destination Directory** window displays.
5. Review and verify the destination of the FlashTool folder.
6. Verify that adequate free disk space is available for the installation.
7. Click **Next**. The **Ready to Install** window displays.
8. Click **Next**. Install completes and an **Installation Completed** window displays.
9. Click **Finish**. The **FlashTool** application closes and there is now a FlashTool folder in the location that you selected for installation on your computer along with an icon on your desktop.


Flashing controllers in maintenance mode or SP firmware earlier than SP3.x

Note: Controllers in maintenance mode or firmware earlier than SP3.x MUST be flashed with the FlashTool application found in your Flashtool application folder.

Flashing a single controller


1. Verify that the computer is serially connected to the controller that is to be flashed.
2. Make sure that FCWnx services are not started, or the selected comm port has assigned controllers set to offline.
3. If not already installed, install FlashTool. Refer to *Installing FlashTool* on page 18.
4. To run FlashTool, double-click on the FlashTool icon on the desktop. The FlashTool introductory window displays.
5. Click **OK**.
6. If this is the first time you are running FlashTool, a message displays stating **No config file found, creating a default file**. Click **OK**. (You will not see this message again when running the FlashTool application.)
7. When FlashTool loads, it prompts you to add new files that are found in the FlashTool folder. Answer **Yes** to all prompts. The application opens, automatically searches for controllers, and usually finds a controller within 30 seconds. The **FlashTool** controller status window displays. If no controller is connected, the window displays as in *Figure 16*.

Figure 16. FlashTool Window




If FlashTool does not recognize the existing firmware, the window displays similar to *Figure 17*.

Figure 17. Micro Status



When FlashTool recognizes the firmware, the window displays the **Micro Type** and firmware application code information, similar to *Figure 18*.

Figure 18. FlashTool Micro Status



8. A controller can be flashed with application firmware in two ways:
 - a. Use one of the **Automatic Firmware Flash** buttons in the middle of the window. Click the button that corresponds to the firmware you want. (The buttons display the latest firmware release on your computer.) The download and flash process begins.
 - b. Alternatively, you may click **Micro Flash** from the **Options** listed on the left of the window. A drop-down list of firmware displays.
 - Select the latest version of Secure Perfect x.000 App Code.
 - Click **Start Flash**. The download and flash process begins.

Note: If you are flashing a Micro/5-PXN, you must follow the steps in this order:

1. Flash the OS firmware.
2. Allow FlashTool to identify the controller.
3. Flash the application firmware.

9. Go to [Download and Flash Process](#) on page 21 for the completion of the flash process.

Flashing a Line of Controllers

FlashTool can flash all controllers in a line that have been selected and fully identified.

1. Select **Search for Line of Micros**. FlashTool searches for all controllers in a specified communication line. The results of the search (up to 8 controllers) are displayed in the box below the Status field.
2. Click an individual controller from the list, then the **Select** button to select an individual controller from the list of controllers found.:



CAUTION: If you choose to flash each controller individually and not the entire line of controllers, you **MUST** start flashing the end-of-line controllers first, and work your way up the line. The head-of-line controller **MUST** be flashed last. If you do not follow this order and start with the head-of-line, you cannot flash the downstream controllers. The way to prevent this from occurring is to select all controllers and flash the entire line at the same time.

-OR-

Click **Select All** to select the entire line of controllers at one time.

Note: To flash the entire line of controllers, all controllers must be selected and identified prior to starting the flash process. The hourglass icon reminds you to wait until the system identifies the selected controller/controllers and allows you to proceed.


3. Once selected and identified, an asterisk displays in front of the controller name in the list. A list box displays the firmware for each controller. Scroll up or down in the list box to view the version information for each controller that has been selected. The parameter block information may be obtained for a selected controller by clicking **Parameters**, which is enabled when a controller is selected. (Refer to [Editing the Parameter Block](#) on page 21 and [Syntax Checking](#) on page 21.)
4. Click **Deselect** to cancel the selection of an individual controller.
5. Begin the flash process using one of the following methods:
 - Click one of the **Automatic Firmware Flash** buttons.
 - Click **Micro Flash**, select firmware from the firmware drop-down box, and then click **Start Flash**.
6. Continue to the next section.

Download and Flash Process

To process the download:

1. The firmware download and flash process takes approximately ten minutes for each controller flashed. You can monitor the flash progress window that displays, similar to [Figure 19](#).

Figure 19. Standard FlashTool Flash Window



2. The window automatically closes after a successful flash process.

Configuring a controller

FlashTool can also be used to configure your controller.

Syntax Checking

From the **File** drop-down menu, **Parameter Block Syntax Checking** can be enabled or disabled. Parameter block syntax checking impedes illegal combinations of settings that are controller-specific. A syntax error occurs if the program cannot understand the command that has been entered. It is strongly recommended that this setting remain enabled. A warning message displays if you choose to disable this feature.

Note: When configuring a Micro/5-PXN controller that contains anything other than SP3.x firmware (for example, Secure Perfect 2.1 or Picture Perfect), this option **MUST** be disabled.

Editing the Parameter Block

The controller parameter block holds controller data such as controller address, phone numbers, and network configuration parameters.

To edit the parameter block:

1. Allow sufficient time for FlashTool to identify the controller.
2. Click **Parameters**. FlashTool reads the parameter block in the controller and displays it in the window.
3. Edit as necessary. Select the **Networking** tab to enter information for a Micro/5-PXN.
 - You **MUST** enter an IP address for the controller.
 - A host IP address is not required and can be left blank.
 - Enter the Gateway IP address (is the same as the controller IP address).
 - All other fields are set by default. Only change them if necessary depending on your network configuration.
4. Click **Save to Micro**. FlashTool writes the data into the parameter block of the controller and resets the controller.

Troubleshooting

eFlash

Problem: No flash files are listed in the combo boxes.

Resolution: This represents a share permissions issue. Make sure you are logged in as a user in the SPAdmin group. If not, log back in as a user in this group.

Integrated Configuration Tool

Problem: I need to restore the factory default settings.

Resolution:

There are two methods to restoring the factory default settings: through the Integrated Configuration Tool and at the controller. The table below explains when to use each method.

Table 3. Restoring factory defaults

Restore the factory defaults by ...	Result
Clicking the Defaults button in the Integrated Configuration Tool	Settings are restored to factory defaults except for the network configuration.
Short JP4 (Restore Defaults pins) on the PXNplus CPU board until DS3 turns on.	All settings are restored to the factory defaults.

The controller is now offline from the host and the factory defaults have been restored. The factory defaults are as follows:

- **Host Server/Type:** Picture Perfect
- **Primary Connection Type:** Ethernet
- **IP Address:** 192.168.6.6
- **Mask:** 255.255.255.0
- **Gateway:** 192.168.6.1


If necessary, reconfigure the controller using the appropriate instructions found in your controller manual.

Problem: The network controller does not connect.


Resolution:

1. Verify your network settings in the Integrated Configuration Tool and in the FCWnx application:
 - controller IP address and micro address
 - network mask
 - gateway IP
 - DHCP/DNS server
2. Check the connectivity by using the ping command. Use the Ping Host option in the Integrated Configuration Tool.
 - a. In the Integrated Configuration Tool, select **Micro Info**.
 - b. From the **Other Info** drop-down list, select **Ping Host**.

Successful ping example:



Unsuccessful ping example:



Problem: The dial-up micro does not connect.

Resolution:

1. Verify your settings in the Integrated Configuration Tool and in the FCWnx application:
 - micro address
 - modem strings
 - baud rate settings
 - cabling
2. If using the PXNplus controller, verify the modem jumper setting on the CPU board:
 - external modem: 1 and 2
 - on-board modem: 2 and 3
3. Verify modem LED activity. Refer to your micro manual for details.

