# User Guide

# LP and JC Series

# **Beside-the-Press Granulators**

Installation Maintenance Operation

Troubleshooting

Instant Access Parts and Service (800) 458-1960 (814) 437-6861

www.conairnet.com





The Conair Group, Inc. One Conair Drive Pittsburgh, PA 15202 Phone: (412) 312-6000 Fax: (412)-312-6001

UGG002/0998

#### WARNING - Reliance on this Manual Could Result in Severe Bodily Injury or Death! This manual is out-of-date and is provided only for its technical information, data and capacities. Portions of this manual

detailing procedures or precautions in the operation, inspection, maintenance and repair of the product forming the subject matter of this manual may be inadequate, inaccurate, and/or incomplete and cannot be used, followed, or relied upon. Contact Conair at info@conairgroup.com or 1-800-654-6661 for more current information, warnings, and materials about more recent product manuals containing warnings, information, precautions, and procedures that may be more adequate than those contained in this out-of-date manual. Please record your equipment's model and serial number(s) and the date you received it in the spaces provided. It's a good idea to record the model and serial number(s) of your equipment and the date you received it in the User Guide. Our service department uses this information, along with the manual number, to provide help for the specific equipment you installed.

Please keep this User Guide and all manuals, engineering prints and parts lists together for documentation of your equipment.

Date:
Manual Number: UGG002/0998
Serial number(s):
Model number(s):

The Conair equipment described in this publication is covered by: U.S. Patent number 4,706,899.

**DISCLAIMER:** The Conair Group, Inc., shall not be liable for errors contained in this User Guide or for incidental, consequential damages in connection with the furnishing, performance or use of this information. Conair makes no warranty of any kind with regard to this information, including, but not limited to the implied warranties of merchantability and fitness for a particular purpose.

INTRODUCTION	1-1
Purpose of the User Manual	1-2
How the Manual is organized	1-2
Your Responsibility as a User	1-2 1-3
DESCRIPTION	
Typical Applications	2-2
Specifications: JC models	· · · · · .2-3
Installing the granulator	3_2
Pre-operation tests and inspection	
	4-1
Sofa Operating Presentions	4 2
To start granulating	
To stop granulating	
MAINTENANCE	5-1
Preventative maintenance checklist	5-2
Replacing helical segments	5-2
Getting ready	
Removing and replacing segments	5-4
Finishing up	5-5
Helical blade sharpening	5-6
Bed knife	57
Sharpening	
Knife Gap Guidelines	5-7
TROUBLESHOOTING	6-1
Before beginning	6-2
Stalled machine	6-3
Material overheating	
Knife breakage	
Screen cradle will not close	6-4
Motor will not start	6-4
Appendix	
Customer service information	A-1
Warranty information	A-2

# TABLE OF CONTENTS

TABLE OF	Parts and Diagrams
	LP Series Cutting Chamber
CONTENTS	JC Series Cutting ChamberP-2
	Electrical Schematics
	Rotor Only
	Rotor and Blower
	Option schematics

# INTRODUCTION

Purpose of the User Guide ....1-2
How the guide is organized ....1-2
Your responsibilities as a user .1-2
ATTENTION: Read this so no one gets hurt .....1-3

Purpose of The User Guide	This User Guide describes the Conair LP and JC model gran- ulators and explains step-by-step how to install, operate, maintain and repair this equipment. Before installing this product, please take a few moments to read the User Guide and review the diagrams and safety infor- mation in the instruction packet. You also should review man- uals covering associated equipment in your system. This review won't take long, and it could save you valuable instal- lation and operating time later.				
How THE Guide is	Symbols have been used to help organize the User Guide and call your attention to important information regarding safe installation and operation.				
ORGANIZED	Symbols within triangles warn of conditions that could be hazardous to users or could damage equipment. Read and take precautions before proceeding.				
	Numbers within shaded squares indicate tasks or steps to be performed by the user.				
	<ul> <li>A diamond indicates the equipment's response to an action performed by the user.</li> </ul>				
	□ An open box marks items in a checklist.				
	• A shaded circle marks items in a list.				
Your Responsibility	You must be familiar with all safety procedures concerning installation, operation and maintenance of this equipment. Responsible safety procedures include:				
As a User	• Thorough review of this User Guide, paying particular attention to hazard warnings, appendices and related diagrams.				
	• Thorough review of the equipment itself, with careful attention to voltage sources, intended use and warning labels.				
	<ul> <li>Thorough review of instruction manuals for associated equipment.</li> </ul>				
	• Step-by-step adherence to instructions outlined in this User Guide.				

We design equipment with the user's safety in mind. You can avoid the potential hazards identified on this machine by following the procedures outlined below and elsewhere in the User Guide.

### WARNING: Improper installation, operation or servicing may result in equipment damage or personal injury.

This equipment should be installed, adjusted, and serviced by qualified technical personnel who are familiar with the construction, operation and potential hazards of this type of machine.

All wiring, disconnects and fuses should be installed by qualified electrical technicians in accordance with electrical codes in your region. Always maintain a safe electrical ground. Improper grounding can result in severe personal injury and erratic machine operation. Do not operate the equipment at power levels other than what is specified on the the machine serial tag and data plate.

### DANGER: Amputation hazard.

This equipment uses sharp, rotating blades that can cause severe personal injury, including amputation. To avoid this hazard:

- Do **not** remove guards during operation.
- Do not remove or bypass the electrical interlocks that prevent operation when the cutting chamber is open or blades are exposed.
- Always disconnect and lock out the incoming main power source before opening the cutting chamber or performing non-standard operating procedures, such as routine maintenance.
- Always use extreme caution when the cutting chamber is open. Wear gloves when handling the knives.
- Follow the safe operating procedures as outlined in this User Guide.

### ATTENTION: READ THIS SO NO ONE GETS HURT

### ATTENTION: READ THIS SO NO ONE GETS HURT



### WARNING: Voltage hazard

This equipment is powered by three-phase alternating current, as specified on the machine serial tag and data plate.

Always disconnect and lock out the incoming main power source before opening the electrical enclosure or performing non-standard operating procedures, such as routine maintenance. Only qualified personnel should perform troubleshooting procedures that require access to the electrical enclosure while power is on.



# WARNING: Follow these procedures for safe operation.

- Do **not** start the machine with material in the cutting chamber.
- Do not operate with foreign objects on or around granulator.
- Do **not** attempt to bypass safety interlocks.
- Do **not** feed large lumps or purgings.
- Do **not** allow the bin to overfill.
- Do **not** batch feed LP model granulators.
- Always start machine **before** feeding material.
- Feed only the amount and type of material for which the granulator has been sized and designed to granulate.
- Allow machine to purge **before** turning it off.
- Periodically inspect knives for wear and proper clearance. Adjust, sharpen or replace as necessary. Failure to do this could affect performance.
- Rotate the screen to extend screen life. The screen will show washout on the holes on one side if this is not done.

# **Description**

• What is the LP/JC?	-	-	-	-	-	-	-	-	.2-2
• Typical Applications	-						-	-	.2-2
• Specifications	-						-	-	.2-3

#### **TYPICAL** LP model granulators are designed for robot or conveyor fed sprues, runners, and light duty parts. The LP granulator should **APPLICATIONS** not be batch fed. Primarily designed for beside-the-press applications, the LP granulators have a low infeed height for closed-loop robot/granulator systems. The low rotor speed provides better regrind, less noise, reduced flyback, and less wear with abrasive material. JC model granulators are designed for batch fed parts and runners and tough applications. The JC granulator may be used beside the processing machine or in a central granulation application. Primarily designed for engineered materials, thick cross section parts and runners, the JC granulator produces a higher throughput per hour and requires less horsepower than a conventional 3-blade rotor, due to the standard flywheel coupled

to the helical rotor.

# SPECIFICATIONS: LP MODELS

GRANULATOR WITH STANDARD ROBOT/CONVEYOR FEED HOPPER





STANDARD HELICAL ROTOR



STANDARD HELICAL SEGMENT OPTIONAL BOLT-ON-TIP SEGMENT

C

MODELS	LP-78	LP-810	LP-814	LP-1016	LP-1021	SPECIFICATION
Performance characteristics						NOTES:
Maximum throughput* lbs/hr {kg/hr}	100 {45}	120 {54}	150 {68}	200 {91}	300 {136}	t Theorem and a second second
Cutting chamber in. {mm}	7 x 8	8 x 10	8 x 14	10 x 16	10 x 21	ad as a capacity guide
	{178 x 203}	{203 x 254}	{203 x 356}	{254 x 406}	{254 x 533}	line only Throughput will
Cutting circle in. {mm}	6.4 {163}	6.4 {163}	6.4 {163}	8 {203}	8 {203}	vary according to the
Rotor speed rpm	140	140	140	140	140	size, shape, thickness
Standard Motor power Hp	3	3	3	5	5	and properties of the
Rotor type	he	elical rotor standard	(bolt-on-tips optio	nal)		material to be cut, as
Screen mesh sizes	rar	iges from 3/16 to 3/8	8 in. {4.76 to 9.53	mm}		well as the desired size
Dimensions inches {mm}	1					Consult Conair for a
A - Height	52 {1320}	54 {1372}	57 {1448}	59 {1499}	59 {1499}	material test or help
B - Width	20 {508}	23 {584}	27 {686}	30 {762}	35 {889}	determining the correct
C - Depth	27 {1350}	27 {1350}	30 {1350}	34 {1350}	34 {1350}	granulator model for your
D - Infeed height	52 {1321}	52 {1321}	57 {1448}	59 {1499}	59 {1499}	application.
Hopper opening in. {mm}	12 x 14	14 x 16	14 x 16	16 x 18	18 x 21	§ Noise level will vary
	{305 x 356}	{356 x 406}	{356 x 406}	{406 x 457}	{457 x 533}	according to material
Weight lbs {kg}					•	and the granulator con-
Installed	700 {318}	820 {372}	900 {408}	1200 {544}	1400 {635}	figuration. These ranges
Shipping	790 {358}	880 {399}	1015 {460}	1400 {635}	1745 {792}	are based on tests using
Blades						SPI standards.
Number of rotor segments	5	7	7	9	12	
Number of bolt-on knives	NA	5	7	6	8	
Number of stationary knives	2	2	2	2	2	without notice Check with a
Voltages Total full load amps	-	-				Conair representative for the
460V/3 phase/60 hz	4.2	4.2	4.2	6.5	6.5	most current information.
230V/3 phase/60 hz	8.4	8.4	8.4	13.0	13.0	
208V/3 phase/60 hz	10.8	17.9	17.9	35.9	53.8	
575V/3 phase/60 hz	3.9	6.5	6.5	13.0	19.5	
380V/3 phase/50 hz	5.9	9.8	9.8	19.6	29.5	
415V/3 phase/50 hz	5.9	9.8	9.8	19.6	29.5	
Noise level§						]
With standard soundproofed hopper			< 87 dbA			
1	1					

# SPECIFICATIONS: JC MODELS

GRANULATOR WITH STANDARD ROBOT/CONVEYOR FEED HOPPER



STANDARD HELICAL ROTOR



SEGMENT



OPTIONAL BOLT-ON-TIP SEGMENT

MODELS	JC-78	JC-810	JC-814	JC-1016	JC-1021
Performance characteristics					
Maximum throughput* lbs/hr {kg/hr}	300 {136}	400 {181}	600 {272}	800 {363}	1000 {454}
Cutting chamber in. {mm}	7 x 8	8 x 10	8 x 14	10 x 16	10 x 21
	{178 x 203}	{203 x 254}	{203 x 356}	{254 x 406}	{254 x 533}
Cutting circle in. {mm}	6.4 {163}	6.4 {163}	6.4 {163}	8 {203}	8 {203}
Rotor speed rpm	600	600	600	520	520
Standard motor power Hp	3	5	5	10	15
Rotor type		helical rotor star	ndard (bolt-on-tips	optional)	•
Screen mesh sizes		ranges from 3/16	to 3/8 in. {4.76 to	9.53 mm}	
Dimensions inches {mm}	·				
A - Height	54 {1372}	54 {1372}	54 {1372}	62 {1575}	62 {1575}
B - Width	20 {508}	23 {584}	27 {686}	30 {762}	35 {889}
C - Depth	27 {1350}	27 {1350}	30 {1350}	34 {1350}	34 {1350}
D - Infeed height	45 {1143}	45 {1143}	45 {1143}	52 {1321}	52 {1321}
Hopper opening in. {mm}	7 x 8	8 x 10	8 x 14	10 x 16	10 x 21
	{178 x 203}	{203 x 254}	{203 x 356}	{254 x 406}	{254 x 533}
Weight lbs {kg}	•	·	•		•
Installed	760 {345}	880 {399}	950 {431}	1350 {612}	1550 {703}
Shipping	815 {370}	960 {435}	1015 {460}	1545 {701}	1745 {792}
Blades	·	•			
Number of rotating helical knives	5	7	7	9	12
Number of bolt-on-knives	NA	5	7	6	8
Number of bed knives	2	2	2	2	2
Voltages Full load amps		-			
460V/3 phase/60 hz	4.9	8.1	8.1	16.2	24.3
230V/3 phase/60 hz	9.7	16.2	16.2	32.4	48.7
208V/3 phase/60 hz	10.8	17.9	17.9	35.9	53.8
575V/3 phase/60 hz	3.9	6.5	6.5	13.0	19.5
380V/3 phase/50 hz	5.9	9.8	9.8	19.6	29.5
415V/3 phase/50 hz	5.9	9.8	9.8	19.6	29.5
Noise level §					
With standard soundproofed hopper			< 87 dbA		
	1				

SPECIFICATION

\* Throughputs are provided as a capacity guideline only. Throughput will vary according to the size, shape, thickness and properties of the material to be cut, as well as the desired size of the granulate. Consult Conair for a material test or help determining the correct granulator model for your application.

S Noise level will vary according to material type being processed and the granulator configuration. These ranges are based on tests using SPI standards.

Specifications may change without notice. Check with a Conair representative for the most current information.



# INSTALLING THE GRANULATOR

# WARNING: Improper installation may result in equipment damage or personal injury.

This equipment should be installed, adjusted, and serviced by qualified technical personnel who are familiar with the construction, operation and potential hazards of this type of machine.

All wiring, disconnects and fuses should be installed by qualified electrical technicians in accordance with electrical codes in your region. Always maintain a safe electrical ground. Improper grounding can result in severe personal injury and erratic machine operation. Do not operate the equipment at power levels other than what is specified on the the machine serial tag and data plate.

### Move the granulator to the operating location.

### **2** Connect the main power.

See the wiring diagrams for your model for connection information. Make sure the supply voltage is the same as specified on the serial tag and data plate on the granulator.

# PRE-OPERATION TESTS AND INSPECTION



### DANGER: TO AVOID AMPUTATION

- 1. Disconnect and lockout all power.
- 2. Do NOT operate without covers.
- 3. Do NOT override interlock switches.

**1** Disconnect and lock out the main power.

### **2** Open and inspect the machine.

Disengage safety interlocks, release the hopper latch and open the hopper. Open screen cradle using hand knobs.



**3** Clean the screen cradle thoroughly.



# PRE-OPERATION TESTS AND INSPECTION

### **4** Close the screen cradle and machine.

The screen cradle must close tightly to the cutting chamber or machine damage could occur.

**5** Verify rotation of all motors BEFORE processing material. When using a blower to evacuate, blower must be started first. To start blower motor, press BLOW-ER START button. Verify blower impeller rotation by jogging blower motor and checking the fan rotation against the rotation indicator arrow.

**6** To start the rotor motor, press the ROTOR START button. With motor on, verify rotor shaft is rotating in the direction of the arrow located over the outboard bearing. For JC style units, outboard side guard panel must be



removed to view. Re-install after checking rotation.

**7** To stop the machine, press the ROTOR STOP button. Wait 30 seconds after stopping the rotor, then stop the blower by pressing BLOWER STOP button.

# 

# SAFE OPERATING PRECAUTIONS

In order to maintain your equipment's safe operation, follow these precautions.

• Do NOT start machine with material in chamber.

• Do NOT operate with foreign objects on or around granulator.

• Do NOT attempt to bypass safety interlocks.

• Do NOT feed large lumps or purgings.



- Do NOT allow bin to overfill.
- Do NOT batch feed LP series.

• Always start machine BEFORE feeding material.

• Only feed in the proper amount that the granulator is sized for and capable of granulating.

• Allow machine to purge BEFORE turning OFF.

• Periodically inspect knives for wear and proper clearance. Adjust, sharpen or replace as necessary. Failure to do this could affect performance.

• Rotate the screen to extend screen life. The screen will show washout on the holes on one side if this is not done.

**IMPORTANT:** When using your own method of regrind removal, the rate of material throughput should NEVER exceed the rate of removal, or jam-ups within the granulator will occur. We recommend a high level proximity switch if bin overfill is a problem.

<b>1 Inspect and clean the granulator.</b> See the <i>Pre-Operation Test and Inspection</i> procedures in the Installation section.	To Start Granulating
<b>2</b> After inspection, close machine completely.	
<b>3</b> If a blower is being used to evacuate, start blower motor first. To do this, press BLOWER START button.	
<b>4</b> Start rotor motor by pressing ROTOR START button.	
<b>IMPORTANT:</b> If there is any abnormal sound or operation, stop the rotor motor, disconnect the main power and refer to the Troubleshooting section.	
<b>5</b> Begin feeding material slowly at first to determine the maximum amount machine is capable of granulating	

**1 Stop the rotor motor first.** To stop the rotor motor, press the ROTOR STOP button.

without overfeeding.

2 If a blower is being used to evacuate, stop the blower motor 30 seconds AFTER stopping the rotor motor. To stop the blower motor, press the BLOWER STOP button. Doing this ensures all granulated material is purged, thus eliminating jam ups within the cutting chamber and/or blower system.

### TO STOP GRANULATING

# MAINTENANCE

Preventative maintenance
checklist
• Replacing helical segments5-2
• Getting ready
• Removing the bearing flange
Removing and replacing
segments
• Finishing up
Helical blade sharpening5-6
Bed knife removal and
sharpening
• Knife gap guidelines

# PREVENTATIVE MAINTENANCE CHECKLIST

/'₩\

#### **CAUTION:** Voltage and amputation hazard.

Disconnect and lock out the main power supply before attempting to perform an maintenance or troubleshooting procedures.



Use extreme care when cutting chamber is open. Exposed knives are sharp! We recommend wearing gloves when handling knives.

- Rotate the screen to obtain even wear and extend screen life. The screen will show washout on the holes on one side if this is not done.
- Periodically, inspect knives for wear and proper clearance. Adjust, sharpen or replace as necessary. Keep the knives sharp at all times.
- Rotate the rotating end disc 180 degrees at blade sharpening interval to extend disc life.
- Grease the outboard rotor shaft bearing every three (3) months or as required. Do NOT over grease. Damage to the bearing seal could result.
- Periodically inspect all nuts, bolts and screws to ensure that none have become loose due to operation.
- Inspect the cutting chamber about every 3 months to make sure that material is not getting caught between the end discs and the chamber walls.

### REPLACING THE HELICAL SEGMENTS

**HE** To replace the helical segments, see the following sets of instructions.

**Getting ready** 

**Removing the bearing flange** 

**Removing and replacing blades** 

Finishing up

<b>1</b> Open the granulator front door.	<b>GETTING READY</b>
<b>2</b> Remove the granule bin.	
<b>3 Tilt the hopper back.</b> (Release the two clamps that hold the hopper.)	
<b>4</b> Lower the screen bin and screen. (Loosen the knob bolts.)	
<b>5</b> Remove the side panel that covers the bearing flange.	
<b>6 Remove the safety interlock.</b> It is not necessary to remove any wires, simply remove the two allen bolts.	
1 Loosen the set screws on set screws	REMOVING THE
<ul> <li>an allen wrench, it is not necessary to remove the screws, just loosen them)</li> <li>Remove the bolts holding the bearing flange to the granulator body.</li> </ul>	FLANGE
<ul> <li>an allen wrench, it is not necessary to remove the screws, just loosen them)</li> <li>2 Remove the bolts holding the bearing flange to the granulator body.</li> <li>3 Use a bearing puller to remove the bearing from the shaft.</li> </ul>	end plate
<ul> <li>an allen wrench, it is not necessary to remove the screws, just loosen them)</li> <li>2 Remove the bolts holding the bearing flange to the granulator body.</li> <li>3 Use a bearing puller to remove the bearing from the shaft.</li> <li>4 Loosen the spanner nut set screws. (Again, use an allen wrench and do not remove the screws.)</li> </ul>	end plate
<ul> <li>an allen wrench, it is not necessary to remove the screws, just loosen them)</li> <li>2 Remove the bolts holding the bearing flange to the granulator body.</li> <li>3 Use a bearing puller to remove the bearing from the shaft.</li> <li>4 Loosen the spanner nut set screws. (Again, use an allen wrench and do not remove the screws.)</li> <li>5 Remove the spanner nut. (It will be necessary to use a spanner nut wrench.)</li> </ul>	end plate

# Removing And Replacing Segments

**NOTE:** Rotor blades are numbered. Replace in the same order in which they were removed. **1 Remove the segments from the shaft.** Take note of the stamped number on the segments. When you replace the segments, you will want them in the same order.



- **2** Wipe down the shaft using a rag and petroleum-based lubricant.
- **3** Replace the segments in the same direction and in the order that you removed them.
- **4** Replace the shaft end plate.
- **5** Replace the spanner nut. Make sure that it is fully tightened. It may be necessary to place a board in the chamber between the blades and the bed knives to keep the shaft from rotating while tightening.
- **6 Tighten the spanner nut set screws.** We recommend using some type of adhesive/sealant compound.
- **7** Replace the bearing flange.
- **8** Replace the bearing flange bolts. Again, use the adhesive/sealant compound.
- **9** Tighten the bearing stopper set screws.



# Helical Rotor Blade Sharpening

### WARNING:

- Do NOT attempt to weld on these knives.
- Do NOT sharpen OUTSIDE diameter of knives. Permanent damage to knives will occur.
- Damage to knife seats and tips could occur.

**NOTE:** The knives must be cooled during sharpening. The knives must not be burned or blued under any circumstances.



Sharpen inside blade tip ONLY!

The distance from the center of the segment to the center of a 1.25 inch OD grinding wheel is 2.80 - .00+.01 for the 8xx series and 3.66 - .00+.01 for the 10xx series. If the distance is too small, the knife tips may bend or break. If the distance is too large, the granulator performance will suffer.



**TIP:** Conair has a knife sharpening service available. Simply call the toll free number, get your RGA (return goods authorization) number, and send your blades to Conair. You can also purchase extra sets of blades, so it is never necessary to wait while blades are being sharpened. Repeat steps for HELICAL ROTOR BLADE REMOVAL procedure shown on page 5-3, then proceed with the steps below to remove bed knives for sharpening.

# Bed knife Removal and Sharpening



**2** Grind bed knives to 15 degree angle.



# **3 Reassemble.** Use bed knife adjusting bolts and a feeler gauge to reset the proper gap between bed knives and rotor blades.

### SUGGESTED KNIFE GAP:

General purpose: (.005") to (.009") Film application: (.003") to (.007")

Tighten bed knife bolts to 85 ft/lb.

Recheck gap AFTER tightening to verify clearance has not changed.



KNIFE GAP GUIDELINES

# TROUBLESHOOTING

When Trouble Occurs	.6-2
• A Few Words Of Caution	.6-2
• Stalled Machine	.6-3
Material Overheating	.6-3
Knife Breakage	.6-4
• Screen Cradle Will Not Close .	.6-4
Motor Will Not Start	.6-4

# WHEN TROUBLE OCCURS

You can avoid most problems by following the recommended installation and maintenance procedures outlined in this User Guide. If you do have a problem, this section will help you determine what caused it and how to fix it.

- **1** Turn off the granulator.
- **2** Refer to the charts. Identify the symptom that you saw.
- **3** Perform applicable tasks in the chart.
- **4** If the problem remains, contact Conair.

# A Few Words Of Caution



**WARNING:** This machines should be adjusted and serviced only by qualified technical personnel who are familiar with construction and operation of this type of equipment.

### DANGER: Amputation and voltage hazard.

Disconnect and lock out the main power supply before attempting to perform any maintenance or troubleshooting procedures.



Make sure blades have stopped rotating before opening the cutting chamber. The knives are sharp and can cause severe personal injury. Use extreme caution when the cutting chamber is open. We recommend wearing gloves when handling the knives.

Symptom	Possible cause	Solution				
Stalled Machine	Is the unit being over- loaded?	Feed material more slowly.				
	Are knives worn, dam- aged, or improperly set?	Sharpen, replace, or adjust as required.				
	Are screen holes and/or material transition plugged?	Unplug screen and/or material transition.				
	Is the motor running in reverse?	Switch two of the three incom- ing power wires.				
	Have you lost power?	Check power supply, electrical hookup and safety interlocks.				
Material Overheating	Is unit being overloaded, are knives worn, or is screen blocked?	See above for STALLED MACHINE.				
	Are screen holes too small?	Install screen with larger diameter holes.				

Symptom	Possible cause	Solution				
Knife Breakage	Is there foreign material in scrap?	Examine scrap to be processed for foreign material.				
	Are knives seated proper- ly?	Clean knife seat and replace.				
	Are knives sufficiently gapped?	Adjust knives for proper clear- ance.				
Screen Cradle Will Not Close	Is screen properly seat- ed?	Remove screen and replace to ensure tight closure.				
	Is screen cradle clean?	Remove screen and clean cra- dle to ensure tight closure.				
Motor Will Not Start.	Is main power ON?	Check fuses and/or circuit breakers.				
	Are safety interlocks secured?	Check safety switches for operation mechanically and electronically.				
	Is motor overheated?	Allow motor to cool and reset overloads.				
	Is the cutting chamber full of material?	Clean cutting chamber.				
	Has starter failed?	Repair/replace starter.				

Conair has made the largest investment in customer support in the plastics industry. Our service experts are available to help with any problem you might have installing and operating your equipment. Your Conair sales representative also can help analyze the nature of your problem, assuring that it did not result from misapplication or improper use. We're Here to Help

To contact Customer Service personnel, call: From outside the United States, call: 814-437-6861



You can commission Conair service personnel to provide onsite service by contacting the Customer Service Department. Standard rates include an on-site hourly rate, with a one-day minimum plus expenses.

# How to Contact Customer Service

# If you do have a problem, please complete the following checklist before calling Conair:

- □ Make sure you have all model, serial and parts list numbers for your particular equipment. Service personnel will need this information to assist you.
- $\square$  Make sure power is supplied to the equipment.
- □ Make sure that all connectors and wires within and between control systems and related components have been installed correctly.
- Check the troubleshooting guide of this manual for a solution.
- Thoroughly examine the instruction manual(s) for associated equipment, especially controls.
   Each manual may have its own troubleshooting guide to help you.
- □ Check that the equipment has been operated as described in this manual.
- □ Check accompanying schematic drawings for information on special considerations.

# BEFORE YOU CALL ...

Additional manuals and prints for your Conair equipment may be ordered through the Customer Service or Parts Departments for a nominal fee.

# EQUIPMENT GUARANTEE

# **Performance Warranty**

Conair guarantees the machinery and equipment on this order, for a period as defined in the quotation from date of shipment, against defects in material and workmanship under the normal use and service for which it was recommended (except for parts that are typically replaced after normal usage, such as filters, liner plates, etc.). Conair's guarantee is limited to replacing, at our option, the part or parts determined by us to be defective after examination. The customer assumes the cost of transportation of the part or parts to and from the factory.

Conair warrants that this equipment will perform at or above the ratings stated in specific quotations covering the equipment or as detailed in engineering specifications, provided the equipment is applied, installed, operated and maintained in the recommended manner as outlined in our quotation or specifications.

Should performance not meet warranted levels, Conair at its discretion will exercise one of the following options:

- Inspect the equipment and perform alterations or adjustments to satisfy performance claims. (Charges for such inspections and corrections will be waived unless failure to meet warranty is due to misapplication, improper installation, poor maintenance practices or improper operation.)
- Replace the original equipment with other Conair equipment that will meet original performance claims at no extra cost to the customer.
- Refund the invoiced cost to the customer. Credit is subject to prior notice by the customer at which time a Return Goods Authorization Number (RGA) will be issued by Conair's Service Department. Returned equipment must be well crated and in proper operating condition, including all parts. Returns must be prepaid.

Purchaser must notify Conair in writing of any claim and provide a customer receipt and other evidence that a claim is being made.

Except for the Equipment Guarantee and Performance Warranty stated above, Conair disclaims all other warranties with respect to the equipment, express or implied, arising by operation of law, course of dealing, usage of trade or otherwise, including but not limited to the implied warranties of merchantability and fitness for a particular purpose.

# WARRANTY LIMITATIONS

	_ PARTS
<ul> <li>LP Series</li> <li>Cutting Chamber</li> <li>IC Series</li> </ul>	P-2
Cutting Chamber	P-3

# LP SERIES CUTTING CHAMBER



LP Series Cutting Chamber Part List											
#	DESCRIPTION	QTY	LP-78	QTY	LP-810	QTY	LP-814	QTY	LP-1016	QTY	LP-1021
1	Upper Head	1	HED-00025	1	HED-00026	1	HED-00024	1	HED-00023	1	HED-00027
2	Screen Gradle	1	CRA-00018	1	CRA-00019	1	CRA-00016	1	CRA-00015	1	CRA-00020
3	Inboard Flange	1	FLG-00036	1	FLG-00036	1	FLG-00038	1	FLG-00029	1	FLG-00029
4	Bearing Cover	1	COV-00214	1	COV-00214	1	COV-00214	1	COV-00215	1	COV-00215
5	Rotor Shaft	1	SHF-00337	1	SHF-00340	1	SHF-00329	1	SHF-00324	1	SHF-00341
6	Rotor Knife Assy	1	ASY-00142	1	ASY-00177	1	ASY-00137	1	ASY-00141	1	ASY-00164
7	Outboard Flange	1	FLG-00038	1	FLG-00038	1	FLG-00038	1	FLG-00032	1	FLG-00032
8	Round Flange	1	FLG-00037	1	FLG-00037	1	FLG-00037	1	FLG-00030	1	FLG-00030
9	Driven Sprocket	1	SPR-00027	1	SPR-00027	1	SPR-00027	1	SPR-00027	1	SPR-00027
10	Inboard Bearing	1	BRG-00789	1	8RG-00789	1	BRG-00789	1	BRG-00788	1	BRG-00788
11	Outboard Bearing	1	BRG-00331	1	BRG-00331	1	BRG-00331	1	BRG-00334	1	BRG-00334
12	Bearing Looknut	1	NUT-00125	1	NUT-00125	1	NUT-00125	1	NUT-00136	1	NUT-00136
13	Segment Locknut	1	NUT-00124	1	NUT-00124	1	NUT-00124	1	NUT-00133	1	NUT-00133
14	Sprocket Bushing	1	64587	1	64587	1	64587	1	BUS-00169	1	BUS-00169
15	Rotor Knife Keys	2	KEY-00031	2	KEY-00040	2	KEY-00027	2	KEY-00029	2	KEY-00037
16	Bushing Key	1	KEY-00028	1	KEY-00028	1	KEY-00028	1	KEY-00039	1	KEY-00039
17	Rotor Knife End Disc	2	DIS-00011	2	DIS-00011	2	DIS-00011	2	DIS-00012	2	DIS-00012
18	Round Flange Bolts	5	212-046-05	5	SCR-00516	5	212-046-05	17	SCR-00302	17	SCR-00302
19	Inboard Flange Bolts	8	SCR-00358	8	SCR-00358	8	SCR-00358	15	212-117-08	15	212-117-08
20	Bedknife Bolts (Not Shown)	8	SCR-00642	8	SCR-00842	8	SCR-00842	12	SCR-00842	12	SCR-00842
21	Outboard Bearing Bolts	18	SCR-00843	18	SCR-00843	18	SCR-00843	4	SCR-00843	4	SCR-00843
22	Bedknives (Not Shown)	2	KNF-00003	2	KNF-00005	2	KNF-00001	2	KNF-00002	4	KNF-00004

LP Series Cutting Chamber Part List



# JC SERIES CUTTING CHAMBER

	JC Series Cutting Chamber Part List										
#	DESCRIPTION	QTY	JC-78	QTY	JC-810	QTY	JC-814	QTY	JC-1016	QTY	JC-1021
1	Upper Head	1	HED-00025	1	HED-00026	1	HED-00024	1	HED-00023	1	HED-00027
2	Screen Cradle	1	CRA-00018	1	CRA-00019	1	CRA-00016	1	CRA-00015	1	CRA-00020
3	Inboard Flange	1	FLG-00036	1	FLG-00036	1	FLG-00036	1	FLG-00029	1	FLG-00029
4	Bearing Cover	1	COV-00214	1	COV-00214	1	COV-00214	1	COV-00215	1	COV-00215
5	Rotor Shaft	1	SHF-00337	1	SHF-00340	1	SHF-00329	1	SHF-00324	1	SHF-00341
6	Rotor Knife Assy	1	ASY-00142	1	A\$Y-00177	1	ASY-00137	1	ASY-00141	1	ASY-00164
7	Outboard Flange	•	-	-	-	1	FLG-00038	1	FLG-00031	1	FLG-00031
8	Round Flange	1	FLG-00037	1	FLG-00037	1	FLG-00037	1	FLG-00030	1	FLG-00030
9	Flywheel Pulley	1	PLY-00027	1	PLY-00027	1	PLY-00027	1	PLY-00027	1	PLY-00027
10	Inboard Bearing	1	BRG-00789	1	BRG-00789	1	BRG-00789	1	BRG-00788	1	BRG-00788
11	Outboard Bearing	1	BRG-00331	1	BRG-00331	1	BRG-00331	1	BRG-00334	1	BRG-00334
12	Bearing Lcoknut	1	NUT-00125	1	NUT-00125	1	NUT-00125	1	NUT-00136	1	NUT-00136
13	Segment Locknut	1	NUT-00124	1	NUT-00124	1	NUT-00124	1	NUT-00133	1	NUT-00133
14	Sprocket Bushing	1	64587	1	64587	1	64587	1	BUS-00157	1	BUS-00157
15	Rotor Knife Keys	2	KEY-00031	2	KEY-00040	2	KEY-00027	2	KEY-00029	2	KEY-00037
16	Bushing Key	1	KEY-00028	1	KEY-00028	1	KEY-00028	1	KEY-00039	1	KEY-00039
17	Rotor Knife End Disc	2	DIS-00011	2	DIS-00011	2	DIS-00011	2	DIS-00012	2	DIS-00012
18	Round Flange Bolts	5	212-046-05	5	212-046-05	5	212-046-05	17	SCR-00302	17	SCR-00302
19	Inboard Flange Bolts	8	SCR-00358	8	SCR-00358	8	SCR-00358	15	212-117-08	15	212-117-08
20	Bedknife Bolts (Not Shown)	8	SCR-00842	8	SCR-00842	8	SCR-00842	12	SCR-00842	• 12	SCR-00842
21	Outboard Bearing Bolts	18	SCR-00843	18	SCR-00843	18	SCR-00843	4	SCR-00843	4	SCR-00843
22	Bedknives (Not Shown)	2	KNF-00003	2	KNF-00005	2	KNF-00001	2	KNF-00001	4	KNF-00004

# ELECTRICAL SCHEMATIC (ROTOR ONLY)



UGG002/0998

# ELECTRICAL SCHEMATIC (ROTOR & BLOWER)



# **OPTIONS SCHEMATIC**

