



Power Xpert[®] FMX - IEC Medium Voltage Switchgear

User manual 605.4016 G01 01



User manual

FMX

605.4016 G01 01

Eaton Industries (Netherlands) B.V.
P.O. box 23, 7550 AA Hengelo, The Netherlands
tel: +31 74 246 91 11
fax: +31 74 246 44 44
e-mail: info.electric@eaton.com
internet: www.eatonelectric.com

Service emergency:
Eaton – Electrical Services & Systems: tel: +31 74 246 68 88

Administrative data	
Issue number:	G01 01
Date of issue:	01-02-2011
Translation of:	51350 2509 G01 001

Authorised by	
Job title:	Product Manager
Name:	B. Ter Hedde
Date:	01-02-2011
Initials:	

CONTENT

1. GENERAL 5

1.1 Introduction 5

1.2 Explanation of used warnings 5

1.3 Safety relating to medium-voltage installations 5

1.4 Tools, aids and protection equipment 6

1.5 Product standards and guidelines used 6

1.6 Product information 7

2. FMX SYSTEM DESCRIPTION 9

2.1 FMX System description 9

2.2 Cross-section, single line diagram and list of functions 10

2.3 Technical specifications, general 11

3. INSTALLING THE UNIT 12

3.1 Environmental requirements 12

3.1.1 Transport, assembly and storage conditions 12

3.1.2 Ambient conditions when the unit is in service 13

3.2 Installing the unit 14

3.2.1 Lifting 14

3.2.2 Travelling 15

3.3 Connecting the cables 15

3.3.1 Types of cables 15

3.3.2 Cable assembly instructions 15

3.3.3 Safety precautions with test voltages for the FMX-unit 16

3.3.4 Cable testing 16

3.4 Connection of station earthing 18

3.5 Access to secondary compartment 18

3.6 Connection of secondary cables 18

4. OPERATION 19

4.1 Explanation of the Control Panels 19

4.2 Operation (electrical) 20

4.2.1 Service position ON/OFF switching 20

4.2.2 Switch cable earthing on/off 22

4.3 Manual operation 27

4.4 Interlocks 29

4.4.1 Earth position interlocking 29

4.4.2 Locking of the 2-position change-over switch 30

4.5 Signals 30

4.5.1 Voltage detectors 30

5. REMOTE SIGNALLING AND REMOTE CONTROL 31

5.1 Remote signalling 31

5.2 Remote control..... 31
 5.2.1 Remote opening..... 31
 5.2.2 Remote closing 31

6. INSPECTION AND MAINTENANCE 32

6.1 Introduction..... 32

6.2 Inspections..... 32
 6.2.1 Inspecting of cable connections 32
 6.2.2 Inspection of the enclosure 32
 6.2.3 Inspection of the operation of the circuit-breaker 32
 6.2.4 Inspection of the protection relay..... 33

6.3 Decommissioning the unit..... 33
 6.3.1 Material processing after dismantling 33

7. ACCESSORIES 34

7.1 Supplied accessories..... 34

7.2 Available accessories and spare parts 34

APPENDIX 1 – VOLTAGE DETECTION 35

APPENDIX 2 – AVAILABLE ACCESSOIRES AND SPARE PARTS..... 36

1. GENERAL

1.1 Introduction

The user must have authority to perform switching operations, which means being qualified in accordance with locally applicable guidelines, government legislation and in-house company regulations with respect to the operation of medium-voltage installations.

Legal and other regulations and documents pertaining to accident prevention, personal safety and environmental protection must be observed.

Operations involving the repair of the switchgear unit are to be carried out by or under the responsibility of Eaton Industries (Netherlands) B.V.

Information with respect to these operations is, therefore, not included in this manual.

1.2 Explanation of used warnings

The manual uses the following names and signs to highlight important (safety) information:

WARNING

This warning indicates that non-observance of the specified (safety) instructions **COULD** result in serious bodily injury or even death.

NOTE

This note provides the user with additional information. The user's attention is drawn to possible problems.

TIP

Tips provide the user with suggestions and advice on how to make certain tasks easier or more convenient.

1.3 Safety relating to medium-voltage installations

WARNING

Operations on medium-voltage installations can be life threatening if the necessary procedures are not observed.

Always take suitable precautions before working on a medium-voltage installation.

All personnel involved in operations carried out on, with or near electrical installations require to have been instructed on the safety requirements, safety rules and instructions applicable to the operation of the installation. Personnel must wear suitable clothing which fits the body closely. The person in charge of the operations must ensure that all requirements, regulations and instructions are complied with. The FMX unit has been designed to ensure that it exceeds applicable regulations. Furthermore, primary component enclosures are arc-resistant and interlocks have been fitted to prevent dangerous operations.

Operations when the unit has been isolated

Carrying out operations on an isolated system is subject to a number of essential requirements.

1. switching off;
2. complete isolation;
3. protection from reactivation;
4. checking whether the unit is dead;
5. provide short-circuit proof protective earthing and a visible take-over earth when needed.
6. provide protection with respect to active components in the vicinity.

Safe layout of the work area

Ensure that access and escape routes are free at all times. Do not leave flammable materials in or near access and escape routes. Flammable materials must not be stored in areas which could be affected by arcs.

In the event of a fire

Never attempt to extinguish a fire on the switchgear unit before it is completely dead, this applies to both primary and secondary switchgear. Even if non-conducting extinguishing materials are used, electricity may pass through the extinguishing equipment. Never extinguish a fire on the unit with water. Prevent water from flowing into the unit. Keep well clear of the unit while the fire is being extinguished in the area around the unit.

1.4 Tools, aids and protection equipment

Tools, aids and protection equipment must meet the requirements of national and international standards insofar as they are applicable.

Drawings and documents

Recent documents of the electrical installation must be available in order to gain sufficient understanding of the schematic layout of the switchgear unit.

Warning signs

If necessary, suitable warning signs shall be placed on the switchgear unit during operations to highlight possible hazards. The warning signs must comply with the applicable standards, insofar as they apply.

Performing measurements safely on the unit

Suitable and safe measuring equipment must be used for measuring safely on the unit. These instruments must be checked before and after use. The instruments must also be inspected periodically in accordance with the applicable regulations.

1.5 Product standards and guidelines used

Switchgear	IEC Standard	Title
General	62271-1	Common specifications for high-voltage switchgear and controlgear
	62271-200	A.C. metal-enclosed switchgear and controlgear for rated voltages above 1 kV and up to and including 52 kV
	62271-201	A.C. insulation-enclosed switchgear and controlgear for rated voltages above 1 kV and up to and including 38 kV
Devices	62271-100	High-voltage alternating-current circuit-breakers
	62271-102	Alternating current disconnectors and earthing switches
	50181	Plug-in type bushings above 1kV up to 36kV and from 250A to 1.25kA for equipment other than liquid filled transformers
Degrees of protection	60529	Degrees of protection provided by enclosures (IP Code)
Voltage detection	61243-5	Live working - Voltage detectors - Part 5: Voltage detecting systems (VDS)
Transformers	60044-1	Instrument transformers - Part 1: Current transformers
	60044-2	Instrument transformers - Part 2 : Inductive voltage transformers
Communication	60870-5	Telecontrol equipment and systems. Part 5: Transmission protocols
	61850	Communications networks and systems in substations
ISO	ISO 9001-2000	Quality
	ISO 14001	Environmental management

Table 1: Current product standards used

1.6 Product information

The unit is equipped with nameplates on the bottom of the top-unit.

The system nameplate includes:

- technical specifications;
- serial number and year of manufacture.

Each panel is uniquely identifiable by its panel nameplates. They are located on the left inside wall in the cable connection compartment of each panel.

The panel nameplate includes:

- the switch type;
- technical specifications.

Application outside the 'Normal Service Conditions' set out in IEC

Please contact Eaton if the unit is used in an environment not in accordance with the 'Normal Service Conditions' in IEC 62271-1.

Eaton Industries (Netherlands) B.V. Medium Voltage P.O. box 23, 7550 AA Hengelo, The Netherlands		EATON <i>Powering Business worldwide</i>	
M.V. SWITCHGEAR		IEC 62271-200	
system: FMX r1.0 Metal enclosed		w.o. no.:xxxxxxx	
Serialno: xxxFMXxxxxxxxx		Year of man.: 2010	
U _r 24 kV	U _p 125 kV	U _d 50 kV	f _r 50 Hz
I _r 2000 A	I _k 25 kA	I _p 63 kA	t _k 3 s
IAC AFL	U _a xxx VDC		
Main switching device: 25kA-1s			
Cable compartments: 25kA-1s			

Figure 1-1: Example of system nameplate

CIRCUIT-BREAKER		IEC 62271-100	
type: NVF18CA-2416 R1.0		Class: M2 E2 C2	
U _r 24 kV	U _p 125 kV		
I _r 1600 A	I _{sc} 25 kA	t _k 3.0 s	
I _c 31.5 A			
Operating sequence O-0.3s-CO-15s-CO			
For system information refer to nameplate			

Figure 1-2: Example of panel nameplate for circuit-breaker

CURRENT TRANSFORMER		IEC 60044-1	
type: CTS		Make: EATON	
S1 – S2 75/5 A			
5 VA Cl. 10P10 extd. 120%			
I _p 63 A	I _k 25 kA	t _k 1 s	

Figure 1-3: Current transformer information plate

VOLTAGE TRANSFORMER		IEC 60044-2	
type: YH0-3		Make: Sadtem	
A-N	10000/v3		
a1-n	100/v3	7,5 V	Cl. 0,2 Sth. 400VA
da-d	100/3	30 VA	Cl. 3P Sth. 100VA
12-28-75 kV		1,9 U _r - 8h	

Figure 1-4: Voltage transformer Information plate

Table 2: Explanation of nameplate data in accordance with IEC

Variable	Description	Unit
system	System	-
r.	Release	-
IEC	IEC reference	-
type	Type of switching device	-
serial no.	Serial number	-
year of man.	Year of manufacturing	-
w.o.no.	Works order number	-
f_r	Rated frequency	Hz
I_k	Rated short-time withstand current	kA
I_{ma}	Rated short-circuit making current	kA
I_p	Rated peak withstand current	kA
I_r	Rated normal current	A
I_{sc}	Rated short-circuit breaking current kA	kA
t_k	Rated duration of short-circuit	s
U_a	Rated supply voltage of auxiliary circuits	V
U_d	Rated short-duration power-frequency withstand voltage (1 minute)	kV r.m.s.
U_p, U_w	Rated lightning impulse withstand voltage (peak)	kV
U_r	Rated voltage	kV
$U_r.t$	Rated voltage factor and corresponding rated time	Vs
Isolation level	Rated insulation level	kV
Class M, E, C	Classification according to IEC	-
Operating sequence	Rated operating sequence	-
VA	Rated output	VA
CL	Accuracy Class	-
IAC	Internal Arc Classification	-
AFLR	A= Authorized personnel only F = Front side L = Lateral sides R = Rear side	-

2. FMX SYSTEM DESCRIPTION

2.1 FMX System description

The FMX switchgear system is a system with circuit-breakers which can be available for applications up to 24kV.

The system is fully metal-enclosed. A very compact and safe implementation is achieved using high-quality epoxy resin insulation.

Electric field strengths are kept at low levels by using specially shaped single-pole insulation components, as a result of which the risk of an internal fault is kept to an absolute minimum.

All live primary components of the unit and the main components of the drive mechanisms are housed in a closed enclosure. This prevents any dust, moisture and other environmental factors from affecting the proper operation of the system.

The enclosure is also arc resistant and thus provides conditions of optimum safety for the operator. The cable compartments are also available in arc-proof configuration.

Two basic panel versions are available:

- a vacuum circuit-breaker of 630, 800, 1250, 1600, 2000 A
- a sectionaliser panel with vacuum circuit-breakers of 1250, 1600, 2000 A

Both versions can be supplied in any combination and sequence in a system.

The system has two compartments: one main Busbar/Disconnecter compartment and a Circuit-breaker/Cable connection compartment.

The main busbar system is on top of the panel and is completely closed. In the cable compartment the current transformers and voltage transformers can be installed. The voltage transformers in the cable compartment are fully electrically operated from the front of the panel where the cable must be tested.

Busbar voltage transformers are on the top of the system. An interlocked cable connection point to test the cables is in the front of the panel.

Earthing of the busbar is possible with the sectionaliser. It is also possible to make a circuit-breaker applicable for earthing the busbar. The circuit-breaker is equipped with vacuum interrupters and an electromagnetic mechanism, suitable for 30,000 operations.

The circuit breaker can be exchanged within 30 minutes from the front side of the panel.

The disconnecter has two positions, connected to the busbar or connected to earth.

The cable is earthed via the circuit-breaker.

The interlock between the circuit-breaker and the door of the cable compartment is mechanical. The interlock between the circuit-breaker and the disconnecter is electric.

2.2 Cross-section, single line diagram and list of functions





Figure 2-1: Cross section circuit-breaker 630 / 800 A





Figure 2-2: Cross section circuit-breaker 1250...2000 A





Figure 2-3: Cross section sectionaliser 1600 / 2000 A

Functions circuit-breaker

- Connect cable to busbar.
- Disconnect cable.
- Connect cable to earth.
- Protect outgoing feeder from overcurrents.
- Testing of the cable.

Functions sectionaliser

- Connection of sections.
- Disconnection of sections.
- Earthing of sections.

2.3 Technical specifications, general

Table 3: Technical specifications

Item	Explanation			Specification	
Sound emission	A-weighted equivalent noise pressure level at the work area. In accordance with EN292-2			Less than 70 dB(A)	
Radiation emission	This emission is measured by the Physikalisch-Technische Bundesanstalt at a distance of 100 mm from the surface of the vacuum switch. A Certificate of Conformity has been issued to this effect			Less than 2x10 ⁻⁷ Sv/hour at operating voltage	
Weight of the heaviest transport unit		Nett (kg)	Gross (kg)	See delivery note for the exact value	
	1 circuit-breaker 630, 800 A	625	675		
	1 circuit-breaker 1250 A	750	800		
	1 circuit-breaker 1600 A	900	950		
	1 circuit-breaker 2000 A	950	1000		
	1 sectionaliser 1250 A	1300	1400		
	1 sectionaliser 1600 A	1450	1550		
Unit dimensions		Width (mm)	Depth (mm)	Height (mm)	Refer to the floor plan
	1 circuit-breaker 630, 800, 1250 A	500	1440	2100*	
	1 circuit-breaker 1600,2000 A	1000	1440	2100*	
	1 sectionaliser 1250 A	1200	1440	2100*	
	1 sectionaliser 1600, 2000 A	1700	1440	2100*	
Unit dimensions incl. packing		Width (mm)	Depth (mm)	Height (mm)	Refer to the floor plan
	1 circuit-breaker 630, 800,1250 A	800	1600	2220	
	1 circuit-breaker 1600,2000 A	1100	1600	2220	
	1 sectionaliser 1250 A	1300	1600	2220	
Lifting and transport facilities	The unit is fitted with special lifting fixtures. The unit may only be lifted by these fixtures, see section 3.2.1				
	Connection of power cables			In accordance with cable and plug manufacturer specifications, see section 3.3	
Degree of protection	Protection degree in accordance with IEC 60529			IP4X	

* Per section one arc absorber box of 150 mm should be installed. With busbar voltage transformers the height is 500 mm more.

3. INSTALLING THE UNIT

3.1 Environmental requirements

3.1.1 Transport, assembly and storage conditions

If the temperature and humidity conditions as specified in IEC 62271-1 cannot be guaranteed during the transport, assembly and storage of the unit, preventive measures must be taken in consultation with Eaton.

Care should be taken not to damage the unit, even if the packaging has not been removed. The packaging is only intended to prevent minor damage.

During shipment all switches are to be switched to the earthed position (circuit-breaker closed and change-over switch in earthed position).

Special preventive measures may be required to avoid:

- moisture absorption in the packaging as a result of rain, snow or condensation;
- vibrations during transport;

Inspect the equipment as soon as possible after receipt for any damage that might have occurred during transport.

Before unpacking the equipment itself should be to examine whether a package is damaged because a damaged packaging may indicate an area of injury. Be careful when unpacking the equipment. The finish and equipment itself can be damaged using hammers and crowbars. Use proper tools.

Examine the equipment for possible damage after unpacking.

Check the shipping papers to ensure that all items are received. Do not destroy packing material until you have justified all items on the shipping papers.

Small packages of components may be lost in packing.

Remove any identification labels on the equipment until the switchgear is fully installed.

If there are any shortages, or there is an injury not previously mentioned, be sure that it is listed on the delivery and contact with the carrier. Notify the sales office of the supplier of a shortage or damage.

Storing switchgear

If the switchgear equipment should not be immediately installed, it must be unpacked, inspected within 15 days of receipt and stored in a clean, dry area. Switchgear for use within buildings is not weatherproof nor drip-proof.

Packaging for transport is not suitable for storage. Part of the original packaging can be removed when the switchgear is unloaded. The main busbar system is due to open connection ends, particularly vulnerable to moisture and dirt during storage.

If the equipment have to be stored for a certain time, make a suitable storage ready. Store the equipment in a heated building that is clean and dry. The floor should be clean and flat to avoid mechanical distortion of the switchgear. Make sure the water in the area is drained so that there is no stagnant water. Store the switchgear on the pallets free from the floor so that the air can circulate freely around. Take measures to protect the switchgear from moisture, cement dust, corrosive environments and extreme temperature fluctuations.

To avoid condensation make sure the equipment is well ventilated. Install temporary space heating if necessary. Switches should be checked periodically for signs of deterioration.

It is not recommended to store the switchgear outside buildings. It is the responsibility of the customer to protect the equipment during storage.

All parts and various equipment have to be stored with the same care as the main switchgear.

Summary of storage procedures:

1. Check the ventilation of the switchgear itself and protective coatings. Serious damage can result from a non-ventilated tarpaulin.
2. Check the ventilation of the closed storage room.
3. Check for adequate heating in case of doubt, a heating element have to be placed.
4. Verify that deformation is occurred.
5. Check for damage and standing water.
6. Check for weather protection such as open doors, windows, etc.
7. Store the equipment not in the open air.
8. Inspect regularly.

3.1.2 Ambient conditions when the unit is in service

The unit has been designed in accordance with IEC 62271-1, refer to the type plate on the unit for the specification.

Eaton also imposes additional ambient requirements, see Table 4. If the ambient conditions do not meet the specifications, Eaton can no longer guarantee the operation and service life of the unit.

Table 4: Ambient conditions

Item	Condition
Requirements for the floor and wall of the building	Minimum permissible floor loading 1200 kg/m ² .
	The floor must be level and have a smooth finish to ensure that the carrier frame of the unit is evenly supported
	Provide cable recesses according to the floor plan.
	The cable openings in the floor can be sealed to prevent rising damp. Polyurethane with a compact cellular structure can be used for this.
Requirements for clearances around the FMX	At least 600 mm at the top. This is equivalent to a minimum height of 2700 mm for the operating area.
	One side minimum 100 mm and the other side minimum 500 mm.
	Sufficient space should be available at the front and along the entire length of the unit for operational purposes and to be able to work safely, for instance with a voltage probe or earth rod in excess of 800 mm. In accordance with IEC 61936-1.
Requirements for escape routes	When the unit is installed in an accessible area, escape routes shall be provided according to the local requirements.
Ambient conditions (IEC 62271-1)	<p>Indoor switchgear and controlgear must comply:</p> <ul style="list-style-type: none"> • The ambient air temperature does not exceed 40 °C and its average value, measured over a period of 24 h, does not exceed 35 °C. • The minimum ambient air temperature is -5 °C for class "minus 5 indoor", -15 °C for class "minus 15 indoor" and -25 °C for class "minus 25 indoor". • The influence of solar radiation may be neglected. • The altitude does not exceed 1 000 m. • The ambient air is not significantly polluted by dust, smoke, corrosive and/or flammable gases, vapours or salt.

Item	Condition
Ambient conditions (IEC 62271-1)	<p>The conditions of humidity are as follows:</p> <ul style="list-style-type: none"> • the average value of the relative humidity, measured over a period of 24 h, does not exceed 95 %; • the average value of the water vapour pressure, over a period of 24 h, does not exceed 2,2 kPa; • the average value of the relative humidity, over a period of one month, does not exceed 90 %; • the average value of the water vapour pressure, over a period of one month, does not exceed 1,8 kPa. <p>For these conditions, condensation may occasionally occur.</p> <p>NOTE 1 Condensation can be expected where sudden temperature changes occur in periods of high humidity.</p> <p>NOTE 2 To withstand the effects of high humidity and condensation, such as breakdown of insulation or corrosion of metallic parts, switchgear designed for such conditions and tested accordingly should be used.</p> <p>NOTE 3 Condensation may be prevented by special design of the building or housing, by suitable ventilation and heating of the station or by the use of dehumidifying equipment.</p> <ul style="list-style-type: none"> • Vibration due to causes external to the switchgear and controlgear or earth tremors are negligible. • Induced electromagnetic disturbances at interfaces of the secondary system, as a result of switching in the high-voltage system, do not exceed 1,6 kV common mode for normal EMC severity class, and 0,8 kV common mode for reduced EMC severity class.

3.2 Installing the unit

The unit is packaged.

Provision for lifting is fitted to the top of the unit, see Figure 3-1

The unit can be handled simply and safely providing the standard lifting equipment are used.

The installation of the unit includes the following actions:

1. Lifting.
2. Travelling.
3. Preparation prior to installation.
4. Installing the unit.
5. Securing to the floor.

The first 2 actions can be done by the customer.

Action 3-5 should be done by Eaton Service specialists or certified specialists.



Figure 3-1

3.2.1 Lifting

WARNING

The person in charge of lifting the FMX-unit must hold a certificate issued by the relevant authorities to certify that he/she is authorised to carry out these operations.

3.2.2 Travelling

The unit can be moved simply and safely on a pallet truck.

WARNING

- Keep the load low, the panel is top-heavy.
- Drive carefully.

3.3 Connecting the cables

WARNING

Each panel is supplied in ON-position of the circuit-breaker with the 2-position change-over switch in earth-position. In this position it is possible to open the door of the cable compartment. Do not open the circuit-breaker with the manual operation handle. Otherwise, the door of the cable compartment does not open without an auxiliary voltage

3.3.1 Types of cables

Single-core cables can be connected to the unit.
 Three-core cables can be connected, if the dimensions of the associated splitting point fit into the cable compartment.

Insulated T-connectors can be applied such as Euromold, Tyco Raychem and NKT, standardized according EN 50181 with cone types C and F.
 The panels up to 1250 A are applied with C-cones.
 The panels >1250 A are applied with with F-cones.
 For T-plugs and coupling inserts see the manufacturers information.

3.3.2 Cable assembly instructions

Strain relief

Strain relief prevents mechanical forces from being transmitted to other parts of the unit via the cable connection point.

Each panel is provided with three single phase plastic cable clamps or one three phase plastic cable clamp.

Assembly

WARNING

At delivery each cable cone is provided with a “temporarily” mounted allen key transport bolt M16 x 30.

These bolts must be removed before connecting the cable.

- Remove the plinth.
- Remove the bottom-plates.
- Clean the cable cone and lubricate with silicone grease.
- Secure all cables using cable clamp blocks. This is in order to enable the short-circuit forces to be absorbed in the event of any short-circuit occurring.
- The cable clamp blocks are mounted on a frame in the cable connection compartment. The bolts through the plastic cable clamps must be tightened to a torque of 20 Nm.
- Connect the T-plug to the cone according the assembly instructions of the manufacturer.
- Use the appropriate torque.
- Connect the cables to ensure that no mechanical forces are created at the cable connection point. The maximum torque securing a C-cone is 70 Nm. The weight of the cable and tensile forces originating from the cable must be absorbed by the cable clamp blocks on the cable support.
- Connect the sheath of the cable to the earth busbar.
- Make the bottom-plates suitable for the cables and mount these into the panel.
- Seal all cable recesses in the floor properly. Use polyurethane with a closed cellular structure, for instance. This will protect the cable connection compartment from rising damp and vermin.
- Fit the plinth.



Figure 3-2

3.3.3 Safety precautions with test voltages for the FMX-unit

- The unit must be isolated from any possible normal source of supply, other than the test device.
- Under no circumstances it must be possible for the unit to be re-energized by any source other than the external supply used for voltage testing.
- Safety measures must be applied with respect to all personnel present during voltage testing.

3.3.4 Cable testing

The unit is suitable as standard for cable testing with the following test voltages, for a maximum of 10 minutes per phase:

System voltage	Test voltage (DC or AC-peak value)
24 kV	60 kV
17,5 kV	45 kV
12 kV	30 kV
7,2 kV	30 kV

WARNING

Test accessories are needed to apply test current and test voltage to the connected cables.

- Earth the unit in accordance with section 4.2.2.
- If cable-side voltage transformers are installed, switch the transformers into an isolated position by interrupting the connection with pushbutton (18).



Figure 3-3

- Open the cable access openings by moving the locking slide (15) to the right.
- Insert the test pins fully into the three openings until the protections rings are against the front of the panel.
- The locking slide has to move to the left by inserting each pin to avoid damaging the pin.
- Connect the cable testing device.



Figure 3-4

- Remove the padlock of the interlocking of the earth position.
- The circuit-breaker must not be activated until you and the person responsible for the unit are satisfied that the earthed connection can be opened safely.
- Open the circuit-breaker with push button (14).
- Test the cable with the appropriate voltage. Since the procedure for testing of cables is different per client, this procedure is not described in this manual.
- The unit requires to be earthed again with push button (3) in accordance with section 4.2.2 before the test accessories are removed on completion of the work.
- Remove the test pins. The locking slide has to move to the left by taking out each pin to avoid damaging the pin.
- The unit have to switched into the neutral position after testing by switching the circuit-breaker to the OFF position with push button (14).
- Check the position indicator (2).



Figure 3-5



Figure 3-6

3.4 Connection of station earthing

The FMX-unit can be connected either to the left or to the right of the station earthing.
 In each circuit-breaker and cable compartment an earth bar is located to which the earth screens of the power cables and the system earth can be connected. See Figure 3-7.
 Three M8 nuts are mounted on the earth bar in each cable compartment for the connection of the earth screens of the power cables.



Figure 3-7

The earth bar to the left and right ends is provided with 4 M8 holes for mounting of the earth to the system. See Figure 3-8.



Figure 3-8

3.5 Access to secondary compartment

Access to the secondary compartment is possible with a suitable key.
 This door can always be opened.
 In this door in the upper part is also included the operation panel.
 The operation depends on the type of operation and type of protection.



Figure 3-9

3.6 Connection of secondary cables

The secondary compartment in the panel is behind the upper door on the front side and have secondary cable ducts and terminal blocks. See Figure 3-10.
 The wiring can be connected to the terminal block via both the left and right top openings.



Figure 3-10

4. OPERATION

4.1 Explanation of the Control Panels

The FMX unit is equipped with two types of control panel, one for normal operation and one for operation under special circumstances such as in case there is no auxiliary supply voltage.




Figure 4-1

4.2 Operation (electrical)

4.2.1 Service position ON/OFF switching

For switching ON/OFF the following operation sequence is necessary:

Switching ON:

Starting position of the Circuit-breaker (see Figure 4-2):

Circuit-breaker OFF.

2-position change-over switch on Earth position.



Figure 4-2

- Push button (1) for moving the 2-position change-over switch to the busbar position.
- The position indicator(13) shows the final position after some time.



Figure 4-3

- Push button (3) for Circuit-breaker ON.
- The position indicator (2) shows directly the end position.
- The cable is now connected to the main busbar.



Figure 4-4

Starting position of the Circuit-breaker:
 Circuit-breaker ON.
 2-position change-over switch in Busbar position.



Figure 4-5

Switching OFF:

- Push button(14) for Circuit-breaker OFF.
- The position indicator (2) shows directly the end position.



Figure 4-6

- Push button(12) for moving the 2-position change-over switch to the Earth position.
- The position indicator (13) shows the final position after some time.



Figure 4-7



Figure 4-8

4.2.2 Switch cable earthing on/off

NOTE

When gaining access to the cable, the following basic rules apply at all times:

- Disconnect the cable at both ends.
- Check that the cable is dead with the voltage detection.
- The panel must be in the closed earthed position.
- Hang the warning sign.
- Secure this internal earthing by locking it with a personal padlock.
- Verify that the cable cannot be made live from the other end.
- On request a visible take-over earth can be installed in accordance with the cable connection supplier's instructions.

For switching ON/OFF of the cable-earthing the following operation sequence is necessary:

Starting position of the Circuit-breaker (see Figure 4-9):

Circuit-breaker ON.

2-position change-over switch in Busbar position.

Switching ON cable-earthing:

- Push button(14) for Circuit-breaker OFF.
- The position indicator (2) shows directly the end position.



Figure 4-9



Figure 4-10

Use the built-in voltage detector (4) to check that the cable is dead.

Arrows and dots are visible: detector is functioning correctly and the cable is live

Arrows and dots not visible: cable is dead.

NOTE

The visible dot shows that the detector is functioning correctly in accordance with the demands for voltage detecting systems as described in VDE 0682 art. 415.

This is a continuous internal function check.



Figure 4-11

When the arrows and dots are not visible then check the operation of the voltage detection using the voltage detection tester see Figure 4-12:

1. Insert the tester plugs in the contact sockets "earth" and L1. Test the detector by pressing the tester button. The tested phase arrow and dot should now be present;
2. Repeat the test for L2 and L3.
3. If one or more arrows and dots do not appear, this might be the result of a faulty voltage detector. Should this be the case contact Eaton. Ensure by other means that the cable is dead before carrying out any further switching operations.




Figure 4-12

When the arrows and dots are visible then the functionality of the voltage detector can be tested as follows:

1. Connect a wire from the tester between the contact sockets "earth" and L1. The arrow and dot indication from this phase must disappear.
2. Repeat this test with the phases L2 and L3.

NOTE

The detector also has a piezo test button on the front for testing the LCD screen only.

- Push button(12) for moving the 2-position change-over switch to the Earth position.
- The position indicator(13) shows the final position after some time.

**Figure 4-13**

- Push button(3) for Circuit-breaker ON.
- The position indicator (2) shows directly the end position.
- The cable is now connected to earth.

**Figure 4-14****Figure 4-15**

If required, the door of the cable compartment can be opened after placing a padlock on the earth position interlock and by moving the door upwards and then forwards.



Figure 4-16



Figure 4-17

Switch OFF cable earthing:

Starting position of the Circuit-breaker:

Circuit-breaker ON.

2-position change-over switch on Earth position.

Padlock on earth position interlock.

- Remove padlock of earth position interlock.



Figure 4-18

- Push button(14) for Circuit-breaker OFF.
- The position indicator (2) shows directly the end position.



Figure 4-19

- Push button (1) for moving the 2-position change-over switch to the Busbar position.



Figure 4-20

- The position indicator (13) shows the final position after some time.



Figure 4-21

- Push button (3) for Circuit-breaker ON.
- The position indicator (2) shows directly the end position.
- The cable is now connected to the Busbar.



Figure 4-22



Figure 4-23

4.3 Manual operation

If there is a lack of supply there are several facilities to switch manually to a safe situation.

Manual opening of the circuit-breaker:

The circuit-breaker can be opened if the mechanical operating handle (8) is pushed downwards.

The circuit-breaker can only be switched ON if there is a provision to supply an auxiliary voltage to the panel.



8. Mechanical operating handle Circuit-breaker to OFF position

Figure 4-24



Figure 4-25

Manual operation of the 2-position change-over switch:

The 2-position change-over switch can be manually operated when the locking slide (3) is in the left position and the circuit-breaker is in the OFF position with the handle (6) is held down in the lower position.

Connected to earth:

Place manual operating handle completely in the opening (15) and turn right clockwise until it stops, see also the mechanical position indicator (6). The 2-position change-over switch is connected to earth.



Figure 4-26



Figure 4-27

Connected to busbar:

Place the manual operating handle completely in the opening (15) and turn left counterclockwise until it stops, see also the mechanical position indicator (6). The 2-position change-over switch is now connected to the main busbar.

4.4 Interlocks

The FMX unit is equipped as standard with interlocks to prevent accidental switching operations. A number of switching positions can also be interlocked with padlocks.

WARNING

Undesirable switching operations could result in the following:

- **danger to personnel (operating and service personnel);**
- **failure of power supply;**
- **damage to the unit.**

WARNING

If a (switching) action cannot be achieved with normal operating force:

- **Check against section 4 whether the action to be carried out is permissible;**
- **Notify Eaton-ESS if the action is permissible but cannot be accomplished with normal operating force.**

WARNING

After any temporary absence, check that the necessary interlocks and back-up earths are still in place.

The following interlocks are included in the FMX-installation:

1. It is not possible to operate electrically the 2-position change-over switch when the circuit-breaker is ON.
2. It is not possible to operate the 2-position change-over switch electrically if the mechanical operating handle (8) is used.
3. It is only possible to disconnect the voltage transformers on the cable if the circuit-breaker is in the earthed and locked position.
4. It is only possible to open the cable access openings if the cable is earthed and the earth position interlock is pulled out.
Note: After opening the cable access openings, the circuit-breaker can be switched to the OFF position to perform cable testing, while the connection to earth is disconnected.
5. It is only possible to open the door of the cable compartment if the Circuit-breaker is in the Earthed(locked) position.
6. It is only possible to go to the service position if the cable compartment door is closed.

7. It is only possible to go to the service position if the cable access openings are closed.
8. It is not possible to operate the Circuit-breaker and the 2-position change-over switch in Earthed(locked) position.

4.4.1 Earth position interlocking

The earth position interlocking is used to lock the accidental breaking of the cable earthing. Cable earthing can only be done with the circuit-breaker; the circuit-breaker should therefore be locked to secure the cable earthing.

If this padlock is installed, then the following operations are no longer possible:

1. Opening of the circuit-breaker with the electrical push button (12).
2. Opening of the circuit-breaker with the mechanical operating handle (6).
3. Opening of the circuit-breaker by the protection relay.
4. Switching the 2-position change-over switch to the busbar position.

The earth interlocking can be applied if (see section 4.2.2):

1. The 2-position change-over switch is in earth-position;
2. The circuit-breaker is ON;
3. The door of the cable compartment is closed.

Installation of the padlock, see Figure 4-28:

1. Pull the earth position interlocking lever. The hole for a padlock is then released.
2. Lock the lever in this position with a padlock with a bracket of round 3...12 mm.
3. If required hang a warning sign "Cable earthed".



Figure 4-28

4.4.2 Locking of the 2-position change-over switch

The 2-position change-over switch can be locked with a locking slide (5) which can be locked in any position with a padlock 3 ... 12 mm.

Operation of the 2-position change-over switch is only possible in the OFF position of the circuit-breaker.

There are three positions:

1. Mechanically operated, electrically locked (service opening is available only if the mechanical operating handle (8) is held down).
2. Electrically and mechanically locked.
3. Mechanically locked, electrically operated.



Figure 4-29

4.5 Signals

The FMX unit features voltage detectors in the control panel (4) conform IEC 61243-5 with LRM interface.

4.5.1 Voltage detectors

The voltage detector includes an LCD screen with indication arrows and dots, one for each phase, see Figure 4-30. These arrows and dots are present when the cable is live.

The voltage detector detects whether the operating voltage is present at the cable connection of the panel concerned.

NOTE

The visible dot shows that the detector is functioning correctly in accordance with the demands for voltage detecting systems as described in IEC 61243-5.

This is a continuous internal function check.

In combination with the ORION 3 tester the voltage detectors can also be used for phase comparison between two adjacent live cables. See Appendix 1 for further information.



Figure 4-30

5. REMOTE SIGNALLING AND REMOTE CONTROL

TIP

See the schedule included with the installation package for the right connection and the correct secondary voltage.

FMX switchgear can be equipped with optional electric remote control and remote signaling.

5.1 Remote signalling

The positions of the circuit-breaker and the 2-position change-over switch, are connected to the terminal strip using potential free auxiliary contacts.

Furthermore, also the condition of the mechanism is connected to the terminal strip.

5.2 Remote control

5.2.1 Remote opening

The panels concerned are provided with auxiliary contacts as described under remote signalling, a controller, a universal voltage inverter, an opening coil and a closing coil.

For on-site commissioning:

1. Check that the power supply is live.
2. Use the position indicator (13) to check whether the 2-position change-over switch is fully in the busbar position or in the earthed position.
3. Use the position indicator (2) to check whether the circuit-breaker is closed or locked.
4. The circuit-breaker will switched OFF if the make contact on the terminals of the terminal strip is closed.

5.2.2 Remote closing

The panels concerned are provided with auxiliary contacts as described under remote signalling, a controller, a universal voltage inverter and an opening coil, and a closing coil.

For on-site commissioning:

1. Check that the power supply is live.
2. Use the position indicator (13) to check whether the 2-position change-over switch is fully in the busbar position or in the earthed position.
3. Use the position indicator (2) to check whether the circuit-breaker is closed or locked.
4. The circuit-breaker will switched ON if the make contact on the terminals of the terminal strip is closed.



Figure 5-1

6. INSPECTION AND MAINTENANCE

6.1 Introduction

The FMX system is theoretically a maintenance-free system. No specific components need to be maintained. All primary, live components are maintenance-free and are housed in a IP4X enclosure. All other components in accessible HV compartments are single-phase insulated by epoxy-resin.

Parts of the system can be inspected depending of the ambient conditions.

Table 5 shows the time interval for different ambient conditions.

The normal ambient conditions are described in Table 4.

6.2 Inspections

The frequency of periodic inspection must be carried out, depends very much on the environmental conditions of the FMX system, see Table 5.

6.2.1 Inspecting of cable connections

Inspect the cable connection in accordance with the following procedure:

1. Open the cable connection compartment in accordance with the procedure described in section 4.2.2.
2. Clean the compartment with a dry cloth.
3. Check the cable plug connection according to the plug supplier's instructions. Ensure that the cable does not impart any mechanical strain on the plug. The cable forces are to be absorbed by the cable support..
4. Check the cable support. The cables must be secure in the cable clamp blocks. Check that the bolts are still tightened to a torque of 20 Nm, see Cable assembly instructions in section 3.3.2.
5. Check the earth connections:
 - between cables and earth strip;
 - between earth strip and enclosure;
 - between earth strip and system earth
6. Close the cable compartment.

6.2.2 Inspection of the enclosure

Check the enclosure, hinges and mounting of doors for functionality. Clean if necessary and grease the hinges again.

6.2.3 Inspection of the operation of the circuit-breaker

The circuit-breaker has a controller that checks the status of various components/control circuits. If everything operates correctly, all indications are green.

Table 5: Time interval between inspections.

	Normal ambient conditions	Deviating ambient conditions
Mechanism of the circuit-breaker	No inspections	No inspections
Mechanism of the 2-position change-over switch	No inspections	No inspections
Vacuum interrupter	No inspections	No inspections
Cable connections and earth connections	No inspections	every 10 years
Enclosure	No inspections	every 10 years
Operation of the circuit-breaker	every 10 years	every 10 years
Protection relay	every 10 years	every 10 years

The indications are:

- “Circuit-breaker ON” ; the circuit-breaker is switched ON.
- “System healthy” ; the full circuit-breaker is functioning well.
- “Closing coil cap charged”; the capacitors required for switching ON are fully charged.
- “Leakage current too high” ; the capacitors required for switching ON are NOT fully charged.
- “Open circuit opening coil, open circuit closing coil, end stage defective, control logic defective”; the internal circuits are operating well.



Figure 6-1

6.2.4 Inspection of the protection relay

For inspection and maintenance of the protection relay refer to the manual of the manufacturer of the relay.

6.3 Decommissioning the unit

6.3.1 Material processing after dismantling

Eaton pays a great deal of attention to the environmentally-friendly design aspects of its units and installations. Eaton designs and manufactures in accordance with the ISO 14001 environmental standard. FMX designs do not include any raw materials or other materials that pose a threat to the environment. It is reasonable, therefore, not to expect any problems when FMX products are processed as waste products at the end of their service life. The materials used in FMX units are suitable for re-use. At the end of the service life of a unit, specialized companies will be able to dismantle a unit which has been disposed of. All materials used are suitable for recycling.

TIP

Eaton-ESS can deal with dismantling the unit, as well disposing of and processing materials.

7. ACCESSORIES

7.1 Supplied accessories

- 1 Key for opening the top door.
- 1 User manual.
- 1 Operating handle for 2-position change-over switch per installation.
- 1 Padlock including 2 keys (6 mm) per installation.

7.2 Available accessories and spare parts

See Appendix 2.

APPENDIX 1 – VOLTAGE DETECTION

Each system is equipped with a standard three-phase Voltage Detection System for voltage testing according IEC 61243-5 (VDE 0682 Part 415) with HR-system (other systems on demand).

1. Live part
2. Indication system
3. Voltage indicator
4. Coupling dielectric
5. Coupling electrode
6. Voltage limiting device
7. Measuring circuit
8. Stray capacitance
9. Test point
10. Short-circuiting device




Figure A1-1 Voltage detection system with integrated indicator

Features

- According IEC 61243-5
- Suitable for continuous operation
- Without auxiliary power

A choice can be made of the following types:

- Horstmann Wega 1.2 (LRM system), Fig. A1-2



Figure A1-2 Horstmann Wega 1-2

When the arrows and dots are not visible then check the operation of the voltage detection(4) using the voltage detection tester see figure A1-3.

1. Insert the tester plugs in the contact sockets "earth" and L1. Test the detector by pressing the tester button. The tested phase arrow and dot should now be present;
2. Repeat the test for L2 and L3.
3. If one or more arrows and dots do not appear, this might be the result of a faulty voltage detector. Should this be the case contact Eaton. Ensure by other means that the cable is dead before carrying out any further switching operations.




Figure A1-3 Tester

When the arrows and dots are visible then the functionality of the voltage detector can be tested as follows:

1. Connect a wire from the tester between the contact sockets "earth" and L1. The arrow and dot indication from this phase must disappear.
2. Repeat this test with the phases L2 and L3.

NOTE

The detector also has a piezo test button on the front for testing the LCD screen only.

APPENDIX 2 – AVAILABLE ACCESSOIRES AND SPARE PARTS

E6046005 Phase sequence indicator type Orion Compare. Simplified version of the Orion 3.0. Used for voltage test and phase sequence test of the voltage detecting unit type WEGA.



E6046007 Functional tester for WEGA voltage detecting units.



665868 Cable fixing clamps for primary cables.
36-52 mm single phase cables.
665997 26-38 mm single phase cables.
665867 66-90 mm three phase cables.



Voltage detector with LCD screen make Horstmann type WEGA 1.2
E6015230 3-4.15 kV
E6015231 6-7.2 kV
E6015232 10-15 kV
E6015233 17.5-24 kV



Voltage detector with LCD screen make Horstmann type WEGA 2.2. Equal to the 1.2 version, however including aux.voltage connection and signalling contacts.



107926 Padlock, used for padlocking the earth interlock and/or 2-position change-over switch.



107079 Warning sign, used when a panel is switched ON in earthed position and any further manual operation is not allowed.



6058923 Operating handle for manual operation of the 2-position change-over switch.



6054334 3 Test pins for testing the cables



