



# COLOR LCD EXPANSION MODULE



## USER GUIDE

### UC40

# Notices Information

## Copyright

Copyright © 2005 - 2015 Nanjing Hanlong Technology CO., LTD. All rights reserved.

Nanjing Hanlong Technology Co., LTD. owns all the right to revise and change this document at any time. And all the illustrations and instructions in this paper are subject to the copyright protection of legal law. No parts of this document may be used or reproduced, transmitted by the third parties for any purposes without the express written permission of Nanjing Hanlong Technology Co., LTD.

When this document is made available on Hanlong's web page, hanlong Technology Co., LTD. gives its right to download and print copies of this content only for private use as a user manual. No parts shall have the right to alter, modify or use as commercial means without the express written permission of Nanjing Hanlong Technology Co., LTD.

## Safety cautions

- To use the device follow the instructions in this manual.
- To use the power adapter that delivered with the device. Other power adapters may damage the device.
- The device is only for indoor use. And also avoid in high humidity, water and some other liquids.
- Do not use the device during thunderstorms.
- CE
- FCC

## Disposal of the phone



This symbol indicates that the product is classified as electrical or electronic equipment and should not be disposed of with other commercial or household waste at the end of its working life.

## Cleaning

To clean the device, use an anti-static cloth. Please avoid cleaning liquids as they might damage the surface or internal electronics of the phone

# Table of Content

Notices Information .....	1
Copyright .....	1
Safety cautions .....	1
Disposal of the phone .....	1
Cleaning .....	1
Table of Content .....	2
Getting Started .....	4
Packing List .....	4
Expansion Module Installation .....	6
1. Connect the expansion module and IP Phone .....	6
2. Attach the Foot stand .....	6
3. Connect the IP Phone and Power .....	7
Getting Familiar with Expansion Module .....	8
Hardware Components Preview .....	8
Icon Preview .....	9
How to connect to the IP Phone .....	11
Change the IP Phone to “Connect to Expansion Module.” .....	11
Features Configuration .....	11
Line .....	11
Speed Dial .....	12
BLF .....	12
Voice Mail .....	14
Direct Pickup .....	14
Group Pickup .....	15
Call Park .....	15
Intercom .....	16
DTMF .....	17
Prefix .....	17
Local Group .....	18
XML Group .....	18
LDAP .....	19
XML Browser .....	20
Broadsoft Group .....	20
Conference .....	21
Forward .....	21
Transfer .....	22
Hold .....	22
Group Listening .....	23
DND .....	23
Redial .....	24
Call Return .....	25
SMS .....	25


Record .....	26
Paging .....	26
Shared Line .....	27
Public Hold .....	28
Private Hold .....	28
Hot Desking .....	29
ACD(Pending) .....	29
Zero Touch .....	30
Multicast Paging .....	31
Upgrade.....	32
A. Upgrade via IP Phone.....	32
B. Upgrade via Exp upgrade server ( Only works for HTTP) .....	32

# Getting Started


## Packing List

The package contains the following parts, please check if all the items are not missed:


1. The Expansion module device




2. The Stand




3. Connecting Sheet




4. Power adapter




5. Ethernet cable/Connecting Cord



6. Quick installation reference




7. Quick installation reference




## Expansion Module Installation


### 1. Connect the expansion module and IP Phone



### 2. Attach the Foot stand



### 3. Connect the IP Phone and Power



#### Note:

1. In order to use the UC40, you must first change a setting in the phone attached to the UC40 to accept Expansion Modules on the PC Port. This setting can be found in the phone menu under "Settings / Advanced Settings / Network / PC Port" or in the web GUI under "Network / PC Port".
2. Our expansion modules must be connected to the IP Phone's PC port and can't be connected to the any switches in a LAN.
3. Use the "Uplink" port on the UC40 to connect to the phone, or to the previous UC40 in the chain (if using multiple UC40s). Use the "Downlink" port to connect to the next UC40 in the chain.
4. The open "Downlink" port on the last UC40 may be used as an Ethernet port to provide a data connection to a PC or other device.(please refer to the "Figure 1")
5. The Htek IP phones UC86x and UC84x can support six expansion modules at most.





Figure 1




















# Getting Familiar with Expansion Module

## Hardware Components Preview



## Icon Preview


Icon	Description
	Line(Registered succeed)
	Line (Unregistered)
	Line(Ringing)
	Speed Dial
	BLF
	BLF(Ringing)
	BLF(Talking)
	Voice messages
	Pick up
	Call Park
	Intercom/Paging
	DTMF
	Prefix
	XML Group
	Local Group
	XML Browser

	LDAP
	Broadsoft Group
	Conference
	Forward
	Transfer
	Hold
	Line on Hold
	DND
	Redial
	Call Return
	SMS
	Record
	Recording
	Group Listening
	Shared Line
	Other Functions

## How to connect to the IP Phone

### Change the IP Phone to “Connect to Expansion Module.”

Log on the web page of Phone, on the page “Network→Basic”, PC Port option, choose “Connect to Expansion Module”.



After save set the Phone will reboot.

## Features Configuration

### Line

It works same as Line keys.

#### To configure Line Feature via Web Interface

1. Click Function keys → EXP Key.
2. Select the wanted Key and set as Line.
3. Select the Account.

- Click the **SaveSet** to save the configuration.

The screenshot shows the 'IP PHONE' web interface with a navigation bar containing 'Home', 'Account', 'Network', 'Function Keys', 'Setting', 'Directory', and 'Management'. On the left, there is a sidebar with 'Line Key', 'Memory Key', 'Programmable Key', and 'EXP KEY'. The main content area is titled 'Expansion Key' and has a dropdown menu set to 'Expansion 1'. Below this is a table with columns: Key, Type, Value, Label, Account, and Pickup Code. The table contains three rows: Key1 (Type: Line, Account: Account 1), Key2 (Type: N/A, Account: Account 1), and Key3 (Type: N/A, Account: Account 1). The 'Key1' row is highlighted with a red border. To the right of the table is a 'NOTE' box.

Key	Type	Value	Label	Account	Pickup Code
Key1	Line			Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

## Speed Dial

With this feature, you can dial one directory by press the definite key.

### To configure Speed Dial feature via Web Interface

- Click Function keys → EXP Key.
- Select the wanted Key and set as Speed Dial.
- Enter the desired phone number in the Value field.
- Filled the Label displayed on LCD
- Select the Account.
- Click the **SaveSet** to save the configuration.

The screenshot shows the 'IP PHONE' web interface with a navigation bar containing 'Home', 'Account', 'Network', 'Function Keys', 'Setting', 'Directory', and 'Management'. On the left, there is a sidebar with 'Line Key', 'Memory Key', 'Programmable Key', and 'EXP KEY'. The main content area is titled 'Expansion Key' and has a dropdown menu set to 'Expansion 1'. Below this is a table with columns: Key, Type, Value, Label, Account, and Pickup Code. The table contains three rows: Key1 (Type: Speed Dia, Value: 531, Account: Account 1), Key2 (Type: N/A, Account: Account 1), and Key3 (Type: N/A, Account: Account 1). To the right of the table is a 'NOTE' box.


Key	Type	Value	Label	Account	Pickup Code
Key1	Speed Dia	531		Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	


## BLF

You can use the BLF (Busy Lamp Field) feature to monitor a specific one whether his phone is busy or free.

1. When the monitored line is idle, the light is steady green.
2. When the monitored line is ringing, the light is blinking red, press the BLF key to pick the phone up directly.
3. When the monitored line is calling or in a conversation, the light is steady red.

#### To configure a BLF key by web

1. Click Function keys → EXP Key.
2. Select the desired Key and select BLF in the Type.
3. Enter the monitored phone number in the Value field.
4. Filled the Label displayed on LCD.
5. Select the Account.
6. Filled the Pickup code.
7. Click  to save the configuration and then restart.



Key	Type	Value	Label	Account	Pickup Code
Key1	BLF	531		Account 1	*04
Key2	N/A			Account 1	
Key3	N/A			Account 1	

#### Note:

This feature is not available on all servers. For more information, contact your system administrator.

In the Web interface, you can also active the pickup function(Setting->Features->Call Pickup) and set the pickup code. For example, if you set the BLF value as 333, and the pickup code is \*\*, then when there is an incoming call to 333, press the BLF key, it will call out the \*\* automatically to pickup the incoming call on 333.

## Voice Mail

### To configure Voice Mail feature via Web Interface

1. Click Function keys → EXP Key.
2. Select the wanted Key.
3. Enter the desired voicemail feature codes in the Value field.
4. Filled the Label displayed on LCD.
5. Select the Account.
6. Click **SaveSet** to save the configuration.

Key	Type	Value	Label	Account	Pickup Code
Key1	Voice Mail	*02		Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

## Direct Pickup

With this feature, you can pick up the set line when it ringing.

### To configure Direct Pickup feature via Web Interface


1. Click Function keys → EXP Key..
2. Select the wanted Key and set as Direct Pickup.
3. Enter the pickup code and followed the desired phone number in the Value field.
4. Filled the Label displayed on LCD.
5. Select the Account.
6. Click **SaveSet** to save the configuration.

Key	Type	Value	Label	Account	Pickup Code
Key1	Direct Pi	*04531		Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

## Group Pickup

With this feature, you can pick up the specified group that you want incoming calls.


### To configure the Group Pick up via Web interface

1. Click Function keys → EXP Key.
2. Select the desired Key and select Group Pickup in the Type.
3. Enter the pickup code and followed the desired Group number in the Value field.
4. Filled the Label displayed on LCD..
5. Click  to save the configuration.

## Call Park

With this feature, you can put a call on hold and continue the conversation from another phone.

### To configure the Call Park via Web interface

1. Click Function key → EXP Key.
2. Select the desired Key and select Call Park in the Type.
3. Enter the park feature codes in the value field.
4. Filled the Label displayed on LCD.
5. Select the Account.
6. Click  to save the configuration.



[logout](#)

**IP PHONE**    Home | Account | Network | **Function Keys** | Setting | Directory | Management

Line Key

Memory Key

Programmable Key

**EXP KEY**

**Expansion Key**    Expansion 1 ▾

Key	Type	Value	Label	Account	Pickup Code
Key1	Call Park ▾	70		Account 1 ▾	
Key2	N/A ▾			Account 1 ▾	
Key3	N/A ▾			Account 1 ▾	

NOTE

**Note:**

Your VoIP PBX must support this feature and enable this feature.

## Intercom

When use the intercom feature, you can quickly get access connect to the configured EXPension.

### To configure Intercom feature via Web Interface

1. Click Function keys → EXP Key.
2. Select the wanted Key and select Intercom as the Type.
3. Enter the intercom codes followed by desired number in the Value field.
4. Filled the Label displayed on LCD.
5. Select the Account.
6. Click SaveSet to save the configuration.

[logout](#)

**IP PHONE**    Home | Account | Network | **Function Keys** | Setting | Directory | Management

Line Key

Memory Key

Programmable Key

**EXP KEY**

**Expansion Key**    Expansion 1 ▾

Key	Type	Value	Label	Account	Pickup Code
Key1	Intercom ▾	*5531		Account 1 ▾	
Key2	N/A ▾			Account 1 ▾	
Key3	N/A ▾			Account 1 ▾	

NOTE

**Note:**

This feature is not available on all servers. For more information, contact your system administrator, And make sure the intercom EXPension enables the Auto-answer function.

## DTMF

When the key is configured as DTMF key, You are allowed to send out the desired DTMF number during the conversation.

### To configure the DTMF via Web interface

1. Click Function keys → EXP Key.
2. Select the desired Key and select DTMF in the Type.
3. Fill the value with the Desired DTMF number
4. Enter the Label displayed on LCD.
5. Click  to save the configuration.

Key	Type	Value	Label	Account	Pickup Code
Key1	DTMF	11236#		Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

## Prefix

If the key is configured as Prefix key, you can set the number prefix (e.g. Before the number plus 9), then you don't input 9, press the key and 9 will display on the LCD interface.

### To configure the Prefix via Web interface

1. Click Function key → EXP Key.
2. Select the desired Key and select Prefix in the Type.
3. Fill the value with number that you want to set as prefix
4. Enter Label displayed on LCD.
5. Click  to save the configuration.

Then when you press this key, the set value is input directly.

Key	Type	Value	Label	Account	Pickup Code
Key1	Prefix	9		Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

## Local Group

When use the Local Group feature, press the key and enter the local Contacts interface quickly.

### To configure the Local Group via Web interface

1. Click Function key → EXP Key.
2. Select the desired Key and select Local group in the Type.
3. Filled the Label displayed on LCD.
4. Click  to save the configuration.


Then you can press the local group key to access the pre-defined contact group in the local directory quickly.


Key	Type	Value	Label	Account	Pickup Code
Key1	Local Gro			Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

## XML Group

When use the XML Group feature, press the key and enter the Remote Contacts interface quickly.

**To configure the Local Group via Web interface**

1. Click Function key → EXP Key.
2. Select the desired Key and select XML group in the Type.
3. Filled the Label displayed on LCD.
4. Click  to save the configuration.




The screenshot shows the 'IP PHONE' web interface. The top navigation bar includes 'Home', 'Account', 'Network', 'Function Keys', 'Setting', 'Directory', and 'Management'. The left sidebar has buttons for 'Line Key', 'Memory Key', 'Programmable Key', and 'EXP KEY'. The main content area is titled 'Expansion Key' with a dropdown for 'Expansion 1'. Below this is a table with columns: Key, Type, Value, Label, Account, and Pickup Code. The table contains three rows: Key1 (XML Group, Value: phonebook, Label: Account 1), Key2 (N/A, Value: Account 1), and Key3 (N/A, Value: Account 1). A 'NOTE' box is on the right.


Key	Type	Value	Label	Account	Pickup Code
Key1	XML Group	phonebook	Account 1	Account 1	
Key2	N/A	Account 1		Account 1	
Key3	N/A	Account 1		Account 1	

## LDAP

When use the LDAP feature, you can get the LDAP Phonebook directly.

**To configure the LDAP via Web interface**

1. Click Function key → EXP Key.
2. Select the desired Key and select LDAP in the Type.
3. Filled the Label displayed on LCD.
4. Click  to save the configuration.



The screenshot shows the 'IP PHONE' web interface. The top navigation bar includes 'Home', 'Account', 'Network', 'Function Keys', 'Setting', 'Directory', and 'Management'. The left sidebar has buttons for 'Line Key', 'Memory Key', 'Programmable Key', and 'EXP KEY'. The main content area is titled 'Expansion Key' with a dropdown for 'Expansion 1'. Below this is a table with columns: Key, Type, Value, Label, Account, and Pickup Code. The table contains three rows: Key1 (LDAP, Value: ldap, Label: Account 1), Key2 (N/A, Value: Account 1), and Key3 (N/A, Value: Account 1). A 'NOTE' box is on the right.

Key	Type	Value	Label	Account	Pickup Code
Key1	LDAP	ldap	Account 1	Account 1	
Key2	N/A	Account 1		Account 1	
Key3	N/A	Account 1		Account 1	

## XML Browser

### To configure the XML Browser via Web interface

1. Click Function key → EXP Key.
2. Select the desired Key and select xml browser in the Type.
3. Filled the value and Label.
4. Click **SaveSet** to save the configuration.

IP PHONE [logout](#)

Home | Account | Network | **Function Keys** | Setting | Directory | Management

Line Key  
Memory Key  
Programmable Key  
**EXP KEY**

Expansion Key Expansion 1

Key	Type	Value	Label	Account	Pickup Code
Key1	XML Brows	http://192.168.1.100:8080/xml		Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

NOTE

## Broadsoft Group

When use the BroadSoft Group feature, press the key and enter the Remote Contacts interface quickly.

### To configure the Broadsoft group via Web interface

1. Click Function key → EXP Key.
2. Select the desired Key and select Broadsoft group in the Type.
3. Filled the Label displayed on LCD.
4. Click **SaveSet** to save the configuration.

IP PHONE [logout](#)

Home | Account | Network | **Function Keys** | Setting | Directory | Management

Line Key  
Memory Key  
Programmable Key  
**EXP KEY**

Expansion Key Expansion 1


Key	Type	Value	Label	Account	Pickup Code
Key1	BroadSoft		book	Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	


NOTE

## Conference

The HanLong IP Phone supports up to 5-way conference. You are allowed to configure the programmable key to be used as a conference key.

### To configure Conference via Web Interface

1. Click Function keys →EXP Key.
2. Select the desired Key and select Conference in the Type.
3. Enter the Label displayed on LCD.
4. Click  to save the configuration.




Key	Type	Value	Label	Account	Pickup Code
Key1	Conferenc			Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

## Forward

If the key is configured as Forward key, press this key under the idle status, the IP phone will turn to the Always Forward interface and you can set the Forward to number, then when there is any call to the EXPension number will be forwarded to the set number automatically.

### To configure Forward via Web Interface

1. Click Function keys →EXP Key.
2. Select the desired Key and select Forward in the Type.
3. Enter the Value with the number you want to forward
4. Enter the Label displayed on LCD.
5. Click  to save the configuration.



IP PHONE [logout](#)

Home | Account | Network | **Function Keys** | Setting | Directory | Management

Line Key  
Memory Key  
Programmable Key  
EXP KEY

Expansion Key Expansion 1

Key	Type	Value	Label	Account	Pickup Code
Key1	Forward	530		Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

NOTE

## Transfer

You are able to configure the key as a transfer key to perform the Blind/Attended Transfer.

### To configure Transfer via Web Interface

1. Click Function keys → EXP Key.
2. Select the desired Key and select Transfer in the Type.
3. Enter the Value with the number that wanted transfer to
4. Enter the Label displayed on LCD.
5. Click  to save the configuration.

IP PHONE [logout](#)

Home | Account | Network | **Function Keys** | Setting | Directory | Management

Line Key  
Memory Key  
Programmable Key  
EXP KEY

Expansion Key Expansion 1

Key	Type	Value	Label	Account	Pickup Code
Key1	Transfer	530		Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

NOTE

## Hold

The key can be configured as a hold key. You can use this key to hold and resume a call during the conversation.

### To configure Hold via Web Interface

1. Click Function keys →EXP Key.
2. Select the desired Key and select Hold in the Type.
3. Enter the Label displayed on LCD.
4. Click **SaveSet** to save the configuration.

IP PHONE [logout](#)

Home | Account | Network | **Function Keys** | Setting | Directory | Management

Line Key  
Memory Key  
Programmable Key  
**EXP KEY**

Expansion Key Expansion 1

Key	Type	Value	Label	Account	Pickup Code
Key1	Hold			Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

NOTE

## Group Listening

### To configure Group listening via Web Interface

1. Click Function keys →EXP Key.
2. Select the desired Key and select Group listening in the Type.
3. Enter the Label displayed on LCD.
4. Click **SaveSet** to save the configuration.

IP PHONE [logout](#)

Home | Account | Network | **Function Keys** | Setting | Directory | Management

Line Key  
Memory Key  
Programmable Key  
**EXP KEY**

Expansion Key Expansion 1

Key	Type	Value	Label	Account	Pickup Code
Key1	Group Lis			Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

NOTE


## DND


If the key is configured as DND key, you are allowed to active the DND function immediately when you press it and the phone is to reject all incoming calls automatically. Press it again to



deactivate DND mode.

### To configure DND via Web Interface

1. Click Function keys →EXP Key.
2. Select the desired Key and select DND in the Type.
3. Enter the Label displayed on LCD.
4. Click  to save the configuration.





Key	Type	Value	Label	Account	Pickup Code
Key1	DND			Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

## Redial

If the key is configured as Redial key, you can redial the last placed call from the IP Phone.

### To configure Redial via Web Interface

1. Click Function keys →EXP Key.
2. Select the desired Key and select redial in the Type.
3. Enter the Label displayed on LCD.
4. Click  to save the configuration.





Key	Type	Value	Label	Account	Pickup Code
Key1	Redial			Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

## Call Return

When the key is configured as Call Return key you are allowed to dial out the last phone call you received.

### To configure Call Return via Web Interface


1. Click Function keys → EXP Key.
2. Select the desired Key and select Call Return in the Type.
3. Enter the Label displayed on LCD.
4. Click  to save the configuration.



Key	Type	Value	Label	Account	Pickup Code
Key1	Call Retu			Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

## SMS

### To configure SMS via Web Interface

1. Click Function keys → EXP Key.
2. Select the desired Key and select SMS in the Type.
3. Enter the Label.
4. Click  to save the configuration.

[logout](#)

**IP PHONE**    Home | Account | Network | **Function Keys** | Setting | Directory | Management

Line Key  
Memory Key  
Programmable Key  
EXP KEY

**Expansion Key**    Expansion 1 ▾


Key	Type	Value	Label	Account	Pickup Code
Key1	SMS ▾		sms	Account 1 ▾	
Key2	N/A ▾			Account 1 ▾	
Key3	N/A ▾			Account 1 ▾	

NOTE

## Record

With record feature, you can record calls by pressing a record key on the phone.

### To configure the record via Web Interface

1. Click Function keys → EXP Key.
2. Select the desired Key and select Record in the Type.
3. Enter the Label displayed on LCD.
4. Click  to save the configuration.

[logout](#)

**IP PHONE**    Home | Account | Network | **Function Keys** | Setting | Directory | Management

Line Key  
Memory Key  
Programmable Key  
EXP KEY

**Expansion Key**    Expansion 1 ▾

Key	Type	Value	Label	Account	Pickup Code
Key1	Record ▾			Account 1 ▾	
Key2	N/A ▾			Account 1 ▾	
Key3	N/A ▾			Account 1 ▾	

NOTE

### Note:

Please contact the system administrator whether support this feature or not.

## Paging

With this feature, you can call a phone or a group directly.

### To configure the Paging via Web interface

1. Click Function keys → EXP Key.

2. Select the desired Key and select Paging in the Type.
3. Enter the Paging codes followed by phone number or group number
4. Enter the Label displayed on LCD.
5. Click **SaveSet** to save the configuration.

Key	Type	Value	Label	Account	Pickup Code
Key1	Paging	*07831		Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

## Shared Line

This feature allows subscribers to share SIP lines. Moreover it also provides status monitoring of the shared line.

### To configure shared line via Web Interface

1. Click Function keys → EXP Key.
2. Select the desired Key and select Shared Line in the Type.
3. Enter the Value.
4. Enter the Label displayed on LCD.
5. Select the Account.
6. Click **SaveSet** to save the configuration and then restart.

Key	Type	Value	Label	Account	Pickup Code
Key1	Shared Li	2404984031	4031_1	Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	


**Note:**


This feature is not available on all servers. For more information, contact your system administrator.

## Public Hold

The key can be configured as a public hold key. During a conversation, all members belonging to that particular SLA group can use this key to hold or resume a call.

### To configure public hold via Web Interface

1. Click Function keys → EXP Key.
2. Select the desired Key and select public hold in the Type.
3. Enter the Label displayed on LCD.
4. Click  to save the configuration.




Key	Type	Value	Label	Account	Pickup Code
Key1	Public Ho			Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

## Private Hold

The key can be configured as a private hold key. During a conversation, all members belonging to that particular SLA group can use this key to hold the call, but only the initiator can resume the call.

### To configure private hold via Web Interface

1. Click Function keys → EXP Key.
2. Select the desired Key and select public hold in the Type.
3. Enter the Label displayed on LCD.
4. Click  to save the configuration.

IP PHONE [logout](#)

Home | Account | Network | **Function Keys** | Setting | Directory | Management

Line Key  
Memory Key  
Programmable Key  
EXP KEY

Expansion Key Expansion 1

Key	Type	Value	Label	Account	Pickup Code
Key1	Private B			Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	


NOTE

## Hot Desking

Hot Desking originates from the definition of being the temporary physical occupant of a work station or surface by a particular employee. A primary motivation for Hot Desking is cost reduction. This feature is regularly used in places where not all the employees are in the office at the same time, or not in the office for very long at all, which means actual personal offices would be often vacant, consuming valuable space and resources.

You can use Hot Desking on the IP phone to logout the existing accounts and then log in a new account, that is, many users can share the phone resource in different time. To use this feature, you need to configure a Hot Desking key in advance.

### To configure Hot Desking via Web Interface

1. Click Function keys → EXP Key.
2. Select the desired Key and select hot desking in the Type.
3. Enter the Label displayed on LCD.
4. Click  to save the configuration

IP PHONE [logout](#)

Home | Account | Network | **Function Keys** | Setting | Directory | Management

Line Key  
Memory Key  
Programmable Key  
EXP KEY

Expansion Key Expansion 1

Key	Type	Value	Label	Account	Pickup Code
Key1	Hot Deski		Account 1	Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

NOTE


## ACD(Pending)


ACD feature is often used in offices for customer service, such as call center. The ACD system handles large volumes of incoming calls from callers who have no need to talk to a specific person but who require assistance from any of multiple persons at the earliest opportunity. The ACD



feature on the Htek IP Phone allows the ACD system to distribute calls from large volumes of incoming calls to the registered IP phone users. To use this feature, you should configure an ACD key in advance.

#### To configure ACD via Web Interface

1. Click Function keys → EXP Key.
2. Select the desired Key and select ACD in the Type.
3. Enter the Label displayed on LCD.
4. Click  to save the configuration




Key	Type	Value	Label	Account	Pickup Code
Key1	ACD			Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

## Zero Touch

You can use this key feature to configure auto provision and network parameters quickly.

#### To configure Zero Touch via Web Interface

1. Click Function keys → EXP Key.
2. Select the desired Key and select zero touch in the Type.
3. Enter the Label displayed on LCD.
4. Click  to save the configuration

Key	Type	Value	Label	Account	Pickup Code
Key1	Zero Touch			Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	

## Multicast Paging

Hanlong IP Phones support MultiCast Paging function, you can use this function follow below steps:

Firstly, Multicast address is a Class D addresses are reserved from 224.0.0.0-239.255.255.255, some have a specific use, such as address 224.0.0.0-244.0.0.255 only be used for LAN router is not forward, and 224.0.0.1 the addresses of all hosts, 224.0.0.2 all routers address, 224.0.0.5 address all of routers 224.0.13 is PIMv2 router address; 239.0.0.0-239.255.255.255 is a private address (such as 192.168.x .x); 224.0.1.0-238.255.255.255 can use the Internet.

### To configure Multicast Paging via Web Interface

1. Click Function keys →EXP Key.
2. Select the desired Key and select multicast paging in the Type.
3. Enter the multicast address in the Value field.
4. Enter the Label displayed on LCD.
5. Click **SaveSet** to save the configuration

Key	Type	Value	Label	Account	Pickup Code
Key1	Multicast	224.5.6.20	2001	Account 1	
Key2	N/A			Account 1	
Key3	N/A			Account 1	



# Upgrade

Two ways to upgrade for the Expansion Module

## A. Upgrade via IP Phone

1. Connect the expansion module with IP Phone
2. Click Management→ Auto Provision
3. Choose **Yes** for the Self as Server
4. Put the Expansion module firmware files under the same path of the upgrade for IP Phone, and upgrade via TFTP/FTP/HTTP/HTTPS

The screenshot displays the HANLONG web interface for the 'Firmware Upgrade' section. The top navigation bar includes links for Home, Account, Network, Function Keys, Setting, Directory, and Management (which is highlighted with a red box). The left sidebar contains buttons for Password, Upgrade, Auto Provision (highlighted with a red box), Configuration, TLS Certs, Restart, and Reboot. The main content area is titled 'Firmware Upgrade' and contains the following settings:

- Upgrade Mode: TFTP, ☒ HTTP, FTP, HTTPS
- Firmware Server Path: 192.168.0.240:8080/fm
- Config Server Path: 192.168.0.86:8080/fm
- Allow DHCP Option: 128
- To Override Server: ☐ No, ☒ Yes
- AUTO Upgrade: ☐ No, ☒ Yes; check for upgrade every 10080 Minutes
- HTTP/FTP/HTTPS UserName: [Empty field]
- HTTP/FTP/HTTPS Password: [Empty field]
- Upgrade Check Mode:
  - ☒ Always Check For New Firmware
  - ☐ check new firmware only when FMV pre/suffix changes
  - ☐ Always Skip The Firmware Check
- Authenticate Cfg File: ☒ No, ☐ Yes
- Set Common AES Key: [Empty field]
- Self as Server: ☐ No, ☒ Yes (highlighted with a red box)
- Exp Upgrade Server: [Empty field]

On the right side, there is a 'NOTE' section with two sub-sections: 'Firmware Upgrade' and 'Phonebook Download', both providing detailed instructions about the upgrade process.

## B. Upgrade via Exp upgrade server ( Only works for HTTP)

1. Connect the expansion module with IP Phone

2. Click Management→ Auto Provison
3. Choose **No** for the Self as Server
4. Set the exp upgrade server path: 172.20.xxx.xx (The http server address must start with 172.20.)
5. Upgrade via HTTP.

	Self as Server	<input checked="" type="radio"/> No <input type="radio"/> Yes
	Exp Upgrade Server	<input type="text" value="172.20.21.20"/>