

Operation and Programming 11/03 Edition

sinumerik

SINUMERIK 802D

SINUMERIK 802D base line

Turning

SIEMENS

SIEMENS

SINUMERIK 802D

Operation and Programming Turning

| | |
|--|---|
| Introduction | 1 |
| Turning On an Reference-Point Approach | 2 |
| Setting Up | 3 |
| Manually Controlled Mode | 4 |
| Automatic Mode | 5 |
| Part Programming | 6 |
| System | 7 |
| Programming | 8 |
| Cycles | 9 |

Valid for

| <i>Control System</i> | <i>Software Version</i> |
|--------------------------|-------------------------|
| SINUMERIK 802D | 2 |
| SINUMERIK 802D base line | 1 |

SINUMERIK® Documentation

Printing history

Brief details of this edition and previous editions are listed below.

The status of each edition is shown by the code in the "Remarks" column.

Status code in the "Remarks" column:

A New documentation.

B Unrevised reprint with new Order No.

C Revised edition with new status.

If actual changes have been made on the page since the last edition, this is indicated by a new edition coding in the header on the page.

| Edition | Order-No. | Remark |
|----------------|---------------------|---------------|
| 11.00 | 6FC5 698-2AA00-0BP0 | A |
| 07.01 | 6FC5 698-2AA00-0BP1 | C |
| 10.02 | 6FC5 698-2AA00-0BP2 | C |
| 11.03 | 6FC5 698-2AA00-0BP3 | C |

This Manual is included on the documentation on CD-ROM (**DOCONCD**)

Trademarks

SIMATIC®, SIMATIC HMI®, SIMATIC NET®, SIROTEC®, SINUMERIK® and SIMODRIVE® are registered trademarks of Siemens. Third parties using for their own purposes any other names in this document which refer to trademarks might infringe upon the rights of trademark owners.

This publication was produced with Interleaf V 7

The reproduction, transmission or use of this document or its contents is not permitted without express written authority. Offenders will be liable for damages. All rights, including rights created by patent grant or registration of utility model or design, are reserved.

© Siemens AG 2003. All rights reserved.

Other functions not described in this documentation might be executable in the control. This does not, however, represent an obligation to supply such functions with a new control or when servicing.

We have checked that the contents of this document correspond to the hardware and software described. Nonetheless, differences might exist and therefore we cannot guarantee that they are completely identical. The information contained in this document is, however, reviewed regularly and any necessary changes will be included in the next edition. We welcome suggestions for improvement.

Subject to change without prior notice.

Safety notices

This Manual contains notices intended to ensure your personal safety and to avoid material damage. The notices are highlighted by a warning triangle and, depending on the degree of hazard, represented as shown below:



Danger

indicates that loss of life, severe personal injury or substantial material damage **will** result if the appropriate precautions are not taken.



Warning

indicates that loss of life, severe personal injury or substantial material damage **may** result if the appropriate precautions are not taken.



Caution

indicates that minor personal injury or material damage may result if the appropriate precautions are not taken.

Caution

without a warning triangle means that material damage **can** occur if the appropriate precautions are not taken.

Attention

means that an undesired event or status **can** occur if the appropriate note is not observed.

Note

is used to draw your special attention to an important information on the product, the handling of the product or the corresponding part of the documentation.

Qualified personnel

Start-up and operation of a device may only be carried out by **qualified personnel**. Qualified personnel as referred to in the safety notices provided in this Manual are persons who are authorized to start up, ground and tag devices, systems and circuits according to the relevant safety standards.

Usage as per intended purpose

Please observe the following:



Warning

The device may only be used for the cases of application, as intended by the Catalog, and only in conjunction with third-party devices and components recommended or approved by Siemens.

The proper and safe operation of the product requires transport, storage and installation according to the relevant instructions and qualified operation and maintenance at the prescribed intervals.

Table of Contents

| | | |
|----------|---|-------------|
| 1 | Introduction | 1-13 |
| 1.1 | Screen Layout | 1-13 |
| 1.2 | Operating Areas | 1-16 |
| 1.3 | Accessibility Options | 1-17 |
| 1.3.1 | Calculator | 1-17 |
| 1.3.2 | Editing Chinese Characters | 1-22 |
| 1.3.3 | Hotkeys | 1-22 |
| 1.4 | The Help System | 1-23 |
| 1.5 | Coordinate Systems | 1-24 |
| 2 | Turning on and Reference Point Approach | 2-27 |
| 3 | Setting Up | 3-29 |
| 3.1 | Entering Tools and Tool Offsets | 3-30 |
| 3.1.1 | Creating a New Tool | 3-32 |
| 3.1.2 | Determining Tool Offsets (manually) | 3-33 |
| 3.1.3 | Determining the Tool Compensations Using a Probe | 3-36 |
| 3.1.4 | Determining the tool compensations values using an optical measuring system | 3-37 |
| 3.1.5 | Probe Settings | 3-38 |
| 3.2 | Tool monitoring | 3-40 |
| 3.3 | Entering/Modifying Zero Offset | 3-42 |
| 3.3.1 | Determining Zero Offset | 3-43 |
| 3.4 | Programming Setting Data - Operating Area "Parameters" | 3-44 |
| 3.5 | R Parameters - Operating Area "Offset/Parameters" | 3-47 |
| 4 | Manually Controlled Operation | 4-49 |
| 4.1 | Jog Mode - Operating Area "Position" | 4-50 |
| 4.1.1 | Assigning Handwheels | 4-53 |
| 4.2 | Operating Mode MDA (Manual Input) | 4-54 |
| 4.2.1 | Face Turning | 4-57 |
| 5 | Automatic Mode | 5-61 |
| 5.1 | Selecting and Starting a Part Program | 5-65 |
| 5.2 | Block Search - Operating Area "Machine" | 5-66 |
| 5.3 | Stopping/Aborting a Part Program | 5-67 |
| 5.4 | Reapproach after Interruption | 5-68 |
| 5.5 | Repositioning after interruption | 5-68 |
| 5.6 | Program Execution from External (RS232 Interface) | 5-69 |
| 6 | Part Programming | 6-71 |
| 6.1 | Entering a New Program - Operating Area "Program" | 6-74 |
| 6.2 | Editing a Part Program - Operating Mode "Program" | 6-75 |
| 6.3 | Blueprint programming | 6-77 |
| 6.4 | Simulation | 6-96 |
| 6.5 | Data Transfer via the RS232 Interface | 6-97 |










| | | |
|----------|---|--------------|
| 7 | System | 7-99 |
| 7.1 | PLC diagnosis using the ladder diagram representation | 7-120 |
| 7.1.1 | Screen layout | 7-120 |
| 7.1.2 | Operating options | 7-121 |
| 8 | Programming | 8-131 |
| 8.1 | Fundamentals of NC Programming | 8-131 |
| 8.1.1 | Program Names | 8-131 |
| 8.1.2 | Program Structure | 8-131 |
| 8.1.3 | Word Structure and Address | 8-132 |
| 8.1.4 | Block Structure | 8-133 |
| 8.1.5 | Character Set | 8-134 |
| 8.1.6 | List of Statements | 8-136 |
| 8.2 | Positional Data | 8-150 |
| 8.2.1 | Absolute / Incremental Data Input: G90, G91, AC, IC | 8-150 |
| 8.2.2 | Metric and Inch Dimensions: G71, G70, G710, G700 | 8-151 |
| 8.2.3 | Radius / Diameter Programming: DIAMOF, DIAMON | 8-152 |
| 8.2.4 | Programmable Zero Offset: TRANS, ATRANS | 8-153 |
| 8.2.5 | Programmable Scaling Factor: SCALE, ASCALE | 8-154 |
| 8.2.6 | Workpiece Clamping - Settable Zero Offset: G54 to G59, G500, G53, G153 | 8-155 |
| 8.2.7 | Programmable Working Area Limitation: G25, G26, WALIMON, WALIMOF | 8-156 |
| 8.3 | Axis Movements | 8-158 |
| 8.3.1 | Linear Interpolation at Rapid Traverse: G0 | 8-158 |
| 8.3.2 | Linear Interpolation with Feed: G1 | 8-159 |
| 8.3.3 | Circular Interpolation: G2, G3 | 8-160 |
| 8.3.4 | Circular Interpolation via Intermediate Point: CIP | 8-163 |
| 8.3.5 | Circle with Tangential Transition: CT | 8-163 |
| 8.3.6 | Thread Cutting with Constant Lead: G33 | 8-164 |
| 8.3.7 | Thread cutting with variable lead: G34, G35 | 8-167 |
| 8.3.8 | Thread interpolation: G331, G332 | 8-168 |
| 8.3.9 | Fixed-Point Approach: G75 | 8-169 |
| 8.3.10 | Reference Point Approach: G74 | 8-169 |
| 8.3.11 | Measuring with Switching Tracer: MEAS, MEAW | 8-170 |
| 8.3.12 | Feed F | 8-171 |
| 8.3.13 | Exact Stop / Continuous-Path Control Mode: G9, G60, G64 | 8-172 |
| 8.3.14 | Acceleration Behavior: BRISK, SOFT | 8-174 |
| 8.3.15 | Percentage Acceleration Compensation: ACC | 8-175 |
| 8.3.16 | Traversing with Feedforward Control: FFWON, FFWOF | 8-176 |
| 8.3.17 | 3rd and 4th Axes | 8-176 |
| 8.3.18 | Dwell Time: G4 | 8-177 |
| 8.3.19 | Travel to fixed stop | 8-178 |
| 8.4 | Spindle Motions | 8-181 |
| 8.4.1 | Spindle Speed S; Directions of Rotation | 8-181 |
| 8.4.2 | Spindle Speed Limiting: G25, G26 | 8-181 |
| 8.4.3 | Positioning the Spindle: SPOS | 8-182 |
| 8.4.4 | Gear stages | 8-183 |
| 8.4.5 | 2nd spindle | 8-183 |
| 8.5 | Special Turning Functions | 8-185 |
| 8.5.1 | Constant Cutting Speed: G96, G97 | 8-185 |
| 8.5.2 | Rounding, Chamfer | 8-187 |
| 8.5.3 | Contour Definition Programming | 8-188 |
| 8.6 | Tool and Tool Compensation | 8-191 |
| 8.6.1 | General Notes | 8-191 |
| 8.6.2 | Tool T | 8-191 |
| 8.6.3 | Tool Offset Number D | 8-192 |



















| | | |
|----------|--|--------------|
| 8.6.4 | Selection of Tool Radius Compensation: G41, G42 | 8-195 |
| 8.6.5 | Corner Behavior: G450, G451 | 8-197 |
| 8.6.6 | Tool Radius Compensation OFF: G40 | 8-198 |
| 8.6.7 | Special Cases of Tool Radius Compensation | 8-199 |
| 8.6.8 | Example of Tool Radius Compensation | 8-200 |
| 8.6.9 | Using milling tools | 8-201 |
| 8.6.10 | Tool compensation special cases | 8-203 |
| 8.7 | Miscellaneous Function M | 8-204 |
| 8.8 | H function | 8-205 |
| 8.9 | Arithmetic parameters R, LUD and PLC variables | 8-206 |
| 8.9.1 | Arithmetic parameters R | 8-206 |
| 8.9.2 | Local user data (LUD) | 8-208 |
| 8.9.3 | Reading and writing PLC variables | 8-209 |
| 8.10 | Program Jumps | 8-210 |
| 8.10.1 | Jump Destination for Program Jumps | 8-210 |
| 8.10.2 | Unconditional Program Jumps | 8-210 |
| 8.10.3 | Conditional Program Jumps | 8-211 |
| 8.10.4 | Programming Example of Jumps | 8-213 |
| 8.11 | Subroutine Technique | 8-214 |
| 8.11.1 | General | 8-214 |
| 8.11.2 | Calling Machining Cycles | 8-216 |
| 8.12 | Timer and Workpiece Counter | 8-217 |
| 8.12.1 | Runtime Timer | 8-217 |
| 8.12.2 | Workpiece Counter | 8-218 |
| 8.13 | Language commands for tool monitoring | 8-220 |
| 8.13.1 | Overview: Tool monitoring | 8-220 |
| 8.13.2 | Tool life monitoring | 8-221 |
| 8.13.3 | Count monitoring | 8-222 |
| 8.14 | Milling on turning machines | 8-225 |
| 8.14.1 | Milling face ends - TRANSMIT | 8-225 |
| 8.14.2 | Milling of peripheral surfaces - TRACYL | 8-227 |
| 8.15 | Equivalent G Functions with SINUMERIK 802S - Turning | 8-232 |
| 9 | Cycles | 9-233 |
| 9.1 | Overview of cycles | 9-233 |
| 9.2 | Programming cycles | 9-234 |
| 9.3 | Graphical cycle support in the program editor | 9-236 |
| 9.4 | Drilling cycles | 9-238 |
| 9.4.1 | General | 9-238 |
| 9.4.2 | Preconditions | 9-238 |
| 9.4.3 | Drilling, centering – CYCLE81 | 9-240 |
| 9.4.4 | Center drilling – CYCLE82 | 9-243 |
| 9.4.5 | Deep hole drilling – CYCLE83 | 9-245 |
| 9.4.6 | Rigid tapping – CYCLE84 | 9-249 |
| 9.4.7 | Tapping with compensation chuck – CYCLE840 | 9-252 |
| 9.4.8 | Reaming 1 (boring 1) – CYCLE85 | 9-256 |
| 9.4.9 | Boring (boring 2) – CYCLE86 | 9-259 |
| 9.4.10 | Boring with Stop 1 (boring 3) – CYCLE87 | 9-262 |
| 9.4.11 | Drilling with stop – CYCLE88 | 9-265 |
| 9.4.12 | Reaming 2 (boring 5) – CYCLE89 | 9-267 |
| 9.4.13 | Row of holes – HOLES1 | 9-269 |
| 9.4.14 | Circle of holes – HOLES2 | 9-273 |
| 9.5 | Turning cycles | 9-277 |

| | | |
|-------|---|-------|
| 9.5.1 | Preconditions | 9-277 |
| 9.5.2 | Grooving – CYCLE93 | 9-279 |
| 9.5.3 | Undercut form E .. F – CYCLE94 | 9-287 |
| 9.5.4 | Stock removal – CYCLE95 | 9-291 |
| 9.5.5 | Thread undercut – CYCLE96 | 9-304 |
| 9.5.6 | Thread cutting – CYCLE97 | 9-308 |
| 9.5.7 | Chaining of threads – CYCLE98 | 9-314 |
| 9.6 | Error Messages and Error Handling | 9-321 |
| 9.6.1 | General notes | 9-321 |
| 9.6.2 | Error handling in the cycles | 9-321 |
| 9.6.3 | Overview of cycle alarms | 9-321 |
| 9.6.4 | Messages in the cycles | 9-323 |


SINUMERIK 802D Key Definition



-  Recall key
-  ETC key
-  Acknowledge Alarm key
-  Not assigned
-  Info key
-  Shift key
-  Control key
-  Alt key
-  SPACE (INSERT)

-  Deletion key (Backspace)
-  Deletion key
-  Insertion key
-  Tabulator
-  ENTER / Input key
-  Position operating area key
-  Program operating area key
-  Parameters operating area key
-  Program Manager operating area key
-  Alarm/System operating area key
-  Not assigned
-  Not assigned
-  Paging keys
-  Cursor keys
-  Selection key/toggle key
-  Not assigned
-  Alphanumeric keys
Double assignment on the Shift level
-  Numerical keys
Double assignment on the Shift level

External machine control panel




Reset




NC STOP



NC START



emergency stop



Spindle override



User-defined key with LED



User-defined key with LED



INCREMENT



JOG



REFERENCE POINT



AUTOMATIC



SINGLE BLOCK



MANUAL DATA



SPINDLE START
CCW rotation



SPINDLE START
CW rotation



SPINDLE STOP




RAPID TRAVERSE OVERRIDE
Rapid traverse override



X axis



Z axis



Feed override

Introduction

Note

In the present Manual, SINUMERIK 802D base line is further referred to as 802D-bl.

1.1 Screen Layout




Fig. 1-1 Screen layout

The screen is divided into the following main areas:

- Status area
- Application area
- Tip and softkey area

Status area




Fig. 1-2 Status area

Table 1-1 Explanation of the display elements in the status area

| Display Element | Display | Meaning |
|-----------------|---|--------------------------------|
| ① | <p>Active operating area, active mode</p> <p>Position JOG; 1 INC, 10 INC, 100 INC, 1000 INC, VAR INC (incremental evaluation in JOG mode)</p> <p>MDA AUTOMATIC</p> <p>Offset Program Program Manager System Alarm</p> <p>Marked as an "external language" using G291</p> | |
| ② | <p>Alarm and message line</p> <p>The following is displayed (either/or):</p> <ol style="list-style-type: none"> 1. Alarm number with alarm text 2. Message text | |
| ③ | Program status | |
| | RESET | Program aborted / basic status |
| | RUN | Program running |
| ④ | Program controls in Automatic mode | |
| | Reserved | |
| ⑥ | NC messages | |
| ⑦ | Selected part program (main program) | |

Tip and softkey area








Fig. 1-3 Tip and softkey area

Table 1-2 Explanation of the display elements in the tip and softkey area

| Display Element | Display | Meaning |
|-----------------|--|--|
| ① | | Recall symbol Pressing the Recall key lets you return to the next higher level. |
| ② | | Tip line Displays tips for the operator |
| ③ |     | MMC status information ETC is possible (If you press this key, the horizontal softkey bar will display further functions.) Mixed notation active Data transfer running Link with the PLC programming tool active |
| ④ | | Softkey bar vertical and horizontal |

Standard softkeys



Use this softkey to quit the screen form.



Use this softkey to cancel input; the window will be quitted.



Pressing this softkey will complete your input and start the calculation.

1.2 Operating Areas



Pressing this softkey will complete your input and accept the entered values.



This function is used to switch over the screen form from diameter programming to radius programming.

1.2 Operating Areas

The functions of the control system can be carried out in the following operating areas:



Position Machine operation



Offset/Parameters Input of compensation values and setting data



Program Creation of part programs



Program Manager Part program directory



System Diagnosis, start-up



Alarm Alarm and message lists

To switch to a different operating area, press the appropriate key (hardkey).

Protection levels

The input or modification of data in the control system is password-protected in sensible places.

In the menus listed below the input or modification of data depends on the protection level set.

- Tool offsets
- Zero offsets
- Setting data
- RS232 settings
- Program creation / program correction

1.3 Accessibility Options

1.3.1 Calculator



The calculator function can be activated from any operating area using SHIFT and “=”.

To calculate terms, the four basic arithmetic operations can be used, as well as the functions “sine”, “cosine”, “squaring” and “square root”. A bracket function is provided to calculate nested terms. The bracketing depth is unlimited.

If the input field is already occupied by a value, the function will accept this value into the input line of the calculator.

When you press the **Input** key, the result is calculated and displayed in the calculator.

Pressing the **Accept** softkey enters the result in the input field at the current cursor position of the part program editor and closes the calculator automatically.

Note

If an input field is in the editing mode, it is possible to restore the original status using the “Toggle” key.




Fig. 1-4 Calculator

Characters permitted for input

- + , - Basic arithmetic operations
- *, /
- S Sine function
The X value (in degrees) before the input cursor is replaced by the value sin(X).
- C Cosine function
The X value (in degrees) before the input cursor is replaced by the value cos(X).
- Q Square function
The X value before the input cursor is replaced by the value X².

1.3 Accessibility Options

- R Square root function
The X value before the input cursor is replaced by the value \sqrt{X} .
- () Bracket function $(X+Y)*Z$

Calculation examples

| Task | Input -> Result |
|------------------|-------------------------|
| $100 + (67*3)$ | $100+67*3$ -> 301 |
| $\sin(45^\circ)$ | 45 <u>S</u> -> 0.707107 |
| $\cos(45^\circ)$ | 45 <u>C</u> -> 0.707107 |
| 4^2 | 4 <u>Q</u> -> 16 |
| $\sqrt{4}$ | 4 <u>R</u> -> 2 |
| $(34+3*2)*10$ | $(34+3*2)*10$ -> 400 |

To calculate auxiliary points on a contour, the calculator provides the following functions:

- Calculating the tangential transition between a circle sector and a straight line
- Moving a point in the plane
- Converting polar coordinates to Cartesian coordinates
- Adding the second end point of a straight line/straight line contour section given from an angular relation

Softkeys



This function is used to calculate a point on a circle. The point results from the angle of the tangent created, the radius and the direction of rotation of the circle.




Fig. 1-5

Enter the circle center, the angle of the tangent and the circle radius.





Use the softkey G2 / G3 to define the direction of rotation of the circle.



When you press this softkey, the abscissa and ordinate values are calculated. The abscissa is the first axis, and the ordinate is the second axis of the plane. The value of the abscissa is copied into the input box from which the calculator function has been called, and the value of the ordinate is copied into the next following input box. If the function has been called from the part program editor, the coordinates are saved with the axis names of the selected basic plane.

Example: Calculate the intersection point between circle sector ^① and straight line ^② in plane G18.

Given: Radius: 10
 Circle center: Z 147 X103
 Connection angle of the straight line: -45°



Result: Z = 154.071
 X = 110.071



This function calculates the Cartesian coordinates of a point in the plane, which is to be linked with a point (PP) on a straight line. For calculation, the distance between the points and the slope angle (A2) of the new straight line to be created with reference to the slope (A1) of the given straight line must be known.




Fig. 1-6

Enter the following coordinates or angles:

- the coordinates of the given point (PP)
- the rise angle of the straight line (A1)
- the distance of the new point with reference to PP
- the rise angle of the connecting straight line (A2) with reference to A1

1.3 Accessibility Options



When you press this softkey, the Cartesian coordinates are calculated, which are then copied into two input fields following another to one. The value of the abscissa is copied into the input box from which the calculator function has been called, and the value of the ordinate is copied into the next following input box.

If the function has been called from the part program editor, the coordinates are saved with the axis names of the selected basic plane.



This function converts the given polar coordinates into Cartesian coordinates.




Fig. 1-7

Enter reference point, vector length and slope angle.



When you press this softkey, the Cartesian coordinates are calculated, which are then copied into two input fields following another to one. The value of the abscissa is copied into the input box from which the calculator function has been called, and the value of the ordinate is copied into the next following input box.

If the function has been called from the part program editor, the coordinates are saved with the axis names of the selected basic plane.



This function is used to calculate the missing end point of the straight line/straight line contour section whereby the second straight line stands vertically on the first straight line.

The following values of the straight line are known:

Straight line 1: Start point and slope angle

Straight line 2: Length and one end point in the Cartesian coordinate system






Fig. 1-8



This function is used to select the given coordinate of the end point. The ordinate value or the abscissa value is given.



The second straight line is rotated in CW direction or in counterclockwise direction by 90 degrees relative to the first straight line.



The missing end point is calculated. The value of the abscissa is copied into the input box from which the calculator function has been called, and the value of the ordinate is copied into the next following input box. If the function has been called from the part program editor, the coordinates are saved with the axis names of the selected basic plane.

Example





Fig. 1-9

Add the drawing above by the value of the center circle in order to be able to calculate then the intersection point between the circle sector of the straight line. The missing coordinate of the center point is calculated using the calculator function , since the radius in the tangential transition stands vertically on the straight line.






Fig. 1-10

Calculating M1 in section 1:

The radius stands at an angle of 90° turned CW on the straight-line defined by the angle.

Use the softkey  to select the appropriate direction of rotation. Use the softkey  to define the given end point.

1.3 Accessibility Options

Enter the coordinates of the pole, the slope angle of the straight line, the ordinate angle of the end point and the circle radius as the length.




Fig. 1-11

Result: $X = 60$
 $Z = -44.601$

1.3.2 Editing Chinese Characters

This function is only available in the Chinese language version.

The control system provides a function for editing Chinese characters in the program editor and in the PLC alarm text editor. After activation, type the phonetic alphabet of the searched character in the input box. The editor will then offer various characters for this sound, from which you can choose the desired one by entering either of the digits 1 to 9.




Fig. 1-12 Chinese editor

Alt S is used to turn on/turn off the editor

1.3.3 Hotkeys

This operator control can be used to select, copy, cut and delete texts using special key commands. This functions are available both for the part program editor and for input fields.

- CTRL C Copy
- CTRL B Select
- CTRL X Cut
- CTRL V Paste
- Alt L is used to switch to mixed notation

Alt H Help system
or Info key

1.4 The Help System

To activate the help system, use the Info key. It offers a brief description for all essential operating functions.

Further, the help feature contains the following topics:

- Overview of the NC commands with a brief description
- Cycle programming
- Explanation of the drive alarms




Fig. 1-13 Table of contents of the help system

Show

This function opens the topic selected.




Fig. 1-14 Description with regard to a help topic

Go to
topic

Use this function to select cross references. A cross reference is marked by the characters ">>.....<<". This softkey is only unhidden if a cross reference is displayed in the application area.

**Back to
topic**

If you select a cross reference, in addition, the **Back to topic** softkey is displayed. This function lets you return to the previous screen form.

Find

Use this function to search for a term in the table of contents. Type the term you are looking for and start the search process.

Help in the Program Editor area

The system offers an explanation for each NC instruction. To display the help text directly, position the cursor behind the instruction and press the Info key.

1.5 Coordinate Systems

For machine tools, right-handed, right-angled coordinate systems are used. The movements on the machine are described as a relative movement between tool and workpiece.




Fig. 1-15 Determination of the axis directions another to one; coordinate system for programming on turning

Machine coordinate system (MCS)

How the coordinate system is located with reference to the machine, depends on the machine type concerned. It can be rotated in different positions.




Fig. 1-16 Machine coordinates/machine axes using the example of a turning machine

The origin of this coordinate system is the **machine zero**.

In this point, all axes have the position 'zero'. This point represents only a reference point defined by the machine manufacturer. It need not be approachable.

The traversing range of the **machine axes** can be in the negative range.

Workpiece coordinate system (WCS)

The coordinate system described above (see Fig. 1-15) is also used to describe the geometry of a workpiece in the workpiece program.

The **workpiece zero** can be freely selected by the programmer in the Z axis. In the X axis, it is in the turning center.




Fig. 1-17 Workpiece coordinate system

Relative coordinate system

Apart from the machine and workpiece coordinate systems, the control system provides a relative coordinate system. This coordinate system is used for setting reference points that can be freely selected and have no influence on the active workpiece coordinate system. All axis movements are displayed relative to these reference points.

Clamping the workpiece

For machining, the workpiece is clamped in the machine. The workpiece must be aligned such that the axes of the workpiece coordinate system run in parallel with those of the machine. Any resulting offset of the machine zero with reference to the workpiece zero is determined along the Z axis and entered in a data area intended for the **settable zero offset**. In the NC program this offset is activated, e.g. using a programmed **G54**.




Fig. 1-18 Workpiece on the machine

Current workpiece coordinate system

The programmed zero offset TRANS can be used to generate an offset with reference to the workpiece coordinate system resulting in the current workpiece coordinate system (see Section "Programmable Zero Offset: TRANS").

Turning on and Reference Point Approach

Note

When you turn on the SINUMERIK 802D and the machine, please also observe the Machine Documentation, since turning on and reference point approach are machine-dependent functions.

This documentation assumes an 802D standard machine control panel (MCP). Should you use a different MCP, the operation may be other than described herein.

Operating sequence

First turn on the power supply of CNC and machine. After the control system has booted, you are in the Position operating area, **Jog** mode.

The window "Reference-point approach" is active.

| JOG REF | | Reference point | | T, F, S | |
|------------------|-----------------------------|-----------------|---|---------|--------|
| RESET | SKP DRY RDV M01 PRT SGL | DEM01.MPF | | | |
| MCS | | | | | |
| + X | <input type="radio"/> 0.000 | mm | T | 1 | D 1 |
| + Z | <input type="radio"/> 0.000 | mm | F | 0.000 | 0% |
| + SP | <input type="radio"/> 0.000 | mm | S | 0.000 | mm/min |
| | | | | 0.0 | 0% |
| | | | | 0.0 | 0 |
| MCS / MCS REL | | | | | |

Fig. 2-1 The Jog-Ref start screen



Use the **Ref** key on the machine control panel to activate "reference-point approach".

The Reference-Point Approach window (Fig. 2-1) will display whether the axes have a reference point or not.

- Axis has to be referenced
- Axis has reached its reference point

+X

...

-Z

Select a direction key.

If you select the wrong approach direction, no movement will be carried out.

Approach the reference point one after the other for each axis.

Quit the function by selecting a different mode (**MDA**, **Automatic** or **Jog**).

Note

"Reference-point approach" is only possible in **Jog** mode.

Setting Up

Preliminary remarks

Before you can work with the CNC, set up the machine, the tools, etc. on the CNC as follows:

- Enter the tools and the tool offsets.
- Enter/modify zero offset.
- Enter setting data.

Menu tree

| | | | | | | | |
|--------------|-------------|--|--|-------------------|------------|-----------------|--------------|
| Tool list | Tool life * | | | Work offset | R variable | Setting data | User data * |
| | | | | | | Work area limit | |
| Tool measure | | | | Measure workpiece | | Time counter | Tool measure |
| Delete tool | | | | | | | Delete tool |
| Extend | | | | | | | Extend |
| | | | | | | | |
| Edges | | | | | Find | Misc. | Edges |
| Find | | | | | | | Find |
| New tool | | | | | | | New tool |

Fig. 3-1 The menu tree for the "Parameters" operating area

Note

The softkeys marked with "*" in Fig. 3-1 are not available in the 802D-bl.

3.1 Entering Tools and Tool Offsets

Functionality

The tool offsets consist of several data describing the geometry, the wear and the tool type. Depending on the tool type, each tool is assigned a defined number of parameters. Tools are identified by a number (T number).

See also Section 8.6 "Tool and Tool Offset"

Operating sequence

Offset Param Use this softkey to open the Tool Offset Data window that contains a list of the tools created. Use the cursor keys and the Page Up/PageDown keys to navigate in this list.

Tool List

| T | D | Geometry | Radius | Wear |
|---|---|----------|---------|------------------------|
| | | Length1 | Length2 | Length1 Length2 Radius |
| 1 | 1 | 0.000 | 0.000 | 0.000 0.000 0.000 3 |
| 2 | 2 | 0.000 | 0.000 | 0.000 0.000 0.000 |

Fig. 3-2 Tool list

Use the following operating sequence to enter the compensation values:

- Position the cursor bar on the input box you want to modify,
- enter the desired value(s)



and confirm your input by pressing **Input** or by a cursor movement.

For special tools, the softkey function **Extend** is provided, which offers a complete parameter list, which can be filled in.

Softkeys

Tool measure Use this softkey to determine the tool offset data.

Measure manual Use this softkey to determine the tool offset data manually (see section 3.1.2).

Measure auto Use this softkey to determine the tool offset data semi-automatically (see Section 3.1.3).

Calibrate probe Use this softkey to calibrate the probe.

Note

With the 802D-bl, the **Gauge tool** softkey opens the "Gauge tool" window directly.

Delete tool

Use this softkey to delete the tool offset data of all cutting edges of the tool.

Extend

Use this function to display all parameters of a tool. For the meanings of the parameters, please refer to the Section "Programming".

Fig. 3-3 Screen form for entering special tools

For the meanings of the parameters, please refer to the Chapter "Programming".

Activate change

Pressing this softkey will enable the compensation values of the cutting edge immediately.

Edges

Use this softkey to open a lower-level menu bar offering all functions required to create and display further cutting edges.

D >>

Use this softkey to select the next higher cutting edge number.

<< D

Use this softkey to select the next lower cutting edge number.

New tool edge

Use this softkey to create a new edge.

Reset edge

Use this softkey to reset all offset values of the cutting edge to zero.

Change type

Use this function to change the tool type. Use the relevant softkey to select the appropriate tool type.

Find

Type the number of the tool you are looking for and start the search using the **OK** softkey. If the tool you are looking for exists, the cursor is positioned on the relevant line.

New tool

Use this softkey to create tool offset data for a new tool. A maximum of 48 tools can be created with the 802D, and 18 tools with the 802D-bl. Milling tools are not offered for the 802D-bl.

3.1.1 Creating a New Tool

Operating sequence

New tool

This function offers another two softkey functions to select the tool type. After selecting the tool type, type the desired tool number (max. 3 digits) in the input field.





Fig. 3-4 The *New Tool* window

Input of tool number

For milling and drilling tools, the operator must select the machining direction.




Fig. 3-5 Selection of the machining direction for a milling tool

OK

Use **OK** to confirm your input. A data record loaded with zero by default will be accepted into the tool list.

3.1.2 Determining Tool Offsets (manually)

Functionality

This function can be used to determine the unknown geometry of a tool T.

Prerequisite

The respective tool is changed. In JOG mode, use the **cutting edge** of the tool to approach a point on the machine with known **machine coordinate values**. This can be a workpiece with a known position.

Procedure

Enter the reference point in the appropriate field Ø or Z0.

Please observe: The assignment of length 1 or 2 to the axis depends on the tool type (turning tool, drill).

With a turning tool, the reference point for the X axis is a diameter dimension!

Using the actual position of the point F (machine coordinate) and the reference point, the control system can calculate the compensation value assigned to length 1 or length 2 for the axis preselected.

Note: You can also use a zero offset already determined (e.g. value of G54) as the known machine coordinate. In this case, use the edge of the tool to approach the workpiece zero point. If the edge is positioned directly at workpiece zero, the reference point is zero.




Fig. 3-6 Determination of length compensation values using the example of a cutting tool

3.1 Entering Tools and Tool Offsets




Fig. 3-7 Determining the length compensation using the example of a drill: Length 1 / Z axis

Note

The diagram 3-7 is only applicable if the variables 42950 TOOL_LENGTH_TYPE and TOOL_LENGTH_CONST ≠ 0; otherwise, length tool will apply for the milling and drilling tools.

Operating sequence

Measure tool

Use this softkey to open the selection window for manual or semi-automatic measurement.

| JOG 10000 INC | | | | Measure manual | |
|---------------|----------|-------------------------|--------------|--------------------------|-----------------|
| Reset | | SKP DRY RDV M01 PRT SBL | | DEMO1.MPF | |
| MCS | Position | Repos offset | T,F,S | | |
| + X | 0.000 | 0.000 mm | T 1 | D 1 | Measure auto |
| + Z | 0.000 | 0.000 mm | F | 0.000 0% 0.000 mm/min | |
| | | | | | Calibrate probe |
| | | | | | Back |
| Set base | | Measure workpiece | Measure tool | Settings | |

Fig. 3-8 Selection of manual or semi-automatic measurement

Measure manual

Use this softkey to open the *Measure tool* window.




Fig. 3-9 The "Measure tool" window

- In the field Z0, type the workpiece diameter or in the Z0 field, type a value you wish to have for the tool at the current position. This can be either the current machine coordinate or a value from the zero offsets. If any other values are used, the compensation value will refer to the specified position.
- After the softkeys **Set length 1** or **Set length 2** have been pressed, the control system will determine the searched geometry length 1 or length 2 according to the preselected axis. The compensation value determined will be stored.

Save
position

Pressing this softkey will save the position of the X axis. The X axis can be moved from the workpiece away. It is thus possible, e.g. to determine the workpiece diameter. The saved value of the axis position will then be used for calculating the length compensation.

The behavior of the softkey is determined by the display machine data 373

MEAS_SAVE_POS_LENGTH2 (see also Manufacturer Documentation "SINUMERIK 802D Start-Up")

3.1.3 Determining the Tool Compensations Using a Probe

Note

This function is only available with the 802D.

Operating sequence

Measure tool

Select this softkey and then:

Measure auto

the *Measure Tool* window appears.




Fig. 3-10 The "Measure Tool" window

This interactive screen form can be used to enter tool and edge number. In addition, the tool point direction is displayed after the symbol.

After the screen form has been opened, the boxes of the interactive screen form are filled with the tool currently being in mesh.

The tool can be either



- the active tool of the NC (loaded via a part program) or
- a tool loaded via the PLC.

If the tool has been loaded by the PLC, the tool number in the interactive screen form can differ from the tool number in the window **T,F,S**.

If you change the tool number, no automatic tool change is carried out. The measurement results, however, are assigned to the entered tool.

Measuring process

Approach the probe using either the traversing keys or the handwheel.

After the symbol "Probe triggered"  has appeared, release the traversing key and wait until the end of the measuring process. During the automatic measurement, a gauge  is displayed, symbolizing that the measuring process is in progress.

Note

To create the measuring program, the parameters 'safety clearance' from the "Settings" screen form and 'feedrate' from the "Probe Data" screen form are needed.

If several axes are moved simultaneously, no calculation of the compensation data is carried out.

3.1.4 Determining the tool compensations values using an optical measuring system

Note

This function is only available with the 802D.




Fig. 3-11 Measuring using an optical measuring system (input fields T and D, see measuring using a sensing probe)

Measuring process

For measuring, position the tool tip of a chisel or of a drilling tool into the crosshair. With a milling tool, use the highest point of the cutting edge to determine the tool length.

Then, press the **Set length** softkey to calculate the compensation values.

3.1.5 Probe Settings

Note

This function is only available with the 802D.



This screen form is used to store the probe coordinates and to set the axis feedrate for the automatic measuring process.

All position values refer to the machine coordinate system.




Fig. 3-12 The "Probe Data" screen form

Table 3-1

| Parameter | Meaning |
|----------------------|---|
| Absolute position P1 | Absolute position of the probe in the Z direction |
| Absolute position P2 | Absolute position of the probe in the X+ direction |
| Absolute position P3 | Absolute position of the probe in the Z+ direction |
| Absolute position P4 | Absolute position of the prober in the X- direction |
| Feedrate | Feedrate at which the tool is moved towards the probe |

Calibrating the probe



The calibration of the probe can be carried out either in the **Settings** menu or in the **Measure tool** menu.

To do so, approach four points of the probe.


For calibration, use a tool of the type 500 with tool tip position 3 or 4.


The appropriate parameters to determine the four probe positions can be written to the data records of two cutting edges.

| JOG 10000 INC | | Reset | | SKP DRV ROV M01 PRT SBL | | DEM01.MPF | |
|--|-------------------|--------------|--------|-------------------------|-------|-----------|----------|
| MCS | Position | Repos | offset | T,F,S | | | |
| + X | 0.000 | 0.000 | mm | T 1 | D 1 | | |
| + Z | 0.000 | 0.000 | mm | F | 0.000 | 0% | |
| | | | | S | 0.000 | mm/min | |
| | | | | | 0.0 | 0% | |
| | | | | | 0.0 | 0 | |
| Probe data | | | | | | | |
| Abs. position P1 | 0.000 mm | | | | | | |
| Abs. position P2 | 0.000 mm | | | | | | |
| Abs. position P3 | 0.000 mm | | | | | | |
| Abs. position P4 | 0.000 mm | | | | | | |
| Approach probe with the following axis:Z | | | | | | | Back |
| Set base | Measure workpiece | Measure tool | | | | | Settings |

Fig. 3-13 Calibrating the probe

After the screen form has opened, an animation signaling the current step to be carried out appears next to the current positions of the probe. This position must be approached with the appropriate axis.

After the symbol "Probe triggered"  has appeared, release the traversing key and wait

until the end of the measuring process. During the automatic measuring process, a gauge  is displayed, symbolizing the progress of the measuring process.

The position provided by the measuring program serves to calculate the real probe position.

It is possible to quit the measuring function without all positions having approached. The points already captured remain stored.

Note

To create the measuring program, the parameters 'safety clearance' from the "Settings" screen form and 'feedrate' from the "Probe Data" screen form are needed.

If several axes are moved simultaneously, no calculation of the compensation data is carried out.

To skip a point not needed for measuring, use the **Next Step** function.

3.2 Tool monitoring

Note

This function is only available with the 802D.

Tool-life

Each monitoring type is displayed in 4 columns.

- Setpoint
- Prewarning limit
- Residual value
- active

Use the checkbox in the 4th column to activate/deactivate the monitoring type.




Fig. 3-14 Tool monitoring

Symbols in the T column provide information on the tool status.

- Prewarning limit reached
- Tool disabled
- Tool is monitored

Reset monitor

Use this softkey to reset the monitoring values of the selected tool.




Fig. 3-15

After
enable

Use this softkey to change the enable status of the selected tool.

3.3 Entering/Modifying Zero Offset

Functionality

After reference-point approach, the actual-value memory and thus also the actual-value display are referred to the machine zero. A machining program, however, is always referred to the workpiece zero. This offset must be entered as the zero offset.

Operating sequence

OFFSET
PARAM


Select "Zero Offset" via **Parameters** and **Zero Offset**.

Zero
Offset


A list of settable zero offsets will appear on the screen. The screen form also displays the values of the programmed zero offset, the active scaling factors, the status display "Mirroring active", and the total of all active zero offsets.

| Work offset | | | | | |
|-------------|----------|--------|----------|--|--|
| WCS X | 0.000 mm | MCS X1 | 0.000 mm | | |
| Z | 0.000 mm | Z1 | 0.000 mm | | |
| SP | 0.000 ° | SP | 0.000 ° | | |
| X mm | Z mm | SP ° | | | |
| Base | 0.000 | 0.000 | 0.000 | | |
| G54 | 0.000 | 0.000 | 0.000 | | |
| G55 | 0.000 | 0.000 | 0.000 | | |
| G56 | 0.000 | 0.000 | 0.000 | | |
| G57 | 0.000 | 0.000 | 0.000 | | |
| G58 | 0.000 | 0.000 | 0.000 | | |
| G59 | 0.000 | 0.000 | 0.000 | | |
| Program | 0.000 | 0.000 | 0.000 | | |
| Scale | 1.000 | 1.000 | 1.000 | | |
| Mirror | 0 | 0 | 0 | | |
| Total | 0.000 | 0.000 | 0.000 | | |

Fig. 3-16 The Zero Offset window



Position the cursor bar on the input box you wish to modify,



enter value(s). The values are accepted into the zero offsets either by a cursor movement or using the **Input** key.

Change
activated

The offset values of the cutting edge come into effect immediately.

3.3.1 Determining Zero Offset

Prerequisite

You have selected the window with the corresponding zero offset (e.g. G54) and the axis for which you wish to determine the offset.




Fig. 3-17 Determining the zero offset - Z axis

Procedure

Measure workpiece

Press the softkey **Zero Offs Measur.** The control system will switch to the operating area "Position" and open the dialog box for measuring the zero offsets. The axis selected will appear as a softkey with a black shadow.

Then scratch the workpiece using the tool tip. In the box **Set position to:**, type the position you wish to have for the workpiece edge in the workpiece coordinate system.





Fig. 3-18 Screen form *Determine zero offset in X* Screen form *Determine zero offset in Z*

Set zero offset

The softkey will calculate the offset and will display the result in the "Offset" box.

Abort

Press **Abort** to quit the window.

3.4 Programming Setting Data - Operating Area "Parameters"


Functionality

The setting data are used to make the settings for the operating states. These can be modified if necessary.

Operating sequence



Use the **Offset Parameters** and **Setting Data** softkeys to open the Setting Data window.



The **Setting Data** softkey will branch into another menu level where various control options can be set.




Fig. 3-19 Main screen *Setting data*

Jog feed

Feed value in Jog mode

If the feed value is zero, the control system will use the value stored in the machine data.

Spindle

Spindle speed

Min. / max.

A limitation of the spindle speed in the max. (G26)/min. (G25) fields can therefore only be carried out within the limit values specified in the machine data.

Programmed (LIMS)


Programmable upper speed limiting (LIMS) at constant cutting speed (G96).

Dry run feed (DRY)

The feed that can be entered here will be used instead of the programmed feed in automatic mode if the function "Dry run feed" is selected.

Start angle for thread cutting (SF)

For thread cutting, a start position for the spindle is displayed as the start angle. If the thread cutting operation is repeated, a multiple thread can be cut by modifying the angle.



Position the cursor bar on the input box you wish to modify, enter value(s).



Use the **Input** key or carry out a cursor movement to confirm your input.

Softkeys

Work area limit.

The work area limiting is active for the geometry and for additional axes. Enter the values for the work area limiting. The softkey **Set Active** enables/disables the values for the axis selected using the cursor.




Fig. 3-20

Time counter




Fig. 3-21

3.4 Programming Setting Data - Operating Area "Parameters"

Meaning:

- Parts required: Number of workpieces required (required workpieces)
- Parts total: Number of workpieces manufactured in total (actual total)
- Part count: This counter logs the number of all workpieces produced beginning from the starting time.
- Run time: Total runtime of NC programs in the AUTOMATIC mode (in seconds)

The AUTOMATIC mode counts the runtimes of all programs executed between NC START and end of program / RESET. The timer is reset to zero with every power-up of the control system; runtime of the selected NC program (in seconds)

- Cycle time: Tool action time (in seconds)

In the NC program selected, the runtime between NC START and end of program / RESET is measured. Starting a new NC program will clear the timer.

- Cutting time

The runtime of the path axes is measured in all NC programs between NC START and end of program, without rapid traverse active and the tool active. With the dwell time active, the measurement is additionally interrupted.

If the control system is booted with the default values, the timer is reset to zero automatically.

Misc

Use this softkey to display a complete list of all setting data of the control system. The data are divided into

- general,
- axis-specific and
- channel setting data.

| OFFSET | | | | 1 | Axis + |
|----------------------------|-------------------------|-------------|-------------|--------------|------------------|
| Axis-Specific setting data | | | | | Axis - |
| 43210 | SPIND_MIN_VELO_G25 | 0.000000 | rev/min | po | General |
| 43220 | SPIND_MAX_VELO_G26 | 0.000000 | rev/min | po | Axis Spec. |
| 43230 | SPIND_MAX_VELO_LIMS | 0.000000 | rev/min | po | Channel specific |
| 43400 | WORKAREA_PLUS_ENABLE | 0 | | po | |
| 43410 | WORKAREA_MINUS_ENABLE | 0 | | po | |
| 43420 | WORKAREA_LIMIT_PLUS | 0.000000 | mm | po | |
| 43430 | WORKAREA_LIMIT_MINUS | 0.000000 | mm | po | |
| 43900 | TEMP_COMP_ABS_VALUE | 0.000000 | mm | po | |
| 43910 | TEMP_COMP_SLOPE | 0.000000 | | po | |
| 43920 | TEMP_COMP_REF_POSITION | 0.000000 | mm | po | |
| 53013 | OSCILL_REVERSE_POS1 | 0.000000 | mm | po | |
| 53014 | OSCILL_REVERSE_POS2 | 0.000000 | mm | po | |
| 53015 | OSCILL_VELO | 0.000000 | mm/min | po | |
| 53016 | OSCILL_DWELL_TIME1 | 0.000000 | s | po | |
| 53017 | OSCILL_DWELL_TIME2 | 0.000000 | s | po | |
| 53018 | OSCILL_NUM_SPARK_CYCLES | 0 | | po | |
| | | | | | Back |
| Tool list | | Zero offset | R parameter | Setting data | |

Fig. 3-22

3.5 R Parameters - Operating Area "Offset/Parameters"

Functionality

The main screen **R Parameters** displays a complete list of all R parameters of the control system (see also Section 8.9 "Arithmetic Parameters R"). These can be modified if necessary.





Fig. 3-23 The R Parameters window


Operating sequence



Select the softkeys **Parameters** and **R Parameters**,




position the cursor bar on the input box you wish to modify, and



enter value(s).



Use the **Input** key or carry out a cursor movement to confirm your input.



Use this softkey to search for R parameters.

4

Manually Controlled Operation

Manually controlled operation is possible in **Jog** and **MDA** modes.

The softkeys marked with an "✱" (asterisk) are not available with the 802D-bl.

| | Set base | Measure workpiece | Measure tool | | | | Settings |
|--|----------------|-------------------|-------------------|--|--|--|-----------------|
| | x=0 | | Measure manual ✱ | | | | Data probe ✱ |
| | z=0 | Work offset | Measure auto ✱ | | | | |
| | | X | | | | | |
| | | Z | | | | | |
| | Set rel | | | | | | Switch mm>inch. |
| | Delete base W0 | | Calibrate probe ✱ | | | | |
| | x=z=0 | Set work offset | | | | | |
| | Back << | Back << | Back << ✱ | | | | Back << |

Fig. 4-1 Jog menu tree

| | Set basis | | | | | Face | Settings |
|--|----------------|--|--|--|--|-------------------|-----------------|
| | x=0 | | | | | Peripher. surface | Data probe ✱ |
| | z=0 | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | Set rel | | | | | | Switch mm>inch. |
| | Delete base W0 | | | | | | |
| | x=z=0 | | | | | Abort | |
| | Back << | | | | | OK | Back << |

Fig. 4-2 MDA menu tree

4.1 Jog Mode - Operating Area "Position"

Operating sequence



Use the **Jog** key on the machine control panel to select Jog mode.



...



To traverse the axes, press the appropriate key of the X or Z axis.

As long as this key is hold down, the axes will traverse continuously at the rate defined in the setting data. If the value in the setting data is zero, the value stored in the machine data will be used.



Set the speed using the override switch.



If you also press the **Rapid Traverse Override** key, the selected axis will be traversed at rapid traverse velocity as long as the keys are hold down.



In **Incremental Dimension** mode, you can use the same operating sequence to traverse settable increments. The set increment is displayed in the display area. To cancel, simply press **Jog** once more.

The *Jog* main screen displays position, feed and spindle values, as well as the current tool.

| JOG 10000 INC | | DEMO1.MPF | | | G function |
|---------------|----------|-------------------|--------------|--------------------------|--------------------|
| MCS | Position | Repos. offset | T, F, S | | |
| + X | 0.000 | 0.000 mm | T 1 | D 1 | Auxiliary function |
| + Z | 0.000 | 0.000 mm | F | 0.000 0% 0.000 mm/min | |
| | | | S | 0.0 0% 0.0 0 | Axis feedrate |
| | | | | | MCS / WCS REL. |
| | | | | | Hand wheel |
| | | | | | Settings |
| | Set base | Measure workpiece | Measure tool | | |

Fig. 4-3 The Jog main screen

Parameters

Table 4-1 Description of the parameters displayed in the *Jog* main screen

| Parameters | Explanation |
|------------------|--|
| MCS X Z | Display of addresses of existing axes in the machine coordinate system (MCS). |
| +X - Z | If you traverse an axis in the positive (+) or negative (-) direction, a plus or minus sign is displayed in the corresponding field. If the axis is already in the desired position, no sign will be displayed. |
| Position mm | These fields display the current position of the axes in the MCS or WCS. |
| Repos offset | If the axes are traversed in the state "Program interrupted" in Jog mode, this column displays the distance traversed by each axis with reference to the break point. |
| G function | Display of important G functions |
| Spindle S rpm | Display of actual and set values of spindle speed |
| Feed F mm/min | Display of feedrate actual and set values |
| Tool | Display of the currently engaged tool and of the current edge number |

Note

If a second spindle is integrated into the system, the workspindle is displayed using a lower font size. The window will always display only the data of one spindle.

The control system displays the spindle data, taking into account the following aspects:

The master spindle is displayed:


- in the idle condition,
- at spindle start,
- if both spindles are active.

The workspindle is displayed:

- at spindle start of the workspindle.

In all cases, the power bar applies to the spindle currently active.

Softkeys



This softkey is used to set the basic zero offset or a temporary reference point in the relative coordinate system. After opening, this function can be used to set the basic zero offset.

4.1 Jog Mode - Operating Area "Position"

The following subfunctions are offered:

- Direct input of the axis position desired
In the position window, position the input cursor on the desired axis and enter the new position. Complete your input either by pressing the **Input** key or by a cursor movement.
- Setting all axes to zero
The softkey function **X=Y=Z=0** will overwrite the current position of the corresponding axis with zero.
- Setting individual axes to zero
If you select either of the softkeys **X=0**, **Y=0** or **Z=0**, the current position will be overwritten with zero.

Pressing the Set Rel softkey switches the display to the relative coordinate system. The following inputs will modify the reference point in this coordinate system.

Note

A modified basic zero offset will act regardless of any other zero offsets.

Measure workpiece Determining the zero offset (see Chapter 3)

Measure tool Use this softkey to determine the tool compensation values (see Chapter 3)

Settings In MDA mode, this screen form is used to set the retraction level, the safety distance and the direction of rotation for part programs generated automatically.

In addition, this screen form can be used to set the values for JOG feed and for the variable incremental dimension.




Fig. 4-4

Retraction plane: The "Face" function will retract the tool to the specified position (Z position) after execution.

Safety distance: Clearance to the workpiece surface. defines the minimum distance between workpiece surface and workpiece. It is used by the functions "Face" and "Automatic tool gauging".

4.2 Operating Mode MDA (Manual Input)

Functionality

In **MDA** mode, you can create and run a part program.



Caution

In manual mode, the same safety locks are applicable as in fully automatic mode. Furthermore, the same prerequisites are required as in fully automatic mode.

Operating sequence



Use the **MDA** key on the machine control panel to select **MDA** mode.




Fig. 4-6 The MDA main screen

Enter one or several blocks using the keyboard.



Press **NC START** to start machining. During the machining, the blocks cannot be edited.

After execution, the contents of the input field remain stored so that NC Start can be activated again to continue.

ParametersTable 4-2 Description of the parameters displayed in the **MDA** working window

| Parameters | Explanation |
|---------------------|---|
| MCS X Z | Display of existing axes in MCS or WCS |
| +X -Z | If you traverse an axis in the positive (+) or negative (-) direction, a plus or minus sign is displayed in the corresponding field. If the axis is in the desired position, no sign is displayed. |
| Position mm | These fields display the current position of the axes in the MCS or WCS. |
| Distance to go | This field displays the distance to go for the axes in MCS or WCS. |
| G function | Display of important G functions |
| Spindle S rpm | Display of the actual and set values of the spindle speed |
| Feed F | Display of the feedrate actual and set values in mm/min or mm/rev. |
| Tool | Display of the currently active tool and of the current edge number (T..., D...). |
| Editing win- dow | In the program state "Stop" or "Reset", an editing window is used to enter part program blocks. |

Note

If a second spindle is integrated into the system, the workspindle is displayed using a lower font size. The window will always display only the data of one spindle.

The control system displays the spindle data, taking into account the following aspects:

The master spindle is displayed:

- in the idle condition,
- at spindle start,
- if both spindles are active.

The workspindle is displayed:

- at spindle start of the workspindle.

In all cases, the power bar applies to the spindle currently active.

Softkeys

- | |
|----------|
| Set base |
|----------|

Use this softkey to set a basic zero offset (see Section 4.1).
- | |
|------|
| Face |
|------|

Face milling (see Section 4.2.1)
- | |
|----------|
| Settings |
|----------|

see Section 4.1
- | |
|------------|
| G function |
|------------|

The G function window provides G functions whereby each G function is assigned a group and has a fixed position in the window. Use the **PageUp** and **PageDown** keys to display further G functions. If you press this softkey several times, the window is closed.
- | |
|---------------------|
| Auxiliary functions |
|---------------------|

This window displays the active auxiliary and M (miscellaneous) functions. If you press this softkey several times, the window is closed.
- | |
|---------------|
| Axis feedrate |
|---------------|

This softkey will unhide the Axis Feed window. If you press this softkey several times, the window is closed.
- | |
|------------------|
| Delete MDI prog. |
|------------------|

This function will delete all blocks displayed in the program window.
- | |
|----------------|
| Save MDI prog. |
|----------------|

Type a name with which you want to save the MDA program in the program directory in the input field. Alternatively, you can select an existing program from the list. To switch between the input field and the program list, use the TAB key.




Fig. 4-7

- | |
|-------------|
| MCS/WCS REL |
|-------------|

The display of the actual values for **MDA** mode is carried out depending on the selected coordinate system.

4.2.1 Face Turning

Functionality

This function can be used to prepare the blank for the subsequent machining without creating a special part program.

Operating sequence



Face

In **MDA** mode, open the input screen form using the **Face** softkey.

- Position the axes on their start points.
- Enter the values in the screen form.



If you have filled in the screen form completely, the function will create a part program, which can be started using **NC Start**. The screen form will be closed, and the machine main screen appears where the progress of the program can be viewed.

Important

First the retraction level and the safety distance must be defined in the Settings menu.




Fig. 4-8 Face turning

4.2 Operating Mode MDA (Manual Input)

Table 4-3 Description of the parameters in the **Face Turning** window

| Parameters | Explanation |
|---------------------------|--|
| Tool | Input of the tool to be used The tool is changed prior to the machining. To this aim, the function will call a user cycle that will carry out all steps required. This cycle is provided by the machine manufacturer. |
| Feed F | Input of feedrate in mm/min or mm/rev. |
| Spindle S rpm | Input of spindle speed |
| Machining | Determination of surface quality It is possible to choose between roughing and finishing. |
| Diameter | Input of the coarse diameter of the part |
| Z0 Blank dimension | Input of Z position |
| Z1 Cutting dimension | Cutting dimension, incremental |
| DZ Cutting dimension | Input of cutting length in Z direction This dimension is always specified in increments and is referred to the workpiece edge. |
| UZ Max. infeed per cut | Allowance in Z direction |
| UX Max. infeed per cut | Allowance in X direction |

Peripher. surface .Longitudinal turning




Fig. 4-9 Longitudinal turning

Table 4-4 Description of the parameters in the **Face Turning** window

| Parameters | Explanation |
|---------------------------|--|
| Tool | Input of the tool to be used The tool is changed prior to the machining. To this aim, the function will call a user cycle that will carry out all steps required. This cycle is provided by the machine manufacturer. |
| Feed F | Input of feedrate in mm/min or mm/rev. |
| Spindle S rpm | Input of spindle speed |
| Machining | Determination of surface quality It is possible to choose between roughing and finishing. |
| X0 Blank diameter | Input of the diameter of the blank |
| X1 Cutting length | Cutting length, incremental, in Z direction |
| Z0 Position | Input of the workpiece edge position in Z direction |
| Z1 Cutting length | Cutting length, incremental, in Z direction |
| DX Max. infeed per cut | Input of infeed dimension |
| UZ | Input field for allowance on roughing |
| UX | Allowance |

Get curr.
position

Use this function to accept the current position of the tool tip into the input field Z0 or X0.

Automatic Mode

Functionality

In the Automatic mode, you can execute part programs fully automatically, i.e. this is the mode intended for normal operation of part machining.

Operating sequence



Use the **Automatic** key to select **Automatic** mode.

The *Automatic* mode start screen appears, which displays position, spindle, tool values and the current block.




Fig. 5-1 The *Automatic* start screen

Note

The **Real-time simulat.** softkey is only available with the 802D-bl with the color display option.

Spindle power and load display are not implemented in the 802D-bl.

| | | | | | | | |
|--|--|--|------------------|-------------------|--|----------------------|----------------|
| | | | Program control | Block search | | Real-time simulat. | Correct progr. |
| | | | Program test | To contour | | Zoom Auto | |
| | | | Dry run feedrate | To endpoint | | To origin | |
| | | | Condit. stop | Without calculate | | display all | |
| | | | Skip | Interr. point | | Zoom + | |
| | | | SiBL fine | Find | | Zoom - | |
| | | | ROV active | | | Delete window | |
| | | | | | | Cursor coarse / fine | |
| | | | Back << | Back << | | Back << | Back << |

Fig. 5-2 The *Automatic* menu tree

Parameters

Table 5-1 Description of the parameters in the working window

| Parameters | Explanation |
|--------------------------------|--|
| MCS X Z | Display of the existing axes in MCS or WCS |
| + X - Z | If you traverse an axis in the positive (+) or negative (-) direction, a plus or minus sign will appear in the relevant window. If the axis is positioned, no sign is displayed. |
| Position mm | These fields display the current position of the axes in MCS or WCS. |
| Distance to go | These fields display the distance to go for the axes in MCS or WCS. |
| G function | Display of important G functions |
| Spindle S rpm | Display of spindle speed set and actual values |
| Feed F mm/min or mm/rev. | Display of feedrate actual and set values |
| Tool | Display of the currently engaged tool and of the current edge (T..., D...). |
| Current block | The block display shows seven blocks of the active part program, which follow one after another without spaces. The display of each individual block is limited to the width of the window. If blocks are quickly executed one after the other, the display switches to the display of three blocks so that you can follow the program execution as best as possible. Use the softkey "Program sequence" to return to 7-segment display. |

Note

If a second spindle is integrated into the system, the workspindle is displayed using a lower font size. The window will always display only the data of one spindle.

The control system displays the spindle data, taking into account the following aspects:

The master spindle is displayed:

- in the idle condition,
- at spindle start,
- if both spindles are active.

The workspindle is displayed:

- at spindle start of the workspindle.

In all cases, the power bar applies to the spindle currently active.

Softkeys

Progr.
control

When you press this softkey, the softkeys for selecting the program control options (e. g. Skipped Block, Program Test) are displayed.

Program
test

Pressing Program Test will disable the setpoint output to the axes and spindles. In this case, the setpoint display will "simulate" the traversing movement.

Dry run
feed rate

Traversing movements are carried out with the feed setpoint specified using the Dry Run Feed setting data. The dry run feed is active instead of the programmed motion commands.

Condit.
STOP

If this function is active, the program execution always stops at the blocks in which the miscellaneous function M01 is programmed.

Skip

Program blocks that are marked with a slash ahead of the block no. will be ignored during the program execution (e.g. "/N100").

SBL fine

If this function is active, the part program blocks will be executed separately as follows: Each block will be decoded separately, and the program will stop at each block; an exception are only thread blocks without dry run feed. With these blocks, the program stops only at the end of the current thread block. "Single Block fine" can only be selected in the RESET state.

ROV active

If you press this softkey, the feed override switch will also be active for rapid traverse.

Back <<

Use this softkey to quit the screen form you are currently working in.

Block
Search

Use the Block Search key to go to the desired position in the program.

To
contour

Block search forward with calculation

During block search, the same calculations are carried out as in normal program mode, only the axes do not move.

To
endpoint

Block search forward with calculation to the end-of-block position

During block search, the same calculations are carried out as in normal program mode, only the axes do not move.

- Without calculate

 Block search forward without calculation
 During block search, no calculations are carried out.
- Interr. point

 The cursor is positioned on the main program block of the interruption point. Setting of the search destination in the subroutine levels is carried out automatically.
- Find

 The **Find** softkey provides the functions “Find line” and “Find text”.
- Real-time simulat.

 The programmed tool ,path can be tracked using a broken-line graphics.
 (see also Section 6.4)
- Correct progr.

 Use this program to correct false program passages. Any changes will be stored immediately.
- G funct

 Use this softkey to open the *G function* window to display all G functions active.
 The *G function* window contains all active G functions whereby each G function is assigned a ground and has a fixed place.
 Use the **PageUp** or **PageDown** keys to display further G functions.




Fig. 5-3 The Active G functions window

- Auxiliary function

 This window displays the auxiliary and M(iscellaneous) functions currently active.
 Pressing this softkey several times will close the window.
- Axis feedrate

 Pressing this softkey will display the *Axis Feed* window.
 If you press this softkey several times, the window is closed.
- Program sequence

 Pressing this softkey will switch the display from 7-block to 3-block display.
- MCS/WCS REL

 Use this softkey to select the values for the machine, workpiece or relative coordinate systems.
- External programs

 An external program is transferred to the control system via the RS232 interface and executed immediately by pressing **NC START**.

5.1 Selecting and Starting a Part Program

Functionality

Before starting a program, CNC and machine have to be set up. Make sure that the safety notes of the machine manufacturer are complied with.

Operating sequence




Use the **Automatic** softkey to select **Automatic** mode.




An overview of all programs existing in the control system will be displayed.



Position the cursor bar on the desired program.



Use the **Execute** softkey to select the desired program for execution. The selected program name will appear in the display line "Program name".



As necessary make appropriate settings how you wish the program to be executed.




Fig. 5-4 Program control



If you press **NC START**, the part program will be executed.

5.2 Block Search - Operating Area "Machine"

Operating sequence

Prerequisite: The desired program has already been selected (see Section 5.1) and the control system is in the reset condition.

Progr.
control

The block search function provides program advance to the desired part program position. The search destination is set by directly positioning the cursor bar on the desired block of the part program.




Fig. 5-5 Block search

To
contour

Block search up to start of block

To
endpoint

Block search up to end of block

Without
calculate

Block search without calculation

Interr.
point

The interruption point is loaded.

Find

If you press this softkey, a dialog box will open, which will prompt you to enter the terms you are looking for.




Fig. 5-6 Entering the searched term

Result of search

Display of the desired block in the *Current Block* window

5.3 Stopping/Aborting a Part Program

Operating sequence



Use **NC STOP** to interrupt the execution of a part program.
Press **NC START** to continue.



Use **RESET** to abort the program currently running.
If you press **NC START** again, the aborted program will be restarted and executed from the beginning.

5.4 Reapproach after Interruption

After program interruption (RESET), you can move away the tool from the contour in Manual mode (**Jog**).


Operating sequence




Select **Automatic** mode.



Open the *Block Search* window to load the interruption point.



The interruption point will be loaded.



Pressing this softkey will start block search to the interruption point. An adjustment to the start position of the interrupted block will be carried out.



Press **NC START** to continue the program execution.

5.5 Repositioning after interruption

After a program interruption (**NC STOP**), you can retract the tool from the contour in the Manual mode (**Jog**); the coordinates of the interruption point are stored by the control system. The path differences traversed by the axes are displayed.

Operating sequence



Select the **AUTOMATIC** mode.



Press **NC START** to continue the program execution.

Caution

When reapproaching the interruption point, **all axes will traverse at the same time.** Make sure that the traversing area is not obstructed.

5.6 Program Execution from External (RS232 Interface)

Functionality

An external program is transferred to the control system via the RS232 interface and executed immediately by pressing **NC START**.

While the buffer memory is processed, reloading is carried out automatically. For example, a PC on which the PCIN tool for external data transfer is installed can be used as the external device.

Important

Always connect and disconnect the V24 cable when the PCU and the PC are switched off.

Operating sequence

Prerequisite: The control system is in the RESET state.

The RS232 interface is parameterized correctly (see Chapter 7) and not occupied by any other application (DataIn, DataOut, STEP7).

External
progr.

Press this softkey.

Use the PCIN tool on the external device (PC) to set active the program intended for data output.

The program will be loaded into the buffer memory and automatically selected and displayed in the program selection.

It is advantageous for the program execution to wait until the buffer memory has been filled.



The program execution starts with **NC START**. The program is reloaded continuously.

The program is automatically removed from the control system either at the end of the program or in the event of **RESET**.

Note

Any errors during the program transfer are displayed in the **Services / Data I/O** area if you press the **Error log** softkey.

Block search is not possible for programs read in from external.

Part Programming

Operating sequence



Open the **Program Manager**. It displays the part program or cycle directory in the form of a list.




Fig. 6-1 The *Program Manager* main screen

You can use to cursor key for navigating in the program directory. To find programs quickly, type the initial letter of the program name. The control system will then automatically position the cursor on a program in which matching characters have been found.

Softkeys

- | | |
|-------------|--|
| Programs | Use this softkey to open the part program directory. |
| Execute | Use this softkey to choose the program for execution, which you have selected using the cursor. The program will be started with the next NC START . |
| New | Use the softkey New to create a new program. A window appears, which requests you to enter program name and program type. |
| Copy | Use the softkey Copy to copy the selected program into another program with a new name. |
| Open | Use this softkey to open the file for execution, which you have selected using the cursor. |
| Delete | Use this softkey to delete the program or all part programs selected by means of the cursor. Pressing the OK softkey will execute the deletion job, and Abort will cancel it. |
| Rename | If you press the softkey Rename , a window opens in which you can rename the program, which you have selected first, using the cursor. Type the new name, press OK to confirm the new order or use Abort to cancel. |
| Read out | Use this softkey to save programs via the RS232 interface. |
| Read in | Use this softkey to load part programs via the RS232 interface. For the interface settings, please refer to the operating area System (Chapter 7). The transfer of part programs must be carried out using the text format. |
| Cycles | Use the softkey Cycles to display the Standard Cycles directory. This softkey is only available if the operator has the required access authorization. |
| Delete | Use this softkey to delete the cycle highlighted by the cursor; first, a confirmation warning will appear. |
| User cycles | Use the User cycles softkey to display the "User cycles" directory. With the appropriate access right, the softkeys New , Copy , Open , Delete , Rename , Read out and Read in are displayed. |




Fig. 6-2

Save
data

Save data

This function will save the contents of the volatile memory into a nonvolatile memory area.

Prerequisite: There is no program currently executed.

Do not carry out any operator actions while the data backup is running!

6.1 Entering a New Program - Operating Area "Program"

Operating sequences



Programs

You have selected the operating area **Programs** and are in the overview of the programs already created in the NC.

New

If you press the **New** softkey, a dialog box appears where you can type the new name of the main program or subroutine. The extension .MPF for main programs is entered automatically. The extension .SPF for subroutines has to be entered with the program name.




Fig. 6-3 Input screen form *New Program*

A J W Z

Enter the name of the new program.

OK

Press the **OK** softkey to complete your input. The new part program file is generated and the editor window opens automatically.

Abort

Use **Abort** to cancel the creation of the program; the window will be closed.

6.2 Editing a Part Program - Operating Mode "Program"

Functionality

A part program or sections of a part program can only be edited if the program is not being executed.

All changes in the part program are stored immediately.




Fig. 6-4 The Program Editor main screen

Menu tree




Fig. 6-5 The Program menu tree

The softkeys marked with an "*" (asterisk) are only available with 802D-bl with color display option.

Operating sequence

Use the "Program manager" to select the program you want to edit and select **Open** to open the program.

Softkeys

| | |
|--------------|---|
| Edit | Program editor |
| Execute | Pressing this key will execute the selected file. |
| Mark block | Use this softkey to select a text block up to the current cursor position. |
| Copy block | Use this softkey to copy a selected block into the clipboard. |
| Insert block | Use this function to paste a text from the clipboard to the current cursor position. |
| Delete block | Use this softkey to delete a selected text block. |
| Find | Use the softkeys Find and Find Next to search for a string in the displayed program file. In the input box, type the term you are looking for and press OK to start the search. If the string you are looking for is not found in the program file, an error message appears. Use Back to close the dialog box without starting the search. |
| Renumber | This function replaces the block numbers from the current cursor position to the program end. |
| Contour | For programming the contour ("blueprint programming"), see Section 6.3. |
| Drill | see Manual "Cycles" |
| Milling | see Manual "Cycles" (with the options "Transmit" and "Tracyl") |
| Turning | see Manual "Cycles" |
| Recompile | For recompilation, position the cursor on the cycle calling line in the program. The function decodes the cycle name and prepares the screen form with the appropriate parameters. If there are any parameters across the valid range, the function will automatically load default values. If the screen form has been quitted, the original parameter block is replaced by the corrected block. Please note: Only blocks generated automatically can be recompiled. |
| Simulation | The simulation is described in Section 6.4. |

6.3 Blueprint programming

Functionality

The control system offers various contour screenforms for the fast and reliable creation of part programs. The interactive screenforms must be filled with the required parameters.

Using the contour screenforms, you can program the following contour elements or contour sections:

- Straight line section with specification of end point or angle
- Circle sector with specification of center point / end point / radius
- Contour section straight line - straight line with specification of angle and end point
- Contour section straight line - circle with tangential transition; calculated on the basis of angle, radius and end point
- Contour section straight line - circle with any transition; calculated on the basis of angle, center point and end point
- Contour section circle - straight line with tangential transition; calculated on the basis of angle, radius and end point
- Contour section circle - straight line circle with any transition; calculated on the basis of angle, center point and end point
- Contour section circle - circle with tangential transition; calculated on the basis of center point, radius and end point
- Contour section circle - circle with any transition; calculated on the basis of center point and end point
- Contour section circle - straight line - circle with tangential transitions
- Contour section circle - circle - circle with tangential transitions
- Contour section straight line - circle - straight line - circle with tangential transitions




Fig. 6-6

The coordinates can be input either as an absolute, incremental or polar value. Input is switched using the Toggle key.

Softkeys

Use these softkey functions to branch into the individual contour elements.

When opening a contour screenform for the first time or after a cursor motion, the control system must be advised of the starting point of the relevant contour section. All subsequent motions will refer to this point.




Fig. 6-7 Setting the starting point

Use this interactive screenform to define whether the following contour sections are to be programmed using radius or diameter programming or whether the transformation axes are to be used for TRANSMIT or for TRACYL.

Note

The TRANSMIT and TRACYL softkeys do not exist with the 802D-bl. Therefore, in the interactive screenform, it must only be defined whether the following contour sections are to be programmed using radius or diameter programming.

The **Approach start point** softkey function will generate an NC block approaching the entered coordinates.



Programming aid for the programming of straight line sections




Fig. 6-8

Enter the end point of the straight line in absolute dimensions, in incremental dimensions (with reference to the starting point) or in polar coordinates. The current settings are displayed in the interactive screenform.

The end point can also be defined by a coordinate and the angle between an axis and the straight line.

If the end point is determined via polar coordinates, you will need the length of the vector between the pole and the end point, as well as the angle of the vector referred to the pole.

The prerequisite is that a pole was set beforehand. This pole will be applicable until a new pole is set.



A dialog box will appear where the coordinates of the pole point must be entered. The pole point will refer to the selected plane.




Fig. 6-9

G0/G1

If this function is selected, the selected block is traversed at rapid traverse or with the programmed path feedrate.

Add. functions If necessary you can enter additional functions in the fields. The commands can be separated from each other by spaces, commas or semicolons.




Fig. 6-10

This interactive screenform is provided for all contour elements.

OK Pressing the **OK** softkey will accept all commands into the part program.
 Select **Abort** to quit the interactive screenform without saving the values.



This function is intended to calculate the point of intersection between two straight lines. Specify the coordinates of the end point of the second straight line and the angles of the straight lines.




Fig. 6-11 Calculating the point of intersection between two straight lines

Table 6-1 Input in the interactive screenform

| | | |
|------------------------------|----|---|
| End point of straight line 2 | E | Enter the end point of the straight line. |
| Angle of straight line 1 | A1 | The angle is specified in the counterclockwise direction from 0 to 360 degrees. |

Table 6-1 Input in the interactive screenform, continued

| | | |
|--------------------------|----|---|
| Angle of straight line 2 | A2 | The angle is specified in the counterclockwise direction from 0 to 360 degrees. |
| Feedrate | F | Feedrate |



Use this interactive screenform to create a circular block using the coordinates end point and center point.





Fig. 6-12

Enter the end point and center point coordinates in the input fields. Input fields no longer needed are hidden.



G2/G3

Use this softkey to switch the direction of rotation from G2 to G3. G3 will appear on the display. Pressing this softkey again will switch back the display to G2.



OK

Pressing the **OK** softkey will accept the block into the part program.



This function will calculate the tangential transition between a contour and a circle sector. The straight line must be described by the starting point and the angle. The circle must be described by the radius and the end point.

For calculating the points of intersection with any transition angles, the POI softkey function will display the center point coordinates.




Fig. 6-13 Straight line - circle with tangential transition

Table 6-2 Input in the interactive screenform

| | | |
|----------------------------|---|--|
| End point of the circle | E | Enter the end point of the circle. |
| Angle of straight line | A | The angle is specified in the counterclockwise direction from 0 to 360 degrees. |
| Radius of the circle | R | Input field for the circle radius |
| Feedrate | F | Input field for the interpolation feedrate |
| Center point of the circle | M | If there is no tangential transition between the straight line and the circle, the circle center point must be known. The specification is performed depending on the type of calculation (absolute, incremental or polar coordinates) selected in the previous block. |

G2/G3 Use this softkey to switch the direction of rotation from G2 to G3. G3 will appear on the display. Pressing this softkey again will switch back the display to G2. The display changes to G2.

POI You can choose between tangential or any transition.
The screenform generates a straight line and a circle block from the data you have entered.

If several points of intersection exist, the desired point of intersection must be selected from a dialog box.

If one coordinate was not entered, the program tries to calculate it from the existing specifications. If there are several possibilities, a dialog box is provided to choose from.



This function will calculate the tangential transition between a straight line and a circle sector. The circle sector must be described by the parameters starting point and radius, and the straight line must be described by the parameters end point and angle.




Fig. 6-14 Tangential transition

Table 6-3 Input in the interactive screenform

| | | |
|----------------------------|---|---|
| End point of straight line | E | Enter the end point of the straight line in absolute, incremental or polar coordinates. |
| Center point | M | Enter the center point of the circle in absolute, incremental or polar coordinates. |
| Radius of the circle | R | Input field for the circle radius |
| Angle of straight line 1 | A | The angle is specified in the counterclockwise direction from 0 to 360 degrees and with reference to the point of intersection. |
| Feedrate | F | Input field for the interpolation feedrate |

G2/G3

Use this softkey to switch the direction of rotation from G2 to G3. G3 will appear on the display. Pressing this softkey again will switch back the display to G2. The display changes to G2.

POI

You can choose between tangential or any transition.

The screenform generates a straight line and a circle block from the data you have entered.

If several points of intersection exist, the desired point of intersection must be selected from a dialog box.



This function will insert a straight line tangentially between two circle sectors. The sectors are determined by their center points and their radii. Depending on the direction of rotation selected, different tangential points of intersection result.

Use the displayed screenform to enter the parameters center point and radius for the sector 1 and the parameters end point, center point and radius for the sector 2. Furthermore, the direction of rotation of the circles must be selected. A help screen is provided to display the current settings.

Pressing OK calculates three blocks from the entered values and inserts them into the part program.




Fig. 6-15

Table 6-4 Input in the interactive screenform

| | | |
|------------------------------|----|--|
| End point | E | 1. and 2nd geometry axes of the plane If no coordinates are entered, this function provides the point of intersection between the circle sector you have inserted and sector 2. |
| Center point of the circle 1 | M1 | 1st and 2nd geometry axes of the plane(absolute coordinates) |
| Radius of circle 1 | R1 | Input field for radius 1 |
| Center point of circle 2 | M2 | 1st and 2nd geometry axes of the plane(absolute coordinates) |
| Radius of circle 1 | R2 | Input field for radius 2 |
| Feedrate | F | Input field for the interpolation feedrate |

The screenform generates one straight line and two circle blocks from the data you have entered.

G2/G3

Use this softkey to define the direction of rotation of the two circle sectors. You can choose between

| | |
|----------|----------|
| sector 1 | sector 2 |
| G2 | G3, |
| G3, | G2, |
| G2, | G2 and |
| G3, | G3. |

The end point and the center point coordinates can be entered either in absolute dimensions, incremental dimensions or polar coordinates. The current settings are displayed in the interactive screenform.

Example DIAMON




Fig. 6-16

| | | |
|--------|----|--------------|
| Given: | R1 | 50 mm |
| | R2 | 100 mm |
| | R3 | 40mm |
| | M1 | Z -159 X 138 |
| | M2 | Z -316 X84 |
| | M3 | Z -413 X 292 |

Starting point: The point X = 138 and Z = -109 mm (-159 - R50) is supposed as the starting point.





Fig. 6-17 Setting the starting point

After you have confirmed the starting point, use the screenform  to calculate the contour section C1 - L1 - C2.

Use softkey 1 to set the direction of rotation (G2/G3) of the two circle sectors and to fill out the parameter list.

6.3 Blueprint programming

The center point coordinates must be entered as absolute coordinates, i.e. the X coordinate with reference to zero.

The end point remains open.




Fig. 6-18

After you have filled out the interactive screenform, click on OK to quit the screenform. The points of intersection are calculated and the two blocks are generated.

```

ANF: G1 G94 X78 F3000 T1=1 D1=1 %
DIAMON%
G2 G90 Z=-202.54467 X88.85279 K=50.00000 I0.00000%
G1 Z=-228.91867 X182.29441%
G2 G90 Z=202.54467 X88.85279 K=50.00000 I0.00000%
    
```

Fig. 6-19 Result of step 1

Since the end point has been left open, the point of intersection of the straight line

(L1) with the circle sector (C2) will be used as the starting point for the next contour definition.

Now, call the interactive screenform for calculating the contour section (C2) - (C3) again. The end point of the contour section are the coordinates Z= -413.0 and X=212.




Fig. 6-20 Calling the screenform




Fig. 6-21 Result of step 2



The function calculates the tangential transition between two circle sectors. Circle sector 1 must be described by the parameters starting point, center point and radius, and the circle sector 2 be described by the parameters end point and radius.




Fig. 6-22 Tangential transition

Table 6-5 Input in the interactive screenform

| | | |
|------------------------------|----|--|
| End point of circle 2 | E | 1st and 2nd geometry axes of the plane |
| Center point of the circle 1 | M1 | 1st and 2nd geometry axes of the plane |
| Radius of circle 1 | R1 | Input field for the radius |
| Center point of circle 2 | M2 | 1st and 2nd geometry axes of the plane |
| Radius of circle 1 | R2 | Input field for the radius |
| Feedrate | F | Input field for the interpolation feedrate |

The specification of the points is performed depending on the type of calculation (absolute, incremental or polar coordinates) selected beforehand. Input fields no longer needed are hidden. If a value is omitted from the center point coordinates, the radius must be entered.

6.3 Blueprint programming

G2/G3 Use this softkey to switch the direction of rotation from G2 to G3. G3 will appear on the display. Pressing this softkey again will switch back the display to G2. The display changes to G2.

POI You can choose between tangential or any transition.
The screenform generates two circle blocks from the data you have entered.

Selecting the point of intersection

If several points of intersection exist, the desired point of intersection must be selected from a dialog box.




Fig. 6-23 Selecting the point of intersection

POI 1 The contour will be drawn using the point of intersection 1.




Fig. 6-24

POI 2 The contour will be drawn using the point of intersection 2.





Fig. 6-25



Pressing OK accepts the point of intersection of the displayed contour into the part program.



This function will insert a circle sector between two adjacent circle sectors. The circle sectors are described by their center points and circle radii, and the inserted sector is described only by its radius.

The operator is offered a screenform where he will enter the parameters center point, radius for circle sector 1 and the parameters end point, center point and radius for the circle sector 2. Furthermore, the radius for the inserted circle sector 3 must be entered and the direction of rotation be defined.

A help screen is provided to display the selected settings.

Pressing OK calculates three blocks from the entered values and inserts them into the part program.




Fig. 6-26 Screenform for calculating the contour section circle-circle-circle

| | | |
|------------------------------|----|---|
| End point | E | 1st and 2nd geometry axes of the plane If no coordinates are entered, this function provides the point of intersection between the circle sector you have inserted and sector 2. |
| Center point of the circle 1 | M1 | 1st and 2nd geometry axes of the plane |
| Radius of circle 1 | R1 | Input field for radius 1 |
| Center point of circle 2 | M2 | 1st and 2nd geometry axes of the plane |
| Radius of circle 1 | R2 | Input field for radius 2 |
| Radius of circle 3 | R3 | Input field for radius 3 |
| Feedrate | F | Input field for the interpolation feedrate |

If it is not possible to determine the starting point from the previous blocks, use the "Starting point" screenform to enter the appropriate coordinates.

G2/G3

Use this softkey to define the direction of rotation of the two circles. You can choose between

| sector 1 | inserted sector | sector 2 |
|----------|-----------------|----------|
| G2, | G 3, | G2, |
| G2 | G2 | G2, |
| G2 | G2 | G3, |
| G2 | G3 | G3, |
| G3 | G2 | G2, |
| G3 | G3 | G2, |
| G3 | G2 | G3, |
| G3 | G3 | G3 |

Center and end points can be acquired either in absolute dimensions, incremental dimensions or using polar coordinates. The current settings are displayed in the interactive screenform.

Example DIAMON - G23





Fig. 6-27

| | | |
|--------|----|--------------|
| Given: | R1 | 39 mm |
| | R2 | 69 mm |
| | R3 | 39 mm |
| | R4 | 49 mm |
| | R5 | 39 mm |
| | M1 | Z -111 X 196 |
| | M2 | Z -233 X 260 |
| | M3 | Z -390 X 162 |

The coordinates Z -72, X 196 will be selected as the starting point.

After you have confirmed the starting point, use the screenform to calculate  the contour section (C1) - (C3). The end point is left open, since the coordinates are not known.

Use softkey 1 to set the direction of rotation of the two circles (G2 - G2 - G3) and to fill out the parameter list.




Fig. 6-28 Setting the starting point

6.3 Blueprint programming




Fig. 6-29 Input of step 1







Fig. 6-30 Result of step 1

The function provides the point of intersection between circle sector 2 and circle sector 3 as the end point.

In the second step, use the screenform to calculate  the contour section

 - . For calculation, select the direction of rotation G2 - G3 - G2. Starting point is the end point of the first calculation.




Fig. 6-31 Input of step 2




Fig. 6-32 Result of step 2

The function provides the point of intersection between circle sector 4 and circle sector 5 as the end point.

To calculate the tangential transition between \textcircled{CS} and $\textcircled{L1}$ use the screenform "Circle - straight line".




Fig. 6-33 Screenform "Circle - straight line"




Fig. 6-34 Result of step 3



The function inserts a circle sector (with tangential transitions) between two straight lines. The circle sector is described by the center point and the radius. Specify the coordinates of the end point of the second straight line and, optionally, the angle A2. The first straight line is described by the starting point and the angle A1.

The screenform can be used if the following conditions are fulfilled:

| Point | Given coordinates |
|----------------|--|
| Starting point | <ul style="list-style-type: none"> Both coordinates in a Cartesian coordinate system Starting point as a polar coordinate |
| Circle sector | <ul style="list-style-type: none"> Both coordinates in the Cartesian coordinate system and the radius Center point as a polar coordinate |
| End point | <ul style="list-style-type: none"> Both coordinates in a Cartesian coordinate system End point as a polar coordinate |

| Point | Given coordinates |
|----------------|---|
| Starting point | <ul style="list-style-type: none"> Both coordinates in a Cartesian coordinate system Starting point as a polar coordinate |
| Circle sector | <ul style="list-style-type: none"> One coordinate in the Cartesian coordinate system and the radius Angle A1 or A2 |
| End point | <ul style="list-style-type: none"> Both coordinates in a Cartesian coordinate system End point as a polar coordinate |

If it is not possible to determine the starting point from the previous blocks, the starting point must be set by the operator.




Fig. 6-35 Straight line - circle - straight line

Table 6-6 Input in the interactive screenform

| | | |
|------------------------------|----|---|
| End point of straight line 2 | E | Enter the end point of the straight line. |
| Center point of the circle | M | 1st and 2nd axes of the plane |
| Angle of straight line 1 | A1 | The angle is specified in the counterclockwise direction. |

| | | |
|--------------------------|----|---|
| Angle of straight line 2 | A2 | The angle is specified in the counterclockwise direction. |
| Feedrate | F | Input field for the feedrate |

End and center points can be specified either absolute, incremental or polar coordinates. The screenform generates one circle and two straight line blocks from the data you have entered.

G2/G3

Use this softkey to switch the direction of rotation from G2 to G3. G3 will appear on the display. Pressing this softkey again will switch back the display to G2. The display changes to G2.

6.4 Simulation

Note

With the 802D-bl, this function is only available with the color display option.

Functionality

The programmed tool path can be traced using a broken-line graphics.

Operating sequence

You are in the Automatic mode and have selected a program you want to run (cf. Section 5.1).



Simulation

The main screen appears.




Fig. 6-36 The Simulation main screen



Press **NC Start** to start the simulation of the selected part program.

Softkeys

| | |
|-----------|---|
| Zoom Auto | Use this softkey if you wish the recorded tool path to be scaled automatically. |
| To origin | Use this softkey if you wish to use the default setting for scaling. |
| Show ... | Use this softkey to display the entire workpiece. |
| Zoom + | Use this softkey to zoom out the display cutout. |
| Zoom - | Use this softkey to zoom in the display cutout. |

Delete
window

Use this softkey to clear the visible screen.

Cursor
coarse/fi

Use this softkey to modify the step size of the cursor.

6.5 Data Transfer via the RS232 Interface

Functionality

The RS232 interface can be used to output data (e. g. part programs) to an external data back-up device or to read in them from there. The RS232 interface and your data back-up device must be matched another to one.

File types

- **Part programs**
 - Part programs
 - Subroutines
- **Cycles**
 - Standard cycles

Operating sequence

PROGRAM
MANAGER

Programs

You have selected the operating area **Program Manager** and are in the overview of NC programs already created.

Read out

Use this softkey to save part programs via the RS232 interface.




Fig. 6-37 Reading out a program

6.5 Data Transfer via the RS232 Interface

- | |
|-----------|
| All files |
|-----------|

Use this softkey to select all files.
All files in the part program directory will be selected and the data transfer started.
- | |
|-------|
| Start |
|-------|

Use this softkey to start output.
One or several files from the part program directory will be output. Press **STOP** to cancel the transfer.
- | |
|---------|
| Read in |
|---------|

Use this softkey to load part programs via the RS232 interface.
- | |
|-----------|
| Error log |
|-----------|

Error log
All files transferred are listed with status information.
 - For files to be output:
 - the file name
 - an error acknowledgment
 - For files to be input:
 - the file name and the path specification
 - an error acknowledgment

Transfer messages:

| | |
|-----------------|---|
| OK | Transfer completed without errors |
| ERR EOF | End-of-text character has been received, but the archive file is incomplete |
| Time Out | The time monitoring reports an abortion of the transfer |
| User Abort | Transfer aborted by the Stop softkey |
| Error Com | Error at port COM 1 |
| NC / PLC Error | Error message from NC |
| Error Data | Data error 1. Files read in with/without leader or 2. Files in punched tape format sent without file name. |
| Error File Name | The file name does not comply with the name convention of the NC. |

System

Functionality

The "System" operating area provides all functions required for parameterizing and analyzing the NCK and the PLC.




Fig. 7-1 The System main screen

Depending on the functions selected, the horizontal and vertical softkey bars change. The menu tree shown below shows only the horizontal functions.

| | | | | |
|----------|--------------|------------------|--------------------|----------------|
| Start up | Machine data | Service display | PLC | Data I/O |
| NC | General MD | Service axes | Step 7 connect | Data selection |
| PLC | Axis MD | Service drives | PLC status | RS232 settings |
| | Chan-spec MD | Service profibus | Status list | |
| | Drive MD | | PLC lprogram * | |
| | | | Program list * | |
| | Display MD | | | |
| | Servo trace | Servo trace | | |
| | | Version | Edit PLC alarm txt | |

Fig. 7-2 The "System" menu tree (only horizontal level)

The softkeys marked with an "*" (asterisk) are not available with the 802D-bl.

Softkey

Start up

Start-up

NC

Use this softkey to select the power-up mode of the NC. Select the desired mode using the cursor.

- Normal power-up
System is restarted.
- Power-up with default data
Cold restart with default values (will restore the default state as on delivery)
- Power-up with saved data
Cold restart with the data saved last

PLC

The PLC can be started in the following modes:

- **Restart** Cold restart
- **Overall reset** Overall reset

Furthermore, it is possible to link the start with a **debugging mode** to follow.

OK

Use **OK** to RESET the control system and to carry out a restart in the mode selected. Press **RECALL** to return to the System main screen without any action.

Machine data

Machine data

The modification of machine data has a substantial influence on the machine. Wrong parameterization may destroy the machine.

The machine data are divided into groups.




Fig. 7-3 Structure of a machine data line

| | | |
|------------|----|-------------------|
| Activation | so | Immediately |
| | cf | With confirmation |
| | re | Reset |
| | po | Power on |



Caution

Faulty parameterization may result in destruction of the machine.

General MD

General machine data

Open the *General Machine Data* window. Use the PageUp/PageDown keys to leaf up and down.

| SYSTEM | | | | | | |
|-------------------------|------------------------------|----------|---|--|----|--------------|
| General NC machine data | | | | | | |
| 10000 | AXCONF_MACHAX_NAME_TAB(0) | | | | po | |
| 10000 | AXCONF_MACHAX_NAME_TAB(1) | | | | po | |
| 10000 | AXCONF_MACHAX_NAME_TAB(2) | | | | po | |
| 10000 | AXCONF_MACHAX_NAME_TAB(3) | | | | po | |
| 10010 | ASSIGN_CHAN_TO_MODE_GROUP(0) | 0 | | | po | |
| 10050 | SYSCLOCK_CYCLE_TIME | 0.000000 | s | | po | |
| 10060 | POSCTRL_SYSCLOCK_TIME_RATIO | 0 | | | po | |
| 10070 | IPO_SYSCLOCK_TIME_RATIO | 0 | | | po | |
| 10074 | PLC_IPO_TIME_RATIO | 0 | | | po | |
| 10080 | SYSCLOCK_SAMPL_TIME_RATIO | 0 | | | po | |
| 10082 | CTRLOUT_LEAD_TIME | 0.000000 | % | | po | |
| 10083 | CTRLOUT_LEAD_TIME_MAX | 0.000000 | % | | cf | Find |
| 10110 | PLC_CYCLE_TIME_AVERAGE | 0.000000 | s | | po | Continue |
| 10130 | TIME_LIMIT_NETTO_COM_TASK | 0.000000 | s | | po | Find |
| 10134 | MM_NUM_MMC_UNITS | 0 | | | po | Select group |
| 10140 | TIME_LIMIT_NETTO_DRIVE_TASK | 0.000000 | s | | po | |

Fig. 7-4 The "Machine Data" main screen

Axis
MD**Axis-specific machine data**

Open the *Axis-Specific Machine Data* window. The softkey bar will be added by the softkeys **Axis +** and **Axis -**.

| SYSTEM | | | | | | |
|----------------------------|-----------------------|----------|---------|----|----|--------------|
| Axis-specific machine data | | | | | | |
| 30100 | CTRLOUT_SEGMENT_NR(0) | 0 | | | po | Axis + |
| 30110 | CTRLOUT_MODULE_NR(0) | 0 | | | po | Axis - |
| 30120 | CTRLOUT_NR(0) | 0 | | | po | |
| 30130 | CTRLOUT_TYPE(0) | 0 | | | po | |
| 30132 | IS_VIRTUAL_AX(0) | 0 | | | cf | |
| 30200 | NUM_ENCS | 0 | | | po | |
| 30210 | ENC_SEGMENT_NR(0) | 0 | | | po | |
| 30220 | ENC_MODULE_NR(0) | 0 | | | po | |
| 30230 | ENC_INPUT_NR(0) | 0 | | | po | |
| 30240 | ENC_TYPE(0) | 0 | | | po | Refresh |
| 30242 | ENC_IS_INDEPENDENT(0) | 0 | | | cf | Find |
| 30250 | ACT_POS_ABS(0) | 0.000000 | | | po | Continue |
| 30300 | IS_ROT_AX | 0 | | | po | Find |
| 30310 | ROT_IS_MODULO | 0 | | | po | Select group |
| 30320 | DISPLAY_IS_MODULO | 0 | | | po | |
| 30330 | MODULO_RANGE | 0.000000 | Degrees | so | | |

Fig. 7-5

The data of the X axis are displayed.

Axis +

Use **Axis +** or **Axis -** to switch to the machine data area of the next or previous axis.

Axis -

Find

Search

Type the number or the name of the machine data you are looking for and press **OK**.

The cursor will jump to the data searched.

Continue
find

Use this softkey to continue searching for the next match.

Select group

This function provides various display filters for the active machine data group. Further softkeys are provided:

The **Expert** setting displays all machine data of the active group.

The **Filter active** softkey: Use this softkey to activate the data groups selected. After you have quitted the window, you will only see the selected data on the machine data display.

The **Select all** softkey: Pressing this softkey will display all data groups.

The **Deselect all** softkey: Pressing this softkey will deselect all data groups.




Fig. 7-6 Display filter

Channel MD

Other machine data

Open the *Channel-Specific Machine Data* window. Use the PageUp/PageDown keys to leaf up and down.

Drive MD

Drive machine data

Open the *Drive-Specific Machine Data* window. Use the PageUp/PageDown keys to leaf up and down.

Display MD

Display machine data

Open the *Display Machine Data* window. Use the PageUp/PageDown keys to leaf up and down.



Lesehinweis

For a description of the machine data, please refer to the manufacturer documentation:
 "SINUMERIK 802D, Start-Up"
 "SINUMERIK 802D Description of Functions".

Service display

The *Service Axes* window appears.

Service Axes

The window displays information on the axis drive.

The softkeys **Axis +** and **Axis -** are additionally displayed. You can use these softkeys to display the values for the next or previous axis.

Service drive

The window displays information on the digital drive.

Service Profibus

The window contains information regarding the PROFIBUS settings.

Servo trace

To optimize the axis, an oscillograph function is implemented, which provides graphical representation

- of the velocity set value
The velocity set value corresponds to the $\pm 10V$ interface.
- of the contour deviation
- of the following error
- of the actual position value
- of the set position value
- of exact-stop fine/coarse.

The start of recording can be linked with various criteria allowing the recording to be carried out synchronously to internal control states. This setting must be made using the function “**Select Signal**”.

To analyze the result, the following functions are provided:

- Changing of scaling of abscissa and ordinate;
- Measuring of a value using the horizontal or vertical marker;
- Measuring of abscissa and ordinate values as a difference between two marker positions;
- Storing of the result as a file in the part program directory. Then it is possible to read out the file using WINPCIN and to edit the graphics using MS Excel.




Fig. 7-7 The *Servo Trace* main screen

The title bar of the diagram contains the current scaling of the abscissa and the difference value of the marker.

The diagram shown above can be moved within the visible display area using the cursor keys.




Fig. 7-8 Meaning of the individual fields

Select
signal

This menu is intended to parameterize the measuring channel.



Fig. 7-9

- **Selecting the axis:** The selection of the axis is carried out in the toggle field "Axis".
- **Signal type:** Following error
 - Servo difference
 - Contour deviation
 - Actual position value
 - Velocity actual value
 - Velocity setpoint
 - Compensation value
 - Parameter record
 - Position setpoint at controller input
 - Velocity setpoint at controller input
 - Acceleration setpoint at controller input
 - Velocity feedforward control value
 - Exact stop fine signal
 - Exact stop coarse signal
- **Status:**
 - On The recording is carried out in this channel.
 - Off The channel is inactive.

In the lower half of the screen, the parameters 'measuring time' and 'trigger type' can be set for channel 1. The remaining channels will accept this setting.

- **Determining the measuring time:** The measuring time is entered in ms directly in the input box "Measuring time".

- **Selecting the trigger condition:** Position the cursor on the field "Trigger condition" and select the appropriate condition using the toggle key.
 - No trigger, i.e. the measurement starts immediately after pressing the Start softkey
 - Positive edge
 - Negative edge
 - Exact-stop fine reached
 - Exact-stop coarse reached

Marker
V-OFF

You can hide/unhide the auxiliary lines using the softkeys **Marker on / Marker off**.

Marker
T-OFF

FIX
V-Mark

The markers can be used to determine the difference in the horizontal and vertical direction. To do so, position the marker on the start point and press the softkey "**Fix H - Mark.**" or "**Fix T - Mark.**"

FIX
T-Mark

The difference between the start point and the current marker position is now displayed in the status bar. The softkey designation will change to "**Free H - Mark.**" or "**Free T - Mark.**"

Show
trace

Pressing this softkey will open another menu level providing softkeys to hide/unhide the diagrams. If a softkey has a black background, the diagrams will be displayed for the trace channel selected.

Time
scale +

Use this function to zoom in / zoom out the time basis.

Time
scale -

Vertical
scale +

Use this function to increase / reduce the resolution (amplitude).

vertical
scale -

Marker
steps

Use this function to define the step sizes of the markers.




Fig. 7-10

The markers are moved using the cursor keys at a step size of one increment. Larger step sizes can be set using the input boxes. The value specifies by how many grid units the marker must be moved using the **cursor**. If a marker reaches the margin of the diagram, the grid automatically appears in the horizontal or vertical direction.

File service

This function is used to save or load trace data.




Fig. 7-11

Enter the desired file name without extension in the File Name box.

The **Save** softkey is used to save the data with the specified name in the part program directory. The file can then be read out via the RS232 interface and the data can be edited using MS Excel.

The **Load** softkey loads the specified file and displays the data graphically.

Version

This window contains the version numbers and the date of creation of the individual CNC components.

HMI details

The **HMI details** menu area is intended for servicing; access is granted via the user password. All programs of the operator terminal are displayed with their version numbers in the form of a list. By reloading software components, the version numbers may be different.

| DLL Details | | | Registry Details |
|-------------|--------------------|--------------------|------------------|
| DLL-Name | DLL Version | Interface version | |
| accsrv.dll | V04.01.03 02/08/15 | V04.01.03 02/08/15 | |
| achssin.dll | V04.01.03 02/08/15 | | |
| ain.dll | V04.01.03 02/08/15 | V04.01.03 02/08/15 | |
| BMP_ARJ | | | |
| dcom.dll | V01.00.00 02/04/03 | V04.01.02 02/06/24 | Font Details |
| dg.dll | V04.01.03 02/08/15 | V04.01.03 02/08/15 | |
| dn.dll | V04.01.03 02/08/15 | V04.01.03 02/08/15 | |
| gl.dll | V04.01.03 02/08/15 | V04.01.03 02/08/15 | |
| HELP_ARJ | | | |
| hlp.dll | V04.01.03 02/08/15 | V04.01.03 02/08/15 | |
| hz.dll | V04.01.03 02/08/15 | V04.01.03 02/08/15 | |
| ld.dll | V04.01.03 02/08/15 | V04.01.03 02/08/15 | |
| na.dll | V04.01.03 02/08/15 | V04.01.03 02/08/15 | |
| nass.dll | V04.01.03 02/08/15 | V04.01.03 02/08/15 | |
| monitor.dll | | V04.01.03 02/08/15 | |
| pa.dll | V04.01.03 02/08/15 | V04.01.03 02/08/15 | |
| PAT.dll | V04.01.03 02/08/15 | V04.01.03 02/08/15 | |
| pe.dll | V04.01.03 02/08/15 | V04.01.03 02/08/15 | |
| ppi.dll | V04.01.03 02/08/15 | V04.01.03 02/08/15 | |
| pr.dll | V04.01.03 02/08/15 | V04.01.03 02/08/15 | |
| sin.dll | V04.01.03 02/08/15 | V04.01.03 02/08/15 | Zurück |

Fig. 7-12 The "HMI version" menu area

registry
details

This function displays the assignment of the hardkeys (function keys "Machine", "Offset", "Program", ...) for the programs to be started in the form of a list. For the meanings of the individual columns, please refer to the table below.




Fig. 7-13

Table 7-1 Meanings of the entries under [DLL arrangement]

| Designation | Meaning |
|-------------------------------------|--|
| Softkey | SK1 to SK7 Hardkey assignment 1 to 7 |
| DLL name | Name of the program to be executed |
| Class name | This column defines the identifier for receiving messages. |
| Start method | Number of the function executed after starting the program |
| Execute flag (kind of execution) | 0 - The program is managed via the basic system. 1 - The basic system starts the program and transfers the control to the loaded program. |
| Text file name | Name of the text file (without extension) |
| Softkey text ID (SK ID) | reserved |
| Password level | The execution of the program depends on the password level. |
| Class SK | reserved |
| SK file | reserved |

Font
details

This function displays the data of the loaded character sets in the form of a list.




Fig. 7-14

Change Start DLL

Defining the start program

After the system has booted, the control system automatically starts the "Machine" operating area (SK 1). If a different starting behavior is desired, you can use this function to define a different starting behavior.

Type the number of the program you wish to be started after the system has booted.




Fig. 7-15 Modifying the start-up DLL

PLC

This softkey provides further functions for diagnosis and start-up of the PLC.

STEP 7
connect

This softkey can be used to link the PLC with the external PLC 802 Programming Tool. If the link is active, an appropriate symbol appears in the status bar (cf. Table 1-2).

If the RS232 interface is already occupied by the data transfer, you can couple the control system with the programming unit only if the transfer is completed.

The RS 232 interface is activated with activating the link.




Fig. 7-16 Enabling/disabling RS232 for the Programming Tool

The baud rate is set using the toggle field. The following values are possible: 9600 / 19200 / 38400 / 57600 / 115200.




Fig. 7-17 Settings with the modem active

With the modem active ("ON"), you can additionally choose between the data formats 10 or 11 bits.

- Parity: "None" with 10-bit format
"Even" with 11-bit format
- Stop bits: 1 (set by default; active with initialization of the control system)
- Data bits: 8 (set by default; active with initialization of the control system)

Connect on Use this softkey to activate the link between the PC and the control system. The softkey designation changes to **Connect off**.

Connect off The Enabled or Disabled status remains stored also after Power On (except booting with default data).

Use **RECALL** to quit the menu.

Modem settings In this area, the modem settings are made.

Possible modem types are: Analog Modem
ISDN Box
Mobile Phone.

The types of both communication partners must match with each other.




Fig. 7-18 Settings for an analog modem

When specifying several AT strings, AT must merely be written once; the remaining commands can simply be attached, e.g. AT&FS0=1E1X0&W. How the individual commands and their parameters must look exactly is to be seen in the manufacturer manuals, since these are partially very different between the devices of one and the same manufacturer. The default values of the control system are therefore only a real minimum and should be verified very exactly in any case before they are used for the first time. To be on the safe side, you can also first connect the devices to a PC and try and optimize the connection establishment via a terminal program.




Fig. 7-19 Settings for an ISDN box

PLC status

Use this softkey to display the current states of the PLC memory cells listed below; as necessary, you can also modify them.

It is possible to display 16 operands at a time.

| | | |
|----------|-------------|---|
| Inputs | I | Input byte (IBx), input word (Iwx), input double word (IDx) |
| Outputs | Q | Output byte (Qbx), output word (Qwx), output double word (QDx) |
| Flags | M | Flag byte (Mx), flag word (Mw), flag double word (MDx) |
| Timers | T | Timer (Tx) |
| Counters | C | Counter (Zx) |
| Data | V | Data byte (Vbx), data word (Vwx), data double word (VDx) |
| Format | B H D | binary hexadecimal decimal The binary representation is not possible with double words. Counters and timers are represented decimally. |




Fig. 7-20 PLC status display

Operand
+

The operand address displays the value incremented by 1.

Operand
-

The operand address displays the value decremented by 1.

Delete

Use this softkey to delete all operands.

Change

This softkey will cancel the cyclic update of the values. Then you can modify the values of the operands.

Status
list

Use the function **PLC Status lists** to locate PLC signals quickly, as well as to watch and modify them.

The following areas are offered to choose from:

- Inputs (default setting) left list
- Outputs (default setting) central list
- Flags (default setting) right list
- Variable




Fig. 7-21 The *PLC Status List* main screen

Change

Use this softkey to modify the variable value.

Edit
pad

Use this softkey to assign the active pad a new area. The dialog screen form offers four areas to choose from. For each area, a start address can be assigned, which must be entered in the corresponding input box. If you quit the input screen form, the settings will be saved.




Fig. 7-22 The Data Type screen form

Use the cursor keys and the Page up / Page Down keys to navigate in and between the pads.

PLC
program

PLC diagnosis using the Ladder Diagram representation (see Section 7.1)
This function is not available with the 802D-bl.

Program
list

Using the PLC, you may select part programs and run them via the PLC. To this end, the PLC user program writes a program number to the PLC interface, which is then converted to a program name using a reference list. It is possible to manage max. 255 programs.




Fig. 7-23

This dialog displays all files of the CUS directory and their assignment in the reference list (PLCPROG.LST) in the form of a list. You can use the TAB key to switch between the two columns. The softkey functions **Copy**, **Insert** and **Delete** are displayed with reference to a specific context. If the cursor is positioned on the left-hand side, only the **Copy** function is available. On the right-hand side, the functions **Insert** and **Delete** are offered to modify the reference list.

This function is not available with the 802D-bl.

Copy

... writes the selected file name to the clipboard

Insert

... pastes the file name at the current cursor position

Delete

... deletes the selected file name from the assignment list

Structure of the reference list (file PLCPROG.LST)

It is divided into 3 areas:

| Number | Area | Degree of protection |
|-------------|----------------------|----------------------|
| 1 ... 100 | User area | User |
| 101 ... 200 | Machine manufacturer | Machine manufacturer |
| 201 ... 255 | Siemens | Siemens |

The notation is carried out for each program by lines. Two columns are intended per line, which must be separated from each other by TAB, space or the "I" character. In the first column, the PLC reference number must be specified, and in the second column, the file name.

Example: 1 | Welle.mpf
 2 | Kegel.mpf

Edit PLC alarm txt

This function can be used to insert or modify PLC user alarm texts. Select the desired alarm number using the cursor. At the same time, the text currently valid is displayed in the input line.




Fig. 7-24 Editing the PLC alarm text

Enter the new text in the input line. Press the **Input** key to complete your input and select **Save** to save it.

For the notation of the texts, please refer to the Start-Up Guide.

Data I/O

The window is divided into two columns. The left column is used to select the data group, and the right-hand column is used to select individual data for transfer. If the cursor is positioned in the left-hand column, the whole data group is output when **Read out** is selected. If it is positioned in the right-hand column, only the selected file is transferred. You can use the TAB key to switch between the two columns.




Fig. 7-25

In the **NC Card** selection area, the set interface parameters are ineffective. When reading in data from **NC Card**, first the desired area must be selected.

If

- **PLC Sel.** or
- **Alarm texts PC** is selected when reading in
- **Start-up data PC, PLC-Application PC or Display machine data PC**
- ,

the settings of the column **special functions** are internally switched to **Binary format**.

Note

If you select the menu option "Part programs to the NC card" or "Part programs from the NC card to the NC", existing files are overwritten without any confirmation warning.

Note

These functionalities are not implemented in the 802D-bl_

- Part programs NC -> NC_CARD
- Part programs NC_CARD -> NC.

Data selection

Select the data to be transferred. To start the transfer of the data to an external device, use the "Read out" softkey function.

To read in data from an external device, use the "Read in" function. For reading in, it is not necessary to select the data group, since the target is determined by the data flow.

RS232 setting

Use this function to display the interface parameters currently selected. Appropriate softkey functions are provided to switch between binary transmission and the transmission of text files.

Additionally, it is possible to set the parameters directly in the window.




Fig. 7-26

Any changes in the settings come into effect immediately.

Pressing the **Save** softkey will save the selected settings even beyond switching off.

The **Default Data** softkey will reset all settings to their default settings.

Set
password

Setting the password

Four password levels are distinguished in the control system, which provide different access rights:

- System password
- Manufacturer password
- User password

Depending on the access levels (see also "Technical Manual"), the data can be changed.

Enter the password. If you do not know the password, access will be denied.




Fig. 7-27 Entering the password

After you have selected the **OK** softkey, the password is set.

Use **ABORT** to return without any action to the *System* main screen.


Change
password**Changing the password**

Fig. 7-28 Changing the password

Depending on the access right, various possibilities are offered in the softkey bar to change the password.

Select the password level using the appropriate softkeys. Enter the new password and press **OK** to complete your input. You will be prompted to enter the new password once more for confirmation.

Press **OK** to complete the password change.

Use **ABORT** to return without any action to the main screen.

Delete
password

Resetting the access right

Change
language**Switching the language**

Use this softkey to switch between foreground and background language.

Save
data**Save data**

This function will save the contents of the volatile memory into a nonvolatile memory area.

Prerequisite: There is no program currently executed.

Do not carry out any operator actions while the data backup is running!

Interface parameters

Table 7-2 Interface parameters

| Parameter | Description |
|---------------------|---|
| Protocol | <ul style="list-style-type: none"> • XON/XOFF A possibility of controlling the transmission is the use of XON (DC1, DEVICE CONTROL 1) and XOFF (DEVICE CONTROL 2) control characters. If the buffer of the peripheral device is full, the device will send XOFF, and once it is ready to receive data, it will send XON. • RTS/CTS The signal RTS (Request to Send) controls the Send mode of the data transfer device. Active: Data are to be sent. Passive: The Send mode is only quitted after all data have been transmitted. The CTS signal indicates the readiness to transmit data as the acknowledgment signal for RTS. |
| XON | This is the character required to start a transmission. It is only effective for the device type XON/XOFF. |
| XOFF | This is the character required to stop a transmission. |
| End of transmission | This is the character signaling the end of transmission of a text file. For transmitting binary data, the special function "Stop with end-of-transmission character" may not be active. |
| Baud rate | ... used to set the interface transmission rate. 300 Baud 600 Baud 1200 Baud 2400 Baud 4800 Baud 9600 Baud 19200 Baud 38400 Baud 57600 Baud 115200 Baud |
| Data bits | Number of data bits with asynchronous transmission Input: 7 data bits 8 data bits (default setting) |
| Stop bits | Number of stop bits with asynchronous transmission Input: 1 stop bit (default setting) 2 stop bits |
| Parity | Parity bits are used for error detection. These are added to the coded character to convert the number of digits set to "1" into an odd or even number. Input: No parity (default setting) Parity even Parity odd |

Special functions

Table 7-3 Special functions

| Function | active | inactive |
|---------------------------------|--|--|
| Start with XON | The transmission is started if an XON character has been received in the data stream issued by the sender. | The transmission is started independently of whether or not an XON character was issued. |
| Overwriting with confirmation | When reading in, it is checked whether the file already exists in the NC. | The files are overwritten without confirmation warning. |
| End of block with CR LF | With output in the punched-tape format, CR characters (hexadecimal 0D) are inserted. | No additional characters are inserted. |
| Stop at the end of transmission | The end-of-transmission character is active. | The character is not evaluated. |
| Evaluating the DSR signal | If the DSR signal is missing, the transmission is interrupted. | DSR signal without effect |
| Leader and trailer | The leader is skipped when data are received With the data output, a leader 120 * 0 h is created. | Leader and trailer are also read in. With the data output, no leader is output. |
| Punched-tape format | Reading in of part programs | Reading in of archives in the SINUMERIK archive format |
| Time monitoring | If any transmission problems occur, the transmission is aborted after 5 seconds. | No abortion of the transmission |

7.1 PLC diagnosis using the ladder diagram representation

Note

This function is not available with the 802D-bl.

Functionality


A PLC user program consists to a large degree of logical operations to realize safety functions and to support process sequences. These logical operations include the linking of various contacts and relays. As a rule, the failure of a single contact or relay results in a failure of the whole system/installation.

To locate causes of faults/failures or of a program error, various diagnostic functions are offered in the "System" operating area.

Note

It is not possible here to edit the program.

Operating sequence



Select the **PLC** softkey which is to be found in the "System" operating area. The PLC main screen will appear.



The project stored in the permanent memory is opened.

7.1.1 Screen layout

The division of the screen into the individual main areas is to a large degree as described in Section 1.1 of the User's Guide. Any deviations and amendments pertaining to the PLC diagnosis are shown below.






Fig. 7-29 Screen layout

| Control | Display | Meaning |
|---------|---|-----------------------------------|
| ① | Range of application | |
| ② | Supported PLC program language | |
| ③ | Name of the active program block Representation: Symbolic name (absolute name) | |
| ④ | Program status | |
| | RUN | Program running |
| | STOP | Program stopped |
| | Status of the range of application | |
| | Sym | Symbolic representation |
| ⑤ | abs | Absolute representation |
| |   | Display of the active keys |
| ⑥ | Focus performs the tasks of the cursor | |
| ⑦ | Notes line contains notes for searching | |

7.1.2 Operating options



























In addition to the softkeys and the navigation keys, this area provides still further key combinations.

Key combinations

The cursor keys move the focus over the PLC user program. When reaching the window borders, it is scrolled automatically.

7.1 PLC diagnosis using the ladder diagram representation

Table 7-4 Key combinations

| Key combination | Action |
|--|--|
|  or   | to the first line of the row |
|  or   | to the last line of the row |
|  | up a screen |
|  | down a screen |
|  | one field to the left |
|  | one field to the right |
|  | up a field |
|  | down a field |
|   or   | to the first field of the first network |
|   or   | to the last field of the first network |
|   | opens the next program block in the same window |
|   | opens the previous program block in the same window |
|  | <ul style="list-style-type: none"> • displays the complete text line in a table • displays the network comment when using network titles • displays the complete operands when using commands |
|  | displays all information of the operand including comment when using commands |

7.1 PLC diagnosis using the ladder diagram representation




Fig. 7-32 Status list

Window 1
xxxx

Window 2
xxxx

This window displays all logical and graphical information of the PLC program running in the appropriate program block. The logic in the LAD (ladder diagram) is divided into clearly structured program parts and current paths, called networks. Generally, programs written in LADs represent the electrical current flow using various logical operations.




Fig. 7-33 Window 1

In this menu, you can switch between symbolic and absolute representation of the operand. Furthermore, it is possible here to view a desired program section in different resolutions and to search for a certain operand.

Program block

This softkey can be used to display the list of the PLC program blocks. Use the **Cursor Up/Cursor Down** or **Page Up/Page Down** keys to select the PLC program block you want to open. The current program block is displayed in the Info line of the list box.




Fig. 7-34 PLC block selection

Properties

Pressing this softkey displays the description of the selected program block, which was stored when the PLC project was created.




Fig. 7-35 Properties of the selected PLC program block

Local variables

Pressing this softkey displays the table of local variables of the selected program block.

There are two types of program blocks.

- OB1 only temporary local variable
- SBRxx in, in-out, out and temporary local variable

A table of variables exists for each program block.

7.1 PLC diagnosis using the ladder diagram representation

| SYSTEM | | | | |
|----------------------------------|-----------|-----------------|------------------------------|-----|
| SIMATIC LAD | | MCP_SIMU(SBR37) | Run | abs |
| Local variables | | | | |
| buffered handwheel 1 information | | | | |
| Name | Var. type | Data type | Comment | |
| EN | IN | BOOL | | |
| LB0 HW1 | TEMP | BYTE | buffered handwheel 1 inform~ | |
| LB1 HW2 | TEMP | BYTE | buffered handwheel 2 inform~ | |
| LB2 HW3 | TEMP | BYTE | buffered handwheel 3 inform~ | |
| L3.0 HW1ucsX | TEMP | BOOL | Handwheel 1 at work piece c~ | |
| L3.1 HW1ucsY | TEMP | BOOL | Handwheel 1 at work piece c~ | |
| L3.2 HW1ucsZ | TEMP | BOOL | Handwheel 1 at work piece c~ | |
| L3.3 HW2ucsX | TEMP | BOOL | Handwheel 2 at work piece c~ | |
| L3.4 HW2ucsY | TEMP | BOOL | Handwheel 2 at work piece c~ | |
| L3.5 HW2ucsZ | TEMP | BOOL | Handwheel 2 at work piece c~ | |
| L3.6 HW3ucsX | TEMP | BOOL | Handwheel 3 at work piece c~ | |
| L3.7 HW3ucsY | TEMP | BOOL | Handwheel 3 at work piece c~ | |
| L4.0 HW3ucsZ | TEMP | BOOL | Handwheel 3 at work piece c~ | |

Fig. 7-36 Table of local variables for the selected program block

Texts which are longer than the column width are cut in all tables and the "~" character is attached. For such a case, a higher-level text field exists in such tables in which the text of the current cursor position is displayed. If the text is cut with a "~", it is displayed in the same color as that of the cursor in the higher-level text field. With longer texts, it is possible to display the whole text by pressing the SELECT key.



Pressing this key opens the selected program block; its name (absolute) is displayed on the "Window 1/2" softkey.



Use this softkey to activate/deactivate the display of the program status. It is possible here to observe the current network states beginning from the end of the PLC cycle. The states of all operands are displayed in the "Program status" ladder diagram. This LAD acquires the values for the status display in several PLC cycles and then refreshes the status display.




Fig. 7-37 "Program status" ON – symbolic representation





Fig. 7-38 "Program status" ON – absolute representation



Use this softkey to switch between the absolute and symbolic representation of the operands. Depending on the selected type of representation, the operands are displayed either with absolute or symbolic identifiers.



If no symbol exists for a variable, this is automatically displayed absolutely.



The representation in the application area can be zoomed in or zoomed out step by step. The following zoom stages are provided:



20% (default), 60%, 100% and 300%



can be used to search for operands in the symbolic or absolute representation

A dialog box is displayed from which various search criteria can be selected. Using the **Absolute/symbolic address** softkey, you may search for a certain operand matching this criterion in both PLC windows. When searching, uppercase and lowercase letters are ignored.

Selection in the upper toggle field:

- Searching for constants (only absolute)
- Search for absolute and symbolic operands
- Go to network number
- Find SBR command

Further search criteria:

- Search direction down (from the current cursor position)
- Whole program block (from the beginning)
- In one program block
- Over all program blocks

You can search for the operands and constants as whole words (identifiers).

Depending on how the operand display is set, an alternative search is possible either for symbolic or absolute representation.

Press the **ok** softkey to start the search. The found search element is highlighted by the focus. If nothing is found, an appropriate error message will appear.

Use the **Abort** softkey to quit the dialog box; no search is carried out.

7.1 PLC diagnosis using the ladder diagram representation





Fig. 7-39 Searching for symbolic operands



Searching for absolute operands

If the search object is found, use the **Continue search** softkey to continue the search.

Symbol info

Pressing this softkey displays all symbolic identifiers used in the highlighted network.




Fig. 7-40 Network symbolic

Cross refs.

Use this softkey to display the list of cross references. All operands used in the PLC project are displayed.

This list indicates in which networks an input, output, flag etc. is used.





Fig. 7-41 The "Cross references" main menu (absolute) (symbolic)

Furthermore, it is possible to jump quickly to a desired position in the program in the windows 1/2 with reference to the selected operand(s) or symbol using the *Open in* function.

Symbolic address

Depending on the active type of representation, the elements are displayed either with absolute or symbolic identifiers.

Absolute address

If no symbol exists for an identifier, the description is automatically absolute.

The type of representation of identifiers is displayed in the status bar. The absolute representation of identifiers is set by default.

Open in window 1

The operand selected from the list of cross references is opened in the appropriate window.

Open in window 2

Example:

You want to view the logic interrelation of the absolute operand M251.0 in network 1 in program block OB1.


Select the relevant operand from the list of cross references and press the "Open in window 1" soft-key; the display will appear in window 1.

| Element | Block | Address | Context |
|---------|--------|----------------------------|----------|
| 1111 | M251.3 | MCP_S1MU (SBR33) Network 7 | =I 1- |
| 1112 | M251.3 | MCP_S1MU (SBR33) Network 7 | =(R) |
| 1113 | M251.4 | MCP_S1MU (SBR33) Network 3 | =I 1- |
| 1114 | M251.4 | MCP_S1MU (SBR33) Network 7 | =I 1- |
| 1115 | M251.4 | MCP_S1MU (SBR33) Network 7 | =(R) |
| 1116 | M251.5 | MCP_S1MU (SBR33) Network 5 | =I 1- |
| 1117 | M251.5 | MCP_S1MU (SBR33) Network 7 | =I 1- |
| 1118 | M251.5 | MCP_S1MU (SBR33) Network 7 | =(R) |
| 1119 | M251.0 | MAIN (OB1) Network 2 | EMG_STP |
| 1120 | M251.0 | MAIN (OB1) Network 2 | EMG_STP |
| 1121 | M251.0 | MAIN (OB1) Network 6 | AXIS_CTL |
| 1122 | M251.0 | MAIN (OB1) Network 6 | AXIS_CTL |
| 1123 | M251.0 | MAIN (OB1) Network 6 | AXIS_CTL |
| 1124 | M251.0 | EMG_STP (SBR33) Network 7 | =(R) |
| 1125 | M251.7 | EMG_STP (SBR33) Network 2 | =I 1- |

Cross refs. [Line 1120, Column 2]

| | | | | | |
|----------|------------|-------------|----------|----------|-------------|
| PLC Info | PLC status | Status list | Window 1 | Window 2 | Cross refs. |
| | | | OB1 | SBR33 | |

Fig. 7-42 Cursor "M251.0 in OB1 network 2)



M251.0 in OB1 network 2 in window 1

Find

... is used to search for operands in the list of cross references

You can search for the operands as whole words (identifiers). When searching, uppercase and lowercase letters are ignored.

Search options:

- Search for absolute and symbolic operands
- Go to line

Search criteria:

- Down (from the current cursor position)
- Whole program block (from the beginning)

7.1 PLC diagnosis using the ladder diagram representation




Fig. 7-43 Searching for an operand in cross references

The text you are looking for is to be found in the notes line. If the text is not found, an appropriate error message is displayed which must be confirmed with OK.

If the search object is found, use the "Continue search" softkey to continue the search.

Programming

8.1 Fundamentals of NC Programming

8.1.1 Program Names

When creating a program, the program name can be freely selected if the following conventions are observed:

- The first two characters must be letters.
- The remaining characters may be letters, digits or underscore.
- Do not use any separators (see Section "Character Set")
- A maximum of 16 characters is permitted.

Example: **WELLE527**

8.1.2 Program Structure

Structure and contents

The NC program consists of a sequence of **blocks** (see Table 8-1).

Each block constitutes a machining step.

Statements in a block are written in the form of **words**.

The last block in the order of execution of blocks contains a special word for the **program end: M2**.

Table 8-1 NC program structure

| Block | Word | Word | Word | ... | ; Comment |
|-------|------|------|------|-----|------------------|
| Block | N10 | G0 | X20 | ... | ; 1st block |
| Block | N20 | G2 | Z37 | ... | ; 2nd block |
| Block | N30 | G91 | ... | ... | ; ... |
| Block | N40 | ... | ... | ... | |
| Block | N50 | M2 | | | ; end of program |

8.1.3 Word Structure and Address

Functionality/structure

A word is a block element and mainly constitutes a control command. A word consists of

- **address character** (generally, a letter)
- and a **numerical value**. The numerical value consists of a sequence of digits, which with certain addresses can be added by a sign in front of the value and a decimal point.

A positive sign (+) may be omitted.




Fig. 8-1 Example of a word structure

Several address characters

A word may also contain several address letters. In this case, however, the numerical value must be assigned using the intermediate character “=”.

Example: CR=5.23

In addition, G functions can also be called using a symbolic name (see also Section “List of Statements”).

Example: **SCALE** ; scaling factor ON

Extended address

With the addresses

R arithmetic parameter

H H function

I, J, K interpolation parameters/intermediate point,

the address is extended by 1 to 4 digits in order to achieve a larger number of addresses. In this case, the value must be assigned using an equality sign “=” (see also Section “List of Statements”).

Example: **R10=6.234 H5=12.1 I1=32.67**

8.1.4 Block Structure

Functionality

A block should contain all data required to execute a step of machining.

Blocks generally consist of several **words** and are always completed with the **end-of-block character** "LF" (new line). This character is automatically generated when pressing the line space key or the **Input key** on writing.




Fig. 8-2 Block structure diagram

Word order

If a block contains several statements, the following order is recommended:

N... G... X... Z... F... S... T... D... M... H...

Note on block numbers

First select the block numbers in steps of 5 or 10. You can thus later insert blocks and nevertheless observe the ascending order of block numbers.

Block skip

Blocks of a program, which are to be executed not with each program run, can be **marked** by a slash "/" in front of the block number.

The block skip **operation** itself is activated either via **operation** (program control: "SKP") or from the PLC (signal). It is also possible to skip a whole program section by skipping several blocks using the "/" character.

If block skip is active during program execution, all blocks marked with "/" are skipped. All statements contained in the blocks concerned will not be considered. The program is continued with the next block without marking.

Comment, note

The statements contained in the blocks of a program can be explained by comments (notes). A comment starts with the “;” character and ends with block end. Comments are displayed in the current block display, together with the remaining contents of the block.

Messages

Messages are programmed in a separate block. A message is displayed in a special field and remains active until a block with a new message is executed or until the end of the program is reached. Max. 65 Zeichen characters of a message text can be displayed. A message without message text will delete a previous message.
MSG(“THIS IS THE MESSAGE TEXT“)

Programming example

```
N10 ; Company G&S Order No. 12A71
N20 ; Pump part 17, Dwg. No.: 123 677
N30 ; Program created by H. Adam, Dept. TV 4
N40 MSG(“BLANK, ROUGHING“)
:50 G54 F4.7 S220 D2 M3 ; Main block
N60 G0 G90 X100 Z200
N70 G1 Z185.6
N80 X112
/N90 X118 Z180 ; Block can be skipped
N100 X118 Z120
N110 G0 G90 X200
N120 M2 ; End of program
```

8.1.5 Character Set

The following characters are used for programming; they are interpreted in accordance with the relevant definitions.

Letters, digits

A, B, C, D, E, F, G, H, I, J, K, L, M, N, O, P, Q, R, S, T, U, V, W, X, Y, Z
0, 1, 2, 3, 4, 5, 6, 7, 8, 9
No distinction is made between lowercase and uppercase letters.

Printable special characters

| | | | |
|---|---------------------------------|---|------------------------------------|
| (| left round bracket | “ | inverted commas |
|) | right round bracket | _ | underscore (belonging to a letter) |
| [| left bracket | . | decimal point |
|] | right bracket | , | comma, separator |
| < | less than | ; | begin of a comment |
| > | greater than | % | reserved; do not use |
| : | main block, completion of label | & | reserved; do not use |

| | | | |
|---|------------------------------|----|-------------------------------------|
| = | assignment, part of equality | ' | reserved; do not use |
| / | division, block skip | \$ | system-specific variable identifier |
| * | multiplication | ? | reserved; do not use |
| + | addition, positive character | ! | reserved; do not use |
| - | subtraction, negative sign | | |

Non-printable special characters

| | |
|----------------|--------------------------------|
| L _F | end-of-block character |
| Blank | separator between words; blank |
| Tabulator | reserved; do not use |

8.1.6 List of Statements

| Address | Meaning | Value Assignment | Explanation | Programming |
|---------|--|--------------------------------|--|---|
| D | Tool offset number | 0 ... 9, only integer, no sign | contains compensation data for a particular tool T... ; D0-> offset value= 0, max. 9 D numbers per tool | D... |
| F | Feed | 0.001 ... 99 999.999 | traversing rate of tool/workpiece; unit in mm/min or mm/rev. depending on G94 or G95 | F... |
| F | Dwell time in a block containing G4 | 0.001 ... 99 999.999 | dwell time in seconds | G4 F... ;separate block |
| F | Thread lead change (block containing G34, G35) | 0.001 ... 99 999.999 | in mm/rev ² | see with G34, G35 |
| G | G function (preparatory function) | only integer, given values | The G functions are divided into G groups. Only one G group of a group may be programmed in a block. A G function can be either modal (until it is canceled by another function of the same group) or only effective for the block in which it is programmed (non-modal) | G... or symbolic name, e.g.: CIP |
| | | | G group: | |
| G0 | Linear interpolation at rapid traverse | | 1: Motion commands | G0 X... Z... |
| G1 * | Linear interpolation at feedrate | | (interpolation type) | G1 X...Z... F... |
| G2 | Circular interpolation in CW direction | | | G2 X... Z... I... K... F...;center and end points G2 X... Z... CR=... F... ;radius and end point G2 AR=... I... K... F... ;aperture angle and center point G2 AR=... X... Z... F... ;aperture angle and end point |
| G3 | Circular interpolation in CCW direction | | | G3 ;otherwise, as with G2 |
| CIP | Circular interpolation via intermediate point | | | CIP X...Z... I1=...K1=... F... ;I1, K1 is intermediate point |
| CT | Circular interpolation, tangential transition | | | N10 ... N20 CT Z... X... F... ;circle, tangential transition to previous path piece N10 |
| G33 | Thread cutting with constant lead | | modal | G33 Z... K... SF=... ;cylindrical thread G33 X... I... SF=... ;transversal thread G33 Z... X... K... SF=... ;taper thread, in Z axis travel greater than in X axis G33 Z... X... I... SF=... ;taper angle, in X axis travel greater than in Z axis |

| | | | |
|--------|--------------------------------------|---|--|
| G34 | Thread cutting, increasing lead | | G33 Z... K... SF=... ; cylinder thread, constant lead G34 Z... K... F17.123 ; increasing lead with ; 17.123 mm/rev. ² |
| G35 | Thread cutting, decreasing lead | | G33 Z... K... SF=... ; cylinder thread G35 Z... K... F7.321 ; decreasing lead with ; 7.321 mm/rev. ² |
| G331 | Thread interpolation | | N10 SPOS=... ;Spindle in position control N20 G331 Z... K... S... ;Tapping without compensating chuck, e.g. along Z axis ;RH or LH thread is defined by the sign of the lead (e.g. K+): + : as with M3 - : as with M4 |
| G332 | Thread interpolation - retraction | | G332 Z... K... ;Tapping without compensating chuck, e.g. along Z axis, Retraction movement ; sign of lead as with G331 |
| G4 | Dwell time | 2: Special movements, dwell time non-modal | G4 F... ;separate block, F: time in seconds or G4 S.... ;separate block, S: in spindle revolutions |
| G74 | Reference-point approach | | G74 X...Z... ;separate block (machine axis identifier) |
| G75 | Fixed-point approach | | G75 X... Z... ;separate block (machine axis identifier!) |
| TRANS | Programmable offset | 3: Write memory non-modal | TRANS X... Z... ;separate block |
| SCALE | Programmable scaling factor | | SCALE X... Z... ; scaling factor in the direction of the specified axis; separate block |
| ROT | programmable rotation | | ROT RPL=... ;rotation in the current plane G17 ... G19, separate block |
| MIRROR | programmable mirroring | | MIRROR X0 ; coordinate axis whose direction is changed; separate block |
| ATRANS | Additive programmable offset | | ATRANS X... Z... ;separate block |
| ASCALE | Additive programmable scaling factor | | ASCALE X... Z... ; scaling factor in the direction of the specified axis; separate block |

| | | | |
|---------|---|--|---|
| AROT | additive programmable rotation | | AROT RPL=... ; add. rotation in the current plane G17 ... G19, separate block |
| AMIRROR | additive programmable mirroring | | AMIRROR X0 ; coordinate axis whose direction is changed; separate block |
| G25 | Lower spindle speed limiting or lower work area limiting | | G25 S... ;separate block G25 X... Z... ;separate block |
| G26 | Upper spindle speed limiting or upper work area limiting | | G26 S... ;separate block G26 X... Z... ;separate block |
| G17 | X/Y plane (when center-drilling, TRANSMIT milling required) | 6: Plane selection | |
| G18 * | Z/X plane | | |
| G19 | Y/Z plane (required for TRACYL milling) | | |
| G40 * | Tool radius compensation OFF | 7: Tool radius compensation modal | |
| G41 | Tool radius compensation left of the contour | | |
| G42 | Tool radius compensation right of the contour | | |
| G500 * | Settable zero offset OFF | 8: Settable zero offset modal | |
| G54 | 1st settable zero offset | | |
| G55 | 2nd settable zero offset | | |
| G56 | 3rd settable zero offset | | |
| G57 | 4th settable zero offset | | |
| G58 | 5th settable zero offset | | |
| G59 | 6th settable zero offset | | |
| G53 | Non-modal suppression of settable zero offset | 9: Non-modal suppression of settable zero offset | |
| G153 | Non-modal suppression of settable zero offset including basic frame | | |
| G60 * | Exact stop | 10: Approach behavior modal | |
| G64 | Continuous-path control mode | | |

| | | | |
|-----------|---|--|--|
| G9 | Non-modal exact stop | 11: Non-modal exact stop non-modal | |
| G601 * | Exact-stop window fine at G60, G9 | 12: Exact-stop window modal | |
| G602 | Exact-stop window rough at G60, G9 | | |
| G70 | Inch dimension data input | 13: Inch/metric dimension data input modal | |
| G71 * | Metric dimension data input | | |
| G700 | Inch dimension data input, also for feed F | | |
| G710 | Metric dimension data input, also for feed F | | |
| G90 * | Absolute dimension data input | 14: Absolute/incremental data input modal | |
| G91 | Incremental dimension data input | | |
| G94 | Feed F in mm/min | 15: Feed/spindle modal | G96 S... LIMS=... F... |
| G95 * | Feed F in mm/spindle rev's | | |
| G96 | Constant cutting speed ON (F in mm/rev., S in m/min) | | |
| G97 | Constant cutting speed on turning OFF | | |
| G450 * | Transition circle | 18: Corner behavior at tool radius compensation modal | |
| G451 | Intersection point | | |
| BRISK * | Abrupt path acceleration | 21: Acceleration profile modal | |
| SOFT | Jerk-limited path acceleration | | |
| FFWOF * | Feedforward control OFF | 24: Feedforward control modal | |
| FFWON | Feedforward control ON | | |
| WALIMON * | Work area limiting ON | 28: Work area limiting modal | ; applies to all axes activated by setting data; values set using G25, G26 |
| WALIMOF | Work area limiting OFF | | |
| DIAMOF | Radius input | 29: Dimension input radius / diameter modal | |
| DIAMON * | Diameter input | | |

| | | | |
|--|----------------------------------|--|--|
| G290 * | SIEMENS mode | 47: External NC languages modal | |
| G291 | External mode (not with 802D-bl) | 47: External NC languages modally effective | |
| The functions marked with an asterisk (*) act on program start (with factory setting and unless not otherwise programmed) and the machine manufacturer has not changed the default technology setting "Turning". | | | |

| Address | Meaning | Value Assignment | Explanation | Programming |
|--------------------------|--|---|---|---------------------------------------|
| H H0= to H9999= | H function | ± 0.0000001 ... 9999 9999 (8 decimal places) or with exponent specification: ± (10 ⁻³⁰⁰ ... 10 ⁺³⁰⁰) | Value transfer to PLC, Definition of meaning by machine manufacturer | H0=... H9999=... e.g.: H7=23.456 |
| I | Interpolation parameter | ±0.001 ... 99 999.999 Thread: 0.001 ... 2000.000 | relates to X axis, meaning dependent on G2, G3 -> circle center point or G33, G331, G332 -> thread lead | see G2, G3 and G33 |
| K | Interpolation parameter | ±0.001 ... 99 999.999 Thread: 0.001 ... 2000.000 | relates to Z axis; otherwise as with I | see G2, G3 and G33 |
| I1= | Intermediate point for cir- cular interpolation | ±0.001 ... 99 999.999 | relates to X axis; specification for circular interpolation with CIP | see CIP |
| K1= | Intermediate point for cir- cular interpolation | ±0.001 ... 99 999.999 | relates to Z axis; specification for circular interpolation with CIP | see CIP |
| L | Subroutine, name and call | 7 decimal places, only integer, no sign | Instead of a random name, it is also possible to select L1 ...L9999999; the subroutine will thus also be called in a separate block. Note: L0001 is not equal to L1 The name "LL6" is reserved for the tool change sub- routine. | L.... ;separate block |
| M | Miscellaneous function | 0 ... 99 only integer, no sign | e.g. for initiating switching operations, such as "Coo- lant ON"; max. 5 M functions per block | M... |
| M0 | Programmed stop | | Machining stops at the end of a block containing M0; machining is continued by pressing NC START again | |
| M1 | Optional stop | | as M0, but stop is only carried out if a special signal is provided | |
| M2 | End of program | | is contained in the last block of the sequence of opera- tions | |
| M30 | - | | reserved; do not use | |
| M17 | - | | reserved; do not use | |
| M3 | CW rotation of spindle | | | |
| M4 | CCW rotation of spindle | | | |
| M5 | Spindle stop | | | |
| Mn=3 | CW rotation of spindle (for spindle n) | | n = 1 or = 2 | M2=3 ; CW rotation stop for spindle 2 |

| Address | Meaning | Value Assignment | Explanation | Programming |
|----------------------|--|---|---|--|
| Mn=4 | CCW rotation of spindle (for spindle n) | n = 1 or = 2 | | M2=4 ; CCW rotation stop for spindle 2 |
| Mn=5 | Spindle stop (for spindle n) | n = 1 or = 2 | | M2=5 ; Spindle stop for spindle 2 |
| M6 | Tool change | only if activated with M6 via machine data; otherwise change directly with T command | | |
| M40 | Automatic gear stage switching | | | |
| Mn=40 | Automatic gear stage switching (for spindle n) | n = 1 or = 2 | | M1=40 ; gear stage selected automatically ; for spindle 1 |
| M41 to M45 | Gear stage 1 to gear step 5 | | | |
| Mn=41 to Mn=45 | Gear stage 1 to gear stage 5 (for spindle n) | n = 1 or = 2 | | M2=41 ; 1st gear stage for spindle 2 |
| M70, M19 | - | reserved; do not use | | |
| M... | Remaining M functions | functionality is not defined on side of the control system and is thus free for use by the machine manufacturer | | |
| N | Block number of auxiliary block | 0 ... 9999 9999 only integer, no sign | can be used to mark blocks with a number; is used in the beginning of a block | N20 |
| : | Block number of main block | 0 ... 9999 9999 only integer, no sign | special marking of blocks, instead of N... ; this block should contain all statements for the next following, complete section of machining | :20 |
| P | Number of subroutine cycles | 1 ... 9999 only integer, no sign | is used if the subroutine is run several times and is contained in the same block as the call, | L781 P... ;separate block N10 L871 P3 ; passed three times |
| R0 bto R299 | Arithmetic parameters | ± 0.0000001 ... 9999 9999 (8 decimal places) or with exponent specification: ± (10 ⁻³⁰⁰ ... 10 ⁺³⁰⁰) | | R1=7.9431 R2=4 with exponent specification: R1=-1.9876EX9 ;R1=-1 987 600 000 |
| Arithmetic functions | | | Apart from the 4 basic arithmetic operations using the operands + - * / , there still are some other arithmetic functions: | |
| SIN() | Sine | specified in degrees | | e. g.: R1=SIN(17.35) |
| COS() | Cosine | specified in degrees | | e. g.: R2=COS(R3) |
| TAN() | Tangens | specified in degrees | | e. g.: R4=TAN(R5) |

| Address | Meaning | Value Assignment | Explanation | Programming |
|------------|-------------------------------------|---------------------------------------|---|--|
| ASIN() | Arcussinus | | | R10=ASIN(0.35) ; R10: 20.487 degrees |
| ACOS() | Arcuscosinus | | | R20=ACOS(R2) ; R20: ... degrees |
| ATAN2(,) | Arcustangens2 | | The angle of the sum vector is calculated from 2 vectors standing vertically one on another. The 2nd vector specified is always used for angle reference. Result in the range: -180 to +180 degrees | R40=ATAN2(30.5,80.1) ; R40: 20.8455 degrees |
| SQRT() | Square root | | | e. g.: R6=SQRT(R7) |
| POT() | Square | | | e. g.: R12=POT(R13) |
| ABS() | Amount | | | e. g.: R8=ABS(R9) |
| TRUNC() | Integer portion | | | e.g.: R10=TRUNC(R11) |
| LN() | Natural logarithm | | | R12=LN(R9) |
| EXP() | Exponential function | | | R13=EXP(R1) |
| RET | End of subroutine | | is used instead of M2 to maintain continuous-path control mode | RET ;separate block |
| S | Spindle speed | 0.001 ... 99 999.999 | Unit of spindle speed: rpm | S... |
| S1=... | Spindle speed for spindle 1 | 0.001 ... 99 999.999 | Unit of measurement of the spindle r.p.m. | S1=725 ; speed 725 r.p.m. for spindle 1 |
| S2=... | Spindle speed for spindle 2 | 0.001 ... 99 999.999 | Unit of measurement of the spindle r.p.m. | S2=730 ; speed 730 r.p.m. for spindle 2 |
| S | Cutting speed with G96 active | 0.001 ... 99 999.999 | Unit of cutting speed with G96: m/min | G96 S... |
| S | Dwell time in a block containing G4 | 0.001 ... 99 999.999 | Dwell time in spindle revolutions | G4 S... ;separate block |
| T | Tool number | 1 ... 32 000 only integer, no sign | Tool change can only be carried either directly using the T command or on M6. This can be set in machine data. | T... |
| X | Axis | ±0.001 ... 99 999.999 | Positional data | X... |
| Y | Axis (not with 802D-bl) | ±0.001 ... 99 999.999 | Positional data, e.g. with TRACYL, TRANSMIT | Y... |
| Z | Axis | ±0.001 ... 99 999.999 | Positional data | Z... |
| AC | Absolute coordinate | - | For certain blocks, the dimensional specification for end or center point of a certain axis can be entered other than defined by G91. | N10 G91 X10 Z=AC(20) ;X - incr. dimension, Z - abs. dimension |

| Address | Meaning | Value Assignment | Explanation | Programming |
|-----------|---|---|--|--|
| ACC[axis] | Percentage acceleration compensation | 1 ... 200, integer | Acceleration compensation for an axis or spindle, specification as percentage | N10 ACC[X]=80 ;X - incremental dimension Z - absolute dimension |
| ACP | Absolute coordinate, approach position in the positive direction (only rotary axis) | - | For a rotary axis, ACP(...) can be used to specify the unit for the end point can other than for G90/G91; can also be used for positioning the spindle. | N10 A=ACP(45.3) ; approach absolute position in the positive direction N20 SPOS=ACP(33.1) ; positioning the spindle |
| ACN | Absolute coordinate, approach position in the positive direction (for rotary axis, spindle) | - | For a rotary axis, the unit for the end point with ACP(...) can be specified other than for G90/G91; also applicable to spindle positioning. | N10 A=ACN(45.3) ; absolute position; approaching A axis in the negative direction SPOS=ACN(33.1) ; positioning the spindle |
| ANG | Angle for specification of a straight line with contour definition | $\pm 0.0001 \dots 359.99999$ | Specification in degrees; a possibility to specify a straight line with G0 or G1; only one end point coordinate of the plane is known or the entire end point is known in case of contours over several blocks | N10 G1 X... Z... N11 X... ANG=... or contour over several blocks: N10 G1 X... Z... N11 ANG=... N12 X... Z... ANG=... |
| AR | Aperture angle for circular interpolation | 0.00001 ... 359.99999 | Specification in degrees; one possibility to define a circle with G2/G3 | see G2; G3 |
| CALL | Indirect cycle call | - | Special form of cycle call; no parameter transfer; name of cycle stored in variables; intended for cycle-internal use only | N10 CALL VARNAME ; variable name |
| CHF | Chamfer, general use | 0.001 ... 99 999.999 | inserts a chamfer of specified chamfer length between two contour blocks | N10 X... Z... CHF=... N11 X... Z... |
| CHR | Radius for circular interpolation | 0.001 ... 99 999.999 negative sign - for circle selection: greater than semicircle | inserts a chamfer of specified leg length between two contour blocks | N10 X... Z... CHF=... N11 X... Z... |
| CR | Radius for circular interpolation | 0.010 ... 99 999.999 negative sign - for circle selection: greater than semicircle | a possibility to define a circle with G2/G3 | see G2; G3 |
| CYCLE... | Machining cycle | only given values | The machining cycle call requires a separate block; the intended transfer parameters must be assigned values (see also Section "Cycles") | |
| CYCLE82 | Center drilling | | | N10 RTP=110 RFP=100 ...) ;assign values N10 CYCLE82(RTP, RFT, ...) ;separate block |

| Address | Meaning | Value Assignment | Explanation | Programming |
|----------------|--|----------------------------------|---|--|
| CYCLE83 | Deep hole drilling | | | N10 CCYCLE83(110, 100, ...) ;or transfer values directly, separate block |
| CYCLE84 | Rigid tapping | | | N10 CYCLE84(...) ;separate block |
| CYCLE840 | Tapping with compensating chuck | | | N10 CYCLE840(...) ;separate block |
| CYCLE85 | Reaming | | | N10 CYCLE85(...) ;separate block |
| CYCLE86 | Boring | | | N10 CYCLE86(...) ;separate block |
| CYCLE88 | Drilling with stop | | | N10 CYCLE98(...) ;separate block |
| CYCLE93 | Grooving | | | N10 CYCLE93(...) ;separate block |
| CYCLE94 | Undercut (forms E and F) | | | N10 CYCLE94(...) ;separate block |
| CYCLE95 | Stock removal | | | N10 CYCLE95(...) ;separate block |
| CYCLE97 | Thread cutting | | | N10 CALL CYCLE97(...) ;separate block |
| DC | Absolute coordinate, direct position approach (for rotary axis, spindle) | - | For a rotary axis, the unit for the end point with DC(...) can be specified other than for G90/G91; can also be used for positioning the spindle. | N10 A=DC(45.3) ; approach position of A axis directly N20 SPOS=DC(33.1) ; positioning the spindle |
| DEF | Definition instruction | | Defining a local user variable of the type BOOL, CHAR, INT, REAL, directly at the beginning of the program | DEF INT VARI1=24, VARI2 ; 2 variables of the type INT ; the name is defined by the user |
| FXS [axis] | Travel to fixed stop | =1: Selection =0: Deselection | Axis:Use the machine identifier | N20 G1 X10 Z25 FXS[Z1]=1 FXST[Z1]=12.3 FXSW[Z1]=2 F... |
| FXST [axis] | Clamping torque, travel to fixed stop | > 0.0 ... 100.0 | in %, max. 100% from the max. torque of the drive, axis: Use the machine identifier | N30 FXST[Z1]=12.3 |
| FXSW [axis] | Monitoring window, travel to fixed stop | > 0.0 | Unit of measurement mm or degrees, axis-specific, axis: Use the machine identifier | N40 FXSW[Z1]=2.4 |
| GOTOB | GoTo statement backwards | - | In conjunction with a label, a GoTo operation to the selected block is done; the jump destination is in the direction of the program start. | N10 LABEL1: N100 GOTO LABEL1 |
| GOTOF | GoTo statement forward | - | In conjunction with a label, a GoTo operation to the selected block is done; the jump destination is in the direction of the program start. | N10 GOTOF LABEL2 ... N130 LABEL2: ... |

| | | | | |
|--|---|----------------------|--|--|
| IC | Coordinate in incremental dimension | - | For certain blocks, the dimensional specification for end or center point of a certain axis can be specified other than defined by G90/G91. | N10 G90 X10 Z=IC(20) ;Z - incremental dimension X - absolute dimension |
| IF | Jump condition | - | If the GoTo condition is fulfilled, the branch (jump) to the next block containing the label is carried out; otherwise, next statement/block; several IF statements are possible in a block. Comparison operands: == equal to, <> not equal > greater than, < less than >= greater than or equal to <= less than or equal to | N10 IF R1>5 GOTOF LABEL3 ... N80 LABEL3: ... |
| LIMS | Upper limit speed of spindle with G96 | 0.001 ... 99 999.999 | limits the spindle speed if the function G96 (constant cutting speed for turning) is enabled | see G96 |
| MEAS | Measuring with deleting the distance to go | +1 -1 | =+1: Measuring input 1, rising edge =-1: Measuring input 1, falling edge | N10 MEAS=-1 G1 X... Z... F... |
| MEAW | Measuring without deleting the distance to go | +1 -1 | =+1: Measuring input 1, rising edge =-1: Measuring input 1, falling edge | N10 MEAW=1 G1 X... Z... F... |
| \$A_DBB[n] \$A_DBW[n] \$A_DBD[n] \$A_DBR[n] | Data byte Data word Data double word Real data | | Reading and writing of PLC variables | N10 \$A_DBR[5]=16.3 ; write real variables ; with offset position 5 ; (position, type and meaning are agreed between NC and PLC) |
| \$A_MONI-FACT | Factor for tool life monitoring | > 0.0 | Initialization value: 1.0 | N10 \$A_MONIFACT=5.0 ; tool life elapsed 5 times faster |
| \$AA_FXS [axis] | Status, travel to fixed stop | - | Values: 0 ... 5 axis: machine axis identifier | N10 IF \$AA_FXS[X1]==1 GOTOF |
| \$AA_MM[ax is] | Measurement result of an axis in the machine coordinate system | - | Axis: Identifier of an axis (X, Z, ...) traversing on measuring | N10 R1=\$AA_MM[X] |
| \$AA_MW[ax is] | Measurement result of an axis in the workpiece coordinate system | - | Axis: Identifier of an axis (X, Z, ...) traversing on measuring | N10 R2=\$AA_MW[X] |
| \$AC_MEA[1] | Measuring order state | - | default setting 0: Initial state, pushbutton key has not switched 1: Pushbutton key has switched | N10 IF \$AC_MEAS[1]==1 GOTOF ; continue program if tracer has switched ... |

| | | | | |
|----------------------|---|---|--|--|
| \$A ____ TIME | Timer for runtime: \$AN_SETUP_TIME \$AN_POWERON_TIME \$AC_OPERATING_TIME \$AC_CYCLE_TIME \$AC_CUTTING_TIME | 0.0 ... 10 ⁺³⁰⁰ min (read-only value) min (read-only value) s s s | System variables, time since the control system has last booted Time since the control system has last booted normally Total runtime of all NC programs Runtime of NC program (only of the selected one) Tool intervention time | N10 IF \$AC_CYCLE_TIME==50.5 |
| \$AC____ PARTS | Workpiece counter: \$AC_TOTAL_PARTS \$AC_REQUIRED PARTS \$AC_ACTUAL_PARTS \$AC_SPECIAL_PARTS | 0 ... 999 999 999, integer | System variables, total actual number, workpiece set number Current actual number Number of workpieces specified by the user | N10 IF \$AC_ACTUAL_PARTS==15 |
| \$AC_ MSNUM | Number of the active master spindle | | read-only | |
| \$P_ MSNUM | Number of the programmed master spindle | | read-only | |
| \$P_NUM_ SPINDLES | Number of configured spindles | | read-only | |
| \$AA_S[n] | Actual speed of spindle n | | Spindle number n =1 or =2, read-only | |
| \$P_S[n] | Speed of spindle n, which was last programmed | | Spindle number n =1 or =2, read-only | |
| \$AC_ SDIR[n] | Current direction of rotation of spindle n | | Spindle number n =1 or =2, read-only | |
| \$P_ SDIR[n] | Direction of rotation of spindle n, which was last programmed | | Spindle number n =1 or =2, read-only | |
| \$P_ TOOLNO | Number of the active tool T | - | read-only | N10 IF \$P_TOOLNO==12 GOTOF |
| \$P_TOOL | Active D number of the active tool | - | read-only | N10 IF \$P_TOOL==1 GOTOF |
| \$TC_MOP1 [t,d] | Tool life prewarning limit (not with 802D-bl) | 0.0 ... | in minutes, writing or reading values for tool t, D number d | N10 IF \$TC_MOP1[13,1]<15.8 GOTOF |
| \$TC_MOP2 [t,d] | Residual tool life (not with 802D-bl) | 0.0 ... | in minutes, writing or reading values for tool t, D number d | N10 IF \$TC_MOP2[13,1]<15.8 GOTOF |

| | | | | |
|-----------------------|---|----------------------------|--|--|
| \$TC_MOP3 [t,d] | Prewarning limit for the number of pieces (not with 802D-bl) | 0 ... 999 999 999, integer | writing or reading values for tool t, D number d | N10 IF \$TC_MOP3[13,1]<15 GOTOF |
| \$TC_MOP4 [t,d] | Residual number of workpieces (not with 802D-bl) | 0 ... 999 999 999, integer | writing or reading values for tool t, D number d | N10 IF \$TC_MOP4[13,1]<8 GOTOF |
| \$TC_MOP1 1[t,d] | Required tool life (not with 802D-bl) | 0.0 ... | in minutes, writing or reading values for tool t, D number d | N10 \$TC_MOP11[13,1]=247.5 |
| \$TC_MOP1 3[t,d] | Residual number of workpieces (not with 802D-bl) | 0 ... 999 999 999, integer | writing or reading values for tool t, D number d | N10 \$TC_MOP13[13,1]=715 |
| \$TC_TP8[t] | Tool status (not with 802D-bl) | - | default status - coding by bits for tool t, (bit 0 to bit 4) | N10 IF \$TC_TP8[1]==1 GOTOF |
| \$TC_TP9[t] | Type of monitoring of the tool (not with 802D-bl) | 0 ... 2 | Monitoring type for tool t, writing or reading 0: No monitoring, 1: Tool life, 2: Count | N10 \$TC_TP9[1]=2 ; Select count monitoring |
| MSG() | Message | max. 65 characters | Message text in inverted commas | MSG("MESSAGE TEXT") ; separate block ... N150 MSG() ; delete previous message |
| OFFN | Groove width with TRA-CYL, otherwise specification of stock allowance | - | Only effective with the tool radius compensation G41, G42 active | N10 OFFN=12.4 |
| RND | Rounding | 0.010 ... 99 999.999 | inserts a rounding with the specified radius value tangentially between two contour blocks | N10 X... Z... RND=... N11 X... Z... |
| RPL | Angle of rotation with ROT, AROT | ±0.00001 ... 359.9999 | Specification in degrees; angle for a programmable rotation in the current plane G17 to G19 | see ROT, AROT |
| SET(, , ,) REP() | Set values for the variable fields | | SET: Various values, from the specified element up to: according to the number of values REP: the same value, from the specified element up to the end of the field | DEF REAL VAR2[12]=REP(4.5) ; all elements value 4.5 N10 R10=SET(1.1,2.3,4.4) ; R10=1.1, R11=2.3, R4=4.4 |
| SETMS(n) SETMS | Define spindle as master spindle | n= 1 or n= 2 | n: Number of the spindle, if only SETMS is set, the default master spindle comes into effect | N10 SETMS(2) ; separate block, 2nd spindle = master |
| SF | Thread start point at G33 | 0.001 ... 359.999 | specified in degrees; the thread starting point at G33 is offset by the specified value (not important for tapping) | see G33 |

| | | | | |
|---------------------|--|-------------------------|---|---|
| SPI(n) | converts the spindle number n into the axis identifier | | n= 1 or n= 2 axis identifier: e.g. "SP1" or "C" | |
| SPOS SPOS(n) | Spindle position | 0.0000 ... 359.9999 | specified in degrees; the spindle stops at the specified position (to achieve this, the spindle must provide the appropriate technical prerequisites: position control) Spindle number n: 1 or 2 | N10 SPOS=... N10 SPOS=ACP(...) N10 SPOS=ACN(...) N10 SPOS=IC(...) N10 SPOS=DC(...) |
| STOPRE | Block search stop | - | special function; the next block is only decoded if the block is completed prior to STOPRE | STOPRE ;separate block |
| TRACYL(d) | Milling of peripheral surface (not with 802D-bl) | d: 1.000 ... 99 999.999 | kinematic transformation (only available if the relevant option exists; to be configured) | TRACYL(20.4) ; separate block ; Cylinder diameter: 20.4 mm TRACYL(20.4,1) ; also possible |
| TRANSMIT | Milling of end face (not with 802D-bl) | - | kinematic transformation (only available if the relevant option exists; to be configured) | TRANSMIT ; separate block TRANSMIT(1) ; also possible |
| TRAFOOF | Disable TRANSMIT, TRACYL (not with 802D-bl) | - | disables all kinematic transformations | TRAFOOF ; separate block |

8.2 Positional Data

8.2.1 Absolute / Incremental Data Input: G90, G91, AC, IC

Functionality

With the statements G90/G91, the programmed dimensional data X, Z are interpreted either as a coordinate end point (G90) or as a distance to be traversed by the axis (G91). G90/G91 applies to all axes. Deviating from the G90/G91 setting, certain positional data can be specified in absolute/incremental dimensions using AC/IC.

These statements will **not define the path** on which the end points are reached. For this purpose, a G group is provided (G0,G1,G2,G3,... see Section 8.3 "Axis Movements").

Programming

G90 ;absolute data input
G91 ;incremental data input

Z=AC(..) ;absolute data input for a certain axis (here: Z axis), non-modal
Z=IC(..) ;incremental data input for a certain axis (here: Z axis), non-modal




Fig. 8-3 Different dimensions in one drawing

Absolute dimensioning G90

With absolute data input, the dimensions are specified with reference to the **zero point of the currently active coordinate system** (workpiece or current workpiece coordinate system or machine coordinate system). This is dependent on which offsets are currently active: programmable, settable or no offset.

With program start, G90 is active for **all axes** and remains active until it is canceled in a later block by G91 (incremental data input) (modally effective).

Incremental data input G91

With incremental data input, the numerical value of the positional information corresponds to the **distance to be traversed by the axis**. The sign specifies the **traversing direction**.

G91 applies to all axes and can be canceled by G90 (absolute data input) in a later block.

Specification with =AC(...), =IC(...)

After the end position coordinate, an equality sign must be written. The value must be put in round brackets.

Absolute dimensions can also be specified for circle centers using =AC(...). Otherwise, the reference point for the circle center will be the circle start point.

Programming example

```

N10 G90 X20 Z90           ;absolute data input
N20 X75 Z=IC(-32)        ;X dimensions still remain absolute, Z incremental dimension
...
N180 G91 X40 Z20         ;switch to incremental data input
N190 X-12 Z=AC(17)       ;X - still incremental data input, Z - absolute

```

8.2.2 Metric and Inch Dimensions: G71, G70, G710, G700**Functionality**

If the workpiece dimensions are other than set in the basic system of the control system (inch or mm), you can enter the dimensions directly into the program. The required conversions into the basic system are carried out by the control system.

Programming

```

G70           ;inch dimensions
G71           ;metric dimensions

G700          ;inch dimensions, also for feed F
G710          ;metric dimensions, also for feed F

```

Programming example

```

N10 G70 X10 Z30          ;inch dimensions
N20 X40 Z50              ;G70 still active
...
N80 G71 X19 Z17.3        ;metric dimensions from here
...

```

Information

Depending on the **basic scaling settings**, the control system interprets all geometrical values as metric **or** inch dimensions. Tool offsets and settable zero offsets including the corresponding displayed values are also to be understood as geometrical values; this also applies to the feed F specified in mm/min or inch/min.

The basic settings can be set in machine data.

All examples listed in these instructions start from the **metric scaling**.

G70 or G71 interprets all geometrical data specified directly with reference to the **workpiece** in inches or metrically, e.g.:

- positional data X, Z with G0,G1,G2,G3,G33, CIP, CT

- interpolation parameters I, K (including pitch)
- circle radius CR
- **programmable** zero offset (TRANS, ATRANS)

The remaining geometrical data that are no direct workpiece data, such as feedrates, tool offsets, **settable** zero offsets are not affected by **G70/G71** .

G700/G710, however, additionally affects the feed F (inch/min, inch/rev. or mm/min, mm/rpm).

8.2.3 Radius / Diameter Programming: DIAMOF, DIAMON

Functionality

When machining parts on **turning machines**, the positional data for the **X axis** (traverse axis) are usually programmed with diameter dimensions. If necessary it is possible to switch over to radius programming.

DIAMOF and DIAMON will evaluate the end point specification for the X axis as a radius or diameter input. The actual value will therefore be displayed in the workpiece coordinate system.

Programming

DIAMOF; radius input
 DIAMON ;diameter input




Fig. 8-4 Diameter and radius data input for the transverse axis

Programming example

```

N10 DIAMON X44 Z30 ;for X axis - diameter input
N20 X48 Z25 ;DIAMON is still active
N30 Z10
...
N110 DIAMOF X22 Z30 ;switchover to radius data input for X axis from here
N120 X24 Z25
N130 Z10
...
    
```

Note

A programmable offset with TRANS X... or ATRANS X... is always interpreted as a radius dimension input. Description of this function: see next following Section.

8.2.4 Programmable Zero Offset: TRANS, ATRANS

Functionality

The programmable zero offset is used in case of recurring geometries/arrangements in different positions on a workpiece or simply when selecting a new reference point for the dimensional notation or as the allowance for roughing; this results in the **current workpiece coordinate system**. The newly programmed dimensions will refer to this coordinate system. The offset is possible in all axes.

Note:

In the X axis, the workpiece zero should be in the rotation center because of the functions "Diameter programming: DIAMON" and "Constant cutting speed: G96". In this case, none or only a minor offset (e.g., as the allowance) along the axis.




Fig. 8-5 Effects of the programmable offset

Programming

| | |
|-------------|--|
| TRANS Z... | programmable offset, deletes all statements of offset, rotation, scaling factor, mirroring |
| ATRANS Z... | ;programmable offset, additive to the existing statements |
| TRANS | ;without values: deletes all statements of offset, rotation, scaling factor, mirroring |

The statement with TRANS/ATRANS always requires a separate block.

Programming example

```

N10 ...
N20 TRANS Z5           ;programmable offset 5mm along the Z axis
N30 L10               ;subroutine call; contains the geometry
                       to be shifted
...
N70 TRANS             ;offset deleted
...
Subroutine call - see Section 8.11 "Subroutine Technique"

```

8.2.5 Programmable Scaling Factor: SCALE, ASCALE

Functionality

SCALE, ASCALE can be used to program a scaling factor for all axes, by which an increase or a reduction is carried out along the specified axis.

The currently set coordinate system serves as the reference for the scale modification.

Programming

SCALE X...Z... ;programmable scaling factor, deletes all statements of offset, rotation, scaling factor, mirroring
 ASCALE X... Z... ;programmable scaling factor, additive to the existing statements
 SCALE ;without values: deletes all statements of offset, rotation, scaling factor, mirroring

The statements with SCALE, ASCALE require a separate block.

Notes

- For circles, the same factor should be used for both axes.
- If ATRANS is programmed with SCALE/ASCALE active, these offset values will also be scaled.




Fig. 8-6 Example of a programmable scaling factor

Programming example

```
N20 L10 ; programmed contour - original
N30 SCALE X2 Z2
N40 L10 ; contour in X and Z enlarged twice
...
Subroutine call - see Section 8.11 "Subroutine Technique"
```

Information

In addition to the programmable shift and the scaling factor, there are still some other functions:

programmable rotation ROT, AROT and
programmable mirroring MIRROR, AMIRROR.

These functions are intended mainly for milling. On turning machines, this is possible with TRANSMIT or TRACYL (see Section 8.14 "Milling on turning machines").

Examples for rotation and mirroring: see Section 8.1.6 "Overview of statements"

For detailed information, see:

References: "Operation and Programming - Milling" SINUMERIK 802D

8.2.6 Workpiece Clamping - Settable Zero Offset: G54 to G59, G500, G53, G153

Functionality

The settable zero offset specifies the position of the workpiece zero on the machine (offset of workpiece zero with reference to the machine zero). This offset is determined when clamping the workpiece on the machine, and it is then entered in the relevant data field by operation. The value is enabled by the program by choice from six possible groups: G54 to G59.

For the operation, see Section "Entering/Modifying Zero Offset"

Programming

| | |
|------|---|
| G54 | ;1st settable zero offset |
| G55 | ;2nd settable zero offset |
| G56 | ;3rd settable zero offset |
| G57 | ;4th settable zero offset |
| G58 | ;5th settable zero offset |
| G59 | ;6th settable zero offset |
| G500 | ;settable zero offset OFF - modal |
| G53 | ;settable zero offset OFF - non-modal, also suppresses the programmable offset |
| G153 | ;as with G53; also suppresses basic frame |




Fig. 8-7 Settable zero offset

Programming example

```

N10 G54 ...           ;calling the first settable zero offset
N20 X... Z...       ;machining of workpiece
...
N90 G500 G0 X...    ;disabling of settable zero offset
    
```

8.2.7 Programmable Working Area Limitation: G25, G26, WALIMON, WALIMOF

Functionality

G25/G26 can be used to define a working range for all axes, within which traversing is permitted and outside of which traversing is not permitted. With tool length compensation active, the tool tip can be inside this range; otherwise, the tool carrier reference point. The coordinates are specified with reference to the machine.

The validity of the working area limitation can be defined for each axis and direction separately in the setting data. In addition to programming the values using G25/G26, it is also possible to input these values in the setting data via operation.

For enabling/disabling the limitation for all enabled axes/directions, another programmable instruction group with WALIMON/WALIMOF is provided.

Programming

```

G0 X... Z...      ; lower working area limitation
G26 X... Z...    ; working area limitation

WALIMON          ; working area limitation ON
WALIMOF         ; working area limitation OFF
    
```




Fig. 8-8 Programmable work area limiting

Notes

- When working with G25, G26, the channel axis identifier from machine data 20080: AXCONF_CHANAX_NAME_TAB must be written. With SW 2.0 and higher, kinematic transformations are possible for the SINUMERIK 802D. In this case, different axis identifiers are configured for MD 20080 and for the geometry axis identifiers MD 20060: AXCONF_GEOAX_NAME_TAB.
- G25/G26 is also used in conjunction with address S for the spindle speed limitation (see also Section "Spindle Speed Limiting").
- A working area limitation can only be activated if the reference point has been approached for the relevant axes.

Programming example

```

N10 G25 X0 Z40           ; values for the lower working area limitation
N20 G26 X80 Z160        ; values for the upper working area limitation
N30 T1
N40 G0 X70 Z150
N50 WALIMON             ; working area limitation ON
...                     ; only inside working area
N90 WALIMOF            ; working area limitation OFF

```

8.3 Axis Movements

8.3.1 Linear Interpolation at Rapid Traverse: G0

Functionality

The rapid traverse movement G0 is used for quick positioning of the tool, **not for direct work-piece machining**.

All axes can be traversed at the same time, resulting in a straight path.

The maximum speed (rapid traverse) for each axis is defined in machine data. If only one axis traverses, it will traverse at its rapid traverse. If two axes simultaneously traverse, the tool path feedrate (e.g. resulting speed at the tool tip) will be selected such that the **maximum possible tool path feedrate** results, with consideration of all axes involved.

A programmed feed (F word) is not relevant for G0.

G0 is effective until it is canceled by another statement from this G group (G1, G2, G3,...).




Fig. 8-9 Linear interpolation at rapid traverse from point P1 to P2

Programming example

```
N10 G0 X100 Z65
```

Note: Another possible way to program a straight line is to use the angle specification ANG= (see Section "Contour Definition Programming").

Information

To approach a position, another group of G functions (see Section 8.3.13 "Exact Stop/Continuous-Path Control Mode: G60, G64") is provided. With G60 - Exact Stop -, another group is provided to select a window with different accuracies. For exact stop, a modal statement is provided: G9.

You should take into account this option for adaptation to your particular positioning task!

8.3.2 Linear Interpolation with Feed: G1

Functionality

The tool moves from the starting point to the end point along a straight path. For the **tool path feedrate**, the programmed **F word** is decisive.

All axes can be traversed at the same time.

G1 is effective until it is canceled by another statement from the same G group (G0, G2, G3, ...).




Fig. 8-10 Linear interpolation with G1

Programming example

```

N05 G54 G0 G90 X40 Z200 S500 M3 ;tool traverses at rapid traverse,
                                spindle speed = 500 rpm, CW rotation;
N10 G1 Z120 F0.15 ;linear interpolation with feed 0.15 mm/rev.
N15 X45 Z105
N20 Z80
N25 G0 X100 ;clearance at rapid traverse
N30 M2 ;end of program

```

Note: Another possible way to program a straight line is to use the angle specification ANG= (see Section "Contour Definition Programming").

8.3.3 Circular Interpolation: G2, G3

Functionality

The tool moves from the starting point to the end point on a circular path. The direction is determined by the G function:




Fig. 8-11 Definition of direction of rotation of the circle using G2/G3

The description of the desired circle can be specified in different ways:




Fig. 8-12 Possibilities of circle programming

G2/G3 is active until it is canceled by another statement of this G group (G0, G1, ...).
 For the **tooth path velocity**, the programmed **F word** is decisive.

Note

Further circle programming facilities are provided by:
 CT - circle with tangential connection and
 CIP - circle via intermediate point (see next following sections).

Input tolerances for circle

Circles are only accepted by the control system within a certain dimensional tolerance. To this aim, the circle radius is compared in the starting and in the end points. If the difference is within the tolerance, the internal setting of the center point will be carried out exactly. Otherwise, an alarm message is output.

The tolerance value can be set via machine data.

Programming example: Center and end point specification




Fig. 8-13 Center and end point specification (example)

```
N5 G90 Z30 X40 ;start point of circle for N10
N10 G2 Z50 X40 K10 I-7 ;end point and center point
```

Note: The center point values are referred to the starting point of the circular path.

Programming example: End point and radius specification




Fig. 8-14 End point and radius input (example)

```
N5 G90 Z30 X40 ;start point of circle for N10
N10 G2 Z50 X40 CR=12.207 ;end point and radius
```

Note: A negative sign for the value of CR=- ... will select a circle segment greater than a semi-circle.

Programming example: End point and aperture angle




Fig. 8-15 End point and aperture angle specification (example)

```
N5 G90 Z30 X40 ;start point of circle for N10
N10 G2 Z50 X40 AR=105 ;end point and aperture angle
```

Programming example of center point and aperture angle:




Fig. 8-16 Center point and aperture angle specification (example)

```
N5 G90 Z30 X40 ;start point of circle for N10
N10 G2 K10 I-7 AR=105 ;center point and aperture angle
```

Note: The center point values are referred to the starting point of the circular path.

8.3.4 Circular Interpolation via Intermediate Point: CIP

Functionality

In this case, the direction of the circle results from the position of the intermediate point (between start and end points). CIP is effective until it is canceled by another statement from this G group (G0, G1, G2, ...).

Note: The set dimension data input format G90 or G91 is applicable both to the end point **and** the intermediate point!




Fig. 8-17 Circle with end and intermediate point specification (example with G90)

Programming example

```
N5 G90 Z30 X40 ;starting point of circle for N10
N10 CIP Z50 X40 K1=40 I1=45 ;end and intermediate point
```

8.3.5 Circle with Tangential Transition: CT

Functionality

CT and the programmed end point in the current plane (G18: Z/X plane) will create a circle tangentially connected to the previous path section (circle or straight line).

Radius and center point of the circle are derived from the geometrical relations of previous path section and programmed circle end point.




Fig. 8-18 Circle with tangential transition to the previous path section

8.3.6 Thread Cutting with Constant Lead: G33

Functionality

The function G33 can be used to machine threads with constant lead of the following type:

- threads on cylindrical bodies
- threads on taper bodies
- external and internal threads
- single and multiple threads
- multi-block threads (sequencing of threads)

This function requires a spindle with position measuring system.

G33 is effective until it is canceled by another statement of this group (G0, G1, G2, G3, ...).




Fig. 8-19 External/internal threads using the example of a cylindrical thread

RH or LH thread

RH or LH threads are defined with the direction of rotation of the spindle (M3 - CW rotation, M4 - CCW rotation - see Section 8.4 "Spindle Movement"). This requires the speed to be programmed under address S or a speed to be set.

Note: For the thread length, the run-in and run-out travels should be taken into account!




Fig. 8-20 Programmable parameters for thread with G33




Fig. 8-21 Lead assignment using the example of Z / X axes

Taper thread

For taper threads (2 axes to be specified), the required lead address I or K with the **longer path** (longer thread length) must be used. Another lead will not be specified.

Start point offset SF=

A start point offset of the spindle is required to produce either threads using set cuts or multiple threads. The start point offset is programmed in the thread block using G33 under the address **SF** (absolute position).

If no start point offset is programmed, the value from the setting data will be used.

Note:In all cases, a programmed value for SF= will also be entered in the setting data.

Programming example

Cylindrical thread, double, start point offset 180 degrees, thread length (including run-in and run-out) 100 mm, thread lead 4 mm/rev.

RH thread, cylinder already prepared:

```

N10 G54 G0 G90 X50 Z0 S500 M3           ;start-point approach, CW spindle rotation
N20 G33 Z-100 K4 SF=0                   ;lead: 4 mm/rev.
N30 G0 X54
N40 Z0
N50 X50
N60 G33 Z-100 K4 SF=180                 ;2nd pitch offset by 180 degrees
N70 G0 X54 ...

```

Multi-block thread

If several thread blocks are programmed one after the other (multi-block thread), it is recommended to specify a start-point offset only in the first thread block because the information is used only in this block.

Multi-block threads will automatically be linked using G64 continuous-path control mode (see Section 8.3.13 "Exact Stop/Continuous-Path Control Mode: G60, G64").




Fig. 8-22 Example of multi-block thread (thread chaining)

Velocity of the axes

For G33 threads, the velocity of the axes for the thread length results from the set spindle speed and the programmed thread lead. The **feed F will not apply here**. However, it remains stored. The maximum axis velocity (rapid traverse), however, which is defined in machine data, cannot be exceeded. In this case, an alarm will be output.

Information**Important**

- Make sure that the spindle speed override switch is not changed when machining the thread.
- The feed override switch is not relevant in this block.

8.3.7 Thread cutting with variable lead: G34, G35**Functionality**

G34, G35 can be used to manufacture threads with variable lead in one block:

- G34 ; thread with increasing lead
- G35 ; thread with decreasing lead

Both functions provide the same functionality as contained in G33 and require the same prerequisites.

G34 or G35 are effective until they are canceled by another statement of this G group (G0, G1, G2, G3, G33, ...).

Thread lead:

- I or K ; starting thread lead in mm/rev, belonging to axis X or Z

Lead change:

In the block that contains G34 or G35, the address F is given the meaning of the lead change:

The lead (mm per revolution) changes per revolution.

- F ; lead change in mm/rev².

Note: Beyond G34, G35, the address F has additionally the meaning of the feedrate or of the dwell time when using G4. The values programmed there remain stored.

Determining F

If the starting and final leads of a thread are known, the thread lead change F to be programmed can be calculated using the following equation:

$$F = \frac{|K_e^2 - K_a^2|}{2 \cdot L_G} \quad [\text{mm}/\mu^2]$$

The meanings of the variables above are:

| | |
|-------|--|
| K_e | Thread lead of the axis target coordinate [mm/rev] |
| K_a | Thread starting lead (programmed under I, K) [mm/rev.] |
| L_G | Thread length in [mm] |

Programming

- G34 Z... K... F... ; cylinder thread with increasing lead
- G35 X... I... F... ; face thread with decreasing lead
- G35 Z... X... K... F... ; taper thread with decreasing lead

Programming example

```

; cylinder thread, then with decreasing lead
N10 M3 S40 ; turn on spindle
N20 G0 G54 G90 G64 Z10 X60 ; approach starting point
N30 G33 Z-100 K5 SF=15 ; thread, constant lead 5mm/rev.,
; starting point at 15 degrees
N40 G35 Z-150 K5 F0.16 ; starting lead 5 mm/rev.,
; lead decrease 0.16 mm/rev. 2,
; thread length 50 mm,
; desired lead at block end 3 mm/rev.
N50 G0 X80 ; retraction in X
N60 Z120
N100 M2

```

8.3.8 Thread interpolation: G331, G332**Functionality**

This function requires a position-controlled spindle with position measuring system. G331/G332 can be used to tap threads **without** compensating chuck provided the dynamic properties of both the spindle and the axes are such that this is possible. If nevertheless a compensating chuck is used, the path differences to be compensated by the compensating chuck are getting smaller. Thus, tapping with higher spindle speed is possible.

G331 is used for drilling, and G332 is used for retracting the drill.

The drilling depth is specified via the axis, e.g. Z; the thread lead is specified via the appropriate interpolation parameter (here: K).

When using G332, the same lead is programmed as with G331. The reversal of the direction of rotation of the spindle is performed automatically.

The spindle speed is programmed with S, without M3/M4.

Before tapping using G332, the spindle must be switched to the position-controlled mode using SPOS=... (see also Section 8.4.3 "Positioning the spindle").

Right-hand or left-hand thread

The direction of rotation of the spindle is determined by the **sign of the thread lead**:

positive: CW rotation (as with M3)

negative: CCW rotation (as with M4)

Note:

A complete tapping cycle with thread interpolation is provided with the standard cycle CYCLE84.

Velocity of the axes

With G331/G332, the velocity of the axis for the thread length results from the spindle speed and the thread lead. The **feedrate F is not relevant**, but it remains stored. The maximum axis velocity (rapid traverse rate), however, which is defined in the machine data, cannot be exceeded. In this case, an alarm is issued.

Programming example

```

Metric thread 5 ,
lead as per table: 0.8 mm/rev., drill hole already prepared:
N5 G54 G0 G90 X10 Z5           ;approach starting point
N10 SPOS=0                     ;spindle in position control
N20 G331 Z-25 K0.8 S600        ;tapping, K positive =CW rotation
                                of spindle, end point -25 mm
N40 G332 Z5 K0.8               ;retraction
N50 G0 X... Z...

```

8.3.9 Fixed-Point Approach: G75**Functionality**

G75 can be used to approach a fixed point on the machine, e.g. the tool change point. The position is fixed in the machine data for all axes. No offset is effective. The velocity of each axis is its rapid traverse.

G74 requires a separate block and is effective block by block. The machine axis identifier must be programmed!

In the block following G74, the previous G command of the interpolation type group (G0, G1, G2, ...) is active again.

Programming example

```
N10 G75 X1=0 Z1=0
```

Note: The programmed position values for X1, Z1(here = 0) are ignored, but must be programmed.

8.3.10 Reference Point Approach: G74**Functionality**

G74 can be used for reference-point approach in the NC program. Direction and speed of each axis are stored in machine data.

G74 requires a separate block and is effective block by block. The machine axis identifier must be programmed!

In the block following G74, the previous G command of the interpolation type group (G0, G1, G2, ...) is active again.

Programming example

```
N10 G74 X1=0 Z1=0
```

Note: The programmed position values for X1, Z1(here = 0) are ignored, but must be programmed.

8.3.11 Measuring with Switching Tracer: MEAS, MEAW

Functionality

If either the statement MEAS=... or MEAW=... is contained in a block for traversing movements of axes, the positions of the traversed axes are acquired at the switching edge of a connected tracer and then stored. The measuring result for each axis can be read from the program.

With MEAS, the movements of the axes are decelerated when the selected switching edge of the tracer comes in, and the remaining distance to go will be deleted.

Programming

| | |
|---------|---|
| MEAS=1 | G1 X... Z... F... ;measuring at the rising edge of the tracer; deletion of distance to go |
| MEAS=-1 | G1 X... Z... F... ;measuring at the falling edge of the tracer; deletion of distance to go |
| MEAW=1 | G1 X... Z... F... ;measuring at the rising edge of the tracer without deleting the distance to go |
| MEAW=-1 | G1 X... Z... F... ;measuring at the falling edge of the tracer without deleting the distance to go |

Measuring order state

If the tracer has switched, the variable \$AC_MEA[1] after the measuring record has the value =1; otherwise, it has the value = 0.

Starting of the measuring record will set the variable to 0.

Measurement result

The measurement result is available for the axes traversed using the measuring record with the variables listed below and specified after the measuring record if the tracer has switched successfully:

| | |
|-------------------------------------|-------------------------|
| in the machine coordinate system: | \$AA_MM[axis] |
| in the workpiece coordinate system: | \$AA_MW[axis] |
| | Axis stands for X or Z. |

Programming example

```

N10 MESA=1 G1 X300 Z-40 F4000 ;measuring with deleting the distance to go,
                                rising edge
N20 IF $AC_MEA[1]==0 GOTOF MEASERR ;measuring error ?
N30 R5=$AA_MW[X] R6=$AA_MW[Z] ;process measured values
..
N100 MEASERR: M0 ; measuring error
Note: IF statement - see Section "Conditioned Program Jumps"

```

8.3.12 Feed F

Functionality

The feed F constitutes the **tool path feedrate** and represents the amount of the geometrical total of the speed components of all axes involved.

The individual axis speeds therefore result from the position of the axis path in the whole contour path.

The feed F is active for the interpolation types G1, G2, G3, CIP,CT and remains stored until a new F word is programmed.

Programming

F...

Note:For **integer values**, the decimal point may be omitted,
e. g.: F300

Unit for F- G94, G95

The unit of the F word is determined by G functions:

- G94 **F** as feed in **mm/min**
- G95 **F** as feed in **mm/rev.** of the spindle
(only makes sense if the spindle rotates!)

Note:

This unit applies to metric dimension input. As mentioned in Section "Metric and Inch Dimension Input", a setting using inch dimensions is also possible.

Programming example

```
N10 G94 F310 ;Feed in mm/min
```

```
...
```

```
N110 S200 M3 ;Spindle rotation
```

```
N120 G95 F15.5;Feed in mm/rev.
```

Note: Write a new F word if you change G94 - G95!

Information

The G group with G94 and G95 also contains the functions G96 and G97 for constant cutting speed. These functions additionally affect the S word (see Section 8.5.1 "Constant Cutting Speed").

8.3.13 Exact Stop / Continuous-Path Control Mode: G9, G60, G64

Functionality

To set the traversing behavior at the block borders and for block relaying, G functions are provided for optimum adaptation to various demands. Example: You want to use the axes for quick positioning, or you want to machine path contours over several blocks.

Programming

| | |
|------|--|
| G60 | ;exact stop - modally effective |
| G64 | ;continuous-path control mode |
| G9 | ;exact stop - effective block-by-block |
| G601 | ;exact-stop window fine |
| G602 | ;exact-stop window, coarse |

Exact stop G60, G9

If the Exact Stop function (G60 or G9) is enabled, the speed is decelerated to zero at the end of the block in order to be able to achieve the exact target position.

Another modally effective G group is provided to set when the traversing movement of the block concerned is considered completed and switching to the next block is carried out.

- G601 exact-stop window fine
Block relaying is only carried out if all axes have achieved the exact-stop window, fine (value in machine data).
- G602 exact-stop window coarse
Block relaying is only carried out if all axes have achieved the exact-stop window coarse (value in machine data).

The selection of the exact-stop window substantially influences the total time if many positioning processes are carried out. Fine adjustments require more time.




Fig. 8-23 Exact-stop windows coarse and fine, effective with G60/G9; enlarged representation of the windows

Programming example

```

N5 G602                                ;exact-stop window coarse
N10 G0 G60 Z...                          ;exact-stop, modal
N20 X... Z...                            ;G60 remains active
...
N50 G1 G601 ...                          ;exact-stop window fine
N80 G64 Z...                              ;change to continuous-path control mode
...
N100 G0 G9 Z...                          ;exact stop is only effective for this block
N111 ...                                  ;continuous-path control mode again

```

Note: The command G9 will only create exact stop for the block in which it is programmed; G60, however, remains active until it is canceled by G64.

Continuous-path control mode G64

The objective of continuous-path control mode is to avoid deceleration at the block borders and to change **to the next block** at the **same tool path velocity** if possible (with tangential transitions). This function uses the principle of **look-ahead velocity control** over several next blocks.

With non-tangential transitions (corners), the velocity is decreased if necessary such that none of the axes must perform a sudden velocity change, or the jerk (change in acceleration) is limited (if SOFT is active).

Programming example

```

N10 G64 G1 Z... F...                      ;continuous-path control mode
N20 X..                                    ;continuous-path control mode continued
...
N180 G60 ...                              ;change to exact stop

```

Look-ahead velocity control

In continuous-path control mode with G64, the control system determines the velocity control for several NC blocks automatically. In case of approximately tangential transitions, it is possible to accelerate or decelerate over several blocks. In case of paths consisting of several short paths in the NC blocks, it is possible to achieve higher velocities than without LookAhead.




Fig. 8-24 Comparison of velocity behavior using G60 and G64, resp., with short block travels

8.3.14 Acceleration Behavior: BRISK, SOFT

BRISK

The axes of the machine are traversed as a path at maximum acceleration until they have achieved the required feedrate. BRISK provides time-optimized working. The set speed is achieved within a short time. However, jerks in the acceleration characteristic are to be noticed.

SOFT

The machine axes are traversed along a non-linear, steady characteristic until they have reached the required final velocity. This jerk-free acceleration allows SOFT to provide for a lower burden on the machine; the same behavior will also apply to braking processes.




Fig. 8-25 Diagram of tool path feedrate characteristic with BRISK / SOFT

Programming

BRISK ;abrupt path acceleration
 SOFT ;jerk-limited path acceleration

Programming example

N10 SOFT G1 X30 Z84 F6.5 ;jerk-limited path acceleration
 ...
 N90 BRISK X87 Z104 ;further with abrupt path acceleration
 ...

8.3.15 Percentage Acceleration Compensation: ACC**Functionality**

In certain program sections, it can be necessary to modify the axis or spindle acceleration set in the machine data. This programmable acceleration is a percentage acceleration compensation.

It is possible to program a percentage value $> 0\%$ and $\leq 200\%$ for each axis (e.g.: X) or spindle (S). In this case, the axis interpolation is carried out using this proportional acceleration. The reference value (100%) is the valid machine data value for the acceleration (depending on axis or spindle, for the spindle also dependent on gear stage and positioning mode or speed mode).

Programming

ACC[*Axis name*] = *percentage value* ;for the axis
ACC[S] = *percentage value* ;for the spindle

Programming example

N10 ACC[X]=80 ; 80% acceleration for the X axis
 N20 ACC[S]=50 ; 50% acceleration for the spindle
 ...
 N100 ACC[X]=100 ;disabling the compensation for the X axis

Activation

The limitation is effective in all kinds of interpolation in AUTOMATIC and MDA modes. The limitation is not effective in JOG mode and on reference point approach.

The value assignment **ACC**[...] = 100 will disable the correction; this also applies to RESET and end of program.

The programmed compensation value is also effective with dry run feedrate.

Note: A programmed value greater than 100% can only be carried out if the machine mechanics is designed for such a load and the drives have the appropriate reserves - otherwise, alarm messages are output.

8.3.16 Traversing with Feedforward Control: FFWON, FFWOF

Functionality

Feedforward control will reduce the following error to zero.

Traversing with feedforward control provides a higher traversing accuracy and thus better manufacturing results.

Programming

```
FFWON      ;feedforward control ON
FFWOF      ;feedforward control OFF
```

Programming example

```
N10 FFWON      ; feedforward control ON
N20 G1 X... Z... F9
...
N80 FFWOF      ; feedforward control OFF
```

8.3.17 3rd and 4th Axes

Functionality

Prerequisite: Extended control system configuration for 4 axes

Depending on the machine design, a 3rd and 4th axes can be necessary. These axes can be designed either as a linear or a rotary axis. The identifier for these axes must be configured accordingly, e.g.: U or C or A, etc. With rotary axes, the traversing range can be configured between 0 ...<360 degrees (Modulo behavior).

A 3rd or 4th axis can be traversed as a linear axis together with the remaining axes if the machine is designed accordingly. If the axis is traversed in a block that contains G1 or G2/G3 together with the remaining axes (X, Z) it will not be assigned a component of the feedrate F. Its velocity will then depend on the traversing rate of the axes X, Z. Its movement starts and ends with the remaining path axes. However, the velocity cannot be greater than the defined limit value.

If the axis is programmed in a separate block with G1, it will traverse with the active feedrate F. In case of a rotary axis, the unit for F is degrees/min with G94, or degrees/spindle revolution with G95.

The offsets for this axis can be set (G54 ... G57) and programmed (TRANS, ATRANS).

Programming example

Supposed the 4th axis is a rotary axis with axis identifier A:

```
N5 G94          ; F in mm/min or degrees/min
N10 G0 X10 Z30 A45 ; traversing along X-Z path at rapid traverse, A at the same time
N20 G1 X12 Z33 A60 F400 ; traversing along X-Z path at 400mm/min, A at the same time
N30 G1 A90 F3000   ; axis A traverses alone to the 90 degrees position at a
                   ; traversing rate of 3,000 degrees/min
```


Special statements for rotary axes: DC, ACP, ACN

e.g., for rotary axis A:

A=DC(...) ; absolute data input, direct position approach (using the shortest possible way)

A=ACP(...) ; absolute data input, position approach in the positive direction

A=ACN(...) ; absolute data input, position approach in the negative direction

Example:

N10 A=ACP(55.7) ; approach absolute position 55.7 degrees in the positive direction

8.3.18 Dwell Time: G4**Functionality**

You can interrupt the program execution for a defined time by inserting a separate block between two NC blocks using G4, e.g. for relief cutting.

The words containing F... or S... are only used for this block for time specification. A previously programmed feed F and a previously programmed spindle speed S remain stored.

Programming

G4 F... ;dwell time in seconds

G4 S... dwell time in spindle revolutions

Programming example

N5 G1 F3.8 Z-50 S300 M3 ;feed F, spindle speed S

N10 G4 F2.5 ;dwell time 2.5 s

N20 Z70

N30 G4 S30 ;dwelling for 30 spindle revolutions,
corresponds to S=300 rpm and 100 %
speed override: t=0.1 min

N40 X... ;feed and spindle speed are still
effective

Note

G4 S.. is only possible in conjunction with a controlled spindle (if the speed is also programmed via S...).

8.3.19 Travel to fixed stop

Functionality

This function is an option and available as of SW 2.0.

Using the function "Travel to fixed stop" (FXS = Fixed Stop), it is possible to build up defined forces required for the clamping of workpieces, such as they are required for quills and grippers. Furthermore, this function can also be used to approach mechanical reference points. With a sufficiently reduced torque, simple measuring processes are also possible without a probe connected.

Programming

```
FXS[axis]=1           ; Select travel to fixed stop
FXS[axis]=0           ; Deselect travel to fixed stop
FXST[axis]=...       ; Clamping torque, specification in % of the max. torque of the drive
FXSW[axis]=...       ; width of the window for monitoring of traveling to fixed stop in mm/deg.
```

Note: The **machine axis identifier** is preferably written as the axis identifier, e.g.: X1. Writing the channel axis identifier (e.g.: X) is only permissible, e.g. if no coordinate rotation is active and this axis is assigned directly to a machine axis.

The commands are modal. The distance to be traversed and the selection of the function FXS[axis]=1 must be programmed in a **separate block**.

Programming example - selection

```
N10 G1 G94 ...
N100 X250 Z100 F100 FXS[Z1]=1 FXST[Z1]=12.3 FXSW[Z1]=2
      ; FXS function selected for machine axis Z1,
      clamping torque 12.3 %,
      width of the window 2 mm
```

Notes

- When selecting the function, make sure that the fixed stop is between starting and target position.
- Torque (FXST[]=) and window width (FXSW[]=) may be specified optionally. If they are not written, the value of the existing setting data are used. If there are any programmed values, they are accepted into the setting data. First, the setting data are loaded with values from the machine data. FXST[]=... or FXSW[]=... can be changed in the program at any time. The changes come into effect prior to any traversing motions programmed in the block.




Fig. 8-26 Example for traveling to fixed stop: The quill is pressed onto the workpiece

Further programming examples

N10 G1 G94 ...

N20 X250 Z100 F100 FXS[X1]=1 ; FXS selected for machine axis X1
Clamping torque and window width as specified in the SDs

N20 Y250 Z100 F100 FXS[X1]=1 FXST[X1]=12.3

; FXS selected for machine axis X1
Clamping torque 12.3 %, window width as specified in the SDs

N20 X250 Y100 F100 FXS[X1]=1 FXST[X1]=2

; FXS selected for machine axis X1 FXS
Clamping torque 12.3%, window width 2 mm

N20 X250 Z100 F100 FXS[X1]=1 FXSW[X1]=2

; FXS selected for machine axis X1,
clamping torque as specified in the SD, window width 2 mm

Fixed stop reached

After the fixed stop has been reached,

- the distance to go is deleted and the position setpoint is corrected accordingly,
- the driving torque increases up to the programmed limit value FXST[]=... or to the value specified in the SD, then remaining constant,
- the fixed-stop monitoring within the given window width becomes active (FXSW[]=... or value specified in the SD).

Deselecting the function

Deselecting the function results in a preprocessing stop. The block that contains FXS[X1]=0 must contain traversing motions.

Example:

N200 G1 G94 X200 Y400 F200 FXS[X1] = 0 ;The X1 axis is retracted to the position
X= 200 mm.

Important

The traversing motion to the retraction position must lead away from the fixed stop; otherwise, the fixed stop or the machine may be damaged.

The block change is carried out after the retraction position has been reached. If no retraction position is specified, the block change is carried out immediately after disabling the torque limitation.

Further notes

- "Measuring with deletion of the distance to go" (command "MEAS") and "Travel to fixed stop" cannot be programmed in the same block.
- No axis-specific contour monitoring is carried out during "Traveling to fixed stop".
- If the torque limit is reduced too far, the axis may no longer follow the setpoint specification, the position controller will activate the limiting and the contour deviation will increase. In this operating state, sudden motions may occur due to an increased torque limit. To make sure that the axis may still follow, make sure that the contour deviation is not greater than with unlimited torque.
- Appropriate machine data are provided to define a new torque limit to prevent the torque limit from being set suddenly (e.g. when pressing the quill onto the workpiece).

System variable for the status: \$AA_FXS[*axis*]

This system variable delivers the status of "Traveling to fixed stop" for the specified axis:

- Value =0: Axis is not at the stop
1. The stop was approached successfully
(axis is in fixed-stop monitoring window)
 - 2: Fixed-stop approach was not successful (axis is not at the stop)
 - 3: Travel to fixed stop activated
 - 4: Stop was recognized
 - 5: Travel to fixed stop will be deselected. The deselection is not yet completed.

The interrogation of the system variable in the part program triggers a preprocessing stop.

With the SINUMERIK 802D, only the static states before selection/deselection may be acquired.

Alarm suppression

The output of the following alarms may be suppressed via machine data:

- 20091 "Fixed stop not reached"
- 20094 "Fixed stop broken"

References: "Description of Functions", Section "Travel to Fixed Stop"

8.4 Spindle Motions

8.4.1 Spindle Speed S; Directions of Rotation

Functionality

The speed of the spindle is programmed in revolutions per minute under the address S provided the machine has a controlled spindle.

The direction of rotation and the beginning or the end of the movement are defined using M commands (see also Section 8.7 "Miscellaneous Function M").

| | |
|----|-------------------------|
| M3 | CW rotation of spindle |
| M4 | CCW rotation of spindle |
| M5 | Spindle Stop |

Note: For integer S values, the decimal point may be omitted, e.g. S270.

Information

If you program M3 or M4 in a **block with axis movements**, the M commands come into effect prior to the axis movements.

Default setting: The axis movements start only if the controlled spindle has accelerated (M3, M4). M5 is also output before the axis movement starts. The axes, however, will not wait until the spindle has stopped. The spindle is stopped with program end or RESET.

At program start, spindle speed zero (S0) is active.

Note: Other settings can be configured via the machine data.

Programming example

```

N10 G1 X70 Z20 F3 S270 M3      ;prior to traversing the axes X, Z, the
                                spindle accelerates in CW direction to 270 rpm
...
N80 S450 ...                  ;speed change
...
N170 G0 Z180 M5               ;Z movement in the block, spindle stop

```

8.4.2 Spindle Speed Limiting: G25, G26

Functionality

If you program G25 or G26 and enter the speed limit value at spindle address S, you can limit the limit values usually applicable to a controlled spindle. This will at the same time overwrite the values entered in the setting data.

G25 and G26 each require a separate block. Any values for the speed S programmed previously remain stored.

Programming

| | |
|----------|-------------------------------|
| G25 S... | ;lower spindle speed limiting |
| G26 S... | ;upper spindle speed limiting |

Information

The uppermost limits of the spindle speed are set in machine data. Further setting data for limiting can be entered from the operator panel.

For the G96 function - constant cutting speed - an additional upper limit can be entered/programmed.

Programming example

```
N10 G25 S12           ;lower spindle limit speed : 12 rpm
N20 G26 S700         ;upper spindle limit speed : 700 rpm
```

8.4.3 Positioning the Spindle: SPOS**Functionality**

Prerequisite: The spindle must be technically designed for position-control mode.

The function SPOS= can be used to position the spindle on a certain angle position. The spindle is fixed in position by the position control.

The **velocity** of the positioning process is stored in machine data.

With SPOS=*value* from the M3/M4 movement, the respective **direction of rotation** is kept up to the end of positioning. When positioning from standstill, the position is approached on the shortest way. In this case, the direction results from the corresponding start and end positions.

Exception: first movement of spindle, i.e. if the measuring system is not yet synchronized. In this case, the direction is defined in machine data.

It is also possible to specify other movements (as with rotary axes) for the spindle using SPOS=ACP(...), SPOS=ACN(...), ... (see Section "3rd and 4th Axes +

The movement of the spindle is parallel to any axis movements programmed in the same block. The block is completed if both movements are completed.

Programming

```
SPOS =.....      ; absolute position: 0 ... <360 degrees
SPOS=ACP(...)    ; absolute data input, position approach in the positive direction
SPOS=ACN(...)    ; absolute data input, position approach in the positive direction
SPOS=IC(...)     ; incremental data input, the sign defines the traversing direction
SPOS=DC(...)     ; absolute data input, direct position approach (using the shortest possible way)
```

Programming example

```
N10 SPOS=14.3      ; spindle position 14.3 degrees
...
N80 G0 X89 Z300 SPOS=25.6 ;positioning of spindle with axis movements. The block is
                           only completed if all movements are completed.
N81 X200 Z300      ;Block N81 will only start if the spindle position programmed
                           in N80 is reached.
```

8.4.4 Gear stages

Function

Up to 5 gear stages can be configured for a spindle for speed / torque adaptation. The gear stage is selected in the program via M commands (see Section 8.7 "Miscellaneous function M"):

- M40 ; automatic gear stage selection
- M41 to M45 ; gear stages 1 to 5

8.4.5 2nd spindle

With the SINUMERIK 802D, with SW 2.0 and higher, a 2nd spindle is provided. Not with 802D-bl.

Function

With SW 2.0 and higher, the kinematic transformation functions TRANSMIT and TRACYL are possible for the milling machining on turning machines. These functions require a 2nd spindle for the driven milling tool.

When using these functions, the main spindle is operated as a rotary axis (see Section 8.14).

Master spindle

The master spindle results in various functions which are only possible with this spindle:

- G95 ; Revolutionary feedrate
- G96, G97 ; Constant cutting rate
- LIMS ; Upper limit speed with G96, G97
- G33, G34, G35, G331, G332 ; Thread cutting, thread interpolation
- M3, M4, M5, S... ; Simple specifications for direction of rotation, stop and speed

The master spindle is defined by configuration (machine data). As a rule, the main spindle (spindle 1) is the master spindle. It is also possible to define a different spindle as master spindle in the program:

- SETMS(n) ; Spindle n (= 1 or 2) is master spindle as of now.

Switching back is also possible via:

- SETMS ; Now, the configured master spindle is master spindle again, or
- SETMS(1) ; Spindle 1 is master spindle again.

The definition of the master spindle, which was changed in the program, will only apply to the end of the program / program abortion. Then, the configured master spindle is active again.

Programming via the spindle number

Some spindle functions can also be selected via the spindle number:

- S1=..., S2=... ; Spindle speed for spindle 1 or 2
- M1=3, M1=4, M1=5 ; Specifications for direction of rotation, stop for spindle 1
- M2=3, M2=4, M2=5 ; Specifications for direction of rotation, stop for spindle 2
- M1=40, ..., M1=45 ; Gear stages for spindle 1 (if installed)
- M2=40, ..., M2=45 ; Gear stages for spindle 2 (if installed)
- SPOS[n] ; Position spindle n
- SPI (n) ; Converts spindle number n to axis identifier, e.g. "SP1" or "CC"
; n must be a valid spindle number (1 or 2)
; As regards their functions, spindle identifier SPI(n) and Sn are identical.
- P_S[n] ; Speed of spindle n, which was last programmed
- \$AA_S[n] ; Actual speed of spindle n
- \$P_SDIR[n] ; Direction of spindle n, which was last programmed
- \$AC_SDIR[n] ; Current direction of rotation spindle n

2 spindles installed

Using the system variable, it is possible to interrogate the following in the program:

- \$P_NUM_SPINDLES ; Number of configured spindles (channel)
- \$P_MSNUM ; Number of the programmed master spindle
- \$AC_MSNUM ; Number of the active master spindle

8.5 Special Turning Functions

8.5.1 Constant Cutting Speed: G96, G97

Functionality

Prerequisite: This function requires a controlled spindle.

With the function G96 enabled, the spindle speed will be adapted to the diameter of the work-piece currently machined (face axis) such that a programmed cutting speed S at the tool edge remains constant (spindle speed by diameter = constant).

From the block containing G96, the S word will be interpreted as the cutting speed. G96 is modally active until it is disabled by another G function of the group (G94, G95, G97).

Programming

G96 S... LIMS=... F... ;constant cutting speed ON
G97 ;constant cutting speed OFF

S ;cutting speed, unit m/min
LIMS= ;upper limit speed of spindle; only active with G96
F ;feed in mm/rev. - as with G95

Note:

If previously G94 was active instead of G95, a new suitable F value must be programmed!




Fig. 8-27 Constant cutting speed G96

Traversing at rapid traverse

When traversing at rapid traverse G0, the speed is not changed.

Exception: If the contour is approached at rapid traverse and the next following block contains either of the interpolation types G1 or G2, G3, CIP, CT (contour block), the speed for the contour block is already set in the approach block using G0.

Upper limit speed LIMS=

When machining from large to small diameters, the spindle speed may increase substantially. In this case, it is recommended to specify the upper spindle speed limitation LIMS=... ; LIMS only applies with G96 and G97.

If LIMS=... is programmed, the value entered in the setting data is overwritten.

The upper limit speed either programmed via G26 or defined in the machine data cannot be exceeded if LIMS= is programmed.

Disabling constant cutting speed: G97

The function "Constant cutting speed" is disabled using G97. If G97 is enabled, any **S word** programmed will be interpreted again as a **spindle speed** specified in revolutions per minute. If no new S word is programmed, the spindle will rotate at the speed last determined with the G96 function active.

Programming example

| | |
|------------------------|---|
| N10 ... M3 | ;direction of rotation of spindle |
| N20 G96 S120 LIMS=2500 | ;constant cutting speed ON, 120 m/min, limit speed 2,500 rpm |
| N30 G0 X150 | ;no speed change, because of block N31 with G0 |
| N31 X50 Z... | ;no speed change, because of block N32 with G0 |
| N32 X40 | ;contour approach; new speed will automatically be set such, as required for the start of block N40 |
| N40 G1 F0.2 X32 Z... | ;Feed 0.2 mm/rev. |
| ... | |
| N180 G97 X... Z... | ;disable constant cutting speed |
| N190 S... | ;new spindle speed, rpm |

Information

The function G96 can also be switched off using either G94 or G95 (same G group). In this case, the spindle speed S last **programmed** will also be effective for the further sequence of machining if no new S word is programmed.

The programmable offset: TRANS or ATRANS (see Chapter of the same name) should not or only with small values be applied to the transversal axis X. The workpiece zero point should be in the turning center. Only thus the exact function of G96 is guaranteed.

8.5.2 Rounding, Chamfer

Functionality

You can insert the elements chamfer or rounding into any contour corner.

The corresponding statement CHF= ... or RND=... is programmed in the block containing the axis movements leading to the corner.

Programming

CHF=... ;Insert chamfer; value: length of chamfer
 RND=... ;Insert rounding; value: radius of rounding

Chamfer CHF=

A linear section is inserted between **linear and circle contours** in any combination. The edge will be broken.




Fig. 8-28 Inserting a chamfer between two straight lines (example)

Programming example for chamfer

N10 G1 Z... CHF=5 ;Insert 5mm chamfer
 N20 X... Z...

Rounding RND=

A circular contour element is inserted between **linear and circle contours** in any combination with tangential connection.




Fig. 8-29 Inserting roundings (examples)

Programming example for rounding

```

N10 G1 Z... RND=8           ;Insert rounding with 8 mm radius
N20 X... Z...
...
N50 G1 Z... RND=7.3       ;Insert radius with 7.3 mm radius
N60 G3 X... Z...
    
```

Information

If the contour length programmed in a block involved is not sufficient, the value programmed for chamfer and rounding will be reduced automatically.
 No chamfer/rounding will be inserted if more than three blocks are programmed, which do not contain information for traversing in the plane.

8.5.3 Contour Definition Programming

Functionality

If direct end point specifications for the contour cannot be seen from the machining drawing, it is also possible to use angle specifications for the straight line determination. You can insert the elements chamfer or rounding into any contour corner. The corresponding statement CHR= ... or RND=... is programmed in the block containing the axis movements leading to the corner.

Programming of the contour definition can be used in blocks with G0 or G1.
 Theoretically, you can link as many straight line blocks as you want and insert a rounding or a chamfer between them. When doing so, each straight line must be unambiguously defined by point and/or angle specifications.

Programming

```

ANG=...           ;angle specification for defining a straight line
CHR=...          ;insert chamfer; value: side length of chamfer
RND=...          ;insert rounding; value: radius of rounding
    
```

Angle ANG=

If for a straight line only one end position coordinate of the plane is known or, in case of contours over several blocks, the entire end point, an angle specification can be used to define the straight path section unambiguously. The angle is always referred to the Z axis (normal case: G18 active). Positive angles are oriented in the counter-clockwise direction.

| Contour | Programming |
|---------|--|
| | End point in N20 not fully known N10 G1 X1 Z1 N20 X2 ANG=... or: N10 G1 X1 Z1 N20 Z2 ANG=... The values are only symbolically. |

Fig. 8-30 Angle specification to define a straight line

Rounding RND=

Another circle contour element is inserted in the corner between two linear blocks with tangential connection (see also Fig. 8-28).

Chamfer CHR=

Another linear contour element (chamfer) is inserted in the corner between two linear blocks. The programmed angle is the **leg length** of the chamfer.

| Contour | Programming |
|---------|---|
| | Insert chamfer with leg length, e.g. 5 mm: N10 G1 Z... CHR=5 N20 X... Z.. |

Fig. 8-31 Inserting a chamfer with CHR

Information

- If Radius and chamfer are programmed in a block, only the radius is inserted, independently of the programming order.
- In addition to the contour definition programming, there is also the chamfer specification with CHF=. In this case, the value constitutes the chamfer length instead of the leg length with CHR=.

| Contour | Programming |
|---------|--|
| | <p>End point in N20 not known</p> <pre>N10 G1 X1 Z1 N20 ANG=...1 N30 X3 Z3 ANG=...2</pre> <p>The values are only symbolically.</p> |
| | <p>End point in N20 unknown, insert rounding:</p> <pre>N10 G1 X1 Z1 N20 ANG=...1 RND=... N30 X3 Z3 ANG=...2</pre> <p>analogously</p> <p>Insert chamfer:</p> <pre>N10 G1 X1 Z1 N20 ANG=...1 CHR=... N30 X3 Z3 ANG=...2</pre> |
| | <p>End point in N20 unknown, insert rounding:</p> <pre>N10 G1 X1 Z1 N20 X2 Z2 RND=... N30 X3 Z3</pre> <p>analogously</p> <p>Insert chamfer:</p> <pre>N10 G1 X1 Z1 N20 X2 Z2 CHR=... N30 X3 Z3</pre> |
| | <p>End point in N20 unknown, insert roundings:</p> <pre>N10 G1 X1 Z1 N20 ANG=...1 RND=...1 N30 X3 Z3 ANG=...2 RND=...2 N40 X4 Z4</pre> <p>analogously</p> <p>Insert chamfer:</p> <pre>N10 G1 X1 Z1 N20 ANG=...1 CHR=...1 N30 X3 Z3 ANG=...2 CHR=...2 N40 X4 Z4</pre> |

Fig. 8-32 Examples for multi-block contours

8.6 Tool and Tool Compensation

8.6.1 General Notes

Functionality

When creating programs for workpiece machining, you do not need to take into account tool length or cutter radius. Program the workpiece dimensions directly, e.g. using the drawing.

Enter the tool data separately in a special data area.

Simply call the required tool with its offset data in the program and enable the tool radius compensation if necessary. The control system will carry out the path corrections required to create the workpiece described.




Fig. 8-33 Machining of a workpiece with different tool dimensions

8.6.2 Tool T

Functionality

Programming of the T word will select the tool. Whether it is a tool change or only a preselection is defined in machine data:

- Tool change (tool call) is carried out directly using the T word (e.g. as usual for tool revolvers on turning machines) or
- the change is carried out after preselection using the T word and the miscellaneous function **M6** (see also Section 8.7 "Miscellaneous Functions M").

Note:

If a certain tool has been activated, it remains stored as the active tool even beyond program end and even after POWER ON.

If you change a tool manually, you must also enter the change into the control system so that the control system 'knows' the appropriate tool. For example, you can start a block in MDA mode using the new T word.

Programming

T... ;tool number: 1 ... 32 000

Note: A maximum of **32** tools can be stored in the CNC at a time.

Programming example

```

Tool change without M6:
N10 T1          ;tool 1
...
N70 T588       ;tool 588
    
```

8.6.3 Tool Offset Number D

Functionality

A tool can be assigned 1 to 9 data fields each containing different tool offset data records (for several cutting edges). If a special cutting edge is necessary, it can be programmed with D and an appropriate number.

If no D word is programmed, D1 will be used **by default**.

D0 will **disable** the tool offsets.

Programming

```

D...          ;Tool offset numbers 1 ... 9, D0: no offsets effective !
    
```

Note:A maximum of **64** data fields containing tool offset data records can be stored in the control system at a time.




Fig. 8-34 Assignment of tool offset numbers to the tool (example)

Information

Tool length compensations come into effect immediately if the tool is active; if no D number has been programmed, the values of D1 are used.

The compensation is achieved with the first programmed traversing of the length compensation axis.

In addition, it is necessary to enable **tool radius compensation** using G41/G42.

Programming example

```

Tool change:
N10 T1          ;tool 1 is activated with the related D1
N11 G0 X... Z... ;the length offset compensation is superimposed
N50 T4 D2       ;change tool 4; D2 of T4 is active
...
N70 G0 Z... D1  ;D1 for tool 4 is active; only cutting edge changed
    
```


Contents of tool offset memory

- Geometric quantities: Length, radius
 These consist of various components (geometry, wear). The control system uses these components and calculates a resulting quantity (e.g. total length 1, total radius). The appropriate total dimension comes into effect when activating the offset memory. How these values are taken into account in the axes is determined by the tool type and by the commands G17, G18, G19 (see the following illustrations).
- Tool type
 The tool type determines which geometry specifications are required and how these are taken into account (drill or turning tool or milling tool).
- Tool point direction
 With the tool type "Turning tool", the tool tip position must additionally be specified.

The illustrations below show which tool parameters have to be used for which tool type.




Fig. 8-35 Required length compensation values for turning tools




Fig. 8-36 Turning tool with two edges - length compensation




Fig. 8-37 Required compensation data for turning tools with tool radius compensation




Fig. 8-38 Required compensation data for drill

Center hole

To make a center hole, switch to G17. The length compensation for the drill will thus be effective in the Z axis. If drilling has been completed, use G18 to switch back to normal compensation for turning tools.

Example:

```
N10 T...           ;drill
N20 G17 G1 F... Z... ;length compensation is effective in Z axis
N30 Z...
N40 G18 ....      ;drilling completed
```




Fig. 8-39 Drilling a center hole

8.6.4 Selection of Tool Radius Compensation: G41, G42

Functionality

A tool with a corresponding D number must be active. The tool radius compensation (cutter radius compensation) is enabled by G41/G42. The control system will thus automatically calculate the required equidistant tool paths for the programmed contour corresponding to the radius currently active.

G18 must be active.




Fig. 8-40 Tool radius compensation (cutter radius compensation)

Programming

G41 X... Z... ;tool radius compensation left of contour
 G42 X... Z... ;tool radius compensation right of contour

Note: The selection can only be carried out with linear interpolation (G0, G1).
 Program both axes. If you specify only one axis, the second axis will be added automatically by the value programmed last.




Fig. 8-41 Compensation right / left of the contour

Start compensation

The tool approaches the contour along a straight line and positions vertically to the path tangent in the start point of the contour.
 Select the start point such that collision-free traversing is guaranteed!




Fig. 8-42 Start of tool radius compensation using the example G42, edge position = 3

Information

The block containing G41/G42 is usually followed by the first block containing the workpiece contour. The contour description, however, may be interrupted by an intermediate block, which does not contain any information on the contour path, e.g. only an M command.

Programming example

```

N10 T... F...
N15 X... Z...           ;P0 - start point
N20 G1 G42 X... Z...   ;selection right of the contour, P1
N30 X... Z...           ;start contour; circle or straight line

```

8.6.5 Corner Behavior: G450, G451**Functionality**

The functions G450 and G451 can be used to set the behavior in case of a non-continuous transition from one contour element to another contour element (corner behavior) with G41/G42 enabled.

Internal and external corners are recognized by the control system itself. With internal corners, the intersection point of the equidistant path is approached in all cases.

Programming

```

G450           ;transition circle
G451           ;intersection point

```




Fig. 8-43 Corner behavior at an external corner




Fig. 8-44 Corner behavior at an internal corner

Transition circle G450

The tool center point traverses round the workpiece external corner with the tool radius along an arc.

From the point of view of data technology, the transition circle belongs to the next block with traversing movements, e.g. as far as the feed value is concerned.

Intersection point G451

With G451 - intersection point of the equidistants -, the point (intersection point) is approached, which results from the center point paths of the tool (circle or straight line).

8.6.6 Tool Radius Compensation OFF: G40

Functionality

To cancel compensation mode G41/G42, G40 is used. This function is also the default position when the program starts.

The tool completes the block **prior to G40** in normal position (compensation vector vertically to the tangent at the end point), irrespective of the leaving angle.

If G40 is active, the reference point is the tool tip. When canceled, the tool tips will thus approach the programmed point.

Always select the end point of the G40 block such that collision-free traversing is guaranteed!

Programming

G40 X... Z... ;tool radius compensation OFF

Note: Compensation mode can only be canceled with linear interpolation (G0, G1).

Program both axes. If you specify only one axis, the second axis will be added automatically by the value programmed last.




Fig. 8-45 Quitting tool radius compensation with G40 using the example of G42, edge position = 3

Programming example

```

...
N100 X... Z... ;last block of contour; circle or straight line, P1
N110 G40 G1 X... Z... ;tool radius compensation OFF, P2
    
```

8.6.7 Special Cases of Tool Radius Compensation

Change of compensation direction

The compensation direction G41 <-> G42 can be changed without programming G40. The last block that contains the old compensation direction ends with the normal position of the compensation vector at the end point. The new compensation direction is carried out as a compensation start (normal position at start point).

Repetition G41, G41 or G42, G42

The same contour can be programmed once more, without programming G40. The last block prior to the new compensation call ends with the normal position of the compensation vector at the end point. The new compensation is carried out as a compensation start (behavior as described for the change of the compensation direction).

Change of tool offset number D

The offset number D can be changed in compensation mode. In this case, a changed tool radius starts to come into effect already in the beginning of the block that contains the new D number. Its full change is only achieved at the end of the block. This means that the change is traversed continuously over the entire block; this also applies to circular interpolation.

Cancellation of compensation by M2

If compensation mode is canceled by M2 (end of program) without programming the command G40, the last block will end with the coordinates in normal position of the compensation vector. **No** compensatory movement is carried out. The program will end at this tool position.

Critical machining cases

When programming, pay special attention to cases where the contour path of internal corners is less than the tool radius or, in case of two internal corners following each other, where the contour path is less than the diameter.

Such cases should be avoided!

Also check over several blocks that no "bottle necks" are contained in the contour.

To carry out a test/dry run, use the largest tool radius offered to choose from.

Acute contour angles

If very acute rearward elbows occur in the contour with intersection point G451 active, the control system will automatically switch to transition circle. This will avoid long lost idle motions.

8.6.8 Example of Tool Radius Compensation




Fig. 8-46 Example of tool radius compensation; cutter edge radius enlarged

Programming example

```

N1                ;contour cut
N2 T1             ;tool 1 with offset D1
N10 DIAMON F... S... M... ;radius input; technological values
N15 G54 G0 G90 X100 Z15
N20 X0 Z6
N30 G1 G42 G451 X0 Z0 ;start compensation mode
N40 G91 X20 CHF=(5* 1.1223) ;insert chamfer, 30 degrees
N50 Z-25
N60 X10 Z-30
N70 Z-8
N80 G3 X20 Z-20 CR=20
N90 G1 Z-20
N95 X5
N100 Z-25
N110 G40 G0 G90 X100 ;quit compensation mode
N120 M2
    
```


8.6.9 Using milling tools

Function

The use of the kinematic transformation functions TRANSMIT and TRACYL is connected with the use of milling tools on turning machines (see Section 8.14).

The effect of the tool compensation when working with milling tools is different to that with turning tools.




Fig. 8-47 Effect of the tool compensations with tool type 'milling tool'




Fig. 8-48 Effect of the tool length compensations, three-dimensionally (special case)

Cutter radius compensation G41, G42




Fig. 8-49 Cutter radius compensation to the right / left of the contour

Starting the correction

The tool approaches the contour along a straight line and positions itself vertically to the path tangent at the contour starting point.

Select the starting point such that collision-free traversing is guaranteed.




Fig. 8-50 Starting the cutter radius compensation using the example with G42

Information

In all the other concerns, the behavior of the cutter radius compensation is as that of the radius compensation with the tuning tool (see Sections 8.6.5 through 8.6.7).

For detailed information, please refer to

References: "Operation and Programming - Milling" SINUMERIK 802D

8.6.10 Tool compensation special cases

With the SINUMERIK 802D with SW 2.0 and higher, the following special cases are available for the tool compensation.

Influence of setting data

Using the setting data specified in the following, the operator / programmer may influence how the **length compensation values** of the tool used are taken into account:

- SD 42940: TOOL_LENGTH_CONST
(assignment of the tool length components to the geometry axes)
- SD 42950: TOOL_LENGTH_TYPE
(assignment of the tool length components irrespective of the tool type)

Note: The changed setting data come into effect with the next cutting edge selection.

Examples

With SD 42950: TOOL_LENGTH_TYPE =2,
a milling tool with length compensation is taken into account as a turning tool:

- G17: Length 1 in the Y axis, length 2 in the X axis
- G18: Length 1 in the X axis, length 2 in the Z axis
- G19: Length 1 in the Z axis, length 2 in the Y axis

With SD 42940: TOOL_LENGTH_CONST =18,
a length assignment is carried out in all planes G17 ... G19 in the same manner as with G18:

- Length 1 in the X axis, length 2 in the Z axis

Setting data in the program

Apart from defining setting data via the operation, it is also possible to write them in the program.

Example:

```
N10 $MC_TOOL_LENGTH_TYPE=2  
N20 $MC_TOOL_LENGTH_CONST=18
```

Information

For detailed information on tool compensation special cases, please refer to

References: Description of Functions, Section "Tool compensation special cases"

8.7 Miscellaneous Function M

Functionality

The miscellaneous function M can be used, for example, to initiate switching actions, such as "Coolant ON / OFF", and other functions.

A minor part of the M functions is assigned a fixed functionality by the control manufacturer. The remaining part is available to the machine manufacturer for free use.

Note:

For an overview of the M miscellaneous functions used and reserved in the control system, please refer to the Section "List of Statements".

Programming

M... ; max. 5 M functions per block can be programmed

Activation

Activation in blocks with axis movements:

If the functions **M0, M1 and M2** are contained in a block with traversing movements of the axes, these M functions come into effect **after the traversing movements**.

The functions **M3, M4 and M5** are output to the internal PLC **prior to the traversing movements**. The axis movements start only if the controlled spindle has accelerated at M3, M4. With M5, however, the axes will not wait until the spindle has come to a standstill; the axis movements will start already prior to the standstill.

The remaining M functions are output to the internal PLC **with** the traversing movements.

If you want to program an M function deliberately prior to or after an axis movement, then insert a separate block with this M function. **Please take into account:** This block interrupts G64 continuous-path control mode and generates exact stop!

Programming example

```
N10 S...
N20 X... M3           ;M function in a block with axis movement
                       Spindle accelerates prior to movement of X axis
N180 M78 M67 M10 M12 M37 ;max. 5 M functions per block
```

Note

Apart from M and H functions, T, D and S functions can also be transferred to the PLC. A total of 10 of such function outputs are possible per block.

Information

With SW 2.0 and higher, 2 spindles are possible. This provides an extended programming possibility for M commands - only for the spindle:

```
M1=3, M1=4, M1=5, M1=40, ... ; M3, M4, M5, M40, ... for spindle 1
M2=3, M2=4, M2=5, M2=40, ... ; M3, M4, M5, M40, ... for spindle 2
```

8.8 H function

Functionality

The H functions can be used to transfer floating-point data from the program to the PLC (of the type, such as arithmetic parameters, see Section "Arithmetic Parameters R").

The meanings of the values for a certain H function are defined by the machine manufacturer.

Programming

H0=... to H9999=... max. 3 H functions per block

Programming example

```
N10 H1=1.987 H2=978.123 H3=4                      ; max. 3 H functions per block
N20 G0 X71.3 H99=-8978.234                      ; with axis movements in the block
N30 H5                                              ; analogously to H0=5.0
```

Note

Apart from M and H functions, T, D and S functions can also be transferred to the PLC. A total of 10 of such function outputs per block are possible.

8.9 Arithmetic parameters R, LUD and PLC variables

8.9.1 Arithmetic parameters R

Functionality

If an NC program is desired to be applicable not only for values defined once or if you must calculate any values, then use the arithmetic parameters. You can have calculated any required values by the control system while the program is running, or you can have set them by the control system.

Another possibility is to set arithmetic parameters by operation. If the arithmetic parameters are already assigned values, they can be assigned different NC addresses in the program, which should be flexible in their values.

Programming

R0=... to R299=...

Value assignment

The arithmetic parameters can be assigned values in the following range:

$\pm(0.000\ 0001 \dots 9999\ 9999)$
(8 decimal places and sign and decimal point).

For integer values, the decimal point can be omitted. A positive sign can always be omitted.

Example:

R0=3.5678 R1=-37.3 R2=2 R3=-7 R4=-45678.123

The **exponential notation** can be used to assign an extended range of figures:

$\pm (10^{-300} \dots 10^{+300})$.

The value of the exponent is written after the **EX** character; max. number of characters: 10 (including signs and decimal point).

Range of values for EX: -300 to +300

Example:

R0=-0.1EX-5 ;Meaning: R0 = -0.000 001

R1=1.874EX8 ;Meaning: R1 = 187 400 000

Note: Several assignments per block are permitted, including the assignment of arithmetic terms.

Assignment to other addresses

The flexibility of an NC program is based on the fact that you assign other NC addresses these arithmetic parameters or arithmetic terms using arithmetic parameters. It is possible to assign all addresses values, arithmetic terms or arithmetic parameters, **with the following exception: addresses N, G and L.**

When doing the assignment, the address character must be followed by the character "=" . Assignments with a negative sign are possible.

If assignments are to be made for axis addresses (traversing commands), a separate block is required.

Example:

N10 G0 X=R2 ;assignment to X axis

Arithmetic operations/functions

When using the operands/arithmetic functions, make sure that the usual mathematical notation is observed. Any priorities in the processing are defined by round brackets. Otherwise, the general rule whereby multiplication and division are performed before addition and subtraction will apply.

For the trigonometric functions, specification in degrees should be used.

Admissible arithmetic functions: see Section "List of Statements"

Programming example: R parameters

N10 R1= R1+1 ;the new R1 results from the old
R1 plus 1

N20 R1=R2+R3 R4=R5-R6 R7=R8·R9 R10=R11/R12

N30 R13=SIN(25.3) ;R13 results in a sine of 25.3 degrees

N40 R14=R1·R2+R3 ;multiplication and division before addition and subtraction
R14=(R1·R2)+R3

N50 R14=R3+R2·R1 ;result as block N40

N60 R15=SQRT(R1·R1+R2·R2) ; meaning: $R15 = \sqrt{R1^2 + R2^2}$

Programming example: Assignment to axes

N10 G1 G91 X=R1 Z=R2 F3

N20 Z=R3

N30 X=-R4

N40 Z=-R5

...

8.9.2 Local user data (LUD)

Functionality

The user / programmer may define his/her own variables of different data types in a program (LUD = Local User Data). These variables exist only in the program in which they were defined. The variables are defined immediately in the beginning of the program and can be linked with a value assignment. Otherwise, the initial value is zero.

The name of the variable can be defined by the programmer himself. The naming is subject to the following rules:

- maximum length 32 characters
- The first two characters must be letters; for the characters left, letters, underscore or digits can be used.
- Names that have already been used in the control system may not be used (NC addresses, keywords, names of programs, subroutines, etc.)

Programming

```

DEF BOOL varname1      ; Type Bool, values: TRUE (=1), FALSE (=0)
DEF CHAR varname2      ; TypeChar, 1 character in the ASCII code: "a", "b", ...
                        ; code numerical value: 0 ... 255
DEF INT varname3        ; Type Integer; integer values, 32-bit range of values:
                        ; -2 147 483 648 to +2 147 483 648 (decimal)
DEF REAL varname4      ; Type Real, natural number (as arithmetic parameter R),
                        ; Range of values: ±(0.000 0001 ... 9999 9999)
                        ; (8 decimals and sign and decimal points) or
                        ; Exponential notation: ± ( 10-300 ... 10+300 ).

```

Each type requires a separate program line. It is, however, possible to define several variables of the same type in a line.

Example:

```
DEF INT PVAR1, PVAR2, PVAR3=12, PVAR4      ; 4 variables of the type INT
```

Fields

In addition to individual variables, it is also possible to define one or two-dimensional fields of variables of these data types:

```

DEF INT PVAR5[n]        ; one-dimensional field of the type INT, n: integer
DEF INT PVAR6[n,m]      ; two-dimensional field of the type INT, n, m: integer

```

Example:

```
DEF INT PVAR7[3]        ; field with 3 elements of the type INT
```

Access to the individual field elements is granted in the program via the field index; each individual field element can be handled as an individual variable. The field index ranges from 0 to "less number of elements".

Example:

```
N10 PVAR7[2]=24          ; The third field element (with index 2) is assigned the value 24.
```

Value assignment for the field that contains a SET statement:

```
N20 PVAR5[2]=SET(1,2,3) ; From the 3rd field element, different values are assigned.
```


Value assignment for the field that contains a REP statement:

N20 PVAR7[4]=REP(2) ; From field element [4], all are assigned the same value, 2 in this case.

Number of LUDs

With the SINUMERIK 802D, max. 200 LUDs may be defined. Please note: The SIEMENS standard cycles also use LUDs and share this number with the user. Always keep a sufficient reserve when working with these cycles.

Note with regard to this display

There is no special display for LUDs. They would anyway only be visible during the runtime of the program.

For testing purposes, when creating the program, the LUDs may be assigned to the arithmetic parameters R and are thus visible via the arithmetic parameter display, but are converted into the REAL type.

Another possibility of displaying is offered in the STOP condition of the program via a message output:

MSG(" value VAR1: "<<PVAR1<<" value VAR2: ": "<<PVAR2) ; value of PVAR1, PVAR2
M0

8.9.3 Reading and writing PLC variables

Functionality

To provide fast data exchange between NC and PLC, there is a special data area in the PLC user interface, which has a length of 512 bytes. In this area, PLC data are agreed with a data type and a position offset. These agreed PLC variables can be written or read in the NC program.

To this end, special system variables are provided:

\$A_DBB[n] ; Data byte (8-bit value)
\$A_DBW[n] ; Data word (16-bit value)
\$A_DBD[n] ; Data double-word (32-bit value)
\$A_DBR[n] ; REAL data (32-bit value)

n stands for the position offset (from the beginning of the data area to the beginning of the variable) in bytes

Example:

R1=\$A_DBR[5] ; Reading of a REAL value, offset 5 (starting at byte 5 of the area)

Notes

- When reading variables, a preprocessing stop is generated (internal STOPRE).
- A maximum of 3 variables may be programmed at the same time (in one block).

8.10 Program Jumps

8.10.1 Jump Destination for Program Jumps

Functionality

A **label** or **block number** is used to mark blocks as a jump destination for program jumps. Program jumps provide branching of the program sequence.

Labels can be freely defined, but include a minimum of 2, max. of 8 letters or digits whereby **the first two characters must be letters** or underscores.

Labels are **completed by a colon** in the block used as the jump destination. They always stand at the beginning of the block. If in addition to the label a block number is provided, the label **follows the block number**.

Labels must be programmed unambiguously.

Programming example

| | |
|--------------------|---|
| N10 LABEL1: G1 X20 | ;LABEL1 is the label, jump destination |
| ... | |
| TR789: G0 X10 Z20 | ;TR789 is the label, jump destination |
| | - no block number exists |
| N100... | ;the block number can be the jump destination |
| ... | |

8.10.2 Unconditional Program Jumps

Functionality

NC programs execute their blocks in the order in which they have been allocated on writing.

The order of execution can be changed by inserting program jumps.

Jump destination can be a block with a **label** or with a **block number**. This block must be inside the program.

The unconditional jump instruction (GO TO statement) requires a separate block.

Programming

GOTOF *Label* ;jump forward (in the direction of the last block of the program)
 GOTOB *Label* ;jump backwards (in the direction of the first block of the program)

Label ;selected character sequence for label or block number




Fig. 8-51 Unconditional jumps (example)

8.10.3 Conditional Program Jumps

Functionality

After the **IF statement**, **jump conditions** are programmed. If the jump condition is not fulfilled (**value not zero**), the jump is carried out.

Jump destination can only be a block with a **label** or with a **block number**. This block must be inside the program.

Conditional jump instructions require a separate block. Several conditional jump instructions per block are possible.

If you use conditional program jumps, you may achieve a considerable program reduction.

Programming

IF *condition* GOTOF *Label* ;jump forward
 IF *condition* GOTOB *Label* ;jump backwards

GOTOF ;jump direction forward (in the direction of the last block of the program)
 GOTOB ;jump direction backwards (in the direction of the first block of the program)
Label ;selected character sequence for the label or block number
 IF ;initiation of jump condition
Condition ;arithmetic parameter, arithmetic term required to formulate the condition

Comparison operations

| Operands | Meaning |
|----------|--------------------------|
| = = | equal to |
| < > | unequal to |
| > | greater than |
| < | less than |
| > = | greater than or equal to |
| < = | less than or equal to |

The comparison operations are used to assist the formulation of a jump condition. It is also possible to compare arithmetic terms.

The result of comparing operations is either "fulfilled" or "not fulfilled". "Not fulfilled" is to be considered as zero.

Programming example for comparison operands

```

R1>1                ;R1 greater than 1
1 < R1              ;1 less than R1
R1<R2+R3            ;R1 less than R2 plus R3
R6>=SIN( R7*R7)    ;R6 greater than or equal to SIN (R7)2
    
```

Programming example

```

N10 IF R1 GOTOF LABEL1      ;if R1 is not zero, go to block with LABEL1
...
N90 LABEL1: ...
N100 IF R1>1 GOTOF LABEL2   ;if R1 is greater than 1, go to the block with LABEL2
...
N150 LABEL2: ...
...
N800 LABEL3: ...
...
N1000 IF R45==R7+1 GOTOB LABEL3; if R45 equal to R7 plus 1, go to the block
                               with LABEL3
...
several conditional jumps in the block:
N10 MA1: ...
...
N20 IF R1==1 GOTOB MA1 IF R1==2 GOTOF MA2 ...
...
N50 MA2: ...
    
```

Note: The jump is carried out at the first condition fulfilled.

8.10.4 Programming Example of Jumps

Task

Approaching points on a circle segment

| | | | |
|--------|------------------------------|-------|-------|
| Given: | Start angle: | 30° | in R1 |
| | Circle radius: | 32 mm | in R2 |
| | Distance of positions: | 10° | in R3 |
| | Number of points: | 11 | in R4 |
| | Circle center position in Z: | 50mm | in R5 |
| | Circle center position in X: | 20mm | in R6 |




Fig. 8-52 Approaching points on a circle segment

Programming example

```

N10 R1=30 R2=32 R3=10 R4=11 R5=50 R6=20 ;assignment of start values
N20 MA1: G0 Z=R2 *COS (R1)+R5 X=R2*SIN(R1)+R6
;calculation and assignment to axis addresses

N30 R1=R1+R3 R4= R4-1
N40 IF R4 > 0 GOTOB MA1
N50 M2

```

Explanation

The initial conditions are assigned to the corresponding arithmetic parameters in block N10. N20 is used for the calculation of the coordinates in X and Z and its processing.

In block N30, R1 is increased by the distance angle R3; R4 is decreased by 1. If R4 > 0, N20 is executed again; otherwise, N50 with end of program.

8.11 Subroutine Technique

8.11.1 General

Application

Generally, there is no difference between a main program and a subroutine.

Subroutines are used to store often recurring machining sequences, e.g. certain contour forms. This subroutine is called and executed in the main program when required.

One form of the subroutine is the **machining cycle**. Machining cycles contain generally applicable cases of machining (e.g. thread cutting, stock removal, etc.). By loading values using the intended arithmetic parameters, you can achieve an adaptation to your particular application (see Section "Machining Cycles").

Subroutine structure

The structure of a subroutine is identical to that of a main program (see Section 8.1.2 "Program Structure"). Like main programs, subroutines are also programmed with the command **M2 - end of program** - in the last block of the program sequence. In this case, it means return to the calling program level.

End of program

As a substitute for M2 - end of program - it is also possible to use the end statement RET in the subroutine.

RET requires a separate block.

Use the RET statement if G64 continuous-path control mode is not to be interrupted by the return. M2 will interrupt G64 and generate exact stop.




Fig. 8-53 Sequence when calling the subroutine twice (example)

Subroutine name

In order to be able to choose a certain subroutine from several subroutines offered, the program is assigned its own name. The name can be freely selected when creating the program provided the following conventions are observed:

The same rules are applicable, as for main program names.

Example: **SLEEVE7**

In addition, for subroutines it is possible to use the address word **L...** . 7 decimal places (only integer) are possible for the value.

Please note: For address L, leading zeros are significant for distinction.

Example: **L128** is not L0128 or **L00128** !

These are 3 different subroutines.

Note: The subroutine name **LL6** is reserved for the tool change.

Calling subroutines

Subroutines are called in a program (main program or subroutine) by their names. This requires a separate block.

Example:

N10 L785 ;call of subroutine L785

N20 SHAFT7 ;call of subroutine SHAFT7

Program repetition P...

If you wish a subroutine to be executed several times in succession, program the number of passes in the calling block after the subroutine name at **address P**. Max. **9,999 passes** are possible (P1 ... P9999).

Example:

N10 L785 P3 ;call of subroutine L785, 3 passes

Nesting depth

Subroutines cannot only be called in a main program, but also in a subroutine. For such a nested call, **8 program levels**, including the main program level, are provided in total.




Fig. 8-54 Sequence with 8 program levels

Information

In a subroutine, modally effective G functions can be changed, e.g. G90 -> G91. When returning to the calling program, make sure that all modally effective functions are set such, as you need them.

The same applies to the arithmetic parameters R. Make sure that the values of the arithmetic parameters used for the upper program levels are not inadvertently changed in lower program levels.

SIEMENS cycles will require up to 4 program levels.

8.11.2 Calling Machining Cycles

Functionality

Cycles are technology subroutines that realize a certain technology, such as drilling or thread cutting, in a generally applicable form. The adaptation to the particular problem is carried out using the defining parameters/values directly at the moment when the related cycle is called.

Programming example

```
N10 CYCLE83(110, 90, ...) ; call cycle 83, transfer values directly, separate block
...
N40 RTP=100 RFP= 95.5 ... ; set transfer parameters for cycle 82
N50 CYCLE82(RTP, RFP, ...) ; call cycle 82, separate block
```


8.12 Timer and Workpiece Counter

8.12.1 Runtime Timer

Functionality

Timers that can be used for monitoring technological processes either in the program or only in the display are provided as system variables (\$A...).

These timers are read-only timers. Certain timers are always active. Other timers are activated using machine data.

Timers that are always active

- Time since the last "booting of the CNC with default values" (in minutes):
`$AN_SETUP_TIME` (read-only)
 When the control system boots with the default values, the timer is automatically reset to zero.
- Time since the last booting of the CNC (in minutes):
`$AN_POWERON_TIME` (read-only)
 When the control system boots, the timer is automatically reset to zero.

Timers that can be disabled

The timers listed below are activated using machine data (default setting). The start is timer-specific. Every active runtime measurement is interrupted automatically either by a program state other than "Program running" or if the feed override is equal to zero.

The response of the activated time measurements with dry run feed and program test active can be defined using machine data.

- Total runtime of NC programs in AUTOMATIC mode (in seconds):
`$AC_OPERATING_TIME`
 The runtimes of all programs between NC start and program end / reset are added. The timer is set to zero with each booting of the control system.
- Runtime of the selected NC program (in seconds):
`$AC_CYCLE_TIME`
 The runtime between NC start and program end / reset is measured in the selected NC program. Starting a new NC program deletes the timer.
- Tool intervention time (in seconds):
`$AC_CUTTING_TIME`
 The runtime of the path axes (without rapid traverse) is measured between NC start and program end / reset in all NC programs with the tool active.
 The measurement is additionally interrupted with the dwell time active.
 The timer is automatically reset to zero with each booting of the control system.

Programming example

```
N10 IF $AC_CUTTING_TIME >= R10 GOTOF WZZEIT ;tool intervention time limit value?
...
N80 WZZEIT:
N90 MSG ("Tool intervention time: Limit value reached")
N100 M0
```

Display

The contents of the system variable is displayed (after activation as necessary) on the screen in the operating area "OFFSET/PARAM" -> softkey "Setting Data" (2nd page):

Runtime = \$AC_OPERATING_TIME
Cycle time = \$AC_CYCLE_TIME
Cutting time = \$AC_CUTTING_TIME
Setup time = \$AN_SETUP_TIME
Power on time = \$AN_POWERON_TIME

In addition, "Cycle time" is displayed in AUTOMATIC mode in the operating area "Position" in the Tip line.

8.12.2 Workpiece Counter**Functionality**

The Workpiece Counter function provides counters that can be used for counting workpieces. These counters are provided as system variables with read and write access either from the program or by operation (pay attention to the protection level for writing!). It is possible to control the counter activation, the time of resetting to zero and the counting algorithm via machine data.

Counters

- Number of parts required (required parts):
 \$AC_REQUIRED_PARTS
 This counter can be used to define the number of workpieces at which when reached the number of current workpieces \$AC_ACTUAL_PARTS is set to zero.
 The generation of the display alarm 21800 "Number of required parts reached" can be activated via machine data.
- Number of parts produced in total (total parts):
 \$AC_TOTAL_PARTS
 The counter specifies the number of all parts produced from the moment of starting. The timer is automatically reset to zero when the control system boots.
- Number of current parts (actual parts):
 \$AC_ACTUAL_PARTS
 This counter counts the number of all parts produced from the moment of starting. The counter is automatically reset to zero when the number of required parts is reached (\$AC_REQUIRED_PARTS, value greater than zero).
- Number of parts specified by the user:
 \$AC_SPECIAL_PARTS
 This counter permits the user to carry out part counting using his own definition. It is possible to define an alarm output if the \$AC_REQUIRED_PARTS (required number of parts) is reached. It is the user's job to reset the counter to zero.

Programming example

```
N10 IF $AC_TOTAL_PARTS==R15 GOTOF SIST ;number of parts reached?  
...  
N80 SIST:  
N90 MSG("Required number of parts reached")  
N100 M0
```

Display

The contents of the active system variables is displayed on the screen in the operating area "OFFSET/PARAM" -> softkey "Setting Data" (2nd page):

```
Parts total    = $AC_TOTAL_PARTS  
Parts required = $AC_REQUIRED_PARTS  
Part count    = $AC_ACTUAL_PARTS  
                $AC_SPECIAL_PARTS is not displayed
```

In addition, "Part count" is displayed in AUTOMATIC mode in the operating area "Position" in the Tip line.

8.13 Language commands for tool monitoring

8.13.1 Overview: Tool monitoring

With SINUMERIK 802D, this function is an option and available with software release 2.0 and higher.

Functionality

The tool monitoring is activated via machine data.

The following monitoring types are possible for the active cutting edge of the active tool:

- Monitoring of the **tool life**
- Monitoring of the **count**

All of the above mentioned monitoring functions can be activated for a tool at the same time.

The control / data input of the tool monitoring is provided preferably via operation. Additionally, the functions can also be programmed.

Monitoring counter

Monitoring counters are provided for every monitoring type. The monitoring counters run from a set value > 0 against zero. If a monitoring counter reaches a value <= 0, the limit value is deemed to be reached; an appropriate alarm message is generated.

System variable for monitoring type and status

- \$TC_TP8[t] - status of the tool with number t:
 - Bit 0 =1: Tool is **active**
=0: Tool not active
 - Bit 1 =1: Tool is **enabled**
=0: not enabled
 - Bit 2 =1: Tool is **disabled**
=0: not disabled
 - Bit 3 : reserved
 - Bit 4 =1: **Prewarning limit reached**
=0: not reached
- \$TC_TP9[t] - type of the monitoring function for the tool with number t :
 - = 0: No monitoring
 - = 1: (Tool monitored for the tool life
 - = 2: Tool monitored for the count (number of workpieces)

These system variables can be read / written in the NC program.

System variable for tool monitoring data

Table 8-2 Tool monitoring data

| Identifier | Description | Data Type | Default |
|----------------|---------------------------------------|-----------|---------|
| \$TC_MOP1[t,d] | Prewarning limit Tool life in minutes | REAL | 0.0 |
| \$TC_MOP2[t,d] | Residual tool life in minutes | REAL | 0.0 |
| \$TC_MOP3[t,d] | Prewarning limit Count | INT | 0 |
| \$TC_MOP4[t,d] | Residual count | INT | 0 |
| ... | ... | | |

| | | | |
|-----------------|--------------------|------|-----|
| \$TC_MOP11[t,d] | Required tool life | REAL | 0.0 |
| \$TC_MOP13[t,d] | Required count | INT | 0 |

t for tool number T, d for D number

System variable for the active tool

The following can be read in the NC program using a system variable:

- \$P_TOOLNO - number of the active tool T
- \$P_TOOL - active D number of the active tool

8.13.2 Tool life monitoring

The tool life is monitored for the tool cutting edge currently being in use (active cutting edge D of the active tool T).

Once the path axes traverse (G1, G2, G3, ... but not with G0), the residual tool life (\$TC_MOP2[t,d]) of this tool cutting edge is updated. If during the machining the residual tool life of a cutting edge of a tool falls below the value of "Prewarning limit Tool life" (\$TC_MOP1[t,d]), an appropriate interface signal is provided to the PLC.

If the residual tool life is ≤ 0 , an alarm is issued and another interface signal is set. Following, the tool changes to the "disabled" status and can no longer be programmed anew until the "disabled" status is canceled. Now, the operator must intervene: He must change the tool and make sure that an operative tool is available for machining again.

System variable \$A_MONIFACT

Using the system variable **\$A_MONIFACT** (data type REAL), it is possible to run the clock for the monitoring feature slower or faster. This factor can be set before using the tool, e.g. to take into account the different wear according to the used workpiece material.

After booting of the control system, Reset/end of program, the factor \$A_MONIFACT has the value 1.0. The real time is effective.

Examples for taking into account the system variable:

\$A_MONIFACT=1 1 minute in real time = 1 minute of tool life which is decremented

\$A_MONIFACT=0.1 1 minute of real time = 0.1 minute of tool life which is decremented

\$A_MONIFACT=5 1 minute of real time = 5 minutes of tool life, which are decremented

Setpoint update using RESETMON()

The function RESETMON(state, t, d, mon) sets the actual value to the setpoint:
 - either for all cutting edges or only for a certain cutting edge of a certain tool
 - either for all monitoring type or only for a certain monitoring type.

Transfer parameters:

| | | |
|-----|---------------------|--|
| INT | state | Status of command execution : |
| | = 0 | Successful execution |
| | = -1 | The cutting edge with the specified D number d does not exist. |
| | = -2 | The tool with the specified T number t does not exist. |
| | = -3 | The specified tool t does not have a defined monitoring function. |
| | = -4 | The monitoring function is not activated, i.e. the command is not executed. |
| INT | t | Internal T number : |
| | = 0 | for all tool |
| | <> 0 | for this tool (t < 0 : absolute-value generation t) |
| INT | d | <i>optional</i> : D number of the tool with number t: |
| | > 0 | for this D number |
| | without d / = 0 | all cutting edges of tool t |
| INT | mon | <i>optional</i> : bit-coded parameter for the monitoring type (values analogously to \$TC_TP9): |
| | = 1: | tool life |
| | = 2: | count |
| | without mon or = 0: | All actual values of the monitoring functions active for tool t are set to the setpoints. |

Notes:

- RESETMON() is not effective with "Program test" active.
- The variable for the status checkback message **state** must be defined in the beginning of the program using a DEF statement:
DEF INT state
It is also possible to define a different name for the variable (instead of "state", but max. 15 characters, starting with 2 letters). The variable can only be used in the program in which it was defined.
This also applies to the monitoring type variable **mon**. If any specification is required here at all, it can also be transferred directly as a number (1 or 2).

8.13.3 Count monitoring

The active cutting edge of the active tool is monitored for the count.

The count monitoring includes all tool cutting edges used to manufacture a workpiece. If the count changes due to any new values specified, the monitoring data of all cutting edges that became active since the last workpiece counting are adapted.

Updating of the count via operation or SETPIECE()

The count can be adapted either via operation (HMI) or in the NC program using the language command SETPIECE().

Using the **SETPIECE** function, the programmer may update the count monitoring data of the tools involved in the machining process. All tools that became active since the last activation of SETPIECE are acquired with their D numbers. If a tool is active at the time when SETPIECE() is called, it is also counted.

If a block containing path axis motions is programmed after SETPIECE(), the appropriate tool is also taken into account in the next SETPIECE call.

SETPIECE(x) ;
 x : = 1... 32000 Number of workpieces produced since the last execution of the SETPIECE function.
 The count for the residual count (\$TC_MOP4[t,d]) is reduced by this value.
 x : = 0 Deletion of all counters for the residual count (\$TC_MOP4[t,d]) for the tools/D number involved in machining since then.
 Alternatively, the deletion via operation is recommended (HMI).

Programming example

```

N10 G0 X100
N20 ...
N30 T1
N40 M6
N50 D1
N60 SETPIECE(2)      ;$TC_MOP4[1,1 ] (T1,D2) is decremented by 2

N70 T2
N80 M6
N90 SETPIECE(0)      ;deletion of all tools above
N91 D2
N100 SETPIECE(1)     ;$TC_MOP4[2,2 ] (T2,D2) is decremented by 1

N110 SETPIECE(0)     ;deletion of all tools above
N120 M30
  
```

Notes:

- The command SETPIECE() does not act during block search.
- Programming \$TC_MOP4[t,d] directly is only recommended in the simple case. In this case, a block that contains the STOPRE command must be programmed after this command.

Setpoint update

As a rule, updating of the setpoints, i.e. setting of the residual workpiece quantity counters (\$TC_MOP4[t,d]) to the setpoint count (\$TC_MOP13[t,d]), is carried out via operation (HMI). It is also possible, however, as described for the tool life monitoring, via the function RESETMON (state, t, d, mon).

Example:

```

DEF INT state      ; Defining a variable for the status feedback in the beginning of the program
...
N100 RESETMON(state,12,1,2) ; Updating the setpoint of the workpiece counter for T12, D1
...
  
```

Programming example

```
DEF INT state                ; Defining the variable for the status feedback of RESETMON()
;
G0 X...                      ; Retraction
T7                            ; Load a new tool, possible via M6
$TC_MOP3[$P_TOOLNO,$P_TOOL]=100 ; Prewarning limit 100 pcs.
$TC_MOP4[$P_TOOLNO,$P_TOOL]=700 ; Residual count
$TC_MOP13[$P_TOOLNO,$P_TOOL]=700; Count setpoint
                                ; Activation after setting:
$TC_TP9[$P_TOOLNO,$P_TOOL]=2   ; Activation of the count monitoring, active tool
STOPRE
ANF:
BEARBEIT                    ; Subroutine for workpiece machining
SETPIECE(1)                 ; Update counter
M0                           ; Next workpiece; press NC START to continue
IF ($TC_MOP4[$P_TOOLNO,$P_TOOL]>1) GOTOB ANF
MSG("Tool T7 worn - please change")
M0                           ; after changing the tool, press NC START to continue
RESETMON(state,7,1,2)       ; Workpiece counter setpoint update
IF (state<>0) GOTOF ALARM
GOTOB ANF
ALARM: ; Display error:
MSG("Error RESETMON: " <<state)
M0
M2
```


8.14 Milling on turning machines

Note

This function is only available with the 802D.

8.14.1 Milling face ends - TRANSMIT

With SINUMERIK 802D, this function is an option and available with software release 2.0 and higher.

Functionality

- Using the kinematic transformation function TRANSMIT provides a face-end milling/drilling machining of turned parts clamped in rotating chucks.
- To program this machining technology, a Cartesian coordinate system is used.
- The control system transforms the programmed traversing motions of the Cartesian coordinate system into motions of the real machine axes. In this case, the main spindle works as a machine rotary axis.
- TRANSMIT must be configured via special machine data. A tool center offset relative to the turning center is permissible and is also configured using these machine data.
- In addition to the tool length compensation, it is also possible to use the tool radius compensation (G41, G42).
- The motions defined for rotary motions are taken into account by the velocity control.




Fig. 8-55 Milling machining at a face end

Programming

TRANSMIT ; Activate TRANSMIT (separate block)
TRAFOOF ; Deactivate (separate block)

TRAFOOF will deactivate any active transformation function.

Programming example




Fig. 8-56 Cartesian coordinate system X, Y, Z with its origin in the turning center when programming TRANSMIT

```

; Milling of a square, eccentric and rotated
N10 T1 F400 G94 G54           ; Milling tool, feedrate, feedrate type
N20 G0 X50 Z60 SPOS=0       ; Approach start position
N25 SETMS(2)                 ; Master spindle is now the milling spindle
N30 TRANSMIT                 ; Activate TRANSMIT function
N35 G55 G17                  ; Zero offset, activate X/Y plane
N40 ROT RPL=-45              ; Programmable rotation in the X/Y plane
N50 ATRANS X-2 Y3            ; Programmable offset
N55 S600 M3                  ; Turn on milling spindle
N60 G1 X12 Y-10 G41          ; Enable tool radius compensation
N65 Z-5                       ; Infeed cutter
N70 X-10
N80 Y10
N90 X10
N100 Y-12
N110 G0 Z40                   ; Retract cutter
N120 X15 Y-15 G40            ; Disable tool radius compensation
N130 TRANS                   ; Disable programmable offset and rotation
N140 M5                       ; Turn off milling spindle
N150 TRAFOOF                 ; Deactivate TRANSMIT
N160 SETMS                   ; Master spindle is now main spindle again
N170 G54 G18 G0 X50 Z60 SPOS=0 ; Approach start position
N200 M2
    
```

Information

The turning center with X0/Y0 is referred to as the pole. It is therefore not recommended to machine a workpiece in the vicinity of the pole, since in some cases substantial feedrate reductions are required to avoid that the rotary axis is not overloaded. Avoid to select TRANSMIT if the tool stands exactly in the pole. You should also avoid passing of the pole X0/Y0 with the tool center point.

References: Description of Functions, Section "Kinematic Transformations"

8.14.2 Milling of peripheral surfaces - TRACYL

With SINUMERIK 802D, this function is an option and available with software release 2.0 and higher.

Functionality

- The kinematic transformation function TRACYL is used for the milling of peripheral surfaces of cylindrical bodies, allowing the manufacture of any shape and running in any direction.
- The course of the grooves is programmed in the **plane** peripheral surface which was wound off in the mind at a certain machining cylinder diameter.




Fig. 8-57 Cartesian coordinate system X, Y, Z when programming TRACYL

- The control system transforms the programmed traversing motions in the Cartesian coordinate system X, Y, Z into motions of the real machine axes. In this case, the main spindle works as a machine rotary axis.
- TRACYL must be configured via special machine data. It is also defined at which position of the rotary axis the value $Y=0$ is to be found.
- If the machine possesses a real Y machine axis (YM), an extended TRACYL variant may be configured. Thus, it is possible to produce grooves, using the groove side correction: groove side and groove bottom stand vertically to one another - even if the cutter diameter is less than the groove width. Otherwise, this is only possible with an exactly matching cutter.




Fig. 8-58 Special machine kinematics with additional machine Y axis (YM)




Fig. 8-59 Various grooves (cross sectional view)

Programming

TRACYL(d) ; Activate TRACYL (separate block)

TRAFOOF ; Deactivate (separate block)

d - machining diameter of the cylinder in mm

TRAFOOF will deactivate any active transformation function.

Address OFFN

Distance of the groove side to the programmed path

Usually, the groove center line is programmed. OFFN defines the (half) groove width when working with cutter radius compensation (G41, G42).

Programming OFFN=... ; distance in mm

Note:

Set OFFN=0 after manufacturing the groove. OFFN is used also beyond TRACYL - for the programming of the stock allowance in conjunction with G41, G42.




Fig. 8-60 Use of OFFN for the groove width

Programming notes

To be able to mill grooves using TRACYL, the groove center line is programmed in the part program, specifying the coordinates, and the (half) groove width is programmed via OFFN.

OFFN will only come into effect after selecting tool radius compensation. Furthermore, it must be guaranteed that $OFFN \geq$ tool radius to avoid that the opposite groove side is damaged.

As a rule, a part program for the milling of a groove consists of the following steps:

1. Selection of the tool
2. Selection of TRACYL
3. Selection of the appropriate zero offset
4. Positioning
5. Programming of OFFN
6. Selection of the TRC
7. Approach block (approaching to the groove side, taking into account the TRC)
8. Programming of the groove course via the groove center line
9. Deselection of the TRC
10. Retraction block (retraction from the groove side, taking into account the TRC)
11. Positioning
12. Deletion of OFFN
13. TRAF00F (deselection of TRACYL)
14. Re-selection of the original zero offset
(see also the programming example below)

Information

- Guiding grooves:
Using a tool diameter that matches exactly the groove width, it is possible to produce exact grooves. The tool radius compensation (TRC) is not disabled in this case.
Using TRACYL, it is also possible to produce grooves with which the tool diameter is less than the groove width. In this case, the tool radius compensation (G41, G42) and OFFN are used efficiently.
To avoid accuracy problems, the tool diameter should be only slightly smaller than the groove width.
- When working with TRACYL with groove side correction, the axis used for the correction (YM) should stand on the turning center. Thus, the groove is produced centrally to the programmed groove center line.
- Selection of the tool radius compensation (TRC):
The TRC acts towards the programmed groove center line, resulting in the groove side. To cause the tool moving to the left of the groove side (to the right of the groove center line), enter G42. Correspondingly, G41 must be written for if you wish the tool moving right of the groove side (left of the groove center line).
Alternatively for changing G41<->G42, you may enter the groove width in OFFN with a negative sign.
- Since OFFN is also taken into account without TRACYL with the TRC active, after TRAF00F, OFFN should be reset to zero. The effect of OFFN with TRACYL is other than that without TRACYL.
- It is not possible to change OFFN within the part program. Thus, it is possible to shift the real center line from the center.

References: Description of Functions, Section "Kinematic Transformations"

Programming example

Producing a hook-style groove




Fig. 8-61 Example of producing a groove

8.15 Equivalent G Functions with SINUMERIK 802S - Turning

| SINUMERIK 802S | SINUMERIK 802D |
|----------------|----------------|
| G5 | CIP |
| G158 | TRANS |
| G22 | DIAMOF |
| G23 | DIAMON |

The remaining G functions are identical for 802S and 802D (as far as provided).

Cycles

9.1 Overview of cycles

Cycles are generally applicable technology subroutines that can be used to carry out a specific machining process, such as tapping or pocket milling. These cycles are adapted to individual tasks by parameter assignment.

The cycles described here are the same as supplied for the SINUMERIK 840D/810D.

Drilling cycles and turning cycles

With the SINUMERIK 802D control system, the following cycles are possible:

- Drilling cycles

| | |
|----------|--|
| CYCLE81 | Drilling, centering (not with 802D-bl) |
| CYCLE82 | Center drilling |
| CYCLE83 | Deep hole drilling |
| CYCLE84 | Rigid tapping |
| CYCLE840 | Tapping with compensation chuck |
| CYCLE85 | Reaming |
| CYCLE86 | Boring (boring 2) (not with 802D-bl) |
| CYCLE87 | Boring with Stop 1 (boring 3) (not with 802D-bl) |
| CYCLE88 | Drilling with stop |
| CYCLE89 | Reaming 2 (boring 5) |
| HOLES1 | Row of holes |
| HOLES2 | Circle of holes |

With SINUMERIK 840D, the boring cycles CYCLE85 ... CYCLE89 are called boring 1 ... boring 5, but are nevertheless identical in their function.

- Turning cycles

| | |
|---------|--|
| CYCLE93 | Grooving |
| CYCLE94 | Undercut (forms E and F to DIN) |
| CYCLE95 | Stock removal |
| CYCLE96 | Thread undercut |
| CYCLE97 | Thread cutting |
| CYCLE98 | Chaining of threads (not with 802D-bl) |

The cycles are supplied with the tool box. They are loaded via the RS232 interface into the part program memory during the start-up of the control system.

Auxiliary cycle subroutines

The cycle package includes the following auxiliary subroutines:

- cyclest.spf
- steigung.spf and
- meldung.spf

These must always be loaded in the control.

9.2 Programming cycles

A standard cycle is defined as a subroutine with name and parameter list.

Call and return conditions

The G functions effective prior to the cycle call and the programmable offsets remain active beyond the cycle.

The machining plane G17 for drilling cycles or G18 for turning cycles must be defined before the cycle is called.

With drilling cycles, the drilling operation is carried out in the axis standing vertically to the current plane.

Messages output during execution of a cycle

During some cycles, messages that refer to the state of machining are displayed on the screen of the control system during program execution.

These messages do not interrupt the program execution and continue to be displayed on the screen until the next message appears.

The message texts and their meaning are listed together with the cycle to which they refer.

A summary of all relevant messages is to be found in Section 9.4.

Block display during execution of a cycle

The cycle call is displayed in the current block display for the duration of the cycle.

Cycle call and parameter list

The defining parameters for the cycles can be transferred via the parameter list when the cycle is called.

Note

Cycle calls must always be programmed in a separate block.

Basic instructions with regard to the assignment of standard cycle parameters

The Programming Guide describes the parameter list of every cycle with the

- order and the
- type.

It is imperative to observe the order of the defining parameters.

Each defining parameter of a cycle has a certain data type. The parameter being used must be specified when the cycle is called. In the parameter list, you can transfer

- R parameters (only numerical values)
- constants.

If R parameters are used in the parameter list, they must first be assigned values in the calling program. Cycles can be called

- with an incomplete parameter list
or
- by leaving out parameters.

If you want to exclude the last transfer parameters that have to be written in a call, you can prematurely terminate the parameter list with ")". If you wish to leave out parameters in between, a comma "... , ..." is used as a place holder.

No plausibility checks are made for parameter values with a limited range of values unless an error response has been specifically described for a cycle.

If when calling the cycle the parameter list contains more entries than parameters are defined in the cycle, the general NC alarm 12340 "Too many parameters" is displayed and the cycle is not executed.

Cycle call

The individual methods for writing a cycle are shown in the programming examples provided for the individual cycles.

Simulation of cycles

Programs with cycle calls can be tested first in simulation.

During simulation, the traversing movements of the cycle are visualized on the screen.

9.3 Graphical cycle support in the program editor

The program editor in the control system provides you with programming support to add cycle calls to the program and to enter parameters.

Function

The cycle support consists of three components:

1. Cycle selection
2. Input screenforms for parameter assignment
3. Help display per cycle.

Overview of required files

The following files constitute the basis for cycle support:

- sc.com
- cov.com

Note

These files are loaded during the start-up of the control system and must always remain loaded.

Operating the cycle selection

To add a cycle call to the program, carry out the following steps one after the other:

- In the horizontal softkey bar, you can branch to the individual cycles using the appropriate softkeys "**Drilling**" or "**Turning**".
- The cycle selection is carried out using the vertical softkey bar until the appropriate input screenform with the help display appears on the screen.
- Then enter the values for the parameters.
The values can be entered either directly (numerical values) or indirectly (R parameters, e.g. R27, or expressions consisting of R parameters, e.g. R27+10).
If numerical values are entered, a check is carried out to see whether the value is within the admissible range.
- Some parameters that may have only a few values are selected using the toggle key.
- With drilling cycles, it is also possible to use the vertical softkey "**Modal Call**" for calling a cycle modally.
To deselect the modal call, choose "**Deselect modal**" from the list box for the drilling cycles.
- Press "**OK**" to confirm (or "**Abort**" in case of error).

Recompiling

Recompiling of program codes serves to make modifications to an existing program using the cycle support.

Position the cursor on the line to be modified and press the softkey "**Recompile**".

This will reopen the input screenform from which the program piece has been created, and you can modify the values.

9.4 Drilling cycles

9.4.1 General

Drilling cycles are motional sequences defined to DIN 66025 for drilling, boring, tapping etc.

They are called in the form of a subroutine with a defined name and a parameter list. They all follow a different technological procedure and are therefore parameterized differently.

The drilling cycles can be modal, i.e. they are executed at the end of each block that contains motion commands. Other cycles written by the user can also be called modally.

There are two types of parameters:

- Geometrical parameters and
- machining parameters

The geometrical parameters are identical with all drilling cycles. They define the reference and retraction planes, the safety clearance and the absolute or relative final drilling depth. Geometrical parameters are assigned once during the first drilling cycle CYCLE82.

The machining parameters have a different meaning and effect in the individual cycles. They are therefore programmed in each cycle separately.




Fig. 9-1

9.4.2 Preconditions

Call and return conditions

Drilling cycles are programmed independently of the actual axis names. The drilling position must be approached in the higher-level program before the cycle is called.

The required values for feedrate, spindle speed and direction of spindle rotation must be programmed in the part program if there are no defining parameters in the drilling cycle.

The G functions and the current data record active before the cycle was called remain active beyond the cycle.

Plane definition

In the case of drilling cycles, it is generally assumed that the current workpiece coordinate system in which the machining operation is to be performed is to be defined by selecting plane G17 and activating a programmable offset. The drilling axis is always the axis of this coordinate system which stands vertically to the current plane.

A tool length compensation must be selected before the cycle is called. Its effect is always perpendicular to the selected plane and remains active even after the end of the cycle.

In turning, the drilling axis is thus the Z axis. Drilling is performed to the end face of the workpiece.




Fig. 9-2

Dwell time programming

The parameters for dwell times in the drilling cycles are always assigned to the F word and must therefore be assigned with values in seconds. Any deviations from this procedure must be expressly stated.

9.4.3 Drilling, centering – CYCLE81

Note

This standard cycle is not available with the 802D-bl.

Programming

CYCLE81(RTP, RFP, SDIS, DP, DPR)

Table 9-1 Parameter CYCLE81

| | | |
|------|------|---|
| RTP | real | Retraction plane (absolute) |
| RFP | real | Reference plane (absolute) |
| SDIS | real | Safety clearance (enter without sign) |
| DP | real | Final drilling depth (absolute) |
| DPR | real | Final drilling depth relative to the reference plane (enter without sign) |

Function

The tool drills at the programmed spindle speed and feedrate to the entered final drilling depth.

Operational sequence

Position reached prior to cycle start:

The drilling position is the position in the two axes of the selected plane.

The cycle creates the following sequence of motions:

Approach of the reference plane brought forward by the safety clearance by using G0

- Traversing to the final drilling depth at the feedrate programmed in the calling program (G1)
- Retraction to the retraction plane with G0

Explanation of the parameters

RFP and RTP (reference plane and retraction plane)

Normally, reference plane (RFP) and return plane (RTP) have different values. In the cycle, it is assumed that the retraction plane is ahead of the reference plane. This means that the distance from the retraction plane to the final drilling depth is larger than the distance from the reference plane to the final drilling depth.

SDIS (safety clearance)

The safety clearance (SDIS) acts with reference to the reference plane. This is brought forward by the safety clearance.
The direction in which the safety clearance acts is determined by the cycle automatically.

DP and DPR (final drilling depth)

The final drilling depth can be specified either absolute (DP) or relative (DPR) to the reference plane.

With relative specification, the cycle will calculate the resulting depth automatically using the positions of reference and retraction planes.




Fig. 9-3

Note

If a value is entered both for DP and for DPR, the final drilling depth is derived from DPR. If this differs from the absolute depth programmed via DP, the message "Depth: Corresponding to value for relative depth" is output in the dialog line.

If the values for reference and retraction planes are identical, a relative depth specification is not permitted. The error message 61101 "Reference plane not correctly defined", and the cycle is not executed. This error message is also output if the retraction plane is located after the reference plane, i.e. its distance to the final drilling depth is smaller.

Programming example: Drilling_centering

Using this program, you may produce 3 drill holes using the drilling cycle CYCLE81, whereby this is called using different parameters. The drilling axis is always the Z axis.




Fig. 9-4

| | |
|---------------------------------------|---|
| N10 G0 G17 G90 F200 S300 M3 | Specification of the technological values |
| N20 D3 T3 Z110 | Approaching the retraction plane |
| N30 X40 Y120 | Approach of the first drilling position |
| N40 CYCLE81(110, 100, 2, 35) | Cycle call with absolute final drilling depth, safety clearance and incomplete parameter list |
| N50 Y30 | Approach of next drill position |
| N60 CYCLE81(110, 102, , 35) | Cycle call without safety clearance |
| N70 G0 G90 F180 S300 M03 | Specification of the technological values |
| N80 X90 | Approach next position |
| N90 CYCLE81(110, 100, 2, , 65) | Cycle call with relative final drilling depth and safety clearance |
| N100 M30 | End of program |

9.4.4 Center drilling – CYCLE82

Programming

CYCLE82(RTP, RFP, SDIS, DP, DPR, DTB)

Parameters

Table 9-2 Parameters of CYCLE82

| | | |
|------|------|---|
| RTP | real | Retraction plane (absolute) |
| RFP | real | Reference plane (absolute) |
| SDIS | real | Safety clearance (enter without sign) |
| DP | real | Final drilling depth (absolute) |
| DPR | real | Final drilling depth relative to the reference plane (enter without sign) |
| DTB | real | Dwell time at final drilling depth (chip breaking) |

Function

The tool drills at the programmed spindle speed and feedrate to the entered final drilling depth. A dwell time can be allowed to elapse when the final drilling depth has been reached.

Operational sequence

Position reached prior to cycle start:

The drilling position is the position in the two axes of the selected plane.

The cycle creates the following sequence of motions:

- Approach of the reference plane brought forward by the safety clearance by using G0
- Traversing to the final drilling depth with the feedrate (G1) programmed prior to the cycle call
- Dwell time at final drilling depth
- Retraction to the retraction plane with G0

Explanation of the parameters

For the parameters RTP, RFT, SDIS, DP, DPR see CYCLE81




Fig. 9-5

DTB (dwell time)

The dwell time to the final drilling depth (chip breaking) is programmed under DTB in seconds.

Note

If a value is entered both for DP and for DPR, the final drilling depth is derived from DPR. If this differs from the absolute depth programmed via DP, the message "Depth: Corresponding to value for relative depth" is output in the message line.

If the values for reference and retraction planes are identical, a relative depth specification is not permitted. The error message 61101 "Reference plane defined incorrectly" is output and the cycle is not executed. This error message is also output if the retraction plane is located after the reference plane, i.e. its distance to the final drilling depth is smaller.

Programming example: Boring_counterboring

The program machines a single hole of a depth of 20 mm at position X0 with cycle CYCLE82.

The dwell time programmed is 3 s, the safety clearance in the drilling axis Z is 2,4 mm.

| | |
|---|--|
| N10 G0 G90 G54 F2 S300 M3 | Specification of the technological values |
| N20 D1 T6 Z50 | Approaching the retraction plane |
| N30 G17 X0 | Approaching the drill position |
| N40 CYCLE82(3, 1.1, 2.4, -20, , 3) | Cycle call with absolute final drilling depth and safety clearance |
| N50 M2 | End of program |

9.4.5 Deep hole drilling – CYCLE83

Programming

CYCLE83(RTP, RFP, SDIS, DP, DPR, FDEP, FDPR, DAM, DTB, DTS, FRF, VARI)

Parameters

Table 9-3 Parameters of CYCLE83

| | | |
|------|------|---|
| RTP | real | Retraction plane (absolute) |
| RFP | real | Reference plane (absolute) |
| SDIS | real | Safety clearance (enter without sign) |
| DP | real | Final drilling depth (absolute) |
| DPR | real | Final drilling depth relative to the reference plane (enter without sign) |
| FDEP | real | First drilling depth (absolute) |
| FDPR | real | First drilling depth relative to the reference plane (enter without sign) |
| DAM | real | Amount of degression (enter without sign) |
| DTB | real | Dwell time at final drilling depth (chip breaking) |
| DTS | real | Dwell time at starting point and for swarf removal |
| FRF | real | Feedrate factor for the first drilling depth (enter without sign) Range of values: 0.001 ... 1 |
| VARI | int | Machining type: Chip breaking=0 Swarf removal=1 |

Function

The tool drills at the programmed spindle speed and feedrate to the entered final drilling depth.

Deep hole drilling is performed with a depth infeed of a maximum definable depth executed several times, increasing gradually until the final drilling depth is reached.

The drill can either be retracted to the reference plane + safety clearance after every infeed depth for swarf removal or retracted in each case by 1 mm for chip breaking.

Operational sequence

Position reached prior to cycle start:

The drilling position is the position in the two axes of the selected plane.

The cycle creates the following sequence of motions:

Deep hole drilling with swarf removal (VARI=1):

- Approach of the reference plane brought forward by the safety clearance by using G0
- Traversing to the first drilling depth with G1, the feedrate for which is derived from the feedrate defined with the program call which is subject to parameter FRF (feedrate factor)
- Dwell time at final drilling depth (parameter DTB)
- Retraction to the reference plane brought forward by the safety clearance for swarf removal by using G0
- Dwell time at the starting point (parameter DTS)
- Approach of the drilling depth last reached, reduced by anticipation distance by using G0
- Traversing to the next drilling depth with G1 (sequence of motions is continued until the final drilling depth is reached)
- Retraction to the retraction plane with G0




Fig. 9-6 Deep hole drilling with swarf removal

Deep hole drilling with chip breaking (VARI=0):

- Approach of the reference plane brought forward by the safety clearance by using G0
- Traversing to the first drilling depth with G1, the feedrate for which is derived from the feedrate defined with the program call which is subject to parameter FRF (feedrate factor)
- Dwell time at final drilling depth (parameter DTB)
- Retraction by 1 mm from the current drilling depth with G1 and the feedrate programmed in the calling program (for chip breaking)
- Traversing to the next drilling depth with G1 and the programmed feedrate (sequence of motions is continued until the final drilling depth is reached)
- Retraction to the retraction plane with G0




Fig. 9-7 Deep hole drilling with chip breaking

Explanation of the parameters

For the parameters RTP, RFP, SDIS, DP, DPR, see CYCLE82

Interrelation of the parameters DP (or DPR), FDEP (or FDP) and DMA

The intermediate drilling depth are calculated in the cycle on the basis of final drilling depth, first drilling depth and amount of degression as follows:

- In the first step, the depth parameterized with the first drilling depth is traversed as long as it does not exceed the total drilling depth.
- From the second drilling depth on, the drilling stroke is obtained by subtracting the amount of degression from the stroke of the last drilling depth, provided that the latter is greater than the programmed amount of degression.
- The next drilling strokes correspond to the amount of degression, as long as the remaining depth is greater than twice the amount of degression.
- The last two drilling strokes are divided and traversed equally and are therefore always greater than half of the amount of degression.
- If the value for the first drilling depth is incompatible with the total depth, the error message 61107 "First drilling depth defined incorrectly" is output and the cycle is not executed.

The parameter FDP has the same effect in the cycle as the parameter DPR. If the values for the reference and retraction planes are identical, the first drilling depth can be defined as a relative value.

If the first drilling depth is programmed larger than the final drilling depth, the final drilling depth is never exceeded. The cycle will reduce the first drilling depth automatically as far as the final drilling depth is reached when drilling only once, and will therefore drill only once.

DTB (dwell time)

The dwell time to the final drilling depth (chip breaking) is programmed under DTB in seconds.

DTS (dwell time)

The dwell time at the starting point is only performed if VARI=1 (swarf removal).

FRF (feedrate factor)

With this parameter, you can enter a reduction factor for the active feedrate which only applies to the approach to the first drilling depth in the cycle.

VARI (machining type)

If parameter VARI=0 is set, the drill retracts 1 mm after reaching each drilling depth for chip breaking. If VARI=1 (for swarf removal), the drill traverses in each case to the reference plane brought forward by the safety clearance.

Note

The anticipation distance is calculated internally in the cycle as follows:

- If the drilling depth is 30 mm, the value of the anticipation distance is always 0.6 mm.
- For larger drilling depths, the formula drilling depth /50 is used (maximum value 7 mm).

Programming example - deep hole drilling

This program executes the cycle CYCLE83 at the position X0. The first drill hole is drilled with a dwell time zero and machining type chip breaking. The final drilling depth and the first drilling depth are entered as absolute values. The tapping axis is the Z axis.

| | |
|--|--|
| N10 G0 G54 G90 F5 S500 M4 | Specification of the technological values |
| N20 D1 T6 Z50 | Approaching the retraction plane |
| N30 G17 X0 | Approaching the drill position |
| N40 CYCLE83(3.3, 0, 0, -80, 0, -10, 0, 0, 0, 0, 1, 0) | Call of cycle; depth parameters with absolute values |
| N50 M2 | End of program |

9.4.6 Rigid tapping – CYCLE84

Programming

CYCLE84(RTP, RFP, SDIS, DP, DPR, DTB, SDAC, MPIT, PIT, POSS, SST, SST1)

Parameters

Table 9-4 Parameters of CYCLE84

| | | |
|------|------|---|
| RTP | real | Retraction plane (absolute) |
| RFP | real | Reference plane (absolute) |
| SDIS | real | Safety clearance (enter without sign) |
| DP | real | Final drilling depth (absolute) |
| DPR | real | Final drilling depth relative to the reference plane (enter without sign) |
| DTB | real | Dwell time at thread depth (chip breaking) |
| SDAC | int | Direction of rotation after end of cycle Values: 3, 4 or 5 (for M3, M4 or M5) |
| MPIT | real | Pitch as thread size (signed) Range of values 3 (for M3) ... 48 (for M48); the sign determines the direction of rotation in the thread |
| PIT | real | Pitch as a value (signed) Range of values: 0.001 ... 2000.000 mm); the sign determines the direction of rotation in the thread |
| POSS | real | Spindle position for oriented spindle stop in the cycle (in degrees) |
| SST | real | Speed for tapping |
| SST1 | real | Speed for retraction |

Function

The tool drills at the programmed spindle speed and feedrate to the entered final thread depth.

CYCLE84 can be used to perform rigid tapping operations.

Note

CYCLE84 can be used if the spindle to be used for the boring operation is technically able to go into position-controlled spindle operation.

For tapping with compensating chuck, a separate cycle CYCLE840 is provided.

Operational sequence

Position reached prior to cycle start:

The drilling position is the position in the two axes of the selected plane.

The cycle creates the following sequence of motions:

- Approach of the reference plane brought forward by the safety clearance by using G0
- Oriented spindle stop (value in the parameter POSS) and switching the spindle to axis mode
- Tapping to final drilling depth and speed SST
- Dwell time at thread depth (parameter DTB)
- Retraction to the reference plane brought forward by the safety clearance, speed SST1 and direction reversal
- Retraction to the retraction plane with G0; spindle mode is reinitiated by reprogramming the spindle speed active before the cycle was called and the direction of rotation programmed under SDAC

Explanation of the parameters

For the parameters RTP, RFP, SDIS, DP, DPR, see CYCLE82




Fig. 9-8

DTB (dwell time)

The dwell time is programmed in seconds. When tapping blind holes, it is recommended to omit the dwell time.

SDAC (direction of rotation after end of cycle)

Under SDAC, the direction of rotation after end of cycle is programmed. The direction reversal when tapping is carried out automatically internally in the cycle.

MPIT and PIT (as a thread size and as a value)

The value for the thread pitch can be defined either as the thread size (for metric threads between M3 and M48 only) or as a value (distance from one thread turn to the next as a numerical value). The parameter not required in each case is omitted in the call or is assigned the value zero.

RH or LH threads are defined by the sign of the pitch parameters:

- positive value → RH (as for M3)
- negative value → LH (as for M4)

If the two thread pitch parameters have conflicting values, alarm 61001 "Thread pitch wrong" is generated by the cycle and cycle execution is aborted.

POSS (spindle position)

Before tapping, the spindle is stopped with orientation in the cycle by using the command SPOS and switched to position control.

The spindle position for this spindle stop is programmed under POSS.

SST (speed)

Parameter SST contains the spindle speed for the tapping block.

SST1 (retraction speed)

The speed for retraction from the tapped hole is programmed under SST1 with G332. If this parameter is assigned the value zero, retraction is carried out at the speed programmed under SST.

Note

The direction of rotation when tapping in the cycle is always reversed automatically.

Programming example: Rigid tapping

Rigid tapping is carried out at position X0; the drilling axis is the Z axis. No dwell time is programmed; the depth is programmed as a relative value. The parameters for the direction of rotation and for the pitch must be assigned values. A metric thread M5 is tapped.

| | |
|---|---|
| N10 G0 G90 G54 T6 D1 | Specification of the technological values |
| N20 G17 X0 Z40 | Approaching the drill position |
| N30 CYCLE84(4, 0, 2, , 30, , 3, 5, , 90, 200, 500) | Cycle call; parameter PIT has been omitted; no value is entered for the absolute depth or the dwell time; spindle stop at 90 degrees; speed for tapping is 200, speed for retraction is 500 |
| N40 M2 | End of program |

9.4.7 Tapping with compensation chuck – CYCLE840

Programming

CYCLE840(RTP, RFP, SDIS, DP, DPR, DTB, SDR, SDAC, ENC, MPIT, PIT)

Parameters

Table 9-5 Parameter of CYCLE840

| | | |
|------|------|--|
| RTP | real | Retraction plane (absolute) |
| RFP | real | Reference plane (absolute) |
| SDIS | real | Safety clearance (enter without sign) |
| DP | real | Final drilling depth (absolute) |
| DPR | real | Final drilling depth relative to the reference plane (enter without sign) |
| DTB | real | Dwell time at thread depth (chip breaking) |
| SDR | int | Direction of rotation for retraction Values: 0 (automatic reversal of the direction of rotation) 3 or 4 (for M3 or M4) |
| SDAC | int | Direction of rotation after end of cycle Values: 3, 4 or 5 (for M3, M4 or M5) |
| ENC | int | Tapping with/without encoder Values: 0 = with encoder 1 = without encoder |
| MPIT | real | Thread pitch as the thread size (signed) Range of values 3 (for M3) ... 48 (for M48) |
| PIT | real | Pitch as a value (signed) Range of values: 0.001 ... 2000.000 mm |

Function

The tool drills at the programmed spindle speed and feedrate to the entered final thread depth.

Using this cycle, you can perform tapping with compensating chuck

- without encoder and
- with encoder.

Sequence of operations: Tapping with compensating chuck without encoder

Position reached prior to cycle start:

The drilling position is the position in the two axes of the selected plane.

The cycle creates the following sequence of motions:

- Approach of the reference plane brought forward by the safety clearance by using G0
- Tapping to the final drilling depth
- Dwell time at tapping depth (parameter DTB)
- Retraction to the reference plane brought forward by the safety clearance
- Retraction to the retraction plane with G0




Fig. 9-9

Sequence of operations: Tapping with compensating chuck with encoder

Position reached prior to cycle start:

The drilling position is the position in the two axes of the selected plane.

The cycle creates the following sequence of motions:

- Approach of the reference plane brought forward by the safety clearance by using G0
- Tapping to the final drilling depth
- Dwell time at thread depth (parameter DTB)
- Retraction to the reference plane brought forward by the safety clearance
- Retraction to the retraction plane with G0




Fig. 9-10

Explanation of the parameters

For the parameters RTP, RFP, SDIS, DP, DPR, see CYCLE81

DTB (dwell time)

The dwell time is programmed in seconds. It is only effective in tapping without encoder.

SDR (direction of rotation for retraction)

SDR=0 must be set if the spindle direction is to reverse automatically.

If the machine data are defined such that no encoder is set (in this case, machine data MD30200 NUM_ENC is 0), the parameter must be assigned the value 3 or 4 for the direction of rotation; otherwise, alarm 61202 "No spindle direction programmed" is output and the cycle is aborted.

SDAC (direction of rotation)

Because the cycle can also be called modally (see Section 9.3), it requires a direction of rotation for tapping further threaded holes. This is programmed in parameter SDAC and corresponds to the direction of rotation programmed before the first call in the higher-level program. If SDR=0, the value assigned to SDAC has no meaning in the cycle and can be omitted in the parameterization.

ENC (tapping)

If tapping is to be performed without encoder although an encoder exists, parameter ENC must be assigned value 1.

If, however, no encoder is installed and the parameter is assigned the value 0, it is ignored in the cycle.

MPIT and PIT (as a thread size and as a value)

The parameter for the spindle pitch is only relevant if tapping is performed with encoder. The cycle calculates the feedrate from the spindle speed and the pitch.

The value for the thread pitch can be defined either as the thread size (for metric threads between M3 and M48 only) or as a value (distance from one thread turn to the next as a numerical value). The parameter not required in each case is omitted in the call or is assigned the value zero.

If the two thread pitch parameters have conflicting values, alarm 61001 "Thread pitch wrong" is generated by the cycle and cycle execution is aborted.

Further notes

Depending on the settings in machine data MD30200 NUM_ENCS, the cycle selects whether tapping is to be performed with or without encoder.

The direction of rotation for the spindle must be programmed with M3 or M4 before the cycle is called.

In thread blocks with G63, the values of the feedrate override switch and spindle speed override switch are frozen to 100%.

A longer compensating chuck is usually required for tapping without encoder.

Programming example: Tapping without encoder

Tapping is carried out without encoder at position X0; the drilling axis is the Z axis. The parameters SDR and SDAC for the direction of rotation must be assigned; parameter ENC is assigned the value 1, the value for the depth is the absolute value. Pitch parameter PIT can be omitted. A compensating chuck is used in machining.

| | |
|---|---|
| N10 G90 G0 G54 D1 T6 S500 M3 | Specification of the technological values |
| N20 G17 X0 Z60 | Approaching the drill position |
| N30 G1 F200 | Determination of the path feed |
| N40 CYCLE840(3, 0, , -15, 0, 1, 4, 3, 1, ,) | Cycle call, dwell time 1 s, direction of rotation for retraction M4, direction of rotation after cycle M3, no safety clearance Parameters MPIT and PIT are omitted |
| N50 M2 | End of program |

Example: Tapping with encoder

This program is used for tapping with encoder at position X0. The tapping axis is the Z axis. The pitch parameter must be defined, automatic reversal of the direction of rotation is programmed. A compensating chuck is used in machining.

| | |
|---|---|
| N10 G90 G0 G54 D1 T6 S500 M3 | Specification of the technological values |
| N20 G17 X0 Z60 | Approaching the drill position |
| N30 G1 F200 | Determination of the path feed |
| N40 CYCLE840(3, 0, , -15, 0, 0, , ,0, 3.5,) | Cycle call; no safety clearance; |
| N50 M30 | End of program |

9.4.8 Reaming 1 (boring 1) – CYCLE85

Programming

CYCLE85(RTP, RFP, SDIS, DP, DPR, DTB, FFR, RFF)

Parameters

Table 9-6 Parameters of CYCLE85

| | | |
|------|------|---|
| RTP | real | Retraction plane (absolute) |
| RFP | real | Reference plane (absolute) |
| SDIS | real | Safety clearance (enter without sign) |
| DP | real | Final drilling depth (absolute) |
| DPR | real | Final drilling depth relative to the reference plane (enter without sign) |
| DTB | real | Dwell time at final drilling depth (chip breaking) |
| FFR | real | Feedrate |
| RFF | real | Retraction feedrate |

Function

The tool drills at the programmed spindle speed and feedrate to the entered final drilling depth.

The inward and outward movement is performed at the feedrate assigned to FFR and RFF respectively.

Operational sequence

Position reached prior to cycle start:

The drilling position is the position in the two axes of the selected plane.




Fig. 9-11

The cycle creates the following sequence of motions:

- Approach of the reference plane brought forward by the safety clearance by using G0
- Traversing to the final drilling depth with G1 and at the feedrate programmed under the parameter FFR
- Dwell time at final drilling depth
- Retraction to the reference plane brought forward by the safety clearance with G1 and the retraction feedrate defined under the parameter RFF
- Retraction to the retraction plane with G0

Explanation of the parameters

For the parameters RTP, RFP, SDIS, DP, DPR, see CYCLE81




Fig. 9-12

DTB (dwell time)

The dwell time to the final drilling depth is programmed under DTB in seconds.

FFR (feedrate)

The feedrate value programmed under FFR is active in drilling.

RFF (retraction feedrate)

The feedrate value programmed under RFF is active when retracting from the hole to the reference plane + safety clearance.

Programming example: First boring pass

CYCLE85 is called at Z70 X0. The tapping axis is the Z axis. The value for the final drilling depth in the cycle call is programmed as a relative value; no dwell time is programmed. The workpiece upper edge is at Z0.

| | |
|--|--------------------------------------|
| N10 G90 G0 S300 M3 | |
| N20 T3 G17 G54 Z70 X0 | Approaching the drill position |
| N30 CYCLE85(10, 2, 2, , 25, , 300, 450) | Cycle call, no dwell time programmed |
| N40 M2 | End of program |

9.4.9 Boring (boring 2) – CYCLE86

Note

This standard cycle is not available with the 802D-bl.

Programming

CYCLE86(RTP, RFP, SDIS, DP, DPR, DTB, SDIR, RPA, RPO, RPAP, POSS)

Parameter

Table 9-7 Parameters of CYCLE86

| | | |
|------|------|---|
| RTP | real | Retraction plane (absolute) |
| RFP | real | Reference plane (absolute) |
| SDIS | real | Safety clearance (enter without sign) |
| DP | real | Final drilling depth (absolute) |
| DPR | real | Final drilling depth relative to the reference plane (enter without sign) |
| DTB | real | Dwell time at final drilling depth (chip breaking) |
| SDIR | int | Direction of rotation Values: 3 (for M3) 4 (for M4) |
| RPA | real | Retraction path in the 1st axis of the plane (incremental, enter with sign) |
| RPO | real | Retraction path in the 2nd axis of the plane (incremental, enter with sign) |
| RPAP | real | Retraction path in the boring axis (incremental, enter with sign) |
| POSS | real | Spindle position for oriented spindle stop in the cycle (in degrees) |

Function

The cycle supports the boring of holes with a boring bar.

The tool drills at the programmed spindle speed and feedrate to the entered final drilling depth.

With boring 2, oriented spindle stop is activated once the drilling depth has been reached. Then, the programmed retraction positions are approached in rapid traverse and, from there, the retraction plane.

Operational sequence

Position reached prior to cycle start:

The drilling position is the position in the two axes of the selected plane.

The cycle creates the following sequence of motions:

- Approach of the reference plane brought forward by the safety clearance by using G0
- Traversing to final drilling depth with G1 and the feedrate programmed prior to the cycle call
- Dwell time to final drilling depth
- Oriented spindle stop at the spindle position programmed under POSS
- Traverse retraction path in up to three axes with G0
- Retraction in the boring axis to the reference plane brought forward by the safety clearance by using G0
- Retraction to the retraction plane with G0 (initial drilling position in both axes of the plane)

Explanation of the parameters

Parameter RTP, RFP, SDIS, DP, DPR see CYCLE81




Fig. 9-13

DTB (dwell time)

The dwell time to the final drilling depth (chip breaking) is programmed under DTB in seconds.

SDIR (direction of rotation)

With this parameter, you determine the direction of rotation with which boring is performed in the cycle. If values other than 3 or 4 (M3/M4) are generated, alarm 61102 "No spindle direction programmed" is generated and the cycle is not executed.

RPA (retraction path in the 1st axis)

Use this parameter to define a retraction movement in the 1st axis (abscissa), which is executed after the final drilling depth has been reached and oriented spindle stop has been performed.

RPO (retraction path in the 2nd axis)

Use this parameter to define a retraction movement in the 2nd axis (ordinate), which is executed after the final drilling depth has been reached and oriented spindle stop has been performed.

RPAP (retraction path in the boring axis)

Use this parameter to define a retraction movement in the boring axis, which is executed after the final drilling axis has been reached and oriented spindle stop has been performed.

POSS (spindle position)

Use POSS to program the spindle position for the oriented spindle stop in degrees which is performed after the final drilling depth has been reached.

Note

It is possible to stop the active spindle with orientation. The angular value is programmed using a transfer parameter.

Cycle CYCLE86 can be used if the spindle to be used for the boring operation is technically able to go into position-controlled spindle operation.

Programming example: Second boring pass

CYCLE86 is called at position X70 Y50 in the ZX plane. The drilling axis is the Z axis. The final drilling depth is programmed as an absolute value; no safety clearance is specified. The dwell time at the final drilling depth is 2 s. The workpiece upper edge is at Z110. In the cycle, the spindle is to rotate with M3 and to stop at 45 degrees.




Fig. 9-14

| | |
|--|---|
| N10 G0 G17 G90 F200 S300 M3 | Specification of the technological values |
| N20 T11 D1 Z112 | Approaching the retraction plane |
| N30 X70 Y50 | Approaching the drill position |
| N40 CYCLE86(112, 110, , 77, 0, 2, 3, -1, -1, 1, 45) | Cycle call with absolute drilling depth |
| N50 M2 | End of program |

9.4.10 Boring with Stop 1 (boring 3) – CYCLE87

Note

This standard cycle is not available with the 802D-bl.

Programming

CYCLE87 (RTP, RFP, SDIS, DP, DPR, SDIR)

Parameter

Table 9-8 Parameter CYCLE87

| | | |
|------|------|---------------------------------------|
| RTP | real | Retraction plane (absolute) |
| RFP | real | Reference plane (absolute) |
| SDIS | real | Safety clearance (enter without sign) |
| DP | real | Final drilling depth (absolute) |

Table 9-8 Parameter CYCLE87, Fortsetzung

| | | |
|------|------|---|
| DPR | real | Final drilling depth relative to the reference plane (enter without sign) |
| SDIR | int | Direction of rotation Values: 3 (for M3) 4 (for M4) |

Function

The tool drills at the programmed spindle speed and feedrate to the entered final drilling depth.

During boring 3, a spindle stop without orientation M5 is generated after reaching the final drilling depth, followed by a programmed stop M0. Pressing the NC START key continues the retraction movement at rapid traverse until the retraction plane is reached.

Operational sequence

Position reached prior to cycle start:

The drilling position is the position in the two axes of the selected plane.

The cycle creates the following sequence of motions:

- Approach of the reference plane brought forward by the safety clearance by using G0
- Traversing to final drilling depth with G1 and the feedrate programmed prior to the cycle call
- Spindle stop with M5
- Press NC START
- Retraction to the retraction plane with G0

Explanation of the parameters

Parameter RTP, RFP, SDIS, DP, DPR see CYCLE81




Fig. 9-15

SDIR (direction of rotation)

This parameter determines the direction of rotation with which the drilling operation is carried out in the cycle.

If values other than 3 or 4 (M3/M4) are generated, alarm 61102 "No spindle direction programmed" is generated and the cycle is aborted.

Programming example: Third boring

CYCLE87 is called at position X70 Y50 in the XY plane. The drilling axis is the Z axis. The final drilling depth is specified as an absolute value. The safety clearance is 2 mm.




Fig. 9-16

| | |
|--|--|
| DEF REAL DP, SDIS | Definition of the parameters |
| N10 DP=77 SDIS=2 | Value assignments |
| N20 G0 G17 G90 F200 S300 | Specification of the technological values |
| N30 D3 T3 Z113 | Approaching the retraction plane |
| N40 X70 Y50 | Approaching the drill position |
| N50 CYCLE87 (113, 110, SDIS, DP, , 3) | Cycle call with programmed direction of rotation of spindle M3 |
| N60 M2 | End of program |

9.4.11 Drilling with stop – CYCLE88

Programming

CYCLE88(RTP, RFP, SDIS, DP, DPR, DTB, SDIR)

Parameters

Table 9-9 Parameters of CYCLE88

| | | |
|------|------|---|
| RTP | real | Retraction plane (absolute) |
| RFP | real | Reference plane (absolute) |
| SDIS | real | Safety clearance (enter without sign) |
| DP | real | Final drilling depth (absolute) |
| DPR | real | Final drilling depth relative to the reference plane (enter without sign) |
| DTB | real | Dwell time at final drilling depth (chip breaking) |
| SDIR | int | Direction of rotation Values: 3 (for M3) 4 (for M4) |

Function

The tool drills at the programmed spindle speed and feedrate to the entered final drilling depth. During boring pass 4, a dwell time, a spindle stop without orientation M5 and a programmed stop M0 are generated when the final drilling depth is reached. Pressing the NC START key continues the retraction movement at rapid traverse until the retraction plane is reached.

Operational sequence

Position reached prior to cycle start:

The drilling position is the position in the two axes of the selected plane.

The cycle creates the following sequence of motions:

- Approach of the reference plane brought forward by the safety clearance by using G0
- Traversing to final drilling depth with G1 and the feedrate programmed prior to the cycle call
- Dwell time at final drilling depth
- Spindle and program stop with M5 M0. After program stop, press the NC START key.
- Retraction to the retraction plane with G0

Explanation of the parameters

For the parameters RTP, RFP, SDIS, DP, DPR, see CYCLE81




Fig. 9-17

DTB (dwell time)

The dwell time to the final drilling depth (chip breaking) is programmed under DTB in seconds.

SDIR (direction of rotation)

The programmed direction of rotation is active for the distance to be traversed to the final drilling depth.

If values other than 3 or 4 (M3/M4) are generated, alarm 61102 "No spindle direction programmed" is generated and the cycle is aborted.

Programming example: Drilling with stop

CYCLE88 is called at X0. The tapping axis is the Z axis. The safety clearance is programmed with 3 mm; the final drilling depth is specified relative to the reference plane. M4 is active in the cycle.

| | |
|--|--|
| N10 T1 S300 M3 | |
| N20 G17 G54 G90 F1 S450 | Specification of the technological values |
| N30 G0 X0 Z10 | Approach drilling position |
| N40 CYCLE88 (5, 2, 3, , 72, 3, 4) | Cycle call with programmed direction of rotation of spindle M4 |
| N50 M2 | End of program |

9.4.12 Reaming 2 (boring 5) – CYCLE89

Programming

CYCLE89 (RTP, RFP, SDIS, DP, DPR, DTB)

Parameter

Table 9-10 Parameter CYCLE89

| | | |
|------|------|---|
| RTP | real | Retraction plane (absolute) |
| RFP | real | Reference plane (absolute) |
| SDIS | real | Safety clearance (enter without sign) |
| DP | real | Final drilling depth (absolute) |
| DPR | real | Final drilling depth relative to the reference plane (enter without sign) |
| DTB | real | Dwell time at final drilling depth (chip breaking) |

Function

The tool drills at the programmed spindle speed and feedrate to the entered final drilling depth. If the final drilling depth is reached, a dwell time may be programmed.

Operational sequence

Position reached prior to cycle start:

The drilling position is the position in the two axes of the selected plane.

The cycle creates the following sequence of motions:

- Approach of the reference plane brought forward by the safety clearance by using G0
- Traversing to final drilling depth with G1 and the feedrate programmed prior to the cycle call
- Dwell time to final drilling depth
- Retraction up to the reference plane brought forward by the safety clearance using G1 and the same feedrate value
- Retraction to the retraction plane with G0

Explanation of the parameters

Parameter RTP, RFP, SDIS, DP, DPR see CYCLE81




Fig. 9-18

DTB (dwell time)

The dwell time to the final drilling depth (chip breaking) is programmed under DTB in seconds.

Programming example: Fifth boring

At X80 Y90 in the XY plane, the drilling cycle CYCLE89 is called with a safety clearance of 5 mm and specification of the final drilling depth as an absolute value. The drilling axis is the Z axis.




Fig. 9-19

| | |
|--|---|
| DEF REAL RFP, RTP, DP, DTB | Definition of the parameters |
| RFP=102 RTP=107 DP=72 DTB=3 | Value assignments |
| N10 G90 G17 F100 S450 M4 | Specification of the technological values |
| N20 G0 X80 Y90 Z107 | Approach drilling position |
| N30 CYCLE89(RTP, RFP, 5, DP, , DTB) | Cycle call |
| N40 M2 | End of program |

9.4.13 Row of holes – HOLES1

Programming

HOLES1 (SPCA, SPCO, STA1, FDIS, DBH, NUM)

Parameter

Table 9-11 Parameters of HOLES1

| | | |
|------|------|--|
| SPCA | real | 1. axis of the plane (abscissa) of a reference point on the straight line (absolute) |
| SPCO | real | 2. axis of the plane (ordinate) of this reference point (absolute) |
| STA1 | real | Angle to the 1st axis of the plane (abscissa) -180<STA1<=180 degrees |
| FDIS | real | Distance from the first hole to the reference point (enter without sign) |
| DBH | real | Distance between the holes (enter without sign) |
| NUM | int | Number of holes |

Function

This cycle can be used to produce a row of holes, i.e. a number of holes arranged along a straight line, or a grid of holes. The type of hole is determined by the drilling hole cycle that has already been called modally.

Operational sequence

To avoid unnecessary travel, the cycle calculates whether the row of holes is machined starting from the first hole or the last hole from the actual position of the plane axes and the geometry of the row of holes. The drilling positions are then approached one after the other at rapid traverse.




Fig. 9-20

Explanation of the parameters




Fig. 9-21

SPCA and SPCO (reference point of 1st axis of the plane and 2nd axis of the plane)

One point along the straight line of the row of holes is defined as the reference point for determining the distances between the holes. The distance to the first hole FDIS is defined from this point.

STA1 (angle)

The straight line can be in any position in the plane. It is specified both by the point defined by SPCA and SPCO and by the angle contained by the straight line with the 1st axis of the plane of the workpiece coordinate system that is active when the cycle is called. The angle is entered under STA1 in degrees.

FDIS and DBH (distance)

The distance of the first hole and the reference point defined under SPCA and SPCO is programmed with FDIS. The parameter DBH contains the distance between any two holes.

NUM (number)

The NUM parameter is used to define the number of holes.

Programming example: Row of holes

Use this program to machine a row of holes consisting of 5 threaded holes arranged parallel to the Z axis of the ZX plane and which have a distance of 20 mm one to another. The starting point of the row of holes is at Z20 and X30 whereby the first hole has a distance of 10 mm from this point. The geometry of the row of holes is described by the cycle HOLES1. First, drilling is carried out using CYCLE82, and then tapping is performed using CYCLE84 (tapping without compensating chuck). The holes are 80 mm in depth (difference between reference plane and final drilling depth).




Fig. 9-22

| | |
|--|---|
| N10 G90 F30 S500 M3 T10 D1 | Specification of the technological values for the machining step |
| N20 G17 G90 X20 Z105 Y30 | Approach starting position |
| N30 MCALL CYCLE82(105, 102, 2, 22, 0, 1) | Modal call of the drilling cycle |
| N40 HOLES1(20, 30, 0, 10, 20, 5) | Call of row-of-holes cycle; the cycle starts with the first hole; only the drill positions are approached in this cycle |
| N50 MCALL | Deselect modal call |
| ... | Tool change |
| N60 G90 G0 X30 Z110 Y105 | Traverse to position next to the 5th hole |
| N70 MCALL CYCLE84(105, 102, 2, 22, 0, , 3, , 4.2, ,300,) | Modal call of the tapping cycle |
| N80 HOLES1(20, 30, 0, 10, 20, 5) | call of the row-of-holes cycle started with the 5th hole in the row |
| N90 MCALL | Deselect modal call |
| N100 M2 | End of program |

Programming example: Grid of holes

Use this program to machine a grid of holes consisting of 5 rows with 5 holes each, which are arranged in the XY plane, with a distance of 10 mm between them. The starting point of the grid is at X30 Y20.

The example uses R parameters as transfer parameters for the cycle.




Fig. 9-23

| | |
|---------|--|
| R10=102 | Reference plane |
| R11=105 | Retraction plane |
| R12=2 | Safety clearance |
| R13=75 | Drilling depth |
| R14=30 | Reference point: Row of holes of the 1st axis of the plane |
| R15=20 | Reference point: Row of holes of the 2nd axis of the plane |
| R16=0 | Starting angle |
| R17=10 | Distance of the 1st hole to the reference point |
| R18=10 | Distance between the holes |
| R19=5 | Number of holes per row |
| R20=5 | Number of rows |
| R21=0 | Count of rows |
| R22=10 | Distance between the rows |

| | |
|--|--|
| N10 G90 F300 S500 M3 T10 D1 | Specification of the technological values |
| N20 G17 G0 X=R14 Y=R15 Z105 | Approach starting position |
| N30 MCALL CYCLE82(R11, R10, R12, R13, 0, 1) | Modal call of the drilling cycle |
| N40 LABEL1: | Call of the row-of-holes cycle |
| N41 HOLES1(R14, R15, R16, R17, R18, R19) | |
| N50 R15=R15+R22 | Calculate y value for the next line |
| N60 R21=R21+1 | Increment line counter |
| N70 IF R21<R20 GOTOB LABEL1 | Return to LABEL1 if the condition is fulfilled |
| N80 MCALL | Deselect modal call |
| N90 G90 G0 X30 Y20 Z105 | Approach starting position |
| N100 M2 | End of program |

9.4.14 Circle of holes – HOLES2

Programming

HOLES2 (CPA, CPO, RAD, STA1, INDA, NUM)

Parameter

Table 9-12 Parameters of HOLES2

| | | |
|------|------|---|
| CPA | real | Center point of circle of holes (absolute), 1st axis of the plane |
| CPO | real | Center point of circle of holes (absolute), 2nd axis of the plane |
| RAD | real | Radius of circle of holes (enter without sign) |
| STA1 | real | Starting angle Range of values: -180<STA1<=180 degrees |
| INDA | real | Incrementing angle |
| NUM | int | Number of holes |

Function

Use this circle to machine a circle of holes. The machining plane must be defined before the cycle is called.

The type of hole is determined by the drilling hole cycle that has already been called modally.




Fig. 9-24

Operational sequence

In the cycle, the drilling positions are approached one after the other in the plane with G0.




Fig. 9-25

Explanation of the parameters




Fig. 9-26

CPA, CPO and RAD (center point position and radius)

The position of the circle of holes in the machining plane is defined via center point (parameters CPA and CPO) and radius (parameter RAD). Only positive values are permitted for the radius.

STA1 and INDA (starting and incremental angle)

These parameters define the arrangement of the holes on the circle of holes.

Parameter STA1 specifies the angle of rotation between the positive direction of the 1st axis (abscissa) in the workpiece coordinate system active before the cycle was called and the first hole. Parameter INDA contains the angle of rotation from one hole to the next.

If parameter INDA is assigned the value zero, the indexing angle is calculated internally from the number of holes which are positioned equally in a circle.

NUM (number)

Parameter NUM defines the number of holes.

Programming example: Circle of holes

The program uses CYCLE82 to produce 4 holes having a depth of 30 mm. The final drilling depth is specified as a relative value to the reference plane. The circle is defined by the center point X70 Y60 and the radius 42 mm in the XY plane. The starting angle is 33 degrees. The safety clearance along the drilling axis Z is 2 mm.




Fig. 9-27

| | |
|--|---|
| N10 G90 F140 S170 M3 T10 D1 | Specification of the technological values |
| N20 G17 G0 X50 Y45 Z2 | Approach starting position |
| N30 MCALL CYCLE82(2, 0, 2, , 30, 0) | Modal call of the drilling cycle, without dwell time, DP is not programmed |
| N40 HOLES2 (70, 60, 42, 33, 0, 4) | Call of the circle-of-holes cycle; the incremental angle is calculated in the cycle since the parameter INDA has been omitted |
| N50 MCALL | Deselect modal call |
| N60 M2 | End of program |

9.5 Turning cycles

9.5.1 Preconditions

The turning cycles are part of the configuration file setup_T.cnf which is loaded into the user memory of the control system.

Call and return conditions

The G functions effective prior to the cycle call remain active beyond the cycle.

Plane definition

The machining plane must be defined prior to the cycle call. With turning, it is usually the G18 (ZX plane). The two axes of the current plane in turning will be called in the following longitudinal axis (first axis of this plane) and transverse axis (second axis of this plane).

In the turning cycles, with diameter programming active, the second axis is taken into account as the transverse axis in all cases (see Programming Guide).




Fig. 9-28

Contour monitoring referred to the tool clearance angle

Certain turning cycles in which traversing motions with relief cutting are generated monitor the clearance angle of the active tool for a possible contour violation. This angle is entered in the tool compensation as a value (in the D offset under the parameter DP24). A value between 1 and 90 degrees (0=no monitoring) without sign must be specified for the angle.




Fig. 9-29

When entering the tool clearance angle, note that this depends on the machining type 'longitudinal' or 'face'. If you want to use one tool for longitudinal and face machining, two tool compensations must be used in the case of different tool clearance angles.

The cycle will check whether or not the programmed contour can be machined using the selected tool.

If the machining is not possible using this tool, then

- the cycle will abort and an error message is output (in stock removal) or
- the contour is continued to be machined and a message is output (with undercut cycles). In this case, the contour is determined by the cutting edge geometry.

If the tool clearance angle is specified with zero in the tool compensation, this monitoring will not be performed. For details on the reactions, please refer to the individual cycles.




Fig. 9-30

9.5.2 Grooving – CYCLE93

Programming

CYCLE93(SPD, SPL, WIDG, DIAG, STA1, ANG1, ANG2, RCO1, RCO2, RCI1, RCI2, FAL1, FAL2, IDEP, DTB, VARI)

Parameters

Table 9-13 Parameters of CYCLE93

| | | |
|------|------|---|
| SPD | real | Starting point in the transverse axis |
| SPL | real | Starting point in the longitudinal axis |
| WIDG | real | Groove width (enter without sign) |
| DIAG | real | Groove depth (enter without sign) |
| STA1 | real | Angle between contour and longitudinal axis Range of values: $0 \leq \text{STA1} \leq 180$ degrees |
| ANG1 | real | Flank angle 1: on the groove side determined by the starting point (enter without sign) Range of values: $0 \leq \text{ANG1} < 89.999$ degrees |
| ANG2 | real | Flank angle 2: on the other side (enter without sign) Range of values: $0 \leq \text{ANG2} < 89.999$ |
| RCO1 | real | Radius/chamfer 1, externally: on the side determined by the starting point |
| RCO2 | real | Radius/chamfer 2, externally: |
| RCI1 | real | Radius/chamfer 1, internally: on the starting point side |
| RCI2 | real | Radius/chamfer 2, internally: |
| FAL1 | real | Finishing allowance at the recess base |
| FAL2 | real | Finishing allowance at the flanks |
| IDEP | real | Infeed depth (enter without sign) |
| DTB | real | Dwell time at recess base |
| VARI | int | Machining type Range of values: 1...8 and 11...18 |

Function

The grooving cycle can be used to carry out symmetrical and asymmetrical recesses for longitudinal and face machining at any straight contour elements. You can carry out both external and internal grooves.

Operational sequence

The infeed in the depth (towards the groove base) and in the width (from groove to groove) are calculated in the cycle internally and distributed equally with the maximum possible value.

When grooving at oblique faces, the tool will traverse from one groove to the next on the shortest path, i.e. parallel to the cone at which the groove is machined. During this process, a safety clearance to the contour is calculated internally in the cycle.

1st step

Paraxial roughing in individual infeed steps up to the base
The tool will retract for chip breaking after each infeed.




Fig. 9-31

2nd step

The groove is machined vertically to the infeed direction in one or several steps whereby each step, in turn, is divided according to the infeed depth. From the second cut along the groove width onwards, the tool will retract by 1 mm each before retraction.




Fig. 9-32

3rd step

Stock removal of the flanks in one step if angles are programmed under ANG1 or ANG2. in-feed along the groove width is carried out in several steps if the flank width is larger.




Fig. 9-33

4th step

Stock removal of the finishing allowance parallel to the contour from the edge to the groove center. During this operation, the tool radius compensation is selected and deselected by the cycle automatically.




Fig. 9-34

Explanation of the parameters

SPD and SPL (starting point)

These coordinates can be used to define the starting point of a groove starting from which the form is calculated in the cycle. The cycle starting point approached at the beginning is determined by the cycle itself. In the case of an external groove, first the tool will traverse in the direction of the longitudinal axis, and in the case of an internal groove, first in the direction of the transverse axis.

Grooves at bent contour elements can be realized differently. Depending on the form and radius of the bend, either a paraxial straight line can be laid over the maximum of the bend or a tangential oblique line can be created in a point of the edge points of the groove.

Radii and chamfers at the groove edge make sense with bent contours only if the appropriate edge point is on the straight line specified for the cycle.




Fig. 9-35

WIDG and DIAG (groove width and groove depth)

The parameters groove width (WIDG) and groove depth (DIAG) are used to define the form of the groove. In its calculation, the cycle always assumes the point programmed under SPD and SPL.

If the groove width is larger than that of the active tool, the width is removed in several steps. When doing so, the whole width is distributed by the cycle equally. The maximum infeed is 95% of the tool width after deduction of the cutting edge radii. This provides a cutting overlap.

If the programmed groove width is smaller than the real tool width, the error message 61602 "Tool width defined incorrectly" and machining is aborted. The alarm will also appear if a cutting edge width equal to zero is detected in the cycle.




Fig. 9-36

STA1 (angle)

Use the parameter STA1 to program the angle of the oblique line at which the groove is to be machined. The angle can assume values between 0 and 180 degrees and always refers to the longitudinal axis.

ANG1 and ANG2 (flank angle)

Asymmetric grooves can be described by flank angles specified separately. The angles can assume values between 0 and 89.999 degrees.

RCO1, RCO2 and RCI1, RCI2 (radius/chamfer)

The form of the groove can be modified by entering radii/chamfers at the edge or base. **Note that radii are entered with positive sign and chamfers with negative sign.**

How the programmed chamfers are taken into account is specified in dependence of the tens digit of parameter VARI.

- If VARI<10 (tens digit=0) Chamfers with CHF=...
- If VARI>10 Chamfers with CHR programming

(CHF / CHR see Section 8.1.6)

FAL1 and FAL2 (finishing allowance)

It is possible to program separate finishing allowances for groove base and flanks. During roughing, stock removal is carried out up to these finishing allowances. Then a cut is carried out parallel to the contour with the same tool along the final contour.




Fig. 9-37

IDEP (infeed depth)

You can divide the paraxial grooving into several depth infeeds by programming an infeed depth. After each infeed, the tool is retracted by 1 mm for chip breaking.

The parameter IDEP must be programmed in all cases.

DTB (dwell time)

The dwell time at the groove base should be selected such that at least one spindle revolution is carried out. It is programmed in seconds.

VARI (machining type)

The machining type of the groove is defined with the units digit of the parameter VARI. It can assume the values indicated in the illustration.

The tens digit of parameter VARI determines how the chamfers are taken into account.

VARI 1...8: The chamfers will be taken into account as CHF.

VARI 11...18: The chamfers will be taken into account as CHR.




Fig. 9-38

If the parameter has a different value, the cycle will abort with alarm 61002 "Machining type defined incorrectly".

The cycle carries out a contour monitoring such that a reasonable groove contour results. This is not the case if the radii/chamfers come into contact or intersect at the groove base or if you try to carry out a face grooving operation at a contour segment located parallel to the longitudinal axis. In such cases, the cycle will abort with alarm 61603 "Groove form defined incorrectly".

Further notes

Before calling the grooving cycle, a double-edged tool must be enabled. The offset values for the two cutting edges must be stored in two successive D numbers of the tool whereby the first of which must be activated prior to the first cycle call. The cycle itself defines for which machining step it will use which of the two tool compensation values and will also enable them automatically. After completion of the cycle, the tool compensation number programmed prior to the cycle call is active again. If no D number is programmed for a tool compensation when the cycle is called, the execution of the cycle is aborted with the alarm 61000 "No tool compensation active".

Programming example: Grooving

This program is used to produce a groove externally at an oblique line in the longitudinal direction.

The starting point is on the right-hand side at X35 Z60.

The cycle will use the tool compensations D1 and D2 of tool T5. The cutting tool must be defined accordingly.




Fig. 9-39

| | |
|---|---|
| N10 G0 G90 Z65 X50 T5 D1 S400 M3 | Starting point prior to cycle start |
| N20 G95 F0.2 | Specification of the technological values |
| N30 CYCLE93(35, 60, 30, 25, 5, 10, 20, 0, 0, -2, -2, 1, 1, 10, 1, 5) | Cycle call |
| N40 G0 G90 X50 Z65 | Next position |
| N50 M02 | End of program |

9.5.3 Undercut form E .. F – CYCLE94

Programming

CYCLE94(SPD, SPL, FORM)

Parameters

Table 9-14 Parameters of CYCLE94

| | | |
|------|------|---|
| SPD | real | Starting point in the transversal axis (enter without sign) |
| SPL | real | Starting point of the tool compensation in the longitudinal axis (enter without sign) |
| FORM | char | Definition of the form Values: E (for form E) F (for form F) |

Function

Using this cycle, you can program undercuts to DIN509 of the forms E and F for usual stress and with a finished part diameter >3 mm.




Fig. 9-40

Operational sequence

Position reached prior to cycle start:

The starting position can be any position from which the undercut can be approached without collision.

The cycle creates the following sequence of motions:

- Approach of the starting point determined in the cycle by using G0
- Selection of the cutter radius compensation according to the active tool point direction and traveling along the undercut contour at the feedrate programmed prior to the cycle call
- Retraction to the starting point with G0 and deselection of the cutter radius compensation with G40

Explanation of the parameters**SPD and SPL (starting point)**

Use the parameter SPD to specify the finished part diameter for the undercut. The finished part diameter in the longitudinal axis is defined using the parameter SPL.

If a final diameter <3 mm results for the value programmed for SPD, the cycle aborts with alarm 61601 "Finished part diameter too small".




Fig. 9-41

FORM (definition)

Form E and form F are fixed in DIN509 and must be defined using this parameter.

If the parameter has a value other than E or F, the cycle aborts and creates alarm 61609 "Form defined incorrectly".




Fig. 9-42

The tool point direction is determined by the cycle automatically from the active tool compensation. The cycle can operate with the tool point directions 1 ... 4.

If the cycle detects either of the tool point directions 5 ... 9, the alarm 61608 "Wrong tool point direction programmed" and the cycle is aborted.

The cycle determines its starting point automatically. This is by 2 mm away from the end diameter and by 10 mm away from the finishing dimension in the longitudinal axis. The position of this starting point referred to the programmed coordinate values is determined by the tool point direction of the active tool.

The clearance angle of the active tool is monitored in the cycle if an appropriate value is specified in the appropriate parameter of the tool compensation. If it turns out that the form of the undercut cannot be machined using the selected tool since its tool clearance angle is too small, the message "Changed form of undercut" is displayed on the control system. The machining, however, is continued.




Fig. 9-43

Further notes

Before you call the cycle, a tool compensation must be activated. Otherwise, the cycle is aborted after alarm 61000 "No tool compensation active" has been output.

Programming example: Undercut_form_E

This program can be used to program an undercut of form E.




Fig. 9-44

| | |
|-----------------------------------|---|
| N10 T1 D1 S300 M3 G95 F0.3 | Specification of the technological values |
| N20 G0 G90 Z100 X50 | Selection of the starting position |
| N30 CYCLE94(20, 60, "E") | Cycle call |
| N40 G90 G0 Z100 X50 | Approach next position |
| N50 M02 | End of program |

9.5.4 Stock removal – CYCLE95

Programming

CYCLE95 (NPP, MID, FALZ, FALX, FAL, FF1, FF2, FF3, VARI, DT, DAM, _VRT)

Parameters

Table 9-15 Parameters of CYCLE95

| | | |
|------|--------|---|
| NPP | string | Name of contour subroutine |
| MID | real | Infeed depth (enter without sign) |
| FALZ | real | Finishing allowance in the longitudinal axis (enter without sign) |
| FALX | real | Finishing allowance in the transverse axis (enter without sign) |
| FAL | real | Finishing allowance according to the contour (enter without sign) |
| FF1 | real | Feedrate for roughing without undercut |
| FF2 | real | Feedrate for insertion into relief cut elements |
| FF3 | real | Feedrate for finishing |
| VARI | real | Machining type Range of values: 1 ... 12 |
| DT | real | Dwell time fore chip breaking when roughing |
| DAM | real | Path length after which each roughing step is interrupted for chip breaking |
| _VRT | real | Retraction travel from the contour when roughing, incremental (enter without sign) |

Function

Using the rough turning cycle, you can produce a contour, which has been programmed in a subroutine, from a blank by paraxial stock removal. The contour may contain relief cut elements. It is possible to machine contours using longitudinal and face machining, both externally and internally. The technology can be freely selected (roughing, finishing, complete machining). When roughing the contour, paraxial cuts from the maximum programmed infeed depth are programmed and burrs are also removed parallel to the contour after an intersection point with the contour has been reached. Roughing is carried out up to the programmed finishing allowance.

Finishing is carried out in the same direction as roughing. **The tool radius compensation is selected and deselected by the cycle automatically.**




Fig. 9-45

Operational sequence

Position reached prior to cycle start:

The starting position is any position from which the contour starting point can be approached without collision.

The cycle creates the following sequence of motions:

The cycle starting point is calculated internally and approached with G0 in both axes at the same time.

Roughing without relief cut elements:

- The paraxial infeed to the current depth is calculated internally and approached with G0.
- Approach of paraxial roughing intersection point with G1 and at feedrate FF1.
- Rounding parallel to the contour along the contour + finishing allowance with G1/G2/G3 and FF1.
- Retraction by the amount programmed under `_VRT` in each axis and retraction with G0.
- This sequence is repeated until the total depth of the machining step is reached.
- When roughing without relief cut elements, retraction to the cycle starting point is carried out axis by axis.




Fig. 9-46

Roughing the relief cut elements:

- Approach of the starting point for the next relief cut axis by axis with G0. When doing so, an additional cycle-internal safety clearance is observed.
- Infeed along the contour + finishing allowance with G1/G2/G3 and FF2.
- Approach of paraxial roughing intersection point with G1 and at feedrate FF1.
- Rounding along the contour, retraction and return are carried out as with the first machining step.
- If there are further relief cut elements, this sequence is repeated for each relief cut.




Fig. 9-47

Finishing:

- The cycle starting point is approached axis by axis with G0.
- The contour starting point is approached with G0 in both axes at the same time.
- Finishing along the contour with G1/G2/G3 and FF3
- Retraction to the starting point with both axes and G0

Explanation of the parameters**NPP (name)**

This parameter is used to specify the name of the contour.

1. The contour can be defined as a subroutine:
NPP=name of subroutine

The name of the contour subroutine is subject to all name conventions described in the Programming Guide.

Input:

- The subroutine already exists --> enter name, continue
- The subroutine does not yet exist --> enter name and press softkey "**new file**". A program (main program) with the entered name is created and the program will jump to the contour editor.

To quit your input, press the softkey "**Technol. mask**"; the program returns to the cycle support screenform.

2. The contour can also be a section of the calling program:
NPP=name of starting label: name of end label

Input:

- Contour is already described --> name of starting label: Enter name of end label
- Contour is not yet described --> enter name of starting label and press softkey "**contour append**".
Starting and end label are automatically created from the name you have entered; then the program will jump to the contour editor.

To quit your input, press the softkey "**Technol. mask**"; the program returns to the cycle support screenform.




Fig. 9-48

Examples:

NPP=KONTUR_1

The rough turning contour is the complete program Kontur_1.

NPP=ANFANG:ENDE

The rough turning contour is defined as a section in the calling program, which starts from the block containing label ANFANG to the block containing label ENDE.

MID (infeed depth)

Parameter MID is used to define the maximum possible infeed depth for the roughing process.

The cycle will automatically calculate the current infeed depth used for roughing.

With contours containing relief cut elements, the roughing process is divided by the cycle into individual roughing sections. The cycle calculates a new current infeed depth for each roughing section. This infeed depth is always between the programmed infeed depth and the half of its value. The number of required roughing steps is determined on the basis of the total depth of a roughing section and of the programmed maximum infeed depth to which the total depth to be machined is distributed equally. This provides optimum cutting conditions. For roughing this contour, the machining steps shown in the illustration result.




Fig. 9-49

Example of calculating the current infeed depth:

Machining step 1 has a total depth of 39 mm. Therefore, 8 roughing steps are still required with a maximum infeed depth of 5 mm. These are carried out with an infeed of 4.875 mm.

In machining step 2, 8 roughing steps, too, are carried out with an infeed of 4.5 mm each (total difference 36 mm).

In machining step 3, two roughing passes are carried out with a current infeed of 3.5 (total difference 7 mm).

FAL, FALZ and FALX (finishing allowance)

A finishing allowance for roughing can be specified either using the parameters FALZ and FALX if you want to specify different finishing allowances axis-specifically or via the parameter FAL for a finishing allowance that follows the contour. In this case, this value is taken into account in both axes as a finishing allowance.

No plausibility check is carried out for the programmed values. In other words: If all three parameters are assigned values, all these finishing allowances are taken into account by the cycle. It is, however, reasonable to decide either on the one or other form of definition of a finishing allowance.

Roughing is always carried out up to these finishing allowances. The resulting residual corner is also removed parallel to the contour after each paraxial roughing process immediately so that no additional residual corner cut is required after completion of roughing. If no finishing allowances are programmed, stock is removed when roughing up to the final contour.

FF1, FF2 and FF3 (feedrate)

Different feedrates can be specified for the individual machining steps as shown in the illustration.




Fig. 9-50

VARI (machining type)

Table 9-16 Type of machining

| Value | Longitudinal/face | Ext./int. | Roughing/finishing/complete |
|-------|-------------------|-----------|-----------------------------|
| 1 | L | A | Roughing |
| 2 | P | A | Roughing |
| 3 | L | I | Roughing |
| 4 | P | I | Roughing |
| 5 | L | A | Finishing |
| 6 | P | A | Finishing |
| 7 | L | I | Finishing |
| 8 | P | I | Finishing |
| 9 | L | A | Complete machining |
| 10 | P | A | Complete machining |
| 11 | L | I | Complete machining |
| 12 | P | I | Complete machining |

In longitudinal machining, the infeed is always carried out along the transversal axis, and in face machining - along the longitudinal axis.

External machining means that the infeed is carried out in the direction of the negative axis. With internal machining, the infeed is carried out in the direction of the positive axis.

The parameter VARI is subjected to a plausibility check. If its value is not in the range 1 ... 12 when the cycle is called, the cycle is aborted with alarm 61002 "Machining type defined incorrectly".




Fig. 9-51

DT and DAM (dwell time and path length)

These parameters can be used to achieve an interruption of the individual roughing steps after certain distances traversed in order to carry out chip breaking. These parameters are only relevant for roughing. The parameter DAM is used to define the maximum distance after which chip breaking is to be carried out. In DT, an appropriate dwell time (in seconds) can be programmed which is carried out at each of the cut interruption points. If no distance is specified for the cut interruption (DAM=0), uninterrupted roughing steps without dwell times are created.




Fig. 9-52

_VRT (retraction travel)

Parameter _VRT can be used to program the amount by which the tool is retracted in both axes when roughing.

If _VRT=0 (parameter not programmed), the tool will retract by 1 mm.

Further notes: Contour definition

The contour must contain at least 3 blocks with motions in the two axes of the machining plane.

If the contour is shorter, the cycle is aborted after the alarms 10933 "Number of contour blocks contained in the contour program not sufficient" and 61606 "Error in contour preparation" have been output.

Relief cut elements can be connected directly one after the other. Blocks without motions in the plane can be written without restrictions.

In the cycle, all traversing blocks are prepared for the first two axes of the current plane since only these are involved in the cutting process. The contour program may contain any motions programmed for other axes; their distances to be traversed, however, will not come into effect during the whole cycle.

Only straight line and circle programming with G0, G1, G2 and G3 are permitted as the geometry in the contour. Furthermore, it is also possible to program the commands for rounding and chamfer. If any other motion commands are programmed in the contour, the cycle is aborted with the alarm 10930 "Illegal type of interpolation in the stock removal contour".

The first block with traversing motion in the current machining plane must contain a motion command G0, G1, G2 or G3; otherwise, the cycle is aborted with alarm 15800 "Illegal initial conditions for CONTPRON". This alarm will also appear with active G41/42. The starting condition of the contour is the first position in the machining plane which is programmed in the contour subroutine.

To process the programmed contour, a cycle-internal memory is prepared which can accommodate a maximum number of contour elements. Much is dependent on the contour: If a contour contains too many contour elements, the cycle is aborted with alarm 10934 "Contour table overflow". In this case, the contour must be divided into several contour sections, and the cycle has to be called for each section separately.

If the maximum diameter is not at the programmed end or starting point of the contour, at the end of machining, the cycle will automatically add a paraxial straight line up to the maximum of the contour, and this part of the contour will be removed as the relief cut.




Fig. 9-53

The programming of the tool radius compensation with G41/G42 in the contour subroutine will result in abortion of the cycle with output of alarm 10931 "Invalid stock removal contour".

Contour direction

The direction in which the stock removal contour is programmed can be freely selected. In the cycle, the machining direction is defined automatically. In complete machining, the contour is finished in the same direction as machining was carried out when roughing.

When deciding on the machining direction, the first and the last programmed contour points are taken into account. Therefore, both coordinates must always be programmed in the first block of the contour subroutine.

Contour monitoring

The cycle provides contour monitoring with regard to the following:

- Clearance angle of the active tool
- Circle programming of arcs with an aperture angle > 180 degrees

With relief cut elements, the cycle checks whether the machining is possible using the active tool. If the cycle detects that this machining will result in a contour violation, it will be aborted after alarm 61604 "Active tool violates programmed contour" has been output.

If the tool clearance angle is specified with zero in the tool compensation, this monitoring will not be performed.

If too large arcs are found in the compensation, alarm 10931 "Incorrect machining contour" appears.

Starting point

The cycle determines the starting point for machining operation automatically. The starting point is located in an axis in which the depth infeed is carried out, by the finishing allowance + retraction travel (parameter `_VRT`) from the contour away. In the other axis, it is by finishing allowance + `_VRT` ahead of the contour starting point.

When the starting point is approached, the cutter radius compensation is selected internally in the cycle.

The last point before the cycle is called must therefore be selected such that this approach is possible without collision and space enough is provided to carry out the appropriate compensatory motion.




Fig. 9-54

Cycle approach strategy

In roughing, the starting point determined by the cycle is always approached with both axes simultaneously, and in finishing, axis by axis. In finishing, the infeed axis traverses first.

Programming example 1: Stock removal cycle

The contour shown in the illustration to explain the defining parameters is to be machined longitudinally externally by complete machining. Axis-specific finishing allowances are specified. Cutting will not be interrupted when roughing. The maximum infeed is 5 mm.

The contour is stored in a separate program.




Fig. 9-55

| | |
|--|-------------------------------------|
| N10 T1 D1 G0 G95 S500 M3 Z125 X81 | Approach position prior to the call |
| N20 CYCLE95("KONTUR_1", 5, 1.2, 0.6, , 0.2, 0.1, 0.2, 9, , , 0.5) | Cycle call |
| N30 G0 G90 X81 | Reapproach of starting position |
| N40 Z125 | Traversing by axes |
| N50 M30 | End of program |
| %_N_KONTUR_1_SPF | Start of contour subroutine |
| N100 Z120 X37 | Traversing by axes |
| N110 Z117 X40 | |
| N120 Z112 RND=5 | Rounding with radius 5 |
| N130 Z95 X65 | Traversing by axes |
| N140 Z87 | |
| N150 Z77 X29 | |
| N160 Z62 | |
| N170 Z58 X44 | |
| N180 Z52 | |
| N190 Z41 X37 | |
| N200 Z35 | |
| N210 X76 | |
| N220 M17 | End of subroutine |

Programming example 2: Stock removal cycle

The stock removal contour is defined in the calling program and is traversed directly after the cycle for finishing has been called.




Fig. 9-56

| | |
|--|------------|
| N110 G18 DIAMOF G90 G96 F0.8 | |
| N120 S500 M3 | |
| N130 T1 D1 | |
| N140 G0 X70 | |
| N150 Z160 | |
| N160 CYCLE95("ANFANG:ENDE",2.5,0.8, 0.8,0,0.8,0.75,0.6,1, , ,) | Cycle call |
| N170 G0 X70 Z160 | |
| N175 M02 | |
| ANFANG: | |
| N180 G1 X10 Z100 F0.6 | |
| N190 Z90 | |
| N200 Z70 ANG=150 | |
| N210 Z50 ANG=135 | |
| N220 Z50 X50 | |
| ENDE: | |
| N230 M02 | |

9.5.5 Thread undercut – CYCLE96

Programming

CYCLE96 (DIATH, SPL, FORM)

Parameter

Table 9-17 Parameters of CYCLE94

| | | |
|-------|------|--|
| DIATH | real | Nominal diameter of the thread |
| SPL | real | Starting point of the correction in the longitudinal axis |
| FORM | char | Definition of the form Values: A (for form A) B (for form B) C (for form C) D (for form D) |

Function

Using this cycle, you can perform thread undercuts to DIN76 for parts with metrical ISO thread.




Fig. 9-57

Operational sequence

Position reached prior to cycle start:

The starting position can be any position from which each thread undercut can be approached without collision.

The cycle creates the following sequence of motions:

- Approach of the starting point determined in the cycle by using G0
- Selection of tool radius compensation according to the active tool point direction. Traversing along the undercut contour using the feedrate programmed before the cycle was called
- Retraction to the starting point with G0 and deselection of the tool radius compensation with G40

Explanation of the parameters

DIATH (nominal diameter)

Using this cycle, you can perform thread undercuts for metric threads from M3 through M68.

If a final diameter <3 mm results according to the value programmed for DIATH, the cycle is terminated, generating the alarm

61601 "Finished part diameter too small"

If the parameter has a value other than specified in DIN76 Part 1, the cycle is also terminated, generated the alarm

61001 "Thread pitch defined incorrectly".

SPL (starting point)

The finished dimension in the longitudinal axis is defined using the parameter SPL.




Fig. 9-58

FORM (definition)

Thread undercuts of the forms A and B are defined for external threads, form A for standard run-outs of threads, and form B for short run-outs of threads.

Thread undercuts of the forms C and D are used for internal threads, form C for a standard run-out of the thread, and form D for a short run-out.

If the parameter has a value other than A ... D, the cycle aborts and creates alarm 61609 "Form defined incorrectly".

Internally in the cycle, the tool radius compensation is selected automatically.

The cycle uses only the tool point directions 1 ... 4. If the cycle recognizes one of the tool point directions 5 ... 9 or if the relevant undercut form cannot be machined using the selected tool point direction, the alarm 61608 "Wrong tool point direction programmed" appears, and the cycle is terminated.

The cycle will find the starting point determined by the tool point direction of the active tool and the thread diameter automatically. The position of this starting point referred to the programmed coordinate values is determined by the tool point direction of the active tool.

For the forms A and B, the undercut angle of the active tool is monitored in the cycle. If it is detected that the form of the undercut cannot be machined using the selected tool, the message "Changed form of undercut" is displayed on the control system; the machining, however, is continued.




Fig. 9-59




Fig. 9-60

Further notes

Before calling the cycle, a tool compensation must be activated. Otherwise, the cycle is terminated and the error message 61000 "No tool compensation active" is issued.

Programming example: Thread_undercut_form_A

This program can be used to program a thread undercut of form A.




Fig. 9-61

| | |
|-----------------------------------|---|
| N10 D3 T1 S300 M3 G95 F0.3 | Specification of the technological values |
| N20 G0 G90 Z100 X50 | Selection of the starting position |
| N30 CYCLE96 (40, 60, "A") | Cycle call |
| N40 G90 G0 X30 Z100 | Approach next position |
| N50 M30 | End of program |

9.5.6 Thread cutting – CYCLE97

Programming

CYCLE97(PIT, MPIT, SPL, FPL, DM1, DM2, APP, ROP, TDEP, FAL, IANG, NSP, NRC, NID, VARI, NUMT)

Parameters

Table 9-18 Parameters of CYCLE97

| | | |
|------|------|--|
| PIT | real | Thread pitch as a value (enter without sign) |
| MPIT | real | Thread pitch as a thread size Range of values: 3 (for M3) ... 60 (for M60) |
| SPL | real | Thread starting point in the longitudinal axis |
| FPL | real | Thread end point in the longitudinal axis |
| DM1 | real | Thread diameter at the starting point |
| DM2 | real | Thread diameter at the end point |
| APP | real | Run-in path (enter without sign) |
| ROP | real | Run-out path (enter without sign) |
| TDEP | real | Thread depth (enter without sign) |
| FAL | real | Finishing allowance (enter without sign) |
| IANC | real | Infeed angle Range of values: "+" (for flank infeed at the flank) "–" (for alternating flank infeed) |
| NSP | real | Starting point offset for the first thread turn (enter without sign) |
| NRC | int | Number of roughing cuts (enter without sign) |
| NID | int | Number of idle passes (enter without sign) |
| VARI | int | Determination of machining type for the thread Range of values: 1 ... 4 |
| NUMT | int | Number of thread starts (enter without sign) |

Function

Using the thread cutting cycle, you can produce cylindrical and tapered external and internal threads with constant pitch in longitudinal and face machining. The threads can be both single-start and multiple threads. With multiple threads, the individual thread starts are machined one after the other.

The infeed is performed automatically; you can choose between the variants constant infeed per cut or constant cutting cross-section.

Right-hand or left hand thread is determined by the direction of rotation of the spindle which must be programmed prior to the cycle start.

Both feed and spindle override are ineffective in the traversing blocks with thread.




Fig. 9-62

Important

To be able to use this cycle, a speed-controlled spindle with position measuring system is required.

Operational sequence

Position reached prior to cycle start:

Starting position is any position from which the programmed thread starting point + run-in path can be approached without collision.

The cycle creates the following sequence of motions:

- Approach of the starting point determined in the cycle at the beginning of the run-in path for the first thread turn with G0
- Infeed for roughing according to the infeed type defined under VARI.
- Thread cutting is repeated according to the programmed number of roughing cuts.
- The finishing allowance is removed in the following step with G33.
- This step is repeated according to the number of idle passes.
- The whole sequence of motions is repeated for each further thread turn.

Explanation of the parameters




Fig. 9-63

PIT and MPIT (value and thread size)

The thread pitch is an axis-parallel value and is specified without sign. To produce metric cylindrical threads, it is also possible to specify the thread start as a thread size via the parameter MPIT (M3 to M60). Only one of the two parameters should be used by option. If they contain contradicting values, the cycle generates the alarm 61001 "Invalid thread pitch" and is aborted.

DM1 and DM2 (diameter)

Use this parameter to define the thread diameter of starting and end point of the thread. In the case of internal threads, this is the tap-hole diameter.

Interrelation SPL, FPL, APP and ROP (starting, end point, run-in and run-out path)

The programmed starting point (SPL) or end point (FPL) constitutes the original starting point of the thread. The starting point used in the cycle, however, is the starting point brought forward by the run-in path APP, and, correspondingly, the end point is the programmed end point brought back by the run-out path ROP. In the transversal axis, the starting point defined by the cycle is always by 1 mm above the programmed thread diameter. This retraction plane is generated in the internally control system automatically.

Interrelation TDEP, FAL, NRC and NID (thread depth, finishing allowance, number of cuts)

The programmed finishing allowance acts paraxially and is subtracted from the specified thread depth TDEP; the remainder is divided into roughing cuts.

The cycle will calculate the individual infeed depth automatically, depending on the parameter VARI.

When the thread depth is divided into infeeds with constant cutting cross-section, the cutting force will remain constant over all roughing cuts. In this case, the infeed will be performed using different values for the infeed depth.

A second variant is the distribution of the whole thread depth to constant infeed depths. When doing so, the cutting cross-section becomes larger from cut to cut, but with smaller values for the thread depth, this technology can result in better cutting conditions.

The finishing allowance FAL is removed after roughing in one step. Then the idle passes programmed under parameter NID are executed.

IANG (infeed angle)

Using parameter IANG, the angle is defined under which the infeed is carried out in the thread. If you wish to infeed at a right angle to the cutting direction in the thread, the value of this parameter must be set to zero. If you wish to infeed along the flanks, the absolute value of this parameter may amount maximally to the half of the flank angle of the tool.




Fig. 9-64

The execution of the infeed is defined by the sign of this parameter. With a positive value, infeed is always carried out at the same flank, and with a negative value, at both flanks alternating. The infeed type with alternating flanks is only possible for cylindrical threads. If the value of IANG for tapered threads is nonetheless negative, the cycle will carry out a flank infeed along a flank.

NSP (starting point offset) and NUMT (number)

Using this parameter, you can program the angle value defining the point of the first cut of the thread turn at the circumference of the turned part. This is a starting point offset. The parameter can assume values between 0 and +359.9999 degrees. If no starting point offset is specified or the parameter is omitted from the parameter list, the first thread turn automatically starts at the zero-degree mark.




Fig. 9-65

Use the parameter NUMT to define the number of thread turns with a multiple-turn thread. For a single-turn thread, the parameter must be assigned zero or can be dropped completely in the parameter list.

The thread turns are distributed equally over the circumference of the turned part; the first thread turn is determined by the parameter NSP.

To produce a multiple-turn thread with an asymmetrical arrangement of the thread turns on the circumference, the cycle for each thread turn must be called when programming the appropriate starting point offset.

VARI (machining type)

Using the parameter VARI, it is defined whether external or internal machining will be carried out and which technology will be used with regard to the infeed when roughing. The parameter VARI can assume values between 1 and 4 with the following meaning:




Fig. 9-66

Table 9-19 Type of machining

| Value | Ext./int. | Const. infeed/const. cutting cross-section |
|-------|-----------|--|
| 1 | A | Constant infeed |
| 2 | I | Constant infeed |
| 3 | A | Constant cutting cross-section |
| 4 | I | Constant cutting cross-section |

If a different value is programmed for the parameter VARI, the cycle is aborted after output of alarm 61002 "Machining type defined incorrectly".

Further notes

Differentiation between longitudinal and transversal thread

The decision whether a longitudinal or transversal thread is to be machined is made by the cycle itself. This depends on the angle of the taper at which the threads are cut. If the angle at the taper is ≤ 45 degrees, the thread of the longitudinal axis is machined, otherwise - the transversal thread.




Fig. 9-67

Programming example: Thread cutting

Using this program, you can produce a metric external thread M42x2 with flank infeed. Infeed is carried out with constant cutting cross-section. 5 roughing cuts are carried out at a thread depth of 1.23 mm without finishing allowance. At completion of this operation, 2 idle passes will be carried out.




Fig. 9-68

| | |
|--|---|
| N10 G0 G90 Z100 X60 | Selection of the starting position |
| N20 G95 D1 T1 S1000 M4 | Specification of the technological values |
| N30 CYCLE97(, 42, 0, -35, 42, 42, 10, 3, 1.23, 0, 30, 0, 5, 2, 3, 1) | Cycle call |
| N40 G90 G0 X100 Z100 | Approach next position |
| N50 M2 | End of program |

9.5.7 Chaining of threads – CYCLE98

Note

This standard cycle is not available with the 802D-bl.

Programming

CYCLE98 (PO1, DM1, PO2, DM2, PO3, DM3, PO4, DM4, APP, ROP, TDEP, FAL, IANG, NSP, NRC, NID, PP1, PP2, PP3, VARI, NUMT)

Parameter

Table 9-20 Parameter CYCLE98

| | | |
|-----|------|---|
| PO1 | real | Thread starting point in the longitudinal axis |
| DM1 | real | Thread diameter at the starting point |
| PO2 | real | First intermediate point in the longitudinal axis |
| DM2 | real | Diameter at the first intermediate point |

Table 9-20 Parameter CYCLE98, continued

| | | |
|------|------|--|
| PO3 | real | Second intermediate point |
| DM3 | real | Diameter at the second intermediate point |
| PO4 | real | Thread end point in the longitudinal axis |
| DM4 | real | Diameter at the end point |
| APP | real | Run-in path (enter without sign) |
| ROP | real | Run-out path (enter without sign) |
| TDEP | real | Thread depth (enter without sign) |
| FAL | real | Finishing allowance (enter without sign) |
| IANG | real | Infeed angle Range of values: "+" (for flank infeed at the flank) "-" (for alternating flank infeed) |
| NSP | real | Starting point offset for the first thread turn (enter without sign) |
| NRC | int | Number of roughing cuts (enter without sign) |
| NID | int | Number of idle passes (enter without sign) |
| PP1 | real | Thread pitch 1 as a value (enter without sign) |
| PP2 | real | Thread pitch 2 as a value (enter without sign) |
| PP3 | real | Thread pitch 3 as a value (enter without sign) |
| VARI | int | Determination of machining type for the thread Range of values: 1 ... 4 |
| NUMT | int | Number of thread starts (enter without sign) |

Function

Using this cycle, it is possible to produce several chained cylindrical or taper threads with constant pitch using in longitudinal and face traversing, whereby the pitch may be different.




Fig. 9-69

Operational sequence

Position reached prior to cycle start:

Starting position is any position from which the programmed thread starting point + run-in path can be approached without collision.

The cycle creates the following sequence of motions:

- Approach of the starting point determined in the cycle at the beginning of the run-in path for the first thread turn with G0
- Infeed for roughing according to the infeed type defined under VARI.
- Thread cutting is repeated according to the programmed number of roughing cuts.
- The finishing allowance is removed in the following step with G33.
- This step is repeated according to the number of idle passes.
- The whole sequence of motions is repeated for each further thread turn.

Explanation of the parameters




Fig. 9-70

PO1 and DM1 (starting point and diameter)

Using these parameters, you determine the original starting point for the thread chain. The starting point determined by the cycle itself and approached at the beginning using G0 is located by the run-in path before the programmed starting point (starting point A in the diagram on the previous page).

PO2, DM2 and PO3, DM3 (intermediate point and diameter)

These parameters are used to define two intermediate points in the thread.

PO4 and DM4 (end point and diameter)

The original end point of the thread is programmed using the parameters PO4 and DM4. In the case of internal threads, DM1 ... DM4 are the tap-hole diameter.

Interrelation between APP and ROP (run-in/run-out paths)

The starting point used in the cycle, however, is the starting point brought forward by the run-in path APP, and, correspondingly, the end point is the programmed end point brought back by the run-out path ROP.

In the transversal axis, the starting point defined by the cycle is always by 1 mm above the programmed thread diameter. This retraction plane is generated in the internally control system automatically.

Interrelation between TDEP, FAL, NRC and NID (thread depth, finishing allowance, number of roughing and idle passes)

The programmed finishing allowance acts paraxially and is subtracted from the specified thread depth TDEP; the remainder is divided into roughing cuts. The cycle will calculate the individual infeed depth automatically, depending on the parameter VARI. When the thread depth is divided into infeeds with constant cutting cross-section, the cutting force will remain constant over all roughing cuts. In this case, the infeed will be performed using different values for the infeed depth.

A second variant is the distribution of the whole thread depth to constant infeed depths. When doing so, the cutting cross-section becomes larger from cut to cut, but with smaller values for the thread depth, this technology can result in better cutting conditions.

The finishing allowance FAL is removed after roughing in one step. Then the idle passes programmed under parameter NID are executed.

IANG (infeed angle)




Fig. 9-71

Using parameter IANG, the angle is defined under which the infeed is carried out in the thread. If you wish to infeed at a right angle to the cutting direction in the thread, the value of this parameter must be set to zero. In other words, the parameter may also be omitted from the parameter list, since in this case, it is automatically loaded with zero by default. If you wish to infeed along the flanks, the absolute value of this parameter may amount maximally to the half of the flank angle of the tool.

The execution of the infeed is defined by the sign of this parameter. With a positive value, infeed is always carried out at the same flank, and with a negative value, at both flanks alternating. The infeed type with alternating flanks is only possible for cylindrical threads. If the value of IANG for tapered threads is nonetheless negative, the cycle will carry out a flank infeed along a flank.

NSP (starting point offset)

Using this parameter, you can program the angle value defining the point of the first cut of the thread turn at the circumference of the turned part. This is a starting point offset. The parameter can assume values between 0.0001 and +359.9999 degrees. If no starting point offset is specified or the parameter is omitted from the parameter list, the first thread turn automatically starts at the zero-degree mark.

PP1, PP2 and PP3 (thread pitch)

Using these parameters, you will define the thread pitch from the three sections of the thread chain. The pitch value must be entered as a paraxial value without sign.

VARI (machining technology)

Using the parameter VARI, it is defined whether external or internal machining will be carried out and which technology will be used with regard to the infeed when roughing. The parameter VARI can assume values between 1 and 4 with the following meaning:




Fig. 9-72

| Value | Ext./int. | Const. infeed/const. cutting cross-section |
|-------|-----------|--|
| 1 | external | Constant infeed |
| 2 | internal | Constant infeed |
| 3 | external | Constant cutting cross-section |
| 4 | internal | Constant cutting cross-section |

If a different value is programmed for the parameter VARI, the cycle is aborted after output of alarm 61002 "Machining type defined incorrectly".

NUMT (number of thread starts)

Use the parameter NUMT to define the number of thread turns with a multiple-turn thread. For a single-turn thread, the parameter must be assigned zero or can be dropped completely in the parameter list.

The thread turns are distributed equally over the circumference of the turned part; the first thread turn is determined by the parameter NSP.

To produce a multiple-turn thread with an asymmetrical arrangement of the thread turns on the circumference, the cycle for each thread turn must be called when programming the appropriate starting point offset.




Fig. 9-73

Programming example: Thread chain

Using this program, you may produce a thread chain starting with a cylindrical thread. The infeed is performed vertically to the thread; neither finishing allowance, nor starting point offset are programmed. 5 roughing cuts and one idle passes are executed.

The machining type specified is longitudinal, external, with constant cross-sectional area of cut.




Fig. 9-74

| | |
|--|---|
| N10 G95 T5 D1 S1000 M4 | Specification of the technological values |
| N20 G0 X40 Z10 | Approach starting position |
| N30 CYCLE98 (0, 30, -30, 30, -60, 36, -80, 50, 10, 10, 0.92, , , 5, 1, 1.5, 2, 2, 3, 1) | Cycle call |
| N40 G0 X55 N50 Z10 N60 X40 | Traversing by axes |
| N70 M2 | End of program |

9.6 Error Messages and Error Handling

9.6.1 General notes

If error conditions are detected in the cycles, an alarm is generated and the execution of the cycle is aborted.

Furthermore, the cycles display their messages in the message line of the control system. These message will not interrupt the program execution.

The errors with their reactions and the messages in the message line of the control system are described in conjunction with the individual cycles.

9.6.2 Error handling in the cycles

Alarms with numbers between 61000 and 62999 generated in the cycles. This range of numbers, in turn, is divided again with regard to alarm responses and cancel criteria.

The error text that is displayed together with the alarm number gives you more detailed information on the error cause.

Table 9-21

| Alarm Number | Clear Criterion | Alarm Response |
|-----------------|-----------------|--|
| 61000 ... 61999 | NC_RESET | Block preparation in the NC is aborted |
| 62000 ... 62999 | Clear key | The block preparation is interrupted; the cycle can be continued with NC START after the alarm has been cleared. |

9.6.3 Overview of cycle alarms

The error numbers are classified as follows:

| | | | | |
|---|---|---|---|---|
| 6 | - | X | - | - |
|---|---|---|---|---|

- X=0 General cycle alarms
- X=1 Alarms generated by the drilling, drilling pattern and milling cycles
- X=6 Alarms generated by the drilling cycles

The Table below includes a list of all errors occurring in the cycles with their location of occurrence and appropriate instructions for fault correction.

Table 9-22

| Alarm Number | Alarm Text | Source | Explanation, Remedy |
|--------------|--|-----------------------------------|---|
| 61000 | "No tool compensation active" | CYCLE93 to CYCLE95 | D offset must be programmed prior to cycle call |
| 61001 | "Illegal thread pitch" | CYCLE84 CYCLE840 CYCLE97 | Check parameters for thread size or pitch specification (are contradicting) |
| 61002 | "Machining type defined incorrectly" | CYCLE93 CYCLE95 CYCLE97 | The value of parameters VARI for the machining type is specified incorrectly and must be changed |
| 61101 | "Reference plane defined incorrectly" | CYCLE82 to CYCLE88 CYCLE840 | Either different values for reference and retraction plane must be selected in the case of relative specification of the depth or an absolute value must be specified for the depth. |
| 61102 | "No spindle direction programmed" | CYCLE88 CYCLE840 | Parameter SDIR (or SDR in CYCLE840) must be programmed |
| 61107 | "First drilling depth defined incorrectly" | CYCLE83 | First drilling depth is opposite to total drilling depth |
| 61601 | "Finished part diameter too small" | CYCLE94 | No finished part diameter was programmed. |
| 61602 | "Too width defined incorrectly" | CYCLE93 | Cutting tool is larger than programmed groove width |
| 61603 | "Groove form defined incorrectly" | CYCLE93 | <ul style="list-style-type: none"> • Radii/chamfers at groove base do not match with groove width • Face groove at a contour element running parallel to the longitudinal axis is not possible. |
| 61604 | "Active tool violates programmed contour" | CYCLE95 | Contour violation in relief cut elements due to the clearance angle of the tool used, i.e. use a different tool or check the contour subroutine. |
| 61605 | "Contour programmed incorrectly" | CYCLE95 | Illegal relief cut element detected |
| 61606 | "Error in contour preparation" | CYCLE95 | An error has been found in the contour preparation; this alarm always occurs in conjunction with an NCK alarm 10930 ... 10934, 15800 or 15810 |
| 61607 | "Starting point programmed incorrectly" | CYCLE95 | The starting point reached prior to the cycle call is not outside the rectangle described by the contour subroutine. |
| 61608 | "Invalid tool point direction programmed" | CYCLE94 | A tool point direction 1...4 matching to the relief cut form must be programmed. |
| 61609 | "Form defined incorrectly" | CYCLE94 | Check the parameters for the relief cut form. |
| 61611 | "No intersection point found" | CYCLE95 | No intersection point with the contour could be calculated. Check the contour programming or change the infeed depth. |

9.6.4 Messages in the cycles

The cycles display their messages in the message line of the control system. These message will not interrupt the program execution.

Messages provide information with regard to a certain behavior of the cycles and with regard to the progress of machining and are usually kept beyond a machining step or until the end of the cycle. The following messages are possible:

Table 9-23

| Message Text | Source |
|---|-----------------------------|
| "Depth: according to the value for the relative depth" | CYCLE82...CYCLE88, CYCLE840 |
| "1st drilling depth: according to the value for the relative depth" | CYCLE83 |
| "Thread turn <no.> - machining as a longitudinal thread" | CYCLE97 |
| "Thread turn <no.> - machining as a transversal thread" | CYCLE97 |

no.> in the message text always stands for the number of the figure currently machined.

Index

A

absolute drilling depth, 9-241
Address, 8-132

B

Block search, 5-66
Block structure, 8-133
Boring, 9-238
boring 1, 9-256
Boring 2, 9-259
Boring 3, 9-262
Boring 5, 9-267

C

Call conditions, 9-234, 9-238
Center drilling, 9-243
Centering, 9-240
Chaining of threads - CYCLE98, 9-314
Character set, 8-134
Circle of holes, 9-273
Configuring input screenforms, 9-237
Contour definition, 9-299
Contour monitoring, 9-277, 9-301
CONTPRON, 9-300
Cycle alarms, 9-321
Cycle call, 9-234
Cycle support in the program editor, 9-236
CYCLE81, 9-240
CYCLE82, 9-243
CYCLE83, 9-245
CYCLE84, 9-249
CYCLE840, 9-252
CYCLE85, 9-256
CYCLE86, 9-259
CYCLE87, 9-262
CYCLE88, 9-265
CYCLE89, 9-267
CYCLE93, 9-279
CYCLE94, 9-287
CYCLE95, 9-291
CYCLE96, 9-304
CYCLE97, 9-308
CYCLE98, 9-314

D

Data transfer, 6-97
Deep hole drilling, 9-245

Deep hole drilling with chip breaking, 9-246
Deep hole drilling with swarf removal, 9-246
Determining tool offsets, 3-33
Drilling, 9-240
Drilling cycles, 9-233, 9-238
Drilling with stop, 9-265

E

Entering tools and tool offsets, 3-30

F

Fundamentals of NC Programming, 8-131

G

Geometrical parameters, 9-238
Grooving - CYCLE93, 9-279

H

Handwheel, 4-53
HOLES1, 9-269
HOLES2, 9-273

I

Interface parameters, 7-118

J

JOG, 4-50
JOG mode, 4-50

L

Longitudinal thread, 9-313

M

Machine zero, 3-42
Machining parameters, 9-238
Machining plane, 9-234
Manual data input, 4-54
MDA mode, 4-54
Messages, 9-323

O

Operating area "Machine", 4-50
Operating areas, 1-16
Operating the cycle selection, 9-236
Overview of cycle alarms, 9-321
Overview of cycle files, 9-236

P

Part program
 selecting, starting, 5-65
 stopping, aborting, 5-67
Plane definition, 9-234

R

R parameters, 3-47
Re-approach after interruption, 5-68
Reference plane, 9-240
relative drilling depth, 9-241
Repositioning after interrupting, 5-68
Retraction plane, 9-240
Return conditions, 9-234
Rigid tapping, 9-249
Row of holes, 9-269

S

Safety clearance, 9-240
Screen layout, 1-13
Setting data, 3-44
Simulation of cycles, 9-235
Special functions, 7-119
SPOS, 9-250, 9-251

Starting point, 9-301
Stock removal - CYCLE95, 9-291

T

Tapping with compensating chuck, 9-252
Tapping with compensating chuck with encoder, 9-253
Tapping with compensating chuck without encoder, 9-252
Thread cutting - CYCLE97, 9-308
Thread undercut - CYCLE96, 9-304
tool clearance angle, 9-277
Tool zero, 3-42
Transversal thread, 9-313
Turning cycles, 9-233

U

Undercut - CYCLE94, 9-287

V

V24 interface, 6-97

W

Word structure, 8-132

Z

Zero offset, 3-42

SIEMENS AG
A&D MC IS
Postfach 3180
D-91050 Erlangen


(Tel. +49 (0) 180 / 5050 - 222 [hotline]
Fax +49 (0) 9131 - 2176 [Documentation]
email: motioncontrol.docu@erf.siemens.de)

| | |
|-----------------------------|---|
| From | Suggestions |
| Name _____ | Corrections |
| Company/dept. _____ | for Publication/Manual |
| Street _____ | SINUMERIK 802D |
| Zip code: _____ City: _____ | User Documentation |
| Telephone: _____ / _____ | Operation and Programming - Turning |
| Telefax: _____ / _____ | Order-No.:6FC5698-2AA00-0BP3 Edition: 11.03 |
| | Should you come across any printing errors when reading this publication, please notify us on this sheet. Suggestions for improvement are also welcome. |


Suggestions and/or corrections

Document Structure SINUMERIK 802D


General Documentation: **Catalog**



User Manual: **Operation and Programming**




User Manual: **Diagnostics Guide**




Technical Manual: **Start-up**



Technical Manual: **Descriptions of Functions**





Siemens AG

Automatisierungs- und Antriebstechnik

Motion Control Systems

Postfach 3180, D – 91050 Erlangen

Bundesrepublik Deutschland

www.ad.siemens.de

© Siemens AG 2003
Änderungen vorbehalten
Bestell-Nr. 6FC5597-3AA10-0BP3

Gedruckt in der Bundesrepublik Deutschland