




Tidland External Element Shaft

User Manual



EN

MI 651853 1 T

Series 800
GL External Element
GE External Element
GX Ultra-Lightweight External Element
Series 850
GS Spiral External Element

TABLE OF CONTENTS

Important Safety Instructions.....	3
Assembly Diagram and Part Identification	4
Installation.....	5
Core Stops	5
Operation.....	5
To Inflate Shaft.....	5
Maintenance	6
General Information	7
Replacing Rubber External Element	8
Replacing Rubber External Element with Folded Bladder	10
Replacing Aluminum External Element and Bladder	12
Replacing Valves	14
Non-Isolation Quick Release	14
Isolation Valve (3-way or 4-way).....	14
Air Circuits	15
Troubleshooting.....	16
Spare Parts.....	18
Element End Clamps	18
Valves.....	18
Core Stops	19
Hole Punch Guides	19
Miscellaneous.....	19
Mini GL Shafts	20

CAUTION

- Wear eye protection when using tools or compressed air.
- Follow all shaft safety precautions (page 3).
- Petroleum-based products will damage bladders and rubber elements – DO NOT USE.



TIDLAND CUSTOMER SERVICE

1.360.834.2345

www.maxcessintl.com

For repair and warranty information, visit www.maxcessintl.com/repairs


RECOMMENDED TOOLS

- Tidland Inflation Tool (P/N 128052)
- Tidland Air Release Tool (P/N 111630)
- Tidland Hole Punch Tool (See *Miscellaneous*, page 19)
- Tidland Hole Punch Guides (See page 19)
- Hex wrenches: 3 mm, 4 mm, 1/8"
- Thin wall socket wrench: 7/16", 3/4" (may be required during valve replacement)
- *LOCTITE*™ 222 (if not using patchlock screws)
- *AERVOE*® Crown 8035 *Slix-it* silicone spray (or equivalent)

IMPORTANT SAFETY INSTRUCTIONS

When using this Tidland product, basic safety precautions should always be followed to reduce the risk of personal injury. Your company's safety instructions and procedures should always be followed. When using this product with any other equipment or machinery, all safety requirements stipulated by that equipment or machinery manufacturer must be followed. Compliance with local, state, and federal safety requirements is your responsibility. No part of these or the following instructions should be construed as conflicting with or nullifying the instructions from other sources. Be familiar with the hazards and safety requirements in your work environment and always work safely.

1. Read and understand all instructions and shaft design application limits before operation.
2. Never use this product for a purpose or in a machine that it was not specifically designed for. See Product Safety Data Sheet (PSDS).
3. Do not exceed the operation loads for this shaft as noted on its PSDS, Product Safety Data Sheet.
4. Follow all warnings and instructions marked on the product and on the PSDS.
5. Inspect the shaft for wear and/or other safety and functional deficiencies daily, before each use.
6. Wear safety glasses or proper eye protection when inflating or deflating or otherwise operating the air system.
7. Do not remove or otherwise alter any setscrews or fastening devices prior to using this product.
8. Do not operate this product if any setscrews or fastening devices are missing.
9. Do not lift shaft manually if it is beyond your capacity. Loads over 1/3 your body weight may be prohibitive. Consult your company safety policy.
10. When lifting a shaft, use proper lifting techniques, keeping back straight and lifting with the legs.
11. Do not carry or lift this product over wet or slippery surfaces.
12. Use appropriate mechanical lifting devices, such as a hoist or shaft puller, for heavier shafts.
13. When performing maintenance or repair procedures, do not pressurize the shaft if journal setscrews are loose or missing.
14. When performing maintenance procedures, do not pressurize the shaft if the journal is missing.
15. All replacement parts used on this product should be made to original Tidland specifications.
16. All maintenance and repair procedures performed on this product should be done to Tidland specifications by qualified personnel.



- **When using chucks on this shaft, always locate chucks as shown.**
- **Improper placement of chucks will reduce life cycle of the shaft.**
- **Questions about installation, application or load calculations? Call Tidland Customer Service.**

ASSEMBLY DIAGRAM AND PART IDENTIFICATION

Tidland Series 800/850 shafts are available in many configurations. **See *Spare Parts* at the end of this publication for more information about part numbers specific to your model.** Please have your serial number available when you contact Tidland Customer Service.


This publication covers installation, operation and maintenance for the following products:

Series 800

- GL External Element
- GE External Element
- GX Ultra-Lightweight External Element

Series 850

- GS Spiral External Element



Bladder end clamps vary by shaft model and serial number. See *Spare Parts* at the end of this publication or call your Tidland Customer Service Representative for part numbers. Please have your serial number ready when you call.



The one-piece external element configuration is obsolete for the Series 800/850. Tidland can help you update your shaft to the new design that uses a separate polyurethane bladder and external element.

INSTALLATION

Install the shaft as required for your application.

Core Stops

There are many configurations for the Tidland Series 800/850 shafts, some of which include core stops. Basic core stop installation is covered below. Call Customer Service for part numbers if you need replacement parts.

Fig. 1 – Core Stop (Dovetail): Loosen – do not remove – the two socket head capscrews in the top piece of the core stop. Slide the dovetail into the groove in the shaft until it is aligned as required for your application. Tighten the bolts to 55-60 in·lbs.




Fig. 1

Fig. 2 – Core Stop (Ring): Loosen – do not remove – the socket head bolt in the core stop ring until the ring can slide over the shaft. **Make sure the seam in the ring is not aligned directly over a rubber element.** Position the ring along the shaft as required for your application, then tighten the bolt to 55-60 in·lbs.




Fig. 2

OPERATION

To Inflate Shaft

Use only the Tidland Inflation Tool.

1. Push the air nozzle firmly into the valve receiver, which will depress both the valve button and the tip of the inflation tool.
2. Inflate the shaft until the line pressure air gauge indicates a minimum of 80 psig (5.5 bar). Do not exceed the maximum air pressure of 120 psig (8.2 bar).

Note: Keep the shaft pressure above 80 psig (5.5 bar) to ensure optimal safety and performance.



Do not inflate while the shaft is rotating.

To deflate, only use the Tidland air release tool. Do not use finger to release air.




Do not deflate while the shaft is rotating.

To Deflate Shaft

1. Using the air release tool, push in the quick release air valve and allow the air to escape through the hole in the center of the button.
2. Remove the shaft from the roll/core.

MAINTENANCE

The Tidland Series 800/850 shafts come in many configurations. Maintenance procedures are similar for each model. Specific part numbers are on page 18.

IF YOU HAVE THIS ELEMENT CLAMP	USE INSTRUCTIONS ON
 with a rubber element	Page 8
 with folded bladders OR a one-piece rubber element (no bladder) *	Page 10 * The one-piece configuration is obsolete. Call Tidland for assistance to update your shaft to the new design.
 with an aluminum strip element	Page 12
 with 7/16" wide element	Page 20 "Mini GL Shafts"

- Keep shaft clean and free from grit and scratches.
- The external rubber element and the bladder underneath it can be replaced without removing the shaft from the machine.
- Do not remove the aluminum T-slot extrusion from the shaft when replacing external element and bladder.
- To check for leaks after replacing bladders and elements, inflate shaft to operating pressure, spray end clamps with soapy water and check for bubbles.
- Read page 7 for important general information about replacing shaft elements.

MAINTENANCE

General information for working with external elements

See complete instructions for your element type:

Rubber Element, page 8; Folded Bladder, page 10; Aluminum Strips, page 12.

Fig. 3 - The Tidland Series 800/850 External Element shafts are fitted with two different element end clamps. One clamp is for the non-valve end and the other has a recess that accommodates the air fitting at the valve end. The clamps are not interchangeable from end to end.

Fig. 4 - Element end clamps with UHMW strip must be used on spiral strip shafts.

Fig. 5 - Use these end clamps ONLY for bladders that are folded over the air fitting.






Fig. 6 - Cut bladders and elements square across the ends so there is a flush fit at the end clamp. Bladders cut at an angle are at risk for leaks.

Fig. 7 - Use the Tidland Hole Punch and Tidland Hole Punch Guide to punch holes for air fittings in the bladder. Punch the hole in one wall only of the bladder.

Fig. 8 - Make sure that the element end clamps completely cover the ends of the bladders. Using the correct Hole Punch Guide will ensure that the bladder ends are long enough to be secured under the end clamps.








Fig. 9 - If the barbed end of the air fitting comes out of the port and detaches from the air hose, there is a risk of the hose falling back inside the shaft body. If the air hose is exposed, wrap a piece of tape around it as a precaution.

Important: If at any time an air hose is pulled off an air fitting barb, note that the end of the air hose will be stretched or damaged. Do not reuse the hose without cutting off the damaged portion.



Tidland recommends the use of *Loctite 222* on screw threads or a patch-lock type screw for the element end clamps.

MAINTENANCE

To Replace Rubber External Element and Bladder (Straight or Spiral)

- Tidland recommends replacing external element and bladder at the same time. Old bladders deformed by cold flow inhibit the insertion of the external element.
- Before replacing shaft components, refer to page 7 for general information to aid in leak-free operation.
- The one-piece rubber element is obsolete. Tidland can help you update your shaft to the new design that uses a separate polyurethane bladder and external element.

Remove the Rubber Element

1. Remove screws from end clamps and remove the clamps from each end of the shaft.
2. Pry up the rubber element and pull it from the slot.

Remove the Bladder

3. Lift the bladder out of the slot, remove the air fitting head from the barb fitting in the slot. **Use care: If the barb fitting comes off the hose, the hose can fall inside the shaft.**
4. Remove the air fitting "head" from the bladder and set aside.
5. Clean the shaft and slot with a soft cloth. A rag damp with mild solvent, such as rubbing alcohol, is acceptable.

NOTICE

Petroleum-based products will damage bladders. Do not use.

Install Bladder – Valve End

Note: Bladder material supplied for replacement will be longer than the required finished length. Do not cut to length until Step 20.

6. Square off one end of the bladder. (Bladders cut at an angle are at risk for leaks.)
7. Insert the Tidland Hole Punch Guide (blue) into the end of the bladder. With the Tidland Hole Punch Tool, punch a hole in one wall only of the bladder.
8. Insert air fitting "head" into the hole in the bladder wall (Fig. 10).
9. Install the bladder along the length of the slot and connect the air fitting head with the barb half of the air fitting in the slot.
10. Install the valve end clamp, securing the bladder underneath it.
11. Using 4 mm hex wrench, tighten end clamp screws to 55-60 in·lbs.
12. **IMPORTANT:** At the non-valve end, with the bladder relaxed in the slot, mark the bladder .140" inboard from the center of the screw holes. After the rubber element is installed, this mark should be visible at the same point, indicating that your bladder has not bunched up under the element or has not stretched.




Fig. 10






Fig. 11



(Continued on next page.)

MAINTENANCE

Rubber External Element and Bladder – Straight or Spiral (*continued*)

Note: Use silicone spray to ease installation of bladder and external elements, especially for longer shafts. **Do not use** petroleum-based lubricants.

Install the Rubber Element – Valve End

Rubber element material supplied will be longer than the required finished length. Do not cut to length until Step 18.

13. Square off one end of the rubber element. This will be the leading end for installation.
14. Spray the bladder in the slot and all sides of the new rubber element with silicone spray.
15. Starting at the non-valve end of the shaft slot, hold the loose end of the bladder material securely and begin to push the rubber element into the slot.

Note: Do not stretch the bladder, but keep it taut under the rubber element.

16. Push and pull the rubber element (easier with two people) along the length of the slot until the leading end contacts the end clamp at the air end of the shaft. Apply silicone spray as needed to ease insertion and to prevent the bladder from bunching up under the element. If necessary, hold the rubber element with needlenose pliers, being careful not to damage the bladder. Note: For spiral shafts, the rubber element should slide over the top of the UHMW strip on the end clamp.
17. At the valve end, begin to push the element toward the clamp, working your way back along the length of the slot to the non-valve end. This will relieve stretching and slightly compress the element, significantly reducing the risk of the element "shrinking" away from the clamps during operation.
18. Holding the compression in the element, at the non-valve end, cut the element square at a point just inside the clamp pocket. Let the element relax; it should expand into the pocket.


Install Bladder – Non-Valve End

19. At the non-valve end, the mark made on the bladder in Step 12 should be visible .140" from the screw hole edges. If not, then the bladder has contracted under the element or has stretched. You will need to remove or pull back the element in order to relax the bladder for proper installation. Repeat the procedure as needed to align the mark on the bladder. Use silicone spray liberally to ease installation of the elements.

20. Cut square across the end of the bladder at the mark.
21. Push the rubber element back from the clamp pocket into the slot and install the non-valve end clamp, securing the bladder underneath it.

Note: For spiral shafts, always use the end clamp with the UHMW strip attached. The strip will be in between the bladder and the rubber element when assembly is complete.

22. Using 4 mm hex wrench, tighten end clamp screws to 55-60 in.-lbs.






NON-VALVE
END CLAMP
BOTTOM VIEW

Install Rubber Element – Non-Valve End

23. **After all elements are installed inflate shaft to operating pressure.**
24. With a grinder, carefully chamfer the ends of the element next to the clamps so that they fully collapse below the body O.D. when the shaft is deflated.

Note: Make sure to chamfer clear to the end of the element

To **check for leaks** after replacing bladders and elements, inflate shaft to operating pressure, spray end clamps with soapy water and check for bubbles.



END CLAMP BLADDER

MAINTENANCE


To Replace Rubber External Element with Folded Bladder

- Tidland recommends replacing external element and bladder at the same time. Old bladders deformed by cold flow inhibit the insertion of the external element.
- Before replacing shaft components, refer to page 7 for general information to aid in leak-free operation.

Note: For easier, leak-free assembly, the folded bladder style can be updated to the non-folded, flat configuration by converting to a new end clamp. Call Tidland for assistance.

Remove the Rubber Element

1. Remove screws from end clamps and remove the clamps from each end of the shaft.
2. Pry up the rubber element and pull it from the slot.
3. Inspect the element for wear; look for slits, gouges or grooves at the core ends.



TOP AND BOTTOM VIEWS
THIS CLAMP STYLE IS INTERCHANGEABLE
FROM END TO END.

Remove the Bladder

4. Lift the bladder out of the slot, carefully removing the air fitting from its port in the slot.
5. Remove the air fitting "head" from the bladder and set aside.
6. Clean the shaft and slot with a soft cloth. A rag damp with mild solvent, such as rubbing alcohol, is acceptable.

NOTICE


Petroleum-based products will damage bladders. Do not use.

Install Bladder – Valve End

Note: Bladder material supplied for replacement may be longer than the required finished length. Do not cut to length until Step 18.

7. Square off one end of the bladder. (Bladders cut at an angle are at risk for leaks.)
8. Insert the Tidland Hole Punch Guide (red) into the end of the bladder. With the Tidland Hole Punch Tool, punch a hole in one wall only of the bladder.

9. Insert air fitting "head" into the hole in the bladder wall (Fig. 12).



(ILLUSTRATION NOT TO SCALE)

10. Install the bladder along the length of the slot and connect the air fitting head with the other half of the air fitting in the slot. The excess length at the valve end will be folded back over the air fitting when the external element is installed.

(Continued on next page.)

MAINTENANCE

Rubber External Element with Folded Bladder (*continued*)


Note: Use dry silicone spray to ease installation of bladder and external elements.

Do not use petroleum-based lubricants.


11. Square off the leading end of the rubber element.
12. At the non-valve end of the shaft slot, hold the loose end of the bladder material securely and begin to push the rubber element into the slot.

Caution: Do not stretch the bladder, but keep it taut under the rubber element.

13. Push and pull the rubber element along the length of the slot until the leading end is .375" (9.5mm) from the outside edge of the end clamp pocket.




14. Fold the end of the bladder back and tuck it underneath the rubber element.
15. Install the end clamp, securing the bladder and rubber element underneath it.
16. Using 4 mm hex wrench, tighten end clamp screws to 55-60 in-lbs.



Install Bladder – Non-Valve End

17. At the non-valve end, cut the bladder to length .500" past the end of the shaft slot.
18. Cut the rubber element square .375" short of the end of the shaft slot.
19. Lift the end of the rubber element and fold the bladder back underneath.
20. Install the non-valve end clamp, securing the bladder and element underneath it.
21. Using 4 mm hex wrench, tighten end clamp screws to 55-60 in-lbs.



To **check for leaks** after replacing bladders and elements, inflate shaft to operating pressure, spray end clamps with soapy water and check for bubbles.

MAINTENANCE

To Replace Aluminum External Element and Bladder

- When replacing bladders, inspect aluminum elements for wear. Replace if necessary.
- Tidland recommends replacing external element and bladder at the same time. Old bladders deformed by cold flow inhibit the insertion of the external element.
- Before replacing shaft components, refer to page 7 for general information to aid in leak-free operation.

Remove End Clamps

1. Remove screws from end clamps and remove the clamps from each end of the shaft.

Remove Aluminum External Element

2. Grasp the wave springs at one end and pull them from the slot.
3. Pull the aluminum external element from the slot.
4. Inspect the element for wear; look for cracks or grooves.

Remove the Bladder

5. Lift the bladder out of the slot, carefully removing the air fitting from its port in the slot.
6. Remove the air fitting "head" from the bladder and set aside.
7. Clean the shaft and slot with a soft cloth. A rag damp with mild solvent, such as rubbing alcohol, is acceptable.


NOTICE

Petroleum-based products will damage bladders. Do not use.

Install Bladder – Valve End



Note: Bladder material supplied for replacement may be longer than the required finished length. Do not cut to length until Step 17.

8. Square off one end of the bladder. (Bladders cut at an angle are at risk for leaks.)
9. Insert the Tidland Hole Punch Guide (blue) into the end of the bladder. With the Tidland Hole Punch Tool, punch a hole in one wall only of the bladder.



10. Insert air fitting "head" into the hole in the bladder wall (Fig. 13).

11. Install bladder in slot and connect the air fitting head with the other half of the air fitting in the slot.
12. Install the valve end clamp, securing the bladder underneath it.
13. Using 4 mm hex wrench, tighten end clamp screws to 55-60 in·lbs.



(Continued on next page.)

MAINTENANCE

Aluminum External Element and Bladder (*continued*)

14. Starting at the non-valve end of the shaft slot, hold the loose end of the bladder material securely and slide the aluminum external element into the slot until it contacts the end clamp at the valve end.

Note: Do not stretch the bladder, but keep it taut under the aluminum strip.

15. Install the wave springs on top of each side of the aluminum external element (Fig. 14).




Fig. 14

Install Bladder – Non-Valve End

16. At the non-valve end, mark the bladder at a point 0.140" from the end clamp screw hole centers (Fig. 15). Do not stretch the bladder.
17. Cut square across the end of the bladder.
18. Install the non-valve end clamp, securing the bladder underneath it.
19. Using 4 mm hex wrench, tighten end clamp screws to 55-60 in·lbs.





Fig. 15



To **check for leaks** after replacing bladders and elements, inflate shaft to operating pressure, spray end clamps with soapy water and check for bubbles.

MAINTENANCE

To Remove and Replace Valves


- There are several styles of valves used on the Tidland Series 800/850 shafts, installed either in the end or the side of the shaft, depending on your application.
- Ensure that the shaft is completely deflated before removing the valve.
- After removing a valve, remove damaged portion of air hoses before reconnecting them to the valve.
- To check for air leaks after reinstalling valves, inflate shaft to operating pressure, spray valve with soapy water and watch for bubbles.

Non-Isolation Quick Release

Thin wall socket wrench: 7/16", 3/4" (may be required)

1. Use a socket wrench to unscrew the valve from its side or end location in the shaft.
2. Apply thread sealant (according to manufacturer's instructions) to threads of new valve (unless the sealant is pre-applied) and reinstall.


NOTE: Valves with pre-applied thread sealant are good for multiple uses. Always inspect the valve threads for sufficient sealant; do not reuse more than six times.



Isolation Valve (3-way or 4-way)


End or Side Location

1. Remove set screw.
2. Pull valve from shaft carefully and disconnect air hoses.
3. Cut off damaged ends of hoses.
4. Attach air hoses to new valve.
5. Reinstall valve in shaft.
6. Reinstall setscrew.




Side Location Bolt-in

1. Remove socket head bolt.
2. Pull valve from shaft carefully and disconnect air hoses.
3. Cut off damaged ends of hoses.
4. Attach air hoses to new valve.
5. Reinstall valve in shaft.
6. Reinstall socket head bolt.



Bolt-in side valve replaced with new valve and adapter. See Spare Parts, page 18. (April 2011)



Before operation:

- Check for proper inflation and deflation.
- If there is a problem, check air hoses for kinks or disconnects.
- See Troubleshooting on page 16.

Air Circuits

- Air circuits vary in configuration for the Tidland Series 800/850 shaft designs. In most cases, the air fitting at the end of each external element (underneath the element clamp) attaches to a hose inside the shaft.
- For single circuit valves, internal hoses attach to separate barbs on a plug installed either in the journal or on the side of the shaft. Air is delivered through the valve to the plug.
- Some single circuit shafts have no hoses. Air is routed through drilled holes from valve to the air fitting under the rubber elements.
- Isolation valves connect directly to the internal air hoses.
- Maintenance for some air circuit hoses may require removal of shaft journals.
- Hoses may feed out the end of the shaft into the journal or out the side of the shaft, depending upon the type of valve used. Wrap a piece of tape around exposed hoses to prevent them from slipping back inside the shaft body. (Journal removal may be required to retrieve them.)
- After removing an air fitting, always clip off the damaged end of an air hose before reconnecting it to the fitting.





Fig. 16

"T-barb" hose connections are made inside the shaft. The number of connections depends upon how many external elements the shaft has. All connections should be made from opposing pairs of hoses and reduced to the minimum number of pairs needed for the 3-way or 4-way valve used, as shown in Fig. 16a and 16b.

Fig 17.

Hoses originating from end clamps in the shaft "head" must feed back into the shaft body before feeding out through the end of the shaft (to prevent being crushed by the journal).

Note: Check air flow through hoses during assembly. Hose kinking can prevent inflation or deflation.





Fig. 17

TROUBLESHOOTING

See page 6 to determine which set of instructions to use for the Recommended Solution.

To **check for leaks** after replacing bladders and elements, inflate shaft to operating pressure, spray end clamps with soapy water and check for bubbles.

Problem	Possible Cause	Recommended Solution
Air Leak	Element end clamps not tight	Tighten end clamps at both ends of shaft to 55-60 in·lbs. Use 29 in·lbs for the Mini GL Shafts.
	End clamps not centered over bladder	Ensure that the end clamps completely cover the end of the bladder. Bladder must be cut square across its end in order for the end clamp to make contact across the full width of the bladder.
	End clamp with UHMW strip installed incorrectly.	Spiral external element only – ensure that element end clamp with UHMW strip is installed between the bladder and the external element.
	Hole for air fitting in bladder is deformed	Remove end clamp and check the bladder around the air fitting. If the hole is deformed or the bladder is torn, replace the bladder. Use the Tidland Hole Punch Tool and Hole Punch Guide for best results when installing air fittings in a new bladder.
	Air hose connection to the air fitting has failed.	Remove end clamps and confirm that the air fitting is connected to the internal air hose. Check that the fitting is seated correctly in its hole.
	Valve is leaking	Access the valve and confirm that air hoses are attached. If valve is leaking from the center, replace the valve.
	Ruptured bladder	Remove external element and inspect bladder for cracks. Aluminum external element only – ensure that wave springs are correctly installed (Fig. 14, page 13). They should sit on top of the aluminum strip.

TROUBLESHOOTING


Problem	Possible Cause	Recommended Solution
External element will not collapse completely	Fiber or dust buildup in element slot is causing scraping along edges of slot	Clean along slot. If necessary, remove and replace external element and bladder.
	Cold flow of rubber element	Replace rubber element and bladder.
	Wave springs installed incorrectly (aluminum external element style only)	Wave springs must be installed along the top edges of the aluminum external element.
	Kinked hoses	Check hose installation: ▪ Under element end clamps ▪ At valve ▪ In shaft body (may require journal removal)
Elements difficult to install	Buildup in slot	Clean slot with mild non-petroleum based solvent and dry thoroughly. Spray slot and elements with dry silicone lubricant.
External element extrudes out of slot	Element is over-lubricated with dry silicone spray.	Remove element and wipe clean. Reinstall, lubricating only as necessary.
Core will not fit on shaft	Element end clamps extending past shaft O.D.	Inspect bladder length under clamp. If it is too long, it will push up on clamp. Trim small amount from bladder and reinstall clamp.
Core is slipping	Elements not gripping core	▪ Check inflation pressure. ▪ Ensure that the external element is expanding completely. ▪ Check for leaks. ▪ Check for worn elements. ▪ Ensure correct core size.*

* Recommended core clearance on non-inflated shaft is less than .06" for maximum torque capacity.

SPARE PARTS


Call Tidland Customer Service for assistance with choosing the correct replacement parts for your shaft. Please have the shaft serial number ready. (Parts not to scale.)

Element End Clamps



Valves


ISOLATION



132403
4-WAY, SIDE OR END



703276
3-WAY, SIDE OR END
(replaces 132520)



713308 Kit = 703276 valve
713309 adaptor
130248 btn hd scr
133103 soc hd scr
(replaces 133151 bolt-in side valve)

SINGLE CIRCUIT



126475
QUICK RELEASE



126427
QUICK RELEASE




126440
QUICK RELEASE – MIDGET

SPARE PARTS

Core Stops




Call for replacement
part number.



647911
w/ Soc Hd CpScr
M6 x 1.00 x 8mm LG (2 ea)

Hole Punch Guides



If your shaft uses this element end clamp, you will need the **blue** Tidland hole punch guide.

Part No. 577982



If your shaft uses this element end clamp, you will need the **red** Tidland hole punch guide.

Part No. 577980



If your shaft uses this element end clamp, you will need the hole punch kit for Tidland "Mini" GL shafts.

Part No. 538908

Miscellaneous

Air Fitting, Head	562024
Air Fitting, Barb	516618
Air Hose, Poly, 1/8" OD x 1/16" ID, Blue	132556
Bladder, Polyurethane	576711
Deflation Tool	111630
External Element, Rubber	503911
External Element, Aluminum	587827
Hole Punch Tool	760668
Hole Punch Guide, for Folded Bladder only	577980 (red)
Hole Punch Guide, for Straight or Spiral Strip	577982 (blue)
Hole Punch Kit, for Mini GL Shaft	538908
Inflation Tool	128052
Set Screw 1/4-20 (End Valves)	Call Tidland
Soc Hd CpScr (3-way Side Valve)	133103
Springs, Wave (specify length)	617952
T-Barb Hose Connectors	250501

MINI GL SHAFTS


Newer shaft configurations may use one of these end clamps with two bolts:




674761



692484



T-SLOT (MACHINED)




T-SLOT (EXTRUSION GLUED IN)

Note:

- Bladder material supplied for replacement may be longer than the required finished length.
- Use *Loctite 222* or a patch-lock type screw when installing element end clamps.

To Replace External Element

1. Deflate shaft.
2. Remove element end clamps (3mm hex drive)
3. Remove element from shaft and remove air fitting from element.
4. Square off the end of the replacement element and use the Tidland hole locator guide to mark the location of the air fitting hole. (Fig. 18)
5. Punch hole in one wall only of the bladder. Insert the air fitting. (Fig. 19)
6. Install element in slot and seat the air fitting in the slot.
7. Install element end clamp: tighten to 29 in·lbs (3.27 Nm).
8. Cut element to length:



9. Install remaining element end clamp: tighten to 29 in·lbs (3.27 Nm).

Fig. 18






Fig. 19



NORTH, CENTRAL
AND SOUTH AMERICA
Tel +1.360.834.2345
Fax +1.360.834.5865
sales@maxcessintl.com
www.maxcessintl.com

INDIA

Tel +91.22.27602633
Fax +91.22.27602634
india@maxcessintl.com
www.maxcess.in

EUROPE, MIDDLE EAST
AND AFRICA
Tel +49.6195.7002.0
Fax +49.6195.7002.933
sales@maxcess.eu
www.maxcess.eu

JAPAN

Tel +81.43.421.1622
Fax +81.43.421.2895
japan@maxcessintl.com
www.maxcess.jp

CHINA

Tel +86.756.881.9398
Fax +86.756.881.9393
info@maxcessintl.com.cn
www.maxcessintl.com.cn

KOREA, TAIWAN,
AND SE ASIA

Tel +65.9620.3883
Fax +65.6235.4818
asia@maxcessintl.com