



CODICO[®] RTM-3300
COMPACT DVB RE-MULTIPLEXER AND STREAM
PROCESSOR

User Manual



P/N 100374

(Rev. B / March 2003)

**Scopus Network Technologies Inc.
U.S. Offices**

100 Overlook Center Drive, 3rd Floor
Princeton, NJ 08540.
USA

Tel: (858) 618-1600
Fax: (858) 618-1615

Email: info@scopususa.com

Web: www.scopususa.com

**Scopus Network Technologies Ltd.
International Headquarters**

10 Ha'amal St., Park Afek
Rosh Ha'ayin, 48092
Israel

Tel: (972) –3-9007777
Fax: (972) –3-9007888

Email: info@scopus.net

Web: www.scopus.net

© 2001 Scopus Network Technologies Ltd. All rights reserved.

Scopus Network Technologies Ltd. Reserves the rights to alter the equipment specifications and descriptions in this publication without prior notice. No part of this publication shall be deemed to be part of any contract or warranty unless specifically incorporated by reference into such contract or warranty.

The information contained herein is merely descriptive in nature, and does not constitute a binding offer for sale of the product described herein.

CODICO® is a Registered trademark of Scopus Network Technologies Ltd. In Israel, Germany, France, U.K. U.S.A. and Japan. All references to registered trademarks of other vendors are the property of their respective owners.

INTRODUCTION

Scopus Network Technologies Ltd. takes great pride in delivery of its products, and makes every endeavor to ensure its clients full satisfactory.

On behalf of all the Scopus team, we would like to extend our congratulations on your investment in the CODICO® RTM-3300 Compact DVB Re-Multiplexer and Stream Processor.

CODICO® RTM-3300 Compact DVB Re-Multiplexer and Stream Processor



MANUAL SCOPE AND STRUCTURE

The manual is comprised of six main sections:

1. OVERVIEW:

This section provides introduction and product description, including highlights, benefits and typical applications, gives a functional and physical description of the unit and lists its main capabilities and specifications.

2. INSTALLATION:

This section provides data and procedures required to install and activate the unit. Procedures include site requirements and preparation, installation in a 19" rack, cable connections, panel options and Pin-out descriptions, initial settings and serviceability check.

3. OPERATION

This section provides guidelines and operating instructions to perform the RTM-3300 main stream processing tasks:

- a. Re-Multiplexing (Grooming)
- b. PID Re-Mapping
- c. Conditional Access Processing
- d. Updating the Multiplexer Software

4. FRONT PANEL CONTROL MODE:

This section provides data and instructions on operating and monitoring the RTM-3300 operation by using the front panel controls and display.

5. TERMINAL AND TELNET CONTROL MODE

This section describes the monitoring and control functions provided when a terminal (monitor and keyboard) are connected to the RTM-3300.

6. CONFIGURATION FILE MANAGEMENT

This section describes the RTM-3300 configuration files.

It is assumed throughout this document that personnel have a general knowledge about the CODICO® RTM-3300 Compact DVB Re-Multiplexer and Stream Processor, application and capabilities.

General knowledge of the CODICO® System and its application is also assumed. For detailed information, refer to the CODICO® MPEG-2 DVB Family Product Description documents.

TECHNICAL SUPPORT

In case of technical problems with the CODICO® system or one of its' components please refer to the System Documentation. In most instances, this may save you time in resolving technical difficulties.

Should you not be able to resolve the problem please call your local distributor for technical support.

HOW TO RETURN FAULTY PARTS

Before returning an item:

1. Request a RMA (Return Merchandise Authorisation) Tracking Number from your local Distributor.
2. Scopus Network Technologies Support will assign a RMA Tracking Number; this must accompany the item being returned and will be referred to in all correspondence.
3. The item is sent to Scopus Network Technologies with the RMA Number included in the accompanying documentation (shipping and customs forms).

Customer Support Point Of Contact (POC)

Scopus Network Technologies Inc. U.S. OFFICES

100 Overlook Center Drive, 3rd Floor
Princeton, NJ 08540.
USA

Tel: (858) 618-1600
Fax: (858) 618-1615

Email: info@scopususa.com

Web: www.scopususa.com

Scopus Network Technologies Ltd. INTERNATIONAL HEADQUARTERS

10 Ha'amal St., Park Afek
Rosh Ha'ayin, 48092
Israel

Tel: (972) –3-9007777
Fax: (972) –3-9007888

Email: info@scopus.net

Web: www.scopus.net

WARRANTY

SCOPUS Network Technologies Ltd. warrants that the Product and any part thereof, including, but not limited to spare parts, will, when properly installed, conform to SCOPUS Network Technologies Ltd. published specifications and that the Product and any parts thereof, including, but not limited to, spare parts, will be free from defects deriving from wrong workmanship and faulty materials under normal use and service, for a period of twelve (12) months following the date of manufacture thereof.

The supply of spare parts at reasonable cost shall be available for a period of three (3) years from the date of delivery.

This warranty does not cover ordinary wear and tear of the Product or other defects due to circumstances beyond SCOPUS Network Technologies Ltd. control such as unsuitable operating means, chemical, Electro-mechanical or electrical influences and damages which may be caused by interference by the CUSTOMER or any unauthorized third party.

Defective cards/assemblies will be sent to SCOPUS Network Technologies Ltd. for repair. The repaired cards/assemblies will be returned to the CUSTOMER within 30 days from their receipt by SCOPUS Network Technologies Ltd.

Cards/assemblies repaired during the 12 months warranty period will carry a warranty of 6 months from date of repair or until end of original warranty period, whichever is the later date.

SCOPUS Network Technologies Ltd. sole liability under this warranty shall be limited to the repair or replacement with equivalent units at SCOPUS Network Technologies Ltd. facilities, of any Product or parts thereof that do not conform to SCOPUS Network Technologies Ltd. published specifications or that are defective in material or workmanship, as specified above. The expense of installing repaired or replaced parts shall be borne by the CUSTOMER.

SCOPUS Network Technologies Ltd. sole obligation under this Warranty is be the supplier of the Product to the CUSTOMER and to provide such services as set out in this Warranty on the SCOPUS Network Technologies Ltd. terms and conditions provided for herein. In no event will SCOPUS Network Technologies Ltd. be liable to the CUSTOMER for any business expenses, loss of profits, incidental, indirect or consequential damages, however caused, unless such expenses, loss or damages shall have derived from an infringement of patents of copyrights.

THE WARRANTIES STATED HEREIN ARE EXCLUSIVE AND ARE EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Beyond the warranty period, SCOPUS Network Technologies Ltd. shall repair or replace defective cards/assemblies according to its standard price list relevant at such time. Cards/assemblies thus repaired shall carry a warranty of 6 months.

TABLE OF CONTENTS

1.	Overview	1-1
1.1.	General Information	1-1
1.1.1.	RTM-3300 Highlights and Benefits	1-2
1.1.2.	Applications	1-5
1.1.3.	Product Line	1-7
1.2.	RTM-3300 OVERVIEW	1-8
1.2.1.	RTM-3300 Architecture	1-8
1.3.	Mechanical Structure	1-10
1.3.1.	Enclosure	1-10
1.3.2.	Front Panel	1-10
1.3.3.	Rear Panel	1-10
1.4.	Management	1-11
1.5.	Capabilities and Specifications	1-12
1.5.1.	Capabilities	1-12
1.5.2.	Interface Connections	1-13
1.5.3.	Physical Specifications	1-14
2.	Installation	2-1
2.1.	General	2-1
2.2.	Installation Information	2-1
2.2.1.	Safety Precautions	2-1
2.2.2.	Inventory check	2-1
2.3.	MECHANICAL INSTALLATION	2-2
2.3.1.	Site Preparation	2-2
2.3.2.	Mechanical Installation	2-2
2.4.	ELECTRICAL INSTALLATION	2-3
2.4.1.	AC Power Supply Connection	2-3
2.4.2.	DC Power Supply Connection	2-3
2.4.3.	GPI Connections	2-4
2.5.	QUICK START	2-5
2.5.1.	Power up Procedure	2-5
2.5.2.	Initial Configuration Procedure	2-5
3.	Operation	3-1
3.1.	General	3-1
3.2.	Re-Multiplexing (Grooming)	3-1
3.2.1.	Re-Multiplexing Concept	3-1
3.2.2.	Re-Multiplexing Process	3-1
3.3.	PID Re-Mapping	3-3
3.3.1.	PID Re-Mapping Concept	3-3
3.3.2.	PID Re-Mapping Process	3-3
3.4.	Conditional Access (CA) Processing	3-4
3.4.1.	Conditional Access (CA) Processing Concept	3-4
3.4.2.	Conditional Access (CA) Process	3-4
3.5.	Updating the Multiplexer Software	3-8
3.5.1.	Software Update Using RS232	3-8
3.5.2.	Software Update Using FTP	3-9
4.	Front Panel Control Mode	4-1
4.1.	General	4-1
4.1.1.	Front Panel User Interface	4-1
4.1.2.	Front Panel Control Menu Operation	4-2
4.2.	Status Sub-Menu	4-4

4.2.1.	FIFOs Status Report	4-5
4.2.2.	General Status Report	4-6
4.3.	Configuration Sub-Menu.....	4-7
4.3.1.	Select Output Packet Size Function	4-8
4.3.2.	Set TTY Baud Rate Function	4-8
4.3.3.	Enable/Disable TelNet Function.....	4-8
4.3.4.	Enable/Disable FTPSRV	4-8
4.3.5.	Permissions Control Function	4-9
4.3.6.	Panel Contrast Control Function	4-9
4.3.7.	Enable/Disable Scrambling Function	4-9
4.3.8.	Enable/Disable SDT Auto Table Generation Function	4-10
4.3.9.	Enable/Disable NIT Auto Table Generation Function.....	4-10
4.3.10.	Enable/Disable TDT Auto Table Generation Function.....	4-10
4.3.11.	Enable/Disable PMT Auto Table Generation Function	4-10
4.3.12.	Enable/Disable PAT Auto Table Generation Function.....	4-11
4.3.13.	Set-Up Current Time Function	4-11
4.3.14.	Set-Up Current Date Function.....	4-11
4.3.15.	Set-Up Router Address Function	4-12
4.3.16.	Set-Up Mask Function.....	4-12
4.3.17.	Set-Up IP Address Function.....	4-12
4.3.18.	Set-Up Output Rate Function.....	4-13
4.4.	CTRL Sub-Menu.....	4-14
4.4.1.	ReRun Mux Function	4-14
4.4.2.	Load New MUX Version Function.....	4-15
4.4.3.	Reset Output FIFO Function	4-15
4.4.4.	System Boot.....	4-15
4.4.5.	Reset DSP.....	4-15
5.	Telnet and Terminal Control Mode	5-1
5.1.	General.....	5-1
5.2.	Power-Up and Log-In	5-1
5.2.1.	Local Terminal Operation.....	5-1
5.2.2.	Remote Terminal Operation.....	5-1
5.3.	Terminal Control MODE	5-2
5.3.1.	Terminal Control Mode Structure	5-2
5.3.2.	Terminal Main Menu ([Power-Up]).....	5-3
5.4.	Input/Output status Report ([F] key / Main Menu)	5-5
5.5.	General status Report ([s] key / Main Menu).....	5-6
5.6.	MUX Transport Information Report ([m] key / Main Menu)	5-9
5.7.	For Some More Process Status Sub-Menu ([d] key / Main Menu).....	5-11
5.7.1.	Hard/Soft ([0] key / Process Sub-Menu)	5-12
5.7.2.	table_s Status Report ([1] key / Process Sub-Menu).....	5-13
5.7.3.	table_l Status Report ([2] key / Process Sub-Menu).....	5-13
5.7.4.	Permissions Report ([3] key / Process Sub-Menu).....	5-14
5.7.5.	ctrl_udp(n) Status Report ([4] key / Process Sub-Menu)	5-14
5.7.6.	Simulcrypt Status Report ([5] key / Process Sub Menu).....	5-15
5.7.7.	Errors Report ([6] key / Process Sub-Menu).....	5-17
5.7.8.	TCP Status Report ([7] key / Process Sub-Menu)	5-19
5.7.9.	Inp. Hard Status Report ([9] key / Process Sub-Menu)	5-20
5.8.	Miscellaneous Sub-Menu ([i] key / Main Menu)	5-21
5.8.1.	DSP Reset (Hot Boot) Function ([2] key / Misc. Sub-Menu).....	5-22
5.8.2.	DSP Output FIFO Reset Function ([3] key / Misc. Sub-Menu)	5-22
5.8.3.	DSP Input Control Function ([5] key / Misc. Sub-Menu)	5-22
5.8.4.	DSP Inputs Switch Function ([6] key / Misc. Sub-Menu)	5-22
5.8.5.	PC-DSP Message FIFO Reset Function ([7] key / Misc. Sub-Menu)	5-23
5.8.6.	Output Check Enabled/Disabled Function ([a] key / Misc. Sub-Menu).....	5-23

5.8.7.	Record Input Transport Report ([b] key / Misc. Sub-Menu)	5-23
5.8.8.	Record Self-Made Out Table Update Function ([d] key / Misc. Sub-Menu)	5-23
5.9.	Configuration Sub-Menu ([c] key / Main Menu)	5-24
5.9.1.	Remux Input Utility ([r] key / Configuration Sub-Menu).....	5-25
5.9.2.	Miscellaneous Configuration Functions Menu ([m] key / Configuration Sub-Menu)	5-25
5.9.3.	Automatic Tables Configuration Setup Menu ([t] key / Configuration Sub-Menu)	5-29
5.9.4.	New MCMUX Version Loading Procedure ([l] key / Configuration Sub-Menu).....	5-35
5.9.5.	Saves the current configurations in a file ([s] key / Configuration Sub-Menu).....	5-35
5.9.6.	Loads a configuration from file ([u] key / Configuration Sub-Menu).....	5-35
5.10.	Exit and Re-run MCMUX ([x] / Main Menu)	5-35
6.	Configuration File MANAGEMENT	6-1
6.1.	General	6-1
6.2.	Editing the configuration files	6-2
6.2.1.	Disp Command	6-2
6.2.2.	Next Command	6-2
6.2.3.	Priv Command	6-2
6.2.4.	Find Command	6-2
6.2.5.	Replace Command	6-3
6.2.6.	Add Command	6-3
6.2.7.	Copy Command	6-3
6.2.8.	Del Command	6-3
6.3.	MCMUX.CFG File Parameters	6-4
6.3.1.	MCMUX CFG File Parameters	6-4
6.3.2.	MCMUX.CFG File Example	6-7
6.4.	MCMUX.RMP File	6-8
6.4.1.	MCMUX.RMP File Parameters	6-8
6.4.2.	MCMUX.RMP File Example	6-13

LIST OF FIGURES

Figure 1-1:	The RTM-3300 Multiplexer	1-1
Figure 1-2:	Typical Head End RTM-3300 Application	1-5
Figure 1-3:	Typical DTA RTM-3300 Application	1-5
Figure 1-4:	Encryption Block Diagram	1-6
Figure 1-5:	CODICO® Integrated Product Line	1-7
Figure 1-6:	RTM-3300 Functional Block Diagram	1-8
Figure 1-7:	RTM-3300 Compact DVB Re-Multiplexer - Front View	1-10
Figure 1-8:	RTM-3300 Compact DVB Re-Multiplexer - Rear View	1-10
Figure 2-1:	RTM-3300 Rear Panel, AC Power Connection	2-3
Figure 2-2:	RTM-3300 Rear Panel, DC Power Connection	2-3
Figure 3-1:	Example for PID Remapping Process	3-3
Figure 4-1:	RTM-3300 Front Control Panel	4-1
Figure 4-2:	Organization and Menus Hierarchical Structure of the Front Panel Control Mode	4-3
Figure 5-1:	Organization and Structure of the Terminal Control Mode	5-2
Figure 5-2:	Terminal Main Menu - Structure	5-4
Figure 5-3:	Input/Output status report - Structure	5-5
Figure 5-4:	General Status Report - Structure	5-8
Figure 5-5:	MUX Transport Information Report - Structure	5-9
Figure 5-6:	Mux Transport Information Report - Structure	5-10
Figure 5-7:	For Some More Process Status Sub-Menu - Structure	5-11
Figure 5-8:	General Status Report - Structure	5-12
Figure 5-9:	mgcl - table_s Status Report - Structure	5-13
Figure 5-10:	mgcl - table_l Status Report - Structure	5-13
Figure 5-11:	ctrl_upd(n) Status Report - Structure	5-14
Figure 5-12:	Simulcrypt Report - Structure	5-15
Figure 5-13:	Errors Report - Structure	5-17
Figure 5-14:	TCP Status Report - Structure	5-19
Figure 5-15:	Inp. Hard Status Report - Structure	5-20
Figure 5-16:	Miscellaneous Sub-Menu - Structure	5-21
Figure 5-17:	Record Input Transport Report - Structure	5-23
Figure 5-18:	Configuration Sub-Menu - Structure	5-24
Figure 5-19:	Miscellaneous Configuration Functions Menu - Structure	5-26
Figure 5-20:	Automatic Tables Configuration Setup Menu - Structure	5-30
Figure 5-21:	MUX Transport Status Report - Structure	5-34

LIST OF TABLES

Table 1-1:	CODICO® Product Family	1-7
Table 1-2:	RTM-3300 Rear Panel Connectors	1-11
Table 1-3:	RTM-3300 Capabilities	1-12
Table 1-4:	RTM-3300 Input Interfaces	1-13
Table 1-5:	RTM-3300 Output Interfaces	1-13
Table 1-6:	Control Connection Interfaces	1-13
Table 1-7:	RTM-3300 Physical Dimensions.....	1-14
Table 1-8:	RTM-3300 Electrical Power Requirements	1-14
Table 1-9:	RTM-3300 Environmental Conditions.....	1-14
Table 2-1:	RTM-3300 Series Professional Encoder Inventory List.....	2-1
Table 2-2:	RTM-3300 GPI Pin-Out Connection	2-4
Table 4-1:	RTM-3300 Front Control Panel Components	4-1
Table 4-2:	RTM-3300 System Menu Functions	4-2
Table 4-3:	General Status Report Structure	4-6
Table 4-4:	Configuration Sub-Menu Structure	4-7
Table 5-1:	RTM-3800 Error List	5-17
Table 6-1:	MCMUX.CFG File Parameters	6-4
Table 6-2:	RCMUX.RMP File Parameters	6-8

1. OVERVIEW

1.1. General Information

The CODICO® RTM-3300 Compact DVB Re-multiplexer and Stream processor is a compact (1RU) DVB Statistical Multiplexer/Re-multiplexer and Transport Stream (TS) Processor, rich in capabilities and options. It provides real-time re-multiplexing for several MPEG-2 DVB input transport streams into one DVB output transport stream.

The RTM-3300 can be ordered with any number of inputs between 4 and 10. Having up to 10 ASI inputs, the RTM-3300 provides the highest 1RU re-multiplexing port density in the market today.

With its various features and capabilities, the RTM-3300 can be used for several applications:

- Fixed Distribution/Contribution
- Small-Medium head-end applications
- Digital Turnaround
- Satellite, Cable, DVB-T, MMDS
- Multi channel mobile contribution
- Transport stream processing
- Integrated or stand alone DVB scrambler (Simulcrypt or BISS)
- PSI/SI tables injector
- Video Distribution over Telco

The RTM-3300 complements the CODICO® E-1000 Series MPEG-2 Real Time Encoders to provide a comprehensive solution for encoding, multiplexing and re-multiplexing multiple DVB programs.

On the other hand, the RTM-3300 is an open-system platform, highly interoperable with multi-vendor head-end equipment and Conditional Access Systems.

Figure 1-1: The RTM-3300 Multiplexer



1.1.1. RTM-3300 Highlights and Benefits

The RTM-3300 Compact DVB Multiplexer is a proven solution for operation re-multiplexing and transport stream processing applications. The following is a summary of important features of the RTM-3300:

Input Flexibility	<p>The RTM-3300 provides up to 10 ASI (Serial DVB) inputs in three hardware versions:</p> <ul style="list-style-type: none">• 4 ASI Input Version: for 4 input applications• 5 ASI Input Version: for 5 input applications• 10 ASI Input Version: for 5 to 10 input applications
Port Permission	<p>The RTM-3300 number of inputs is controlled by software port permission, allowing full flexibility to user requirements and can be field upgraded to the maximum hardware number of inputs (up to 10 ASI inputs). The upgrade is set by a port permission software code.</p>
Multiplexer	<p>The RTM-3300 accepts any number up to 10 DVB input transport streams and outputs one multiplexed transport stream.</p> <p>Inputs</p> <ul style="list-style-type: none">• Input rate of up to 120 Mbps• Up to 10 ASI inputs <p>Outputs</p> <ul style="list-style-type: none">• Output rate of up to 120 Mbps (78 Mbps with DVB scrambling)• Dual ASI (Serial DVB) Outputs• SPI (Parallel DVB) Output (optional)• Dual ATM DVB-PDH (DS3 / E3) Output (optional)• Dual G.703 E2/E3 unframed (with/without FEC) (optional) <p><i>Note: G.703 and ATM interface are available in the five inputs RTM-3300 version only.</i></p>
Re-Multiplexer (All inputs)	<p>Remuxing enables the selection of individual programs or program components from a feed. RTM-3300 accommodates flexible distribution of digital video data, accepting input of up to 120 Mbps, with a variable output. Each Mux input has the ability to perform Hardware Remuxing without decreasing system performance.</p> <ul style="list-style-type: none">• Re-multiplexes DVB transport streams• PID re-mapping• Maintains unique PID numbering• High accuracy Hardware PCR restamping Completely standard compliant• Maintains PSI/SI information

TriplePass™	<p>The RTM-3300 supports Scopus TriplePass™ - a 3 steps parallel approach, securing best encoding and multiplexing mechanism in multi-encoder environment.</p> <p>The TriplePass™ is based on pre-processing compression, complexity estimation and statistical multiplexing.</p>
Statistical Multiplexing (option)	<p>Statistical Multiplexing permits efficient adaptive distribution of channel resources among input encoders. Using the optional SM-3000 software product allows the allocation of dynamic and/or static access priority to incoming signals according to the required picture quality and output rate.</p> <ul style="list-style-type: none">• Min/Max rate setting of each channel• Maintaining equal quality of all channels by:• Prioritizing the quality of input channels• Fixed quality can be assigned to some of the channels
Conditional Access (Option)	<p>Conditional Access (CA) is supported by the RTM-3300 over DVB Scrambling. Access control is handled by any Simulcrypt compliant CA System, connected over Fast Ethernet to the RTM-3300, or by the CODICO CAS-5000 CA System. DVB common scrambling is performed by the RTM-3300 built in scrambler.</p>
PSI /SI Management	<p>The RTM-3300 provides the following PSI/SI management features:</p> <ul style="list-style-type: none">• Supports incoming Transport Stream tables• Automatic PSI/SI table generator• Extensive automatic PSI/SI Table generation with the use of the optional CODICO® SI-3050 PSI/SI Generator software GUI (graphical user interface)• Maintains consistency of PSI information
Program Clock Reference	<p>Program Clock Reference (PCR) re-stamping is supported. Adjusts the PCR according to the variation of the packet latency in the multiplexing process.</p>
Redundancy Switching	<p>Internal input switching by the RTM-3300 enables the NMS-4000 to switch encoders in case of a fault within the encoders without the need for an external matrix.</p>
Software Upgrade	<p>The RTM-3300 has multiple options for upgrading the Multiplexer software:</p> <ul style="list-style-type: none">• RS-232 Connection The RTM-3300 can be connected to a computer terminal via the RS-232 connection to modify configurations or update software.• FTP The RTM-3300 can receive software upgrades from a network connection via the Ethernet port, by downloading the files using FTP protocol.

User Friendly Controls	Initial setup of the RTM-3300 Multiplexer is quick and easy, with intuitive, menu-driven interface viewed on the Front Panel LCD and controlled locally by the Front Panel control pushbuttons.
Multiple Management Options	RTM-3300 can be managed by: <ul style="list-style-type: none">• Front Panel controls• Terminal (Keyboard and PC Monitor)• NMS-4000 remote management• Telnet• RS-232
General Purpose Interface (GPI)	GPI uses dry contact alarms to indicate various errors.
Filtering	The RTM-3300 filtering capabilities include PID level filtering, as well as discarding any input stuffing packets
Mux Host Application	VxWorks Real Time Operating System.
Data Input Support	Low buffer levels and buffer reset provide very low delay for data packets (with the use of an external IP encapsulator).
Supports Interactive Services	Supports the following interactive services: <ul style="list-style-type: none">• Open TV• Other
BISS (DSNG-CA) Fixed key Scrambling (Optional)	Multi-Channel BISS (DSNG-CA) Fixed key Scrambling
DVB Subtitling	Supports DVB subtitling


1.1.2. Applications

1.1.2.1. Head-End Application

Figure 1-2 illustrates a head-end application for the CODICO® RTM-3300 Compact DVB Re-Multiplexer and Stream Processor in a typical DVB environment.

Video inputs may be encoded in real time by CODICO® E-1000 encoders or pre-encoded and stored on a video server. The video streams are multiplexed by the RTM-3300 and transmitted to the end-user through the transmission chain link. Video streams may also arrive from a broadcast source via a receiver decoder (IRD) or a Common Interface Decoder (CID) and undergo re-multiplexing in the RTM-3300 before redistribution.


Figure 1-2: Typical Head End RTM-3300 Application



1.1.2.2. DTA Application

Figure 1-3 shows a typical DTA RTM-3300 Application.

Figure 1-3: Typical DTA RTM-3300 Application



1.1.2.3. Conditional Access Control Application


The RTM-3300 supports Scopus proprietary and other vendors conditional access systems.

This support includes:

- Embedded scrambling
- Full support of standard SimulCrypt protocol
- Scopus CAS-5000 support over Scopus proprietary protocol

Figure 1-4 illustrates typical encryption architecture.

Figure 1-4: Encryption Block Diagram




1.1.3. Product Line

The SI-3050 PSI/SI Generator is an integral member of the advanced CODICO® product line. The CODICO® product family offers comprehensive solutions for both transmission sites and reception stations. In addition, it is the most cost-effective solution for TV broadcasting applications. Table 1-1 list the CODICO® product family and Figure 1-5 shows the integration of the product line in a DVB environment.

Table 1-1: CODICO® Product Family

PRODUCT	DESCRIPTION
E-900	Industrial Encoder
E-1000/E-1100	Professional Encoders
E-1500/E-1700	DSNG Encoders
IRD-25x0 Series	Professional Integrated Receiver Decoders
IRD-2600/IRD-2800	Advanced Professional Integrated Receiver Decoders
CID-3100	Common Interface Decryptor
RTM-3300	Compact DVB Re-Multiplexer and Stream Processor
RTM-3800	DVB Multiplexer
IVG-6100	IP Broadcast Streamer
RSW-7x00 Series	Redundancy Switches
MOD-7500	DSNG Modulator
NMS-4000	Complete Network Management System
CAS-5000	Conditional Access System
SM-3000	Statistical Multiplexing System
SI-3050	PSI/SI Generator Application

Figure 1-5: CODICO® Integrated Product Line



1.2. RTM-3300 OVERVIEW


1.2.1. RTM-3300 Architecture

The RTM-3300 internally includes a PC Host and one DVB Mux Board. It consists of the following functional blocks (see Figure 1-6):

DVB Mux Boards

The DVB Mux Boards perform the actual Multiplexing operations. It has 10 DVB ASI inputs and 2 DVB ASI outputs. The two outputs are identical and contain the same output transport stream.

Figure 1-6: RTM-3300 Functional Block Diagram



A DVB Mux Board has four main functional blocks: A Multiplexing Block, DSP Block, Output Block and PCI Block.

1. Multiplexing Block

The Multiplexing Block manages the input transport streams. The Multiplexing Block performs on the transport inputs a delineation analyzing and filtering operations such as stuffing drop and 188/204 bytes packet length recognition. The resulting transport streams are forwarded to the FIFOs.

2. DSP Block

The DSP Block takes the transport streams from the FIFOs according to a pre-configured discipline (such as a weighted round robin) and builds an output transport stream. During the process, the DSP forms many manipulations on the packets, such as a PID re-mapping and PCR re-stamping. The DSP Block sends the resulting data to the Output Block.

3. **Output Block**

The Output Block includes output FIFOs, embedded scrambler and two identical DVB ASI Outputs. The DSP Block places its resulting data on the output FIFOs. The output transport stream is encrypted when needed and sent through the two DVB ASI Outputs.

4. **PCI Block**

The PCI Block is used to communicate with the PC Host over PCI BUS.

PC Host

The DVB Mux Board is hosted and managed by the PC Host. It is responsible for downloading the DVB software on initialization stage and providing configuration parameters for DVB Mux functioning. The configuration parameters can be obtained from configuration files or through management applications in real time. The PC Host provides ways of connecting to RS-232, TCP, terminal (System Console) and to the Front Panel.

1.3. Mechanical Structure

1.3.1. Enclosure

The RTM-3300 Compact DVB Re-Multiplexer is housed in a compact, slim-line design yet ruggedized industrial enclosure, 1U by 19" (Rack Mount).

Featuring unrivaled heat dissipation capabilities, the RTM-3300 may be installed in a system rack without the necessity for spacing between units. This allows increased flexibility for installation into limited-space environments.


1.3.2. Front Panel

The front panel of the RTM-3300 provides manual control of the multiplexer (See Figure 1-7).

During operation, initialization and power up, the unit status is displayed by a status report LED and an LCD. The LCD is used to display menu-driven, monitoring and control functions.

A four-way touch pad provides access to extended monitoring and control menu s displayed in the LCD window.

Figure 1-7: RTM-3300 Compact DVB Re-Multiplexer - Front View



1.3.3. Rear Panel

The rear panel of the RTM-3300 Compact DVB Re-Multiplexer provides ASI input/outputs as well as Ethernet and RS-232 control connectors, eliminating the need for additional connector panels on the rack.

A VGA monitor connector and a keyboard connector provide the means to control the multiplexer. The AC connector and the power switch are also located on the rear panel.

Figure 1-8 shows the RTM-3300 rear panel for the 10 ASI Input version.

Figure 1-8: RTM-3300 Compact DVB Re-Multiplexer - Rear View




Table 1-2: RTM-3300 Rear Panel Connectors

CONNECTOR	DESCRIPTION
ASI Output #1 ASI Output #2	Two redundant ASI Outputs. Both transmit the same output stream.
IN #0 through IN #9	The RTM-3300 has a total number of 4, 5 or 10 ASI input connectors. The number of active inputs is defined by the port permission configuration of the unit (10 inputs version only).
VGA	A monitor connection to the standard PC Host. The VGA connection is used for viewing the local terminal screen.
KB	A keyboard connection to the standard PC Host. The keyboard is used to control the local terminal.
RS-232	Enables Terminal control or software download over RS-232.
Ethernet	A connection to a computer network over TCP/IP. The Ethernet connection is used for NMS-4000 control, CA systems, PSI-SI 3050, or for software downloading through FTP.
GPI Connector	GPI uses dry contact alarms to indicate various errors. Refer to paragraph 2.4.3 for details.

1.4. Management

The RTM-3300 Compact Re-Multiplexer and Stream Processor supports the following management interfaces:

- Front Panel Management Interface (Front Panel Control Mode)**
Management of the RTM-3300 from the Front Panel is performed using a menu-driven interface. The position in the menu tree, the parameters and the parameter values are displayed on the front panel LCD display and control. In addition, the LCD displays status and alarm messages constantly.
- Local Terminal Management Interface (Terminal Control Mode)**
The RTM-3300 is based on a PC host and supports terminal operation by using a keyboard and a monitor. This terminal enables the RTM-3300 operator access to all configuration, control and status functions provided by the RTM-3300.
- Telnet Management Interface (Telnet Control Mode)**
The RTM-3300 Multiplexer provides a single session Telnet server interface. The RTM-3300 can be managed from any computer running Telnet client. Telnet provides the remote operator access to the terminal management and to all configurations, controls and status functions provided by the RTM-3300.
- NMS-4000 Management Interface (NMS-4000 Control Mode)**
The NMS-4000 network-management system provides access to operating parameters of the RTM-3300, Automatic and manual redundancy control and uploading software updates. It is possible to view and modify these parameters via the configuration dialog boxes and fields in the NMS-4000 graphical user interface.
- Configuration File Management**
The RTM-3300 can be configured by editing text files containing parameter names and their values and loading the file with the local terminal.

1.5. Capabilities and Specifications

1.5.1. Capabilities

Table 1-3 lists the capabilities of the RTM-3300 and their specifications.

Table 1-3: RTM-3300 Capabilities

FUNCTION	SPECIFICATION
Advanced Re-Multiplexing (All Inputs)	<ul style="list-style-type: none"> • Service Level • Component Level <p>NOTE <i>In the 4 inputs version, only inputs 0 and 1 have advanced Re-Multiplexing capabilities</i></p>
Statistical Multiplexing (Option)	CODICO ® SM-3000 Statistical Multiplexing support
Transport Stream (TS) Processing	<ul style="list-style-type: none"> • PID Re-Mapping • High accuracy PCR Re-Stampling. Completely standard compliant. • PSI/SI DVB Tables Processing and Injection • CODICO® SI-3050 PSI/SI Generator support for DVB Tables Processing and EPG Insertion
Conditional Access (CA) (Option)	<ul style="list-style-type: none"> • DVB Scrambling • SimulCrypt System Interface: 100 BaseT CAS: Irdeto®, Viaccess®, Nagravision®, Batacrypt®, MediaGuard®, VideoGuard®, Conax®, chinacrypt, others • CODICO® CAS-5020 CODICrypt® support • Multi-Channel BISS Multiplexing
Control and Monitoring	<p>Local Control and Monitoring</p> <ul style="list-style-type: none"> • Front Panel Control • Local Terminal and RS-232 • Configuration Files <p>Remote Control and Monitoring</p> <ul style="list-style-type: none"> • Telnet access via Ethernet • CODICO NMS-4000 network management via Ethernet • Software upgrade
Compliance	EMC: FCC part 15 (Class A), CE Safety: CE, CB, cTUVus, UL60950, GS

1.5.2. Interface Connections

Table 1-4, Table 1-5 and Table 1-6 describe the connection interfaces and their specifications.

Table 1-4: RTM-3300 Input Interfaces

INTERFACE	SPECIFICATION
ASI (Serial DVB) Input	4 to 10 ASI Inputs Up to 120 Mbps effective data rate (270 Mbps physical rate)

Table 1-5: RTM-3300 Output Interfaces

INTERFACE	SPECIFICATION
ASI (Serial DVB) Output	2 Identical (Redundancy and Monitoring) ASI Outputs Up to 120 Mbps (78 Mbps with DVB Scrambling). Variable output rate
G.703 – Optional	Dual output Unframed E2 or E3 with/without FEC
ATM DVB-PDH – Optional	Dual output Data rates: DS3, E3, Protocol: ATM AAL-1

NOTE

G.703 and ATM interface are available in the five inputs RTM-3300 version only.

Table 1-6: Control Connection Interfaces

INTERFACE	SPECIFICATION
Serial	2 x RS-232
Ethernet	IEEE 802.3 Ethernet 10BaseT

1.5.3. Physical Specifications

Table 1-7, Table 1-8 and Table 1-9 detail the mechanical dimensions, the electrical power requirements and the environmental conditions for the RTM-3300.

Table 1-7: RTM-3300 Physical Dimensions

DIMENSION	SPECIFICATION
Height	1 RU (Rack Units), 44 mm (1.75")
Width	483 mm (19", standard rack)
Depth	457 mm (18")
Front Clearance (Min.)	900 mm (36")
Rear Clearance (Min.)	800 mm (32")
Weight	7 kg

Table 1-8: RTM-3300 Electrical Power Requirements

REQUIREMENT	SPECIFICATION
AC Supply Voltage	90 to 260 VAC / 50/60 Hz
DC Supply Voltage (Option)	-48V DC
Maximum Power Consumption	70W

Table 1-9: RTM-3300 Environmental Conditions

REQUIREMENT	SPECIFICATION
Temperature	Operational: 0°C thru +45°C Storage and Transportation: -40°C thru +70°C
Operating Humidity (non-condensing)	Operational: 5% thru 85% Storage and Transportation: 0% thru 95%
Cooling	Air convection by means of two fans

2. INSTALLATION

2.1. General

This document describes the procedures required to install the CODICO® RTM-3300 Compact DVB Re-multiplexer and Stream processor. These procedures include site preparation, installation in a 19" rack, cable connections for all unit hardware configurations, and initial power-up and configuration.

2.2. Installation Information

2.2.1. Safety Precautions

To avoid injury and prevent equipment damage, observe the following safety precautions:

WARNING

Do not permit unqualified personnel to operate the equipment.

- Do not move or ship equipment unless it is properly packed in its original wrapping and shipping containers.
- Equipment service and maintenance should be undertaken only by Scopus Network Technologies trained personnel
- To prevent damage by lightning, ground the equipment according to local regulations.

2.2.2. Inventory check

Before installing the unit, ensure that all the equipment to be installed has arrived (Refer to Table 2-1). Check the parts received with the RTM-3300 unit for damage. If anything is missing or damaged, do not continue with the installation.

Table 2-1: RTM-3300 Series Professional Encoder Inventory List

DESCRIPTION	QTY
RTM-3300 Compact DVB Re-Multiplexer and Stream Processor	1
AC Power Cable (for AC Powered RTM-3300)	1 out of the following options: <ul style="list-style-type: none">• European Code Cable (for Euro use)• American Code Cable (for U.S. use)• Power Cable (for Other countries use)
DC Power Cable (for DC Powered RTM-3300)	1
RTM-3300 Compact DVB Re-Multiplexer and Stream Processor User Manual	1

2.3. MECHANICAL INSTALLATION

2.3.1. Site Preparation

NOTE

If the RTM-3300 is to be installed in a standard 19" rack, make sure the rack is fully prepared for the installation.

The RTM-3300 should be installed within 1.5m (5 feet) from an easily accessible grounded AC outlet, capable of furnishing the required supply voltage.

NOTE

Ensure that the AC power supply has been installed by a qualified electrician according to power authority regulations. All powering should be grounded in accordance with local regulations. In any rack installation, ensure that the rack has been properly grounded.

As with any other mission-critical electronic device, the use of a UPS (Uninterrupted Power Supply) and an AVR (Automated Voltage Regulation) is highly recommended to ensure proper operation of the RTM-3300.

2.3.2. Mechanical Installation

The RTM-3300 can be desk mounted or set into a standard 19-inch rack. The unit is supplied with two rack mounting brackets, one for each side of the RTM-3300 housing.

Two L shaped mounting brackets must be secured to the rack rail before installing the RTM-3300 into the rack. The L shaped mounting brackets is used to support the RTM-3300 weight. The RTM-3300 should be slide into the rack above the L shaped mounting brackets and secured with four screws (not included in the kit), two screws in each mounting bracket.

NOTE

When mounting in moving vehicles, the rack must be shock absorbing mounted and attached securely to the vehicle body.

2.4. ELECTRICAL INSTALLATION

The RTM-3300 can be supplied with AC or DC Power Supply. Power and Ground connection for each option is detailed in the following paragraphs

WARNING


Do not connect AC power until you have verified that the line voltage is correct and the proper fuses are installed. Failure to do so could result in electrical shock.

2.4.1. AC Power Supply Connection

The AC Power Cable provides AC power and ground to the RTM-3300. Figure 2-1 shows the location of the AC connector and switch on the RTM-3300 Rear Panel.

1. Connect one end of the cable to the power connector at the AC connector.
2. Connect the other end to the AC power source.
3. The AC power cable provides ground connection to the RTM-3300.

Figure 2-1: RTM-3300 Rear Panel, AC Power Connection




2.4.2. DC Power Supply Connection

The -48 DC power and ground to the RTM-3300 is supplied by an external 48 Vdc Power Supplier. Figure 2-2 shows the DC connections on the RTM-3300 Rear Panel.

1. Connect a (+) 48V DC source wire to the (+) contact on the power terminal board.
2. Connect a (-) 48V DC source wire to the (-) contact on the power terminal board.
3. Connect Grounding point wire to the (GND) contact on the power terminal board.

Figure 2-2: RTM-3300 Rear Panel, DC Power Connection



2.4.3. GPI Connections

Using the dry contact alarms is a two-step process requiring the following:

- a. Connect a device to the GPI using the GPI pin-out connection on Table 2-2. Paragraph 1.3.3 shows the GPI connector in the RTM-3300 rear panel.
- b. Associating alarm numbers with the GPI port number. There are three GPI ports. The alarm numbers are summarized in Table 5-1. Associating a list of alarms to a GPI port is done by editing the command 'RelayErrEnaList' in the MCMUX.CFG file. Chapter 6 details the editing process of the configuration files.

Table 2-2: RTM-3300 GPI Pin-Out Connection

GPI PORT NUM.	PIN NUM.	DESCRIPTION
0	1	Closed on Error / Power Down
	6	Common
	2	Open on Error / Power Down
1	7	Closed on Error / Power Down
	3	Common
	8	Open on Error / Power Down
2	4	Closed on Error / Power Down
	9	Common
	5	Open on Error / Power Down

2.5. QUICK START

Initialization of the RTM-3300 is performed after installation is completed.

Initialization consists of the following procedures:

- Power-up, see paragraph 2.5.1
- Initial configuration (if necessary), see paragraph 2.5.2

2.5.1. Power up Procedure

When powered up, the RTM-3300 executes the following initialization operations:

1. Booting
2. Reading the configuration files
3. Establishing an IP connection (when required)
4. Running the DSP program

When the RTM-3300 is powered-on, it automatically runs the main application program (MCMUX.EXE).

If the system starts successfully, the LCD momentarily displays the <STATUS ALL OK> message followed by the Running Mode display showing the device name, the version number, the date and the time. The status LED is lit.

If there is an error, the LCD displays the appropriate error message.

2.5.2. Initial Configuration Procedure

After initialization, it may be necessary to change the output rate, the IP address configuration or the VPI/VCI addresses in case of an ATM network.

2.5.2.1. Changing Output Rate

To change the output rate, do the following on the RTM3300 front panel:

1. Press the Down key. The System Menu is displayed on the LCD.
2. Select the Config. Menu with the Right and Left keys and then press the Down key. The Config. Menu items are displays.
3. Scroll down until the 'Out Rate' item is displayed and press the Right key once to edit the output rate value.
4. Press the Up and Down keys to modify a single digit. Press the Right and Left keys to select a digit.
5. Press the Enter key to confirm the modification.

2.5.2.2. Changing Device IP Address

To change the device IP address, follow the instructions above for the output rate modification procedure, however, in step 3 scroll down to the 'IP ADR.' Item instead.

2.5.2.3. Changing VPI/VCI Addresses (With ATM Optional Output)

To change the VPI and VCI values, edit the commands 'AtmeVpiAddr' and 'AtmeVciAddr' in the file MCMUX.CFG as explained in chapter 6.

3. OPERATION

3.1. General

This chapter provides information and operating directives for major processes supported and provided by the RTM-3300 Compact DVB Re-Multiplexer and Stream Processor. These processes are:

- Re-multiplexing, or program grooming, see paragraph 3.2.
- PID re-mapping, see paragraph 3.3.
- Conditional Access (CA) processing, see paragraph 3.4.

3.2. Re-Multiplexing (Grooming)

3.2.1. Re-Multiplexing Concept

Remuxing, or program grooming, is the process of selecting individual programs or program components from a variety of digital multiplexes and local feeds to create a customized digital program stream. Grooming also enables the delivery of additional programs and services (pay-per-view, programming, Encapsulated IP, Subtitling, and ad insertion).

NOTE

The re-multiplexing setup is performed for one input at a time.

Accepting the re- multiplexing update process will delete the old remux setup for that input.

The Mux will stop operating for a short time when entering the remux input utility and when updating the changes of the remux input utility.

3.2.2. Re-Multiplexing Process

To configure the RTM-3300, proceed according to the following steps: (refer to chapter 5 for detailed instruction on the terminal operation)

1. From the main menu, select 'c' (configuration menu). The config menu is displayed.
2. From the config menu, select 'r' (remux input utl.). A "select input channel to remux" dialog message is displayed.

```
>r
#-----#
Remux setup is done for 1 input at a time.
Completion of the remux process will destroy the
old remux setup for the same input.
#-----#

--> Enter: Input channel to remux (0-3):
--> 2
```

3. Enter the required input for remuxing. Note that the input numbering starts with zero. The "Remux chnl" dialog for selected channel is displayed. Input 2 was selected in the example below.

```

--> 2
Remux chnl 2
DSP load 'mux.i0' o.k.
DSP msg: ***** MCMUX C30 Ver 99.10 *****
Input Channel 2:
1) -- ON --> Prg.10750: (P) (PMT:0x012C) 'RTL 102.5'
2) -- ON --> Prg.10707: (P) (PMT:0x00CF) 'TV ROMANIA'
3) -- ON --> Prg.10751: (P) (PMT:0x012D) 'In direct Romania'
4) -- ON --> Prg.10752: (P) (PMT:0x012E) 'Romania Musical'
5) -- ON --> Prg.10701: (P) (PMT:0x00C9) '3 ABN'
6) -- ON --> Prg.10703: (P) (PMT:0x00CB) 'Ultra Blue TV'
7) -- ON --> Prg.10704: (P) (PMT:0x1079) '102.5 HIT Ch'
8) -- ON --> Prg.10705: (P) (PMT:0x0038) 'TLC SAT'
9) -- ON --> Prg.10706: (P) (PMT:0x0020) 'PRO-SAT'
10) -- ON --> Prg.10709: (P) (PMT:0x00D1) 'Channel SUN'
11) -- ON --> Prg.10702: (P) (PMT:0x00CA) 'MRTV'
12) -- ON --> Prg.10708: (P) (PMT:0x00D0) 'TRT DISH ASIA'
13) -- ON --> Prg.10710: (P) (PMT:0x00D2) '123SAT/69XTV'

```

4. From the Remux chnl dialog, select the program to modify. The Remux chnl dialog is modified.

```

--> Enter: ESC(abort), 'r'(reread), 'u'(update), '1'..'13'(toggle change) :
--> 2
Input Channel 2:
1) -- ON --> Prg.10750: (P) (PMT:0x012C) 'RTL 102.5'
2) (off) Prg.10707: (P) (PMT:0x00CF) 'TV ROMANIA'
3) -- ON --> Prg.10751: (P) (PMT:0x012D) 'In direct Romania'
4) -- ON --> Prg.10752: (P) (PMT:0x012E) 'Romania Musical'
5) -- ON --> Prg.10701: (P) (PMT:0x00C9) '3 ABN'
6) -- ON --> Prg.10703: (P) (PMT:0x00CB) 'Ultra Blue TV'
7) -- ON --> Prg.10704: (P) (PMT:0x1079) '102.5 HIT Ch'
8) -- ON --> Prg.10705: (P) (PMT:0x0038) 'TLC SAT'
9) -- ON --> Prg.10706: (P) (PMT:0x0020) 'PRO-SAT'
10) -- ON --> Prg.10709: (P) (PMT:0x00D1) 'Channel SUN'
11) -- ON --> Prg.10702: (P) (PMT:0x00CA) 'MRTV'
12) -- ON --> Prg.10708: (P) (PMT:0x00D0) 'TRT DISH ASIA'
13) -- ON --> Prg.10710: (P) (PMT:0x00D2) '123SAT/69XTV'

```

5. Enter 'u' to update the changes to the MUX. An updating message is displayed on the terminal screen.

```

--> Enter: ESC (abort), 'r' (reread), 'u' (update), '1'..'13' (toggle change) :
--> u
Remax Process end O.K.!

...Performing Rerun Command...
    
```

3.3. PID Re-Mapping

3.3.1. PID Re-Mapping Concept

PID re-mapping is the process of automatically changing the output stream PIDs. PIDs on several streams from different sources can be identical to each others. The PID Remapping process eliminates identical PIDs on the output stream by scanning every PID on all streams and changing their values, so that each PID in the output stream is unique. The PID re-mapping process is automatic but can be done manually too.


3.3.2. PID Re-Mapping Process

Figure 3-1 show an example for a PID Remapping process. The example illustrates two streams entering the RTM-3300, each consisting of two programs. The PCR PID of program 1 on stream 1 and the Audio PID of program 1 on stream 2 both has the same PID number, which would have caused an error on the output stream. To prevent ambiguous PIDs, the RTM-3300 re-maps the programs and generates one output stream of four programs, individually identified.

The PID re-mapping process operates as follows:

- The Mux scans all PMT and gives them values of 100, 200, 300, etc.
- All services listed in a PMT are numbered starting with the value of their PMT plus one.

Figure 3-1: Example for PID Remapping Process



3.4. Conditional Access (CA) Processing

3.4.1. Conditional Access (CA) Processing Concept

Conditional Access (CA) is the process of scrambling a program to control the access to licensed end-users (optional feature).

The following conditional access options are supported by the RTM-3300:

- Standard DVB-CSA Scrambling.
- Interface with major SimulCrypt CAS suppliers (Irdeto® Viaccess®, Nagravision®, MediaGuard®, VideoGuard®, Conax®, others)
- Scopus Proprietary scrambling with connection to CODICO® CAS-5000 Conditional Access System.

3.4.2. Conditional Access (CA) Process

The use of the RTM-3300 in a conditional access environment requires the following:

- Configuration of the RTM-3300 for CA operation.
- Synchronization of the CAS bouquet association table with the RTM-3300 program association table.
- Operation of the RTM-3300 and check for correct operation.

3.4.2.1. CA Configuration

The CA configuration requires activation of the conditional access functions in the RTM-3300. It can be performed in several ways:

- From the Front Panel control mode (refer to chapter 4 for detailed information on the options provided by the front panel control mode menus).
- From the Telnet or the Terminal control modes (refer to chapter 5 for detailed information on the options provided by the terminal control mode menus).
- By updating the RTM-3300 configuration files (refer to chapter 6 for detailed information on the mcmux.cfg, mcmux.rmp and simul.ini configuration files).

The following directives describes the specific configuration functions required for the CA operation and the state / parameters required for each function.

NOTE

The RTM-3300 can simultaneously operate with more than one CA system using simulcrypt.

a. Enable conditional access scrambling

- **Front Panel menu:**
Select **CONFIG / SCRAMBLING** to enable the scrambler (refer to paragraph 4.3.7).
- **Terminal menu:**
From the main menu, select 'c' (configuration menu), then
Select 'm' (miscellaneous configuration menu), then
Select '4' to enable the scrambler (refer to paragraph 5.9.2.4).

- **mcmux.cfg file:**
Set "Scramble" parameter to "Enable" (refer to Table 6-1).
- b. **Select the CA system used**
- **Front Panel menu:**
NOTE: Function not accessible from the Front Panel menu.
 - **Terminal menu:**
From the main menu, select 'c' (configuration menu), then
Select 'm' (miscellaneous configuration menu), then
Select '5' to select the scrambler, then select the scrambler from the Scrambling Type list (refer to paragraph 5.9.2.5).
 - **mcmux.cfg file:**
Set "ScrType" parameter to the correct scrambling system (refer to Table 6-1):
 - SCOPUS: Scopus style scrambler
 - MIXED: Scopus + DVB style scrambler
 - SCOPUS_DVB DVB style scrambler
 - SYMULCRYPT DVB style scrambler
 - FIX_KEY BISS Mode 1 style scrambler
- NOTE:**
For Nagra® SimulCrypt CAS, continue from step c.
For all other CA-systems, continue from step d.
- c. **For Nagra® SimulCrypt CA system:**
1. Enable the Nagra® UDP Control for the Main/Backup multiplexer
 - **Front Panel menu:**
NOTE: Function not accessible from the Front Panel menu.
 - **Terminal menu:**
NOTE: Function not accessible from the Terminal menu.
 - **mcmux.cfg file:**
Set "CtrlUdp0Ena" and/or "CtrlUdp1Ena" parameter to "Enable" (refer to Table 6-1).
 2. Set the Nagra® UDP Host port information for the Main/Backup multiplexer
 - **Front Panel menu:**
NOTE: Function not accessible from the Front Panel menu.
 - **Terminal menu:**
NOTE: Function not accessible from the Terminal menu.
 - **mcmux.cfg file:**
Enter the port number in the "CtrlUdp0HostPort" and/or "CtrlUdp1HostPort" parameter (refer to Table 6-1).
 3. Set the Nagra® UDP Host IP information for the Main/Backup multiplexer
 - **Front Panel menu:**
NOTE: Function not accessible from the Front Panel menu.
 - **Terminal menu:**
NOTE: Function not accessible from the Terminal menu.
 - **mcmux.cfg file:**
Enter the IP information in the "CtrlUdp0HostIp" and/or "CtrlUdp1HostIP" parameter (refer to Table 6-1).

d. **For all other CA systems**

1. Set the Host IP address and the Host IP Port number for the Main multiplexer
 - **Front Panel menu:**
NOTE: Function not accessible from the Front Panel menu.
 - **Terminal menu:**
NOTE: Function not accessible from the Terminal menu.
 - **mcmux.cfg file:**
Enter the Host IP address and the Host IP Port number in the "CaeTcp" parameter (refer to Table 6-1).
2. Set the Host IP address for the Backup multiplexer
 - **Front Panel menu:**
NOTE: Function not accessible from the Front Panel menu.
 - **Terminal menu:**
NOTE: Function not accessible from the Terminal menu.
 - **mcmux.cfg file**
Enter the Host IP address in the "CaeBackupHost" parameter (refer to Table 6-1).

e. **Define the Conditional Access Table (CAT) descriptor**

- **Front Panel menu:**
NOTE: Function not accessible from the Front Panel menu.
- **Terminal menu:**
NOTE: Function not accessible from the Terminal menu.
- **mcmux.rnp file:**
Set "CatCaDescriptor" parameters (format: **n m s1**), where (refer to Table 6-1):
n: CA_system_id (16 bit). (For CAS 0).
m: CA_pid (EMM) (13 bit). (For cat automatic treat).
s1: CAT private data byte arrangement style (12:34:A5:3a)
CA_system_id = 0 tab with no ca dscr (BISS).

f. **Define the Pnum CA descriptor:**

- **Front Panel menu:**
NOTE: Function not accessible from the Front Panel menu.
- **Terminal menu:**
NOTE: Function not accessible from the Terminal menu.
- **mcmux.rnp file:**
Set "PnumCaDescriptor" parameters (format: **n m o s1**), where (refer to Table 6-1):
n: out program num (16 bit). (FMT CAS 0).
m: CA_system_id (16 bit).
o: CA_pid (EMM) (13 bit).
s1: CAT private data byte arrangement style (12:34:A5:3a).
CA_system_id (0 x 2600).
CA_pid (0 x 1FFF) for BISS.

3.4.2.2. CA Operation

Conditional Access (CA) operation requires the completion of all configuration and synchronization activities. Activation of the RTM-3300 and the CAS automatically starts the scrambling functions.

Correct operation can be monitored on the RTM-3300 Front Panel menu or on the Monitor menu:

NOTE

*Make sure that the CAS status indicators are displaying correct operation
For example: The status indicator on the CODICO® CAS-5000 lights-up in green.*

Check CA enabled for the correct service.

1. Front Panel menu:

- Select **STATUS / GENERAL STAT** to display the status of the CA scrambler (refer to paragraph 4.2.2).
- Scroll the report and check the following status indications:
'Scramble': **ON** (activated)
'CAE Control': **Enabled** (activated)

2. Terminal menu:

- **Scrambling General Status**
From the main menu, select 's' (General Status report), then check the following:
 - "CAE tcp control" function is enabled (the status line is marked **ENA**)
 - "Scamble Stat" function is enabled and operates as required (the status line is marked **ENA** and the scrambler information is correct, refer to paragraph 5.5).
- **Input CA Status**
From the main menu, select 'm' (Mux Transport Information menu), then Select 'm' (information about all inputs), then check that all scrambled services are enabled (the respective PID is marked **CA**, refer to paragraph 5.6).

3.5. Updating the Multiplexer Software

Software upgrade on the RTM-3300 can be done through FTP or RS232 connection.

Both connection types can be managed through the RTM-3300 front panel or the RTM-3300 terminal/Telnet.

Paragraph 3.5.1 details the software update through RS232 connection.

Paragraph 3.5.2 details the software update through FTP connection.

For FTP server activation, refer to paragraphs 4.3.4 and 5.9.2.8.

3.5.1. Software Update Using RS232

Follow the procedure below to upgrade the RTM-3300 software:

1. Connect a PC with a Null Modem Cable to the Com1 port (RS232) of the MUX.
2. Turn the MUX on and check the software version installed in it.
3. Create a directory on the PC (C:/Mux_vers) and copy the file (e.g. V0250com.exe) into that directory.
4. Double click the file on the PC to activate the self-extraction (the file is a self extracting ARJ file which contains all the required components in order to perform the upgrading of the system).
5. For authorization press "Y" and "Enter".
6. Load the update version in one of the following methods:
 - On the Mux, front panel menu, use the arrows choose the "CTRL. MENU", and select "LOAD NEW MUX VER" and press the Enter button.
 - If you have a monitor and keyboard connected to the MUX, you can activate the action by typing on the keyboard "C" and afterwards "L".
7. On the PC, under the Dos prompt, get into the directory of the update. Run the 'Update.bat' file.
8. The screen will show the update window and the progress of the update.

NOTE

The update might take a while (up to 5 min.)

9. After the update is completed, the update window disappears and the MUX screen shows the conclusion of the update.
10. The MUX automatically restart itself, and the new software version is enabled. The new version of the software will be shown on the Mux terminal.

3.5.2. Software Update Using FTP

The RTM-3300 software can be updated from a distant location using the FTP Server. The FTP server should be enabled in the RTM-3300 in order to perform the software update. Refer to paragraph 4.3.4 and 5.9.2.8 to enable the RTM-3300 FTP Server feature.

Follow the procedure below to upgrade the RTM-3300 software:

1. Connect a PC to the same network as the RTM-3300 device.
2. Create a directory on the PC (C:/Mux_ers) and copy the file (e.g. V0250FTP.exe) into that directory.
3. Double click the file on the PC to activate the self-extraction (the file is a self extracting ARJ file which contains all the required components in order to perform the upgrading of the system).
4. For authorization press "Y" and "Enter".
5. On the PC, under the Dos prompt, get into the directory of the update. Type 'Update.bat' and the RTM-3300 IP address and press enter.
6. The screen will show the update window and the progress of the update.
7. After the update is completed, the update window disappears and the MUX screen shows the conclusion of the update.
8. The MUX automatically restart itself, and the new software version is enabled. The new version of the software will be shown on the Mux terminal.

4.1.2. Front Panel Control Menu Operation

The Control Menu enables the operator to configure the RTM-3300 parameters via the Front Control Panel. The menus are arranged in a hierarchical structure.

Figure 4-2 shows the organization of the Front Panel menus.


The RTM-3300 top menu is the System Menu. It consists of three main functions, described in Table 4-2.

The following paragraphs provide a detailed description of each main function. The description includes information on how to use the function.

Table 4-2: RTM-3300 System Menu Functions

FUNCTION	DESCRIPTION
STATUS	Display of RTM-3300 status messages. For details, see paragraph 4.2.
CONFIG	Manage the configurable parameters. The parameters that can be configured from the front panel include the MPEG-2 transport stream (TS) data rate, and the IP address of the Ethernet management port. For details, see paragraph 4.3.
CTRL	Contains RTM-3300 control functions. For details, see paragraph 4.4.

Figure 4-2: Organization and Menu Hierarchical Structure of the Front Panel Control Mode



4.2. Status Sub-Menu

a. Menu Purpose and Use

The Status Menu displays on the RTM-3300 LCD the status and operational information of the FIFOs. The status messages are read-only; they cannot be changed from the Status Menu.

b. Menu Structure

The Status menu has two sub menus:

- FIFOS – STAT
- GENERAL STAT

c. Menu Control

1. Menu Enter Path

- With the top-level message (“RTM-3300 Ver xx, / Date xx Time xx”) displayed on the LCD, press the Down key. The System Menu is displayed
- Select the Status message option and press the Down key, The Status Menu is displayed.

2. Menu Item Select

- Any item on the Status Menu is selected by pressing the Right or Left key.
- To access an option press the Down or Enter key.

3. Menu Exit

The Status Menu is closed by pressing the Esc key

4.2.1. FIFOs Status Report

a. Report Purpose and Use

The FIFO Status report displays to the RTM-3300 operator the status and operational information of the 10 Input FIFOs and the Output FIFO.

b. Report Structure

The FIFO Status report provides the following information on each system input FIFO and on the output FIFO. Scroll with the up and down arrow to toggle between the different inputs and output:

- **"Chnl":**
Displays the FIFO logic name.
- **"Rate":**
Displays the input/output rate of the FIFO.
The **Output** FIFO shows the division of the output rate between Data and Padding in parenthesis below the rate.
Data Range: 5Mbps – 80Mbps
- **"In":**
Displays the FIFO designated number.
- **"Fifo %":**
Displays the FIFO use of the Mux Buffer.
Usage range: 0% - 100%
- **"ON/OFF":**
Displays the Operational state of the input.
Options: "ON" or "OFF".
- **"ENA/DIS":**
Displays the administrative state. It is displayed only for the output FIFO.
Options: enabled (ENA) or disabled (DIS).

c. Report Control

1. Report Enter Path

From the Status Menu Select the FIFOS-STAT, press the Down key.

2. Browse Through The Report

To browse the FIFOS Status report use the Up and Down key.

3. Report Exit

The FIFOs status report is closed by pressing the Esc key

4.2.2. General Status Report

a. Report Purpose and Use

The General Status report displays a status report on the RTM-3300 main functions.

b. Report Structure

The General Status report provides the following information on the system main functions:

Table 4-3: General Status Report Structure

FUNCTION NAME	DESCRIPTION	OPTIONS
PCR RESTAMPING :	Displays the status of the PCR Restamping.	enabled or disabled
PC LOG FILE REPORT :	Displays the status of the Log file report.	ON or OFF
SCRAMBLE :	Displays the status of the Scramble function.	ON or OFF
CAE CONTROL :	Displays the status of the CAE (CAS) control function.	enabled or disabled
NMS CONTROL :	Displays the status of the NMS Control function.	enabled or disabled
EIT AUTO. TABLE :	Displays the status of the EIT auto. table.	enabled or disabled
CAT AUTO. TABLE :	Displays the status of the CAT auto. table.	enabled or disabled
OUTPUT DEBUG CHK :	Displays the status of the Output Debug Check.	ON or OFF
SDT AUTO. TABLE :	Displays the status of the SDT auto. table.	enabled or disabled
NIT AUTO. TABLE :	Displays the status of the NIT auto. table.	enabled or disabled
TOT AUTO. TABLE :	Displays the status of the TOT auto. table.	enabled or disabled
TDT AUTO. TABLE :	Displays the status of the TDT auto. table.	enabled or disabled
PMT AUTO. TABLE :	Displays the status of the PMT auto. table.	enabled or disabled
PAT AUTO. TABLE :	Displays the status of the PAT auto. table.	enabled or disabled

c. Report Control

1. Report Enter Path

From the Status Menu Select the GENERAL STAT, press the Down key.

2. Browse Through The Report

To browse the FIFOS Status report use the Up or Down key

3. Report Exit

The General status report is closed by pressing the Esc key

4.3. Configuration Sub-Menu

a. Menu Purpose and Use

The CONFIG. Menu provides access to the RTM-3300 configuration operating parameters. The configurable parameters in the Config. Menu depend on the control interface.

Any parameter displayed on the LCD during operation can be changed and set. The LCD displays both the parameters and the range of the legal values.

b. Menu Structure

The Config. Menu provides the following options:

Table 4-4: Configuration Sub-Menu Structure

FUNCTION	DESCRIPTION	MORE DETAILS
OUTP PACKET SIZE :	Select output packet size 188/204	See para. 4.3.1
TTY	Select the TTY Baud rate	See para. 4.3.2
TELNET :	Enable or Disable the Telnet function	See para. 4.3.3
FTPSRV	Enable or Disable the FTP server	See para. 4.3.4
PERMISSION	Set and display permissions status	See para. 4.3.5
PANEL CONTRAST :	Sets the LCD screen contrast	See para. 4.3.6
SCRAMBLING :	Enable or Disable the Scrambling	See para. 4.3.7
SDT AUTO. TAB :	Enable or Disable the SDT table	See para. 4.3.8
NIT AUTO. TAB :	Enable or Disable the NIT table	See para. 4.3.9
TDT AUTO. TAB :	Enable or Disable the TDT table	See para. 4.3.10
PMT AUTO. TAB :	Enable or Disable the PMT table	See para. 4.3.11
PAT AUTO. TAB :	Enable or Disable the PAT table	See para. 4.3.12
TIME HH:MM:SS :	Enables the system time to be modified	See para. 4.3.13
DATA DD-MM-YY:	Enables the system date to be modified	See para. 4.3.14
ROUTER	Set-up the router IP address	See para. 4.3.15
MASK	Set-up the Mask	See para. 4.3.16
IP ADR:	Enables the IP address of the system network interface to be defined	See para. 4.3.17
OUT RATE:	Enables adjustment of the Output Rate of the Mux in Hz units.	See para. 4.3.18

c. Menu Control

1. Menu Enter Path

- With the Running Mode message displayed on the LCD, press the Down key. The System Menu is displayed.
- Select the CONFIG option and press the Down key, The CONFIG. Menu is displayed.

2. Menu Item Select

Any item on the Config. Menu is selected by pressing the Right or Left key for selecting the option, to access an option press the Down or Enter key.

3. Menu Exit

The Config. Menu is closed by pressing the Esc key.

4.3.1. Select Output Packet Size Function

a. Function Purpose and Use

Select Output Packet Size, the packet size can be modified to 188 or 204, the default packet size is 188.

b. Function Run Procedure

1. Use the Right or Left key to select the desired option.
2. Press the Enter key to confirm your choice.

c. Function Cancel

The Output Packet Size function is closed by pressing the Esc key.

4.3.2. Set TTY Baud Rate Function

a. Function Purpose and Use

Select the TTY Baud rate. Available options: 2400, 115200, 38400, 19200, 9600.

b. Function Run Procedure

1. Use the Up or Down key to select the desired option.
2. Press the Enter key to confirm your choice.

c. Function Cancel

The TTY function is closed by pressing the Esc key.

4.3.3. Enable/Disable TelNet Function

a. Function Purpose and Use

Enable or Disable the Telnet control program for the remote terminal.

b. Function Run Procedure

When the Telnet function is selected, press the Right or Enter key to Enable or Disable the Telnet function.

1. Use the Right or Left key to select the desired option.
2. Press the Enter key to confirm your choice.

c. Function Cancel

The Telnet function is closed by pressing the Esc key.

4.3.4. Enable/Disable FTPSRV

a. Function Purpose and Use

Enable or Disable the FTP Server, used for software download and configuration files upload/download.

b. Function Run Procedure

When the FTPSRV is selected, do the following:

1. Use the Right or Left key to select the desired option (Enable / Disable).
2. Press the Enter key to confirm your choice.

Refer to paragraph 3.5.2 for software upgrade instruction and to chapter 6 for configuration file management.

c. Function Cancel

The FTPSRV function is closed by pressing the Esc key.

4.3.5. Permissions Control Function

a. Function Purpose and Use

The Permission function features a field upgrade for the following RTM-3300 functions:

- Scrambling (BISS)
- Simulcrypt (for Simulcrypt operation, both Simulcrypt and scrambling have to be enabled)
- Port permission (applicable for 10 inputs hardware only)

b. Function Run Procedure

The Permission function has three sub-menus:

- **Reg_Num:** Displays a unique ID number for the RTM-3300. The number is required for field upgrade. The number should be provided to Scopus while the upgrade is ordered.
- **Status:** displays the status of the permissions
- **Change:** After getting a permission code from Scopus Network Technologies personnel, enter the code in the Change sub-menu to apply the new permissions.

c. Function Cancel

The Permissions Control function is closed by pressing the Esc key.

4.3.6. Panel Contrast Control Function

a. Function Purpose and Use

The Panel Contrast Control function is used to modify the LCD window contrast.

b. Function Run Procedure

1. When the Panel Contrast Control function is selected, press the Right or Enter key to set the screen contrast.
2. Press the Right key to decrease the screen's contrast and the Left key to increase the screen's contrast.
3. Press the Escape key to confirm the new screen contrast.

4.3.7. Enable/Disable Scrambling Function

a. Function Purpose and Use

The Scrambling function determines whether the output stream of the RTM-3300 will be scrambled or not. If a DVB scrambler board is present (paragraph 5.7.1 describes how to indicate the presence of a scrambler board), scrambling will be performed according to DVB standards.

b. Function Run Procedure

1. When the Scrambling function is selected, press the Right or Enter key to Enable or Disable the Scrambling.
2. Use the Right or Left key to select the desired option.
3. Press the Enter key to confirm your choice.

c. Function Cancel

The Scrambling function is closed by pressing the Esc key.

4.3.8. Enable/Disable SDT Auto Table Generation Function

a. Function Purpose and Use

Enable / Disable the Service Description Table.

b. Function Run Procedure

1. When the Enable / Disable SDT auto table function is selected, press the Right or Enter key to Enable or Disable the SDT table.
2. Use the Right or Left key to select the desired option.
3. Press the Enter key to confirm your choice.

c. Function Cancel

The Enable/Disable SDT table function is closed by pressing the Esc key.

4.3.9. Enable/Disable NIT Auto Table Generation Function

a. Function Purpose and Use

Enable / Disable the Network Information Table.

b. Function Run Procedure

1. When the Enable / Disable NIT auto table function is selected, press the Right or Enter key to Enable or Disable the NIT table.
2. Use the Right or Left key to select the desired option.
3. Press the Enter key to confirm your choice.

c. Function Cancel

The Enable/Disable NIT table function is closed by pressing the Esc key.

4.3.10. Enable/Disable TDT Auto Table Generation Function

a. Function Purpose and Use

Enable / Disable the Time Date Table.

b. Function Run Procedure

1. When the Enable / Disable TDT auto table function is selected, press the Right or Enter key to Enable or Disable the TDT table.
2. Use the Right or Left key to select the desired option.
3. Press the Enter key to confirm your choice.

c. Function Cancel

The Enable/Disable TDT table function is closed by pressing the Esc key.

4.3.11. Enable/Disable PMT Auto Table Generation Function

a. Function Purpose and Use

Enable / Disable the Program Map Table.

b. Function Run Procedure

1. When the Enable / Disable PMT auto table function is selected, press the Right or Enter key to Enable or Disable the PMT table.
2. Use the Right or Left key to select the desired option.
3. Press the Enter key to confirm your choice.

c. Function Cancel

The Enable/Disable PMT table function is closed by pressing the Esc key.

4.3.12. Enable/Disable PAT Auto Table Generation Function

a. Function Purpose and Use

Enable / Disable the Program Association Table.

b. Function Run Procedure

1. When the Enable / Disable PAT auto table function is selected, press the Right or Enter key to Enable or Disable the PAT table.
2. Use the Right or Left key to select the desired option.
3. Press the Enter key to confirm your choice.

c. Function Cancel

Pressing the Esc key closes the Enable/Disable PAT table function.

4.3.13. Set-Up Current Time Function

a. Function Purpose and Use

The Set-Up Current Time function allows the user to modify or define the system time of the RTM-3300. The time format is HH:MM:SS.

b. Function Run Procedure

1. When the Set-Up Current Time function is selected, press the Right or Enter key to modify the system time.
2. Use the Up or Down key to modify the selected digit and the Right or Left key to select the previous or next digit to change.
3. Press the Enter key to confirm the modification.

c. Function Cancel

The Set-Up Current Time function is closed by pressing the Esc key.

4.3.14. Set-Up Current Date Function

a. Function Purpose and Use

The Set-Up Current Date function allows the user to modify or define the system date of the RTM-3300. The date format is DD-MM-YY.

b. Function Run Procedure

1. When the Set-Up Current Date function is selected, press the Right or Enter key to modify the system time.
2. Use the Up or Down key to modify the selected digit and the Right or Left key to select the previous or next digit to change.
3. Press the Enter key to confirm the modification.

c. Function Cancel

The Set-Up Current Date function is closed by pressing the Esc key.

4.3.15. Set-Up Router Address Function

a. Function Purpose and Use

Defines the Router (Default Gateway) IP address. The IP Address format is XXX.XXX.XXX.XXX.

b. Function Run Procedure

1. When the Set-Up Router Address function is selected, press the Right or Enter key to modify the Router Address.
2. Use the Up or Down key to modify the selected digit and the Right or Left key to select the previous or next digit to change.
3. Press the Enter key to confirm the modification.

c. Function Cancel

The Set-Up Router Address function is closed by pressing the Esc key.

4.3.16. Set-Up Mask Function

a. Function Purpose and Use

Defines the network Mask. The Mask format is XXX.XXX.XXX.XXX.

b. Function Run Procedure

1. When the Mask function is selected, press the Right or Enter key to modify the Mask.
2. Use the Up or Down key to modify the selected digit and the Right or Left key to select the previous or next digit to change.
3. Press the Enter key to confirm the modification.

c. Function Cancel

The Mask function is closed by pressing the Esc key.

4.3.17. Set-Up IP Address Function

a. Function Purpose and Use

Enables the IP address if a system interface to be defined, that way the RTM-3300 can be connected to network. The IP Address format is XXX.XXX.XXX.XXX.

b. Function Run Procedure

1. When the Set-Up IP Address function is selected, press the Right or Enter key to modify the IP Address.
2. Use the Up or Down key to modify the selected digit and the Right or Left key to select the previous or next digit to change.
3. Press the Enter key to confirm the modification.

c. Function Cancel

The Set-Up IP Address function is closed by pressing the Esc key.

4.3.18. Set-Up Output Rate Function

a. Function Purpose and Use

Enables adjustments of the Output Rate of the Mux, the output rate must be set to a higher value than the received one otherwise an overflow will occur, setting a higher output rate will cause the system to receive empty table which represents no data. The Output Rate format is XXXXXXXXXX (Bps). The Output Rate Function accepts values up to 150,000,000.

b. Function Run Procedure

1. When the Set-Up Output Rate function is selected, press the Right or Enter key to modify the system time.
2. Use the Up or Down key to modify the selected digit and the Right or Left key to select the previous or next digit to change.
3. Press the Enter key to confirm the modification.

c. Function Cancel

The Set-Up Output Rate function is closed by pressing the Esc key.

4.4. CTRL Sub-Menu

a. Menu Purpose and Use

The CTRL Menu is used to invoke operating commands.

CAUTION

All the commands under the CTRL Sub-Menu require the RTM-3300 to restart itself. While restarting, the RTM-3300 stops its operation for a while.

b. Menu Structure

The Ctrl. Menu provides the following options:

- **Rerun Mux:**
Restarts the Multiplexer. For details, see paragraph 4.4.1.
- **Load New MUX Version Function:**
loads the new Multiplexer. For details, see paragraph 4.4.2.
- **Reset Output FIFO:**
Resets the Output FIFO. For details, see paragraph 4.4.3.
- **System Boot**
Restarts the System. For details, see paragraph 4.4.4.
- **Reset DSP**
Resets the DSP. For details, see paragraph 4.4.5.

c. Menu Control

1. Menu Enter Path

- a. With the Running Mode message displayed on the LCD, press the Down key. The System Menu is displayed.
- b. Select the CTRL. option and press the Down key, The CTRL Menu is displayed.

2. Menu Item Select

Any item on the CTRL Menu is selected by pressing the Right or Left key for selecting the option, to access an option press the Down or Enter key.

3. Menu Exit

The CTRL Menu is closed by pressing the Esc key.

4.4.1. ReRun Mux Function

a. Function Purpose and Use

The Re-Run McMux Function restarts the Host and the DSP.

b. Function Run Procedure

When the Re-Run McMux function is selected, press the Enter key to re-run the mcmux.

4.4.2. Load New MUX Version Function

- a. Function Purpose and Use**
Load a new software version through an RS-232 connector.
- b. Function Run Procedure**
Refer to paragraph 3.5.1 for software upgrade instruction.

4.4.3. Reset Output FIFO Function

- a. Function Purpose and Use.**
The Reset DSP Output FIFO Function Resets DSP without resetting the Mux.
- b. Function Run Procedure**
When the Reset DSP Output FIFO function is selected, press the Enter key to reset the output FIFO.

4.4.4. System Boot

- a. Function Purpose and Use.**
The System Boot function restarts the Mux computer.
- b. Function Run Procedure**
When the System Boot function is selected, press the Enter key to reset the MUX. Wait until the Mux computer restarts.

4.4.5. Reset DSP

- a. Function Purpose and Use.**
The Reset DSP Function Resets the DSP.
- b. Function Run Procedure**
When the Reset DSP function is selected, press the Enter key to reset the DSP.

5. TELNET AND TERMINAL CONTROL MODE

5.1. General

This chapter provides detailed description of the Terminal Control mode, provided for local or remote operation of the RTM-3300 DVB Multiplexer.

Local operation is provided by connecting a keyboard and a VGA monitor to the RTM-3300 or connecting to the unit, through an RS-232 port, another computer.

Remote operation is provided via any computer connected, through the LAN, to the RTM-3300 and using a Telnet Client control program.

5.2. Power-Up and Log-In

5.2.1. Local Terminal Operation

The local terminal operating mode is activated when a standard PC keyboard and a VGA monitor are connected to the RTM-3300 Unit. Once the power up, sequence is completed, the program displays the Terminal Main Menu (refer to paragraph 5.3.2) on the local monitor.

5.2.2. Remote Terminal Operation

The remote terminal operating mode is enabled by connecting a PC running a Telnet client to the Ethernet port of the RTM-3300 Unit.

The Telnet connection provides remote access to all configuration, control and status functions provided by the RTM-3300. Operation of the RTM-3300 Using Telnet is the same as operating the local RTM-3300 terminal but with a remote computer.

A detailed description of the system configuration, control status and commands that can be performed on the RTM-3300 using the Telnet Control Mode, is provided in the rest of this chapter.

- To enable Telnet management from the front panel, refer to paragraph 4.3.2.
- To enable Telnet management from the Local Terminal, refer to paragraph 5.9.2.7.

To initiate the Telnet connection from a computer:

1. Launch the Telnet application.
2. Enter the IP address of the RTM-3300.
3. Open a Telnet connection to the RTM-3300 and perform required management functions.


5.3. Terminal Control MODE

5.3.1. Terminal Control Mode Structure

The Terminal Control Mode is accessed by the operator using a hierarchical menu structure. This menu enables the RTM-3300 operator to perform monitoring, controlling, configuring and testing actions on the RTM-3300, using a local or a remote terminal.

Figure 5-1 shows the hierarchical structure and menu flow of the Terminal Control Mode. The letter next to each menu item indicates the key by which it is accessed.

Figure 5-1: Organization and Structure of the Terminal Control Mode.



5.3.2. Terminal Main Menu ([Power-Up])

a. Menu Purpose and Use

The Terminal main menu enables the RTM-3300 Operator to perform monitoring, controlling, configuring and testing actions on the RTM-3300, using a local or a remote Terminal.

b. Menu Structure

The Terminal main menu provides the following options (see Figure 5-2):

[F] - Input/Output status:

Displays the status and operational information for the RTM-3300 FIFOs; for details, see paragraph 5.4.

[S] - General status:

Displays a status report on the RTM-3300 main functions; for details, see paragraph 5.5.

[M] - Mux transport information:

Displays the transport data for the RTM-3300 inputs; for details, see paragraph 5.6.

[D] - For some more process status:

Displays the current status for the various processes of the RTM-3300; for details, see paragraph 5.7.

[I] - Miscellaneous menu:

Displays the RTM-3300 Miscellaneous Sub-Menu. This menu enables the user to access and perform a large group of miscellaneous operating functions on the RTM-3300; for details, see paragraph 5.8.

[C] - Configuration menu:

Displays the RTM-3300 Configuration Sub-Menu. This menu enables the user to define the RTM-3300 configuration; for details, see paragraph 5.9.

In addition, the Terminal main menu provides system level command functions, activated by the following options:

[X] - Exit and re-run mcmux:

Exits and reboots the RTM-3300.

[H] - Redisplay main menu

[ESC] Exit the program.

Exits to PC Dos environment. To run the terminal again, enter to c:\mcmux directory and run the file mcmux.exe.

Figure 5-2: Terminal Main Menu - Structure.

```

----- Main menu: -----
## 'f'      : Input/Output status.
## 's'      : General status.
## 'm'      : Mux transport information.
## 'd'      : For some more process status.
## 'i'      : miscellaneous menu.
## 'c'      : configuration menu.
## 'x'      : Exit and re-run mcmux.
##
## 'h'      : This help screen.
## Esc     : Exit.
-----

```

c. Menu Control

1. Menu Enter Path

The Terminal main menu is accessed by entering [h] at the > prompt.

NOTE:

The menu is displayed automatically after the RTM-3300 power-up and log-on.

Use the [h] command to redisplay the Terminal main menu.

2. Menu Item Select

Any item on the Terminal main menu is selected by entering the respective letter at the prompt following the menu.

Example:

Enter [i] at the prompt to display the Miscellaneous Sub-menu.

3. Menu Exit

To exit from the Mux Terminal:

[x] - Exits and reboots the RTM-3300.

[ESC] - Exit the program.
Exits to PC Dos environment. To run the terminal again, enter to c:\mcmux directory and run the file mcmux.exe.

5.4. Input/Output status Report ([F] key / Main Menu)

a. Report Purpose and Use

The Input/Output status report displays to the RTM-3300 operator the status and operational information of the ten Input FIFOs and one Output FIFO.

b. Report Structure

The Input/Output status report provides the following information on the system input and output FIFOs (see Figure 5-3):

- **"In":**
Displays the Input/Output designated number.
Options: "00" through "09" for the input and "188" or "204" for the output.
- **"Chnl":**
Displays the Input/Output logic name.
Options: "Channel_00" through "Channel_09" for the input and "Output" for the output.
- **"Administrative State":**
Displays the input administrative state.
Options: input enabled (ENA) or disabled (DIS).
- **"Operational State":**
Displays the input operational state.
Options: input on (ON) or off (OFF).
- **"Fifo %":**
Displays the use of the Mux FIFO
Data Range: 0-100% if the channel is Enabled, N/A if the channel is disabled.
- **"Rate":**
Displays the stream input/output rate.
The Output record shows the division of the output rate between Data and Padding in parenthesis next to the rate.

Figure 5-3: Input/Output status report - Structure.

- In -	Channel	-- Ad.State -	Op.State -	Fifo ---	Rate --
(00)	Channel_00	ENA	ON	0.05%	17.96
(01)	Channel_01	ENA	OFF	0.00%	0.00
(02)	Channel_02	ENA	OFF	0.00%	0.00
(03)	Channel_03	ENA	OFF	0.00%	0.00
(04)	Channel_04	ENA	OFF	0.00%	0.00
(05)	Channel_05	ENA	OFF	0.00%	0.00
(06)	Channel_06	ENA	OFF	0.00%	0.00
(07)	Channel_07	ENA	OFF	0.00%	0.00
(08)	Channel_08	ENA	OFF	0.00%	0.00
(09)	Channel_09	ENA	OFF	0.00%	0.00
(188)	Output	ENA	ON	0.01%	44.00 D(17.77) P(26.23)
--- DSP Date: 15-01-2002 17:30:46 -----					

c. Report Control**1. Report Enter Path**

The Input/Output status report is accessed from the Terminal main menu (see paragraph 5.3.2 above) by entering [f] at the > prompt.

2. Report Exit

The Input/Output status report returns automatically to the main menu. Use of the [h] command redisplay the Terminal main menu.

5.5. General status Report ([s] key / Main Menu)**a. Report Purpose and Use**

The General Status report displays a status report on the RTM-3300 main functions.

b. Report Structure

The General Status report provides the following information on the system main functions (see Figure 5-4):

- **Mcmux type :**
Displays the RTM-3300 type.
Example: MUX_TYPE_10.
- **Sw version:**
Displays the DSP version
Example: 99. 25 Hw-rev(45) (Jan 1 2003).
- **Output-rate:**
Displays the output stream rate
Range: An 9 digit number (10,000,000 – 150,000,000).

NOTE

Max output rate: aggregate throughput 120 Mbit/sec.

- **Out packet size:**
Displays the size of the output packet.
Range: 188/204.
- **PAT auto. table:**
Displays the status of the PAT auto. table.
Options: Table enabled (ENA) or disabled (DIS).
- **PMT auto. table:**
Displays the status of the PMT auto. table.
Options: Table enabled (ENA) or disabled (DIS).
- **TDT auto. table:**
Displays the status of the TDT auto. table.
Options: Table enabled (ENA) or disabled (DIS).
- **NIT auto. table:**
Displays the status of the NIT auto. table.
Options: Table enabled (ENA) or disabled (DIS).
- **SDT auto. table:**
Displays the status of the SDT auto. table.
Options: Table enabled (ENA) or disabled (DIS).
- **Output_chk:**
Displays the status of the Output_chk procedure.
Options: Procedure activated (ON) or disabled (OFF).

- **Log file report:**
Displays the status of the Log file report.
Options: Report activated (ON) or disabled (OFF).
- **NMS TCP CONTROL:**
Displays the setups of the NMS control interface.
Example: ENA. (ON) (udp_port:8113) (host:100.100.100.10).
- **CAE tcp control:**
Displays the setups of the CAE TCP control interface.
Example: ENA. (OFF.) Port (6003) *Host (100.100.100.110)
Backup (NONE).
- **Scramble status:**
Displays the setups of the Scramble function interface.
Example: ENA, 'SCOPUS', (CAS:OFF), (SCR:ON).
- **Telnet:**
Displays the status of the Telnet control program for the remote terminal.
Options: Telnet enabled (ENA) or disabled (DIS).
- **FTP server:**
Displays the status of the FTP server. The FTP server is running in the background and can be enabled or disabled.
Options: server enabled (ENA) or disabled (DIS).
- **WDT:**
Displays the status of the Watch Dog Timer.
Options: enabled (ENA) or disabled (DIS).
- **Table_s process:**
Displays the status of the Short Table process.
Options: Process activated (ON) or disabled (OFF).
- **Table_l process:**
Displays the status of the Long Table process.
Options: Process activated (ON) or disabled (OFF).

Figure 5-4: General Status Report - Structure.

```
----- General status: [10.8.0.250] -----  
PCI_device(19) -- ITR(10).  
Mcmux type :      MUX_TYPE_10 (10).  
Sw version      : 99.25 Hw-rev(45) (Jan 1 2003).  
Output-rate     : 44.000000  
Out packet size: 188.  
PAT auto. table: ENA.  
PMT auto. table: ENA.  
TDT auto. table: DIS.  
NIT auto. table: ENA  
SDT auto. table: ENA.  
Output_chk:     OFF.  
Log file report: OFF.  
NMS TCP CONTROL: DIS  
CAE tcp control: DIS.  
Scramble status: ENA, 'FIX_KEY', (SCR:ON ).  
Telnet:         ENA.  
Ftp server:     ENA  
WDT:           ENA  
Table_s process: OFF.  
Table_l process: ON .  
-----
```

c. Report Control**1. Report Enter Path**

The General Status Report is accessed from the Terminal main menu (see paragraph 5.4.3 above) by entering [s] at the > prompt.

2. Report Exit

The General Status report returns automatically to the system main menu. Use the **[h] command** to redisplay the Terminal main menu.

5.6. MUX Transport Information Report ([m] key / Main Menu)

a. Report Purpose and Use

The MUX Transport Information Report provides the RTM-3300 operator information about the data flow through the Mux's input channels, including the Remap of the PID and the Rename of the program (see Figure 5-5). The MUX Transport Information Report provides three display options to view the report (See the Report Control paragraph below). The examples below shows two of the three displays of the report.

Figure 5-5: MUX Transport Information Report - Structure.

Example of input information:

```
Input number 0:
I0: Serv. 1 (0x0001) - (remapped from 10703 (0x29CF)) 'Ultra Blue TV'
    Pid. 256 (0x0100) - (remapped from 203 (0x00CB)) PMT.
    Pid. 257 (0x0101) - (remapped from 223 (0x00DF)) PCR.
    Pid. 257 (0x0101) - (remapped from 223 (0x00DF)) VIDEO.
    Pid. 258 (0x0102) - (remapped from 243 (0x00F3)) AUDIO.

I0: Serv. 2 (0x0002) - (remapped from 10704 (0x29D0)) '102.5 HIT Ch'
    Pid. 272 (0x0110) - (remapped from 4217 (0x1079)) PMT.
    Pid. 273 (0x0111) - (remapped from 224 (0x00E0)) PCR.
    Pid. 273 (0x0111) - (remapped from 224 (0x00E0)) VIDEO.
    Pid. 274 (0x0112) - (remapped from 244 (0x00F4)) AUDIO.

I0: Serv. 3 (0x0003) - (remapped from 10705 (0x29D1)) 'TLC SAT'
    Pid. 288 (0x0120) - (remapped from 56 (0x0038)) PMT.
    Pid. 289 (0x0121) - (remapped from 225 (0x00E1)) PCR.
    Pid. 289 (0x0121) - (remapped from 225 (0x00E1)) VIDEO.
    Pid. 290 (0x0122) - (remapped from 245 (0x00F5)) AUDIO.

I0: Serv. 4 (0x0004) - (remapped from 10706 (0x29D2)) 'PRO-SAT'
    Pid. 304 (0x0130) - (remapped from 32 (0x0020)) PMT.
    Pid. 305 (0x0131) - (remapped from 3105 (0x0C21)) PCR.
    Pid. 306 (0x0132) - (remapped from 226 (0x00E2)) AUDIO.
    Pid. 307 (0x0133) - (remapped from 246 (0x00F6)) VIDEO.

I0: Serv. 5 (0x0005) - (remapped from 10702 (0x29CE)) 'MRTV'
    Pid. 320 (0x0140) - (remapped from 202 (0x00CA)) PMT.
    Pid. 321 (0x0141) - (remapped from 222 (0x00DE)) PCR.
    Pid. 321 (0x0141) - (remapped from 222 (0x00DE)) VIDEO.
    Pid. 322 (0x0142) - (remapped from 242 (0x00F2)) AUDIO.
```

Figure 5-6: Mux Transport Information Report - Structure.**Example of brief input information:**

```
All Inputs brief: -  
  
I0: Prg.01 (7401) : PMT:0x0100 (0x1D1F) ,           ''  
      0x0101 (P) , 0x0101 (V) , 0x0102 (A) ,
```

b. Report Structure

The Report provides the following information:

- Service number and remap service numbers.
- PID numbers and remap PID numbers.
- Service names.
- PID Type: Pcr, Video, Audio, Data, etc...

c. Report Control**1. Report Enter Path**

The Mux Transport Information Report is accessed by pressing [m] at the > prompt from the Main Menu. The mux transport status has three display options.

- [i] Option Choose one input to display its information [0-18].
- [m] Option Displays information about all the Input Channels.
- [n] Option Displays brief information about all the Input Channels.

2. Report Exit

The Mux Transport Information Report returns automatically to the system main menu.

Use the **[h] command** to redisplay the Terminal main menu.

5.7. For Some More Process Status Sub-Menu ([d] key / Main Menu)

a. Menu Purpose and Use

The 'For Some More Process Status' menu provides to the RTM-3300 operator indication on the Mux processes. It also provides a list of the current errors in the system.

b. Menu Structure

The 'For Some More Process Status' Sub-Menu provides the following options (see Figure 5-7).

- [0] - Displays the Hard/Soft status (for details see paragraph 5.7.1)
- [1] - Displays the table_s status (for details see paragraph 5.7.2)
- [2] - Displays the table_l status (for details see paragraph 5.7.3)
- [3] - Displays the Permissions status (for details see paragraph 5.7.4)
- [4] - Displays the ctrl_udp application status (for details see paragraph 5.7.5)
- [5] - Displays the simulcrypt status report (for details see paragraph 5.7.6)
- [6] - Displays the Errors status (for details see paragraph 5.7.7)
- [7] - Displays the TCP status (for details see paragraph 5.7.8)
- [9] - Displays the inp. Hard status (for details see paragraph 5.7.9)

Figure 5-7: For Some More Process Status Sub-Menu - Structure.

```
----- stat help screen -----
(0) Hard/Soft  status.
(1) table_s   status.
(2) table_l   status.
(3) permission status.
(4) ctrl_udp  status.
(5) Simulcrypt status.
(6) Errors    status.
(7) TCP       status.
(8) fixed key status.
(9) inp. hard status.
(ESC) Exit menu.
-----
```

c. Menu Control

1. Menu Enter Path

The 'For Some More Process Status' Sub-Menu is accessed by pressing [d] at the >prompt from the Terminal main menu.

2. Menu Item Select

Any item on the 'For Some More Process Status' Sub-Menu Menu is selected by entering the respective number at the prompt following the menu.

3. Menu Exit

The 'For Some More Process Status' Sub-Menu is closed by pressing the Escape at the >> prompt.

5.7.1. Hard/Soft ([0] key / Process Sub-Menu)

a. Report Purpose and Use

The Hard/Soft Report provides information on the RTM-3300 DSP Hardware, software and PCI Bus map.

b. Report Structure

Figure 5-8 shows an example of the Hard/Soft status report.

The EB_EXIST value confirms the existence of scrambling hardware in the mux.

Figure 5-8: General Status Report - Structure.

```

----- HARD STATUS -----
PC_BOARD ID          ROCKY C800EV
WD_TIMER             ENABLE
----- PCI-----
Boards found(1):
Board(0) device(19) ven_id(0x10E8) dev_id(0x4760) rev(0x00) (output.
[0]0xD400 (P) [1]0x D000 (P) [2]0xCC00 (P) [3]0Xc800 (P) [4]0xC400 (P) (I) 10 (0x0A)

----- DSP Hard status: -----
MUX_TYPE             MUX_10.
ALTERA VER           45 (0x2D) .
EB_EXIST             YES.
EB_ENA               ENA.
----- Soft General status: -----
PC DSP DATA FIFO    ENABLE.
INPUTS NUM LIMIT     10.
RTM_MODE             3300.
DSP_LOOP_MODE        1.
OUT_CLOCK_SOURCE     DDS.
OUT_CLOCK_DIV_8      YES
----- DSP EB_STATUS: -----
scr_base_addr       :   (0x00080000) .
scr_status          : 8:  0xFF Enabled
chip_ver_id         : 16: 0x0001
lost_sync_flg       : 1:  0x0
curr_sync_flg       : 1:  0x1
-----

```

c. Report Control

1. Report Enter Path

The PCI Report is accessed by pressing [0] at the > prompt from the 'For Some More Process Status' Sub-Menu.

2. Report Exit

The PCI Report is closed automatically after showing the report.

5.7.2. table_s Status Report ([1] key / Process Sub-Menu)

a. Report Purpose and Use

Table_s is used for planning short tables.

The table_s Status Report indicates if the transmitting stream will contain table_s a short table. The short table contains a list of short files to be transmitted.

b. Report Structure

Figure 5-9: mgcl - table_s Status Report - Structure.

```
-----  
mgcl - table_s status [15-01-2002 17:39:11]:  
table_head (short) = NULL.  
-----
```

c. Report Control

1. Report Enter Path

The table_s Status Report is accessed by pressing [1] at the prompt from the 'For Some More Process Status' Sub Menu.

2. Report Exit

The table_s Status Report is closed automatically after showing the report.

5.7.3. table_l Status Report ([2] key / Process Sub-Menu)

a. Report Purpose and Use

Table_l is used for planning long tables.

The table_l Status Report indicates if the transmitting stream will contain table_l a long table. The long table contains a list of long files to be transmitted.

b. Report Structure

Figure 5-10: mgcl - table_l Status Report - Structure.

```
-----  
mgcl - table_l status:  
File: c:\sw_219.ird 'TAB' (pid:0fff) (p_num:0) stage(1) 100m_clk(5729) .  
freq_t(2) tod_clock(572913) freq_t_next(572935) t_next-tod(22) .  
-----
```

c. Report Control

1. Report Enter Path

The table_l Status Report is accessed by pressing [2] at the prompt from the 'For Some More Process Status' Sub Menu.

2. Report Exit

The table_l Status Report is closed automatically after showing the report.

5.7.4. Permissions Report ([3] key / Process Sub-Menu)

a. Report Purpose and Use

The Permissions report provides information about the status of the permissions for various features of the RTM-3300

b. Report Structure

The Permission report provide information on the following:

- Port permission
- Scrambling (BISS) permission
- Simulcrypt permission

c. Report Control

1. Report Enter Path

The Permission Report is accessed by pressing [3] at the prompt from the 'For Some More Process Status' Sub Menu.

2. Report Exit

The Permission Report is closed automatically after showing the report.

5.7.5. ctrl_udp(n) Status Report ([4] key / Process Sub-Menu)

a. Report Purpose and Use

The ctrl_udp Report provides information to the RTM-3300 operator about the application that runs using the udp protocol.

b. Report Structure

The ctrl_udp report provides information on the udp-based application such as Nagra and their connection.

Figure 5-11: ctrl_udp(n) Status Report - Structure.

```

-----
ctrl_udp0 - status: ENA ON .
Udp con. nd(67) host(10.8.0.250) lport(4640) fport(0) Pid(0x0080) C_ctr(ENA) .
Rcv buff max size(1352) [35(head)+1316((7)Packets)+1] .
Rcv msg_rcv(0) msg_ok(0) msg_fail(0) pckts_ctr(0/0) rate(0.00k) .
-----

ctrl_udp1 - status: ENA ON .
Udp con. nd(68) host(10.8.0.250) lport(4641) fport(0) Pid(0x0000) C_ctr(DIS) .
Rcv buff max size(1317) [0(head)+1316((7)Packets)+1] .
Rcv msg_rcv(0) msg_ok(0) msg_fail(0) pckts_ctr(0/0) rate(0.00k) .
-----

```

c. Report Control

1. Report Enter Path

The ctrl_udp Status Report is accessed by pressing [4] at the prompt from the 'For Some More Process Status' Sub Menu.

2. Report Exit

The ctrl_udp Status Report is closed automatically after showing the report.

5.7.6. Simulcrypt Status Report ([5] key / Process Sub Menu)

a. Report Purpose and Use

The Simulcrypt status provides to the RTM-3300 operator information about simulcrypt parameters.

b. Report Structure

Figure 5-12 displays an example of a Simulcrypt Report.

Figure 5-12: Simulcrypt Report - Structure.

```
-----  
Simulcrypt Display MUX (EMM servers) data...  
-----  
TCP mux srv port:(8008).  
Udp mux srv: nd(65) host(10.8.0.250), lsocket(4640)  
-----  
10.8.0.242(4640:UDP) EMMG chnl client_id(0x06020000) chnl_id(0x0000) streams:  
(1) client_id(0x06020000) chnl_id(0x0001) stream_id(0x0001) data_id(0x0001).  
   EMMG(Chnl(0)) Pid(0x0080) CAT_Pid(0x0080) Cont_ctr(ENA) <TRANSPORT>.  
   Pckts_ctr(18) rate(0.79k).  
.  
-----  
Simulcrypt Display SCS (ECM clients):  
-----  
SCS Channels(1) (cp_time(10)Sec):  
  *** CAS(Chnl(0)): SCS(ENA) Host(10.8.0.242,4680) nd(67) <TRANSPORT>.  
    Cas_type: IRDETO    super_cas_id=(0x06020000) chnl_id=(0x0001)  
    erm_pid=(0x0000) erm_c_ctr=(ENA)  
-----  
  
--> more... :  
-->  
*** CP(6) SCS Streams(8):  
xxx Strm(0):'ENA' Ecm_id(0x0001) Pids(0x010F,) Progs (1)1..  
*** Strm(1):'ENA' Ecm_id(0x0002) Pids(0x011F,) Progs (1)2..  
*** Strm(2):'ENA' Ecm_id(0x0003) Pids(0x012F,) Progs (1)3..  
*** Strm(3):'ENA' Ecm_id(0x0004) Pids(0x013F,) Progs (1)4..  
*** Strm(4):'ENA' Ecm_id(0x0005) Pids(0x014F,) Progs (1)5..  
*** Strm(5):'ENA' Ecm_id(0x0006) Pids(0x015F,) Progs (1)6..  
*** Strm(6):'ENA' Ecm_id(0x0007) Pids(0x016F,) Progs (1)7..  
*** Strm(7):'ENA' Ecm_id(0x0008) Pids(0x017F,) Progs (1)8..  
-----  
10.8.0.242(4680:TCP) chnl (0x0001) streams: (0x0000), (0x0001), (0x0002),  
(0x0003), (0x0004), (0x0005), (0x0006), (0x0007).  
-----
```

The report contains the following sections:

- a. **Simulcrypt Display MUX (EMM servers) data**
contains EMM Generator MUX connection parameters. The CAS IP and Port are shown on “Udp mux srv”. The average EMM rate is displayed next to the ‘Rate’ parameter.
 - b. **Simulcrypt Display SCS (ECM clients)**
contains ECM Generator SCS parameters. A ‘****’ sign means that there is a connection to the ECM Generator. An ‘xxx’ sign means that the ECM Generator is not connected.
 - c. **Simulcrypt Stream parameters**
Displays the Simulcrypt streams parameters. Encrypted Simulcrypt streams are marked with ‘****’, all others Simulcrypt streams are marked with ‘xxx’.
 - d. **Simulcrypt Channels and Streams Summary**
Display a summary of the Simulcrypt channels and Simulcrypt streams.
- c. Report Control**
1. **Report Enter Path**
The Simulcrypt Report is accessed by pressing the [5] at the > prompt from the ‘For Some More Process Status’ Sub Menu menu.
 2. **Report Exit**
The Simulcrypt Report is closed automatically after showing the report.

5.7.7. Errors Report ([6] key / Process Sub-Menu)

a. Report Purpose and Use

The Error Report provides to the RTM-3300 operator information about the current errors of the Mux.

b. Report Structure

Figure 5-13 Displays the Error Report structure.

Table 5-1 describes the possible RTM-3300 errors:

Figure 5-13: Errors Report - Structure.

```

--- Errors list: -----
--- Relays port (0x020C) on list<NONE>.
    
```

Table 5-1: RTM-3800 Error List

ERROR NUM.	ERROR NAME	ERROR DESCRIPTION
1	C30_GENERAL_RUN_TIME_ERR	A general error
2	C30_MEM_ALLOC_RUN_TIME_ERR	Memory Allocation run time error
3	C30_OUTPUT_FIFO_OVERFLOW	Output FIFO memory overflow
4	C30_OUTPUT_FIFO_UNDERFLOW	Output FIFO memory underflow
5	C30_INPUT_FIFO_OVERFLOW	Input FIFO memory overflow
6	C30_INPUT_FIFO_UNDERFLOW	Input FIFO memory underflow
7	C30_INPUT_TOO_MANY_ERRORS	Input has too many errors
8	C30_INPUT_MPEG_DATA_ERR	Error in input MPEG data
9	C30_INPUT_LOST_SIGNAL	Lost the input signal
10	MUX_C30_SYSTEM_RESET	System reset
11	MUX_C30_INIT_FAIL	Initialization Failure
12	MUX_C30_MESSAGE_ERR	Message error
13	MUX_GLOBAL_RUN_TIME_ERR	Global run time error
14	MUX_INPUT_FILE_ERR	Error in the input file
15	MUX_INPUT_CFG_FILE_ERR	Error in input CFG file
16	MUX_INPUT_TAB_FILE_ERR	Error in input tab file
17	MUX_OUTPUT_FILE_ERR	Error in output file
18	MUX_RUN_TIME_AT_EXIT_E18	Run time error at exit
19	MUX_RUN_TIME_MALLOC_ERR	Run time error in memory allocation
20	MUX_RUN_TIME_SERIAL_E20	Run time error serial
21	MUX_RUN_TIME_TCP_ERR	Run time error in TCP

Table 5-1: RTM-3800 Error List

ERROR NUM.	ERROR NAME	ERROR DESCRIPTION
22	MUX_C30_NO_COMMUNICATION	No communication

c. Report Control

1. Report Enter Path

The Error Report is accessed by pressing the [6] at the > prompt from the 'For Some More Process Status' Sub Menu menu.

2. Report Exit

The Error Report is closed automatically after showing the report.

5.7.8. TCP Status Report ([7] key / Process Sub-Menu)

a. Report Purpose and Use

The TCP Status Report provides to the RTM-3300 operator information about the current status of the TCP protocol.

b. Report Structure

The TCP Report provides the following information (see Figure 5-14):

Figure 5-14: TCP Status Report - Structure.

```
----- TCP stat -----  
Fei (unit number 0)  
Flags: (0xb036) UP BROUDCAST MULTICAST ARP RUNNING  
Type: ETHERNET_CSMACD  
Internet address: 10.8.0.25  
Broadcast address: 10.255.255.255  
Netmask 0xff00000 Subnetmask 0xffffffff0  
Ethernet address is 00:08:9b:08:71:18  
Netric is 0  
Maximum Transfer Unit size is 1500  
0 octets received  
0 octets sent  
0 packets received  
1 packets sent  
0 unicast packets received  
1 unicast packets sent  
0 non-unicast packets received  
0 non unicast packets sent  
0 input discards  
0 input unknown protocols  
0 input errors  
0 output errors  
0 collision ; 0 dropped  
-----
```

c. Report Control

1. Report Enter Path

The TCP Status Report is accessed by pressing [7] at the prompt from the 'For Some More Process Status' Sub Menu.

2. Report Exit

The TCP status Report is closed automatically after showing the report.

5.7.9. Inp. Hard Status Report ([9] key / Process Sub-Menu)

a. Report Purpose and Use

Input Hardware Status report shows information about all the mux's inputs: their number, their administrative state (0 – for disabled / 1 - for enabled) remux state and the mux's scan order of the inputs.

b. Report Structure

Figure 5-15 shows the Input hardware status report structure.

Figure 5-15: Inp. Hard Status Report - Structure.

```

----- DSP HRD STAT -----
TYPE:      OLD
OUT_LINE:  2
INP:       0 1 2 3 4 5 6 7 8 9
HRD_ENA:   1 1 1 1 1 1 1 1 1 1
REMUX:     0 0 0 0 0 0 0 0 0 0
#
PADD_ENA:  0 0 0 0 0 0 0 0 0 0
LOW_RATE:  0 0 0 0 0 0 0 0 0 0
#
Scan(10)  0 1 2 3 4 5 6 7 8 9
-----

```

Every column represents an input number:

- The INP row displays the input numbers.
- The HRD_ENA displays for each input: '0' for disabled and '1' for enabled.
- The REMUX row displays the remux state for each input.
- The Scan displays the scan order of the inputs.

c. Report Control

1. Report Enter Path

The Inp. Hard Status Report is accessed by pressing [9] at the prompt from the 'For Some More Process Status' Sub Menu.

2. Report Exit

The Inp. Hard Status Report is closed automatically after showing the report.

5.8. Miscellaneous Sub-Menu ([i] key / Main Menu)

a. Menu Purpose and Use

The Miscellaneous Sub-Menu provides Miscellaneous functions screen. These functions are used for debugging the Mux's operational procedures.

b. Menu Structure

The Miscellaneous Sub Menu provides the following options (see Figure 5-16):

[2] - A DSP Reset command, for details see paragraph 5.8.1.

[3] - A DSP output FIFO reset command, for details see paragraph 5.8.2.

[5] - A DSP input options, for details see paragraph 5.8.3.

[6] - A DSP inputs switch command, for details see paragraph 5.8.4.

[7] - A PC-DSP message FIFO Reset command, for details see paragraph 5.8.5.

[a] - A output check Enable command, for details see paragraph 5.8.6.

[b] - A record input transport command, for details see paragraph 5.8.7.

[d] - A record self-made out tab file command, for details see paragraph 5.8.8.

[s] - A simulcrypt status report, for details see paragraph 5.7.6.

Figure 5-16: Miscellaneous Sub-Menu - Structure.

```
----- miscellaneous help -----
(1) N/A.
(2) For DSP Reset (hot-boot) .
(3) For DSP output fifo reset.
(4) N/A.
(5) For DSP input [reset,ena/dis].
(6) For DSP inputs switch.
(7) For pc-Dsp message fifo reset.
(a) For output chk ENA.
(b) For record input transport.
(c) For record message fifo transport.
(d) For record self made out tab file.
(s) For Simulcrypt Status.
(ESC) Exit menu.
-----
```

c. Menu Control

1. Menu Enter Path

The Misc. Menu is accessed by pressing [i] at the >prompt from the Terminal main menu.

2. Menu Item Select

Any item on the Miscellaneous Sub Menu Menu is selected by entering the respective number at the prompt following the menu.

3. Menu Exit

The Misc. Sub Menu is closed by pressing Esc at the >> prompt.

5.8.1. DSP Reset (Hot Boot) Function ([2] key / Misc. Sub-Menu)

a. Function Purpose and Use

The DSP Reset Function provides to the RTM-3300 operator the ability to reset the DSP (hot-boot).

b. Function Run Procedure

The DSP Reset Function is accessed by pressing [2] at the >> prompt from the Misc. Sub-Menu.

5.8.2. DSP Output FIFO Reset Function ([3] key / Misc. Sub-Menu)

a. Function Purpose and Use

The DSP Output FIFO Reset Function provides to the RTM-3300 operator the ability to Reset the DSP output FIFO.

b. Function Run Procedure

The DSP Output FIFO Reset Function is accessed by pressing the [3] at the >> prompt from the Misc. Sub Menu.

5.8.3. DSP Input Control Function ([5] key / Misc. Sub-Menu)

a. Function Purpose and Use

The DSP Input Control Function provides to the RTM-3300 operator the ability to Reset, Enable/Disable each DSP Input.

b. Function Run Procedure

1. The DSP Input Control Function is accessed by pressing the [5] at the >> prompt from the Misc. Sub Menu.
2. Write the input number and one of the following on the same line:
"Reset" – resets the input
"0" – disable the input
"1" – enable the input.

Example:

```
3 Reset - Will reset input 3
5 0     - Will disable input 5
0 1     - Will enable input 0
```

5.8.4. DSP Inputs Switch Function ([6] key / Misc. Sub-Menu)

a. Function Purpose and Use

The DSP Inputs Switch Function provides to the RTM-3300 operator the ability to Switch DSP Inputs.

b. Function Run Procedure

1. The DSP Input Switch Function is accessed by pressing the [6] at the >> prompt from the Misc. Sub Menu.
2. Switch between two DSP Inputs. The two inputs should be written in the same line with space between them.

5.8.5. PC-DSP Message FIFO Reset Function ([7] key / Misc. Sub-Menu)

a. Function Purpose and Use

The PC-DSP Message FIFO Reset Function provides to the RTM-3300 operator to reset the PC-Message FIFO.

b. Function Run Procedure

The PC-DSP Message FIFO Reset Function is accessed by pressing the [7] at the >> prompt from the Misc. Sub Menu.

5.8.6. Output Check Enabled/Disabled Function ([a] key / Misc. Sub-Menu)

a. Function Purpose and Use

The Output Check Function provides to the RTM-3300 operator the ability to Enable the Output check.

b. Function Run Procedure

The Output Check Disabled Function is accessed by pressing the [a] at the >> prompt from the Misc. Sub Menu.

5.8.7. Record Input Transport Report ([b] key / Misc. Sub-Menu)

a. Report Purpose and Use

The Record Input Transport Report provides to the RTM-3300 operator the ability to record the input transport to a file on the Mux device.

b. Report Structure

The Record Input Transport Report provides the following information (see Figure 5-17):

Figure 5-17: Record Input Transport Report - Structure.

```
Rcv transp rec start   in: 0  PID: 0x0  'file.tab'
```

- In – Input channel.
- PID – PID number.
- 'file' – The file to record the report to.

c. Report Control

1. Report Enter Path

The report is accessed by pressing [b] at the >>prompt from the Misc. menu, and selecting an input channel.

2. Report Exit

The Record Input Report is automatically closed after the report is shown.

5.8.8. Record Self-Made Out Table Update Function ([d] key / Misc. Sub-Menu)

a. Function Purpose and Use

The Record Self-Made Out Table Update Function provides to the RTM-3300 operator the ability for record self made out table file.

b. Function Run Procedure

1. The Record Self Made Out Table Update Function is accessed by pressing [d] at the >prompt from the Misc sub menu.
2. Select a table: (1)PAT, (2)PMT, (3)CAT, (4)NIT, (5)SDT, (6)TDT, (7)TOT, (8)EIT.

5.9. Configuration Sub-Menu ([c] key / Main Menu)

- a. **Menu Purpose and Use**
The Configuration Sub-Menu provide to the RTM-3300 operator access to the configurable parameters of the RTM-3300.
- b. **Menu Structure**
The Configuration Sub-Menu provides the following options (see Figure 5-18):
 - [r] Displays information on the Mux input channels (see paragraph 5.9.1).
 - [m] Displays the miscellaneous Configurations Menu (see paragraph 5.9.2).
 - [t] Displays the Table Configuration Menu (see paragraph 5.9.2.8).
 - [l] Loading new Mux version (see paragraph 5.9.4).
 - [s] Saves the current configurations in a file (see paragraph 5.9.5).
 - [u] Loads a configuration from file (see paragraph 5.9.6).

Figure 5-18: Configuration Sub-Menu - Structure.

```

----- config menu -----
'r' : remux input utility.
'm' : miscellaneous configuration menu.
't' : Automaic Tables configuration menu.
'l' : Start loading process of new mcmux ver.
's' : save config.
'u' : load saved config.
'c' : fixed key configuration.

'h' : This help screen.
Esc : Exit.
-----
```

- c. **Menu Control**
 1. **Menu Enter Path**
The Configuration Sub-Menu is accessed by entering [c] at the > prompt from the Terminal main menu.
 2. **Menu Item Select**
Any item on the Configuration Sub-Menu is selected by entering the respective letter at the prompt following the menu.
Example:
Enter [m] at the prompt to display the Miscellaneous Configuration Sub-menu.
 3. **Menu Exit**
 - [h] Redisplays the Configuration Sub-Menu.
 - [ESC] Exits the Configuration Menu.

5.9.1. Remux Input Utility ([r] key / Configuration Sub-Menu)

a. Procedure Purpose and Use

The Remux Input Utl. Determine which input channels are routed to the mux output stream and which are dropped. Paragraph 3.2 explains the remux process in more detail.

b. Procedure Run

The Remux Input Utl. is accessed by pressing [r] at the >> prompt.

Set the input remux :

- Select an Input number.
- Enable / Disable a channel on the current Input number.
- Press [u] to update the changes done in the Remux Input Utl.

5.9.2. Miscellaneous Configuration Functions Menu ([m] key / Configuration Sub-Menu)

a. Menu Purpose and Use

The Miscellaneous Configuration Functions Sub-Menu provides access to the RTM-3300 configurable operating parameters. Any parameter shown on the Terminal screen can be changed and set.

b. Menu Structure

The Miscellaneous Configuration Sub-Menu provides the following option (see Figure 5-19):

- [1] - Sets the output packet size (for details, see para. 5.9.2.1).
- [2] - Sets the output rate (for details, see para. 5.9.2.2).
- [3] - Changes the IP Address (for details, see para. 5.9.2.3).
- [4] - Sets the Scrambling Control (for details, see para. 5.9.2.4).
- [5] - Determine the Scrambling type (for details, see para. 5.9.2.5).
- [6] - Enable/Disable the PCR discontinuity declaration (DCL) (for details, see para. 0).
- [7] - Enable/Disable the Telnet (for details, see para 5.9.2.7).
- [8] - Enable/Disable the Ftp server (for details, see para 5.9.2.8).
- [S] - Displays the Mux General status.

Figure 5-19: Miscellaneous Configuration Functions Menu - Structure.

```

----- config miscellaneous help -----
(1) : output packet size (188). toggle
(2) : Change output rate [44000000].
(3) : Change IP addr [10.8.0.250].
(4) : Scrambling control [ENABLE ], toggle.
(5) : Scrambling Type [FIX_KEY].
(6) : Pcr discontinuity Declaration [ENABLE ], toggle.
(7) : Telnet [ENABLE ], toggle.
(8) : Ftp server [ENABLE], toggle.
's' : For general status.
'h' : This help screen.
(ESC) Exit menu.
-----

```

c. Menu Control

1. Menu Enter Path

The Miscellaneous Configuration Menu is accessed by pressing [m] at the > prompt, from the Terminal main menu.

2. Menu Item Select

Any item on the Miscellaneous Configuration menu is selected by entering the respective letter at the prompt following the menu.

Example:

Enter [1] at the prompt to set the Output Packet Size.

3. Menu Exit

[h] Redisplays the Miscellaneous Configuration Menu.

[ESC] Exits the Miscellaneous Configuration Menu.

5.9.2.1. Select Output Packet Size Function ([1] key / Misc. Config. Sub-Menu)

a. Function Purpose and Use

Select Output Packet Size, 188 or 204. The default packet size is 188 (204 is usually used when FEC is applied for G.703 front end inputs).

b. Function Run

The Select Output Packet Size Function is accessed by pressing [1] at the prompt from the Misc. Config. Menu:

The user is asked to confirm the toggling of the packet size between 188 and 204.

Example:

If the packet size is 188, the Terminal asks the user to confirm the change for packet size of 204.

5.9.2.2. Change Output Rate Function ([2] key / Misc. Config. Sub-Menu)

a. Function Purpose and Use

Enables adjustments of the Output Rate of the Mux. The output rate must be set to a higher value than the aggregate rate of the selected input programs, otherwise, an overflow will occur. Setting a higher output rate will cause the system to receive empty table, which represents no data.

b. Function Run

The Change Configuration OutRate function is accessed by pressing [2] at the prompt from the Misc. Config. Menu:

- Enter out rate - Enter an Output Rate according to the format above. The Output Rate format is XXXXXXXXXX (bps). Default rate is 38152941Bps. Valid values: 10,000,000 – 150,000,000
- Option [d] -Sets the Output Rate to the default.

5.9.2.3. Change IP Address Function ([3] key / Misc. Config. Sub-Menu)

a. Function Purpose and Use

Enables the IP address if a system interface to be defined, that way the RTM-3300 can be connected to network.

b. Function Run

The Change IP Address function is accessed by pressing [3] at the prompt from the Misc. Config Menu. Enter an IP address (format xxx.xxx.xxx.xxx).

To define a default gateway:

1. Exit to VxWorks and edit the file C:\PCTCP.INI on the mux computer:
2. Change the line "router = 0.0.0.0" under the topic [pctcp ifcust 0] to the default gateway IP address.

5.9.2.4. Enable/Disable Scrambling Control Function ([4] key / Misc. Config. Sub-Menu)

a. Function Purpose and Use

The Scrambling function determine whether the output data of the RTM-3300 will be Scrambled or not. Refer to paragraph 5.7.1 for checking the presence of a scrambler board.

b. Function Run

The Enable/Disable Scrambling Control function is accessed by pressing [4] at the prompt from the Misc. Config. Menu:

The Scrambling Control is accessed by pressing [4] at the prompt from the Misc Config Menu. The Scrambling Control function is toggled between Enable/Disable.

5.9.2.5. Select Scrambling Type Function ([5] key / Misc. Config. Sub-Menu)

a. Function Purpose and Use

The Scrambling Type function determine the type of scrambling.

b. Function Run

The Scrambling Type is accessed by pressing [5] at the prompt from the Misc Config. Menu.

To select any item from the Scrambling Type list press the respective number at the prompt following the menu.

Available options:

- 0) Scopus
- 1) Mixed
- 2) Scopus_dvb
- 3) Simukrypt
- 4) Fix_key

5.9.2.6. PCR discontinuity Declaration Function ([6] key / Misc. Config. Sub-Menu)

a. Function Purpose and Use

The PCR Discontinuity Declaration function enables the MUX to raise the discontinuity indicator when it detects an erroneous PCR packet.

b. Function Run

The PCR discontinuity Declaration Function is accessed by pressing the [6] at the prompt, from the Misc. Config. Menu.

5.9.2.7. Toggle TelNet Status Function ([7] key / Misc. Config. Sub-Menu)

a. Function Purpose and Use

Enable or Disable the Telnet control program for the remote Terminal.

b. Function Run

The TelNet Status function is accessed by pressing the [7] at the prompt, from the Misc. Config. Menu. Refer to paragraph 3.5.1 for software upgrade instruction.

5.9.2.8. Toggle Ftp server Status Function ([8] key / Misc. Config. Sub-Menu)

a. Function Purpose and Use

Enable or Disable the FTP server. The FTP server works in the background.

b. Function Run

The FTP Server function is accessed by pressing the [8] at the prompt, from the Misc. Config. Menu. Refer to paragraph 3.5.2 for software upgrade instruction.

5.9.3. Automatic Tables Configuration Setup Menu ([t] key / Configuration Sub-Menu)

a. Menu Purpose and Use

The Automatic Tables Configuration Menu provides to the RTM-3300 operator the ability to determine which data table will be sent out from the Mux and those who will not be sent out from the Mux.

b. Menu Structure

The Automatic Tables Configuration provides the following options (see Figure 5-20):

- [1] - Enable/Disable the PAT table. (See paragraph 5.9.3.1).
- [2] - Enable/Disable the PMT table. (See paragraph 5.9.3.2).
- [3] - Enable/Disable the NIT table. (See paragraph 5.9.3.3).
- [4] - Enable/Disable the SDT table. (See paragraph 5.9.3.4).
- [5] - Enable/Disable the TDT table. (See paragraph 5.9.3.5).
- [9] - Remap the PID. (See paragraph 5.9.3.6).
- [a] - Remap the Program's number. (See paragraph 5.9.3.7).
- [b] - Rename the stream id. (See paragraph 5.9.3.8).
- [c] - Rename the network id. (See paragraph 5.9.3.9).
- [d] - Rename original network. (See paragraph 5.9.3.10).
- [e] - Rename NIT Network. (See paragraph 5.9.3.11).
- [f] - Selects the NIT Service. (See paragraph 5.9.3.12).
- [g] - Rename the SDT Provider. (See paragraph 5.9.3.13).
- [i] - Selects the SDT Program Service. (See paragraph 5.9.3.14).
- [m] - Displays the Mux transport information. (See paragraph 5.9.3.15).

Figure 5-20: Automatic Tables Configuration Setup Menu - Structure.

```

----- Auto. tables config. help -----
(1) : Auto. PAT ena/dis [ENABLE ], toggle.
(2) : Auto. PMT ena/dis [ENABLE ], toggle.
(3) : Auto. NIT ena/dis [ENABLE ], toggle.
(4) : Auto. SDT ena/dis [DISABLE], toggle.
(5) : Auto. TDT ena/dis [DISABLE], toggle.

(9) : Remap PID.
(a) : Remap PROG NUM.
(b) : (PAT,NIT,SDT,EIT...) stream_id [1(0x0001)].
(c) : (NIT,SDT,EIT...) Network_id (ETR 162 ,6): [4369(0x1111)].
(d) : (NIT,SDT,EIT...) Org_Network_id (ETR 162 ,6): [4369(0x1111)].
(e) : NIT Network name [SCOPUS NET].
(f) : NIT Service list descriptor ena/dis [DISABLE], toggle.
(g) : SDT Provider name [SCOPUS PROVIDER].
(i) : SDT Prog. Service name.

(m) : Mmux transport information.
'h' : This help screen.
(ESC) Exit menu.
-----

```

c. Menu Control

1. Menu Enter Path

The Automatic Tables Configuration Menu is accessed by pressing the [t] at the >> prompt from the config. menu.

2. Menu Item Select

Any table on the Automatic Tables list can be Enabled or Disabled by pressing the number next to the table's name, then the user will have to confirm or decline his change.

3. Menu Exit

[h] Redisplays the Miscellaneous Configuration Menu.

[ESC] Exits the Miscellaneous Configuration Menu.

5.9.3.1. Auto. PAT ena/dis Function ([1] key / Auto-Tables. Config. Sub-Menu)

a. Function Purpose and Use

the "Auto. PAT ena/dis" function determines whether the table will be sent along with the transport stream.

b. Function Run

the "Auto. PMT ena/dis" function is accessed by (and it's status is toggled) pressing [1] at prompt from the Auto. Table Configuration Menu. Confirm the toggle by selecting [y] or press [n] to reject changes.

5.9.3.2. Toggle Auto PMT Function ([2] key / Auto-Tables. Config. Sub-Menu)

a. Function Purpose and Use

the "Toggle Auto. PMT" function determines whether the table will be sent along with the transport stream.

b. Function Run

The "Toggle Auto PMT" function is accessed by pressing [2] at prompt from the Auto. Table Configuration Menu. Confirm the toggle by selecting [y] or press [n] to reject changes.

5.9.3.3. Toggle Auto NIT Function ([3] key / Auto-Tables. Config. Sub-Menu)

a. Function Purpose and Use

The "Toggle Auto. NIT" function determine whether the table will be sent along with the transport stream.

b. Function Run

The 'Toggle Auto NIT' function is accessed by pressing [3] at prompt from the Auto. Table Configuration Menu. Confirm the toggle by selecting [y] or press [n] to reject changes.

5.9.3.4. Auto. SDT ena/dis Function ([4] key / Auto-Tables. Config. Sub-Menu)

a. Function Purpose and Use

The 'Auto. SDT ena/dis' function determines whether the table will be sent along with the transport stream.

b. Function Run

The 'Auto. SDT ena/dis' function is accessed by pressing [4] at prompt from the Auto. Table Configuration Menu. Confirm the toggle by selecting [y] or press [n] to reject changes.

5.9.3.5. Auto. TDT ena/dis Function ([5] key / Auto-Tables. Config. Sub-Menu)

a. Function Purpose and Use

The 'Auto. TDT ena/dis' function determines whether the table will be sent along with the transport stream. Auto. Table Configuration Menu. To toggle between the options the operator selects [y] for changing the current option or [n] for leaving it as it is.

b. Function Run

The 'Auto. TDT ena/dis' function is accessed by pressing [5] at prompt from the Auto. Table Configuration Menu. Confirm the toggle by selecting [y] or press [n] to reject changes.

5.9.3.6. Remap PID Function ([9] key / Auto-Tables. Config. Sub-Menu)

a. Function Purpose and Use

The Remap PID function provides to the RTM-3300 operator the ability to determine the Mux mapping of the PID instead of an automatically mapping by the Mux.

b. Function Run

1. The Remap PID is accessed by pressing [9] at the prompt from the Auto Tables Config. functions.
2. Enter input number and IN PID, OUT PID. The IN PID from the input number entered will remap to OUT PID on the output stream.

5.9.3.7. Rename PROG NUM Function ([a] key / Auto-Tables. Config. Sub-Menu)

a. Function Purpose and Use

The Rename Prog Num function provides to the RTM-3300 operator the ability to determine the Mux Program renaming instead of an automatically mapping by the Mux.

b. Function Run

1. The Rename PROG NUM is accessed by pressing [a] at the prompt from the Auto Table Config menu.
2. Enter input number and IN program number, OUT program number.

CAUTION

*It's the user responsibility to keep the Prog. No. and PID's unique when setting them manually.
Should a duplicate Prog. No or PID exists, the receiver won't be able to decode the transmission correctly.*

5.9.3.8. Set-Up stream_id Function ([b] key / Auto-Tables. Config. Sub-Menu)

a. Function Purpose and Use

The Setup stream_id function provides to the RTM-3300 operator to Set up the transferred stream id.

b. Function Run

1. The Set-up stream_id is accessed by pressing [b] at the prompt from the Auto Table Config Menu.
2. Enter a new stream id.

5.9.3.9. Set-Up network_id Function ([c] key / Auto-Tables. Config. Sub-Menu)

a. Function Purpose and Use

The Setup network_id function provides to the RTM-3300 operator to Setup the network id.

b. Function Run

1. The Set-up network_id is accessed by pressing [c] at the prompt from the Auto Table Config Menu.
2. Enter a new network id.

5.9.3.10. Setup Org_Network_id Function ([d] key /Auto Tables Config. Sub-Menu)

a. Function Purpose and Use

The Set-Up Org_Network_id function provides the RTM-3300 operator to the ability to Rename the original network ID.

b. Function Run

1. The Rename Original Network function is accessed by pressing [d] at the prompt from the Auto Tables Config. menu.
2. Enter a new original network id.

5.9.3.11. NIT Network name Function ([e] key / Auto-Tables. Config. Sub-Menu)

a. Function Purpose and Use

The 'NIT Network name' function provides the RTM-3300 operator the ability to Rename the NIT network.

b. Function Run

1. The rename NIT network is accessed by pressing [e] at the prompt from the Auto Table Config Menu.
2. Enter network name.

5.9.3.12. NIT Service list descriptor ena/dis Function ([f] key / Auto-Tables. Config. Sub-Menu)

a. Function Purpose and Use

The 'NIT Service list descriptor ena/dis' provides the RTM-3300 operator the ability to toggle the NIT Network Service from the Services List.

b. Function Run

1. The 'NIT Service list descriptor ena/dis' is accessed by pressing [f] at the prompt from the Auto Table Config Menu.
2. Update NIT service list [y/n].

5.9.3.13. SDT Provider Name Function ([g] key / Auto-Tables. Config. Sub-Menu)

a. Function Purpose and Use

The 'SDT Provider Name' function provides the RTM-3300 operator the ability to Rename the SDT provider.

b. Function Run

1. The 'SDT Provider Name' is accessed by pressing [g] at the prompt from the Auto Table Config Menu.
2. Enter a new provider name.

5.9.3.14. SDT Prg. Service Name Function ([i] key/Auto-Tables Config. Sub-Menu)

a. Function Purpose and Use

the 'SDT Prog. Service Name' function provides the RTM-3300 operator the ability to select an SDT program service.

b. Function Run

1. The 'SDT Prog. Service Name' is accessed by pressing [i] at the prompt from the AutoTable Config Menu.
2. Selects the SDT program service and confirm it with [y].

5.9.3.15. MCMUX Transport Info. Report ([m] key /Auto-Tables Config. Sub-Menu)

a. Report Purpose and Use

The Transport Status Report provides the RTM-3300 operator information about the data flow through the Mux's input channels, including the Remap of the PID and the Rename of the program.

b. Report Structure

The Report provides the following information (see Figure 5-5):

- Service number and remap service numbers.
- PIDs and remap PID numbers.
- Service names.
- Input's programs element Pcr, Video, Audio, Data, etc...

Figure 5-21: MUX Transport Status Report - Structure.

```

Input number 0:
I0: Prog. number 1 - (remapped from 7401) ''
Pid 256 (0x0100) remapped from 7455 (0x1D1F) PMT.
Pid 257 (0x0101) remapped from 7456 (0x1D20) PCR.
Pid 257 (0x0101) remapped from 7456 (0x1D20) VIDEO.
Pid 258 (0x0102) remapped from 7457 (0x1D21) AUDIO.

1.1.1.1. Example of a brief information:
All Inputs brief: -

I0: Prg.01 (7401) : PMT:0x0100 (0x1D1F) ,           ''
                0x0101 (P) , 0x0101 (V) , 0x0102 (A) ,
    
```

c. Report Control

1. Report Enter Path

The Transport Status is accessed by pressing [m] at the > prompt from the Main Menu. The mux transport status has three display options:

- [i] Option Choose one input to display its information [0-18].
- [m] Option Displays information about all the Input Channels.
- [n] Option Displays brief information about all the Input Channels.

2. Report Exit

The Transport Status is closed by pressing Escape at the >prompt.

5.9.4. New MCMUX Version Loading Procedure ([I] key / Configuration Sub-Menu)

- a. Procedure Purpose and Use**
Load a new software version through RS-232 connector.
- b. Procedure Run**
Refer to paragraph 3.5.1 for software upgrade instructions.

5.9.5. Saves the current configurations in a file ([s] key / Configuration Sub-Menu)

- a. Procedure Purpose and Use**
Saves current configurations in a file. Only changes that have been made to the original configuration are saved to the file.
- b. Procedure Run**
 1. The configuration file saving procedure is operated by pressing [s] at the prompt from the configuration sub menu.
 2. Write a name to save to configuration.
 3. MCMUX is creating a directory according to the name and stores in it all configurations files.

5.9.6. Loads a configuration from file ([u] key / Configuration Sub-Menu)

- a. Procedure Purpose and Use**
Loads a stored configuration from files.
- b. Procedure Run**
 1. The configuration file loading procedure is operated by pressing [u] at the prompt from the configuration sub menu.
 2. Enter the name of the stored configuration.

5.10. Exit and Re-run MCMUX ([x] / Main Menu)

- a. Procedure Purpose and Use**
The Re run McMux function exits the McMux program and rerun it, after booting the Mux.
- b. Procedure Run**
The Rerun McMux is operated by pressing [x] at the >prompt from the main menu.

6. CONFIGURATION FILE MANAGEMENT

6.1. General

The configuration of the system can be managed by editing the system configuration files. Editing the configuration files can be done by using the Edit Mode. To access the Edit Mode, press esc from the terminal main menu. The configuration files may also be uploaded/downloaded through FTP protocol.

CAUTION

While exiting to the Edit Mode, the RTM-3300 stops its operation.

Paragraph 6.2 explains How to use the Edit Mode. Refer to paragraphs 5.9.5 and 5.9.6 for information about saving and loading the configurations files.

CAUTION

Make a copy of the configuration files before editing them with the text editor, in order to restore the original configuration files in case of an error.

The ASCII files described are located in C:\MCMUX directory:

- MCMUX.CFG - General configuration file, see paragraph 6.3.
- MCMUX.RMP - Remmapping and DSP related parameters, see paragraph 6.4.
- SIMUL.INI - Simulcrypt configuration file.

The general command format in the configuration files is as follows:

```
Keyword (parameter name) value  
#Remark line  
Keyword "value with spaces, tabs or commas"  
#Remark line  
EndofData
```

The format rules are (refer to the general command format):

- Parameters for which the default values are retained need not be entered by the user. The system automatically reads the default values.
- Each line must begin with a keyword, which is usually the name of the parameter. The keywords are case sensitive.
- The keyword is followed by a parameter value. For more than one value in a line, the values must be separated by spaces, tabs or commas.
- Remarks can be entered after entering parameters and values. Each remark line must begin with the symbol #.
- Single words can be written directly; entries with more than one word or with spaces, tabs and commas, must be enclosed in quotation marks.
- The last line in the configuration file must read EndofData.

6.2. Editing the configuration files

The configuration files are edited by a special command line editor.

To edit a file, type “Edit [filename]”. If the file does not exist, the editor asks to create a new file.

To edit a line, simply write the line number at the prompt and press Enter.

Edit the line and press Enter again to apply the changes.

The following paragraphs describe the rest of the editor commands.

NOTE

It is acceptable to write only the first letter of the command instead of the whole word in most of the commands.

6.2.1. Disp Command

The Disp Command displays a section of the text.

Examples:

D – Displays 10 lines from the current line position.

D 23 - Displays 10 lines from line number 23.

D 7 4 - Displays 4 lines from line number 7.

6.2.2. Next Command

The ‘**Next x**’ command Advances the current line x lines and displays x lines from the text.

Example:

N 15 – If current line is 1, the command advances 15 lines and display the next 15 lines (line 16 to 30).

To view lines 31-45 press n (without 15) again.

6.2.3. Priv Command

The ‘**Priv x**’ command decrease the current line x times back and displays the next x lines.

Example:

P 15 – If the current line is 31, the command decrease the current line to 16 and display the next 15 lines (lines 16-30).

6.2.4. Find Command

The **Find** command Finds a string in the text, position the current line there and displays the text.

Example:

F mux – Find the first occurrence of the word mux starting from the current line. To search the next occurrence, just type F (without mux).

6.2.5. Replace Command

The **Replace** command replaces a text in a specific line with another text.

Example:

When typing: 'R 3' – line three appears and the editor asks the two words to be replaced as shown below:

R 3

Line (3): 'real time multiplexer'

String to replace ? >> Time

Replace 'Time' with >> TIME

Line updated ---

[0003] real TIME multiplexer.

6.2.6. Add Command

The Add Command adds an empty line.

Example:

A 5 – Add an empty line in line 5. The original line 5 becomes line 6 and so on.

6.2.7. Copy Command

The 'copy x y' Command copies line number x, and adds it in position y.

Example:

C 25 – Add line 5 and copy line 2 to line 5.

6.2.8. Del Command

The del Command deletes a line from the text.

Example:

Del 6 – Deletes line 6. Notice that the whole word, 'del', should be written.

6.3. MCMUX.CFG File Parameters

6.3.1. MCMUX CFG File Parameters

The MCMUX.CFG file parameters are summarized in Table 6-1. The format column refers to the following input format:

- **s_string**.
- **n_numerical**.
- **IP_IP** address format.
- **status_fixed** options.

Table 6-1: MCMUX.CFG File Parameters

PARAMETER	FORMAT	DESCRIPTION	RANGE OF VALUES
lftype	n	Defines the control interface. The value (N) is relevant only when COMM is selected.	n = type can be NONE, TCP
UDPort	n	NMS port number for broadcast initialization.	n = udp host port num. Default = 8113
ReTransTime	n	Retransmission time of boot initialization message.	n = Re-transmit period of Boot (init) udp request (in seconds), default 15
lftcpConTO	n	Time out while waiting for the TCP connection.	n = Time out while waiting for the tcp connection.(in seconds), default 10.
lfmsgResponseTO	n	Time out while waiting for message response.	n = Time out while waiting for message response. (In seconds, default 5).
AliveTimer	n	Frequency at which the Active Timer checks the last TCP received from the NMS.	n = Alive timer checks last tcp receive from NMS. (In seconds), default 30.
UdpAliveDelta	n	Frequency for sending alive message to NMS .	n = time for sending UDP Alive message to NMS. (in mili seconds). Default: 0 = no send.
OutRate	n	Defines the output transmission rate.	n = out bit rate Default: 38152941
TdtTable	Status	Enable / Disable automatic TDT Table	Status =Enable / Disable Default: Disable
TotTable	Status	Enable / Disable automatic TOT Table.	Status =Enable / Disable Default: Disable
OutPacet204	Status	Defines the number of bytes in each output packet.	Status =Enable / Disable Default: Disable (188 bytes)

Table 6-1: MCMUX.CFG File Parameters

PARAMETER	FORMAT	DESCRIPTION	RANGE OF VALUES
PcrRestamping	Status	Enables / Disables renumbering of the timing tags.	Status =Enable / Disable Default: enable
ContCtrCheck	Status	Enables or disables validity checks of SPTS input streams. Disable for high traffic loads.	Status =Enable / Disable Default: Disable
OutputCheck	Status	Permits testing and debugging (for manufacturer's use only).	Status =Enable / Disable Default: Disable
PatAutoEna	Status	Enables / Disables the PAT automatic tab builder.	Status = [Enable] / Disable PAT auto. tab builder.
PmtAutoEna	Status	Enables / Disables the PMT automatic tab builder.	Status = [Enable] / Disable PMT auto. tab builder.
CaeTcp	ip n	Defines the host IP address style and host IP port number and port number.	ip = host IP address style : 194.90.203.152 n = host tcp port num.
CaeBackupHost	IP	Defines the backup host IP address style.	ip = host IP address style : 194.90.203.153
CaeAliveTimer	n	Frequency at which the Alive Timer checks the last TCP received from CAE.	n = Alive timer checks last (tcp) cae receive. (in seconds, default 0 no t.o.).
DbgOutCtrlPid	PID	PID for represent debug out counters	PID =pid of debug out counters
Scremble	Status	Enables / Disables the scramble status.	Status = Enable / Disable default = Disable
ScrembleTO	n	Time Out used during scrambling for key changes	n = T.O. for keys Changing Scopus Default = 80 sec.
PcrDiscontDcl	Status	Enables / Disables the Pcr discontinuity declaration status.	Status = [Enable] / Disable Pcr discontinuity declare.
ScrType	Type	T.O. for keys Changing	Type = SCOPUS - scopus style scr (scopus cas). MIXED - scopus+DVB style scr (scopus cas). SCOPUS_DVB - DVB style scr (scopus cas). SIMULCRYPT- DVB style scr (simulcrypt cas). FIX_KEY BISS Mode 0
Telnet	Status	Enables / Disables the Telnet status.	Status = Enable / Disable Default: Disable
CommTerminal	status	Enables / Disables Terminal	Status = Enable / Disable Default: enable

Table 6-1: MCMUX.CFG File Parameters

PARAMETER	FORMAT	DESCRIPTION	RANGE OF VALUES
CtrlUdp0Ena	status	Enables / Disables UDP control.	Status = Enable / Disable Default: Disable
CtrlUdp1Ena (2nd conn.)			
CtrlUdp0HostPort	n	Control UDP host port number.	n = control udp host port num. Default = 8000
CtrlUdp1HostPort (2nd conn.)			
CtrlUdp0HostIp	ip	Control UDP host IP address style.	IP = IP address style: 10.0.0.137 Default is the Mux IP. Can be change to multicast ip (Example 224.1.6.2)
CtrlUdp1HostIp (2nd conn.)			
CtrlUdp0HeadLen	n	The header length when receiving Transport Datagram Packets.	n = when receiving Transport Datagram Packets message , n is the number of bytes before the real first transport packet (each packet starts with 0x47 and is 188 bytes length).
CtrlUdp0HeadLen (2nd conn.)			
CtrlUdp0RemapPID	n	For re mapping the PID	n = Pid (0x... for hex) for remapping the pid; (changes cont_ctr_sw to enable);
CtrlUdp1RemapPID (2nd conn.)			
CtrlUdp0ContCtrEna	Status		Status = Enable / Disable Default: Disable
CtrlUdp1ContCtrEna (2nd conn.)			
CtrlTcp0Ena	Status	tcp control 2nd conn 'frindly' mux protocol. (mcmux server).Enables / Disables TCP control	Status = Enable / Disable Default: Disable
CtrlTcp0HostPort	n	Control TCP host port name.	n = control udp host port num. Default: 8000
CtrlTcp0TrapEna	Status		Status = Enable / Disable Default: Disable
CtrlTcp0Debug	Status		Status = Enable / Disable Default: Disable
RelayErrEnaList	n a b c ...	Associate a specific relay with a list of error number	n = relay index (0-2) a b c ... =list of error numbers that activates the relay.
RelayErrPort	n	Relay error port	n = Error Relay port address Hex Default: 0 X 20C
Debug	Type	For fix key debug information	Type = debug_type = FIX_KEY
AtmeVpiAddr	n	Changes the VPI setting of the ATM output.	n = VPI (1-0xFF). Default: 0x01
AtmeVciAddr	n	Changes the VCI setting of the ATM output.	n = VCI (0x0020-0xFFFF). Default: 0x0020

Table 6-1: MCMUX.CFG File Parameters

PARAMETER	FORMAT	DESCRIPTION	RANGE OF VALUES
#			Remark line
EndOfData			Should come last at the parameters list.

6.3.2. MCMUX.CFG File Example

The following is an example of a completed mcmux.cfg configuration file to use as a guide when working in the configuration file:

```

IFtype          TCP
ReTransTime     2
C30TableFiles   ENABLE
PcrRestamping   ENABLE
TdtTable        ENABLE
TotTable        ENABLE
OutputCheck     ENABLE
ContCtrChk      ENABLE
OutRate         20000000
OutPacets204    ENABLE
CaeTcp          194.90.203.152  1000  dbg
OutReset        0
Sremble         ENABLE
Telnet          ENABLE
CommTerminal    DISABLE
SrembleTO       100
PatAutoEna      DISABLE
PmtAutoEna      DISABLE
PcrDiscontDcl   DISABLE
EbModeDataInit 0x2000
RelayErrEnaList 0      5 6 7 8
RelayErrPort    0x2A0
    
```

6.4. MCMUX.RMP File

6.4.1. MCMUX.RMP File Parameters

MCMUX.RMP parameters define program re-mapping and packet identifiers (PID). The fields are summarized in Table 6-2.

The format column refers to the following input format:

- s- string.
- n, m, l- numerical.
- IP- IP address format.
- status – fixed options.

Table 6-2: RCMUX.RMP File Parameters

FIELD	FORMAT	DESCRIPTION	RANGE OF VALUES
RemapInPIDSt	n m	Selects the start PID for automatic input-PID re-mapping.	n = input-id (0 - 9). m = start pid (hex) for the automatic pid remapping for this channel. if 0x1fff is used no automatic remapping is done and the pids are stay the same. 0 disables the unspecified PIDs.
RemapInPid	n m l s	Re-maps a specific input PID.	n = input-id (0 - 9) m = specific pid (hex) to remap. l = pid (hex) to put insted of 'm'. 0 disables the PID (For PMTs). s = optinal pid type [pcr,pat].
RemapInProgSt	n m	Selects the start program number for automatic program remapping.	n = input-id (0 - 9). m = program number for automaic program remapping. if -1 is used no automatic remapping is done and the prog. numbers are stay the same.
RemapInProg	n m l	Remaps a specific input program number.	n = input-id (0 - 9). m = specific program number to remap. l = program number to use instead of 'm'
InputsEnaDisArr	n	Enables or Disables a specific input.	n = sequence of 10 digits, one digit for each port. - Left most digit is "port 0", - Right most digit is "port 9". Port status is given by the value of the digit: 0 = Port disabled 1 = Port enabled

Table 6-2: RCMUX.RMP File Parameters

FIELD	FORMAT	DESCRIPTION	RANGE OF VALUES
InputsReorder	n*10	Reorder inputs in an irregular order.	n = input-id (0 - 9). 10 inputs to reorder. (Change hardware inputs)
CatCaDescriptor	n m s1	Defines the CAT descriptor.	n = CA_system_id (16 bit). (For CAS 0). m = CA_pid (EMM) (13 bit). (for cat automatic treat). s1 = CAT private data byte arr style (12:34:A5:3a).. CA_system_id = 0 tab with no ca dscr (BISS).
CatCaDescriptor0: same as CatDescriptor for CAS 0.			
CatCaDescriptor1: same as CatDescriptor for CAS 1.			
PnumCaDescriptor	n m o s1	Defines the Pnum CA descriptor.	n = out program num (hex or dec.)(16 bit) (PMT CAS(0)). m = CA_system_id . (hex or dec) (16 bit) o = CA_pid (ECM) . (hex or dec) (13 bit). s1 = private data byte arrangement style (12:34:A5:3a) CA_system_id(0x2600) CA_pid (0x1fff) for BISS.
PnumCaDescriptor0: same as PnumDescriptor for CAS 0.			
PnumCaDescriptor1: same as PnumDescriptor for CAS 1.			
NitAutoEna	n	Enables/ Disables the NIT automatic tab builder.	n = ENABLE/[DISABLE] NIT automatic tab builder.
NitFileName	s1	Uses file of nit table for automatic nit, when NitAuto is enabled. When this file is on, no nit table is build only this file is being used for nit.	s1 = Nit file name
NitNetworkName	s1	Defines the string element that is in the NIT. Contains the network name.	s1 = string element appears in the NIT that contains the network name (default = "SCOPUS NET").
NitAutoServList	n	Enables/ Disables the service list for the NIT automatic tab builder.	n = ["ENABLE"] / "DISABLE" the service list for the NIT automatic tab builder (when enabled).
StreamID	n	Defines the stream ID element displayed in the NIT and PAT	n = 0x....(16 bit number) default = 0x0001
NetworkID	n	Defined the network ID element displayed in the NIT and SDT (from ETR 162 [6]).	n = 0x.....(16 bit number) default = 0x1111

Table 6-2: RCMUX.RMP File Parameters

FIELD	FORMAT	DESCRIPTION	RANGE OF VALUES
OrgNetworkID	n	Defines the Original Network Id. element that appears in the NIT and the SDT (from ETR 162 [6]).	n = 0x... (16 bit number) Default = 0x1111
SdtAutoEna	n	Enables/ Disables the SDT automatic tab builder.	n = ENABLE /[DISABLE]
InputSdtEna	n	For automaic sdt analyze the inpu's sdt.	n = input-id (0 - 9) (Can be array of inputs).
InputSdtDis	n	For automatic sdt do not analyze the input's sdt.	n = input-id (0 - 9) (Can be array of inputs).
CatAutoEna	n	Enables/ Disables the CAT automatic tab builder.	n = ENABLE /[DISABLE]
EitAutoEna	n	Enables/ Disables the EIT automatic tab builder.	n = ENABLE /[DISABLE]
SdtDftProviderName	s1	Defines the string element displayed in all STD's program elements that contain the provider name.	s1 = string element appears in all of the SDT's program elements that contains the provider name (default = "SCOPUS PROVIDER").
PnumServiceDescriptor	n s1	Defines the SDT's string element that contains the service name.	n = out prog num (hex or dec.) (16 bit) for an SDT's program service descriptor. s1 = String element displayed in the STD's program descriptor that contains the service (program) name. default =NONE
PnumServiceType	n m	Defines the PID service type element.	n = out prog num (hex or dec.) (16 bit) for an SDT's or NIT's service type. m = out prog num (hex or dec.) (16 bit) for an SDT's or NIT's service type.
MpegErrNumEna	n m	Enables / Disables the MPEG error number displayed in an error message.	n = mpeg err num (apears in error message). m = [ENABLE]/DISABLE for the specific error num . (Default "ENABLE").
InputWorkLine	n m	Defines the input work line. Line is the line depth in long words at the FIFO at work time.	n = input-id (0 – 9). m = input's fifo work line. Line is the depth line in long words of the fifo at work time. Values are (0 – 65535) or (0x0 - 0xffff). 0 - 100 will take the min. premitted (100).

Table 6-2: RCMUX.RMP File Parameters

FIELD	FORMAT	DESCRIPTION	RANGE OF VALUES
InputLowRate	n	For faster input's start (less resets).	n = input-id (0 - 9). For faster input's start (less resets).
InputHighestRate	n	Used for scan twice per loop. (Only 1 input per DSP).	n = input-id (0 - 9). For scan twice per loop (only 1 input per DSP).
OutPaddCtr	n		n = padd ctr. (default -1). padd minimum ctr.
InputScanArr	a b c	User defined list of inputs for c30 scanning.	a b c = list of inputs for c30 to scan (till 64 inputs).
InputTransparent	n	Use to send input data directly to output data.	n = input-id (0 - 9). For putting input data direct to output data.
InputPnumEnaArr	n a b c ...		n = input-id (0 - 9) for remax. a b c = list of programs number to enable.
OutFifoWorkLine	n		n = Output Fifo meter work line. (50%) (25%) (12.5%) [default] (6.25%) (3.125%) (1.5625%) (0.78125%)
NitSatDescriptor	a-g	Defines the satellite descriptor for NIT.	a = freq long (11.304 GHz = 1130400) b = orbinal_pos long (19.2 deg = 192) c = west_easr -flag 1 bit (Boolean) d = polarization 2 bit (tab) e = modulation 5 bit (tab) f = symbol_rate long (27.500 = 27500) g = fec_inner 4 bit (tab) (1-1/2:3-3/4:5-7/8)
NitCableDescriptor	a-e	Set cable system descriptor for NIT.	a = freq long (312.20 MHz = 3122000) b = fec_outer [4 bit (tab)] c = modulation [8 bit (tab)] d = symbol_rate [long (27.500 = 275000) e = fec_inner [4 bit (tab)]

Table 6-2: RCMUX.RMP File Parameters

FIELD	FORMAT	DESCRIPTION	RANGE OF VALUES
NitTerrestrialDescriptor	a-i	Set Terrestrial system descriptor for NIT	a = center_freq long(32 bit) b = bandwidth 3 bit c = constellation 2 bit d = hierarchy 3bit. e = code_rate_HP_strrm 3 bit. f = code_rate_LP_strrm 3 bit. g = guard_interval 2 bit. h = transmission mode 2 bit. i = other_freq_flag 1 bit
FixKeyData	a-h	Set const key data line.	a = key_id 0-64 b = scr_type: (0 – no_scr, 1 – even, 2-odd, 3 – both). c = even_key_hgh dword hex . d = even_key_low dword hex . e = odd_key_hgh dword hex . f = odd_key_low dword hex . g = prog_num h = optional list of pid's (64) to scr (for prog_num 0 only)
LostSignalErrDelay	n	Lost signal error message delay time.	n = Lost Signal Error message Delay time.
SetPmtTab	n m	Inserts pmt table to pat with service id (n)	input-id (0 - Max) (can be array of inputs). for enabling the inpu's padding. inserts pmt el to pat with service_id(n), pid(m). n = service_id. m = pmt pid.
InputPaddEna	n	For enabling the input padding	n = input-id (0 - Max) (can be array of 2 inputs). for enabling the input's pdvb 0/1.
InputCatEna	n		n = input-id(0 - Max) (can be array of inputs).
InputPnumCaEnaArr	n a b c ...		n = input-id (0 - 9) for remax. a b c = list of in progs num to enable Auto ECM. If (only n(input-id)) exist then enables all progs of the input...
AutoSysId	n		n = specific ca sys id for auto ca emm/ecm. (default 0) All sys id.
#			Remark line
EndOfData			Should come last at the parameters list. for faster input's start (less resets).

6.4.2. MCMUX.RMP File Example

The following is an example of a completed configuration file to use as a guide when working in the configuration file:

```
RemapInPid      1  0x1063 1024
RemapInPidSt    1  0x1fff
RemapInPidSt    5  0x555
RemapInPid      7  0x666 1024
RemapProgSt     25
RemapInProg     1  1  31
InputEna        6  DISABLE
InputsReorder   0  1  3  4  5  2  6  7
CatCaDescriptor 0x123  4567  12:34:A5:3a
PnumCaDescriptor      2  0x5678 0xabc 12:34:A5:3a

NitAutoEna      ENABLE
NitAutoServList ENABLE
NitNetworkName  "NIT NETWORK NAME"
StreamID         0x010
NetworkID        0x01e0
SdtAutoEna      ENABLE
CatAutoEna      ENABLE
EitAutoEna      ENABLE
SdtDfltProviderName "MAIN PROVIDER"
PnumServiceDescriptor  2  "The prog num Service dscr"
PnumServiceType        2  0x01
MpegErrNumEna         13  DISABLE
InputWorkLine         3  0
InputLowRate           5
InputHighestRate      6
InputTransparent       7
InputSdtEna           4
OutFifoWorkLine       6
OutPaddCtr            20
SetPmtTab             0x0101 0x01
```