

Warning: read the manual carefully before attempting to operate the Orangenius juicer

VERSION 1.1 NOVEMBER 2006





INDEX

СН	IAPTER 1 – General Introduction	
1.1	Certificate of compliance	P. 2
1.2	Preliminary remarks	P. 2
1.3	Safety norms	P. 2
1.4	Observance and particular warnings	P. 3
	Unpacking procedures	
	Packing list	
СН	IAPTER 2 – Installation	
2.1		
2.2	USING THE RIGHT SHOVEL KIT (ORANGE COLOR)	P. 9
2.3	USING THE RIGHT SHOVEL KIT (YELLOW COLOR)	P. 10
2.4	INSTALLATION – Phase II.	P. 13
СН	IAPTER 3 – Operative cycle	
	OPERATIVE CYCLE	P. 15
СН	APTER 4 – Disassembling operation and cleaning process	
4.1		P. 16
4.2		
4.3	SQUEEZING POT	P. 19
СН	IAPTER 5 - Assembly	
5.1	ASSEMBLY THE ORANGENIUS	P. 21
5.2	INSTALLING THE SQUEEZING POT	P. 23
5.3	INSTALLING THE KNIFE COVER	P. 27
	IAPTER 6- Maintanence	
6.1	WASTAGE	P. 31
6.2	DAYLY OPERATION	P. 32
	IAPTER 7 – Machine ID	
7.1	MACHINE PLATE	
7.2	TECHNICAL SPECIFICATION	
7.3	TECHNICAL SERVICE CENTRES	P.35
СН	IAPTER 8 – Failures – Shutdowns – Diagnosis	P. 36
	IAPTER 9 – Spare Parts Catalogue	_
8.1	SPARE PARTS	P. 41

Chapter 1 - General Introduction





1.1- Certificate of compliance

The Orangenius has been produced in compliance with international standards and health norms applicable to food machines. In particular, AAT SPA declares, through the Certificate of Compliance included with the machine, that the citrus-fruit squeezing machine OR M5 PL has been designed and manufactured in accordance with the EEC Directive 89/392 (Machine Directive) and with the above mentioned norms.

1.2 – Preliminary remarks

• The illustrations and drawings showing the machine are to be considered only as a general reference and are not necessarily precise in every detail;

• The dimensions and specifications of the machine that are supplied by this manual are not binding and can be changed without any advance notice;

• The drawings and all other documents supplied as a part of this machine are property of AAT SPA and must not be given to third parties without obtaining written authorisation from AAT SPA.

• The manual includes the instructions for all the accessories mounted on the base machine.

• The machine is covered by a warranty as per purchase contract. During the warranty period, any repair intervention (Something missing here!)

1.3 – Safety norms

• THE FOLLOWING NORMS HAS TO BE FOLLOWED FOR YOUR OWN SAFETY. Please follow these rules to avoid serious injury.

! • DO NOT USE THE MACHINE WITHOUT READING THIS MANUAL.

- Be sure to properly install all of the safety panels BEFORE attempting to use the machine;
- DO NOT leave any tool or objects inside the machine;
- In case of malfunction switch off the machine immediately! DO NOT TRY TO REPAIR THE MACHINE WHILE IT IS FUNCTIONING !
- BEFORE restarting the machine after any maintenance be sure to replace all the safety panels;
- Remember that your safety and the safety of your colleagues depend on your responsible behaviour.

• Handle the machine with care, follow instructions and use extra caution if you need to move the machine.

1.4 – Observance and particular warnings

• The personnel working with this machine must know and scrupulously comply with the general safety norms. Non compliance with the norms could cause injuries to the personnel and damage to machine parts;

• The maintenance operations shall be carried out only when the machine is not in use. The electrical cord must be disconnected;

• The user must make sure that all the instructions in this manual are completely followed;







- Any tampering with the safety system is at the user's risk and responsibility;
- Never disconnect or attempt to bypass the safety protections;
- AAT s.p.a. is not responsible for any accessories or machinery used in conjunction with
- Oranfresh Juicing Machines unless AAT s.p.a. supplies such machinery.
- The careful observance of all instructions is necessary if the machine is to work correctly.
- In addition, when installing the machine, please pay particular attention to the general environment in which the machine will be operating.
- All national laws, governing the use of this type of machines, must be followed.

Warning

Our company declines all responsibility for damages that arise from not following the instructions mentioned above

UNPACKING PROCEDURES










PACKING LIST









Chapter 2 – Installation

2.1 – Installation - PHASE I








AT 2.2 – Using the correct Pusher Kit

In order to ensure the best performance of the Orangenius please choose the correct pusher kit. The size of the oranges you are using dictates the choice of Pusher Kit .

2.2.1 – Oranges calibre 6\7 (diameter 70\80) – Orange colour










2.2.2 - Oranges calibre 8\9 (diameter 60\70) – Yellow colour kit (Pusher+collar)

AT










AT 2.3 – Installation – Phase<u>II</u>








Chapter 3 – Operative Cycle

To turn on the machine proceed as follows:






Chapter 4 - Disassembling operation for cleaning

4.1- Glass Tray:


AT






AT 4.2 – Cleaning operations

Lift the transparent cover and follow these instructions:















4.3 – Cleaning the squeezing pot






The cleaning operation of the squeezing pot, the waste container and all the components has to be done daily or after a heavy use. The inside of the machine should also be rinsed to clean the spout.








Chapter 5 – Assembly

5.1 – Installing the knife cover























5.3 – Installing the knife cover








After the squeezing pot has been installed and the knife has been mounted on the knife cover, continue with the following operations:











Finally install the transparent cover as showed in chapter 2.



Chapter 6 – Maintenance

6.1 – Wastage.

All the wastage produced during the squeezing process is conveyed to the peel container. When the peel container is full the machine will stop and an acoustic alarm will start.

When the alarm sounds for the first time, the operator may chose to simply move the container back and forward in order to distribute the peels inside the container evenly and continue to use the Orangenius..

At the second alarm please unload the container.

To restart the Orangenius just press the start button.

ATTENTION The peel container holds only peels and peel-oil. When unloading the container, please check to see if peels have fallen behind the container. If so, remove them before reinserting the container.

ATTENTION

If the oranges are too small they may jam in the knife area and lift up the transparent cover. In that case just remove the oranges, and continue to work.





To maintain the efficiency of the machine:

- At the end of the day or after 100 juice cups clear the machine by pressing the start button and letting the machine work for a few minutes without oranges then

- turn off the main switch on the back of the machine and follow the cleaning instructions in Chapter 2



Chapter 7 – Machine ID

7.1 - Machine Nameplate





In case of any maintenance or overhaul operation not foreseen in this manual, or in case of any technical problem, our technical service department is readily available for further information or to recommend the necessary intervention.

While contacting the technical service department, please supply the model code and the serial number/matricola of the machine on the nameplate attached to the rear of the machine.

Fig. 7.1.


ANT		C
A Agu	roindustry Advanced Tech	ologies S.
70010 100	CATANIA - ITALY	
	DUSTRIALE - VIA V. 5.291233 - Fax 095.2	
MODELLO	OR - M5 PL	1
		1
MATRICOL	A	
DATA		

Fig. 7.1

Р

7.2 – Technical specifications

7.2.1 DIMENSION AND WEIGHT:







С

Dimension:	A Width $= 260 \text{ mm}$
	B Height = 710 mm
	C Depth $= 560 \text{ mm}$
Net weight:	28 kg
Gross weight (wit	h box): 30 kg

B

7.2.2 Technical Specifications:

Electric requirements :	[USA] 110/120V-60Hz / [EC] 220/240V-50Hz grounded single phase
Motor power :	250 W
Electromagnetic compatibility:	in compliance with VDE 0843/IEC801 harness conforming to
	EN55011
Orange calibre:	ø between 60 and 80 mm
Orange feeder arm:	6 citrus fruits
Peel container capacity:	N° 13-15 oranges
Speed:	22 oranges per minute

7.2.3 Noise

Equivalent level of the weighted acoustic pressure at 1 metre: 62 dB. Maximum level of the weighted instantaneous acoustic pressure in the work place: lower than 120 dB/20 uPa.

7.2.4 WORK ENVIRONMENTAL LIMITS

The environmental limits of the machine are:

• Temperature : from 50°-113° F / 10°-45° C;

If the temperature is lower than 50° F/10°C and near 32° F/0°C, when the machine is both installed and dismounted, it is important to avoid allowing condensation inside the machine as AAT S.P.A. is not responsible for any possible damages due to this kind of problem.

• Humidity: from 20% to 95%.

7.3 - Technical Service Centres

In case of any problems requiring our intervention, you can contact the following authorised centres during the warranty period at the time of the machine's maintenance and/or repair.





AAT SPA Blocco Palma I, Z.I. - 95030 CATANIA Tel: 0039 095 291233 Fax: 0039 095 291117 E-mail : info@oranfresh.com www.oranfresh.com

Branches

ROME Via Sannicandro di Bari n° 8/10 - 00193 ROMA Tel: 0039 06 22446984 Fax: 0039 06 22446988 E-mail : inforoma@oranfresh.com

MILAN Via Moncenisio n° 79 - 20089 ROZZANO (MI) Tel:0039 02 57510449 Fax:0039 02 57510457 E-mail:infomilano@oranfresh.com

CHAPTER 8





FAILURES - SHUTDOWNS - DIAGNOSIS

ATTENTION Only qualified personnel shall carry out the following operations.

The machine is not connected with the outlet Connect the machine to an outlet with the outlet The machine does not Start The plug has not been inserted correctly (avoid adapters and multiple jacks) First, make sure that the machine is connected to an outlet supplying the appropriate voltage(and preferably a dedicated line), the top lid of the machine is closed, and the main switch (on the rear panel) is on. The upper cover of the machine is burnt-out The upper transparent cover of the same value The line fuse is burnt-out The line fuse is burnt-out Replace the fuse with one of the same value The motor protection fuse is burnt-out The nume fuse is not in the "ON" Turn clockwise the fastening lever in the knife cover is not in the "ON" The motor protection fuse, Turn clockwise the fastening lever in the knife cover in the "ON" Turn clockwise the fastening lever in the knife cover in the "ON"	FAILURE	REASON	SOLUTION
The machine does not StartCorrectlyadapters and multiple jacks)First, make sure that the machine is connected to an outlet supplying the appropriate voltage(and preferably a dedicated line), the top lid of the machine is closed, and the main switch (on the rear panel) is on.The upper cover of the machine is openEnable the main switch positioned on the rear panel of the machine is openThe upper transparent cover of the machine is closed, and the main switch (on the rear panel) is on.The upper cover of the machine is openThe upper transparent cover of the machine is openThe line fuse is burnt-outReplace the fuse with one of the same valueThe motor protection fuse is burnt-outReplace the fuse with one of the same valueThe fastening butterfly lever in the knife cover is not in the "ON" positionTurn clockwise the fastening lever in the knife cover in the "ON" positionThe motor protection fuse,The motor protection fuse,Replace the fuse with one of the same value			Connect the machine to an outlet
Ine machine does not StartThe main switch has not been enabledpositioned on the rear panel of the machine is on the rear panel of the machineFirst, make sure that the machine is connected to an outlet supplying the appropriate voltage(and preferably a dedicated line), the top lid of the machine is closed, and the main switch (on the rear panel) is on.The upper cover of the machine is openThe upper transparent cover of the machine is openThe ine fuse is burnt-outThe upper transparent cover of the machine is openThe upper transparent cover of the machine is openThe line fuse is burnt-outThe line fuse is burnt-outReplace the fuse with one of the same valueThe motor protection fuse is burnt-outThe fastening butterfly lever in the knife cover is not in the "ON" positionTurn clockwise the fastening lever in the knife cover in the "ON" positionThe motor protection fuse,The motor protection fuse,Replace the fuse with one of the same value			
machine is connected to an outlet supplying the appropriate voltage(and preferably a dedicated line), the top lid of the machine is closed, and the main switch (on the rear panel) is on.The upper cover of the machine is openThe upper transparent cover of the machine is openThe top lid of the machine is closed, and the main switch (on the rear panel) is on.The line fuse is burnt-outReplace the fuse with one of the same valueThe motor protection fuse is burnt-outThe motor protection fuse is burnt-outReplace the fuse with one of the same valueThe fastening butterfly lever in the knife cover is not in the "ON" positionTurn clockwise the fastening lever in the knife cover in the "ON" positionThe motor protection fuse,The motor protection fuse,Replace the fuse with one of the same value	Start		positioned
(on the rear panel) is on. The line fuse is burnt-out Replace the fuse with one of the same value The motor protection fuse is burnt-out The motor protection fuse is burnt-out Replace the fuse with one of the same value The fastening butterfly lever in the knife cover is not in the "ON" position Turn clockwise the fastening lever in the knife cover in the "ON" position The motor protection fuse, The motor protection fuse, Replace the fuse with one of the same value	machine is connected to an outlet supplying the appropriate voltage(and preferably a dedicated line), the top lid of the machine is	11	the machine
burnt-out same value The fastening butterfly lever in the knife cover is not in the "ON" position Turn clockwise the fastening lever in the knife cover in the "ON" position The motor protection fuse, Replace the fuse with one of the	-	The line fuse is burnt-out	-
the knife cover is not in the "ON" positionlever in the knife cover in the "ON" positionThe motor protection fuse,Replace the fuse with one of the		-	-
		the knife cover is not in the "ON"	lever in the knife cover in the
behind the Reschine, is burnt-out same value			-

ÂAT		(interview) interview inte
	The machine is jammed	Clean the internal parts of the machine and make sure that there are no fruits or peels inside the squeezing zone
The machine starts and	The micro switch positioned on the gear motor is damaged	Replace the micro switch

If these checks done so far, do not yield positive results please call the technical service.

The machine starts and does not stop, although	The micro switch positioned on the gear motor is damaged	Replace the micro switch
there are no more oranges in the conveyor	The electronic card is not working	Replace the electronic card

If these checks done so far, do not yield positive results please call the technical service.





REASON	SOLUTION
The relay 1 contacts on the PCB relay are fused	Replace the PCB relay
The knife is blunt	Sharpen or replace the knife
The plastic protection has not been removed from the knife	Remove the plastic protection
The knife is not correctly positioned	Check the knife positioning
The size of the fruit is not correct	Use fruit having the recommended size
The waste compartment is full	Empty the waste compartment
The discharging chute is obstructed	Clear the discharging chute
The peels photocell is dirty	Clean the photocell positioned on the back internal panel of the discharging chute
The peels photocell has loosened	Adjust the photocell
The electronic card is damaged	Replace the card
The idling cycle time is too short	Increase the idling cycle time by turning the trimmer found on the PCB relay in a clockwise fashion
The electronic card is damaged	Replace the card
	The relay 1 contacts on the PCB relay are fusedThe knife is bluntThe plastic protection has not been removed from the knifeThe plastic protection has not been removed from the knifeThe size of the fruit is not correctly positionedThe waste compartment is fullThe discharging chute is obstructedThe peels photocell is dirtyThe peels photocell is damagedThe electronic card is damagedThe idling cycle time is too short





FAILURE	REASON	SOLUTION
The motor runs, but all the mechanic parts do not move	The gear motor is damaged	Replace the gear motor
The fruit are not juiced and the machine jams	The pins projecting out of the small cylinder are jammed or bent	Repair or replace the pins
	The small juicing cylinder is damaged	Replace the small cylinder
The peels are not	The plastic glide is damaged	Replace the plastic glide
unloaded and the machine jams	The cantering pins of the plastic glide are bent	Reset the verticality of the centring pins.
The big cylinder cannot be removed because the orange pusher blocks it	The machine has been stopped manually and is out of phase	Restart the machine by pressing the start micro switch and wait for the automatic stop
The upper cover and/or the small cylinder cannot be removed	The machine was stopped while squeezing half a fruit	Restart the machine in by pressing the start button then wait for the automatic stop These operations must be carried out whit the upper covered properly engaged
The machine is noisy	The noise repeats at each turn of the cylinder: the small cylinder pin bumps against the plastic glide.	Make sure that the plastic helical guide is correctly mounted and in particular that the helical guide pin is not bent
	The noise repeats with quick frequency: the gear teeth are worn out Or There is too much clearance between the teeth of the two cylinders.	Replace the gears Adjust the compensation springs of the big cylinder by loosening the nut located behind the front panel of the machine

A AT	Tangenius	
FAILURE	REASON	SOLUTION
	The thrust plastic bearing roller of the small cylinder is worn out	Replace the thrust bearing roller
The fruit is partially juiced (low yield).	The clearance between the teeth of the two cylinders is more than 2 mm	Adjust the compensation springs of the big cylinder by loosening the nut located behind the front panel of the machine
	The plastic shock absorber are ruined	Replace the shock absorber