



TIME CLOCK WORLD

888 534-5994



Model 125SP

USER MANUAL



Solar Panel Operating Instructions

1. Charge the Panel via Sunlight

- a. Open the Solar Panel and keep it facing the sunlight as shown in Figure 1. The LED indicator on the DC 6V input will become Green, indicating that the lithium battery is being charged. The stronger the sunlight intensity, the stronger the charging current.
- b. Charging times can range from 8-12 hours depending upon the intensity of the sun.




Figure 1

2. Charge via USB Cable Connected to Computer

- a. This is the process to charge the battery when direct sunlight is not available. Plug the Power/Charging cable into the “DC 6V IN” connector on the bottom side of the solar panel as shown in Figure 2. It is not required that solar panel need to be opened when using the PC’s USB plug. Note: The Power cord and charging cord are the same. The function is determined by when connector is used on the Solar Panel.



Figure 2

- b. Connect the other end of the Power/Charging cord to the USB connector on the PC. The “LED” beside the “DC 6V IN” will light up indicating that the Lithium battery is charging. Charging time should be approximately 6 hours for a full charge.

Note: After the Solar Panel has been in the sunlight for at least 15 minutes, the Acroprint Time Clock can be connected to the Solar Panel using the Power/Charging connector, but it is recommended that the Solar Panel lithium battery be fully charged before being placed into operation.

3. Clock Operation with the Solar Panel

- a. When the Solar panel has been fully charged, it can be connected to the Acroprint Time Clock via the supplied Power/Charging cable. First connect the round 1.3mm connector to the Time Clock power jack located on the rear of the clock in the bottom right corner.
- b. Next, connect the “USB” connector to the Solar Panel as shown in Figure 3.
- c. After the “USB” connector has been plugged in, move the power switch from the “OFF” position to the “6V” position. A “GREEN” led should illuminate indicating that the Solar Panel is now active and supplying power to the Time Clock. The Clock will advance the time 1 or 2 minutes when this step is complete.
- d. Set the correct time on the Time Clock.



Figure 3





FIGURE 2

The Rechargeable Recorder BP 125-R6

These recorders include four (4) standard rechargeable batteries.

IMPORTANT: Before setting your recorder to the correct time, plug the machine in for at least 15 minutes to allow batteries to charge up to operating voltage or the recorder will run slow.

125 Rechargeable (120/240V AC)



The BP-12 Acroprint BOSS Recorder

The BP125-12 "BOSS" Recorder is designed to operate on a 12 Volt Automobile Battery.


We recommend you connect the recorder directly to the Battery to insure that constant power is supplied.

We supplied two (2) "ring" terminals to make the connection to your battery and two (2) "y" terminals to make the connection on the terminal block. You will need to purchase two (2) wires in whatever length required. We suggest a No. 20 gauge stranded wire that can be purchased from any hardware store or electrical parts shop.

Once you have the wire, connect a "ring" terminal to one end of each wire and a "y" terminal to the other ends. (Locate the six (6) position terminal block mounted to the time recorder's back case and connect one of the "y" terminals to terminal No. 1 and the other to terminal No. 2, be sure to identify the wire on Terminal No. 2 by wrapping electrician's tape around the ring terminal because this will be connected to the positive (+) terminal on your battery.) Fish the wire through the firewall of the vehicle either through an existing opening used by air conditioning or heating hoses or hood release cable. If necessary, you may drill a hole in the firewall at a place where there are no obstructions under the hood. Run the wire to the battery and remove the battery bolt screw and install it back into the bolt (see Figure 2.) Follow the same procedure for the negative terminal.

If you wish, you may have the unit professionally installed at a nominal fee by any garage specializing in automobile electrical services.

125 Battery Powered (12V DC)




To Remove Case Cover

- 1) Turn key one quarter turn clockwise.
- 2) Lift case cover up then forward.
- 3) Reverse procedure to replace cover.

To Set Time and/or Date

NOTE: Unless your recorder is equipped with continental (0-23) hours, all PM hours on the time card will be printed underscored (Ex.: 1:00). To change the time and/or date follow these steps:

- 1) Unplug recorder and remove Case Cover.
- 2) **To Set Day/Date**
 - A) Make sure current time setting is between midnight and noon (see note above).
 - B) Push down and release Yellow Lever (see Figure 1) to set correct day/date.
 - C) Plug in recorder and punch card to verify correct setting. Repeat steps A-C if reading is incorrect
- 3) **To Set Time**
 - A) Push down and release Black Minute Lever to set the correct time (see Figure 1). If minute lever does not work, plug in recorder and wait for minute hand to advance, then unplug recorder and try lever again. **DO NOT MOVE CLOCK HANDS TO SET THE TIME.**
- 4) **To Set Month** (if so equipped)
 - A) Turn Month Knob (see Figure 1) counter-clockwise to select correct month.
 - B) Plug in recorder and punch card to verify correct setting. Repeat steps A-B if reading is incorrect.
- 5) **To Set Year** (if so equipped)
 - A) Insert point of pen into spoke on side of year wheel and rotate counter-clockwise.
 - B) Plug in recorder and punch card to verify correct setting. Repeat steps A-B if reading is incorrect.




IMPORTANT NOTES

- 1) The date setting (if so equipped) **MUST** be **manually** reset to the first of the month each month, following any month with less than 31 days.
- 2) The month and year settings (if so equipped) **MUST** be **manually** reset every month/year.
- 3) To reset your recorder after a power failure follow the steps 1-5.
- 4) HINT: If clock is set slightly ahead of actual time, you may unplug it until it matches the correct time.

To Set Time and/or Date for Left Print Models

- 1) Unplug recorder and remove Case Cover.
- 2) **To Set Day/Date**
 - A) Follow the same steps as for standard models, but note the different location of Yellow Day/Date lever in Figure 2.
- 3) **To Set Time**
 - A) Follow the same steps as for standard models.
- 4) **To Set Month** (if so equipped)
 - A) Move Month Lever (see Figure 2) to extreme left position then return slowly to right until an audible "click" is heard.
 - B) Plug in recorder and punch card to verify correct setting. Repeat steps A-B if reading is incorrect.
- 5) **To Set Year** (if so equipped)
 - A) Note that year set lever is located at the rear of the typehead assembly. Follow the same steps as for setting the month on left print models.




To Change Ribbon

A replacement Acroprint Ribbon is supplied on two spools. When ordering specify 20-106-002 for two-color right margin print recorder, 20-106-000 for two-color left margin print recorder, or 20-0106-003 for solid blue ribbon. To replace the ribbon, perform the following steps.

- 1) Note how ribbon is threaded. Pull right Ribbon Tension Spring (see Figure 3) forward and remove spool. Pull left Ribbon Tension Spring (see Figure 3) forward and remove spool. Remove and discard ribbon.
- 2) Insert new right Ribbon Spool with "hex" hole fitted on to "hex" shaft on the right ribbon feed ratchet. Thread ribbon, as noted in step 1. Insert new left Ribbon Spool with "hex" hole fitted on to "hex" shaft on the left ribbon feed ratchet. Turn right Ribbon Spool counter-clockwise to remove excess slack in ribbon.

Figure 3 (front view with cover removed)



Installing the Time Recorder

Unpacking and Inspection

Carefully unpack your recorder and inspect it for any damage. Verify that the following accessories are included: three mounting screws, a case lock key, and the General Service Instructions. Report damage or shortages to the company from which the unit was purchased.

Site Requirements


The recorder should be mounted on a sturdy wall, shelf, or other support area. Do not use the recorder under the following conditions:

- extremely high or low temperature
[operating range: 0° to 50° C (32° to 122° F)]
- extremely high or low humidity
[operating range: 0 to 90% RH non-condensing]
- areas of high dust concentration
- areas with extreme vibration or when placed on an unstable or unlevel surface

Mounting the Recorder and Card Racks

The recorder requires an uninterrupted AC power supply, and should be mounted within 6 feet of a power receptacle to accommodate the unit's power cord. The suggested wall mounting layout for the recorder and optional card racks is shown in Figure 4. Suggestions for mounting on specific wall and shelf surfaces follow.

Figure 4 (suggested mounting layout)



Wooden/Plywood Walls

You may use the three screws included with the recorder to mount the recorder. Install a screw in the wall 53" above the floor. Leave enough of the screw protruding so the recorder will hang flat against the wall through the "keyhole" on back of the clock. Hang and level the recorder. Insert and tighten screws through the lower left and right mounting holes.

Masonry Walls

You may use plastic masonry anchors and screws available at your local hardware store to mount the recorder. Mark a location on the wall 53" above the floor. Drill a hole with a 1/4" masonry bit and insert a plastic anchor. Tighten a screw at this location, leaving enough of the screw protruding so the recorder will hang flat against the wall through the "keyhole" on back of the clock. Hang and level the recorder. Mark the location of the lower left and right mounting holes. Remove the recorder, drill holes, and insert anchors. Replace the recorder, insert and tighten screws through the lower left and right mounting holes, and fully tighten the "keyhole" screw.

Sheetrock/Hollow Core Walls

You may use "molly" fasteners available at your local hardware store to mount the recorder. Follow the procedure for masonry walls, using the "molly" fasteners instead. Alternatively, you may use longer wood screws to attach the recorder to a stud behind the sheetrock, using the "keyhole" and the lower center mounting hole on the recorder.

NOTE: Always consult with a professional contractor/carpenter and obey all local building and fire codes when installing your recorder.