

MATAN JetSet[®] p 3.2



User Manual

Table of Contents

CHAPTER 1	OUTLINE	1
1.1	MAIN CHARACTERISTICS	1
1.2	QUALITY AND SAFETY INSURANCE	1
1.3	SPECIFICATIONS	2
1.4	INTRODUCTION TO MAIN COMPONENTS	4
1.5	WARNING SIGNS.....	13
CHAPTER 2	OPERATION GUIDE.....	14
2.1	FEEDING	14
2.2	STARTING YOUR PRINTER.....	16
2.3	INK FILLING PROCEDURE.....	18
2.4	PRINTING CONTROL PROCESS	18
2.5	REMOVING MATERIAL.....	18
2.6	SHUTTING DOWN.....	18
CHAPTER 3	USE OF CONTROL SOFTWARE.....	19
3.1	OBJECTIVES	19
3.2	FUNCTIONS	19
3.3	EXECUTION ENVIRONMENT.....	20
3.4	OPERATION	20
3.4.1	Hardware Installation and Initialization.....	20
3.4.2	RIP Software Installation	20
3.4.3	Control Software Installation.....	20
3.4.4	User Interface	25
3.4.4.1	<i>Main Interface</i>	25
3.4.4.2	<i>File Tab</i>	31
3.4.4.3	<i>Option Tab</i>	32

3.4.4.4	<i>Para Tab</i>	33
3.4.4.5	<i>Move Tab</i>	34
3.4.4.6	<i>Aux Tab</i>	35
3.4.4.7	<i>Engineer Tab</i>	36
3.4.5	Modify Parameters in Printing	38
3.4.6	Operation Introduction	38
3.4.6.1	<i>Printing Document</i>	38
3.4.6.2	<i>Select Print Parameters</i>	38
3.4.6.3	<i>Parameters Export and Import</i>	40
3.4.6.4	<i>Control of Printing Process</i>	40
3.4.6.5	<i>Double-Side Printing</i>	41
3.4.6.6	<i>Region Printing for Large Images</i>	41
3.4.6.7	<i>Multi-file Printing</i>	42
3.4.6.8	<i>Web Printing</i>	43
3.4.6.9	<i>Restore Printing</i>	43
3.4.6.10	<i>RIP EDIT</i>	44
3.5	ERROR AND WARNING CODES.....	48
CHAPTER 4 OFFSET ADJUSTMENT FOR PRINT HEADS.....		49
4.1	OFFSET ADJUSTMENT FOR PRINT HEADS JETTING THE SAME COLOR.....	50
4.1.1	X-Direction Offset Adjustment	50
4.1.2	Y-Direction Offset Adjustment.....	51
4.2	COLOR OFFSET ADJUSTMENT	52
4.2.1	Check Status of Print Heads.....	53
4.2.2	Adjust the Step Difference	53
4.2.3	X & Y Direction Color Offset (Color Offset).....	54
4.2.4	Bi-Difference (Return Difference)	55

CHAPTER 5 MAINTENANCE..... 57

5.1 MAINTENANCE SPECIFICATIONS..... 57

5.1.1 Preparations before Start..... 57

5.1.2 Maintenance in Printing..... 57

5.1.3 Shut Down for Maintenance 58

5.1.3.1 *Daily Maintenance* 58

5.1.3.2 *Weekly Maintenance*..... 58

5.1.3.3 *Monthly Maintenance*..... 58

5.1.3.4 *Quarterly Maintenance* 59

5.1.3.5 *Annual Maintenance* 59

5.2 MAINTENANCE OF PRINT HEAD..... 59

5.2.1 Installation of Print Head 59

5.2.2 Disassembling Print Head 59

5.2.3 Basic Maintenance Knowledge of Print Head 60

5.2.4 How to Fill the Print Head with Ink 60

5.2.5 Cleaning Print Head during Working 60

5.2.6 Protecting Print Heads during Work Stoppage (suitable for stoppage of several days)..... 60

5.3 INK SUPPLY SYSTEM MAINTENANCE..... 61

5.3.1 Cleaning the Ink Supply System 61

5.3.2 Adding Ink..... 61

5.4 CONSIDERATIONS OF INK USAGE 62

CHAPTER 6 APPENDIX..... 63

6.1 ERROR AND WARNING CODES OF CONTROL SOFTWARE 63

6.2 SOFTWARE INSTALLATION LIST 65

6.3 WARNING SIGNS..... 66

Chapter 1 Outline

1.1 Main Characteristics

The JetSet printer includes the following main features:

- ◆ The JetSet printer uses long life piezoelectric Hitachi E1 print heads, fixed on an aluminum metal base. The JetSet printer is highly causticity resistant and can control the ink point exactly, so that it can correctly adjust the fine color of the picture. It can produce high quality images with brilliant and conforming colors.
- ◆ The automatic cleaning system keeps the print heads in best working condition, efficiently keeping the heads from drying. To clean the print heads, you only need to click the Wash Heads function in the software window. The automatic cleaning system can greatly extend the life of print heads and avoid the inconvenience caused by frequent removal and washing of the print heads. The automatic cleaning system thus ensures high efficiency, safety and convenience. The automatic cleaning system is liquid protected.
- ◆ The feeding system employs tension control on the materials, ensuring smooth feeding. This prevents the possibility of pictures being destroyed due to material sticking.
- ◆ The LM (Linear Motion) carriage rail effectively eliminates the influence of carriage shaking on the print precision, thus increasing the print quality observably.
- ◆ The first inkbottle and second ink tank level sensor auto-alarming system supervises the ink level all the time, preventing the waste due to the shortage of ink.
- ◆ An inner warm-up and drying system ensures the ink dissolves in the medium quickly. This not only increases the images' outdoors durability but also extends the application scope of substrates.

1.2 Quality and Safety Insurance

The JetSet conforms to the following Quality and Safety standards:


- ◆ ISO9001: 2000 certificate, insuring the product's quality.
- ◆ CE safety certificate issued by TÜV Rhineland.

1.3 Specifications

Printing technology:	Piezo, bi-direction printing	
Print head set:	Hitachi, 96 nozzles, 12 print heads (2 heads * 6 colors)	
Color:	6 colors: C, M, Y, K, LC, LM. (4-colors printing is also possible)	
Resolution:	600DPI *	
Printing size:		
Max printing width:	2.5 m (3.2m)	
Max material width:	2.6 m (3.4m)	
Max material length:	50 m/roll	
Material thickness:	0.15-1.0 mm	
Machine description:		
Dimensions:	1. 69m(H) * 4.35/5.05m(W) * 0.83m(D)	
Weight:	942/1200 KG	
Feeding system:	Roll to roll with tension control	
Heating system:	Pre-heating, post-heating, cooling fan and carriage-heating	
Ink supply system:	Auto-continuous supply and negative pressure	
Material types:	Flexible materials with banner and flex, self-adhesive vinyl, mesh and textiles, etc.	
Printing mode:	Three Pass (3 Pass); Normal (6 Pass); Enhanced (8 Pass); Master (12 Pass); Ultra (16 Pass)	
Production capacity:	Mode	
	Three Pass	73 m ² /h
	Normal	37 m ² /h
	Ultra	14 m ² /h
Ink and solvent:	Matan Ink The ink and solvent conform to EU's & US regulations. For further details refer to MSDS on Matan's web site.	


Software description:	
Image file format:	The system support PostScriptR3™: Accept all available file format, including EPS, TIFF (CMYK mode), JPG (RGB mode) etc.
RIP operating system:	Scanvec Photo Print server Ver. 4.0 (Windows XP)
Work station configuration:	40GB hard disk, 512MB memory, P4 2.48G CPU, 10/100M Ethernet The above configuration may change in future upgrades.
Operating system:	Windows XP
Environment requirements:	
Power range:	230V AC±10V 50HZ 15A/23A
Maximum power:	3.5/5.3KW
Operating temperature:	20 - 29 °C
Non-operating temperature:	0 - 50 °C
Operating humidity:	40 - 60% RH (Not condensing)
Non-operating humidity:	10 - 80% RH (Not condensing)
Installation altitude:	2000 m or less
Operating noise:	70dB(A) or less
Safety certifications:	CE Certification. IEC/EN 60204
Guarantee:	According to Matan warranty policy. See the Warranty documents.

1.4 Introduction to Main Components



Left-up side view


* Monitor	2.Left box body	* Left emergency stop
* Vacuum adjust	5. Front top	6.Right front door
7.Secondary drying	8.Right box body	9.Cooling fans
10.Left box body	11.Pre-heating temperature controller	12.Drying temperature controller
13. AUX dryer SW	14.Tension SW	15.HV SW
16.Drying fan SW	17.Start SW	18.Platform vacuum SW
19.Lighting SW		




Left box inside

Note: 'SW' = Switch


20.LSN	21. X-axis reducer	22.x-axis motor
23.Y-axis reducer	24.Y-axis motor	




25.Servo card	26.Main power SW	27.X-axis SW
28.Y-axis SW	29.Tension SW	30.Heating SW
31.Contactor	32.Relay	33.Pre-heating relay
34.Drying relay	35. Capacitor(s)	36.Relay
37.Tension adjustor	38.Secondary drying relay	39.Line connect shelf



Platform




Carriage cleaning position




Carriage cleaning position

40.Line railway	41.Cable chain	42.Timing Belt
43.Printing platform	44.Lighting	45.Encoder Strip
46.Cleaning system	47.Carriage	48.Cleaning pump
49. Waste ink tank		


Carriage



Carriage front




Carriage back




50. Carriage PCB	51. Secondary ink tank	52. Print head
53. Carriage heating	54. Vacuum display	55. Vacuum controller
56. Ink connect PCB	57. I/O card	58. Ink card PCB
59. Cleaning PCB		





66



67

68

69

70

71

74

75

76

72

73

77

78

79


The right electric box



The back of the left box body

60.Main rubber roller	61.Pressure Roller	62.Pinch Supporter
63. Side Air valve switch	64.Middle Side Air valve switch	65.Media holder
66.Linear encoder	67. Cable terminal strip	68.PC power
69. Relay (SSR)	70. Filter	71.AC24 transformer
72.X-Axis servo controller	73. Y-Axis servo controller	74.40V Power supply
75.24V Power supply	76.12V/5V Power supply	77.Tension motor
78. Cooling fan	79.PC	80.Ink filter
81.Ink supply pump	82.Primary ink tank	83. Air pressure gauge
84.Air pressure valve	85.Main air pressure gauge	

Servo controller



1.Battery base	2.Battery connector (CON1)	3.Monitor
4.Button MODE	5.Button UP	6.Botton DOWN
7.Botton SET	8.I/O signal connector (CN1A)	9.I/O signal connector (CN1B)
10.Encoder connector (CN2)	11.Communication connector (CN3)	12.Electrification indicator
13.Main circuit terminal base (TE1)	14.Control circuit terminal base (TE2)	15.Protecting grounding (PE) terminal

1.5 Warning Signs

Before operating the printer you must read the warning sign stickers located on the printer. Please see **Appendix 3** Warning sign table.


Chapter 2 Operation Guide

2.1 Feeding

1. Put the material on the material holder.



2. Pull the material on the feeding roller, put on cover cores at both ends, lightly put it on the feeding roller rack. The material should be placed as centrally as possible.
3. Pull the material out from in front of the pinch roller toward the back.
4. Put the material around the main roller, spread the platform, pull it tight and spread it evenly. Turn on both the Side & Middle air valve SW. The material should be feeding toward the front and reaching the tension roller with open tension.




Note: If inducing material is to be added, do not stick two pieces onto the printer. Instead, stick one piece on the ground and then feed it, making sure the stuck part is not pressed between the pinch rollers.

To print on mesh, perform the following steps before feeding:

1. Turn off printer and remove the top platform board.
2. Close the ventilated cover and check if the waste ink tube is well connected.
3. Turn on printer.
4. The rest of the printing process is the same as normal printing.

To print double-face, perform the following steps:

1. Choose the right material.
2. Install the material and mark its installation position, then turn on the power and print.
During the printing process, the best method is to choose center printing.
3. After printing, use the drying icon to dry the printed media.
4. Next, feed the printed material on its other side. Make sure the installation position is the same as you marked in “Step 2”
5. Choose mirror print. If the printing position is not right, adjust the position as follows:
 - a. Click the “Modify print” button. The Modify Print Position dialog box appears:



- b. Set the Modify print position field to change the left-right picture position.
 - c. Set the Modify print move length field to change the carriage position.
 - d. Set the Modify print step field to change the front-back picture position.
6. Repeat adjustments until the printing position is right.

2.2 Starting your Printer

1. Insert the printer's main power plug into the power outlet.
2. Pull the emergency stop switches on the two ends of the printer out/up.
3. In sequence, open the general power SW, the X & Y axis SW, the vacuum cleaner SW, the heating SW, and the control power SW.



4. Press down the start button and the PC power button. After the PC has started, open the HV power SW.



5. Turn on the tension SW, the vacuum adjustor, cooling fan SW, the AUX dryer and the lighting SW.

6. Start the software operation system.

2.3 Ink Filling Procedure

1. Before filling the ink, first clean the ink bucket with solvent.
2. Switch on the control power.
3. Before connecting the print head with the tube, flush every outlet with solvent to ensure the elimination of scraps in the tubes.
4. Connect the print head, push solvent into the print heads.
5. Add ink into the ink containers and let it flow continuously until the ink displaces the solvent.

For more information on the print heads, refer to **Chapter 5**, Maintenance of Print Head.

2.4 Printing Control Process

1. During the printing process, do not open the platform cover or the cleaning position cover; do not turn off the HV power SW, main power supply, or the X & Y axis SW - otherwise the print process will be terminated.
2. During the printing process, if anything unexpected occurs, push the emergency stop SW to terminate the process.
3. Do not modify the parameters of the motor during the printing process.

For more on Printing Control, refer to **Chapter 3**, Use of Control Software.

2.5 Removing Material

1. Loosen tension.
2. Cut the material off the printer (be sure not to scrape the machine).

2.6 Shutting Down

1. Set the HV power SW to OFF.
2. Close the control software.
3. Shut down the PC.
4. In order, turn off all the following: control power, heating, vacuum pump, X & Y axis controller, and general power.
5. Protect the print heads (refer to **Chapter 5**, Maintenance of Print Head).

Chapter 3 Use of Control Software

3.1 Objectives

This User Manual explains how to use Matan's JetSet printer software, and provides useful reference assistance to our customers.

- ◆ **Multi-copy printing:** print the same image on several copies in landscape orientation.
- ◆ **Region printing:** choose one region of a picture to print.
- ◆ **Normal printing:** define the scope before printing, no matter whether it is a blank area or an image.

3.2 Functions

- ◆ Support 600x360dpi with 4/6 colors printing in RIP format.
- ◆ Support print modes of Test, Draft, Normal, Enhanced, Master, and Ultra.
- ◆ Freely set enable or disable for each color.
- ◆ Provide three levels of print speed and five levels of feed speed. The whole printing process can be configured dynamically.
- ◆ Various print solutions including single direction, mirror, and double strike print.
- ◆ Smart print with white space skips in X and Y-axis directions, and with automatic drying after printing.
- ◆ Special print modes including multi-copy print, region print, and separate print.
- ◆ Automatic edge searching (including multiple materials), cleaning in printing, and flash jet.
- ◆ Enable the printing of footnotes, print parameters, user remarks, and date.
- ◆ Modify offset parameter, material feeding speed, and printing position, during the printing.
- ◆ Support batch print and copy configuration.
- ◆ Automatic print head maintenance during printing breaks.

- ◆ Select head set and print color bar to check the status of the print head.
- ◆ Recover and resume printing after an unexpected break.
- ◆ Automatic cleaning system and liquid protection.
- ◆ Support multi-file print, restore print, and files auto division print.

3.3 Execution Environment

- ◆ Operating system: WINDOWS XP.
- ◆ Driver for PCI image card.
- ◆ CPU: P4 2.4 GHz or above.
- ◆ Memory: 256MB or above.
- ◆ Network: 10/100M Ethernet adapter.
- ◆ Hard disk: 40 GB.

3.4 Operation

3.4.1 Hardware Installation and Initialization

Insert the image card into the PCI slot of your PC. Install driver and application programs. As both are pre-configured with default parameters, you can start printing right after this is completed.

3.4.2 RIP Software Installation

The extension of the output file is *.prn or *.prt


The RIP file is exported by RIP software "PPS4"

For its usage, refer to the User Manual on Installation DISK2 (see Appendix 2).


3.4.3 Control Software Installation

Put the installation disk into the CD-ROM drive and perform the following steps to install the control software:


1. Proceed to directory \install of the disk and run the setup.exe file to start the installation wizard.




2. When you see the Welcome screen, click the 'Next' button to continue.




3. Select the Destination Folder for the installation.



4. Click the Next button to keep the default Program Folder name.



5. The installation program will now copy the hardware drivers and control software to the Destination Folder.



Note: If there is an error in the hardware driver installation, the following Install dialogue box pops up. You must then install the hardware driver manually after the installation of the software.



6. After finishing the installation, you must reboot the PC so that the driver will be available.

You must reboot your system



Setup has finished copying files to your computer.

Before you can use the program, you must restart Windows or your computer.

- Yes, I want to restart my computer now.
- No, I will restart my computer later.


Remove any disks from their drives, and then click Finish to complete setup.

< Back

Finish

3.4.4 User Interface

3.4.4.1 Main Interface



1.Menu items

2.Toolbar

3.Print settings bar

4.Property pages

5.Job image information

6.Job preview

7.Status bar

8.Printing job list

◆ **Menu:**

File	
Open	Select a file
Add Task	Add the selected file to the printing job list
Add and Print	Add the selected file to the printing job list, then print the file
Delete	Delete the current RIP file from the printing job list
Exit	Exit the application
Print	
Reset	Reset the position of the print carriage
Measure	Get the edge position and width of material
Print	Printing actions
Stop	
Pause	
Continue	
Multi-file Print	Print many files pieced together with no printing gap
Restore Print	
Option	
Init Printer	Initialize printer action
Move Stop	Moving carriage and feeding material
Move Left	
Move Right	
Move Up	
Move Down	
Wash Heads	Clean the print heads
Modify Print Position	Modify print position for printing
Export Parameter File	Save parameters

Import Parameter File	Load parameters
Tools	
Turn On Cleaner	Turn on/off cleaner for cleaning print heads
Turn Off Cleaner	
Protect Heads	Enable flash jet to protect print heads
Screen Keyboard	Show/hide PC keyboard
View	
View Control Page	Show/hide property pages
Fit view	Preview actions
Zoom Out	
Zoom In	
Refresh	
Status view	Show print head state
Help	
About Matan Print	Software version description

◆ **Toolbar:**

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21



1.View Control Page	Show/hide property pages
2.Open File	Add a file to the list of print jobs
3.Start Print	Printing operations
4.Print Pause	
5.Print Continue	
6.Print Stop	
7.Reset	Reset the position of the print carriage
8.Measure	Get the edge and width of the material
9.Modify Print Position	Modify print position in printing, used for double-side printing
10.Move Left	Move the print carriage from right to left
11.Move Right	Move the print carriage from left to right
12.Move Stop	Stop moving
13.Move Up	Collecting material
14.Move Down	Feeding material
15.Wash Heads	Clean print heads
16.Protect Heads K.C.M.Y.LC.LM	Enable press ink to protect heads
17.Liquid Protection	
18.Dryer	After printing, dry automatically
19.Screen Keyboard	Popup the screen keyboard
20.RIP EDIT	Support multi-files: file edit DPI transit web print
21.About	Software version description

- ◆ **Print settings bar:** Set frequently used settings such as: print speed, print mode, ink quantity, and material's margin.




Operation of Toolbar: Click the Open File button to add files to the printing jobs list. Select the file to be printed, and click the Start Print button to start the operation.

Print Mode:	Select the print mode There are six modes: Three Pass, Draft, Normal, Enhanced, Master and Ultra.
Print Speed:	Define the print speed
Print Align:	The printing position of the image on the material Left: left side align Right: right side align Center: middle position align Align mode is only used for edge checking.
Ink:	Ink density adjustment
Zero Pos:	Distance between the cleaning device and the right limited switch
Margin:	Define the blank margin (refers to the distance between the left edge of material the starting position of printing)
Print Color Bar:	Enable Print Color Bar use in printing
Browse:	Add all RIP files under specified directory to the printing jobs list

- ◆ **Status bar:** Shows the printing progress bar [1], and the absolute position of the print carriage [2].






1. The printing progress bar
2. The absolute position of the print carriage
3. Click the ball button and the "INK&ALARM STATUS VIEW" window opens
4. The ink level status of the Secondary Ink Tank
5. The ink level status of the Main Ink Tank
6. Whether the print head protector is open or not
7. Whether the emergency stop is on or not
8. Pressure of the platform vacuum (future application)
9. Temperature of the print head set

3.4.4.2 File Tab

This displays the printing jobs list. Click the Toolbar's Open File button or the Print settings bar Browse button to add RIP files to the printing jobs list.

Click your right mouse button on the printing jobs list and you see the following menu items:

- Print:** Print the selected job
- Move task ahead:** Move the selected job upward
- Move task back:** Move the selected job downward
- Delete task:** Delete the selected job
- Delete all tasks:** Clear the printing jobs list



3.4.4.3 Option Tab

Print mode

Normal: Print using the standard predefined print parameters.

MultiCopy: Print multiple copies.

Region: Print only the selected region of the image.

Multi copy:

Column: Number of copies to be printed vertically.

Interval: Interval length between copies in the column.

Row: Number of copies to be printed horizontally.

Distance: Distance between copies in the row.

Region:

Left: Left edge of the selected region to be printed.

Top: Top edge of the selected region to be printed.

Width: Width of the selected region to be printed.

Height: Height of the selected region to be printed.

Color Bar:

Width: Width of each color.

Distance: Distance to the printed area.

Protect head:

Wash period: Head cleaning frequency during printing.

Count: The number of times to wash during cleaning.

Flash Jet Period: Frequency of flash jet during printing.

Use the [All] group heads:

Choose which group of print heads to use; if not chosen, both sets [All] are used by default.


Print Select:

Single dir print: Single-direction print.

Direction:

Left: Single-direction print from left to right.

Right: Single-direction print from right to left.




- Mirror print:** Print the image mirror.
- Double strike:** Double strike print.
- Smart print:** Automatically skip the white space area at the X, Y-axis location.

3.4.4.4 Para Tab

Note: Please refer to **Chapter 4**, Offset Adjustment for Print Head.

- Step offset:** Adjust the step difference according to the different possibilities.
- Return difference:** Position difference as a result of printing under various speeds, which can be adjusted online.
- Color offset:** Position offset adjustment of the jet head. Refer to the position offset of two rows of print heads at both directions of X-axis and Y-axis. "→" refers to the rightward offset, while "←" refers to the leftward offset. The offset value defines the number of dots after the print startup position defined by command, where the actual printing operation begins. It is applied to color registration.



Note:

X direction position offset: Use dot as the unit.

Y direction position offset: Use 1/48 dot as the unit

- Adjust:** Pops up the offset adjustment dialog.
- Update:** Updates the parameters in printing.
- Default:** Click this to set all offset parameters from the software defaults.
- Clear:** Clear all the parameters.
- Advanced:** Pops up the print head horizontal adjustment dialog.

3.4.4.5 Move Tab

Move control:

- X Dir Speed:** Moving carriage speed
- X Dir Distance:** Moving carriage length
- Y Dir Speed:** Feeding material speed
- Y Dir Distance:** Feeding material length

Move option:

- U:** Collect material
- D:** Feed material
- ←:** Leftward
- :** Rightward
- Stop:** Stop moving

Line switch and Sensor status:


- LSN:** Status of left position limited switch
- RSN:** Status of right position limited switch
Red means the limited switch is pressed down; green means normal condition.
- Light:** Status of the edge checker (a light sensor)

Analyze:

Analyze the print carriage and feed/collect material movement

Movement analysis: Linear encoder shall be installed to analyze X-axis movement; Stop encoder shall be installed to analyze Y-axis movement.


Choose Analyze to graph the print carriage speed vs. feed/collect material speed. To analyze the relationship: Under same speed conditions, the graphed line is a straight one; this means the operational condition is normal. The print carriage line is red; the feed/collect material line is blue.



3.4.4.6 Aux Tab

Control

- Measure media before starting:**
Measure material to identify edge when starting the program
- Measure media before printing:**
Measure material before printing
- Cleaning before printing:**
Clean print heads when starting the program
- Enable cleaning in printing:**
Automatically wash during printing
- Enable purge ink in cleaning:**
Auto purge ink during cleaning
- Reset before printing:**
Reset the position before printing
- Enable drying:**
Set up drying after printing, or cancel auto-drying.
Control drying when not printing



Enable Footer:

Print footnote of image at the end of the job

- File Name:** Include file name in the footnote
- Size:** Include file size in the footnote
- Date:** Include print date in the footnote
- Comment:** Remarks made by the user
- Distance:** Distance between footnote and printed image
- Font:** Set the Font type of the footnote



Generate bitmap of per head:

Select this item while printing and you get bitmaps of every pass of memory. Bitmaps are in the folder 'D:\Bitmaps'

Color Switch:

Enable the printing colors that you check marked

Feather pass edge:

Check mark 'Enable Feather' if desired

Temperature:

Critical:

Select print head heating temperature

Range:

Select heating temperature area

3.4.4.7 Engineer Tab

Buffer distance (dot):

The distance the print carriage moves to print; the measurement is in dots

Light sensor distance:

The distance from the edge position (light sensor) to the right print head

Material Left:

Default distance between the left edge of the material and the zero point

Material Width:

The printer breadth

Wash Mode:

When "1", the cleaning system and liquid protection system are available; when "0", only cleaning is available

Wash Position:

When the carriage is cleaning, the parameter is "1", the cleaning system is not available, the parameter is "0", the cleaning is available, the carriage cleaning position is zero

Wash width:

The moving distance of the print head during cleaning; the parameter is "1", the cleaning system is not available, the carriage does not move

Print speed of Y:

Feed speed in printing


Max move length:

Maximum movement of the print carriage

Move property:

Defines movement speed. Hardware speed pulse value can be set according to every defined speed. The bigger the value, the lower the speed, the smaller the value, the faster the speed.

Modifying the system configuration requires



proper authorization. Therefore, one must first insert the proper password using the process explained below:


Click the Engineer Tab and the Engineer Login password dialog appears as shown below:



The default password is 'TW'. Click the >> button to change the password. After entering the correct password, click the Login button.

When you click the Move property button, the Speed Table dialog for setting moving parameters appears as shown below:

- X speed:** Set the carriage speed
- Y speed:** Set the step speed
- X Convert:** Moving carriage for convert direction
- Y Convert:** Moving feed-roller for convert direction
- LR sensor convert:** Check LSN and LSP in software.




Note: These parameters should only be modified by a qualified engineer.

3.4.5 Modify Parameters in Printing

This operation is used to offset the position of printed images in printing.

You can adjust any parameters on this page and use the 'Update' button to modify parameters online.



When you click the 'Update' button, the TeckwinPrint dialog appears to verify that you really want to modify the online parameters. If you click the left button, it updates the online parameters at the next pass. Click the right button if you do not want to update the online parameters.

3.4.6 Operation Introduction

3.4.6.1 Printing Document

Two options:

1. Choose the RIP file. Click the Open File button on the Toolbar to open the file. Now that the Start Print button is active, just click it to begin printing. The print parameters should be the same as last time. (Use default values for the first time printing).
2. Use the browse button on the operation panel to choose an RIP files folder.

When you select the folder and click the 'OK' button, it displays all the image files in that RIP folder on the bar of image list in main interface. Then you can select the image file to print.

3.4.6.2 Select Print Parameters



Print Mode: The mode for printing: 3 pass , Draft, Normal, Enhanced, Master and Ultra.

The ink quantity control 3, 4, 6, 8, 12, and 16 pass.

Print Speed: The speed of print head in printing can be modified online.

Print Color Bar: If it is selected, six color bars with colors of C, M, Y, K, LC, and LM will be printed on the blank margin of printed image.

The Print Color Bar can also prevent the nozzle from being clogged. If the printed image only displays part of six colors, the Print Color Bar can greatly improve printing quality.

Pause to wash: The printing process may be paused at any time. Click the Wash Heads button on the Toolbar to wash the print heads, and then on the Print Continue button to resume the printing process.


Reset: Click the Reset button on the Toolbar to move the print head to zero position. Zero Pos is the position from limited switch to zero. The value should be set so that the first print head on the left of the print carriage is aligned with the left side of the cleaning device. Only in this position can all the print heads be cleaned thoroughly.

Measure material:

Use the edge identifier installed on the print carriage to measure the width and left edge of the material, then to define the printing area and to see if the material meets the requirement of the printing task. During measuring, the maximum movement of the print carriage is defined by Max Move Length in the parameter table. If both right and left edges are not found within this range, then edge checking fails. If the operation is successful, the actual left edge of the printed area is the edge of the material plus the margin. Usually, after having identified the right edge of the material, the print carriage will return to its zero position.

Cleaning Heads: two options

1. When the carriage is at the zero position, click the Wash Heads button on the Toolbar to wash the heads automatically. The moving length and the wash times can all be defined in the parameter table.



2. Click 'Turn on Cleaner' on the Tool menu to start cleaning. Click the Move Left and Move Right buttons on the Toolbar to move the print carriage left and right. After you have finished cleaning, click 'Turn off Cleaner' on the Tool menu.

Print head protection in printing:

Protect the print heads by choosing 'Automatic Wash' and 'Automatic FlashJet' during printing.



'Automatic Wash' and 'Automatic FlashJet' are available during printing. The configuration is as below:


Set the Wash period to wash the print heads after the specified number of times printing. Set the FlashJet period to execute an automatic FlashJet after the specified number of times printing. These two operations ensure that the ink supply is normal and that the nozzle is not clogged.

3.4.6.3 Parameters Export and Import

For different materials, printing parameters and especially step difference parameters may be very different. It is useful to store parameters in a backup file which can then be restored when the same material is used in printing again.

Click Option (O)/Export Parameter File to store the current printing parameters into a specified file. When clicked, it will popup a browse window. You can then select the exact location to store the backed up parameters.


Click Option/Import Parameter File to restore the specified parameter file. When clicked it will popup a browse window. You can then select the backed up parameter file with the proper parameters for the printing job you need to do.



3.4.6.4 Control of Printing Process

During the printing process, there is pause, continue and force to stop.

Modify the parameters of step difference, offset difference, color difference, print speed, feed speed and flash jet.




In the printing, click the Print Pause button on the Toolbar, the carriage moves to zero position after finishing the current PASS printing, waiting for the resume printing. Heads can be washed at this time. Click the Resume button on the Toolbar to continue the printing process. Click the stop button, the system will popup a message box to confirm whether to stop the current printing process or not.

Click "Ok" to terminate printing, or "cancel" to resume printing.

Note: Once the printing process is terminated, it can never be resumed.

If stop button is clicked on during batch printing, a message box asking whether to terminate all the printing tasks shall be popped up.

Click "Ok" to terminate all the print tasks.




Modify step value: If step difference is identified in the printing, should modify the value of step difference for corresponding PASS.

Modify color offset value: If every color offset is identified in the printing, you should modify the value of color offset.

Note: Value of step difference takes the unit of 1/10 dot.

3.4.6.5 Double-Side Printing

After one face is printed, print on the other face with mirror mode. In order to ensure that the images on both sides match with each other, stop the printing to adjust print position and Y-axis difference. Click the Modify Print Status button on Toolbar to modify print position.



3.4.6.6 Region Printing for Large Images

In region property page, we can choose 'Region Print' mode to print part of a large image. The region to be printed can be set through four parameters as shown below.

A screenshot of a 'Region' property page. It contains four input fields: 'Left' with the value '501', 'Top' with the value '1000 mm', 'Width' with the value '1001', and 'Height' with the value '950 mm'. The 'mm' unit is displayed to the right of the 'Top' and 'Height' fields.

Left: Set the left border of printing image.

Top: Set the top border of printing image.

Width: Set the width of printing image.

Height: Set the height of printing image.


3.4.6.7 Multi-file Printing

To support no gap multifile printing:



Select “Multi-file Print” in the “Print” menu, and a dialog box pops up.


Note: Request files width equality.



Edit printed files and hit “print” key, to start to print.

3.4.6.8 Web Printing


If RIP software request web printing, the operation software pop-up the below dialog box.




To replace printing parameter and hit "start print", or hit "cancel" key.

3.4.6.9 Restore Printing

To support restoring printing at the breaking print, or start print by the specified printing times.



Restore file: choose to renew the printing files and hit the below dialog box.




Restore position: to appoint to restorer printing position. If printing break suddenly, the default is the printing position that broken.

3.4.6.10 RIP EDIT

- ◆ Support multi roll and web printing.
- ◆ Support large sized pictures and multi file printing on wide media .
- ◆ Support auto edit function (arrange the files for printing effectively).



1. Hit "RIP EDIT" in the Toolbar and the following dialog box pops-up:



Function:



From left to right:

- New:** New a edit project (*.twp);
- Open:** open a edit project (*.twp);
- Save:** save an edited project (*.twp);
- Refresh:** refresh project ;
- Zoom in:** zoom in the view ;


- Fit view:** fit to view ;
- Zoom out:** zoom out view ;
- Material:** enact view ;
- Insert:** input the printing file ;
- Delete:** delete the printing file ;
- Print:** print edited file
- Restore:** restore edit window

Operate:

1. **Material:** enact material


Auto enact material amount and edge position by material sensor or manual enactment.

- Height:** edit high.
- Margin:** file margin on the material
- X Dis:** edit file transverse distance
- Y Dis:** edit file lengthways distance
- Overlap:** auto enact file overlap



2. **Input printed file**


a. Hit “insert” and from the following dialog box, choose RIP files.



b. Drag and drop files in the main dialog box.


3. **Print:** printed edit files. The following dialog box pops up.

- ◆ Choose TCP/IP for web printing.
- ◆ Choose “File” for making file print



If choose TCP/IP and pop-up the below dialog box, Enact IP address and hit “OK” key.

Note: IP address is the printer itself.



3.5 Error and Warning Codes

All the errors, warnings and notifications during software application shall be displayed in the popup message box.

Error information includes: the error occurring time, error code and caused reasons.

See the following chart as an example:




Please see the Appendix 1 for Error and warning codes

Chapter 4 Offset Adjustment for Print Heads

The Color Offset Adjustment consists of two parts. One part is for adjusting between the print heads jetting the same color ink; the other part is for adjusting between the print heads jetting the different color ink.

Adjusting the Y-Direction Color Offset between the print heads jetting the same color ink is achieved by adjusting mechanical position of the print heads. Furthermore, the optimal mechanical position of the print heads can be acquired by printing the calibration picture. The other color-offset adjustment must be accomplished by using the software.


The operation interface of the software is the following figure.



According to the following process go step by step.


4.1 Offset Adjustment for Print Heads Jetting the Same Color

Click the button “Advanced” to popup the dialog shown as below.



4.1.1 X-Direction Offset Adjustment

Click button “Left” to print the calibration picture. Shown as below.




Observe the vertical lines in red circles. Select the best superposition one. Add the figure of the best one to the Left direction offset parameter.

According to the above-mentioned method to adjust the Right direction offset parameters.


When all color-offset adjustment has been accomplished, click the button “OK” to apply the calibration. But if you click the button “Cancel”, the calibration result will be cancelled without saving.

4.1.2 Y-Direction Offset Adjustment

Click the button “Vertical” to print the calibration picture.




Good quality



Poor quality

Observe the calibration picture, and adjust the front-back position of print head by adjusting the screws on print head bracket. Make the calibration picture better quality.




Adjust the Back & Right orientation screw to set the front-back position of print head

Adjust the Left & Right orientation screw to set the right-and-left gradient position of print head.


4.2 Color Offset Adjustment

Click button “adjust”, will popup the dialog for the color offset adjustment. Shown as below.




4.2.1 Check Status of Print Heads

Click the button “Print Head Status” to print the status calibration picture of the print heads.



The status calibration picture can represent the status of every nozzle of print heads, and every line of the oblique line area corresponds to one nozzle of print head. If the oblique lines of the oblique line area are imperfect, this represents that the correspondent nozzles have been blocked and need cleaning.

4.2.2 Adjust the Step Difference



Print calibration chart by using different print mode to get different Y PASS step figure with each chart, make adjustment accordingly to reach the quality with no bifurcation. (When the figure is added or reduced 1 unit, then the step distance will be added or reduced to 0.003528mm)

Generally, first is to complete the adjustment of the Y Pass step by Test mode, if the printed charts are not in good continuum, it means the Y PASS Step is too big, then should reduce it; if the printed charts are overlapped, it means Y PASS Step is too small, then should add it. After finishing the Test mode adjustment, the Y PASS step figure of other print modes should be calculated according to the one of the Test mode, calculation method is as follows:

Draft mode = 3 pass mode / 4

Normal mode = 3 pass mode / 6



Enhanced mode = 3 pass mode / 8

Master mode = 3 pass mode / 12

Ultra mode = 3 pass mode / 16

4.2.3 X & Y Direction Color Offset (Color Offset)

Choose item “<-Left”, and click the button “Color Offset” to print calibration picture.




Adjusting method (Take example for Cyan color offset):


X offset: Choose a black vertical line overlapping with cyan vertical line. Read and add the number in the rectangular to its colors offset parameter.

Y offset: Choose a black horizontal line overlapping with cyan horizontal line. Read and add the number in the rectangular to its colors offset parameter.

4.2.4 Bi-Difference (Return Difference)




Amplify




Different carriage speed has different Bi-Difference parameter, so it is necessary to print the calibration picture under different print speed. When the upper black block and the lower black block are not in superposition, read the difference figure and correct the Bi-Difference with different carriage speed.


- ◆ When the upper block is at the right of the lower block. Add the read figure to original parameter.



- ◆ When the upper block is at the left of the lower block. Reduce the read figure to original parameter.



- ◆ How to mark Bi-difference (example)



From here we get first digit as 1

From the chart, get the result that Bi-difference need to be reduced as:

$$(1 \cdot 100) + (3 \cdot 10) + 1 = 13.$$

Chapter 5 Maintenance

5.1 Maintenance Specifications

Proper maintenance is crucial to the operation of the machine.

These maintenance specifications illustrate maintenance at different levels of detail. We suggest copying the specifications and pasting them on the printer or somewhere near it to enable them to be seen clearly by all operating personnel.

5.1.1 Preparations before Start

1. Check the printer input power.
2. Clean the print head, clean roller, and printing platform. Remove anything superfluous from the surface of the platform.
3. Check the liquid level of the first ink tank.
4. Switch on the general power supply, turn on the computer power, then the servo motor and then the heating.
5. Turn on emergency stop switches at both ends of the machine.
6. Check whether moving parts work normally, moving without blockage. After software starts, operate and check X-Axis, Y-Axis, cleaner, limited SWs, and emergency stops.
7. Tension value should be 55V; maximum is 70V.
8. Turn on the HV voltage SW, select the menu print/flash jet.
9. Check room temperature (20⁰C to 29⁰C) and humidity (40-80%).

5.1.2 Maintenance in Printing

1. Before printing, clean the print heads to enable smooth jetting. Clean print heads after finishing each job. (See cleaning method for print heads).
2. Check around the machine during normal printing:
 - a. There should be no irrelevant articles on the platform of the machine.
 - b. Touch the heating board with your hand to ensure heating temperature is normal. (Note: when moving the print carriage do *not* touch the pre-heating board with your hands).
 - c. Listen while the machine is printing. If you hear any strange sound, stop the machine and find out the reason.

- d. If there is any strange smell or you smell something burning, stop the machine and check it.
- e. Check operational parameters: tension, heating values.

5.1.3 Shut Down for Maintenance

1. Protect print heads (see Maintenance of Print Head).
2. Clean the printer with solvent. .
3. Push emergency stop SW.

5.1.3.1 Daily Maintenance

1. Check and empty the waste ink tank (located under the cleaning system.)

5.1.3.2 Weekly Maintenance

1. Dismantle carriage cover; use solvent to clean bottom of the cover.
2. Add lubricating grease to the rail, add oil to bell rail.
3. Set roller movement to 500mm before cleaning. Make sure feeding roller rotates freely, use special rubber roller solvent PMA to clean roller. When done, use dry air gun to blow dry.
4. Use PMA to clean dirt on the surface of roller, ensure there is no relative shift between material and roller and keep the roller clean.

5.1.3.3 Monthly Maintenance

1. Clean the second ink tank on carriage.
2. Check and tighten fixed bolts on transmission shaft coupling and motor shaft coupling
3. Check fixed screws of carriage and straight-line rail, check synchronous belt, if it is loosened, tight it up again.
4. Check 6 outer hex head screws of Y shaft coupling.
5. Check screws on Y-Axis plank.
6. Check clamping screws on X-Axis motor, screw down bolt in the hole of crust, then extend socket head screw into the hole, fasten the clamping bolt).
7. Check all cooling fans and motors.
8. Tidy up hard disk space of the computer, check for viruses.
9. Use air gun (air must be dry) to remove dust from the power supply box, electric control board, and various electric boards.

10. Use petroleum based lubricating grease to lubricate the carriage rail on the printer
Avoid dripping grease under the rail.
11. Use solvent to clean vacuum surface and movable contact face to ensure its flexible movement upward and downward.

5.1.3.4 Quarterly Maintenance

1. Check and test heater, 15 minutes after setting temperature, use temperature multi-meter to check whether temperatures on left, middle and right of preheating and drying heating system exceed 10°C or whether there is evident temperature difference by touch with hand.
2. Remove dust from the printer including inside of left and right boxes.
3. Replace ink filter.

5.1.3.5 Annual Maintenance

1. Level inspection of rail and printing platform (may contact our company).
2. Check entire machine for bolt loosening.

5.2 Maintenance of Print Head

5.2.1 Installation of Print Head

1. Remove the print head protector and use a one time syringe to inject solvent into the print head to clean it up. (Note: don't push the syringe in too much; better to see solvent being slowly exuded from the print head. If you push the syringe too much, the print head might be damaged, and this damage is irreversible).
2. Use two M3 x 10mm screws to affix the print head to the print head holder.
3. Insert the print head assembly (print head affixed to the print head holder in previous step) into the print head groove of the print carriage; use three M3 x 10mm screws to fix the print head holder in place.
4. Insert the ink tube and its protection at the interface and then connect the print head cable.

5.2.2 Disassembling Print Head

1. Switch off the HV power supply and power for ink supply control, then reduce the vacuum value to zero and remove all the ink.
2. Pull the ink tube out of the print head cable.
3. Remove screws and take the print head holder off the print carriage.
4. Remove the print head from the print head holder.

5. Inject solvent into the print head, clean the print head, and cover with the print head protector.

5.2.3 Basic Maintenance Knowledge of Print Head

- ◆ In normal operation, open print head protection function in software, If the printer does not work over 30 minutes, protect the print head with print head cover.
- ◆ Under normal cleaning conditions, if print head clog could not be eliminated, remove the print head and soak it in solvent.
- ◆ Before storing the print head, be sure to inject solvent into it for cleaning, install protector, seal the interface by rubber tube, then wrap it with clean paper and store it after sealing. If the print head is to be mailed, it should have anti-vibration packaging.
- ◆ If printer stops overnight without working, inject several syringes of solvent from top tube of print head. After cleaning, cover the print head again. Cover cleaning paper and protection film on the protection board and fill a little solvent into protection film.
- ◆ Always use solvent to clean where absorbed ink can be cleaned.

5.2.4 How to Fill the Print Head with Ink

After secondary tank is filled, ink pump will be stopped.

1. Connect the print head and the secondary tank with the ink tube.
2. First stop an ink tube, inject air to the secondary tank air hole by syringes, then the ink will fill into the print head from another ink tube.
3. After the air empties, change another tube.
4. Then fill ink into other print head one by one.

5.2.5 Cleaning Print Head during Working

- ◆ If the print head was found dry and clogged, you can use the way of ink filling to inject the ink to the print head to clean.
- ◆ If the print head still has problem after above, we can disconnect the interface in the ink tube and use the syringe with solvent to clean the print head, then connecting the interface of the tube and filling ink to the print head.

5.2.6 Protecting Print Heads during Work Stoppage (suitable for stoppage of several days)

1. Close computer and all power supply SWs.

2. After ink is completely discharged from each secondary tank, use syringe to inject solvent into tank from air hole on top of the tank, inject one syringe of solvent to every ink tank.
3. Place two or three cleaning paper with some solvent clouding, then use PE film and cover the print head.
4. Automatic cleaning function of print head:
 - a. Do not use unauthorized cleaning wiper to clean the surface of print heads.
 - b. To clean with the function of machine's own software.
 - c. You can choose automatic cleaning, or half-automatic cleaning and opening suction function, then move carriage left and right, clean the print heads one by one.
 - d. In printing process, set one cleaning after several automatic go and back working, generally we suggest to clean dark image once within 10 times and 30 times at the most for tint colors.

Keep the surface of the print heads humid with ink or solvent. The surface of a print head set must be protected by cellophane paper, film, or polythene packing material to prevent dryness. To prevent damage to the print heads as much as possible you must:

1. Only use authorized printing ink, solvent, and cleaning wiper.
2. Clean and package the print heads whenever printer idle time exceeds half an hour.

5.3 Ink Supply System Maintenance

5.3.1 Cleaning the Ink Supply System

- ◆ Discharge ink from the ink tank and fill it with solvent.
- ◆ Make printing ink flow out naturally without closing the power supply of the ink supply system until the ink discharged is mainly solvent.
- ◆ Turn on liquid protection in software.

5.3.2 Adding Ink

- ◆ Before the first adding of ink, use solvent to clean the ink tank.
- ◆ Keep the power supply of the ink supply system on, the same as when cleaning the ink supply system.
- ◆ Before connecting print head tubes, release some solvent at each outlet to ensure no residue is left in the tubes.

- ◆ Clean the inside of the print heads with solvent.
- ◆ Add ink in the tank to enable automatic continuous ink supply until ink substitutes for the solvent.

5.4 Considerations of Ink Usage

- ◆ Storage temperature of ink is 10-40°C.
- ◆ Do not shake ink tanks in process of storage and usage.
- ◆ Carefully read instructions before using ink.
- ◆ Treat waste ink according to local rules.
- ◆ Ink tank is not re-collectable.
- ◆ Emergency measures for ink touching:
 - Ink enters eyes, wash by using plenty of water.
 - Skin with ink: use soap and water to clean.
 - Eating ink by mistake will not lead to vomiting.

Chapter 6 Appendix

6.1 Error and Warning Codes of Control Software

Code	Comment
-1	Be printing!
-2	Rip file can't be read!
-3	The Liquid-Protected switch isn't normal
-5	Motor or Linear-Encoder isn't work!
-6	The phase of Linear-Encoder is reverse!
-19	Any image file can't be found!
-21	Footnote Error!
-31	Edge error: Edge sensor maybe damaged if not found materials!
-32	Only right edge is found!
-100	The value of one or more offset parameters is minus!
-101	The print position is out of border!
-102	The image width is larger than the maximum width of printer!
-103	Material width is too small!
-104	Material width is smaller than the left border value of material!
-105	Print speed is invalid!
-106	Margin value is minus!
-107	Group of print head is invalid!
-108	The emergency switch is pressed down!
-109	Invalid mode!
-110	The left value of selected area is out of border when Region printing!
-111	The width of selected area is out of border when Region printing!
-201	Print parameter is invalid!

-204	The operation of importing is invalid when printing!
-301	The rip file isn't supported!
-302:	The rip file can't be read!
-601	Busy, please retry later!
2	File can't be loaded!
11	Failed to create preview!
119	The configuration file of moving isn't exist!
999	Failed to create bitmap file, Access denied!
1002	Login information.
1009	The result about measure material.
-72	The Liquid Protected Device failed!
-73	The waste ink tank is overflow!
-74	The liquid protection device incurred unknown error! If you have fixed the faults, please click the button 'Retry' to continue to check! Or else, click the button 'Cancel' to end the current liquid protection!
-75	The cleaning device incurred unknown error! If you have fixed the faults, please click the button 'Retry' to continue check! Or else, click the button 'Cancel' to end the current washing!

6.2 Software Installation List

- ◆ Software installed in printer's PC
 - a. Operating system: WINDOWS XP
 - b. PCI Image card driver
 - c. Control software
- ◆ Installation CD in machine

Disk 1

Control software installation

Folder List:

Disk1:\ Installations>	Software installation
Disk1:\ Drivers>	Driver for PCI Image card
	Network card driver
	Display driver
Disk1:\ UserManuals>	User manuals








Disk 2


RIP software installation

Disk 3

Operating system: Windows XP with Microsoft license

6.3 Warning Signs

<p>Keep fingers out of machinery</p> 	<p>Watch out for fire</p> 
<p>Pay attention for safety</p> 	<p>Watch out for heat</p> 
<p>Watch out for electric shock</p> 	<p>Keep hands off</p> 
<p>No Touching</p> 	<p>No Rotating</p> 

<p>No Flame</p> 	<p>See manual before operating</p> 
---	---