



MDU



# BLOCK CUTTER 3

Block cutter for marble and granite

## User manual

Quality in Electronic  
Manufacturing

www.qem.it



<b>1. Information</b>	<b>3</b>
<b>2. Description</b>	<b>5</b>
<b>3. Wiring</b>	<b>6</b>
<b>4. HMI</b>	<b>14</b>
<b>5. Parameter insertion</b>	<b>18</b>
<b>6. Functioning</b>	<b>25</b>
<b>7. Appendix</b>	<b>37</b>
<b>8. Assistance</b>	<b>39</b>

<b>1. Information.....</b>	<b>3</b>
1.1 Symbols.....	3
1.2 Limited Warranty.....	3
1.3 Reference Manuals.....	3
1.4 Validity.....	4
<b>2. Description.....</b>	<b>5</b>
<b>3. Wiring.....</b>	<b>6</b>
3.1 Slot 3: H3-I17 card.....	7
3.2 Slot 4: H3-RV2 card.....	9
3.3 CNT1.....	11
3.4 CNT2.....	12
3.5 AN INP.....	13
<b>4. HMI.....</b>	<b>14</b>
4.1 Release message.....	14
4.2 Keyboard.....	14
4.3 User Led.....	15
4.4 Functions Led .....	15
4.5 Insert data.....	15
4.6 General using example.....	16
<b>5. Parameter insertion.....</b>	<b>18</b>
5.1 Generic Set up .....	18
5.2 Set up Cutting speed modulation.....	20
5.3 Z axis Set up .....	21
5.4 Y axis Set up.....	22
5.5 Set up asse X.....	24
<b>6. Functioning.....</b>	<b>25</b>
6.1 Immediate positioning to a quota.....	25
6.2 Semiautomatic.....	25
6.3 JOG stop on the self learnt quota.....	25
6.4 Maximum limit switch self learning of the Z axis.....	25
6.5 Cutting speed regulation in function of the disc.....	26
6.6 Limit switch (Granite cutting).....	26
6.7 Choice and program working.....	27
6.8 I/O diagnostics.....	36
6.9 Alarms .....	36
<b>7. Appendix.....</b>	<b>37</b>
7.1 Functioning examples.....	37
<b>8. Assistance.....</b>	<b>39</b>
8.1 Service.....	39
8.2 Sending.....	39

# 1. Information

Thanks for buying this QEM instruments. We'll be glad to receive any suggestion at our e-mail address [info@qem.it](mailto:info@qem.it).

## 1.1 Symbols



Not reading the message will be dangerous for the instruments integrity and/or for the success of the operation.



Note: Important information for the correct use of the instruments.



For more informations see the user manual indicated in the message.



For more informations see the indicated pages.

## 1.2 Limited Warranty

For two (2) years from the original acquisition, QEM will repair or replace for free controls and devices that QEM thinks be imperfect in materials or quality. This warranty is not valid if the object has not been tampered by not authorized persons or used in an inappropriate way.

This warranty replaces all other warranties either expressed or implicit.


QEM doesn't hold personally responsible for all charges (installation or uninstalling included), draw-back, or damage caused by our products, made or sold. In any case, QEM total duty, always will not exceed the control total price.

Claims for refunds of selling price, reparations, or replacements must be referred to QEM with all pertinent data (damage, purchase date, developed work and problem).





It is not provided any duty for batteries and fusible cut-out consumption.

The product must be returned only with a written notification, included the Number of Restitution Authorization QEM and must be paid all forwarding charges.

## 1.3 Reference Manuals

 - You should conserve all setting parameters and programming parameters in order to simplify the replacement and the service.

The documentation referred to the QEM instrumentation is divided in many issues that allows an easy utilization.

 MIM - Base	<b>MIM - Base: Installation and maintenance manual</b> Instrument hardware and software information
 MIM - Exp	<b>MIM - Exp: Expansions manual</b> Expansions hardware and software information.
 MDU	<b>MDU: User manual</b> User information on the software.
 MIMAT	<b>MIMAT: Service manual</b> Informations on: wiring, right calibration, parameters insertion and breakdown individuation.

It is possible to download manuals from [www.qem.it](http://www.qem.it)

## 1.4 Validity

The present document is fully valid excepted mistakes or omissions.

Manual Release	Description	Date
1.0	New manual	07/02/05
1.1	Inclined cutting function added	09/06/05
1.2	Manual new version	07/04/06
1.3	New contents	12/04/06
1.4	BLOCKUTTER 3.7 new function added	29/05/06
1.5	BLOCKUTTER 3.9 new function added	29/11/06
1.6	Modify the name of the card at page 7	04/05/07

### 1.4.1 Trade Marks

The copyright of this user manual is reserved. No one part of this document can be reproduced or copy without the QEM appointment. QEM doesn't present insurances or warranties on contents and declines all responsibilities on identity warranties. In this document, informations can be modified without any notice. QEM doesn't have any responsibility on this document.

Trade Marks:

- QEM® is a trade mark.

## 2. Description

The **BLOCKCUTTER03** software, installed on a micro Qmove D983 hardware, is realized to automatize a "block cutter" for marble or granite. It is possible to choose italian, english or portuguese language




Fig. 1: Block cutter machine with disc tool




Fig. 2: Block cutter machine with diamond wire

Possible workings are:

- unloader;
- shape copying (self learning) with photocell;
- shape executing;
- multiple shape executing;
- inclined cutting, automatic calculating Y axis forwarding (bridge) and Z axis (cutting depth).;
- diamond wire cutting;
- cutting of multiple blocks (max 10);
- square shaping executing with fresa or polisher.

Possible mode workings are:

- tool choice (disc or diamond wire)
- multiple cuttings;
- settle cutting;
- single cutting;
- many times cutting;
- bilateral cutting;
- pilot cutting;
- "left and right" independent regulation of the lowering disc;
- X self-learnt limit switches;
- dynamic X limit switches;
- cutting speed limitation referred to the disc current;
- the instrument handles three axis motion "X-Y-Z" with only an inverter;
- cutting speed settings;
- The instrument signals anomalies with allarms (stop the machine) and messages in order to facilitate the individuation;
- the instrument handle 3 axis with only 2 counters inputs. Z axis counter is always connected. For X and Y it is used an automatic change handling.

Settings, signals, allarms:

- Direction of the last cut setting;
- Height of the last cut setting;
- Cutting speed settings and independent return;
- The instrument signals anomalies with messages and allarms in order to facilitate the individuation;
- I/O diagnostic.

# 3. Wiring




Fig. 3: Front view





Fig. 4: Back view



For further information about cut-outs please read the D983 MIM-BASE.

### 3.1 Slot 3: L3-I17 card



Clip	Name	Logic activ. state	Contact	Activ. modality	Input	Description	
1	+ 12 Vdc	-	-	-	-	Out 12 Vdc	
2	0 V	-	-	-	-		
3	I0	ON	NO	C	-	Wire stretch mode OK (pag. 34)	
4	PL I0	-	-	-	-	Polarizer I0	
5	I1	OFF	NC	C	PNP	Forward	Limit switch X
6	I2	OFF	NC	C	PNP	Backward	
7	I3	OFF	NC	C	PNP	Forward	Limit switch Y
8	I4	OFF	NC	C	PNP	Backward	
9	I5	OFF	NC	C	PNP	Fall	Limit switch Z
10	I6	OFF	NC	C	PNP	Rise	
11	I7	OFF	NC	C	PNP	Automatic accord	
12	I8	OFF	NC	C	PNP	Emergency	
13	I9	ON	NO	I	PNP	Forward	Jog X
14	I10	ON	NO	I	PNP	Backward	
15	I11	ON	NO	I	PNP	Forward	Jog Y
16	I12	ON	NO	I	PNP	Backward	
17	I13	ON	NO	I	PNP	Fall	Jog Z
18	I14	ON	NO	I	PNP	Rise	
19	I15	OFF	NC	C	PNP	Unloader out of size (pag. 29)	
20	I16	ON	NO	C	PNP	Fast	Jog Speed selector
		OFF	NO	C	PNP	Slow	


**I0:** interrupt input  
**PL I0:** I0 interrupt input polarizer  
**Ix:** digital inputs

**Logic activation state:** ON = activated on close contact;  
 OFF = activated on a open contact.

**Activation Modality:** I = pulsing signal;  
 C = continuous signal.

**Contact type:** NC = normally closed;  
 NO = normally open.

**Inputs:** PNP = positive (12-24 V);  
 NPN / Push-Pull = negative (12-24 V)




CBL\_BLOCKCUTTER3\_0.cdr

Fig. 5: Wiring example Slot 3: L3-I17 card



## 3.2 Slot 4: H3-RV2 card




Clip	Name	Logic activ. state	Contact	Description
1	G AO	-	-	Common AO 1 ÷ AO 2
2	AO 1	-	-	X, Y
3	AO 2	-	-	Z
4	-	-	-	-
5	COM 1	-	-	Common O1 ÷ O8
6	O1	ON	NO	Y
		OFF	NO	X
7	O2	ON	NO	Automatic cycle
8	O3	OFF	NC	Allarm Stop (pag. 36)
9	O4	ON / OFF	NO	Out lubrication
10	O5	ON	NO	End program
11	O6	ON / OFF	NO	Out alarm (pag. 36)
12	O7	ON	NO	Forward
13	O8	ON	NO	Backward
14	COM 2	-	-	Common O9 ÷ O16
15	O9	ON	NO	Fall
16	O10	ON	NO	Rise
17	O11	ON	NO	X
18	O12	ON	NO	Y
19	O13	ON	NO	Z
20	O14	ON	NO	Out unloader
21	O15	ON	NO	Copying (pag. 31)
22	O16	ON	NO	Slow command X, Y axis
23	COM 2	-	-	Common O9 ÷ O16

**AO x:** analogical outputs  
**G AO:** common analogical outputs  
**Ox:** digital outputs  
**COM x:** common digital outputs

**Logic activation state:** ON = activated on close contact;  
 OFF = activated on a open contact.


**Contact type:** NC = normally closed;  
 NO = normally open.



CBL\_BLOCKCUTTER3\_0.cdr


Fig. 6: Wiring example Slot 4: H3-RV2 card

### 3.3 CNT1



Clip	Name	Description
1	-	-
2	-	-
3	-	-
4	+ 12 Vdc	Out 12 Vdc
5	SCH	Shield
6	PHA	Encoder X / Y
7	PHB	
8	PHZ	
9	0 V	


**SCH:** shield  
**PHA:** Phase A encoder  
**PHB:** Phase B encoder  
**PHZ:** Z encoder



CBL\_BLOCKCUTTER3\_0.cdr

Fig. 7: Wiring example CNT1

### 3.4 CNT2



Clip	Name	Description
1	-	-
2	-	-
3	-	-
4	+ 12 Vdc	Out 12 Vdc
5	SCH	Shield
6	PHA	Encoder Z
7	PHB	
8	PHZ	Photocell
9	0 V	-

**SCH:** shield  
**PHA:** encoder Phase A  
**PHB:** encoder Phase B  
**PHZ:** Z encoder




Fig. 8: Wiring example CNT2

### 3.5 AN INP



Clip	Name	Description	
		<i>Parameter insertion (set up) – Generic Set up - Lim vel. X (pag.19)</i>	
		0	1
1	AI 1	Speed Forward X axis	Speed Forward/Backward X axis
2	G AI	0 V	
3	-	-	
4	G AI	0 V	
5	+ 5 V	OUT 5 V	
		<i>Parameter insertion (set up) – Generic Set up - Lim vel. X (pag.19)</i>	
		0	1
6	AI 2	Speed Backward X axis	Drive blade current
7	G AI	0 V	
8	-	-	
9	-	-	

AI x: analogical inputs  
 G AI: 0V analogical inputs




Fig. 9: Wiring example AN INP

# 4. HMI

## 4.1 Release message









Fig. 10: Release message

## 4.2 Keyboard

Key	Descriptions
	Set up axis (pag. 18)
	Access data insert
	Access to HELP page
	I/O diagnostics
	Semiautomatic (led on) Manual (led off)
	Automatic (led on) Manual (led off)
	Stop Start
	Restart
	Reset axis

## 4.3 User Led

Led	Description
 (F5)	Semiautomatic (led on) Manual (led off)
 (F6)	Automatic (led on) Manual (led off)
 (F7)	Automatic Cycle on (led on)
 (F8)	Instrument to RESTART (led on)
 (F9)	RESTART done (led on)


## 4.4 Functions Led



See manual MIM-BASE D983


## 4.5 Insert data

Insert data example.




# 4.6 General using example

## Principal pages








# 5. Parameter insertion

In order to enter in the set-up area:



## 5.1 Generic Set up

```

    GENERIC SETUP
    Lang. 9ITA Default9
    Working set 9999999
    Decimal number 9
  
```

Parameter	Range	Description
Lang.	1,2, 3	1: italian, 2: english, 3: portuguese.
Default	0 ÷ 1	To restore default data: - set this parameter to 0; - switch off then on the instrument.
Working set	XXXXXX (Es. 1 0 1 0 1 0 1).	0 = working ok 1 = working off. Working type: - Square - Multiblock saw - Wire cutting - Slanting disc cutting - Copying - Horizontal cutting - Vertical cutting
Decimal number	0÷2	Number of decimal numbers.

```


    T Lubr. ON 9999999
    T Lubr. OFF 9999999
    X encoder 9
    T end Progr 9999999
  
```

Parameter	Range	Description
T lubr. ON	0 ÷ 99999.999 (sec.)	Time on
T lubr. OFF	0 ÷ 99999.999 (sec.)	Time off
X encoder	0 ÷ 1	0: handled by an encoder 1: not handled by an encoder
T end prog	-99999 ÷ 99999	End of program output activation timer (O5) < 0: the output remain enabled until a restart 0: activation for one second > 0: activation for a set time

```
Z axis movement 9
X vel. lim.      9
Dynamic LS      9
T esc. block    999999
```

Parameter	Range	Description
Z axis movement	0 ÷ 2	Z and X axis motion during the incremental cutting <b>0:</b> X axis moves after the Z axis lowering <b>1:</b> X axis moves simultaneously with Z axis lowering <b>2:</b> Z axis begins the lowering when X axis enter the slow-down
X vel. Lim.	0 ÷ 1	Automatic limitation X axis speed <b>0:</b> Off; <b>1:</b> regulation inversely proportional to the disc motor current
Dynamic LS	0 ÷ 1	In order to use this function enable Lim. Vel. X parameter <b>0:</b> OFF <b>1:</b> ON
T. esc. block	0 ÷ 99,999	Time between blade exit from the block and the next axis movement (with Dynamic LS = 1)

```
Incl. saw ref. 9
Y reset        9
Z encoder      9
Tool           9
```

Parameter	Range	Description
Incl. Saw ref.	0 ÷ 1	Blade inclination:  <b>0:</b> Inclination with horizontal reference  <b>1:</b> Inclination with vertical reference  
Y reset	0 ÷ 1	Reset Y axis at the end of the semi-automatic movement <b>0:</b> OFF <b>1:</b> ON
Z encoder	0 ÷ 2	<b>0:</b> Z axis management to encoder. <b>1:</b> Z axis management to time (with parameters "Spazio 1s Z"). <b>2:</b> Z axis management to limit witch.
Tool	0 ÷ 1	<b>0:</b> DISC tool <b>1:</b> WIRE tool

```

Wait wire T  9999999
Tens. time  9999999
Shift min   9999999
Ctrl time   9999999

```

Parameter	Range	Description
Wait wire T	0 ÷ 999.999 (sec.)	Axis stop time between two movements in "Wire cutting "
Tens. time	0 ÷ 999.999 (sec.)	Axis stop time for "low wire tension"
Shift Min,	0 ÷ 9999999 (Um)	Minimum movement value to do in "TCtrl" for the encoder breaking check
Ctrl time	0 ÷ 9999999 (ms)	Time to execute the minimum movement "Min mov." for the encoder breaking check

```

T Inv. X     9999999
T filter X-  9999999
T filter X+  9999999
Auto Y mode  9

```

Parameter	Range	Description
T Inv X	0 ÷ 999.999 (sec.)	Timer with no LS control after X axis movement inversion.
T filter X-	0 ÷ 999.999 (sec.)	Filter time for X axis backward LS (I2)
T filter X+	0 ÷ 999.999 (sec.)	Filter time for X axis forward LS (I1)
Auto Y mode	0 ÷ 1	Reset Y axis at the end of the automatic movement 0: OFF 1: ON

## 5.2 Set up Cutting speed modulation

```

VEL. LIM. SETUP
ES I of TA  9999999
ES V of TA  9999999
SS V of TA  9999999

```

Parameter	Range	Description	
ES I of TA	0 ÷ 999.99	Max power data	Transformer Ammeter
ES V of TA	0 ÷ 999.99	Max voltage data	
SS V of TA	0 ÷ 999.99	Min voltage data	

```

CNMD        9999999
NPC         9
RC time     9999999

```

Parameter	Range	Description
CNMD	0 ÷ 999.99	Motor disc nominal power
NPC	1 ÷ 9	Number of turn twisted on Transformer Ammeter
RC time	0 ÷ 32767 (tipico 150 ms)	Higher is this value bigger is the filter on the reading the disc current (AI 2)

## 5.3 Z axis Set up

```
Z AXIS SETUP
Res.measureZ 9999999
Res. pulseZ 9999999
Slow Z 9999999
```

Parameter	Range	Description
Z resolution	1 ÷ 999999	<b>MEASURE.</b> It indicates the axis covered space to obtain the set encoder impulses in the Pulse parameter.
	1 ÷ 999999	<b>PULSE.</b> It indicates the encoder impulses ( x 4 times) to obtain the set space in the Measure parameter.
Slow Z	0 ÷ 9999 (Um)	Slow-down axis space.

```
T slow Z 9999999
Inertia mode Z 9
Forw.iner.Z 9999999
Back.iner.Z 9999999
```

Parameter	Range	Description
T slow Z	0 ÷ 999 (ms)	Deactivation motion outputs time at the speed changing. To command the axis with teleruptors, set 50 this parameter, if not set zero.
Inertia mode Z	0,1	Validate inertia recalculation <b>0:</b> OFF <b>1:</b> ON
Forw. iner. Z	0 ÷ 9999 (Um)	Forward inertia
Back iner. Z	0 ÷ 9999 (Um)	Backward inertia

Z axis

```
OverPos.Z 9999999
Z toler. 9999999
Z max.tol. 9999999
Backlash mode Z 9
```

Parameter	Range	Description
Oltrpos. Z	0 ÷ 9999 (Um)	If "recovering play clearance" is not zero, the axis continues his movement over target-quota for a value equal to the set value. It inverts the movements and positions on a target quota.
Z toler.	± 999.9 (Um)	Space within the axis is in tolerance. Out of this space an alarm is not generated
Z max. tol.	± 999.9 (Um)	Space within the axis is in tolerance. Out of this space an alarm is not generated
Back lash mode Z	0, 1, 2	<b>0:</b> without recovery play, <b>1:</b> Forward recovery play, <b>2:</b> Backward recovery play.

```

Reasc. dis. IP    9
No raise Z       9
T dis. Z        9999999
1s Z shift      9999999

```

Parameter	Range	Description
Reasc. Dis. IP	0 ÷ 1	Disable the axis rising at the beginning of the working <b>0</b> : re-rise to "0" <b>1</b> : not re-rise to "0"
No raise Z	0 ÷ 1	Disable the axis rising at the end of the working <b>0</b> : re-rise to "0" <b>1</b> : not re-rise to "0"
T dis. Z	0 ÷ 9999 (sec.)	Time between axis stop and motion outputs deactivation and position transducer reading
1s Z shift	0 ÷ 999999 (Um)	Space covered in a second It is used when "Encoder Z"=1 It allows to estimate the activation time of the last "Lowering Z axis" (O9)

```

Z reascent      9999999
Inv T Z         9999999

```

Parameter	Range	Description
Z reascent	0 ÷ 999999 (Um)	Rising space Z axis after the marble cutting and before the Y axis movement.
Inv T Z	0 ÷ 9999.99	Minimum time between Z axis movement in a direction and the next in the opposite direction.

## 5.4 Y axis Set up

```

Y AXIS SETUP
Res.measureY 9999999
Res. pulseY  9999999
Slow Y       9999999

```

Parameter	Range	Description
Y resolution	1 ÷ 999999	<b>MEASURE.</b> It indicates the axis covered space to obtain the set encoder impulses in the Pulse parameter.
	1 ÷ 999999	<b>PULSE.</b> It indicates the encoder impulses ( x 4 times) to obtain the set space in the Measure parameter.
Slow Y	0 ÷ 9999 (Um)	Slow-down axis space.

```
T slow Y 9999999
Inertia mode Y 9
Forw.iner.Y 9999999
Back.iner.Y 9999999
```

Parameter	Range	Description
T slow Y	0 ÷ 999 (ms)	Deactivation motion outputs time at the speed changing. To command the axis with teleruptors, set 50 this parameter, if not set zero.
Inertia mode Y	0,1	Validate inertia recalculation 0: OFF 1: ON
Forw. Iner. Y	0 ÷ 9999 (Um)	Forward inertia
Back iner. Y	0 ÷ 9999 (Um)	Backward inertia

Y axis

```
Overpos.Y 9999999
Y toler. 9999999
Y max.tol. 9999999
Backlash mode Y 9
```

Parameter	Range	Description
Overpos. Y	0 ÷ 9999 (Um)	If "recovering play clearance" is not zero, the axis continues his movement over target-quota for a value equal to the set value. It inverts the movements and positions on a target quota.
Y toler.	± 999.9 (Um)	Space within the axis is in tolerance. Out of this space an alarm is not generated
Y max. tol.	± 999.9 (Um)	Space within the axis is in tolerance. Out of this space an alarm is not generated
Backlash mode Y	0, 1, 2	0: without recovery play, 1: Forward recovery play, 2: Backward recovery play.

```
Inv T Y 9999999
T enab. Y 9999999
T dis. Y 9999999
```

Parameter	Range	Description
Inv T Y	0 ÷ 999.99 (sec.)	Minimum time between Y axis movement in a direction and the next in the opposite direction.
T enab. Y	0 ÷ 9999 (ms)	Time between axis enable and motion outputs are on and position transducer reading.
T dis. Y	0 ÷ 9999 (ms)	Time between axis stop and motion outputs deactivation and position transducer reading

## 5.5 Set up axis X

```

SETUP ASSE X
Ris.measureX 9999999
Ris. pulseX 9999999
Rallentam.X 9999999

```

Parameter	Range	Description
X resolution	1 ÷ 999999	<b>MEASURE.</b> It indicates the axis covered space to obtain the set encoder impulses in the Pulse parameter.
	1 ÷ 999999	<b>PULSE.</b> It indicates the encoder impulses ( x 4 times) to obtain the set space in the Measure parameter.
X slow-down	0 ÷ 9999 (Um)	Slow-down axis space.

```

T slow X 9999999
Inertia mode X 9
Forw.iner.X 9999999
Back.iner.X 9999999

```

Parameter	Range	Description
T slow X	0 ÷ 999 (ms)	Deactivation motion outputs time at the speed changing. To command the axis with teleruptors, set 50 this parameter, if not set zero.
Inertia mode X	0,1	Validate inertia recalculation <b>0:</b> OFF <b>1:</b> ON
Forw. Iner. X	0 ÷ 9999 (Um)	Forward inertia
Back. iners. X	0 ÷ 9999 (Um)	Backward inertia

Xaxis

```

MovMan X 9
X toler. 9999999
T enab. X 9999999
T dis. X 9999999

```


Parameter	Range	Description
MovMan X	0 ÷ 1	X axis manual movement. <b>0:</b> start on the advancing face and stop on the JOG inputs retreating face <b>1:</b> Start on the advancing face and stop on the next advancing JOG input (SET/RESET)  If this parameter is =1 it will be set a 500ms timer to avoid the axis starting
X tiler.	± 999.9 (Um)	Space within the axis is in tolerance. Out of this space an alarm is not generated
T enab. X	0 ÷ 9999 (ms)	Time between axis enable and motion outputs are on and position transducer reading.
T dis. X	0 ÷ 9999 (ms)	Time between axis stop and motion outputs deactivation and position transducer reading



# 6. Functioning


## 6.1 Immediate positioning to a quota.

Quota insertion for immediate positioning




## 6.2 Semiautomatic

### 6.2.1 Positioning to a quota and cut



At the end of the positioning, cut starts. X axis move on the forward LS (I1), then come back to backward LS (I2).


### 6.2.2 Single cut




On activating I9 (Jog forward X) a single cut starts.

## 6.3 JOG stop on the self learnt quota

To enable or to disable virtual limit switches follow the instructions:





## 6.4 Maximum limit switch self learning of the Z axis



## 6.5 Cutting speed regulation in function of the disc.

Setting table for cutting speed (% data) in function of the disc motor current (% data).




Enable to Set up "Lim. Vel X = 1" (pag. 19)


Insert the value on Set up "Limit cutting speed" (pag. 20)

## 6.6 Limit switch (Granite cutting)


The dynamic limit switches are virtual limit switches that the instrument calculate in function of the disc motor current. When the blade exits from the block, the current decreases, in that moment will be added a space before execute a lower- ing movement of the Z axis and then reversing the X axis in order to have another cut.

The calculation is done respecting cutting parameters:




 To enable dynamic limit switches it is necessary to set to 1 parameters "Kim. speed X" and "Dynamic Limit switches". (see on **Generic set up** pag. 18).

- (1) Driving absorption
- (2) Control line
- (3) Vacuum absorption
- (4) length cutting



## 6.7 Choice and program working

### 6.7.1 Vertical cutting



At the end of each cut, it is activated OUT unloader (O14) that will be activated until the intervention of the Unloader out of the working area input (I15).



Limit switches positions self-learning, before X axis working starting



In order to insert the end of program, digit "pieces number = 0"




Before the starting, the X axis has to be on the left of the block (in is necessary that the minimum limit switch is pushed)



In order to disable the pilot cutting, it is necessary put to 0 the "pilot cutting depth" parameter.


### 6.7.1.1 Example

Vertical cutting			
Step number	1	2	3
Pieces number	2	3	0
Width	20.0mm	8.0mm	0



- 1 = Going/Return blade
- 2 = Cutting width
- 3 = Marble / Granite

## 6.7.2 Horizontal cutting



At the end of each cut, it is activated OUT unloader (O14) that will be activated until the intervention of the Unloader out of the working area input (I15).



Limit switches positions self-learning, before X axis working starting




In order to insert the end of program, digit "pieces number = 0"




Before the starting, the X axis has to be on the left of the block (in is necessary that the minimum limit switch is pushed)

### 6.7.2.1 Example

Horizontal cutting		
Step number	1	2
Pieces number	3	0
Width	20.0mm	0



### 6.7.3 Slanting disc cutting



Limit switches positions self-learning, before X axis working starting



In order to insert the end of program, digit "pieces number = 0"




Before the starting, the X axis has to be on the left of the block (in is necessary that the minimum limit switch is pushed)

Depth type		Thickness type	
0	1	0	1

## 6.7.4 Shape acquisition (Copying)

This procedure allows to acquire a shape with a photocell installed on the Z axis.



**Principal pages**

Pg Dn

Pg Up

```

Copying          1
SHAPE SELF-L.
Marble/Gran. (0/1) 9
Delta Y          9999999

Copying          2
Delta Z ris. 9999999
Bil.cut (0:→ 1:→)99
En. UP Z        9
        
```

▶

0: single cutting (marble),  
1: multiple cutting (granite).

Y axis quota shift (Um)

Z axis rise after every acquisition (Um)

0: From left to right cutting,  
1: From left to right and left to right cutting.

0: Z axis not rise to "0" when the cutting end  
1: Z axis rise to "0" when the cutting end

At the end of the acquisition, quotas are normalized to a minimum zero value and all the other values positive. The display visualize:

**Principal pages**

END OF COPYING OR  
OPERATION ERROR  
  
ENTER TO EXIT

←

Conditions of correct acquiring ending	Conditions of not correct acquiring ending
-Z axis limit switch occupation during the descent - STOP command and RESTART after	- Y axis limit switch occupation during to forwarding - 1000 points are end.

### 6.7.4.1 Shape self-learning (COPY)

#### Preparation

- 1) Set copying parameters;
- 2) Put X axis on out obstruction;
- 3) Position the photocell up on the shape;

#### Executing

- 4) Pull (Led ON = automatic) and after START .
- 5) The Z axis goes down moving the photocell downward;
- 6) The photocell intercepting the shape;
- 7) Acquisition counter to shape survey;
- 8) Stand out than Z axis and "Delta Z ris." quota;
- 9) Y axis shift of to "Delta Y";
- 10) If the photocell is:
  - ON =The Z axis goes up until the photocell OFF, restart to point n. 5;
  - OFF = restart to point n. 5.



### 6.7.1.1 Executing (CUT)

In order to start the working the operator has to reset the Z axis on the block upper face and put in in execution the self learned

#### Preparation

1) Put, on manual mode, X axis to Left of bloc;

#### Executing

- 2) Pull  (Led ON = automatic) and after ;
- 3) The Z axis goes to the sample depth ( or executes the passes cutting up to the sample depth);
- 4) Execute the cutting to the acquired quota;
- 5) Stand out than Z axis to "0" if "En. ris. Z" = 1 (pag. 31);
- 6) Y axis shift;
- 7) Cycle repetition to point n.3.



### 6.7.1.1 Immediate cut (COPY & CUT)

In order to start the working the operator has to reset the Z axis on the block upper face and put in in execution the self learned

#### Preparation

1) Put, on manual mode, X axis to Left of bloc;

#### Executing

- 2) Pull  (Led ON = automatic) and after ;
- 3) The Z axis goes down moving the photocell downward;
- 4) The photocell intercepting the shape;
- 5) Acquisition counter to shape survey and STOP to Z axis;
- 6) Re-positioning Z axis on the acquired quota;
- 7) Execute the cutting;
- 8) Stand out than Z axis to "0" if "En. ris. Z" = 1 (pag. 31);
- 9) Y axis shift;
- 10) Cycle repetition to point n.3.




## 6.7.1 Wire cutting



The parameter "Tool" must be 1.

Step (1÷ 30)  
after / precedent:



0: Y axis move;  
1: Z axis move.

Shift incremental axis quota (Um)


```
Saw by wire
Step number  ←99→
Axis (Y:0,Z:1)  9
Step lenght 99999999
```



To end program digit "Step lenght = 0".

### 6.7.1.1 Example

Wire cutting								
Step number	1	2	3	4	5	6	7	8
Axis	0	1	0	1	0	1	0	0
Step Length	40.0mm	20.0mm	40.0mm	20.0mm	40.0mm	20.0mm	180.0mm	0



If the wire is under a least tension for the block working (I0 = 0) the axis positioning or the automatic cycle starting is blocked and appears the signal on the main visualization:


```


Mis Cont T
→X 9999999 9999999
Y 9999999 9999999
ZS 9999999 9999999
```

The working re-starts automatically after setup timer expiration "T in Tens" from the re-activation of the I0 input.

## 6.7.2 Square


This working allows to execute a four-sided figure in the XY plane between the two LS of the X axis and an incremental quota of the Y axis.



 If the "Deepn. saw" parameter = 0, the automatic cycle, in the marble working, doesn't execute the axis moving to the program beginning.

### 6.7.2.1 Example

Square	
Deepn. saw	50.0 mm
Side	10.0 mm
Repetitions	10




If M/GR(0/1) = 0:

- The Z axis goes down to the 50.0 mm quota or up to the limit switch (I5);
- the X and Y axis perform so many squares how many the repetitions are "Repetition"


If M/GR(0/1) = 1:

- the X and Y axis execute a first square with a 0 depth;
- The Z axis executes a movement equal to the incremental left pass cutting and subsequently the X and the Y execute a square;
- The cycle is repeated up the 50.0 mm quota or up to the limit switch (I5).


 The working starting to the right limit switch of X axis (I2).

## 6.7.3 Multiblock saw

This working allows to execute multiple cutting programs on a max of 10 blocs.



It's possible to self-learn the START BLOC QUOTA by pressing



Limit switches positions self-learning, before X axis working starting



To end program insert "Piece number = 0".




The working starting to the right limit switch of X axis (I2)



To disable Pilot Saw insert 0 in the "Deepness pilot saw" parameter.

## 6.8 I/O diagnostics



## 6.9 Alarms

Message		Motive	Solution
End copy /Copy error		- End memory - Y axis on max limit switch. - Y axis on max limit switch.	- Upper the step of limit switches in use. - Check the limit switch;
Cutting on max limit switch		I1 = off on automatic cycle	Check the quota digit , transducer and connections.
Cutting on min limit switch		I2 = off on automatic cycle	
Bridge axis out of tolerance.		Y axis out of tolerance.	Check lock sistem and positioner speed is high.
Disc out of tolerance.		Z axis out of tolerance.	
FC Y forward		I3 = off on automatic cycle	Check the quota digit , transducer and connections.
FC Y behind		I4 = off on automatic cycle	
FC Z forward		I5 = off on automatic cycle	
FC Z behind		I6 = off on automatic cycle	
FC X fault		I1 = off I2 = off	Check the limit switch and connections.
Emergency		I8 = off	Check the emergency button, and emergency line connections.
No automatic consent		I7 = off on automatic cycle	Check the connections.
Breaking of X axis encoder		Are not detected at least 10 impulsed in 2 seconds of motion	There is a possible problem in the impulse detection or in the motion activation.
Breaking of Y axis encoder			
Breaking of Z axis encoder			

= The machine is not lock: O6 (out alarm) = slow lightning.


= The machine is lock: O3 (Stop for alarm) = OFF,  
O6 (Out alarm) = rapid lightning.

# 7. Appendix

## 7.1 Functioning examples

### 7.1.1 Multiplexer system diagram


The multiplexer system allows the movimentation of more than one axis with only a driver.  
The system handles automatically the teleruptors changing with right timing.



CBL\_AN001\_0.cdr

Enable AXIS 1: brake unblocking  
Enable AXIS 2: brake unblocking  
Enable AXIS 3: brake unblocking  
OUTPUTS common: analogical inputs common

## 7.1.2 Multiplexer encoder system diagram




\* = PNP inputs

CBL\_AN002\_0.cdr

## 7.1.3 Shape acquisition system diagram

### 7.1.3.1 If the photocell is installation on Z axis



# 8. Assistance

## 8.1 Service

In order to provide a quick service, we need your help.



a)

a) Follow all MIMAT indications ([www.qem.it](http://www.qem.it))



b)

b) If the problem persists, compile the fax inserted in the MIMAT manual and send to QEM.




c)

c) Our technicians will obtain necessary elements for understanding your problem.


## 8.2 Sending

It is recommended to pack properly the instrumentation.




a)

a) Use the original pack



b)

b) **Enclose:**  
- A problem description;  
- The part of the electric diagram where the instrument is inserted.  
- Instrument programming (set-up, working quotas, parameters...)  
- Request a reparation estimate; if not request, it will be calculated at the end.



c)

c) **An exhaustive description of the problem allows a quick individuation and resolution of the problem. A good pack will take care of your instrument.**

### Motivation

QEM informs the customers that instrumentation delivered not properly packed won't be repaired, except in case that the customer takes all the service responsibilities.

# Modulo per Assistenza Tecnica Module for Technical Service

Ditta / Firm : ..... Rif: .....

Indirizzo / Address: .....

Tel..... Fax.....

E – mail.....

**Codice strumento / Instrument Code** : .....

Alimentazione strumento / Power Supply: .....

Tipo di macchina / Machine type:

.....  
.....  
.....  
.....

Descrizione ciclo macchina / Cycle machine description:

.....  
.....  
.....  
.....

Parametri / Parameters:

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

Descrizione anomalia / Anomaly Description:

.....  
.....  
.....  
.....

Frequenza anomalia / Anomaly frequency :

- Continuo / Continuous
- Saltuario / Irregular
- Dopo un certo tempo / After a few time
- All'accensione / At the switching on
- Allo spegnimento / At the switching off
- Altro / Other: .....

.....  
.....  
.....

