


EDISecure®

XID 8300 Retransfer Printer

Instruction Manual



- Thank for purchasing this product.
- Please read this manual carefully before use to ensure correct operation. It is particularly important to read the Safety Precautions for safe operation. After reading, retain this manual carefully for future reference.
- The product number is important for quality control. Upon purchase, check the back of the unit to make sure that the product number is correctly displayed.

Notes about this manual

- (1) This manual may not be reprinted in any way without permission.
- (2) The contents of this manual, as well as the specifications and design of this product, may change without notice.
- (3) The illustrations used in this manual may differ slightly from the actual product.



About this Manual

- "Contents of this manual" A page 3
- "How to read this manual" A page 3

Precautions

- "Safety precautions" A page 3
- "Precautions during use" A page 4

Disclaimer

- "Disclaimer" A page 6

Name and functions of parts

- "Internal mechanism diagram" A page 6
- "Front" A page 7
- "Rear" A page 7
- "Right" A page 7
- "Left" A page 7
- "When printer door is open" A page 7
- "Ink ribbon cassette" A page 8
- "Retransfer film cassette" A page 8

Specifications

- "Main specifications" A page 9
- "Outline dimensional drawing" A page 9

Accessories/separately sold items

- "Accessories" A page 9
- "Sold separately" A page 9

Options

- "Functions" A page 10
- "Options" A page 10

Contents

Before Use

Contents	2
About this Manual	3
Precautions	3
Disclaimer	6
Name and functions of parts	6
Specifications	9
Accessories/separately sold items	9
Options	10

Operation

Operation Panel	10
Setting Mode	12
Setting Mode Flow	13
Setting using the operation panel	16
Printing a Card	25

Replacement

Precautions on cards	25
Ink Ribbon	26
Retransfer Film	29

Maintenance

Servicing of Parts	32
Servicing Based on Print Output	41

Troubleshooting?

When an Error Message is Displayed	41
Precautions on cards	43
Ink Ribbon	49
Retransfer Film	49
Unable to produce desired printing results	50
Printer not operating as desired	50
Before sending printer for repair	51

Setup


Installation and Connection	51
Printing Media	52
Printer and Computer Connection	56
Printer Setting	57
Operation Panel	57
Setting using the operation panel	57
List of Error Codes	58

About this Manual

Contents of this manual

- The copyright of this manual belongs to DIS. Reprint and duplicate of this manual in part or full without the prior consent of DIS is strictly prohibited.
- Windows is the registered trademark of Microsoft Corporation in the United States.
- Product names of other companies described in the manual are the trademarks or registered trademarks of the respective companies. Symbols such as E, T, and R are omitted in this manual.
- Designs, specifications, or other details described in this manual may be modified for improvement without prior notice.

How to read this manual



- Information in this frame is for reference purposes, such as information on functions and usage restrictions.



- Precautions are described in this frame.



- Click this frame to display the details page.



- Click this icon to return to the top page.



- Click this icon to open the PDF file for printing.
- The [Adobe Reader] application is needed to browse the PDF file.

Precautions

Safety precautions

- Please read through all the following items before using the printer.

Graphical symbols



■ If you ignore the warning with this mark, and handle the unit in a wrong way, death or serious injuries may occur.



■ If you ignore the caution with this mark, and handle the unit in a wrong way, injuries or damages to properties may occur.

Warnings



■ If the abnormal phenomena as listed below are seen, immediately stop operating the unit. Continuing operation may cause a fire or electric shock.

- Smoke or odd smell comes out from the machine.
 - Water or metal went into the machine.
 - The unit fell to the floor, or the cabinet was broken.
 - The power cable is damaged (exposed lead, broken cable, etc.)
- If you see these phenomena, turn off the power, pull out the power plug, and contact your dealer as soon as possible. Do not try to repair it by yourself. It is dangerous.

■ Do not remove the screws, or disassemble or alter the machine.

- High-voltage components are contained in the unit. Touching these areas may result in an electric shock.
- Ask your dealer if you want your printer inspected or repaired.
- Do not remove the external covers of the machine. You may get an electric shock.

■ Do not work on the power cable, or give excessive force on it. Do not put heavy objects such as furniture on the cable.

- The cable may be damaged, causing a fire or electric shock.
- When you find a defect on the power cable, such as exposed lead, stop using the unit, and consult your dealer.

■ Do not use the machine with the power plug inserted incompletely.

- The machine generates heat due to incomplete contact, causing a fire or electric shock.
- Do not put many cords on a single plug socket. The power cords also heats up.

■ Do not use the machine with dusts piled on the power plug. Do not put a metallic material adjacent to the power plug.

- Dusts and metal are conductive, causing a fire or electric shock.
- Pull out the power plug from the outlet every six months, and clean the dusts piled on the legs and body of the plug.

■ Do not use a line voltage other than instructed.

- Using a line voltage or power supply which is not specified may cause a fire or electric shock.

■ **Do not put foreign materials from the openings of the machine (e.g., vents, card slots, cassette inlet, etc.)**

- Metals, flammable things, and other foreign materials may cause a fire or electric shock if entering into the machine.
- If these things went into the machine, immediately turn off the power, pull out the power plug, and ask your dealer to repair. Do not try to repair it by yourself. It is dangerous.

■ **Do not put a container with liquid in it, or small metal ornaments and the like on the machine.**

- The liquid or metal entering into the machine acts as a conductor, causing a fire or electric shock.
- If liquid or metal went into the machine, immediately turn off the power, pull out the power plug, and ask your dealer to repair. Do not try to repair it by yourself. It is dangerous.

■ **Do not place the machine on a rickety table or slanting places.**

- The machine may fall out of the table or fall over, which may damage the machine or injure you.
- If the machine is damaged by falling or turnover, immediately turn off the power, pull out the power plug, and ask your dealer to repair. Do not try to repair it by yourself. It is dangerous.

■ **Do not wet the machine with water.**

- Using the machine at a place where water splashes on the machine, or wetting the machine with water (applying, throwing, or spilling water over the machine) may cause a fire or electric shock.
- If water entered into the machine, immediately turn off the power, pull out the power plug, and ask your dealer to repair. Do not try to repair it by yourself. It is dangerous.

■ **Do not touch the machine with wet hands.**

- Touching the machine with wet hands may cause an electric shock.

■ **Do not use the printer when cards are jammed inside.**

- Cards may not be discharged correctly such as when the retransfer setting for the card is inappropriate. Stop using and remove the jammed cards immediately. Otherwise, you may have problems removing the cards, and fire or electric shock may also occur as a result.

■ **Do not touch the power plug during electrical storms.**

- Lightning may cause an electric shock.

■ **Ground the machine with the attached electric cord when connecting it to the utility outlet.**

- Using a cord other than the one supplied for grounding may cause an electric shock when the machine fails.

■ **Do not put your head or yourself into the packaging bag**

- Do not play with the packaging bag. You may suffocate yourself.
- Give close attention to small children who may want to play with the packaging bag.

■ **Do not use the machine while it has a fault.**

- Do not use the machine while it has a fault, as this may cause a fire or electric shock.
- Immediately turn off the power, pull out the power plug, and ask your dealer to repair. Do not try to repair it by yourself. It is dangerous.

■ **For users of artificial cardiac pacemakers, keep a distance of at least 22 cm between the printer and the attached pacemaker.**

- Radio waves used by the RF-ID function inside the printer system may affect the operation of the cardiac pacemaker.

Caution



■ **Pull out the power plug before cleaning the machine.**

- This is for preventing electric shocks.

■ **Pull out the power plug when you won't use the machine for a prolonged period of time to assure safety.**

- Remove the power plug from the outlet for safety when you won't use the machine for a long time.

■ **Do not move the machine with the power cable and other electric cables connected.**

- The cables may be damaged while being moved, which may cause a fire or electric shock.
- You may stumble over the cable and get injured.

■ **Do not move the machine with objects placed on it.**

- They may fall on you and hurt you.

■ **Do not put heavy objects on the machine.**

- They may fall on you and hurt you.

■ **Do not block the vents.**

- Heat generated inside the machine cannot escape, which may cause a fire.

■ **Do not rest your body on the machine, or leave it suspended above the ground.**

- The machine may drop, causing damage or injury. Pay particular attention when there are young children around.

■ **Be sure to work with two persons when you unpack, move or lift the machine.**

- If you work alone, you may be injured by the fallen machine or hurt your back by lifting a heavy machine by yourself.

■ **Inspection**

- Ask your dealer or a qualified person to inspect the machine, typically once every two to three years. Operating the machine with dusts piling on the components for a prolonged period of time may cause a fire or a malfunction of the machine. It will be particularly effective to inspect the machine before wet rainy season. Consult your dealer on the costs of inspection.

■ **Do not place the machine in the following locations.**

- Doing so may cause fire or electric shock.
 - Places that are highly humid or dusty.
 - Places that are exposed to oily smoke or steam, such as near a cooking table or humidifier.
 - Places near a heating equipment.
 - Places that are subject to water droplet condensation, such as beside a window.
- Also, placing it at a place that is exposed to direct sunlight may result in deterioration of the cabinet.

■ **Hold the body of the power plug when pulling it out.**

- Do not pull out the plug by holding the cable. The cable may be broken or damaged which may in turn cause a fire or electric shock.

■ **Do not touch the power plug with a wet hand**

- You may get an electric shock.

■ **Do not lay the power cable near the heating equipment.**

- The covering of the cable will melt due to heat from such equipment, which may cause a fire or electric shock.

■ **The heat rollers and adjacent areas become hot during operation.**

- Be careful not to touch the heat rollers and adjacent areas when replacing the ink ribbon or retransfer film, or remove jammed cards.
- Wait until the heat rollers get cooled down to prevent burns.

■ **Be careful of jamming your hand or fingers in the card bracket of the hopper or printer door.**

- Remove cards from the card tray, or jammed cards and ink ribbon/retransfer film cassette with care not to jam your hand or fingers in the mechanism to prevent any injury.

■ **Do not use a power cable other than the specified cable for connection.**

- If you use an unspecified power cable for connection or extension, heat may accumulate in the cable, causing a fire.

Precautions during use

- Please read through all the following items before using the printer.

Handling instructions

- Pay careful attention of the following when handling a printing media (retansfer film or ink ribbon) or card.

- Using a deformed or scratched card may cause card feed errors.
- Touching the printing surface of the printing media or card directly with your hand may cause the print to turn out uneven.
- Foreign particles attached to the printed areas may result in printing voids. Attach the printing media in a clean environment.
- Use of electrically-charged printing media or cards may cause printing errors. Do not allow static to occur, such as due to cards rubbing against each other.
- When replacing or replenishing a printing media or card that is stored under a low temperature, use after leaving the media or card at the operating ambient temperature of the printer for at least one hour. Otherwise, condensation may occur, causing printing errors or malfunction of the printer.

Storage

Storage instructions

- The storage conditions of the printing media (retransfer film or ink ribbon) and card have a significant effect on the printing quality. Store the printing media or card in one of the following locations.

Storage environment

- Temperature: 5 °C to 25 °C
- Relative humidity: 40 % to 60 %

Storage location

Do not store the printing media or card in the following locations. Doing so may cause the media or card to deteriorate.

- Places exposed to direct sunlight.
- Places with a high humidity.
- Places near organic solvents or diazo copiers.

Storage period

- Use the printing media (retransfer film or ink ribbon) within half a year after purchase. For details on the cards, please consult our authorized dealers.

Printer Installation

- When the printer is not in use, it is recommended that you turn off the power, and cover it with a plastic sheet.
- Do not place the printer unit in the following locations. Doing so may have adverse effects on the printer.
 - Carpeted room.
 - Places with a busy flow of people.
 - Places where paper (corrugated boards, etc.) is handled or stored.
 - Places near photocopiers.
 - Places exposed to direct sunlight or near a heating equipment (such as a stove).
 - Inclined or unstable surfaces.
 - Places exposed directly to cold air, such as near an air-conditioner outlet, or places subject to high temperatures.

Precautions on retransfer films/ink ribbons

- Put on the supplied gloves when handling the retransfer film/ink ribbon. Direct contact of your hand with the printing surface may result in printing errors.

When retransfer film/ink ribbon is dismantled

- Winding misalignment may occur. If an improperly wound retransfer film/ink ribbon is installed, the resulting color may vary, or errors may occur.

When attaching the retransfer film/ink ribbon

- Use your hands to adjust the media at the supply and take-up sides so that they are parallel to each other. When doing so, make sure you do not touch the printing surface.
- Refer to the label adhered to the cassette for alignment of the screen position. Printing errors may occur if the position is not properly aligned.



Adjust the position with your hands so that the media position is parallel at the take-up and supply sides

During transport or moving

- Make sure to set to the transport mode. "Transport mode setting" (A page 24)

Precautions on cards

Handling and storage of cards after printing

Avoid storing cards at places that are exposed to direct sunlight or subject to high temperatures and humidity. Discoloration or fading may occur if a card comes into contact with the following chemicals or stationery.

- Organic solvents, including alcohol, film cleaner, or diazo copiers.
- Files, document cases, pass holders, or erasers made of flexible polyvinyl chloride.
- Hair wax or cosmetic products.

Card types

Thin cards and certain card materials may not be suitable for printing using this printer. For details on the card material to use and other specifications, please consult our authorized dealers in advance.

Note:

- If the card thickness is not properly adjusted, printing error or printer malfunction may occur. "Adjusting Card Thickness" (A page 55)

When a card is jammed inside the printer

Cards may not be discharged correctly such as when the retransfer setting for the card is inappropriate. Stop using and remove the jammed cards immediately. Otherwise, you may have problems removing the cards, and fire or electric shock may also occur as a result.

- When a card jam occurs, make use of the jog dial to remove the jam.
- If the card cannot be removed, consult a servicing personnel or our authorized dealers.

Disclaimer

Escape Clause

■ We do not provide compensation for any malfunction during card printing caused by breakdown of the machine, ink ribbon defects or card characteristics. In addition, we also do not provide compensation for insufficient print quality as a general rule. Please evaluate carefully beforehand.

■ Card Material

Some card material may not be suitable for printing. Using a contact-type IC card other than those specified by the dealer, may cause damage to the thermal head. No compensation is made for the life reduction and failures that were caused by unsuitable card material. Warp of card or uneven thickness of IC cards, even though they are within the tolerance of JIS or ISO standards, may not be suitable for printing or feeding. For details on the specifications about card material or others, consult the dealer in advance

■ Version upgrade


The following defects may occur as a result of the version upgrade for the firmware of the printer or for the printer driver.

- Card printing is disabled for the application software that has been used.
- The operation of the printer or application software becomes unstable.
- Defects in print result occurs.
- Print color or shade differs.
- The performance of reproducing fine letters, changes.
- Others

Be sure to retain a copy of the current version when performing version upgrade. Reinstall the previous version immediately if these problems occur. We are not liable for any damage such as defective cards or interruptions during printing as a result of the version upgrade.


Name and functions of parts

Internal mechanism diagram




- ① Card feeder unit
 - This is the roller for feeding cards. Each of the feed rollers needs to be cleaned daily.
- ② Warpage correction heating roller
 - Some types of cards may warp. Adjust accordingly until warpage is eliminated. Set using the host computer.
- ③ Retransfer heating roller
 - You can adjust the temperature and retransfer time for some retransfer films and cards. Set using the host computer.
- ④ Non-contact IC encoder
 - You can adjust the position to stop the card when a non-contact IC card is used. Set using the host computer.
- ⑤ Contact IC
 - You can adjust the position to stop the card when a contact IC card is used. Set using the host computer.
- ⑥ Magnetic encoder
 - You can select the coercivity when writing data to the magnetic stripe card. Set using the host computer.
- ⑦ Card turnover unit
 - Inverts the card.
- ⑧ Cleaning roller
 - Removes any dust or dirt attached to the card. The cleaning roller needs to be cleaned daily.
- ⑨ Card hopper
 - For loading cards.
- ⑩ Retransfer film (take-up side)
 - For attaching the take-up side of the retransfer film.
- ⑪ Retransfer film (supply side)
 - For attaching the unused side of the retransfer film.
- ⑫ Ink ribbon (take-up side)
 - For attaching the take-up side of the ink ribbon.
- ⑬ Thermal head
 - The thermal head is a consumable part. For details on its replacement, please consult our authorized dealers.
- ⑭ Ink ribbon (supply side)
 - For attaching the unused side of the ink ribbon.
- ⑮ NG card outlet
 - Discharges NG cards, such as during card jams.

Front




- ① Operation buttons
 - For selecting and confirming information on the operation panel.
- ② Operation panel
 - Displays menus and error messages.
- ③ Sliding knob
 - Opens/Closes the printer door.
 - Slide it upward, and pull toward you to open the printer door.
- ④ Card hopper
 - For loading cards.
- ⑤ Printer door
- ⑥ Power switch
 - Turns the power On/Off.

Rear




- ① USB cable connection terminal
 - For connecting a USB 2.0 interface cable.
- ② LAN cable connection terminal
 - For connecting an Ethernet interface cable.
- ③ Cable clamp
 - For securing the supplied USB cable.
- "Connection" (A page 56)
- ④ [AC INLET] power supply terminal
 - For connecting the power cord.

Right




- ① NG card outlet
 - If a card is left inside the printer when the power is turned on or re-set, the card will be automatically discharged.
 - Cards in the printer are discharged when an error occurs on the magnetic card or IC card.
- ② Air suction fan opening
 - This is the air inlet for the internal cooling fan.
- ③ Filter cover
 - This is the cover of the fan filter.
- ④ Security slot
 - For attaching the Kensington lock.

Left



- ① Card outlet
 - Outlet for discharging the cards.
- ② Card stacker (supplied) attachment slot
 - For attaching the supplied card stacker.

When printer door is open




- ① Cassette buttons
 - Press these buttons in order to pull out the ink ribbon cassette or re-transfer film cassette.
- ② Cleaning unit
 - Removes any dust or dirt attached to the card.
- ③ Ink ribbon cassette

Before Use


- For attaching the ink ribbon.
- ④ Jog dials
- When there is card jam in the cleaning unit, turnover unit, or retransfer unit, detach the jog dial from the printer body, and attach it accordingly to turn the rollers of the corresponding parts.
- ⑤ Retransfer film cassette
- For attaching the retransfer film.

Ink ribbon cassette



- ① Guide shaft
- Provides guide to the position for attaching the cassette.
- ② Shafts
- When attaching an ink ribbon, unwind it along the shafts.
- ③ Bobbin holder (black)
- For securing the take-up side of the ink ribbon.
- ④ Bobbin holder (yellow)
- For securing the unused side of the ink ribbon.

Retransfer film cassette




- ① Bobbin holder (black)
- For securing the take-up side of the retransfer film.
- ② Guide shaft
- Provides guide to the position for attaching the cassette.
- ③ Shafts
- When attaching a retransfer film, unwind it along the shafts.
- ④ Bobbin holder (green)
- For securing the unused side of the retransfer film.

Specifications

Main specifications

Item	Description
Recording system	Dye sublimation retransfer
Paper feed mode	Automatic
Recording density	300 dpi
Reproduction gradation	256 levels each for Y, M and C: 2 levels for Bk
Interface	USB 2.0 (Hi-Speed/Full-Speed)
Interface	Ethernet(100BASE-TX/10BASE-T)
Operating environment conditions	Temperature between 15 7C and 30 7C Temperature between 17 7C and 28 7C (When using peel-off ink)
Operating environment conditions	No condensation Humidity between 35 % and 70 % Humidity between 35 % and 60 % (When using peel-off ink)
Storage environment conditions	Temperature between -157C and 557C
Storage environment conditions	Humidity between 20 % and 80 %
Power supply	AC 100 V - 120 V/AC 220 V - 240 V(tolerance: $\leq 10\%$) 50 Hz/60 Hz ($\leq 5\%$)
Current consumption	3.5 A (100 V system)
Power consumption	310 W (max.)
Mass	(Standard) approx. 13.9 kg (excluding optional built-in items)
Dimensions (cm)	343 mm x 360 mm x 322 mm (W x H x D)

Outline dimensional drawing



Accessories/separately sold items

Accessories

Please check to ensure that the printer accessories are in place when unpacking the product package.

- CD-ROM x 1
- Getting started guide x 1
- Read Me First (LST1013) x 1
- Power Cord (2 m) x 2
- Cleaning Card x 1
- Card Stacker x 1
- USB 2.0 Cable: QAM1196 (2 m) x 1
- Gloves x 1 Pair

Products sold separately

To purchase these items, please consult our authorized dealers.

- Ink Ribbon (YMCK), 1,000 frames/roll (Model: DIC10216)

- Ink Ribbon (YMCKK), 750 frames/roll (Model: DIC10217)
- Ink Ribbon (YMCK-PO), 750 frames/roll (Model: DIC10218)
- Ink Ribbon (YMCK-UV), 750 frames/roll (Model: DIC10313)
- ART Retransfer Film, 1,000 frames/roll (Model: DIC10319)
- Cleaning Kit (Model: DIK10044)
Set incl. 10 print head cleaning swabs, 10 cleaning tissues for rollers and 10 special cleaning cards
- Magnetic Stripe Encoder Head Cleaning Cards (Model: DIC10311)
Box of 10 cards

Options

Functions

- **Double-sided printer**
Printer that supports double-sided printing.
- **Single-sided printer**
Printer that supports single-sided printing.

Options


- **Warpage correction**
Device for correcting card warpage after printing.
- **Magnetic encoder**
Device for writing data to a magnetic stripe card.
Installation is applicable only for double-sided printer.
- **Contact IC encoder**
Device for writing data to a contact IC card.
- **Non-contact IC encoder**
Device for writing data to a non-contact IC card.

Operating the printer

- "Operation Panel" A page 10
- "Setting using the operation panel" A page 16
- "Printing a Card" A page 25

Operation Panel

Name and functions of parts



- ① Operation panel
 - Displays the mode settings, operating status, and error messages.
- ② Status icon/operation button display
 - Displays the status icon or the function of the operation button during mode setting.
- ③ Operation buttons
 - For selecting the operation button displayed on the operation panel.

Operation buttons

Resets the printer.



- After clearing an error, press in the order of [Reset] **DB**.

Displays the setting mode mode.



Exits setting.



Displays the setting mode in the next lower level.



Confirms or executes a setting.



- The display does not change if an item cannot be altered using the operation panel.

Pressing it each time displays the next setting item.

Pressing it each time displays the next setting value.



Displays the settings change mode.



- If [Change] is not displayed for an item, you can adjust the settings on the status monitor of a PC.

Displays the scroll mode for the displayed characters.



Scrolls to the next displayed character on the left.



Scrolls to the next displayed character on the right.



Operation Panel Display

USB connection

- IP address established
Printer information can be viewed through the network. However, printing is performed through USB connection.



- IP address not established



Network connection

- IP address established



- IP address not established



Security status

- Locked




- Unlocked



Operation panel operation display

Starting up




Initializing




Preheating




Ready




Printing



Loading



Encoding




Adjusting heat roller to the preset temperature




Retransferring



Cleaning



Heater OFF



Setting Mode

- Settings can be viewed on the printer's operation panel.
 - Settings can be changed on the status monitor of the computer.
- "Setting using the operation panel" (A page 16)

Cleaning

- For setting during cleaning of the card feed roller or magnetic head.

Setting values

- Rollers

Select this value when cleaning the card feed roller.

- MG

Select this value when cleaning the magnetic head.

Counter Reset

- Resets the free counter and error counter.

Test Print

- Prints the printer's built-in test pattern, or the different setting values.
- When system troubles occur, printing can be performed using settings on the printer or computer by operating only the printer.

Setting values

- Test Print: Test Pattern, Printer Setting, Network, Lami Setting

Down load

- Updates the firmware.

Transport Mode

- For setting the transport mode.

Media

- Displays the settings of the printing media.

Setting values

- Ink Type: YMCK, YMCKPO, YMCKK, YMCKUV

Set according to the type of ink ribbon.

- Film Type: 1000, 750

Set according to the type of retransfer film.

- Card Thickness: Standard, Thin

Set according to the thickness of the card.

Standard: Supports card thickness of 0.76 mm

Thin: Supports card thickness of 0.25 mm

Print

- Displays the printing settings.

Setting values

- YMC Level: -3, -2, -1, 0, 1, 2, 3

For setting the YMC (color) concentration level.

Selecting a larger value increases the concentration level.

- Black Level: -3, -2, -1, 0, 1, 2, 3

For setting the K(Black) concentration level.

Selecting a larger value increases the concentration level.

- Black Mode: Standard, Fine

For setting the K(Black) printing mode.

If the characters still appear faded after raising the [BlackLevel], set to [Fine].

However, printing time required will be longer than the [Standard] setting.

- UV Level: -3, -2, -1, 0, 1, 2, 3

For setting the UV ink concentration level.

Selecting a larger value increases the concentration level.

During UV printing, card warpage may increase if the card has a low heat resistance or under an environment with high temperature.

- PO Level: -3, -2, -1, 0, 1, 2, 3

For setting the concentration level of the peel-off ink.

Selecting a larger value increases the concentration level.

Retransfer

- Displays the retransfer mode settings.

Setting values

- Temp Level: -2, -1, 0, 1, 2

For setting the retransfer roller temperature.

Selecting a larger value increases the temperature.

Retransfer may fail depending on the card used. If retransfer fails, raise the setting to the next higher value.

A higher retransfer roller temperature helps to enhance card retransfer, but the stronger heat may also cause the card to deform. If the printer is not initialized after changing the temperature setting, temperature is adjusted after the printing operation starts.

- Speed (Front): -3, -2, -1, 0, 1, 2

For setting the surface retransfer speed.

Selecting a larger value increases the speed.

Retransfer may not be successful for some parts of the card depending on the card used. Lowering the setting value helps to enhance retransfer, but the stronger heat may also cause the card to deform.

- Speed (Back): -3, -2, -1, 0, 1, 2

For setting the rear surface retransfer speed.

Selecting a larger value increases the speed.

Some types of cards may warp during double-sided printing. If card warpage occurs, raise the setting to the next higher value.

- MG Peel Mode: Standard, MG Stripe

For setting the method for peeling the retransfer film.

- Standby Mode: Front wait, Back wait

For setting the laminator standby position.

Select whether to standby at the front or rear surface during double-sided printing.

Bend Remedy

- Displays the warpage correction mode settings.

Setting values

- Temp Level: -5, -4, -3, -2, -1, 0, off

For setting the warpage correction roller temperature.

Selecting a larger value increases the temperature.

If the printer is not initialized after changing the temperature setting, temperature is adjusted after the printing operation starts.

- Speed: -2, -1, 0, 1, 2

For setting the warpage correction mode speed.

Selecting a larger value increases the speed.

Heat Roller

- Displays the settings of the power save mode or low temperature standby mode.

Setting values

- Power Saving: 5 mins, 10 mins, 15 mins, 20 mins, 25 mins, 30mins, 45 mins, 60 mins, off

For setting the time of the power save mode.

While in the [Ready] mode, if the printer is not operated during a specific time interval, the retransfer roller, warpage correction roller, and backlight of the operation panel are turned off to save power.

- HR Control: Off, On

For setting whether to standby the printer by lowering the retransfer heat roller temperature if cards are not issued for 30 minutes or longer.

The printer will automatically restored to the original mode during the next card issuance, but it may take a longer time before the first card is printed. Set this to On during normal use.

Setting

- Displays the printer settings.

Setting values

- **Display:**
Mode: Counter
Counter: Total Cnt, Head Cnt, Free Cnt, Cleaning Cnt, Error Cnt
Contrast: -3, -2, -1, 0, 1, 2, 3

For setting the display status the operation panel.

- **Buzzer:** On, Off

For setting whether to sound the buzzer when an error occurs or when settings are changed.

- **Unit No:** No.1 to No.10

For setting the printer's unit number according to the USB environment.

Option

- Displays the optional settings.

Setting values

- **MG:** None, ISO

Displays the availability of a magnetic encoder or the type of encoder used.

- **IC Antenna:** None, Installed

Displays the availability of a non-contact IC encoder.

- **IC Contact:** None, ISO Type

Displays the availability of a contact IC encoder or the type of encoder used.

- **Contact IC R/W:** None, Installed

Displays the availability of an IC contact.

- **Bend Remedy HR:** None, Installed

Displays the availability of a warpage correction heat roller.

- **Turn Over:** None, Installed

Displays the availability of retransfer unit.

MG

- Displays the coercivity settings.

Setting values

- **ISO Type:** Loco, Hico

For setting the coercivity when writing data to an ISO magnetic stripe card.

- **Retry Count:** 0, 1, 2, 3

For setting the number of retries during data writing.

Network

- Displays the network settings.

Setting values

- **Printer Name:** ASCII character strings (10 characters)

For setting the printer name.

- **Host IF:** LAN, USB

For setting the interface.

If the printer is connected via USB interface, the setting switches automatically to the USB setting even if it is set to LAN during initialization.

- **[@TREX[OSD::]IPv4:**
DHCP: On, Off
Setting: IP Address, Subnet Mask, Gateway
Effective IP: IP Address]

For setting IPv4.

- **[@TREX[OSD::]IPv6:**
Adrs Config: Auto, Manual
Setting: IP Address, Prefix Len, Gateway
Effective IP: IP Address1, IP Address2, IP Address3]

For setting IPv6.

- **Session Time Out:** Off, 10 mins, 20 mins, 30 mins, 60 mins

For setting the session timeout interval.

- **MAC Address:** Hexadecimal character strings

Displays the MAC address.

- **IP Sec Mode:** Off, On

For setting the availability of IP Sec.

- **IP Sec Type:** not Setting, Preshard, Certificate


Displays the method for IP Sec verification.

Setting Mode Flow

- Settings can be viewed on the printer's operation panel.
- Settings can be changed on the status monitor of the computer.


1 Press [Menu]

- A setting item appears.




2 Press [Next]

- Pressing it each time displays the next setting item.
- Pressing [Enter] or [Change] displays the setting value.
- Pressing [Next] or \blacktriangle displays the next setting value.
- Pressing [Exit] displays the setting mode of the next higher level.




Operation


>Counter Reset
OK?
Exit Enter Next




>Test Print
Test Pattern
Exit Change Next




>Download>
Exit Enter Next




>Transport Mode
OK?
Exit Enter Next




>Media>
Exit Enter Next




>Print>
Exit Enter Next





>Retransfer>
Exit Enter Next



>Bend Remedy>
Exit Enter Next







Setting using the operation panel

Initialization

- Whenever the power is turned on, cue (initialization) is performed automatically on the ink ribbon and retransfer film.
- You can also perform initialization using the operation button on the operation panel.


1 Press [Reset]

- A [Initialize] message appears.



2 Press **B**

- An [Initializing] message appears, and initialization of the printer starts.




Initializing printer when attaching the cassette


Memo:

- When detaching the ink ribbon cassette or retransfer film cassette from the printer body, dust may adhere to the ink ribbon or retransfer film. Printing errors such as discoloring and retransfer error may occur depending on the size of the dust particles. To prevent printing errors from occurring, initialize the printer when you attach the cassette.
- When attaching a new retransfer film, it is recommended that you forward the film by one or two images before printing.

1 Turn on the power.



2 Check to ensure that [Ready] or [Preheating] is displayed on the operation panel of the printer.




3 Press [Reset]

- A [Initialize] message appears.

Initializing printer without feeding the image

① Press **B**


- An [Initializing] message appears, and initialization of the printer starts.



Initializing printer after feeding by one image


① Press [Next]

- A [Next Panel, OK?] message appears.



② Press **B**


- An [Initializing] message appears, and the printer is initialized after feeding the ink ribbon and retransfer film by one image.



Initializing printer after feeding by two images


① Press [Next]

- A [2'nd Panel, OK?] message appears.



② Press **B**


- An [Initializing] message appears, and the printer is initialized after feeding the ink ribbon and retransfer film by two images.



Firmware update


1 Press [Menu]

- A [Cleaning] message appears.




2 Press [Next] to set to [Down load]

- Pressing the [Next] button each time displays the next screen.



3 Press [Enter]

- Data download from the host computer starts.



- A [Downloading] message during data download from the host computer.



Note:


- Do not turn off the power during data download from the host computer. Doing so may damage the printer firmware and cause malfunction.
- A [Please Power Off] message when data download from the host computer is complete.

Operation



4 Press [Exit]

- Pressing [Exit] each time returns you to the previous screen.



Counter setting

- This is used for setting the type of counter displayed on the operation panel.

Counter types

- **Total Cnt: total counter**

Displays the total number of cards that are correctly printed.

- **Head Cnt: Head counter**

Displays the total number of printed sides for the same head.

- **Free Cnt: free counter**

Displays the number of cards that are correctly printed. This number can be reset.

- **Cleaning Cnt: Cleaning counter**



Displays the number of cards that are correctly printed. This number can be reset.

- **Error Cnt: Error counter**

Displays the number of cards that are not correctly printed. This number can be reset.



1 Press [Menu]

- A [Cleaning] message appears.




2 Press [Next] to display [Setting]

- Pressing the [Next] button each time displays the next screen.




3 Press [Enter]

- A [Display] message appears.




4 Press [Enter]

- A [Mode] message appears.




5 Press [Next]

- A [Counter] message appears.



6 Press [Change]

- A setting change screen appears.



7 Press **A** and select a setting value.

8 Press **B** to confirm the setting value.

- Pressing **B** confirms the setting and returns you to the previous screen.

9 Press [Exit]

- Pressing [Exit] each time returns you to the previous screen.



Operation

Resetting the counter

- Resets the free counter and error counter.

1 Press [Menu]

- A [Cleaning] message appears.



2 Press [Next] to set to [Counter Reset]



3 Press B



- Resets the free counter and error counter.

Checking reset

- Select [Free Cnt] or [Error Cnt] under [Counter setting].

Test print

- Prints the printer's built-in test pattern, or the different setting values.
- When system troubles occur, printing can be performed using settings on the printer or computer by operating only the printer.

Test types

- Test Pattern:**

Prints color patterns on a single side of a card.

- Printer Setting:**

Prints according to the values preset in the setting mode.

- Network:**



Prints according to the values preset through the network.

- Lami Setting:**



Prints according to the values preset in the laminator's user mode.

1 Press [Menu]

- A [Cleaning] message appears.





2 Press [Next] to display [Test Print]



3 Press [Change]

- A [Test Pattern] message appears.

4 Press Δ and select a test type.



5 Press B

- Test print starts.

Contrast setting

- This is used for setting the contrast of the operation panel display.



Setting values

-3, -2, -1, 0, 1, 2, 3

- Selecting a larger value increases the contrast.



1 Press [Menu]

- A [Cleaning] message appears.




2 Press [Next] to set to [Setting]

- Pressing the [Next] button each time displays the next screen.




3 Press [Enter]

- A [Display] message appears.





4 Press [Enter]

- A [Mode] message appears.



5 Press [Next]

- A [Contrast] message appears.



6 Press [Change]

- A setting selection screen appears.



7 Press Δ and select a setting value.

8 Press \mathbf{B} to confirm the setting value.

- Pressing \mathbf{B} confirms the setting and returns you to the previous screen.

9 Press [Exit]

- Pressing [Exit] each time returns you to the previous screen.

Operation

Buzzer sound setting


- This is used for setting the buzzer sound when an error occurs.

Setting values



On: turns on buzzer sound, Off: turns off buzzer sound

1 Press [Menu]

- A [Cleaning] message appears.



2 Press [Next] to set to [Setting]




3 Press [Enter]

- A [Display] message appears.




4 Press [Next] to set to [Buzzer]



5 Press [Change]

- A setting selection screen appears.



6 Press Δ and select a setting value.

7 Press \mathbf{B} to confirm the setting value.

- Pressing \mathbf{B} confirms the setting and returns you to the previous screen.

- To display the next setting value, press Δ .

8 Press [Exit]

- Pressing [Exit] each time returns you to the previous screen.


Unit number setting

- For setting the printer's unit number according to the USB environment.



Setting values

No.1 ~ No.10


- 1 Press [Menu]
- A [Cleaning] message appears.




- 2 Press [Next] to set to [Setting]




- 3 Press [Enter]
- A [Display] message appears.



- 4 Press [Next] to set to [Unit No]



- 5 Press [Change]
- A setting selection screen appears.



- 6 Press Δ and select a setting value.
- 7 Press \mathbf{B} to confirm the setting value.
 - Pressing \mathbf{B} confirms the setting and returns you to the previous screen.
- 8 Press [Exit]
 - Pressing [Exit] each time returns you to the previous screen.

Operation

Transport mode setting


Note:

- Make sure that you set to the transport mode when transporting or moving the printer.
Failure to do so may result in malfunction of the printer.
- When transporting or moving the printer, ensure that the heat roller is secured to a safe position.

1 Open the printer door.



2 Press and hold down the cassette button, and remove the ink ribbon cassette (on the right) to remove the ink ribbon.




3 Press and hold down the cassette button, and remove the retransfer film cassette (on the left) to remove the retransfer film.



4 Close the printer door.


5 Turn on the power.





6 Check to ensure that [Film Search] is displayed on the operation panel of the printer.

7 Press [Menu]



- A [Cleaning] message appears.



8 Press [Next] to set to [Transport Mode]



9 Press **B**



- After setting to the transport mode, a [Please Power Off] message appears.

10 Turn off the power, and attach the cassette.

Note:

- When in the transport mode, the retransfer film cassette cannot be installed to the printer with the retransfer film attached.

Reset the Transport mode

- With the printer door closed, turn on the power, and reset the transport mode.


Printing a Card

Note:

- If you see an [Initializing...] or [Preheating..] message on the LCD panel of the printer, this means the printer is not ready yet. Printing cannot be performed in this case.
- Printing the card on the side with the magnetic stripe may cause printing errors or damage to the card's functions. If you want to do so, consult our authorized dealers in advance.

Printing a Card

- 1 Turn on the power.
- 2 Check to ensure that cards are inserted into the card hopper.
- 3 Open the print settings screen.
- 4 Select this printer from [Name] .
 - If there are multiple printers, select the name of the printer that you want to perform printing on.
- 5 After ensuring that a [Ready] message appears on the LCD panel of the printer, start printing.



Precautions on cards

- "Card has run out" A page 25

Ink Ribbon

- "Ink ribbon has run out" A page 26
- "Ink ribbon is broken" A page 27

Retransfer Film

- "Retransfer film has run out" A page 29
- "Retransfer film is broken" A page 30

Precautions on cards

Card has run out


- Loads the cards.

Print this page


Note:

- If the security lock function is turned on, the card hopper will be locked. Turn off the security from the computer. After loading the card, turn on the security again from the computer.
- Do not touch the printing surface of the card. Touching it may cause printing errors. Put on the supplied gloves when handling the cards.
- When using new cards, separate them one by one before setting them in the printer. Cards may be adhered to each other due to static, thus causing card jams.
- Align the cards before setting them in the printer. Otherwise, the card hopper cover may not close properly, and this may damage the printer.
- Printing the card on the side with the magnetic stripe may cause printing errors or damage to the card's functions. If you want to do so, consult our authorized dealers in advance.
- To set cards with both functions (magnetic stripe and contact IC), follow the procedure for setting the contact IC card.

- 1 Set the card hopper knob to [OPEN] .



- 2 Lift to remove the card hopper cover.




- 3 Align the orientation of the cards, and set them in the printer.

Replacement

Magnetic cards

- Set the card with the magnetic stripe facing upward and toward the printer, or facing downward and toward you.




ISO contact IC cards

- Set the card with the Contact IC terminal facing upward and toward the rear of the printer, or downward and toward the front of the printer.



- 4 Install the card hopper cover.



Ink Ribbon


Ink ribbon has run out

- Replace with a new ink ribbon.

Print this page

Note:

- If the security lock function is turned on, turn off the function from the computer to unlock the printer. After closing the door, turn on the function again from the computer.
- Stand the cassette on a flat surface as illustrated in the diagram. Avoid doing so on a floor as dust attached to the retransfer film may cause printing errors.




- Do not touch the inked surface (the side that faces outward when installed) with your hand. Touching it may cause printing errors. Put on the supplied gloves when handling the ink ribbon.
- When installing a used ink ribbon, align the yellow side of the unused ribbon with the arrow indicated on the label of the cassette. If the position of the yellow side is not properly aligned, the print may turn out light.
- When handling the cassette, hold it with both hands. Accidentally dropping the cassette may damage it or result in injuries.
- Do not perform work on the printer door. Do not place heavy objects or apply load on the printer. Doing so may damage it.
- During replacement, clean the four bobbin holders on the printer. Burrs generated by friction between the bobbins and bobbin holders may be adhered to the ink ribbon or retransfer film, causing printing errors.

- 1 Open the printer door.




- 2 Press and hold down the cassette button, and pull out the ink ribbon cassette (on the right) to remove the ink ribbon.




- 3 Install a new ink ribbon.

- Install while referring to the indication on the label of the cassette.




- ① With the inked surface facing outward, align the yellow side of the unused ribbon with the arrow on the cassette, and unwind it along the three shafts.
- ② Insert the ink ribbon firmly into the bobbin holders with the ribbon set to the far end of the guides.
 - A: take-up side (black)
 - B: unused side (yellow)




4 Remove any slack in the ink ribbon.

- ① Hold the cassette.
- ② Turn the knob in the direction indicated by the arrow.



5 Insert the cassette all the way in along the guide rail until a “click” sound is heard. Close the printer door.



6 Press [Reset] **DB** to reset the printer.



"Initializing printer when attaching the cassette" (A page 16)


Ink ribbon is broken

- Repair the ink ribbon.

Print this page

Note:

- If the security lock function is turned on, turn off the function from the computer to unlock the printer. After closing the door, turn on the function again from the computer.
- Stand the cassette on a flat surface as illustrated in the diagram. Avoid doing so on a floor as dust attached to the retransfer film may cause printing errors.



- Do not touch the inked surface (the side that faces outward when installed) with your hand. Touching it may cause printing errors. Put on the supplied gloves when handling the ink ribbon.
- When handling the cassette, hold it with both hands. Accidentally dropping the cassette may damage it or result in injuries.
- When installing a used ink ribbon, align the yellow side of the unused ribbon with the arrow indicated on the label of the cassette. If the position of the yellow side is not properly aligned, the print may turn out light.


Replacement

- Do not perform work on the printer door. Do not place heavy objects or apply load on the printer. Doing so may damage it.
- During replacement, clean the four bobbin holders on the printer. Burrs generated by friction between the bobbins and bobbin holders may be adhered to the ink ribbon or retransfer film, causing printing errors.


1 Open the printer door.



2 Press and hold down the cassette button, and pull out the ink ribbon cassette (on the right) to remove the ink ribbon.




3 Cut away the broken portion, and attach the unused portion at the supply side to the other end at the take-up side using an adhesive tape.




4 Attach the ink ribbon, and turn the take-up side until the cut section is out of sight.



- Install while referring to the indication on the label of the cassette.




- ① With the inked surface facing outward, align the yellow side of the unused ribbon with the arrow on the cassette, and unwind it along the three shafts.
- ② Turn the knob in the direction of the arrow to remove any slack.
- ③ Insert the ink ribbon firmly into the bobbin holders with the ribbon set to the far end of the guides.



5 Insert the cassette all the way in along the guide rail until a "click" sound is heard. Close the printer door.



6 Press [Reset] **DB** to reset the printer.



"Initializing printer when attaching the cassette" (A page 16)

Retransfer Film


Retransfer film has run out

- Replace with a new retransfer film.


Print this page

Note:

- If the security lock function is turned on, turn off the function from the computer to unlock the printer. After closing the door, turn on the function again from the computer.
- Stand the cassette on a flat surface as illustrated in the diagram. Avoid doing so on a floor as dust attached to the retransfer film may cause printing errors.




- Do not touch the retransfer face (the side that faces outward when installed) with your hand. Touching it may cause printing errors. Put on the supplied gloves when handling the retransfer film.
- When handling the cassette, hold it with both hands. Accidentally dropping the cassette may damage it or result in injuries.
- When installing a used retransfer film, align the unused side of the film with the arrow indicated on the label of the cassette. Failure to do so may result in errors, or the print may turn out light.
- When installing a new film, make sure that at least three black lines are wound onto the take-up side. Insufficient winding may cause the printer to malfunction.



- Do not perform work on the printer door. Do not place heavy objects or apply load on the printer. Doing so may damage it.
- During replacement, clean the four bobbin holders on the printer. Burrs generated by friction between the bobbins and bobbin holders may be adhered to the ink ribbon or retransfer film, causing printing errors.

1 Open the printer door.




- #### 2 Press and hold down the cassette button, and pull out the retransfer film cassette (on the left) to remove the retransfer film.

Replacement




3 Install a new retransfer film.

- Install while referring to the indication on the label of the cassette.
 - ① When installing the retransfer film, make sure that at least three black lines are wound onto the take-up side.




- ② With the retransfer face facing outward, align the unused side of the film with the arrow on the cassette, and unwind it along the three shafts.
- ③ Insert the retransfer film firmly into the bobbin holders with the film set to the far end of the guides.
 - A: take-up side (black)
 - B: unused side (green)




4 Remove any slack in the film.


- ① Hold the retransfer film cassette.
- ② Turn the knob in the direction indicated by the arrow.



5 Insert the cassette all the way in along the guide rail until a "click" sound is heard. Close the printer door.



6 Press [Reset] **DB** to reset the printer.



Memo:

- When attaching a new retransfer film, it is recommended that you forward the film by one or two images before printing.
- "Initializing printer when attaching the cassette" (A page 16)


Retransfer film is broken

- Repair the retransfer film.

Print this page

Note:

- If the security lock function is turned on, turn off the function from the computer to unlock the printer. After closing the door, turn on the function again from the computer.
- Stand the cassette on a flat surface as illustrated in the diagram. Avoid doing so on a floor as dust attached to the retransfer film may cause printing errors.



- Do not touch the retransfer face (the side that faces outward when installed) with your hand. Touching it may cause printing errors. Put on the supplied gloves when handling the retransfer film.
- When handling the cassette, hold it with both hands. Accidentally dropping the cassette may damage it or result in injuries.
- When installing a used retransfer film, align the unused side of the film with the arrow indicated on the label of the cassette. Failure to do so may result in errors, or the print may turn out light.
- Do not perform work on the printer door. Do not place heavy objects or apply load on the printer. Doing so may damage it.
- During replacement, clean the four bobbin holders on the printer. Burrs generated by friction between the bobbins and bobbin holders may be adhered to the ink ribbon or retransfer film, causing printing errors.


1 Open the printer door.



2 Press and hold down the cassette button, and pull out the retransfer film cassette (on the left) to remove the retransfer film.




3 Cut away the broken portion, and attach the unused portion at the supply side to the other end at the take-up side using an adhesive tape.




4 Attach the retransfer film, and turn the take-up side until the cut section is out of sight.


- ① With the retransfer face facing outward, align the unused side of the film with the arrow on the cassette, and unwind it along the three shafts.
- ② Insert the retransfer film firmly into the bobbin holders with the film set to the far end of the guides.
- ③ Turn the knob in the direction of the arrow to remove any slack.



5 Insert the cassette all the way in along the guide rail until a "click" sound is heard. Close the printer door.



6 Press [Reset] **DB** to reset the printer.



"Initializing printer when attaching the cassette" (A page 16)

Servicing of Parts

- "Cleaning roller" A page 32
- "Fan filter" A page 33
- "Card feed roller/heating roller" A page 34
- "Magnetic head" A page 38
- "Bobbin holders" A page 36
- "Thermal head" A page 39

Servicing Based on Print Output

- "Colors appear faded or dirt is conspicuous" A page 41
- "Card jams" A page 41
- "Error during writing/reading" A page 41
- "Lines appear on card after printing" A page 41

Note:

- After servicing or cleaning is complete, check to ensure that all dismantled parts are restored to their original positions. Failure to restore the parts may result in malfunction of the printer.

Request for Routine Servicing

- In order to prevent printing errors and malfunctions from occurring in advance, please request for routine servicing by the servicing personnel. For details on servicing, please consult our authorized dealers.

Servicing of Parts

Cleaning roller

- The function of the cleaning roller is to remove any dirt or dust attached to the card.
- Card jams may occur if the cleaning roller is dirty.
- The color of the printed card may appear faded or dirt may appear conspicuous if the cleaning roller is dirty.

Print this page


Note:

- If the security lock function is turned on, turn off the function from the computer to unlock the printer. After closing the door, turn on the function again from the computer.
- If the printer is used everyday, make sure to clean the cleaning roller daily at the end of the operation.
- Do not perform work on the printer door. Do not place heavy objects or apply load on the printer. Doing so may damage it.
- After washing, allow the cleaning roller to dry completely before installing it to the printer.
- Do not wash the cleaning roller with anything other than water (e.g., alcohol).
- Replace the cleaning unit with a new one after using it for about one year. For details on its replacement, please consult our authorized dealers.
- After cleaning is complete, check to ensure that all dismantled parts are restored to their original positions. Failure to restore the parts may result in malfunction of the printer.

1 Open the printer door.




2 Pull out the cleaning unit.




3 Wash the cleaning roller with water.

- Wash the roller with water, and remove any dirt from the surface of the cleaning roller with your finger.




4 Allow the cleaning roller to air dry.



5 Set the cleaning unit, and close the printer door.

- With the roller facing the right, insert it all the way in.



Fan filter


- The color of the printed card may appear faded or dirt may appear conspicuous if the fan filter is dirty.
- Perform cleaning after printing about 10,000 cards.

Print this page


Note:

- After cleaning is complete, check to ensure that all dismantled parts are restored to their original positions. Failure to restore the parts may result in malfunction of the printer.


1 Remove the filter cover located on the side of the printer.




2 Remove the fan filter.



3 Remove any dirt that is attached to the fan filter using a vacuum cleaner.




4 Set the fan filter.



Maintenance

5 Set the filter cover.




Card feed roller/heating roller

- The color of the printed card may appear faded or dirt may appear conspicuous if the card feed roller/heating roller is dirty.
- Perform cleaning after printing about 1,000 cards.

Print this page


Note:

- If the security lock function is turned on, turn off the function from the computer to unlock the printer. After closing the door, turn on the function again from the computer.
- Before cleaning the card feed roller/heating roller, make sure that you clean the cleaning roller. Otherwise, dirt on the cleaning roller may be attached to the cleaning card, causing its cleaning capability to deteriorate.
- Stand the cassette on a flat surface as illustrated in the diagram. Avoid doing so on a floor as dust attached to the retransfer film may cause printing errors.




- If card jam occurs when the cleaning card is inserted, turn off and on the power of the printer. Doing so automatically discharges the card.
- Do not perform work on the printer door. Do not place heavy objects or apply load on the printer. Doing so may damage it.
- Each cleaning card can only be used once. Reusing a dirty card may dirty the roller or cause the printer to malfunction. For details on the cleaning card, please consult our authorized dealers.
- After cleaning is complete, check to ensure that all dismantled parts are restored to their original positions. Failure to restore the parts may result in malfunction of the printer.
- For details on separately sold items, please consult our authorized dealers.


1 Open the printer door. Press and hold down the cassette button, and remove the retransfer film cassette (on the left).





2 Close the printer door, and remove the card hopper.




3 Turn on the power.



4 Press [Menu] to set to [Cleaning]



5 Press [Enter] to set to [Rollers]




6 Peel off the backing paper from the cleaning card (sold separately).




7 Press **B**

- A [Cleaning Start OK?] message appears.



8 Press **B**

- A [Cleaning...] message appears.



Note:

- If the retransfer heating roller is hot, a [HR is too hot] message will be displayed. Turn off the power, and perform cleaning after the retransfer heating roller has cooled down completely.



9 Insert the cleaning card (sold separately) within 20 seconds.


- The roller draws in the card, and cleaning starts automatically. Reverse the adhesive face, and insert the card again.



Note:

- Insert the card within 20 seconds after pressing **B**.
- After pressing **B**, the buzzer sounds upon a lapse of 20 seconds, and a [Jam (Hopper)] error message appears 10 seconds later. Press [Reset] **DB** to cancel the error.
- When a standard-sized card is inserted, the card is automatically discharged from the NG card outlet, and the printer returns to the [Cleaning Start OK?] screen.

10 After the cleaning card is discharged, turn off the power, and install the retransfer film cassette and card hopper.



- To turn on the power again, do so after an interval of at least 10 seconds.

Magnetic head


- Writing/Reading errors may occur if the magnetic head is dirty.
- Perform cleaning after printing about 1,000 cards.

Print this page


Note:

- If the security lock function is turned on, turn off the function from the computer to unlock the printer. After closing the door, turn on the function again from the computer.
- Before cleaning the magnetic head, make sure that you clean the cleaning roller. Otherwise, dirt on the cleaning roller may be attached to the cleaning card, causing its cleaning capability to deteriorate.
- After cleaning is complete, check to ensure that all dismantled parts are restored to their original positions. Failure to restore the parts may result in malfunction of the printer.
- Do not perform work on the printer door. Do not place heavy objects or apply load on the printer. Doing so may damage it.
- For details on separately sold items, please consult our authorized dealers.


1 Turn on the power.





2 Check to ensure that [Ready] or [Preheating] is displayed on the operation panel of the printer.





3 Remove the card hopper.



4 Press [Menu] to set to [Cleaning]




5 [Enter] Press [Next] to set to [MG]




6 Apply alcohol on the magnetic head cleaning card (sold separately).
 • Apply about three to four drops of alcohol on the magnetic stripe.



7 Press B





8 Insert the magnetic head cleaning card within 20 seconds.



Note:

- Insert the card within 20 seconds after pressing **B**.
- After pressing **B**, the buzzer sounds upon a lapse of 20 seconds, and a [Jam (Hopper)] error message appears 10 seconds later. Press [Reset] **DB** to cancel the error.

9 After the cleaning card is discharged, turn off the power, and install the card hopper.



- To turn on the power again, do so after an interval of at least 10 seconds.

Maintenance


Bobbin holders

- The color of the printed card may appear faded or dirt may appear conspicuous if burrs are attached to the bobbin holders.

Print this page

Note:

- If the security lock function is turned on, turn off the function from the computer to unlock the printer. After closing the door, turn on the function again from the computer.
- Stand the cassette on a flat surface as illustrated in the diagram. Avoid doing so on a floor as dust attached to the retransfer film may cause printing errors.




- Do not perform work on the printer door. Do not place heavy objects or apply load on the printer. Doing so may damage it.
- Perform cleaning each time you replace the ink ribbon or retransfer film. Otherwise, burrs attached to the bobbin holders may fall onto the card, ink ribbon, or retransfer film, causing printing errors.
- After cleaning is complete, check to ensure that all dismantled parts are restored to their original positions. Failure to restore the parts may result in malfunction of the printer.
- For details on separately sold items, please consult our authorized dealers.

1 Open the printer door.




2 Press and hold down the cassette button, and remove the ink ribbon cassette (on the right).





3 Press and hold down the cassette button, and remove the retransfer film cassette (on the left).




4 Apply alcohol to a cotton swab (large), and use it to wipe the four bobbin holders.
(Cotton swab and alcohol: sold separately)




5 Insert the retransfer film cassette along the guide rail until a "click" sound is heard.



6 Insert the ink ribbon cassette along the guide rail until a "click" sound is heard. Close the printer door.






Thermal head

- Lines may appear on the card after printing if the thermal head is dirty.

Print this page


Note:

- If the security lock function is turned on, turn off the function from the computer to unlock the printer. After closing the door, turn on the function again from the computer.
- Stand the cassette on a flat surface as illustrated in the diagram. Avoid doing so on a floor as dust attached to the retransfer film may cause printing errors.




- Do not perform work on the printer door. Do not place heavy objects or apply load on the printer. Doing so may damage it.
- Touching the thermal head with your body electrostatically charged may cause damage to the head. Make sure that you touch the metallic part of the printer before commencing work.
- Pay attention to prevent metallic objects from knocking against the thermal head. Doing so may damage it.
- After cleaning is complete, check to ensure that all dismantled parts are restored to their original positions. Failure to restore the parts may result in malfunction of the printer.
- For details on separately sold items, please consult our authorized dealers.

- 1 Open the printer door.




- 2 Press and hold down the cassette button, and remove the ink ribbon cassette (on the right).




- 3 Press and hold down the cassette button, and remove the retransfer film cassette (on the left).

Maintenance




- 4 Apply alcohol to a cotton swab (large), and use it to wipe the thermal head.
(Cotton swab and alcohol: sold separately)



- Wipe the thermal head with care in the horizontal direction.

- 5 Insert the retransfer film cassette along the guide rail until a “click” sound is heard.



- 6 Insert the ink ribbon cassette along the guide rail until a “click” sound is heard. Close the printer door.

Servicing Based on Print Output

Colors appear faded or dirt is conspicuous

- "Clean the cleaning roller." A page 32
- "Clean the fan filter." A page 33
- "Clean the card feed roller/heating roller." A page 34
- "Clean the bobbin holders." A page 38

Card jams

- "Clean the cleaning roller." A page 32

Error during writing/reading

- "Clean the magnetic head." A page 36

Lines appear on card after printing

- "Clean the thermal head." A page 39

When an Error Message is Displayed

- "Identifying errors using the error code" A page 41

Precautions on cards

- "Card jams" A page 43
- "Card has run out" A page 48

Ink Ribbon

- "Ink ribbon has run out" A page 26
- "Ink ribbon is broken" A page 27

Retransfer Film

- "Retransfer film has run out" A page 29
- "Retransfer film is broken" A page 30
- "Unable to fit retransfer film cassette into printer" A page 49

Unable to produce desired printing results

- "Lines appear on card after printing" A page 50
- "Colors on card appear faded after printing" A page 50
- "Peeling occurs on card after printing" A page 50
- "Overall printing quality is poor" A page 50
- "Card is printed in a single color" A page 50
- "Strange characters or images are printed" A page 50
- "Retransfer cannot be performed successfully" A page 50

Printer not operating as desired

- "Card is not fed into the printer" A page 50
- "Power does not turn on" A page 50
- "Printing does not start or stops halfway" A page 50

When an Error Message is Displayed


Identifying errors using the error code

List of error codes

- Click on an error code below to jump to the page with the corresponding error descriptions.


"44" A page 42 "90" A page 41 "91" A page 41 "92" A page 41 "93" A page 41 "94" A page 41
 "A1" A page 41 "A2" A page 42 "A8" A page 42 "AB" A page 42 "AC" A page 42
 "B0" A page 42 "B1" A page 42 "B2" A page 42
 "C1" A page 42 "C2" A page 42 "C3" A page 43
 "D1" A page 42 "D8" A page 42
 "F0" A page 42 "F1" A page 42 "F2" A page 42 "F3" A page 42 "F4" A page 42 "F5" A page 42 "F6" A page 43
 "F8" A page 43

No Card



- "Cards have run out. Loads the cards." A page 48 Or, "The card hopper is not attached. Attach the card hopper."

Jam(Hopper) 90




- "Card jam in the card hopper unit. Remove the jammed card." A page 43

Jam(TurnOver) 91




- "Card jam in the turnover unit. Remove the jammed card." A page 44

Jam(MG) 92



- "Card jam in the magnetic encoder unit. Remove the jammed card." A page 46

Jam(Transfer) 93




- "Card jam in the retransfer unit. Remove the jammed card." A page 47

Jam(Discharge) 94



- Card jam in the discharge unit. Remove the jammed card.


Film Search A1



- "Retransfer film is broken. Repair it." A page 30

Troubleshooting?

MG Test Err A8




- MG writing error occurred during MG self-diagnosis. Reset the printer.

Ink Error B0



- An incorrect printer ink is installed. Attach a correct ink.

Ink Search B1




- "Ink ribbon is broken. Repair it." A page 27

Door Open D1




- Printer door is open. Close the door. Or, "The cleaning roller is not attached. Attach the cleaning roller."

Film Run Out A2



- "Retransfer film has run out. Replace with a new one." A page 29

Ink Run Out B2




- "Ink ribbon has run out. Replace with a new one." A page 26

Hard ware 44




- A hardware failure has occurred on the printer. Turn off and on the power. If the same problem recurs, turn off the power and consult our authorized dealers.

MG Mechanical AB



- An error has occurred in the mechanical component of the MG unit. Turn off and on the power. If the same problem recurs, turn off the power and consult our authorized dealers.

MG Hardware AC



- A hardware failure has occurred on the MG unit. Turn off and on the power. If the same problem recurs, turn off the power and consult our authorized dealers.

Cam Error C1




- Heating roller operation failure. Turn off and on the power. If the same problem recurs, turn off the power and consult our authorized dealers.

HR Overheat C2



- The temperature of the warpage correction heating roller or retransfer heating roller is too high. Turn off and on the power. If the same problem recurs, turn off the power and consult our authorized dealers.

Hardware D8



- A hardware error has occurred during initialization. Turn off and on the power. If the same problem recurs, turn off the power and consult our authorized dealers.

TR Overheat F0



- The temperature of the retransfer roller is too high. Turn off and on the power. If the same problem recurs, turn off the power and consult our authorized dealers.

TR Heater F1



- Retransfer roller failure. Turn off and on the power. If the same problem recurs, turn off the power and consult our authorized dealers.

TR Thermister F2




- Retransfer roller thermister failure. Turn off and on the power. If the same problem recurs, turn off the power and consult our authorized dealers.

RR Overheat F3




- The temperature of the warpage correction roller is too high. Turn off and on the power. If the same problem recurs, turn off the power and consult our authorized dealers.

RR Heater F4



- Warpage correction roller failure. Turn off and on the power. If the same problem recurs, turn off the power and consult our authorized dealers.

RR Thermister F5



- Warpage correction roller thermister failure. Turn off and on the power. If the same problem recurs, turn off the power and consult our authorized dealers.

Overcool F6




- The operating ambient temperature of the printer is too low. Check the temperature. If the same problem recurs at the same operating ambient temperature, turn off the power and consult our authorized dealers.

Head Overheat F8



- The temperature of the thermal head is too high. Turn off and on the power. If the same problem recurs, turn off the power and consult our authorized dealers.

Power Int. C3



- A 24 V interruption is detected.
- Turn off and on the power again.

Precautions on cards

Card jams

- Check the error code on the operation panel.

Error code 90


- Card jam in the card hopper unit.




Note:

- Do not apply excessive force on the card hopper. Doing so may damage it.
- Do not touch the printing surface of the card. Touching it may cause printing errors. Put on the supplied gloves when handling the cards.

1 Remove the card hopper cover.



2 Remove the loaded cards, and pull out the jammed card with a hand.



3 Install the card hopper cover.


If the card cannot be pulled out by hand

① Open the printer door.




② Use the jog dial to turn the retransfer unit and cleaning unit in the clockwise direction.

Troubleshooting?



③ Close the printer door, and press [RESET] **DB** to reset the printer.




Error code 91

- Card jam in the turnover unit.

Jam(Turn Over)	91
----------------	----


1 Remove the card hopper.





2 Open the printer door, and remove the cleaning unit.

When the cleaning unit cannot be detached

- ① Use the jog dial to turn the cleaning unit in the clockwise direction.





② Open the card hopper cover, and remove the card if this is possible.



③ Use the jog dial to turn the turnover unit slightly in both the left and right directions.


- If the card is protruded from the turnover unit, the turnover unit cannot be turned.

Turn the turnover unit and cleaning unit at the same time in opposite directions to move the card to the turnover unit.




④ Move the card to the turnover unit.

- Turn the turnover unit and cleaning unit in opposite directions.




⑤ Close the printer door, and press [RESET] **DB** to reset the printer.

Troubleshooting?



- The card is discharged from the NG card outlet or card staker.



Error code 92


- Card jam in the magnetic encoder unit.

Jam(MG)	92
---------	----


- 1 Open the printer door.



- 2 Restore the card to the magnetic encoder unit.
 - Use the jog dial to turn the cleaning unit.
- 3 Turn the jog dial at the turnover unit to adjust the unit to a vertical position.
 - While doing so, make use of the printer's label as a reference.
- 4 Move the card to the center of the turnover unit
 - ① Maintain the turnover unit in the vertical position.
 - ② Turn the jog dial at the cleaning unit.
 - Check to ensure that the card moves to the turnover unit.
- 5 Turn the jog dial attached to the turnover and cleaning units at the same time in opposite directions.
 - Set the turnover unit to the horizontal position.
- 6 Turn the jog dial of the turnover unit clockwise to an angle of 45 degree.
 - While doing so, make use of the printer's label as a reference.
- 7 Turn the jog dial at the cleaning unit in the anti-clockwise direction.
 - The card is discharged from the NG card outlet.




- 8 Press [RESET] **DB** to reset the printer.




- The card is discharged from the NG card outlet or card stacker.

Error code 93

- Card jam in the retransfer unit.




1 Press [RESET] **DB** to reset the printer.



Error code 94

- Card jam in the discharge unit.



1 Open the printer door.


Troubleshooting?



2 Remove the retransfer film cassette (on the left), and check the printer interior.



- If the card is found adhered to the retransfer film, remove the card.



Note:

- If the card cannot be removed from the retransfer film cassette (on the left), do not try to do so forcefully. Consult our authorized dealers or servicing personnel.

3 Close the printer door, and press [RESET] **DB** to reset the printer.



Card has run out

- "Loads the cards." A page 25

Ink Ribbon

- "Ink ribbon has run out" A page 26
- "Ink ribbon is broken" A page 27

Retransfer Film

- "Retransfer film has run out" A page 29
- "Retransfer film is broken" A page 30

Unable to fit retransfer film cassette into printer

- With the printer door closed, turn on the power, and cancel the transport mode.

"Transport mode setting" (A page 24)

Unable to produce desired printing results

Lines appear on card after printing

- "Clean the thermal head." [A page 39](#)

Colors on card appear faded after printing

- "Clean the cleaning roller." [A page 32](#)
- "Clean the fan filter." [A page 33](#)
- "Clean the card feed roller/heating roller." [A page 34](#)
- "Clean the bobbin holders." [A page 38](#)

Peeling occurs on card after printing

- Check the retransfer mode settings.

Overall printing quality is poor

- "Clean the cleaning roller." [A page 32](#)
- "Clean the fan filter." [A page 33](#)
- "Clean the card feed roller/heating roller." [A page 34](#)
- "Clean the bobbin holders." [A page 38](#)

- Is the printing face of the card dirty?

Use a clean card.

Card is printed in a single color

- Is the print settings set to single-color printing?
- Is the software application settings set to single-color printing?

Check the print settings.

Strange characters or images are printed

- Is the driver for this printer selected on the computer?

Select the driver for this printer.

- Is the USB cable connection loose?

Plug in the USB cable properly.

Retransfer cannot be performed successfully

- Is the printing face of the card dirty?

Use a clean card.

- Is the surrounding temperature or card surface temperature too low?

Use after the ambient and card surface temperatures have reached the range specified in the operating environment conditions.

- Is the retransfer speed setting value too high?

Set to a value that is smaller than +2 (between +1 and -3).

- Is the temperature of the retransfer roller too low?

Set to a value that is larger than +1 (+2).

Printer not operating as desired

Card is not fed into the printer

- Is the card feed path dirty?

Clean the card feed roller/heating roller.

"Cleaning the card feed roller/heating roller" ([A page 34](#))

- Is the paper load roller dirty?

Apply alcohol (sold separately) to a wiper (sold separately), and use it to clean the paper load roller.

- Is the card thickness correctly adjusted?

Check the card separator settings.

"Card separator settings" ([A page 55](#))

- Are the cards adhered to one another?

Cards may be adhered to one another due to static. Separate the cards one by one before setting them in the printer.

Power does not turn on

- Is the power switch turned off? ( position)

Turn on the power. (I position)

- Is the power cord disconnected?

Plug in the power cord properly.

- Is there electricity supply from the outlet?

Try connecting another electrical device to the outlet. If the device works normally, then it could be due to malfunctioning of the printer. Consult our authorized dealers.

Printing does not start or stops halfway

- Is the printer door open?

Close the printer door properly, and reset the printer.

"Initialization" ([A page 16](#))

- Is the printer connected to a computer?

Connect the printer to a computer correctly using a USB/LAN cable.

- Is the length of the USB cable too long?

A USB cable with a length of not more than 2 m is recommended.

- Are cards set into the printer?

Set the cards correctly.

"Loading cards" ([A page 25](#))

- Is an ink ribbon/retransfer film installed?

Install an ink ribbon/retransfer film correctly.

"Installing the ink ribbon" ([A page 26](#))

"Attaching the retransfer film" ([A page 29](#))

- Is the driver for this printer selected?

Select the driver for this printer.

Before sending printer for repair

Enter the symptoms into the troubleshooting sheet.

Printing the troubleshooting sheet

- Clicking the **Print** icon displays a PDF file.
- Print out the PDF file and enter accordingly.

Installation and Connection

- "Printer Installation" A page 51
- "Power Cord Connection" A page 52
- "Card Stacker (Supplied)" A page 52

Printing Media

- "Installing the ink ribbon" A page 52
- "Attaching the retransfer film" A page 53
- "Setting Cards" A page 54

Printer and Computer Connection

- "Connecting with a USB Cable" A page 56
- "Connecting with a LAN Cable" A page 56
- "Connecting Multiple Printers" A page 57

Printer Setting

- "Operation Panel" A page 10
- "Setting using the operation panel" A page 16

Installation and Connection

Printer Installation


Note:

- Using the printer in an environment beyond the operating ambient temperature range may result in retransfer or printing errors. Check the "Precautions on installation location" (A page 5) "Operating environment conditions" specifications.


"Precautions on installation location" (A page 5)
 "Operating environment conditions" (A page 9)

Ventilation holes for the cooling fan are located at the rear and side of the printer.


- Install the printer by allowing a clearance of at least 20 cm between its sides and surrounding walls.



- Allow a clearance of at least 10 cm between the rear of the printer and the wall.




- Do not place any object on the printer.



Setup

Power Cord Connection

- 1 Insert the power cord (supplied) to the power input terminal at the rear of the printer.



- 2 Plug the power cord (supplied) into an outlet.

Memo:


- Make use of an AVR (automatic voltage regulator) to prevent any fluctuation in voltage. Alternatively, an uninterruptible power supply is recommended in case momentary power outage occurs.

Note:

- Make sure that the power outlet is grounded and used as a dedicated power source for the printer.
- It must not be shared with other power supply facilities.

Card Stacker (Supplied)

- 1 Hook the tab on the card stacker to the card stacker attachment slot.



- ① Card outlet
- ② Card stacker attachment slot
- ③ Tab
- ④ Card stacker

Memo:


- The card stacker is able to store up to about 100 cards with a thickness of 0.76 mm, or about 300 cards with a thickness of 0.25 mm.

Printing Media

Installing the ink ribbon

Note:

- Stand the cassette on a flat surface as illustrated in the diagram. Avoid doing so on a floor as dust attached to the retransfer film may cause printing errors.




- Do not touch the inked surface (the side that faces outward when installed) with your hand. Touching it may cause printing errors. Put on the supplied gloves when handling the ink ribbon.
- When handling the cassette, hold it with both hands. Accidentally dropping the cassette may damage it or result in injuries.
- Do not perform work on the printer door. Do not place heavy objects or apply load on the printer. Doing so may damage it.

- 1 Open the printer door.




- 2 Press and hold down the cassette button, and pull out the ink ribbon cassette (on the right) to remove the ink ribbon.




- 3 Install a new ink ribbon.

- Install while referring to the indication on the label of the cassette.




- ① With the inked surface facing outward, align the yellow side of the unused ribbon with the arrow on the cassette, and unwind it along the three shafts.
- ② Insert the ink ribbon firmly into the bobbin holders with the ribbon set to the far end of the guides.
 - A: take-up side (black)
 - B: unused side (yellow)




4 Remove any slack in the ink ribbon.

- ① Hold the cassette.
- ② Turn the knob in the direction indicated by the arrow.




5 Press [Reset] **DB** to reset the printer.




Attaching the retransfer film

Note:

- Stand the cassette on a flat surface as illustrated in the diagram. Avoid doing so on a floor as dust attached to the retransfer film may cause printing errors.




- Do not touch the retransfer face (the side that faces outward when installed) with your hand. Touching it may cause printing errors. Put on the supplied gloves when handling the retransfer film.
- When handling the cassette, hold it with both hands. Accidentally dropping the cassette may damage it or result in injuries.
- When installing a new film, make sure that at least three black lines are wound onto the take-up side. Insufficient winding may cause the printer to malfunction.



- Do not perform work on the printer door. Do not place heavy objects or apply load on the printer. Doing so may damage it.

1 Open the printer door.




2 Press and hold down the cassette button, and pull out the retransfer film cassette (on the left) to remove the retransfer film.




3 Install a new retransfer film.

- Install while referring to the indication on the label of the cassette.
 - ① When installing the retransfer film, make sure that at least three black lines are wound onto the take-up side.




- ② With the retransfer face facing outward, align the unused side of the film with the arrow on the cassette, and unwind it along the three shafts.
- ③ Insert the retransfer film firmly into the bobbin holders with the film set to the far end of the guides.
 - A: take-up side (black)
 - B: unused side (green)

Setup





4 Remove any slack in the film.

- ① Hold the retransfer film cassette.
- ② Turn the knob in the direction indicated by the arrow.



5 Insert the cassette all the way in along the guide rail until a "click" sound is heard. Close the printer door.




Memo:

- If the retransfer film cassette does not fit into the printer, turn on the power of the printer with the printer door closed to cancel the transport mode.

"Transport mode setting" (A page 24)

6 Press [Reset] **DB** to reset the printer.



Memo:

- When attaching a new retransfer film, it is recommended that you forward the film by one or two images before printing.



"Initializing printer when attaching the cassette" (A page 16)

Setting Cards


Note:

- Do not touch the printing surface of the card. Touching it may cause printing errors. Put on the supplied gloves when handling the cards.
- When using new cards, separate them one by one before setting them in the printer. Cards may be adhered to each other due to static, thus causing card jams.
- Align the cards before setting them in the printer. Otherwise, the card hopper cover may not close properly, and this may damage the printer.
- Printing the card on the side with the magnetic stripe may cause printing errors or damage to the card's functions. If you want to do so, consult our authorized dealers in advance.
- To set cards with both functions (magnetic stripe and contact IC), follow the procedure for setting the contact IC card.

1 Set the card hopper knob to [OPEN] .




2 Lift to remove the card hopper cover.



3 Align the orientation of the cards, and set them in the printer.

Magnetic cards

- Set the card with the magnetic stripe facing upward and toward the printer, or facing downward and toward you.




ISO contact IC cards

1 Set the card with the Contact IC terminal facing upward and toward the rear of the printer, or downward and toward the front of the printer.





4 Install the card hopper cover.




Adjusting Card Thickness

- This printer can print cards with a thickness between 0.25 mm and 1.00 mm. This is adjusted to a thickness of 0.76 mm by default.


① Set the card hopper knob to [LOCK] .



② Remove the card hopper.




- ③ Insert a ballpoint pen into the card separator hole, and turn slowly.



Memo:

- If the card cannot be discharged during printing, adjust the card thickness by turning the card separator in the clockwise direction by one scale at a time.
- If two cards are discharged at a time during printing, adjust the card thickness by turning the card separator in the anti-clockwise direction by one scale at a time.
- If cards of different thickness are used frequently, purchase of an additional card hopper according to the card thickness is recommended. For details on the purchase of card hoppers, please consult our authorized dealers.

- ④ Attach the card hopper cover.



Printer and Computer Connection


Connecting with a USB Cable

Note:

- While printing is in progress, do not turn off the power of the host computer, or switch it to the sleep or standby mode. Doing so may stop the movement of the cards inside the printer.
- Plug the USB cable in correctly and firmly.
- Do not connect the cable to the USB connectors on the monitor or keyboard of the host computer. The printer may not be correctly recognized.
- When using a USB hub, make use of one that is directly connected to the host computer.

- 1 Turn off the power of the printer and host computer.

- 2 Plug the USB cable into the USB cable connection terminal at the rear of the printer, and pass the "A" page 7 USB cable through the cable clamp.



Note:

- As illustrated in the diagram, do not pull the USB cable excessively toward the cable clamp. Doing so may subject the USB connector of the printer to stress, thus resulting in connection problems.



- 3 Plug the other end of the USB cable into the USB cable connection terminal of the host computer.


Connecting with a LAN Cable

Note:

- Plug the LAN cable in correctly and firmly.
- Make use of a shielded LAN cable to avoid any malfunction.
- If a USB cable is also connected at the same time when the power is turned on, priority will be given to USB.

- 1 Turn off the power of the printer and host computer.

- 2 Plug the LAN cable into the LAN cable connection terminal at the rear of the printer.



- 3 Plug the other end of the LAN cable into the LAN cable connection terminal of the host computer.

Connecting Multiple Printers

- To connect multiple printer units to one host computer via USB, assign a different unit number from 1 to 10 to each of the printers.

"Unit number setting" (A page 23)

- To connect multiple printers to the same network, set a different IP address for each printer.

Printer Setting

- "Operation Panel" A page 10
- "Setting using the operation panel" A page 16

Operation Panel

- "Name and functions of parts" A page 10
- "Operation buttons" A page 10
- "Operation Panel Display" A page 11

Setting using the operation panel

- "Initialization" A page 16
- "Initializing printer when attaching the cassette" A page 16
- "Firmware update" A page 17
- "Counter setting" A page 18
- "Operation panel contrast settings" A page 20
- "Buzzer sound setting" A page 22
- "Unit number setting" A page 23
- "Transport mode setting" A page 24

List of Error Codes

Printer (Error Code:0x01000000-0x01040000)

No.	Error Code	Description	Actions (Reference Page No.)
1	0x0102D000	Cards have run out. The card hopper is detached.	Replenish the cards. (A page 25) Install the card hopper. (A page 56)
2	0x0102D100	The printer door is open. The cleaning unit is detached.	Close the door, and press KNB to reset the printer.(A page 16) Install the cleaning unit. (A page 32)
3	0x0102D300 0x0102D400 0x0102D500	The printer is busy.	-
4	0x0102DA00	Preheating is in progress.	Wait until preheating is complete.
5	0x0102DB00	Printer is initializing.	Wait until initialization is complete.
6	0x0102DC00	Offline testing is in progress. Cleaning is in progress.	Wait until the offline test is complete. Wait until cleaning is complete.
7	0x0102DD00	Operation panel is currently in use. The printer is in the transport mode.	- Cancel the transport mode. (A page 24)
8	0x0102DE00	The firmware cannot be downloaded.	Set the printer to the download mode. (A page 17)
9	0x0102FD00	The printer is in the Power Saving mode.	Resetting the printer temporarily cancels the Power Saving mode. (A page 16) The printer resets automatically when the printer driver is used to start printing.
10	0x0102FE00	Password authentication is not complete.	-
11	0x0102RRRR	The printer is not ready.	-
12	0x01039000	Failure occurred during card loading.	Remove the card according to the procedure for the "Error Code: Jam (Hopper) 90". (A page 43)
13	0x01039100	Card jam near the card turn over unit.	Remove the card according to the procedure for the "Error Code: Jam(TurnOver) 91". (A page 44)
14	0x01039200	Card jam near the magnetic encoder.	Remove the card according to the procedure for the "Error Code: Jam (MG) 92". (A page 46)
15	0x01039300	Card jam near the card feed roller.	Remove the card according to the procedure for the "Error Code: Jam (Transfer) 93". (A page 47)
16	0x01039400	Card jam near the card outlet.	Remove the card according to the procedure for the "Error Code: Jam (Discharge) 94". (A page 47)
17	0x01039500	Card jam near the retransfer heating roller.	Remove the card according to the procedure for the "Error Code: Jam (Retran.) 95". (A page 48)
18	0x0103A100	Retransfer film is broken. Retransfer film is not detected.	Repair the retransfer film. (A page 30) Install the retransfer film correctly. (A page 53)
19	0x0103A800	A writing error has occurred during magnetic encoder self-diagnosis.	Check the card specifications.
20	0x0103AD00	An error has occurred during magnetic encoding data writing.	
21	0x0103AE00	An error has occurred during magnetic encoding data reading.	
22	0x0103B000	An incorrect ink ribbon is installed.	Install a correct ink ribbon.
23	0x0103B100	Ink ribbon is broken. Ink ribbon is not detected.	Repair the ink ribbon. (A page 27) Install the ink ribbon correctly. (A page 52)
24	0x0103RRRR	A media error has occurred.	Check the card specifications.

Printer (Error Code:0x01040000-0x02000000)

No.	Error Code	Description	Actions (Reference Page No.)
25	0x01044400	A hardware error has occurred.	Turn off and on the power again. If the same problem recurs, turn off the power and consult our authorized dealers.
26	0x0104AB00	An error has occurred in the mechanical component of the magnetic encoder.	
27	0x0104AC00	A hardware error has occurred in the magnetic encoder.	
28	0x0104C100	A heating roller operation error has occurred.	
29	0x0104C200	The temperature of the bend remedy heating roller or retransfer heating roller is too high.	
30	0x0104C300	An internal 24v instantaneous interruption is detected.	
31	0x0104D800	A hardware error has occurred during initialization.	
32	0x0104F000	The temperature of the retransfer heating roller is too high.	
33	0x0104F100	The retransfer heating roller is faulty.	
34	0x0104F200	The thermistor of the retransfer heating roller is faulty.	
35	0x0104F300	The temperature of the bend remedy heating roller is too high.	
36	0x0104F400	The bend remedy unit is faulty.	
37	0x0104F500	The thermistor of the bend remedy heating roller is faulty.	
38	0x0104F600	The operating ambient temperature of the printer is too low.	Check the temperature. If the same problem recurs within the range of operating ambient temperature, turn off the power and consult our authorized dealers.
39	0x0104F800	The temperature of the thermal head is too high.	Turn off and on the power again. If the same problem recurs, turn off the power and consult our authorized dealers.
40	0x0104RRRR	A hardware error has occurred.	
41	0x01051A00	Printer command is incorrect.	Please consult our authorized dealers.
	0x01052000		
42	0x01052100	A security key has already been set. A new security key cannot be specified.	-
43	0x01052200	Entry does not match the preset security key.	-
44	0x01052300	Security key has not been specified. The security lock function is not enabled.	-
45	0x01052400	Printer command is incorrect.	Please consult our authorized dealers.
	0x01052600		
46	0x01052700	Ink ribbon specification is incorrect.	Ensure that the printer driver's ink setting matches the installed ink ribbon. (Printer Driver Manual page 26)
47	0x01052A00	Printer command is incorrect.	Please consult our authorized dealers.
48	0x01052B00	Magnetic encoding data is incorrect.	Check the card specifications.
49	0x01052C00	IC encoder is not installed.	-
50	0x01052D00	Magnetic encoder is not installed.	-
51	0x01052E00	Optional devices are not installed.	-
52	0x0105RRRR	A command error has occurred.	Please consult our authorized dealers.
	0x010BRRRR		
53	0x0142A200	Retransfer film has run out.	Replace with a new one. (A page 29)
54	0x0142B200	Ink ribbon has run out.	Replace with a new one. (A page 26)

Printer Driver (Error Code:0x02000000-)

No.	Error Code	Description	Actions (Reference Page No.)
1	0x02RRRRRR	Printer is not found.	Check the printer connection.
2	0x0300274D	Printer is not found. Printing using a USB-connected printer cannot be performed via Ethernet (LAN) connection.	Check the printer connection. To print via Ethernet (LAN) connection, disconnect the USB cable from the printer. (A page 56)
3	0x03RRRRRR	Printer is not found. A communication error has occurred.	Check the printer connection.
4	0x04RRRRRR	A communication error has occurred.	Check the printer connection.
5	0x09RRRRRR	A command error has occurred.	Check the computer settings.
6	0x10000103	An error has occurred during magnetic encoding data writing.	Check the card specifications.
7	0x10000201	Contact IC encoding program is not found.	Please consult our authorized dealers.
8	0x10000202	Unable to establish communication with the contact IC encoder.	
9	0x10000203	An error has occurred during contact IC encoding data writing.	Check the card specifications.
10	0x10000301	Non-contact IC encoding program is not found.	Please consult our authorized dealers.
11	0x10000302	Unable to establish communication with the non-contact IC encoder.	
12	0x10000303	An error has occurred during non-contact IC encoding data writing.	Check the card specifications.
13	0x10000401	User program is not found.	Please consult our authorized dealers.
14	0x10000403	An error is returned for the user program.	
15	0x10000501	Magnetic encoding program is not found.	
16	0x10000503	An error has occurred during magnetic encoding data writing.	Check the card specifications.
17	0x10000504	An error has occurred during magnetic encoding data reading.	
18	0x10000505	A magnetic encoding command error has occurred.	Please consult our authorized dealers.
19	0x10000601	End notification program is not found.	
20	0x10000603	An error is returned for the end notification program.	
21	0x10001001	Ink ribbon cannot be recognized.	Ensure that the printer driver's ink setting matches the installed ink ribbon. (Printer Driver Manual page 26)
22	0x10001002	Ink ribbon specification is incorrect.	
23	0x10001003	IC encoder is not installed.	-
24	0x10001004	Magnetic encoder is not installed.	-
25	0x10002000	Printer is not found.	Check the printer connection.
26	0x1000200R	The printer is not ready.	-

Digital Identification Solutions AG

Teckstrasse 52
73734 Esslingen

Germany

Phone: + 49 711 341 689 - 0
Fax: + 49 711 341 689 - 550
Email: support@digital-identification.com

Digital Identification Solutions Pte. Ltd.

#03-01 Hiangkie Industrial Building IV
27 Woodlands Industrial Park E1

Singapore 757718

Phone: + 65 6352 8364
Fax: + 65 6352 8365
Email: support@sg.digital-identification.com

Digital Identification Solutions (Beijing) Co. Ltd.

Lonsdale Center C207, No. 5 Wanhong Road
Chaoyang District, Beijing, 1 00015

P.R. China

Phone: + 86 10 6437 4376
Fax: + 86 10 6433 1278
Email: support@cn.digital-identification.com

Digital Identification Solutions LLC

111 Kiowa Lane
Piedmont, SC 29673

United States of America

Phone: + 1 864 272 1199
Fax: + 1 770 234 5798
Email: support@us.digital-identification.com

Digital Identification Solutions (Branch)

Unit E-20, Dubai Airport Free Zone
P.O. Box 5 46 68

Dubai, United Arab Emirates

Phone: + 971 4 299 4146
Fax: + 971 4 299 4147
Email: support@uae.digital-identification.com

Digital Identification Solutions S. de R.L. de C.V.

Parque Industrial Benito Juárez
Acceso II, No. 5, Bodega No. 1
Querétaro, Qro, C.P. 76130

México

Phone: + 52 442 2171 768 - 0
Fax: + 52 442 2171 768 - 10
Email: support@mx.digital-identification.com

vps ID Systems GmbH

Carl-Zeiss-Strasse 2
76275 Ettlingen

Germany

Phone: + 49 7243 5488 - 0
Fax: + 49 7243 5488 - 11
Email: info@vps.de

www.digital-identification.com