User's Guide model 28517/28527



DECT 6.0

Cordless Telephone

Your new GE telephone system is EXPANDABLE up to 5 handsets (by purchase of optional Model 28507 handset with charge cradle)



www.thehomephones.com




Introduction

Refer to the Important safety instructions section in this book and save them for future reference

at least one phone in your home that isn't cordless, in case the power in your home goes out.

Parts Checklist



2 for 28517xE2 & 28527xE2 3 for 28517xE3 & 28527xE3 4 for 28517xE4 & 28527xE4)

(1 for 28517xF1 & 28527xF1

Installation


Important Installation Guidelines

- Avoid sources of noise and heat, such as motors, fluorescent lighting
- microwave ovens, heating appliances and direct sunlight. • Avoid areas of excessive dust, moisture and low temperature.
- Avoid other cordless telephones or personal computers. • Never install telephone wiring during a lightning storm.
- Never install telephone jacks in wet locations unless the jack is specifically
- Never touch non-insulated telephone wires or terminals, unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.

Installing the phone

Telephone base and charging cradle installation

Install the telephone base and charging cradle(s) as shown below. Make sure that the electrical outlet is not controlled by a wall switch. If you have DSL high speed internet service, a DSL filter is required (not included).



elephone Jack Requirements

use this phone, you need an RJ11C type modular telephone jack, which might look like the one pictured here, installed in your home. If you don't have a modular jack, call your local phone company to find out how to get one installed.



CAUTION: Use only the power adaptor that came with this unit. (Base: IA5075, 100-240Vac/7.5Vdc/500mA) naraer: IA5075, 100-240Vac/7,5Vdc/500mA),

Using other power adaptors may damage the unit.

stalling the Handset Battery

CAUTION: To reduce the risk of fire or personal injury, use only the CCT Tech Global Limited approved model SL-422943 Li-polymer battery, which is compatible with this unit

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.


.. If the battery compartment cover is on the handset, slide the cover to remove. 2. Plug the battery connector securely into the socket inside the handset battery


3. Place the battery and the wire inside the battery compartment 4. Align the cover flat against the battery compartment, then slide it towards the

center of the handset until it clicks into place 5. Charge the handset by placing it in the telephone base or charging cradle. The


battery icon on LCD is scrolling when the handset charges.


For optimum battery performance, charge the battery for 16 hours before use.





Base layout






Repeat: Press to repeat a message or press twice to play previous message. **Play:** Press to play message.

Forward: Press to skip to the next message.

Answer on/off: Press to turn the answering system on and off Volume up/down: Press to adjust the volume during playback and call screening.

Charge Indicator: On when handset is charging.

Power Indicator: On when the base power on.



Soft Key: Press to select a menu item displayed above the key. **Up/Redial:** Press to review the redial list when the telephone is not in use. While in a menu, press to scroll up. During a call, press to increase the listening volume. **Down/CID:** Press to show the CallerID history when the telephone is not in use. While in a menu, press to scroll down. During a call, press to decrease the listening

Delete: Press to delete the last input number or letter. While in a menu, press to return the upper level without making changes.

Flash: During a call, press to answer an incoming call when you receive a call

between speakerphone and handset End/Power off: During a call, press to hang up. During a programming, press to exit

without making changes. Press and hold to power off the handset */Ringer off: Press and hold to set the Ringer off when the telephone is not in use. #/Keylock: Press and hold to set the keylock.

andset Display Items		
Item	Meaning	
Ψ	Turn on when base unit in range. Blinking when base out of range or not subscribed.	
ð	• Turn on when keypad is locked.	
<u> </u>	Scrolling when handset is charging. Display steadily for capacity indication. (Full, 2 blocks, 1block or Empty) Battery frame flash when battery is discharged.	
G	Blinking when there is incoming call. Steady on during a call.	
0(]	Steady on when speakerphone is on.	
	Blinking when there is Voice mail	
Θ	• Turn on when Alarm set	
δ×	Turn on when ringer off set	
æ	Blinking when there is a missing call	
ΙΠΤ	Blinking when there is an internal incoming call or an internal call is heldwhen there is a missing call. Turn on when an internal call is connected.	
60	Turn on when answering machine on. Blinking when there is new message.	
A	Text input in upper case during edit mode.	
	Text input in lower case during edit mode.	

Display language

ou can select change the display language.

+ 1/ſ ¶f]: "LANGUAGE" → [SELECT] 4. [+]/[•]: Select the desired setting

Dialing mode

If you cannot make calls, change this setting according to your telephone line service. The default setting is "TONE"

]/[\P^f]: "DIAL MODE" \rightarrow [SELECT] 4. [†]/[†!]: Select the desired setting

Date and time

1. [MENU]

2. [$\stackrel{+}{\bullet}$]/[$\stackrel{?}{=}$]: "CLOCK & ALARM" \rightarrow [SELECT] 3. [$\stackrel{\cdot}{\bullet}$]/[$\stackrel{!}{\underline{}}$]: "DATE & TIME" \rightarrow [SELECT]

4. Enter the current time, date, month and year by selecting 2 digits. Pressing [2] represent "AM" and pressing [7] represent "PM Example: May 16, 2010 3:15PM Press [0],[3],[1],[5],[7],[1],[6],[1],[0]

 $5. [OK] \rightarrow [6]$ **Note:** You can change date and time display format

Date format

2. [\bigcirc]/[\bigcirc]: "CLOCK & ALARM" \rightarrow [SELECT] 3. $\begin{bmatrix} + \\ \bullet \end{bmatrix} / \begin{bmatrix} \frac{1}{2} \end{bmatrix}$: "SET FORMAT" \rightarrow [SELECT]]: "DATE FORMAT" \rightarrow [SELECT] 4. [👝]/ 5. []/[]: Select the desired setting (MM/DD OR DD/MM) 6. [SELECT] \rightarrow [(1)]

Time format

1. [MENU]]: "CLOCK & ALARM" \rightarrow [SELECT]]: "SET FORMAT" \rightarrow [SELECT] 1/f \P^f 1: "TIME FORMAT" \rightarrow [SELECT]

]: Select the desired setting (12 HOURS OR 24 HOURS) 6. [SELECT] \rightarrow [\checkmark]

Ringer Volume

]: "HANDSET SETTING" \rightarrow [SELECT]

+]/[|]: "HANDSET TONE" \rightarrow [SELECT] 4. $\begin{bmatrix} + \\ - \end{bmatrix}$]: "RINGER VOLUME" \rightarrow [SELECT]

5. [+]/[| ?]: Select the desired setting (VOLUME 1 to 5, ASCENDING and OFF)

6. [SELECT] $\rightarrow [$ (1)

Note: If Ringer off is selected, LCD will show "RINGER OFF" and [\int_X] will turn on.

Ringer Tone

 $\begin{bmatrix} + \\ - \end{bmatrix}/\begin{bmatrix} - \end{bmatrix}$: "HANDSET SETTING" \rightarrow [SELECT]

 $[\cdot, [\overset{+}{\bigcirc}]/[\overset{\P^f}{\bigcirc}]$: "RINGER TONE" \rightarrow [SELECT]

5. [+]/[||]: Select the desired setting (MELODY 1 to 15)

6. [SELECT] \rightarrow [\bigcirc]

Note: If Ringer off is selected, there is no preview during the ringer melody selection.

Answering System Setup (Availiable for 28527)

This section shows you how to set up your answering system to receive incoming calls. Before you begin the set up process, you must turn on the answering system

(on, off and answer only mode) Base Volume

Level 0 is the minimum speaker volume and Level 9 is the maximum.

You can use either: - your own outgoing message

- a pre-recorded outgoing message

Recording Outgoing Announcement

You can record the outgoing message (OGM) through handset microphone

]: "ANSWER MACHINE" \rightarrow [SELECT] : "OUTGOING MSG" \rightarrow [SELECT]

]/[\P :]: "Answer & record" or 'answer only" \rightarrow [Select] 5. [$\stackrel{\mathbf{T}}{\bullet}$]: "RECORD OGM" \rightarrow [SELECT]

6. After a beep sounds, hold the handset about 6 inches away and speak clearly into the microphone (2 minutes max.)

7. Press [STOP] to stop recording 8. Handset shall play back the new record OGM 9. Press [STOP] to stop play and press [) return to idle

Using a pre-recorded Outgoing Announcement If you erase or do not record your own outgoing message, the unit plays a

pre-recorded message asking callers to leave a message. Resetting to a pre-recorded Outgoing Announcement

If you want to use a pre-recorded outgoing message once you record your own outgoing message, you need to erase your own outgoing message.

: "ANSWER MACHINE" \rightarrow [SELECT] : "OUTGOING MSG" \rightarrow [SELECT]]: "ANSWER & RECORD" OR 'ANSWER ONLY" \rightarrow [SELECT]]: "DELETE" \rightarrow [SELECT]

calls with PBX: 6. The handset shall play back the pre-recorded outgoing message 1. Press [**9**], then long press [#] 2. Dial the phone number and press [IQ)) 7. The handset shall display "WAITING" for a few seconds and

create longer pauses

Phonebook

2.[_]/|

Adding record

have a beep sound when finish

Making calls

1. Lift the handset and dial the phone number

To correct a digit, press [CLEAR]

2. Press [()] 3. When you finish talking, press [) or place the handset on the base unit

Adjusting the receiver volume

Speakerphone

Press [) to toggle between handset mode and speakerphone mode

Answering calls

When a call is being received, the LCD and keypad backlight flash rapidly 1. Lift the handset and press [$(\sqrt{3})$] when the unit rings

2. When you finish talking, press [) or place the handset on the base unit

To join the conversation, press $[\hat{\mathbf{Q}}]$ when other handset is on an outside call.

Making a call using the redial list

The last 5 number dialed are stored in the redial list (each 24 digits max) 1. Press [) when handset not in use

2. press [$\stackrel{+}{\bigcirc}$] / [$\stackrel{?}{\bigcirc}$]: Select the desired phone number

Erasing a number in redial list

2. Press [+]/[+]: Select the desired phone number and press [SELECT] to

While mute is turned on, you can hear the other party, but the other party cannot hear you.

2. To return the call, Press [💆] again

For Call waiting or Call Waiting Caller ID service subscriber

2. Press [) / [3. Press $\begin{bmatrix} + \\ \bullet \end{bmatrix}$ / $\begin{bmatrix} \bullet \\ \bullet \end{bmatrix}$ to select "EDIT ENTRY" and press [**SELECT**], then 4. Edit the name if necessary and press [**OK**], then

1. Press [(1))] to answer the 2nd call

Pause (for PBX/long distance service users)

/[\P^{i}]: "PHONEBOOK" \rightarrow [SELECT]

3. $\begin{bmatrix} + \\ 1 \end{bmatrix} / \begin{bmatrix} 1 \end{bmatrix}$: "ADD RECORDS" \rightarrow [SELECT]

4. Enter the name (max. 14 character) \rightarrow [**OK**]

5. Enter the number (max. 24 digits) \rightarrow [**OK**] 6. Select VIP melody and press [SELECT]
7. Record saved and press [Tip] return idle

Character Table for the entering names

Space 1 @ _ # = < > () & € £ \$ ¥ , A B C 2 Á Ä Ç Å Æ

Key Character

Correct the mistake

distance service. When storing a calling card access number and/or PIN in the phonebook, a pause is also needed

Example: If you need to dial the line access number "9" when making outside

Note: A three seconds pause is inserted each time, repeat as needed to

Standby Screen



the handset.

2. Press [$\stackrel{+}{\bullet}$] or [$\stackrel{\bullet}{\underline{\bullet}}$] to select the desired main menu. \rightarrow [SELECT] 3. Press [+] or [\uparrow ?] to select the desired item in sub-menu 1. \rightarrow [SELECT]

4. Press $\begin{bmatrix} + \\ - \end{bmatrix}$ or $\begin{bmatrix} \frac{1}{2} \end{bmatrix}$ to select the desired setting. \rightarrow [SELECT] • This step may vary depending on the feature being programmed

• To exit the operation, press [(1)]









Model 28517/28527 P/N:480-96021-000002






CAUTION: When using telephone equipment, there are basic safety instructions that should always be followed.

IMPORTANT: Because cordless phones operate on electricity, you should have

Before you begin


Make sure your package includes the items shown here.





4 for 28517xE4 & 28527xE4)



Please Fully Charge Before Using!








Find: Press to page all system handsets **Delete:** Press to delete the message during playback or press and hold to delete

Stop: Press to stop message playback.

Handset layout



Intercom: Set up the intercom between handset to handset

Talk/Speakerphone: Press to make or answer a call. During a call, press to switch

Initial settings

 $\begin{bmatrix} + \\ - \end{bmatrix}/[$ $\ref{1}$]: "Handset setting" ightarrow [Select]

Digit input only during edit mode.

]: "ADVANCED SET" \rightarrow [SELECT]

5. [**SELECT**] →[(1)]

 $(0, [\frac{1}{2}])$]: "HANDSET TONE" \rightarrow [SELECT]

\bullet Press the [$\ensuremath{\mathbf{0}}$] on the base to change the answering system status.

Outgoing Announcement When the unit answers a call, an outgoing message is played to callers

3. Press [3]

1. Press [👝 '

3. $\begin{bmatrix} + \\ \bullet \end{bmatrix}$]/ $\begin{bmatrix} \bullet \\ \bullet \end{bmatrix}$]: "DELETE" or "DELETE ALL $\rightarrow [OK]$

4. Press [OK] to confirm

Other Feature during a call

1. Press [💆] during the call

Note: LCD will show "MUTE ON" when mute feature activated

To use call waiting, you must subscribe to call waiting from your service provider. This feature allows you to receive calls while you are already talking on the phone, you will hear a call waiting tone. If you subscribe to both Caller ID and Call Waiting with Caller ID services, the 2nd caller's information is displayed after you hear the call waiting tone on the handset

2. To switch between calls, press [i(j))]

A pause is sometimes required when making calls using a PBX or long

 T^{L}) to select "DELETE ENTRY" and press [**SELECT**], then 3. Press [👝] / [' 4. Press [OK] to confirm delete, then

Programming the Telephone

Make a call from phonebook

Searching by first character

2.[_]/

1. [NAME]

Editing entries

1. Press [MENU], then

Erasing entries

1. Press [MENU], then

]: Select the desired record

2. Press [1] – [9] which contains the character you are searching for

to select "PHONEBOOK" and press [SELECT], then

] to select "PHONEBOOK" and press [**SELECT**], then

3. $\begin{bmatrix} + \\ - \end{bmatrix}$] : Select the desired record if necessary

5. Edit the number if necessary and press [**OK**], then

7. Entries edited and press [7] return to idle

5. Entries deleted and press [📆] return to idle

6. Edit the VIP melody if necessary and press [SELECT], then



Programmable settings You can customize the unit by programming the following features using

Programming by scrolling through the display menus

ullet In some cases, you may need to select from sub-menu 2. ullet [SELECT]


View a phonebook record 1. Press [NAMES] when handset not in use.

Press [CLEAR] to delete the characters or numbers

2. Press $\begin{bmatrix} + \\ - \end{bmatrix} / \begin{bmatrix} - \\ - \end{bmatrix}$ to select desired record

3. Press [SELECT] to view the name and number

IMPORTANT: In order to use this unit's VIP melody features, you must subscribe



Main Menu	Sub-menu 1	Sub-menu 2
	NEW ENTRY	
	LIST	
PHONEBOOK	EDIT ENTRY	
PHONEBOOK	SELECT MELODY	
	DELETE ENTRY	
	DELETE ALL	
	HANDSET NAME	
		RING VOLUME
	HANDSET TONES	RINGER TONE
		KEYTONE
		CONFIRM TONE
	LANGUAGE	CONTINITIONE
HANDSET SETTING	BACKLIGHT TIME	
	DIM MODE	
	AUTO HANG-UP	
	AUTO ANSWER SELECT BASE	
BASE SETTINGS	RING VOLUME	
	RING MELODY	
	SET DATE/TIME	TIME FOMDAT
	SET FORMAT	TIME FOMRAT
0.00.00	32110111111	DATE FORMAT
CLOCK & ALARM	ALARM	
	ALARM TONE	
	ALARM VOLUME	
	CONFERENCE	
	CALL BARRING	
ADVANCED SET	CHANGE PIN	
ADVANCED SET	REGISTRATION	
	DE-REGISTER	
	RESET	
	RECALL TIME	
	AREA CODE	
	DIAL MODE	
	PLAY	
	DELETE ALL	
		ANSWER & RECORD
ANSWER MACHINE	OUTGOING MSG	ANSWER ONLY
(28527)	RECORD MEMO	711VOVVEIL OIVET
	NECORD MEMO	ANSWER & RECORD
	ANSWER MODE	ANSWER & RECORD ANSWER ONLY
		ANSWER OFF
		RING DELAY
	ANS SETTINGS	REMOTE ACCESS
		HS SCREENING

An alarm sounds at the set time for 1 minute once or daily. Alarm can be set for

Important: Set the date and time beforehand

] to select "CLOCK & ALARM" \rightarrow [**OK**]

] to select "ALARM" \rightarrow [**OK**] 4. Press $\begin{bmatrix} + \\ - \end{bmatrix}$ / $\begin{bmatrix} - \\ - \end{bmatrix}$ to select the desired alarm option \rightarrow [OK]

OFF: Turns alarm off, (Go to step 6) ON ONCE: An alarm sounds once at the set time

ON DAILY: An alarm sounds daily at the set time. 5 Set the desired time

6. Alarm set (or turned off) and press [(1)] return to idle

Alarm tone:

You can select from 3 alarm melody

] to select "CLOCK & ALARM" ightarrow [**OK**] T 1 to select "ALARM TONE" \rightarrow [OK] 4. Press [\uparrow] / [\downarrow] to select the desired alarm tone \rightarrow [**OK**]

5. Alarm tone set and press [T) return to idle

The unit will not reveal the PIN to you. If you forget your PIN, please reset your phone

1. Press [MENU], then

2. Press [] / [] to select "ADVANCED SET" and press [SELECT], then

3. Press [$\stackrel{f T}{\bullet}$] / [$\stackrel{f T}{\bullet}$] to select "CHANGE PIN" and press [SELECT], then 4. Input the old 4 digits PIN (Default: 0000) and press [**OK**], then

5. Input the new PIN and press [OK], then

6. Confirm the new PIN and press [**OK**] 7. A beep sound emit and display show "NEW PIN SAVED"

Registering a handset Additional handset

The base unit of this telephone can support up to a total of 4 cordless handsets. The handsets that ship with your main base are pre-registered in the factory. To add or re-register a handset

1. Press [MENU]. the 2. Press [👝] / [] to select "ADVANCED SET" and press [SELECT], then

3. Press [👝]] to select "REGISTRATION" and press [SELECT], then 4. Press [👝] / [

5. Enter you PIN (default PIN: 0000) and press [OK], then 6. Handset will show "WAITING"

7. Press and hold the [$\sqrt{6}$] for 5 seconds, the base LED will blink slowly.

8. Handset will have a long beep when success register

The unit shall able to register with 28507xxx-A only

Deregistering a handset

 $oxedsymbol{\mathsf{T}}^{oldsymbol{ au}}$] to select "ADVANCED SET" and press [**SELECT**], then 2. Press [_] / I

4. Enter you PIN (default PIN: 0000) and press [OK], then

5. Press [) / [] to select the desired handset and press [SELECT], then 6. Selected handset de-registered and press [7) return to idle

<u>Using</u> Caller ID service

to either the standard Name/Number Caller ID Service or Call Waiting Caller ID Service. To know who is calling while you are on the phone, you must

Caller ID records are stored in the order that they are received.

stores the data for the 10 most recent calls. When the 11th call is received the oldest Caller ID record (1st call) is automatically deleted

Reviewing CID Records and call back

As calls are received and stored, the display is updated to let you know how many calls have been received. To scroll CID records:

] to search from the most recent call, or [$\stackrel{+}{\bigcirc}$] to search from

3. To Call back, press [)]
To Exit, press [) return to idle

PIN (Personal Identification Number)

2. $\begin{bmatrix} + \\ - \end{bmatrix}$]: Select the desired record and press [SELECT] to show call details 3. Press [MENU], [$\stackrel{+}{\bigcirc}$] / [$\stackrel{?}{\bullet}$]: "DELETE" or "DELETE ALL" \rightarrow [OK]

4. Press [**OK**] to confirm 5. [📆]

Store a CID record

Delete a CID record

]: Select the desired record \rightarrow [MENU]

]: "SAVE NUMBER" \rightarrow [**OK**] 4. Enter the name and number \rightarrow [**OK**]

Answering system (Available for 28527)

The answering system can answer and record calls for you when you are unavailable to answer the phone.

Important: Only 1 person can access the answering system via handset or base at a time.

When callers leave messages, the unit records the day and time of each __] to select base and press [SELECT], then, message. Make sure the date and time have been set correctly.

Recording capacity (including the outgoing message) The total recording capacity is about 14 minutes. A maximum of 59 messages can be record

Answer mode

There are two answering mode. "ANSWER & RECORD" mode means the answering system will record message when no one pick up the call. "ANSWER ONLY" mode means the answer system will play the outgoing message only but not record the

Press [$oldsymbol{0}$] to change the answering mode. The sequence is "ANSWER & RECORD"

When the answering system is turned on, the LED counter on the base light up with

When the answering system is in answer only mode, the LED counter will show

1. When the answering system answers the call, listen while the caller leaves

When the answering system is off, the LED counter will off.

To select the answering mode

"ANSWER ONLY">"ANSWER OFF"

[🖁 🙃] then change to [🗖]

a message (to determine who is calling).

number of message.

Call screening

On handset: 1 Press [MENU] the

) to select "ANSWER MACHINE" and press [SELECT], then 3. Press [$^{f +}$] / [$^{f i'}$] to select "DE- REGISTER" and press [**SELECT**], then] to select "ANSWER MODE" and press [SELECT], then

4. Press [+]/[+] to select the desired setting, then

5. Press [**SELECT**] and press [) return to idle

subscribe to Call Waiting Caller ID Service.

This unit receives and displays information transmitted by your local phone company. This information can include the phone number, date, and time; or the name, phone number, date, and time.

Receiving CID Records

Storing CID Records (In CID Memory)

2. To speak to the caller, press the [If you are not at home or cannot answer, your telephone's Caller ID memory The answering system automatically stops recording when you activate the handset or pick up an extension phone.

To turn off the call screening, Press [I | woll +] to set the volume off

Playback the messages using the base unit When the new message have been recorded, the message indicator on the

Press [DO]

• If new messages have been recorded, the base plays new messages only, press again to play all messages

Operating the answering system during playback

Operation l vol + Adjust the speaker volume Erase currently play message Repeat message Plav message Stop playback Forward On/Off Switch

Erasing all messages

Long Press [☑] while the unit is not in use

Playback the messages using the handset

"NEW MESSAGE" is displayed

Press (PLAY) when there aew new messages

1. Press [MENU], then

Erasing all messages

4. Press [OK] to confirm

Memo Recording

5. Press [STOP] to stop recording

Secure remote access code

after the message played.

1 Press [MENU] the

2. Press [\mathbf{T}] / [\mathbf{T}] to select "ANSWER MACHINE" and press [**SELECT**], then

4. Press [OPTIONS] to select the operation during playback or

When the new messages have been recorded

The message indicator on the handset flashes slowly To listen to new message:

3. Press [$\begin{tabular}{c} \begin{tabular}{c} \begin{tabular}{c}$

press [STOP] to stop playback

]/[\P^f]: "ANSWER MACHINE" \rightarrow [SELECT]

You can record the memo as a new message through handset.

2. Press [$\overset{\mathbf{T}}{\bullet}$] / [$\overset{\mathbf{I}}{\bullet}$] to select "ANSWER MACHINE" and press [**SELECT**], then

4. When display show "RECORDING", you should move 9 inches from the handset

microphone and speak clearly into the handset microphone. (2 minutes max)

Remote operationUsing a touch-tone phone, you can call your phone number from outside and

2. After the outgoing message finish, Press [\bigstar] and the answering system will

ask you input the remote access code. Please input the remote access code

3. The voice guide will be played if you input the remote access code correctly.

access the unit to listen to messages or change answering system setting.

nessages while away from home. The default PIN is "0000"

To change the PIN code, please refer the PIN section

Using the answering system remotely

3. Press [$^{\bullet}$] / [$^{\bullet}$] to select "RECORD MEMO" and press [**SELECT**], then

3. $\begin{bmatrix} + \\ \bullet \end{bmatrix} / \begin{bmatrix} \bullet \end{bmatrix}$: "DELETE ALL" $\rightarrow [SELECT]$

5. All message deleted and press [(1)] return idle

Remote commands

I can press dial keys to access certain answering system functions.

Keys	Description
[1]	Repeat the Voice Guide
[2]	Play new message
[3]	Play all message
[4]	Skip to the previous message
[5]	Delete the playing message
[6]	Skip to the next message
[7]	Stop message playback
[0]	Set answer mode

If the answering system is off, you can turn it on remotely.

1. Dial your phone number from a touch-tome phone. 2. Let the phone ring 20 times

Keys	Description
[1]	Repeat the Voice Guide
[2]	Play new message
[3]	Play all message
[4]	Skip to the previous message
[5]	Delete the playing message
[6]	Skip to the next message
[7]	Stop message playback
[0]	Set answer mode

Turning on the answering system remotely

- An OGM will be played

3. Press [*] and enter the remote access code within 8 seconds, then 4. You will enter the remote access and press [0] to turn on the answering system

Answering system settings

Number of rings before the unit answers a call You can select the number of rings you want the phone to ring before the nswering system answers a call.

[$\P^{\mathfrak{s}}$]: "ANSWER MACHINE" \rightarrow [SELECT]

/ [\P^{f}]: "ANS SETTINGS" \rightarrow [SELECT] \P^i]: "RING DELAY" \rightarrow [SELECT]

 \P :]: Select the desired setting \rightarrow [SELECT]

If you select Toll Saver (TS) the unit answers after the 3rd ring if there are NEW messages, OR the unit answers after the 5th ring if there are NO new messages. This allows user to access their answerer from another location and then hang up after 4 rings to avoid long distance charges.

Voice mail service

The [] on LCD flash when you receive a new message from your

In order to use this unit's Visual Message Waiting Indicator (VMWI) feature, you must subscribe to this service from your phone company.

ntercom calls can be made between handset

While paging a handset, the paged handset beeps for 1 minute.

If you receive an outside call while talking on the intercom, you hear beep. To answer the call with the handset, long press [*] to switch the outside call

Making an intercom call

[+]/[]: Select the desired handset setting \rightarrow [SELECT]

3. When you finish talking, press [Answering an intercom call

1. Press [1) to answer the page 2. When you finish talking, press [

Handset locator

You can locate a misplaced handset by paging it. 1. Base unit: [🔏] All register handsets beep for 1 minute. 2. To stop paging: Base Unit: Press [🐠] Handset: Press [

Transferring calls

Outside calls can be transferred or a conference call with an outside party

can be made between 2 handsets. 1. During outside call, press [int]

2. $\begin{bmatrix} + \\ - \end{bmatrix} / \begin{bmatrix} - \end{bmatrix}$]: Select the desired handset setting \rightarrow [SELECT] 3. Press [(1)]

2. LCD will show "CONFERENCE"

4. The call will transfer to the paged handset For conference call

1. During the intercom, long press [**int**]

Changing the battery

CAUTION: To reduce the risk of fire or personal injury, use only the CCT ech Global Limited approved model SL-422943 Li-Polymer battery, which is compatible with this unit.

1. Make sure the telephone is **OFF** (not in TALK mode) before you replace the battery. 2. Remove the battery compartment door. 3. Disconnect the cord attached to the battery pack and remove the battery pack

4. Insert the new battery pack and connect the cord to the jack inside the battery

5. Put the battery compartment door back on.

6. Place handset in the base or handset charge cradle to charge. **Allow the** handset battery to properly charge (for 16 hours) prior to first use or when you install a new battery pack. If you do not properly charge the phone, pattery performance will be compromised.

Take sure the battery pack is installed correctly

Fully charge the battery. Check the connections.

Register the handset.

nnected. Check the connections.

off. Adjust the ringer volume.

love closer to the base

Cause/solution

annot operate the answerina l - The remote access is deactivate, activate the remote

support pulse (rotary) dialing

Unplua the base unit's AC adaptor to reset the unit.

Reconnect the adaptor and try again.
The handset has not been registered to the base unit

he base unit's AC adaptor or telephone line cord is no

sconnect the base unit from the telephone line an

onnect the line to a known working telephone. If the

vorking telephone operates properly, contact our service

rsonnel to have the unit repaired. If the working

ider/telephone company. The ringer volume is turne

telephone does not operate properly, contact your ser

- You are using the handset or base unit in an area with

high electrical interference. Reposition the base unit a

use the handset away from sources of interference.

The handset may be out of range of the base.

- The answering system is turned off. Turn it on.

- The message memory is full. Erase unnecessary message

A caller is leaving a message. Wait for the caller finsih

- You are entering the wrong remote access code.

The handset is too far from the base unit. Move closer.

You must use a tone-dial phone. This phone does not

Battery Safety Precautions

• Do not burn, disassemble, mutilate, or puncture. Like other batteries of this type, toxic materials could be released which can cause injury. • To reduce the risk of fire or personal injury, use only the battery listed in the

• Keep batteries out of the reach of children.

• Remove batteries if storing over 30 day

Troubleshooting guide

elephone general use

he unit does not work

not hear a dial tone

landset does not ring

u experience static, noise, or

Answering System (28527 only)

ome of the following information may not apply to your particular product owever, when using telephone equipment, basic safety precautions should Cause/solution always be followed to reduce the risk of fire, electric shock and injury to persons, he handset does not turn on ven after installing battery pack on the handset.

pencil eraser.

including the following: Read and understand all instructions.

Important safety intructions

General product care

• Clean the phone with a soft cloth.

Follow all warnings and instructions marked on the product. . Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

4. Telephones should not be used while you are in a bathtub, shower or pool. Immersion of

he telephone or handset in water could cause an electrical shock 5. Slots and openinas in the cabinet back or bottom are provided for ventilation, to protect it from overheating. Do not block or cover these openings. Do not block the openings by

placing the product on a bed, sofa, rug, or other similar surface. Do not place this produc n a built-in installation unless proper ventilation is provided. 6. Only operate this product from the type of power source indicated on the marking label.

If you are not sure of the type of power supply to your home, consult your dealer or local Plug the adaptor into an easily accessible electrical outlet near the equipment. 8. Do not allow anything to rest on the power cord. Do not locate this product where the

cord will be abused by persons walking on it.

9. Do not overload wall outlets and extension cords as this can result in the risk of fire or). Never push objects of any kind into this product through cabinet slots as they may touch dangerous voltage points or short out parts that could result in a risk of fire or electric

Never spill liquid of any kind on the product. 2. To reduce the risk of electric shock, do not disassemble this product. If service or repair work is required, take it to a qualified serviceman. Opening or removing covers may exposi you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock

3. Do not expose the product to extreme temperatures such as areas near a hot radiator, stove or in a hot car. Do not place product upon other consumer electronic products such as; computer monitors, power amplifiers, etc. Do not place lighted candles, cigarettes, cigars, etc., on the telephone.

Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface 16. Never install or modify telephone wiring during a lightning Never install telephone jacks in wet locations unless the jack is specifically designed for

18. Use caution when installing or modifying telephone lines to prevent electrical shock 9. Under the following conditions, unplug this product from the wall outlet and refer servicing

to qualified service personnel: A. The power supply cord or plug is damaged or frayed B. The product has been exposed to rain or water.

shock. Never spill liquid of any kind on the product.

when the appliance is subsequently used

service provider/telephone company.

If your unit is connected to any additional telepho

If you use a DSL/ADSL service, we recommend

telephone line jack, plug the unit directly into wall ja

connecting a DSL/ADSL filter between the base unit

and the telephone line jack. Contact your DSL/ADSL

The name display service may not be available in

some areas. Contact your service provider/telephon

Other telephone equipment may be interfering with

company, the unit may display the caller's informa

provider/telephone company and subscribe to the

this unit. disconnect the other equipment and try ago

equipment such as a Caller ID box or cordless

Cause/solution

r information is not displayed - You must subscribe to Caller ID service from your

provider for details

information is displayed late - Depending on your service provider /telephone

e 2nd caller's information is not splayed during an outside call

Caller ID (CWID), you must first contact your service

desired service.

• Avoid dropping the handset, as well as other rough treatment to the phone.

• Never use strong cleaning agents, paint thinner, abrasive powder, alcohol,

or other chemical products to clean the unit. Doing so will damage the finish.

Periodically clean the charge contacts on the handset and base with a clean

• Retain the original packaging in case you need to ship the phone at a later date.

To keep your unit working and looking good, follow these guidelines:

at the 2nd ring or later.

Move closer to the base units

E. The product exhibits a distinct change in performance.

C. The product does not operate normally by following the operating instructions.

20. Avoid using a telephone (other than a cordless type) during an electrical storm. There may

be a remote risk of electric shock from lightning.

21. Do not use the telephone to report a gas leak in the vicinity of the leak.

22. Do not place this product on an unstable cart, stand, or table. The product may fall causing serious damage to the product.

23. Only use attachments/accessories specified by the manufacturer. 24. Unplug this apparatus during lightning storms or when unused for long periods of time. IF YOUR PRODUCT UTILIZES BATTERIES, THE FOLLOWING ADDITIONAL

PRECAUTIONS SHOULD BE OBSERVED: 1. Use only the type and size battery(ies) specified in the user manual

Do not use this product if the battery door is removed or missing. Replace batteries that appear to be swollen or have damaged wiring 4. Do not dispose of the battery(ies) in fire. They may explode. Check with local codes for

possible special disposal instructions. 5. Do not open or mutilate the battery(ies). Released electrolyte is corrosive and may cause damage to the eves or skin. It may be toxic if swallowed.

6. Exercise care in handling battery(ies) in order not to short out the battery(ies) with conducting materials such as rings, bracelets, and keys. The batterylies) or conductor may overheat and cause burns.

?. Do not attempt to recharge the battery(ies) provided with or identified for use with this product that are not rechargeable. The battery(ies) may leak corrosive electrolyte or explode

Do not attempt to rejuvenate the batterylies) provided with or identified for use with this product by heating them. Sudden release of the batterylies) electrolyte may occur causing burns or irritation to eyes or skin. 9. When replacing battery(ies), all batteries should be replaced at the same time. Mixing fresh and discharged batteries could increase internal cell pressure and rupture the discharged battery(ies). (Applies to products employing more than one separately replaceable primary

10. When inserting battery(ies) into this product, the proper polarity or direction must be observed. Reverse insertion of battery(ies) may result in leakage or explosion. 1. When inserting battery(ies) into this product, do not twist or pinch the wires or allow wires

13. Discard "dead" battery(ies) as soon as possible since "dead" batteries are more likely to

15. If your product uses rechargeable battery(ies), charge the battery(ies) only in accordance

to become pinched in battery door. .2. If storing over 30 days, remove battery(ies) from this product because the battery(ies) leak and damage the product.

14. Do not store this product, or the battery(ies) provided with or identified for use with this product, in high-temperature areas. Batteries that are stored in a freezer or refrigerator for the purpose of extending shelf life should be protected from condensation during storage and defrosting. Batteries should be stabilized at room temperature prior to use

with the instructions and limitation specified in the User Guide.

Environment

after cold storage

Used equipment must be disposed of in compliance with current environments protection regulations. You should return it to you reseller or dispose of it in an approved recycling centre.



, Do not attempt to open the batteries as they contain chemical substances. In the event of leakage, avoid contact with the skin, eyes and mouth. In the event of contact, rinse the affected part for several minutes in running water. Clean the product with absorbent paper or a dry cloth and contact your reseller for replacement batteries.



This 28517/28527 telephone is compliance with the DECT6.0 standard which operates in the 1.92MHz to 1.93MHz frequency range.

WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD. DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.



THE PRODUCT.

THE LIGHTING TRIANGLE IS A WARNING SIGN ALERTING YOU

HEAD WITHIN THE DO NOT REMOVE COVER (OR BACK), NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO OF "DANGEROUS OUALIFIED SERVICE VOLTAGE" INSINDE | PERSONNEL.

THE EXCLAMATION WITHIN THE TRIANGLE IS WARNING SIGN ALERTING YOU OF IMPORTANT INSTRUCTIONS **ACCOMPANYING** THE PRODUCT.

SEE MARKING ON BOTTOM / BACK OF PRODUCT



FLASH AND ARROW RISK OF ELECTRICAL SHOCK,