

Vacuum Checker VC-35 User manual





Safety Recommendations

ALL WORK SHOULD BE DONE BY QUALIFIED PERSONNEL FAMILIAR WITH THE CONSTRUCTION, OPERATION, AND HAZARDS INVOLVED WITH THE EQUIPMENT.

Mikrotrend products are not authorized for use in safetly-critical applications where a failure of the product would reasonably be expected to cause severe personal injury or death. Buyers represent that they have all necessary expertise in the safety and regulatory ramifications of their applications, and acknowledge and agree that they are solely responsible for all legal, regulatory and safetly-related requirements concerning their products and any use of Mikrotrend products in such safetly-critical applications, notwithstanding any applications-related information or support that may be provided by Mikrotrend.

Mikrotrend products are neither designed nor intended for use in military/aerospace applications or environments.

Buyers acknowledge and agree that any such use of Mikrotrend products which Mikrotrend has not designed as military-grade is solely at the Buyers risk, and they are solely responsible for compliance with all legal and regulatory requirements in connection with such use.

Important User Information

This guide has been developed as a quick reference tool to Mikrotrend d.o.o. industrial automation controls and factory assemblies. Because of the variety of uses for the products described in this publication, those responsible for the application and use of these products must satisfy themselves that all necessary steps have been taken to assure that each application and use meets all performance and safety requirements, including any applicable laws, regulations, codes, and standards. Factory provided user manuals and technical documentation should not be solely relied on for those purposes. Mikrotrend d.o.o. reserves the right to change the features or characteristics of its products at any time. Therefore, the information contained in this publication is subject to change at any time without notice. The illustrations, charts, diagrams, and layout examples shown in technical documentation are intended solely as examples. Since there are many variables and requirements associated with any particular installation, Mikrotrend d.o.o. can not assume responsibility or liability (including intellectual property infringement liability) for actual use based upon the examples shown in this publication.

Performance Data

Performance data given in technical documentation is provided only as a guide for the user in determining suitability and do not constitute a performance warranty of any kind. Such data may represent the results of accelerated testing at elevated stress levels, and the user is responsible for correlating the data to actual application requirements. ALL WARRANTIES AS TO ACTUAL PERFORMANCE, WHETHER EXPRESS OR IMPLIED, ARE EXPRESSLY DISCLAIMED.

X-Ray Concerns

IEEE Switchgear Committee, Spring 2008.

A few facts should be mentioned:

At all voltages X-ray emission is zero when the interrupter is in the closed position.

At MV voltages (up to 38kVrms) X-ray emission is zero or negligible.

Generally for MV circuit breakers significant X-rays could only be generated at test voltages exceeding 38kV. However once the system volts gets to much higher voltages such as 145kV then the possibility of X-ray emission becomes significant, although not generally a safety issue. The real issue for designers is that it is possible for the interrupters to irradiate their local surroundings over a long period, and this may have a detrimental effect on polymeric components or electronics mounted in the circuit breaker locally to the interrupters.

Contents

Safe	ety Recommendations	2
Important User Information		
Per	formance Data	2
X-Ra	ay Concerns	2
1.	Óverview	4
2	Connection and use	5
∠ .		•
2. 3.	Technical specifications	6
2. 3. 4.	Technical specifications Troubleshooting and maintenance	6 6
2. 3. 4. 5.	Technical specifications Troubleshooting and maintenance Important notice	6 6 8

1. Overview

Continuous adjustable High voltage source 1...37kVDC Designed to be used in Industrial and Power substations environment Multi purpose testing of Vacuum Circuit breakers, cable insulation etc... True ammeter reading (guard screened test leads) Single scale voltmeter Overload protected Line variations independent Built in battery Detachable high voltage cable with integrated cable storage space Rugged, portable and reliable, simple tu use Acoustic and visual signalisation when operated

Vacuum circuit breakers do not last forever.

Air is leaking inside vacuum chamber, dirt on the poles and on the exterior surface of the interrupter can reduce insulation, the mechanics of the breaker can become misaligned and the distance between the poles is no longer adequate.

Any of this will change flashover point of Vacuum Circuit Breaker.

VC-35 is portable High voltage DC source for generation of negative voltages from **0...37kVDC**. It is designed for shop an on-site testing of Vacuum Circuit Breakers, cable insulation etc... High Voltage is generated by high voltage transformer and a full wave capacitive voltage multiplier

with silicon rectifiers. Accurate voltage measurements are made directly at the output and current measurements are taken in the return leg.

Test leads are compensated for leakage currents with cable guard screen for true ammeter reading.

Safe discharging of both the test object and the high voltage transformer occur whenever the high voltage is turned off. **VC-35** can be used powered from it's own battery power supply, approx. 15 minutes with full battery charge.

VC-35 is packaged in a handy carrying case and well suited for field applications.



Figure 1: VC-35 Measuring principle

2. Connection and use





WARNING: HANDLING HIGH VOLTAGES!

TO PREVENT ELECTRIC SHOCK OR INJURY DURING MEASUREMENT DO NOT TOUCH CABLE CLIPS WITH HANDS

ALL WORK SHOULD BE DONE BY QUALIFIED PERSONNEL FAMILIAR WITH THE CONSTRUCTION, OPERATION, AND HAZARDS INVOLVED WITH THE EQUIPMENT.

- 1. The Vacuum Circuit Breaker must be disconnected from High Voltage bus-bars and in OPEN position.
- 2. Prior to connecting mains, VC-35 power switch must be switched OFF.
- 3. Connect the power cable (100...240 VAC).
- 4. Set the "VOLTAGE ADJUSTMENT" into the position "MIN".
- 5. At first set ammeter range x100.
- 6. Connect the H.V. cable to VC-35.
- 7. Connect the yellow wire of H.V. cable to system ground.
- 8. Connect the red connector (negative) of H.V. cable to one pole of the Vacuum Circuit Breaker.

- 9. Connect the black connector (positive) of H.V. cable to other pole of the Vacuum Circuit Breaker.
- 10. Turn the "POWER" switch ON. Yellow lamp "HIGH VOLTAGE" shall light-up. Buzzer shall beep.
- Slowly increase voltage using "VOLTAGE ADJUSTMENT" knob until you reach test voltage specified for Vacuum Circuit Breaker. Read the current on microammeter. For guidance on allowed leakage currents refere to vacuum chamber manufacturer's specification and IEC 694 or ANSI C37-06 standards. When the current through the Vacuum Circuit Breaker is greater then 0,5mA, VC-35 will automatically power-off. "OVERLOAD" lamp shall light-up.
- 12. VC-35 may be operated from built-in battery supply approx. 15minutes. For full output voltage the battery must be fully charged.
- Charging battery: Leave the power cable of VC-35 connected for 14 hours or more. The "POWER" switch during charging may be in "OFF" position.

3. Technical specifications

The specifications are valid at nominal input voltage, ambient temperature between 0...+50 °C and relative humidity less then 90%.

Personal safety:	Maximum transient current through the external load is 10 mA. Maximum discharge time for internal high-voltage circuit is 0,5 sec.		
Output voltages:	037 kVDC, load > 100 Mohm, Ripple 5% max.		
Output current:	0,5 mA max, limited		
Voltmeter range:	050kV		
Ammeter range:	x1 05 uA		
-	x10 050 uA		
	x100 0500 uA		
Signalisation:			
RED lamp:	Overload (>0,5mA)		
YELLOW lamp:	High Voltage "ON"		
Sound signal:	High Voltage "ON "		
Working temperature range:	0+50 ℃ (32 ℉+122 ℉)		
Storage temperature range:	-40+70 °C (-40 °F+158 °F)		
Relative humidity:	less then 90%, non condensing		
Mains voltage:	100240V, 50/60Hz, 2A max.		
Built-in battery:	Sealed Gel Lead Acid Rechargable 12V, 2Ah.		
Battery charger:	Constant voltage, 14 hours full charge.		
Dimensions:	Alu-case, 210x335x460 mm		
Weight:	7,5Kg Instrument alone		
-	9Kg with battery and connection cables		
High voltage cable lenght:	1,6 m		

4. Troubleshooting and maintenance

1. Maximum voltage can not be reached:

1. Check battery. If necessary recharge battery. Replace battery every 5...8 years.

2. Check High Voltage connector for dirt and or moisture. Clean both sides of connector (on the case and on the cable) with soft tissue and isopropil alcohol. Do not use other solvents.

3. Check ambient air humidity. When higher than 90%, full output voltage may not be reachable. Periodically replace desiccant (Silica-Gel) on the bottom of instrument case or when necessary.



Figure 3: Battery compartment



Figure 4: High voltage cable assy

5. Important notice

Mikrotrend d.o.o. and its subsidiaries reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete.

All products are sold subject to Mikrotrend's General terms and conditions of sale

(<u>http://www.mikrotrend.com/PDF/Selling Policy GT05c.pdf</u>), supplied at the time of order acknowledgment. Mikrotrend warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with Mikrotrend's standard warranty. Testing and other quality control techniques are used to the extent Mikrotrend deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

Mikrotrend assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using Mikrotrend components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

Mikrotrend does not warrant or represent that any license, either express or implied, is granted under any Mikrotrend patent right, copyright, mask work right, or other Mikrotrend intellectual property right relating to any combination, machine, or process in which Mikrotrend products or services are used.

Information published by Mikrotrend regarding third-party products or services does not constitute a license from Mikrotrend to use such products or services or a warranty or endorsement thereof.

Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from Mikrotrend under the patents or other intellectual property of Mikrotrend.

Reproduction of information in Mikrotrend data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. Mikrotrend is not responsible or liable for such altered documentation. Resale of Mikrotrend products or services with statements different from or beyond the parameters stated by Mikrotrend for that product or service voids all express and any implied warranties for the associated Mikrotrend product or service and is an unfair and deceptive business practice. Mikrotrend is not responsible or liable for any such statements.

Mailing Address:

MIKROTREND d.o.o.

Technology park Zagreb D.Golika 63 10000 ZAGREB CROATIA, EUROPE Tel: +385 1 3667 114 Fax: +385 1 3667 115 GSM: +385 98 504 838 e-mail: mikrotrend2000@yahoo.com www.mikrotrend.com