# Digital FM Broadcast Exciter User's Manual

# **Please notice this:**

- 1. Read Safety notice first.
- 2. A 50  $\Omega$  dummy load or antenna and cable must be connected before turning power on , Avoid water going into connecters and cable.

**3.** Please read System Control Logic section to fully understand how the system works.

4. Please read Power On Sequence.

# Contents

1 Safety Notice	4
2 Overview	
3 Technical Specifications	6
4 Test Instrument	7
5 Test And Maintenance	8
6 Functional Block Diagram	10
7 Panel Function Description	11
8 Power On sequence	14
9 System Control Logic	15
10 Direction For Software Use	17
11 Failures Check	26

# **1** Safety Notice

- 1.1 Please read the following safety points, in order to avoid the accidents and prevent the connecting machines to be broken.
- 1.2 Only the qualified maintenance workers can operate the service.
- 1.3 Prevent the fire and the bodily injury
  - a. Use the proper wire. If not, it will cause the fire and the bodily injury;
  - b. Ensure the machine connect the ground. Please confirm whether the machine has connected the ground, through the wire and the lead, to prevent the electric shock.
  - c. Use the proper fuse. Please use the stipulated type and rating fuse.
  - d. Provide good ventilation. This machine adopts the natural convective radiation. Fix it correctly to keep it radiating well.
- 1.4 Please don't disassemble and repair by yourself when it's broken down. Please send to the professional service department to solve the problems.

**CAUTION:** Please don't assemble the machine in the moist environment;

Please don't assemble the machine in the easy exploding

environment;

Please don't repair by yourself.

1.5 If you have any other questions, please connect with us.

:

:

:

## 2 Overview

ZHC618F(D) series digital FM broadcast exciter is an excellent digital product that owns the highest and newest technology. The whole machine adopts the latest digital signal processing and the direct digital synthesized technology. This advantage provides us with excellent hearing feature which can match to CD audio quality.

ZHC618F(D) series digital FM broadcast exciter is composed of six parts: main control and display, audio interface, digital signal processing, power amplifier, remote control and power supply. It is fitted in the 2U, 19 inches standard case. All the output and input signal is lead from the back panel.

ZHC618F(D) series has password protected function to protect some important parameters from accidentally or incidentally changing. It also provide with LOCK-IN/LOCK-OUT and remote control functions.

ZHC618F(D) exciter has analog and AES/EBU audio interface and SCA interface. It is a full band FM exciter from  $87.00 \sim 108.00$ MHz step 10kHz.

ZHC618F(D) series digital FM broadcast exciter has two frequency synchronous port with which a synchronous FM broadcasting network can be built.

# **3** Technical Specifications

Electrical Specification

Ø	RF Frequency	87.00MHz 108.00MHz Step 10kHz
Ø	Output Power	Continuous adjustable to setting power
		Power Accuracy <=10%
Ø	Power stability	<±3%
Ø	Output Impedance	50Ω
Ø	RF Output connector	N-50K
Ø	SFDR	<-70dB
Ø	Residual Amplitude Modulation	<-50dB
Ø	Carrier Frequency accuracy	±200Hz
Ø	Frequency Stability:	1 x <b>10<sup>6</sup></b>
Ø	Modulation Deviation	0~120KHz (100% ±75kHz)
Ø	Pilot Frequency	19kHz±0.1Hz
Ø	Pilot Amplitude	0~12KHz (10% 7.5K)
Ø	Analog Audio Input Impedance	$600\Omega$ Balance
Ø	Audio Input Level	-12dBm~+8dBm, Step 0.1dBm
Ø	Digital Audio Input Impedance	110 $\Omega$ Balance (optional)
Ø	Digital Audio Input Level	$0.2 \sim 10 \text{Vpp}$ (optional)
Ø	Digital Audio Sample Rate	30kHz~96kHz (optional)
Ø	Audio gain	-15dB~+15dB step 0.1dB
Ø	Pre-emphasis	0μs, 50μs, 75μs
Ø	LR Channel Level Difference	<0.1dB (100% Modulation)
Ø	Frequency Response	$<\pm 0.1$ dB , 30Hz $\sim$ 15000Hz
Ø	THD	<0.1%, 30Hz~15000Hz
Ø	Stereo Separation	$>50$ dB (type.), 30Hz $\sim$ 15000Hz
Ø	SNR	>70dB(type.) , 1kHz 100% Modulation
Ø	Power Supply	□ AC180V~AC260 47Hz~63Hz
Ø	Heat dissipation	Forced ventilation

Physical Specification

Ø	Casing Size	2U、19Inch;
Ø	Weight	18kg
Ø	Ambient temperature	$5^{\circ}C \sim +40^{\circ}C$
Ø	Relative Humidity	<95%
Ø	Altitude	<4500m

# 4 Test Instrument

Number	Name	Туре	Specification	Manufacturer
1	Universal Counter	53132A	225MHz, 12 Word	Agilent
2	Spectrum Analyzer	ectrum Analyzer 8560E 30Hz~2.9GHz		HP
3	Digital	TEK2260	200MHz	Tektronix
	Oscilloscope	12112200	200101112	
4	FM Demodulation	FMAB	100KHz~5.6GHz	RS
5	Stereo Decoder	FMAB	100KHz~5.6GHz	RS
6	Audio Analyzer	P1DD	Analog and digital	Audio Precision

## **5** Test and Maintenance

As a high performance FM exciter designed with digital technology (for example: software modulation, pre-emphasis, digital frequency synthesis...), the unity of some technical specifications are guaranteed. To test its technical specification, higher performance instruments must be used. If test result is below applied standard, please send it to professional maintenance department or the producer.







- a. Connect test instrument to exciter according to Figure 1;
- b. Make audio analyzer output 400Hz, 0dBm;
- c. Finely adjust audio output level until demodulation reaches 75KHz (100% modulated);
- d. Scan audio output frequency from 30Hz to 15kHz, record frequency response ( $<\pm 0.1$ dB) and distortion (< 0.1%);
- d. Scan audio output frequency from 30Hz to 15kHz, record stereo separation (typical > 50dB);

f. Set audio analyzer to 1kHz, exciter pre-emphasis to 50µs, demodulator to 50µs de-emphasis, adjust audio analyzer power output until demodulation reaches 75KHz, record mono SNR(>75dB) and stereo SNR (>70dB).

Ø Carrier Frequency Accuracy Test





- a. Connect the test instrument to exciter according to Figure 2;
- b. The test carrier frequency accuracy  $(\pm 200 \text{Hz})$ .

Ø Harmonic Suppression



Figure 3

- a. Connect the text instrument to exciter according to Figure 3;
- b. Record harmonic suppression relative to carrier (<-60dB).

# 6 Functional Block Diagram



# 7 Panel Function Description

## 7.1 10W/30W/50W/100W Front panel



Figure 5

1—— LED Indicator

ON	power supply indicator;
R.F.	RF power out;
AUDIO	stereo indicator;
REMOT	'E remote control is on.
TEMP	temperature alarm.
V.S.W.R	VSWR is high.
GENER	AL PA Voltage or PA Current alarm;
RF MU	TE inter-lock in or excessive forward power or
	excessive reflect power.
2 — LCD d	isplay screen

3 — Operation button

▲ up or increase

- enter
- ▼down or decrease
- 4—— Power switch

## 7.2 10W/30W/50W/100W Back panel





- 1 AC Socket with 5A Fuse
- 2 Ground pole
- 3— RS232

PIN 2----TX; PIN 3----RX; PIN 5----GND;

- 4 Fan
- 5 RF Output
- 6 SCA input (optional) or

327.68MHz Clock Input (External Synchronization)

- 7 24.32MHz Clock Input (External Synchronization)
- 8 AES/EBU Input (optional)

1----GND

2----positive

- 3----negative
- 9 Left Analog Audio Input

1----GND

- 2----positive
- 3----negative

10 — Right Analog Audio Input

1----GND

2----positive

3----negative

- 11 RF Test Port
- 12— RS485

PIN 2----A;

PIN 3----B;

# PIN 5----GND;

- 13-- Interlock out
- 14-- Interlock in

## 8 Power On Sequence

- 8.1 Open the package, check appearance, switch, key button, sockets, and interface ports on front and rear panels.
- 8.2 Turn power switch on the "OFF" position and connect power cord to power source.
- 8.3 Connect RF out port to a 50 Ohm dummy load or antenna through a cable.
- 8.4 If it is used in synchronous broadcast network, ensure that 24.32MHz, and 327.68MHz external synchronous clock should be connected
- 8.5 Turn power on.
- 8.6 Set RF logical control (see detail in System Logic Control).
- 8.7 Set RF power.
- 8.8 Set parameters such as frequency, digital/analog audio input select, stereo/mono select, audio gain, modulation deviation, pre-emphasis.
- 8.9 Turn on RF power

#### 9 System Control Logic

#### **③ RF output control**

RF output is controlled by three switches: interlock-in (called INTERLOCK), RF Switch in main menu and period control switch in RTC menu.

**Interlock-in:** when exciter received an interlock-in signal (logic low signal), it turns RF power off immediately in any circumstance.

**RF Switch:** when RF Switch is off, turn off RF power.

When RF Switch is on and Period Control is disabled, turn RF power on to setting power.

When RF Switch is on and Period Control is enabled, RF power is controlled by Period Control function (see Period Control).

**Period Control**: when interlock-in is logic high or float, RF Switch is on and Period Control is enabled, the control method is as follow:

The system reads current time through RTC and check whether current time is falling into any of the three periods. If yes; turn on RF power to its setting power. Else turn off RF power. A period is invalid if start time is greater than or equal to end time. Current time will never fall into an invalid period. If three periods are all invalid, turn RF power off for ever.

#### **③ Remote Control**

Remote control is set in <SET> menu. When remote control is enabled, remote LED on front panel is lit and parameters are controlled by remote host and can not be changed locally except "Remote" flag in <SET> menu. Updated parameters will be automatically stored in EEPROM.

When remote is disabled, remote host can not control over the exciter but locally does. Updated parameters will be automatically stored in EEPROM.

RS232 or RS485 are used for remote control. Before enabling remote control, baud rate and device address should be properly set.

#### **©** Change RF frequency

After RF frequency changed, RF power will drop to 0 first, and then increase to its setting power.

#### **③** Time Period Modification

It is suggested that disable Period Control before correcting date and time or changing period's start and end time to avoid instantaneous undesired RF power on and off.

#### **③** System Protection

In some urgent cases such as exceeded forward power, reflect power, current and over temperature, system will reboot. If it is failed successive 5 times, the system will automatically turns off RF power and just acts display function.

System will also shut down when some main parameter can not be set such as frequency, digital/analog audio select.

## **10** Direction For Software Use

#### **10.1 General description**

#### **?** Buttons

#### ▲ ♥ ●

- $\blacktriangle$ : Up or increase, when pressed and held for a longer time, it speeds up.
- $\mathbf{\nabla}$ : Down or decrease, when pressed and held for a longer time, it speeds up.
- •: enter, used to select menu and enter edited parameter.

#### ? Menu classification

There are three kinds of menus: display menu is display only menu; select menu used to select sub menu or goes back to its main menu; edit menu used to enter parameters or configure the system.

How to enter parameter

Just scroll highlight bar to desired edit item and press  $\bullet$ , use  $\blacktriangle$  or  $\lor$  to change parameter and press  $\bullet$  again to save it. Some important parameter or operation may need further confirmation. In this case, a "Y" or "N" will appear after editing at the end of the edit line. Use  $\blacktriangle$  or  $\lor$  to select "Y" (confirm) or "N" (cancel) and press  $\bullet$ to save updated parameter or cancel it.

Parameter can not be modified locally when remote is enabled except "Remote" itself.

#### ? Return to Main Menu

When there is no operation (press button) for a long time, system will return to its main menu automatically with LCD backlight off. Not saved updated parameter will be replaced with its old value.

#### ? LCD backlight

LCD backlight will be automatically turned off when there is no operation for a long time and turned on immediately when any key is pressed.

# 10.2 System Boot up



During the system boot up, company logo is displayed and all LED on front panel blinks 4 times (power LED is on). After system booting up, it enters to its main menu.

# 10.3 Main Menu

IBO E	Inc. outrout	A CONTRACTOR OF
100	FWD POWER:	0.0W 79.0%
75	REL POWER:	0.0
50	DUD GOINS	
30 E	[VIEW] [	STĂŤŬSJ ČŠEŤĴ
ZOE		

Audio bar is located on the left side of the screen, it indicates dynamic modulation deviation. 100% denotes 75KHz modulation.

RF Switch:	RF switch, select ON or OFF.
FWD Power:	forward power, display only.
RFL Power:	reflect power, display only.
Frequency:	RF frequency, display only.

Aud Gain:	left and right audio gain, display only.
[View]	parameter data browse menu, see [View] menu.
[Status]	system running status, see[Status] menu.
[Set]	parameter setting menu, see [Set] menu.

# 10.4 View Menu



# All items in [View] menu are display only.

FWD Power:	forward power.
RFL Power:	reflect power.
Frequency:	RF frequency.
Modu Dev:	modulation deviation.
Aud Gain:	audio gain.
Aud input:	audio input and modulation mode, see [Set] menu.
Pre-emphasis:	pre-emphasis.
Pilot Dev:	pilot deviation.

Amp Voltage:	power voltage of amplifier
Current:	current of amplifier.
Temperature:	temperature of amplifier.
Baudrate:	baud rate used for remote control.
Addr:	device address used for remote control.
Remote:	remote control switch.
Date:	date.
Time:	time.
Period Control:	period control.
[EXIT]	return to its parent menu.

## 10.5 Status Menu



- RF output: Refer to control logic section.
   Normal: RF output is in normal status.
   Off: RF power is off.
   Drop: RF power can not achieve to its setting power.
- System: indicate system errors. Contact equipment provider when error happens.
- Lockin: refer to system control logic section.
   Unlocked: system is not locked.
   Locked: system is locked by external device, RF power is off.
- Fwd Power
  - Normal: forward power is normal.
  - Warning: forward power is higher than setting power.
  - Protected: forward power is too high, RF power is turned off.

Rfl Power

Normal: reflect power is normal. Warning: reflect power is high, may cause RF power drop. Protected: reflect power is too high, RF power is turned off. L Amp Current Normal: amplifier current is normal. Warning: amplifier current is high, may cause RF power drop. Protected: amplifier current is too high, RF power is turned off. L Amp Voltage: device address used for remote control. Normal: amplifier voltage is normal. Warning: amplifier voltage is high, may cause RF power drop. Protected: amplifier voltage is too high, RF power is turned off. Temperature: remote control switch. Normal: temperature is normal.

Normal: temperature is normal. Warning: temperature is high, may cause RF power drop. Protected: temperature is too high, RF power is turned off.

# 10.6 SET Menu

130 5	3 SET	
100	[ [BROADCAST]	
TWO F	I LEENEKHLJ	
75	[ ÉPÁŠŚWORD]	
30	[ [PRESET]	
201	LEXII	
NO. W. W.		

Audio bar is located on the left side of the screen, it indicates dynamic modulation deviation. 100% denotes 75KHz modulation.

Broadcast:	broadcast parameter setting, see "Broadcast" menu.		
General:	system parameter setting, see "General" menu.		
RTC:	date, time and period control setting menu, see "RTC" menu.		
Password:	change password menu, see "Password" menu.		
Preset:	load default parameters, see "Preset" menu.		
[EXIT]	return to its parent menu.		

#### ► "BROADCAST" Menu

130 E 100 75 50 30 20	FWD       POWER       WWWWWWWWWWWWWWWWWWWWWWWWWWWWWWWWWWWW
190 100 75 50 30 20	MODU DEV: 75.00 KHUR MODU DEV: 700 KHUR AUDD GAINN R: 00 ter LUR AUDD GAINN R: 00 ter LUR AUDD HNPUHASIS: 7.5 KHUR PHLOT DEV: 7.5

FWD Power:	forward power, display only, used to watch real output power
	when adjusting output power percentage.
RFL Power:	forward power, display only, used to watch real output power
	when adjusting output power percentage.

- Power Set:set the percentage of output power.Frequency:set RF frequency.
- Modu Dev: set modulation deviation.
- Aud Gain L: set left audio gain.
- Aud Gain R: set right audio gain.

Audio Input: D/Mono L: mono modulation, audio from left digital channel.
D/Mono R: mono modulation, audio from right digital channel.
D/Ster LR: stereo modulation, audio from digital channel.
A/Mono L: mono modulation, audio from left analog channel.
A/Mono R: mono modulation, audio from right analog channel.
A/Ster LR: stereo modulation, audio from analog channel.
Pre-emphasis: select pre-emphasis.
Pilot Dev: set pilot deviation.
[EXIT] return to its parent menu.

#### ► "GERNERAL" Menu



Baud Rate:	select baud rate for remote control.
Address:	set device address for remote control.
Remote:	enable or disable remote control.
[EXIT]	return to its parent menu.

## ► "RTC" Menu



Date:	Set or display date.
Time:	set or display time.
Period Control:	enable or disable period control.
ON Period1:	set first period.
ON Period2:	set second period.
ON Period3:	set third period.

[EXIT] return to its parent menu.

#### ► "PRESET" Menu



[Preset] menu is used to load default parameters. Make sure that some parameters may need to be adjusted after Preset according to your broadcasting requirement.

Select [Sure] to load default parameters. Select [cancel]to return to Main menu.

Preset default parameters				
Frequency:	97.50 MHz			
Power Percentage:	0.0%			
Audio Gain:	0 dB			
Audio Input:	Digital audio, Stereo modulation.			
Pre-emphasize:	50 us			
Modulating deviation:	75.0 KHz			
Pilot deviation:	7.5 KHz			
Delay time:	0 us (only in synchronous exciter)			
AGC:	enable			
Baud rate:	9600 bps			
Address:	0			
Remote:	OFF			
Period Control:	OFF			
Password:	000000			

#### ► "PASSWORD" Menu



Change password: enter new password in "New" edit box, and enter the same new password again in "Again" box. If two enters are the same, it will display "change password successful", else display "Different password, try again!". Just [EXIT] if do not want change password. The initial password if "000000".

Password Control: Enter [Set] and [Preset] menu need password checking when Password Control is "ON"; there is no password check when Password Control is "OFF".

[EXIT] return to its parent menu.

#### ► PASSWORD CHECK Menu



Check password before entering [Set] and [Preset] menu When Password Checkl is enabled. Enter password in "Password" first, and then select [Sure]. If correct password is entered, it will enter to desired menu. Else it will display "Wrong password, try again".

Select [Cancel] to give up password enter and return to its previous menu. The initial password is "000000", if need a new password, refer to "Password" menu.

# 11 Failure Check

11.1 Turn on the power supply, if the equipment doesn't work, it may

- I The fuse is broken: change the fuse;
- I The plug is not inserted tightly or contacted fault: insert the plug tightly;
- Synchronous clock source is not connected: check the wire to ensure it has been connected the clock source correctly. (only used in the synchronous cover network)
- 11.2 No audio output
- I The source of audio signal is not connected: check the wire to ensure it has been connected correctly;
- Choose the wrong source of the signal: please choose the correct source of signal, digital or analog.
  - If there is any other problem that can not be solved, please contact with us